

90mm

90mm

90mm

90mm

90mm

90mm

90mm

150mm

**User Guide**  
AC1200 Gigabit Dual Band Wi-Fi Router

**1. Schematic Diagram of Router Connection**

**Wireless connection**  
Connect the Device: The client-side connects to router Wi-Fi. The default username and password are on the bottom label.

**Wired connection**  
Connect the PC and router via LAN1, LAN2 or LAN3 with cable.

**Use DSL or PON for Internet connection**  
Community broadband Internet access.

**2. Configure the Internet**

**2.1. Configure the Router in Bridge Mode**  
After the connection is completed, use a mobile phone or computer to search for the Wi-Fi name 2.4G SSID or 5G SSID on the label at the bottom of the device, enter the password, connect to the Wi-Fi, and then the Internet access is available.

**2.2. Configure the Router in Gateway Mode**  
**2.2.1. Dial-up for Internet Access:**  
After the connection is completed, use a mobile phone or computer to search for the Wi-Fi name 2.4G SSID or 5G SSID on the label at the bottom of the device and enter the corresponding password to connect to Wi-Fi. Open the mobile phone or computer browser, visit the 192.168.10.1 website, enter the default username and default password on the label at the bottom of the device, and enter the router management interface.

**2.2.2. Static IP for Internet Access**  
In the router management interface, click Network—Network Settings—WAN Connection, select Static IP in WAN Access Type, fill in the IP Address, Subnet Mask, Default Gateway and DNS1 (DNS2 and DNS3 are optional) and click Save&Apply, wait for the device to save the settings and Internet access is available. The Wi-Fi name is the default name (on the label at the bottom of the device).

**2.2.3. Dynamic IP for Internet Access**  
In the router management interface, select Network—Network Settings—Network Scan, click Site Survey, select the uplink signal, click Next.

**2.3. Configure the Router in Repeater Mode**  
In the router management interface, select Network—Network Settings—Network Scan, click Site Survey, select the uplink signal, click Next.

**Operating Mode**

**WAN Settings**  
WAN Access Type: PPPoE  
User Name: \_\_\_\_\_  
Password: \_\_\_\_\_

**Static IP for Internet Access**  
WAN Access Type: Static IP  
IP Address: \_\_\_\_\_  
Subnet Mask: \_\_\_\_\_  
Default Gateway: \_\_\_\_\_  
DNS 1: 192.168.1.1 (Default DNS Server)  
DNS 2: \_\_\_\_\_  
DNS 3: \_\_\_\_\_

**Dynamic IP for Internet Access**  
WAN Access Type: Dynamic IP (DHCP Client) for Internet access. The Wi-Fi name is the default name (on the label at the bottom of the device).

**Repeater Mode**  
WAN Access Type: Repeater  
WAN Access Mode:  Channel Bonding  Pre-Shared Key  
Pre-Shared Key: \_\_\_\_\_  
Pre-Shared Key: \_\_\_\_\_

**Operating Mode**  
This page provides a list of available operating modes for the router. You can click on the mode you want to use to go to the configuration page for that mode.

Mode	SSID	Mode	Mode	Mode	Mode
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1
Dynamic IP	192.168.10.1	Static IP	192.168.10.1	Static IP	192.168.10.1

**3. Revise Wi-Fi Password**  
In the router management interface of 192.168.10.1, click Install—Install Settings, you can customize the 2.4G and 5G SSID and Password.

**4.1. Step 1: set up the Controller**  
In the router management interface connected to the upper-level gateway (optical modem), select Network—EasyMesh—General, in the general settings page:  
1. Fill in Mesh Agent in Device Name.  
2. Select Controller in Role.  
3. Click Save & Apply.

**4.2. Step 2: set up the Agent**  
The Agent needs to be in the Bridge mode in 2.1. In the router management interface of other routers (except the router set in the first step), select Network—EasyMesh—General, in the general settings page:  
1. Fill in Mesh Agent in Device Name.  
2. Select Agent in Role.  
3. Click Save & Apply.

**4.3. Step 3: Two devices' EasyMesh networking**  
After the two devices complete step 1 and step 2, the General interface will refresh, and the Start PBC button will appear. In the General interface of one of the devices, click the Start PBC button or short press the device's WPS button, and within two minutes enter the General interface of the other device, click Start PBC button or short press the WPS button of the device to trigger automatic network pairing. (Note that long pressing the WPS key is not effective.)

**4.4. EasyMesh networking of three or more devices**  
Perform step 2 on the third and more devices.

**4.5. Check the device information in topology**  
In the router management interface of the Controller, select Network—EasyMesh—Topology, you can see the device name and IP address.

**5. Disable EasyMesh**  
When router's EasyMesh has been disabled, the device will depart from the original EasyMesh network. If you open EasyMesh again, please perform step 2 and step 3 to rejoin the network.

**6. Other information**

**Precautions:**  
1. After completing EasyMesh networking, the Controller device will synchronize its 2.4GHz and 5GHz SSID, password, and channel with the Agent device. That is, these configurations of the Agent device will be the same as the Controller device.  
2. After modifying the SSID, password, and channel on the Controller device, the Controller device will synchronize these configurations to all Agent devices. Modifying the SSID and password on the Agent device will not be synchronized.  
3. After the device restarts after a power failure, the device will restore the EasyMesh network group by default, and no connection settings are required.  
4. If the EasyMesh function of the Controller device is disabled, the entire EasyMesh network will be disabled.  
5. If the EasyMesh function of the Agent device is disabled, the device will leave the EasyMesh network.  
6. If you need to switch the access mode of a certain Mesh device, you need to turn off the Mesh function of the device first, and then turn on the Mesh function to complete the switching of the access mode.  
7. The Agent device is not supported to connect to other Mesh devices via Wi-Fi and wired at the same time. That is, the Agent device can only use one of Wi-Fi and wired to connect to other Mesh devices.

**FCC Warning Statement**  
FCC Radiation Exposure Statement: The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**After-sales Service Commitment**  
1. Implementation of the three guarantees regulations, seven days return, 15 days replacement, one-year warranty;  
2. The free warranty period of the product is one year, calculated from the date of sale;  
3. Under the following circumstances, three guarantees are not implemented, and paid maintenance is implemented:  
a. Failure caused by man-made damage, improper operation or resolvable natural disasters;  
b. Failure caused by remodeling, disassembling and assembling the product by yourself;  
c. Exceeding the validity period.

**Manufacturer: Micronet Union Technology(Chengdu) Co., Ltd**  
Address: Room 502, Building 5, N.O. 528, Yuefeng Road, Shibantan Street, Xindu District, Chengdu, Sichuan, China

150mm

**3. Revise Wi-Fi Password**  
In the router management interface of 192.168.10.1, click Install—Install Settings, you can customize the 2.4G and 5G SSID and Password.

**4.1. Step 1: set up the Controller**  
In the router management interface connected to the upper-level gateway (optical modem), select Network—EasyMesh—General, in the general settings page:  
1. Fill in Mesh Agent in Device Name.  
2. Select Controller in Role.  
3. Click Save & Apply.

**4.2. Step 2: set up the Agent**  
The Agent needs to be in the Bridge mode in 2.1. In the router management interface of other routers (except the router set in the first step), select Network—EasyMesh—General, in the general settings page:  
1. Fill in Mesh Agent in Device Name.  
2. Select Agent in Role.  
3. Click Save & Apply.

**4.3. Step 3: Two devices' EasyMesh networking**  
After the two devices complete step 1 and step 2, the General interface will refresh, and the Start PBC button will appear. In the General interface of one of the devices, click the Start PBC button or short press the device's WPS button, and within two minutes enter the General interface of the other device, click Start PBC button or short press the WPS button of the device to trigger automatic network pairing. (Note that long pressing the WPS key is not effective.)

**4.4. EasyMesh networking of three or more devices**  
Perform step 2 on the third and more devices.

**4.5. Check the device information in topology**  
In the router management interface of the Controller, select Network—EasyMesh—Topology, you can see the device name and IP address.

**5. Disable EasyMesh**  
When router's EasyMesh has been disabled, the device will depart from the original EasyMesh network. If you open EasyMesh again, please perform step 2 and step 3 to rejoin the network.

**6. Other information**

**Precautions:**  
1. After completing EasyMesh networking, the Controller device will synchronize its 2.4GHz and 5GHz SSID, password, and channel with the Agent device. That is, these configurations of the Agent device will be the same as the Controller device.  
2. After modifying the SSID, password, and channel on the Controller device, the Controller device will synchronize these configurations to all Agent devices. Modifying the SSID and password on the Agent device will not be synchronized.  
3. After the device restarts after a power failure, the device will restore the EasyMesh network group by default, and no connection settings are required.  
4. If the EasyMesh function of the Controller device is disabled, the entire EasyMesh network will be disabled.  
5. If the EasyMesh function of the Agent device is disabled, the device will leave the EasyMesh network.  
6. If you need to switch the access mode of a certain Mesh device, you need to turn off the Mesh function of the device first, and then turn on the Mesh function to complete the switching of the access mode.  
7. The Agent device is not supported to connect to other Mesh devices via Wi-Fi and wired at the same time. That is, the Agent device can only use one of Wi-Fi and wired to connect to other Mesh devices.

**FCC Warning Statement**  
FCC Radiation Exposure Statement: The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**After-sales Service Commitment**  
1. Implementation of the three guarantees regulations, seven days return, 15 days replacement, one-year warranty;  
2. The free warranty period of the product is one year, calculated from the date of sale;  
3. Under the following circumstances, three guarantees are not implemented, and paid maintenance is implemented:  
a. Failure caused by man-made damage, improper operation or resolvable natural disasters;  
b. Failure caused by remodeling, disassembling and assembling the product by yourself;  
c. Exceeding the validity period.

**Manufacturer: Micronet Union Technology(Chengdu) Co., Ltd**  
Address: Room 502, Building 5, N.O. 528, Yuefeng Road, Shibantan Street, Xindu District, Chengdu, Sichuan, China

quick guide(说明书)

Technical requirements:(技术要求)

1. Material:80g double-sided coated paper(材质：80g双铜 双面黑白印刷)

2. Size:90\*150mm(单页尺寸：90\*150mm)