

 <h2 style="text-align: center;">Label Printer USER GUIDE</h2>	<h2 style="text-align: center;">Contents</h2> <ul style="list-style-type: none"> 1. INTRODUCTION 1 2. ITEM OVERVIEW 2 3. CONNECT TO PC/MAC 3-4 4. DRIVER INSTALLATION FOR WINDOWS 4-7 5. WINDOWS PRINTING SETUP 7-9 6. DRIVER INSTALLATION FOR MACOS 9-14 7. MACOS PRINTING SETUP 14-15 8. LABEL SETUP 16-17 9. MAINTENANCE 17 10. FEDDER BUTTON INSTRUCTIONS 18-19 11. LED INDICATOR 19 12. COMPUTER PRINTING INSTRUCTION 20 13. SUPPORT 21 	<h3>Introduction</h3> <p>Congratulations! Our printer you have purchased is a high-efficiency thermal printer and does not require any ink or toner. Prints will be made by instantly heating compatible labels.</p> <p>Please take a moment to read this user guide as incorrect operation may result in unsatisfactory print quality, reduced user experience, or even damage to your printer or injury.</p> <h3>SAFETY NOTICES</h3> <ol style="list-style-type: none"> DO NOT touch the printer head after use. DO NOT disassemble or repair the unit by yourself. USE ONLY approved accessories. Keep the printer away from water, fire, or other objects that could destroy the components. Keep the printer away from children. DO NOT use the printer if you find any irregularities which could result in electrocution or fire. Please unplug the power when not in use for a long time. <h3>USER TIPS</h3> <ol style="list-style-type: none"> When you load the labels, the peeling-off side should face up. Or it would cause printing blank. Make sure there are no particles on the surface of labels to avoid damages to the PH (Printer Head). For Windows users, please keep using the same USB Port on your computer to avoid producing unexpected duplicated copies of the printer on your computer. 	<h3>Item Overview</h3> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px;"> <p>PACKAGE CONTENTS</p> <ul style="list-style-type: none"> Printer Manual Backset Power Adapter/Cable USB Flash Disk </div> <div style="border: 1px solid black; padding: 5px;"> <p>PRINTER COMPONENTS</p> <ul style="list-style-type: none"> Release Latch Printer Head Roller Paper Guide Power Supply Port USB Cable Port Power Switch (On/Off/Reset) </div> </div> <p>WARNING! The Printer Head(PH) may be very hot. Do not touch internal parts of the thermal printer immediately after using the printer.</p>	<h3>STEP 1 Connect to PC/MAC</h3> <ol style="list-style-type: none"> Ensure the printer is OFF (Press down "O" means Power OFF) Connect the power cable Connect the USB cable with PC/MAC 	<h3>STEP 2-1 FOR Windows DRIVER INSTALLATION</h3> <p>Please insert the included USB into your computer. A dialog box may appear.</p> <p>If it does, select Open folder to view files. If a dialog box does not appear, open Windows Explorer and select the flash drive on the left side of the window. Double-Click "Driver" files, and Open the "window" file with a double-click to start the installation process.</p> <ol style="list-style-type: none"> Click "I accept the terms in the license agreement" and click "next". 	<ol style="list-style-type: none"> Choose the installation directory, and then click "next". Choose the "Run Driver Wizard after unpacking drivers", and then click "next". Choose "install printer drivers", and then click "next". 	<h3>How is this printer going to be</h3> <ul style="list-style-type: none"> <input checked="" type="radio"/> USB <input type="radio"/> Network (Ethernet or WiFi) <input type="radio"/> Bluetooth <input type="radio"/> Other (such as Parallel or Serial) <p>5. Choose USB and insure the printer is connect to the PC and turn it on, Click "next".</p> <p>7. Don't change the printer name, and then Click "next".</p>	<h3>STEP 3-1 FOR Windows Printer Setup</h3> <p>Take Windows 10 as an example:</p> <ol style="list-style-type: none"> Find "CTPrinter CT-428S" along the path: Control Panel--Hardware and Sound--Devices and Printers 	<ol style="list-style-type: none"> Right click on "CTPrinter CT-428S", choose "Printing Preference". Click "Page Setup" and choose the proper size of your label, and make sure the chosen size is corresponding to the label paper you are about to use. 	<h3>ADVANCED DARKNESS AND PRINT SPEED</h3> <p>If you think that you are not satisfied with the clarity and speed of printing, you can adjust the density and speed in the "Options" next to the "Page Setup".</p> <ol style="list-style-type: none"> Open "System Preferences", and click on "Security & Printing" (If you don't see the warning, you can skip this step) Click on "Open AnyWay" button. (If you don't see the warning, you can skip this step) 	<ol style="list-style-type: none"> Double-click "MAC.pkg" if you see a warning shown below. (If you don't see this warning, you can skip this step) Open "System Preferences", and click on "Security & Printing" (If you don't see the warning, you can skip this step)
---	---	--	---	--	---	---	--	--	---	---	--

<ol style="list-style-type: none"> The installation process will auto running, if the driver have not auto running, please right click the "MAC.pkg" file, then select "Open" to start the installation process. Click "Continue" and follow the onscreen instructions. Click "Close" to finish. 	<ol style="list-style-type: none"> Open "System Preferences", and click "Printers & Scanners". Click "+" to add a new printer. 	<p>Then click "Choose a Driver", and "Select Software".</p> <ol style="list-style-type: none"> Select "CTPrinter CT-428S" from the drop-down menu, and click "Add". 	<h3>STEP 3-2 FOR MAC OS Printer Setup</h3> <ol style="list-style-type: none"> Open the PDF file named "Sample Label.pdf" which can be found in USB stick, select "file" and select "Print". 	<ol style="list-style-type: none"> In the Print window, click Page Setup and choose "CT-428S Series" Printer, and select the Paper Size to match your label size. A 4"x6" label is approximately 100x150mm. <p>If you feel that the clarity and printing speed are not suitable, you can adjust according to the following steps.</p> <p>Select "Printer Features", then change the settings of printer, e.g.: Print Speed, Darkness, Horizontal, Vertical.</p>	<h3>STEP 4 LABEL SETUP</h3> <ol style="list-style-type: none"> Ensure the printer is OFF. (Press down "O" means Power OFF) Pull the release latch to open the cover. Load the labels. Make sure the guides are touching the label sides. The printable part of the label should be facing up toward you. Close the cover carefully. Turn the power ON and wait 5 seconds for the printer to initialize. 	<h3>STEP 4 LABEL SETUP</h3> <p>2. Press and hold feeder button until you hear one short beep, take away your finger, the printer will begin automatic label identification. Once the printer stops, it will have identified your label size. The next time you want to put labels into the printer, instead of opening the printer, you can simply feed labels into the back of the printer.</p> <p>Now you can start your printing!!!</p> <p>We recommend using Adobe Reader to edit your labels. You must first modify the size of the labels file the appropriate size before printing.</p>	<h3>MAINTENANCE CLEANING THE PRINT HEAD</h3> <p>The printer head is a sensitive part of the printer and can be found on the upper part of the printer when open.</p> <p>Caution: While the printer is running the printer head can be very hot.</p> <ol style="list-style-type: none"> Ensure that the power switch is OFF, remove the power cord, and open the cover. Wait several moments to ensure that the printer head cools down. Completely clean the printer head using an alcohol swab. Any 70% Alcohol pad would work. Please do not use water. Wait 2-3 minutes until the alcohol has completely dried, then close the cover. Connect the power cord and print a test page to check if it is clean. 	<h3>FEDDER BUTTON INSTRUCTIONS</h3> <p>This printer has one button and one indicator that can display three colors. Pressing the button in conjunction with different colors or collaborating with the power switch will enable the printer to start multiple functions, such as feeding paper, pausing the printer, calibrating the label sensor, printing the self-test value, and initializing the printer. Details are described as follows:</p> <h4>General button functions</h4> <ol style="list-style-type: none"> Paper feeding: When the printer is standby (LED blue fixed), the installed paper will move forward one unit if feed button is pressed once. Pausing of printing operation: While the printer is printing, Press the feed button will pause the operation. At this point, the power indicator blinks blue. Press the button again to resume the printing. <h4>Boot button functions</h4> <p>This printer has four boot functions that can be used to set or test the printer's hardware. Please follow the steps below to start the boot function:</p> <ol style="list-style-type: none"> Turn off the printer. Turn on the printer while holding down the button. Release the button with the light signal indicating the required function, as listed in the table below. 	<table border="1"> <thead> <tr> <th>Indicator signal</th> <th>Purple</th> <th>Blue</th> <th>Red</th> <th>Purple</th> <th>Blue</th> <th>Blue</th> </tr> </thead> <tbody> <tr> <td>Function</td> <td></td> <td></td> <td>Release button</td> <td>Release the button</td> <td>Release the button</td> <td>Release the button</td> </tr> <tr> <td>1. Gap/black mark sensor detection</td> <td></td> <td></td> <td>Release button</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2. Gap/black mark sensor detection, printing self-test value and entering the debugging mode</td> <td></td> <td></td> <td>Release the button</td> <td></td> <td></td> <td></td> </tr> <tr> <td>3. Printer initialization (restore factory defaults)</td> <td></td> <td></td> <td></td> <td>Release the button</td> <td></td> <td></td> </tr> <tr> <td>4. Skip the AUTO_BAS program</td> <td></td> <td></td> <td></td> <td></td> <td>Release the button</td> <td></td> </tr> </tbody> </table> <h3>LED INDICATOR</h3> <table border="1"> <thead> <tr> <th>LED indicator color</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Blue (fixed)</td> <td>Power on, printer standby to print.</td> </tr> <tr> <td>Blue (blinking)</td> <td>The printer is downloading data or the printer is paused.</td> </tr> <tr> <td>Purple</td> <td>The printer is formatting the data.</td> </tr> <tr> <td>Red (fixed)</td> <td>Printer is in head opened or cutter error status.</td> </tr> <tr> <td>Red (blinking)</td> <td>Printing error occurs, e.g. a out of paper, paper jam, or memory error, etc.</td> </tr> </tbody> </table>	Indicator signal	Purple	Blue	Red	Purple	Blue	Blue	Function			Release button	Release the button	Release the button	Release the button	1. Gap/black mark sensor detection			Release button				2. Gap/black mark sensor detection, printing self-test value and entering the debugging mode			Release the button				3. Printer initialization (restore factory defaults)				Release the button			4. Skip the AUTO_BAS program					Release the button		LED indicator color	Description	Blue (fixed)	Power on, printer standby to print.	Blue (blinking)	The printer is downloading data or the printer is paused.	Purple	The printer is formatting the data.	Red (fixed)	Printer is in head opened or cutter error status.	Red (blinking)	Printing error occurs, e.g. a out of paper, paper jam, or memory error, etc.	<h3>Computer Printing Instruction</h3> <ol style="list-style-type: none"> Computer login: https://ga.ctclabel.com/pc After inserting the USB flash disk, open the file, double click "ctlabel trade setup" to install program First, click Agree Clabel trade and then click "Install immediately" 	<h3>SUPPORT</h3> <p>Your label printer is covered by a one-year warranty. In the unlikely event that you experience any issues with your printer, please contact support via amazon for customer service to promptly help with any troubleshooting tips or a replacement.</p> <p>For any questions and/or suggestions, please email the support team.</p> <p>Model: CT-428S</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>The device has been evaluated to meet general RF exposure requirement.</p> <p>Email: Clabel.service@outlook.com</p> <p>CE FCC CB RoHS Made in China</p>
Indicator signal	Purple	Blue	Red	Purple	Blue	Blue																																																											
Function			Release button	Release the button	Release the button	Release the button																																																											
1. Gap/black mark sensor detection			Release button																																																														
2. Gap/black mark sensor detection, printing self-test value and entering the debugging mode			Release the button																																																														
3. Printer initialization (restore factory defaults)				Release the button																																																													
4. Skip the AUTO_BAS program					Release the button																																																												
LED indicator color	Description																																																																
Blue (fixed)	Power on, printer standby to print.																																																																
Blue (blinking)	The printer is downloading data or the printer is paused.																																																																
Purple	The printer is formatting the data.																																																																
Red (fixed)	Printer is in head opened or cutter error status.																																																																
Red (blinking)	Printing error occurs, e.g. a out of paper, paper jam, or memory error, etc.																																																																