




**Transmission System
User Manual
TH006**

CONTENT

Introduction	1
Specification	2
Operating Instruction	2

Introduction



1. Calling key

二、 Specification

Size: 87x36x13mm(Curved handle caller's wire length:30cm(normal)/120cm(Longest stretch);Linear handle caller's wire length:57cm)

Battery: Button type 23A mercury free alkaline manganese 12V battery x1

Operating Frequency: 433.92MHZ±200KHz

Key: 2pcs(Main body 1pcs+handle 1pcs)

Pilot lamp: Display of main button position (illuminated when signal is transmitted)

Long press automatic sleep duration: 8s (After releasing the button for 3 seconds, it will automatically return to standby mode)

三、 Operating instructions

Press the button, and the indicator light of the main body will light up, indicating that a wireless signal is being sent; Release the button to stop sending (the indicator light goes out).

1. Registration number (* can only be used with a receiver): When the receiving host is in the code matching state (registration number/registration call button prompt tone), press

Press and hold the caller button (main button/handle button) that needs to be registered for more than 1 second, then release the button, and the decimal point in the middle of the receiving host number will light up to indicate

Successfully registered the caller button number/prompt tone.

2. Call information transmission (* can only be used with a receiver): When the receiving host is in standby receiving mode, press the registered caller button

Press and hold the button (main button/handle button) for more than 1 second, then release the button, and the receiving host will prompt according to the registered number/prompt tone.

*Note:

(1) To transmit a complete and valid call information, the hold time of pressing the button must be >1s (if the hold time of the button is >8s, the device will enter a sleep state,

After the button is closed and released for 3 seconds, you can re-enter standby mode

(2) For the installation and use of call buttons:

a. Avoid installing and using on metal walls/desks/spaces, as metal surfaces/spaces may cause signal attenuation/shielding, resulting in reduced transmission distance

Short.

b. The handle wire should fall naturally and should not be tied/entangled on other metal objects.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.