

## KF Manual for Certification

Version:

# Table of Contents

1	Using the Key Fob.....	6
1.1	Key fob range.....	6
1.2	Key fob operation.....	7
1.3	NFC function.....	7
1.4	Key fob troubleshooting .....	7
2	Replacing the Key Fob Battery .....	8
3	Caring for the Key Fob.....	9
4	Replacement Key Fobs .....	10
5	Device information.....	11

## List of Figures

No numbered figures included in this document

## List of Tables

No numbered tables included in this document

This is an excerpt of the full Arrival Van user manual.  
Manufacturer identification, EU address and UK address are stated at the informative part of the Arrival Van user manual.

# 1 Using the Key Fob

**WARNING**

To avoid accidental operation of the vehicle's systems by other occupants, do not leave a key fob in an unattended vehicle.


**CAUTION**

To ensure your vehicle is left in a secure state, remove all key fobs from the vehicle before leaving it unattended.

## 1.1 Key fob range

The key fob communicates with receivers in the vehicle via Bluetooth® Low Energy and UWB ultra-high frequency radio communication. While it is not necessary to point your key fob at the vehicle, it must be within operating range to work.

*Note: The key fob operating range can vary, depending upon environmental factors. Other nearby radio transmitters (e.g., amateur or CB radios, radio or television stations, airports) may interfere with communications between the key fob and the vehicle. Therefore, the ranges listed in this manual are approximate. In cases of interference, it may be necessary to move closer to the vehicle than usual in order to operate the key fob.*



Zone	Range
A	> 3 m = Operational range
B	3 m - 1.5m = Vehicle wakes
C	< 1.5m = In Use range
D	Push switch & open the door
E	Inside vehicle

The key fob can be operated manually once it is detected by the vehicle within zone **A** or closer.

Upon entering zone **B** while carrying a key fob, the vehicle will wake its systems and wait in standby.


When located near the door in zone **D**, nearest door is automatically unlocked - the user needs to push the switch next to the door to open it.

When leaving your vehicle while carrying a key fob, all doors automatically lock upon egressing zone **C**.

When the driver with the key fob is located in zone **E**, it is allowed to drive the vehicle.

## 1.2 Key fob operation

The key fob is in operational range when it is able to connect to the vehicle. This range is dependent on several factors, but it is typically more than 10m.



Once within operational range, the key fob operates as follows:

- Press once to lock all doors.
- Press twice to unlock all doors.

Once the key fob is in closer proximity to the vehicle, hands free operation of the key fob is enabled - the vehicle will automatically unlock the nearest door or allow drive when inside the cabin.

## 1.3 NFC function

Use the key fob as an NFC access token to access the vehicle, even if the battery is empty.

To do that, tap the key fob onto the reader located next to the driver's door.

## 1.4 Key fob troubleshooting

If the key fob does not respond when pressed:

- Try operating the key fob closer to your vehicle. Try taking the key fob out of the pocket/lifting it to the chest level.
- Other radio equipment operating on a similar frequency may interfere with the signals from your key fob.
- The key fob battery may need to be replaced. See [Replacing the Key Fob Battery](#).

If you are still unable to unlock your vehicle with the key fob, Contact an Arrival Authorised Repairer if the problem persists.

## 2 Replacing the Key Fob Battery

### **WARNING**

The key fobs supplied with your vehicle contain a coin/button type battery. These batteries contain toxic and corrosive substances.

Batteries are a chemical burn hazard and should never be ingested. If a battery is swallowed, it can cause serious internal burns and may even lead to death.

- Keep new and used batteries out of the reach of children.
- If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

### **WARNING**

If the cover for the key fob will not close securely, stop using the key fob and keep it out of the reach of children. Contact an Arrival Authorised Repairer for a replacement key fob.

### **WARNING**

There is a risk of explosion if an incorrect battery is installed. Only install a battery which is identical to the battery specified in this manual.

The key fob battery is type CR2032 and lasts for about 3 years, depending upon how often it is used.

If the vehicle detects that the key fob battery is low, an alert will display on the Touch Screen.

*Note: To avoid complications with the vehicle systems, it is important to replace a low key fob battery as soon as possible.*

To replace the key fob battery:

1. Insert a small, flat screwdriver into the slot at the end of the key fob, then prize the 2 halves of apart to reveal the battery.
2. Slide the old battery out.
3. Avoid touching the flat surfaces of the new battery if possible, as finger marks can reduce battery life. Wipe the battery clean before installation. Fit the battery with the “+” side facing upwards.
4. Replace the battery cover.

### **ENVIRONMENTAL**

Used batteries must be disposed of correctly, as they contain harmful substances. Refer to local regulations.



### 3 Caring for the Key Fob

**CAUTION**

To protect the electronic circuitry inside, do not expose the key fob to:

- Impacts
- Liquids
- High temperatures (including prolonged sunlight exposure)
- Waxes, solvents, or abrasive cleaners

## 4 Replacement Key Fobs

If you lose a key fob, contact an Arrival Authorised Repairer to obtain a replacement.

If ordering a new key fob, all available key fobs for the vehicle must be brought to the Arrival Authorised Repairer in order to reprogram the system.

## 5 Device information

Key fob operation frequencies and maximum transmit power are:

Band	Frequency range	Max. power
BLE 2.4G	2400-2483.5 MHz	+6dBm
UWB	6.0-8.5 GHz	+10dBm

**WARNING**

*This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.*

FCC ID: XYZ12PRODUCTCODE1

IC: XXXXXX-YYYYYYYYYY

