



User guide

Edge-30R+

Edge-30R-N+

With firmware version from 3.2.3

Review 13

Copyright © 2022 Acura Technologies

<http://www.acura.com.br>

1 Products covered by this manual	5
1.1 Approval note	5
1.2 Legal Notice	6
1.3 About Acura	6
2 Introduction	7
2.1 About this guide	7
2.2 Conventions used in this manual	7
2.3 Target audience	7
3 Introduction to equipment	8
4 Table of revisions	9
4.1 User guide table	9
4.2 Readers firmware table	10
4.3 Readers hardware table	13
5 Installation notes and important warnings	13
Part 1 - Overview and installation	14
6.1 Hardware - Edge-30R+ and Edge-30R-N+ Readers	15
6.2 General reader characteristics	16
6.3 Hardware - PCI interface	18
6.4 General features of pci interface	19
7 Mechanical installation	20
7.1 Reader attachment support	20
7.1.1 Fixing bracket items	20
7.1.2 Fixing the pole base 1" to 1.75" or 1.75" to 3" diameter and wall	21
7.1.3 Fixing the support base on edge-30R+ and Edge-30R-N+ readers	22
7.1.4 Fixing the bracket arm at the base of the pole/wall	23
7.1.5 Degrees of freedom of mechanical support	24
7.2 Positioning of readers	25
7.2.1 Side of the track	25
7.2.2 Track center	26
7.3 Reading problems	27
7.4 Food and Communication	28
7.5 Mechanical installation of pci interface	29
7.6 Dimensions of PCI interface	29
8 Eletrical Intallation	30
8.1 General diagram of electrical connections	30

8.2 Electrical connections - Reader	31
8.3 Electrical connections - PCI	33
8.4 Electrical connections - Ethernet LAN	34
8.6 Electrical connections - Digital input (Sensor)	36
8.7 Electrical connections - Relé	37
8.8 Reader visual indicators	38
8.8.1 STATUS visual indicator	38
8.9 POE Injector Visual Indicators	39
Parte 2 - Operation and operation	40
9 Modes of operation of the reader	41
9.1 Continuous reading mode	41
9.2 Trigger read mode	42
10 Configuring the Reader	43
10.1 Reader IP address	43
10.2 Configuring the reader via web browser	44
10.2.1 Checking the status of the reader	45
10.2.1.1 Status Parameters	45
10.2.2 Security Settings	47
10.2.3 Setting up the network	49
10.2.4 Setting Up Reading	51
10.2.4 Setting Up Communication	53
10.2.6 Configuring IO	56
10.2.7 Setting Date and Time	57
10.3 Configuring reader via ASCII messages	58
10.3.1 Operating logic	58
10.3.2 Syntax of messages and replies	58
10.3.3 Checksum of messages	59
10.3.4 Example of use	60
10.3.5 Checking the status of the reader	60
10.3.6 Configuring Security	62
10.3.7 Setting Up Network	63
10.3.8 Setting Up Reading	66
10.3.9 Setting Up Communication	71
10.3.10 Configuring GPIO	73
10.3.11 Miscellaneous settings	74
11 Data communication	76

11.1 TCP/IP connections to receive tag readings	76
11.2 TCP/IP connection, disconnection, and reconnection logic	77
11.3 Format of reading results via TCP/IP and RS232	78
11.4 Syslog	79
12 Mensagens de Log do leitor - Syslog	81
13 Regional Regulations	82
13.1 Frequencies and operating region	82
13.2 RF reader power	82
14 Integrated antenna measurements	83
14.1 VSWR	83
14.2 Axial Ratio ($\pm 20^\circ$ Azimuth) 902MHz	84
14.3 Axial ratio ($\pm 20^\circ$ Elevation) 902MHz	84
14.4 Axial ratio ($\pm 20^\circ$ Azimuth) 915MHz	85
14.5 Axial ratio ($\pm 20^\circ$ Elevation) 915MHz	85
14.6 Axial ratio ($\pm 20^\circ$ Azimuth) 928MHz	86
14.7 Axial ratio ($\pm 20^\circ$ Elevation) 928MHz	86
14.8 Radiation diagram (Azimuth) 902MHz	87
14.9 Radiation diagram (Elevation) 902MHz	87
14.10 Radiation diagram (Azimuth) 915MHz	88
14.11 915MHz Radiation Diagram (Elevation)	88
14.12 Radiation diagram (Azimuth) 928MHz	89
14.13 928MHz Radiation Diagram (Elevation)	89
15 Solutions to common problems	90
15.1 I do not know the IP of the Reader	90
15.2 I do not know the password of the reader's page	90
15.3 Cannot connect to the Reader via Ethernet	90
15.4 In trigger mode, the input signal is not being activated by the sensor	91
15.5 The Reader is not reading tags	91

1 Products covered by this manual

This user guide belongs to the following product:

Reader	Code
UHF READER ACURA EDGE-30R+ Autoid	100.644
PCI INTERFACE EDGE-30R +	100.647
ANTENNA SUPPORT MTI BR 66MM	100.320
POE POWER SUPPLY 15.4W	501.248

1.1 Approval note

Edge-30R+ AUTOID and EDGE-30R-N+ Autoid readers were tested and approved under the Regulation for Certification and Homologation of Telecommunications Products, approved by Anatel Resolution No. 242 of November 30, 2000.

Types: Radio Frequency Identification Systems - Category II.

Service/Application: Restricted Radiation Radiocommunication.

Federal Communication Commission Interference Statement (FCC)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radiofrequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



MPE Warning: Radiation Exposure Statement – This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 25cm between the radiator & your body. Contains FCCID: QV5MERCURY6E-M

Authorized Antenna

General Characteristics of the Antenna of Edge-30 R+.

Vendor	MTI Wireless
Model	MT-262024
Frequency Range (MHz)	902-928 MHz
Circular Gain (dBiC)	7,5 dBiC
Linear Gain (dBi)	6.0 dBi
Polarization	Circular (RHCP)
Type	Patch

1.2

Legal Notice

While all efforts have been made to ensure that this document and the information contained therein are correct, ACURA Technologies and any other parties involved in the creation of this document declare that it is provided "as is", without any express or implied warranty, including, but not limited to, any warranties that the use of the information contained herein does not infringe any right, legitimacy or fitness to the purpose, and therefore disclaim any liability, directly or indirectly, for loss or damage related to the use of this document.

The information contained in this document may be changed without notice.

1.3 About Acura

Since the end of the 1990s, ACURA has been the pioneer in the radio frequency identification (RFID) market in Brazil and Latin America, and has successfully explored, since the late 1990s, its large-scale adoption in the most diverse sectors of the economy, from mining to steel, agriculture to food processing, from logistics to retail, from transportation to the distribution chain, access control to asset management. Promoter of new technologies, innovative, agile, and focused on the feasibility of cutting-edge projects.

Technological Development and Commercial Office

Wall Street Business

Av. Antarctica, 381 - Jardim do Mar, São Bernardo do Campo - SP, 09726-150

(11)3028-4600

Factory and Service Center

Avenida Nicolau Cesarino, 4197 - Bairro Tenentes - Minas Gerais, ZIP Code: 37640-000

(11)3028-4600

2 Introduction

2.1 About this guide

This user guide provides detailed information about the readers and is divided into two large parts, Part 1 with information for the physical installation (mechanical) of the reader and Part 2 with information on the operation and operation of the reader, including programming and configuration.

2.2 Conventions used in this manual

This guide uses some typographic conventions:

**NOTICE:**

This type of warning shows the user that a particular action may cause damage to the reader or result in the operation of the reader that violates the regulatory requirements of the region.

**ATTENTION:**

This type of warning indicates that the reader is susceptible to electrostatic discharges and appropriate precautions should be taken so that no damage to the equipment occurs.

NOTE: Important information and tips on the subject you are in.

2.3 Target audience

This document is intended for technology professionals and rf equipment installation who will be responsible for installing the reader. Before installing, configuring, and operating the reader, you should be familiar with:

1. Data communication between devices, including ethernet and WiFi interface.
2. Definitions of configuration, positioning of Reader and RFID Antenna.
3. Basic knowledge about network configuration in Operating Systems.

3 Introduction to equipment

Edge-30R+ and Edge-30R-N+ readers are equipment with small and high-performance Radio Frequency Identification (UHF) RFID technology and high tag reading performance, with features and functionality useful for vehicular access control solutions that are described throughout this document. Below are the main features:

- Easy to use, do not require software or API/SDK, have automatic tag reading;
- They can be installed in an external area, have ip67 degree of protection, supports weather;
- Reading results are sent in real time to the PC/Controller;
- It has Wiegand communication (26/34b), Abatrack (10/14) and TCP/IP Ethernet;
- Settings via HTML page and ASCII messages via socket;
- Support up to two (2) simultaneous TCP/IP connections for receiving read data;
- Implement the "Secure Autoid System" of tag reading, where only end-user tags are read, without reading toll tags and/or tags from other locations;
- Edge-30R+ Autoid and Edge-30R-N+ Autoid have integrated antenna with 7.5 dBic gain and circular polarization, not being necessary rf cable installation;
- Two tag reading modes, Continuous Mode and Trigger Mode (with presence sensor);
- They have an opto-isolated digital input that accepts sensors with dry contact output, NPN and PNP to detect the vehicle and be used in Trigger reading mode;
- Option to use a digital output using the built-in pci-embedded radio (external 24VDC source usage required);
- They have reduced dimensions, not impacting on the aesthetics of the installation site;
- Contains tag signal level filter setting (RSSI), which helps filter unwanted tag readings.

The PCI Interface is a board that facilitates connections between the customer controller and the through an RJ45 communication cable. Below are the main features of the PCI Interface.

- It has RJ45 connectors and post type;
- It has small dimensions and can be fixed on DIN rail.

4 Table of revisions

4.1 User guide table

Revision	Month/year date	Description
13	02/2021	<ul style="list-style-type: none"> Update the information according to the Edge-30R+ Autoid and Edge-30R-N+ Autoid reader; Pcl change and information.
12	07/2021	<ul style="list-style-type: none"> Updates regarding the latest firmware; Update the preview procedure by Syslog.
11	01/2018	<ul style="list-style-type: none"> Added information about the Edge-40R-N Autoid reader.
10	05/2017	<ul style="list-style-type: none"> Correction of frequency band information for the Edge-30R-N; Correction of power information for edge-30R-N.
9	04/2017	<ul style="list-style-type: none"> Update of information regarding firmware 3.2.3; Added information about the 1/2W reader of read power, Edge-30R-N.
8	02/2017	<ul style="list-style-type: none"> Update of information regarding firmware 3.1.9; Changed information about maximum reading distance due to new tags with better sensitivity and low energy consumption; Added information about unwanted side readings.
7	09/2016	<ul style="list-style-type: none"> Updated configuration information.
6	02/2016	<ul style="list-style-type: none"> Added information about digital outputs; Added configuration information via ASCII messages via socket; Updated information of the reader configuration parameters; Added chapter on Collecting information for diagnostics using Syslog messages.
5	10/2015	<ul style="list-style-type: none"> Update the graphics of the measurements of the integrated antenna.
4	09/2015	<ul style="list-style-type: none"> Updates with changes to parameters and functionality; Updates with the format of the data string and Syslog protocol; Deleted chapter on Collection of information for diagnostics, this version of the reader firmware (2.0.4) implements the Syslog protocol, which replaces the old status messages.
3	07/2015	<ul style="list-style-type: none"> Fixed Hard Reset time from 4s to 30s; Changes to the new html reader configuration pages; Changes with the new instructions on TCP port, data format, and reader status.
2	05/2015	<ul style="list-style-type: none"> Fixed linefeed hexadecimal value [LF]; Updating information from the reader's characteristics table; Added warning about power;

1	03/2015	<ul style="list-style-type: none"> Creation of this document.
---	---------	--

4.2 Readers firmware table

Revision	Month/year date	Description
3.4.7	04/2021	<ul style="list-style-type: none"> Fixed ERROR in the safe mode tag verification algorithm when two readers with different security codes stood side by side, close to each other, improper readings occurred.
3.4.6	09/2020	<ul style="list-style-type: none"> Fixed excessive memory consumption error when the reader was in Client mode. In this mode, after a period the reader no longer responded to the ASCII configuration commands.
3.4.5	07/2020	<ol style="list-style-type: none"> Added one more parameter "*" for the commands "OUTPUT0" and "OUTPUT1", whose function is to exchange the state of the specific output for a time(s) specified in "OUTPUT0PERIOD" and "OUTPUT1PERIOD"; Added the commands "OUTPUT0PERIOD" and "OUTPUT1PERIOD" to determine pulse time when "*" is passed as a parameter in "OUTPUT0" and "OUTPUT1"; <ul style="list-style-type: none"> Added the commands "OUTPUT0TAG" and "OUTPUT1TAG", whose function is to trigger a pulse in the respective outputs for each tag reading, obeying the time configured in "OUTPUT0PERIOD" and "OUTPUT1PERIOD".
3.4.4	10/2019	<ul style="list-style-type: none"> Fixed algorithm ERROR at startup and RF driver scan.
3.4.2	04/2019	<ul style="list-style-type: none"> Fixed ERROR in the javascript of the network configuration page, where an error message was generated in changing the value of the communication and configuration ports.
3.4.1	03/2019	<ul style="list-style-type: none"> New Ethernet mode as client, it is now possible to choose the behavior of the reader, such as Server (legacy mode until then) and as Client mode where a server port and ip must be configured. The connection attempt is every 3s in Client mode, the commands sent to the reader configuration port are interpreted by the same connection in Client mode. Added 3 more commands "ETHMODE" "SVIPADDR" "SVPORT".
3.3.1	02/2019	<ul style="list-style-type: none"> Added the option to set a fixed Site Code value for the Wiegand interface. Two new commands accessible only via port 9090 have been created. Created command "ENFXSC" and "VALFXSC", to enable and setar value, respectively.
3.2.8	07/2018	<ul style="list-style-type: none"> Fixed ERROR in the filter algorithm when the read mode chosen was the hybrid.
3.2.5	05/2017	<ol style="list-style-type: none"> Changes aimed at improving the stability of the functioning of the


		<ul style="list-style-type: none"> reader; Fixed memory consumption ERROR in the RS232 serial sending function.
3.2.3	04/2017	<ul style="list-style-type: none"> Fixed ERROR in the IPV4LL generation algorithm in the events of disconnecting and connecting a network cable; Fixed ERROR in the formation of the reading command that uses the Select mask (ID Filter); Small changes aimed at improving the stability of the reader's operation; Added an RF time off with new Ascii command "TMRFOFF"; Implemented logic to disable the reset button check, through a new Command Ascii "ENHRDRST"; Fixed ERROR in the need check logic for rebooting in network settings; Fixed ERROR in Hybrid read mode where a secure tag was reported with the secure id and then followed by the normal id of the same secure tag. Only the secure id is now reported.
3.1.9	02/2017	<ul style="list-style-type: none"> Fixed BUG in keepalive String generation timer after the reader exceeds 18 hours of operation; In the temperature compensation logic, one more condition was included, if the temperature is greater than 81°C, it is idle for 5s. Improved logic of RF duty cycle, rfon/rfoff; Fixed ERROR in zero-value comparisons in the Set commands of TMFTDB, FTSMTG, SELFTDG; Changed delay scheme between tags in the transmission of id, now this delay is configurable by the command ascii DELAYTX from 0 to 500ms, is not on the html page, default of 100ms, before there was no delay in the RS232 interface which generated errors in some controllers when it was read but of a tag at the same time; Changed to EEPROM memory all the reader settings, so if in future versions there is the addition of new variables, the firmware update will not cause the return of the factory values of the other configuration variables; Implemented auto generation ip link local address IPV4LL, where the factory default IP is empty and the ASSigned IP is 169.254.MAC. mac with the last two decimal numbers of the MAC address; Added keyword "ALIVE" in the data string and keepalive in order to send the reader uptime in seconds; Removed popup from page html Security when changing the autoid security code, when changing and then clicking the Apply button, gave the false impression of having saved.
3.1.5	09/2016	<ul style="list-style-type: none"> The RS232 interface now only works with LOGIC OR other Wiegand and Abatrack interfaces, so if you're using Wiegand or Aba, the RS232 TX won't work; Implementado o modo Híbrido de funcionamento, onde hora le tag Normal hora le tag Seguro; You no longer need to restart the reader after changing Autoid Mode; One more keyword "TYPE" is included in the data string that sends the letter "S" when the tag is secure and "N" when it is normal; Changed the reading htm page to show all configs if the modo seja Híbrido;

		<ul style="list-style-type: none"> ● Changed the feedback patterns of the status and link LEDs; ● Security Change, there is now a default password <code>acura@autoid</code> , it is no longer allowed to be without any password, changed the page <code>html Security</code>, the password can have up to 16 chars; ● Included Duty Cycle RF (RFon/RFoff) compensation logic according to the reader's temperature increase; ● Improvements in internal error treatments.
3.0.1	02/2016	<ul style="list-style-type: none"> ● Implemented in a single firmware, the two Systems Autoid, Normal and Safe; ● Added English language for html pages; ● Some time parameters have changed to have drive in seconds; ● The maximum trigger read time value was changed to 600s before was 65s; ● Implemented configuration protocol through ASCII messages; ● Fixed a bug in the keepalive sending algorithm; ● Removed delay of 100ms between Wiegand or Aba transmissions when the chosen communication interface is "None".
2.0.4	09/2015	<ul style="list-style-type: none"> ● Implemented Syslog protocol (RFC 5424) for sending reader log messages; ● Eliminated the status ports that sent the log messages, now the protocol is Syslog; ● Implemented DNS protocol for name resolution; ● Implemented automatic name of the reader; ● The Read Result String is now the same as the one sent via TCP/IP and ; ● Added key words to the Data String and keepalive; ● Taken from the end-of-line settings for the Data String and keepalive, control characters can now be placed in strings by the keywords.
2.0.3	06/2015	<ul style="list-style-type: none"> ● Restructuring of html configuration pages; ● Immediate execution of parameter changes without the need for reader reboot; ● The Ethernet communication port number for the read results and reader status are now configurable; ● Accepts two simultaneous TCP/IP connections on the port configured to receive read data; ● The read result string that is sent via TCP/IP can now be customized using keywords; ● Included a number of receive buffers for the TCP/IP sockets of the reader to avoid the "Zero Window" events in the TCP/IP Ethernet protocol.
2.0.2	03/2015	<ul style="list-style-type: none"> ● Creation and release of the firmware.

4.3 Readers hardware table

Revision	Month/year date	Description
V1	03/2015	<ul style="list-style-type: none"> • Creation and launch of the Edge-30R reader.

5 Installation notes and important warnings



NOTICE: The maximum¹ reading distance of passive tags per reader is up to 6m for the Edge-30R+, 4m for the Edge-30R-N+. The effective reading distance of passive tags varies according to each installation and environment, and may change according to:

- Material on which the tag is installed;
- Tag placement;
- Reader targeting in relation to the tag;
- Electromagnetic interference caused by other equipment installed nearby.

NOTE: It is recommended that reading tests are performed before the reader is installed at the place where the reader is to be installed.

NOTE: Reader models have the same Irradiated Effective Power (ERP) of no more than 36dBm (4W), but the maximum power value configured on the reader is 30 dBm for the Edge-30R+ and 27 dBm for the Edge-30R-N+

¹ Distance obtained with the use of acutag UHF T5-C, T5-U And T7-C properly installed and in interference-free conditions of shielded/metallized glass or other nearby devices (e.g. Non-Stop or ConectCar). However, the reading distance may vary depending on the tag model, usage mode, and the environment.

Part 1 - Overview and installation


Equipment overview

Mechanical Installation

Wiring

6 Equipment overview

6.1 Hardware - Edge-30R+ and Edge-30R-N+ Readers



6.2 General reader characteristics

Transponder Protocols

Protocole ISO 18000-6C (Gen2)

Interface RF

RF output power *Edge-30R+*: from 0 to 30dBm with 0.5dBm increment
Edge-30R-N+: from 0 to 27dBm with an increment of 0.5dBm

Regulation ANATEL (BR) 902 - 907 MHz e 915 - 928 MHz

Mode Frequency Hopping

Modulation / RF Coding PR-ASK / Miller4 (M4)

Backscatter Link Frequency (BLF) 250KHz

Performance

Maximum reading distance² *Edge-30R+*: 6m w/ integrated antenna 7.5dBic (36dBm EIRP)
Edge-30R-N+: 4m w/ integrated antenna 7.5dBic (33dBm EIRP)

Dados / Interface de Controle

Connectors **Communication and power:**
RJ45 connector

Communication Interface **Ethernet:**
Communication speed 10/100Mbps
Galvanic insulation of 1.5KVCA
Wiegand/Abatrack (not using GPIO digital outputs):
Wiegand 26 and 34 bit / Abatrack 10 and 14 digits
Galvanic insulation of 1.0KVrms, current limitation 100mA (TBU)

² The reading distance may vary depending on the tag used and the reader's usage environment.

Data / Control Interface (continued)

<i>GPIO</i>	<p>1x Opto-isolated Digital Input: 1KV RMS insulation Supports Dry Contact, NPN (Sinking) and PNP circuit (Sourcing). Minimum pulse width: 100ms High Level (3.0 to 24.0VCC), Low Level (0 to 2.0VCC)</p> <p>1x Digital output opto-insulated by relin: High Level 24VCC RL_NC (Normal Contact Closed) RL_CM (Common Contact) RL_NO (Open Normal Contact)</p>
-------------	--

<i>Programming</i>	Does not require SDK/API, the reader works automatically by sending the reading result via Ethernet.
--------------------	--

Energy

<i>Energy</i>	Compatible with IEEE802.3af standard (15.4W) 10/100/1000M PoE Injector
---------------	---

<i>Consumption</i>	Maximum 15W With maximum power and high duty cycle.
--------------------	--

Physical characteristics

<i>Degree of protection of the reader</i>	IP67 (Considering the RJ45 PLUG properly connected)
---	--

<i>Integrated antenna</i>	<p><i>Edge-30R+</i>: 7.5 dBic gain, RHCP Circular Polarization <i>Edge-30R-N+</i>: 7.5 dBic gain, RHCP Circular Polarization</p>
---------------------------	---

<i>Dimensions</i>	<p><i>Edge-30R+</i>: 215x215x83 mm [LxAxP] <i>Edge-30R-N</i>: 190x190x77mm [LxAxP]</p>
-------------------	---

<i>Operating temperature</i>	-10°C a + 65°C
------------------------------	----------------


<i>Storage temperature</i>	-10°C a + 70°C
----------------------------	----------------

<i>Relative humidity of the air</i>	95%
-------------------------------------	-----

<i>Fixation</i>	With support on the back for poles (Ø 1" to 1.75" and 1.75" to 3") or flat surfaces (wall)
-----------------	--

6.3 Hardware - PCI interface

The PCI Interface should be used in conjunction with the Edge-30R+ Autoid and Edge-30R-N+ Autoid readers with the function of facilitating the installation of the readers. It has RJ45 type connector and terminals for a quick and easy connection between the readers and the client controller.



6.4 General features of pci interface

Data / Control Interface

Connectors

Reader Communication:

RJ45 connector

Communication/Digital Input/Digital

Output Terminal type Removable terminal for cables/wires 12-24 AWG

[WG/ABA, INPUT, RELAY]

Physical Characteristics

Degree of protection

Internal use only

Dimensions

58x51x36mm [LxAxP]

Weight

32g (Out of box)

Operating temperature

-10°C a + 65°C

Storage temperature

-10°C a + 70°C

Fixation








Compatible with DIN TS35 rail (35x7.5mm)

7 Mechanical installation



7.1 Reader attachment support


Readers together with the fixing bracket can be fixed on poles with a diameter variation from 1" to 1.75" or 1.75" to 3", can also be fixed on flat surfaces such as walls.

7.1.1 Fixing bracket items


<p>Item 1 - Qt 1 Base of the bracket on the reader</p> 	<p>Item 2 - Qt 4 M5 flat washer Item 3 - Qt 4 Pressure washer M5 Item 7 - Qt 4 M8 flat washer Item 8 - Qt 4 Pressure washer M8</p> 	<p>Item 4 - Qt 4 Nut M5 Item 9 - Qt 2 Nut M8</p> 	<p>Item 5 - Qt 1 Bracket arm</p> 
<p>Item 6 - Qt 4 Screw M8x40 Item 12 - Qt 2 Screw M8x70 Item 13 - Qt 4 Screw M5x16</p> 	<p>Item 10 - Qt 1 Pole/wall base</p> 	<p>Item 11 - Qt 1 Fixing part</p> 	

7.1.2 Fixing the pole base 1" to 1.75" or 1.75" to 3" diameter and wall






7.1.3 Fixing the support base on edge-30R+ and Edge-30R-N+ readers




7.1.4 Fixing the bracket arm at the base of the pole/wall



NOTE: Readers can be mounted with the cable facing the top side or on the sides, as it is easier for installation, as the integrated antenna has circular polarization, the position in which the reader is installed relative to the output of its cable will not influence the performance of reading tags.

7.1.5 Degrees of freedom of mechanical support



7.2 Positioning of readers


NOTE:

The measurements and illustrations described in this section are *recommendations* for the best performance of reading the passive tag in the vehicle. It is important to follow the reader's maximum installation height recommendations so that the effective distance *between the reader and the installed tag does not exceed the optimal reading distance of the passive tag*. To avoid reading failures, the ideal distance between *the reader and tag installed in the vehicle* is 3m (three meters).

7.2.1 Side of the track

The **angle of the reader** depends on the height of installation, the face of the antenna of the reader should be pointed to where the vehicle tag will be at the ideal reading distance of 3m between the reader and tag. You can measure 3m from the center of the antenna (installed) to an average height of 1.5m from the floor where the tags will be, the reader should be pointed to this location, where the tag should be.


7.2.2 Track center



The **angle of the reader** depends on the height of installation, the face of the antenna of the reader should be pointed to where the tag in the vehicle will be at the ideal reading distance of 3m between the reader and tag. You can measure 3m from the center of the antenna (installed) to an average height of 1.5m from the floor where the tags will be, the reader should be pointed to this location, where the tag should be.

7.3 Reading problems

When there are adjacent lanes near each other, tag readings may occur on unwanted tracks or locations near the reader's installation point. Below are some examples of multi-lane installations.



To minimize the occurrence of unwanted reads as much as possible, some actions can be performed:

1. Filter of unwanted side/adjacent readings. You must enable the "Filter by tag signal level" on the Read page or via the Ascii command "FTRSSI";
 1. What is the value of the cut-off RSSI?

The best way to determine the cutoff value of the trailing tag sign (RSSI) is by reading (on the side track) that informs rssi at the installation site by placing the keyword "RSSI" on the Data String on the Communications page or via the Ascii command "STRDT". To view the readings via TCP/IP you can use the "Putty Terminal Software". It is important to log readings of various types of cars to find a great cut value.
1. Adjusting the reading power combined with the reading filter by rssi. In many cases the reading power can be decreased without compromising tag readings on the correct track. Decreasing reading power helps a lot in eliminating unwanted side readings.
2. Mechanical adjustment of the reader (bring the tag/vehicle reader closer together) to be able to decrease the reading power.

NOTE: For the actions mentioned above, the tags must be properly installed in the vehicle (Glass, headlight, etc.), if the tags are shown in the hand or improperly the actions may not result in improved reading performance.

7.4 Food and Communication

To facilitate the installation of the reader, the power is made from a POE Injector via RJ45 cable, not requiring the PCI to be energized. If wiegand/abatrack communication is used, or the use of the input and logical output, it is necessary to use the PCI, which in turn, this communication is made by an RJ45 cable connected directly to the Interface Card of the reader.

Características

<i>PoE Injector</i>	PoE Standards IEEE 802.3af (15.4W) - 10/100/1000M
<i>Cable</i>	RJ45 T568A ou T568B
<i>Dimensions</i>	53 x 33 x 119mm [LxAxP]
<i>Weight</i>	138g (Outside the box)

The figure below demonstrates a POE injector model




NOTICE: The network cable with RJ45 connectors for power and communication It is NOT provided by ACURA. It is the customer's responsibility to acquire.


NOTE: We provide as an optional purchase of the PoE Injector (501.238).

7.5 Mechanical installation of pci interface

The interface plate must be fixed on a DIN TS35 rail (35 x 7.5mm).




7.6 Dimensions of PCI interface



No scale

8 Eletrical Intallation

8.1 General diagram of electrical connections




**ATTENTIO
N:**

The antenna port of the readers are susceptible to damage from electrostatic discharges (ESD). If electrostatic discharges occur on the antenna, the result may be equipment failure.

NOTE: In the case of the use of the reader, ACURA may optionally offer the

8.2 Electrical connections - Reader

The figure below describes the reader's connection to the POE Injector.




The table below describes the pins and colors of the RJ45 cable that will be used to connect the POE injector with the reader.

Injector Connector	RJ45	Standard color T568A	Position RJ45
HOST ETHERNET/PO WER	1	Light Green	
	2	Green	
	3	White	
	4	Blue	
	5	Light Blue	
	6	Orange	
	7	Light Brown	
	8	Brown	

NOTE: A standard T568A or T568B network cable can be used to connect the Injector to the Reader.

8.3 Electrical connections - PCI

The figure below describes the reader's connection to the PCI.




The table below describes the pins and colors of the RJ45 cable that will be used to connect the PCI Interface with the reader.

PCI Connector	RJ45	Standard color T568A	Position RJ45
SIGNAL	1	Light Green	
	2	Green	
	3	White	
	4	Blue (SIG RELAY)	
	5	Light Blue	
	6	Orange (GND)	
	7	Light Brown (DI COM)	
	8	Brown (DI IN)	

NOTE: A standard T568A or T568B network cable can be used to connect the Injector to the Reader.

8.4 Electrical connections - Ethernet LAN

The figure below describes the connection of the reader's POE injector to the local Ethernet network of the client.




The table below describes the pins and colors of the network cable that will be used to connect the POE/Reader injector to the local Ethernet network.

Injector Connector	RJ45	Standard color T568A	Position RJ45
HOST ETHERNET	1	Light Green	
	2	Green	
	3	White	
	4	Blue	
	5	Light Blue	
	6	Orange	
	7	Light Brown	

8 Brown (MR/MR CL)

NOTA: A standard T568A or T568B network cable can be used to connect the Injector to the.

The figure below describes the electrical connections of the Wiegand/Abatrack communication interface, which can be done with a customer's computer or with the client's controller board.



The table below describes the Wiegand/Abatrack connection pins.

PCI Connector	Pine	Function	PCI Connector
	ISO_GND	Wiegand/Aba Reference	
WIEG/ABA	W1/DATA	Signal W1 or Data1 (Wiegand) or Date Signal (Abatrack)	WG/ABA
	W0/CLK	Signal W0 or Data0 (Wiegand) or Clock Signal (Abatrack)	

NOTE: The reader's Wiegand/Aba interface features galvanic insulation of 1.0KVrms, protecting it from power surges and other electrical disturbances.



NOTICE:

To avoid noise and external interference that may hinder communication between the reader and the controller/PC, avoid passing the Wiegand communication cable/flap near sources, lamp reactors, electrical power cables, or other electromagnetic noise sources.

8.6 Electrical connections - Digital input (Sensor)

The digital input of the reader has the following electrical characteristics:

- 1KV RMS Opto-Isolated Input;
- Supports dry contact circuit, NPN and PNP;
- Minimum pulse width: 100ms;
- High Level (3,0 a 24,0VCC);
- Low Level (0 a 2,0VCC);
- Maximum voltage in NPN and PNP: 24VCC;

The digital input can be accessed via the "SENSOR INPUT" connector of the PCI card Interface, below follows the descriptions of the signals of the digital inputs.

PCI Connector	Pino	Função
SENSOR INPUT	ISO_GND	Reference (common) for sensors with dry contact output
	DI_COM	Reference (common) for sensors with NPN or PNP output
	DI_IN	Isolated digital input #1

Below are examples of sensor connections in the digital input of the reader.

Sensor with dry contact output (lens)	Sensor with PNP output (Sourcing)	Sensor with PNP (Sinking) output
Pinos ISO GND e ISO IN	Pinos ISO COM e ISO IN	

 **NOTICE:** For digital input, use the "ISO_GND" pin for sensors with Dry Contact output and use the "ISO_COM" pin for sensors with wet contact output in any polarity.

8.7 Electrical connections - Relé


Built into the PCI, the reader itself can send a digital signal through the handover. To use the digital outputs, the relay is required to power with an external 24 VDC source (not supplied, but may be the same as that used in the Edge-30R Autoid).

A saída digital do leitor possui as seguintes características elétricas:

- 1KV RMS Opto-Isolated Output;
- High Level (24V), triggered via ethernet command, example "\$ SET OUTPUT0=1<cr>";
- Low Level (0VDC), triggered via ethernet command, example "\$ SET OUTPUT0=0<cr>";

The digital outputs can be accessed through the "RELAY" connector of the PCI Interface card, below follows the descriptions of the signals of the digital outputs.

Below is image informing the Contacts of the Relé on PCI.



PCI Connector	Pino	Function
	RL+	Power Relay
	RL-	GND Relay
Relay	RL_NC	Normal Contact Closed
	RL_CM	Common Contact
	RL_NO	Open Normal Contact





NOTA: It is necessary to use an external 24VDC source (not supplied). Can be the same as used in EDGE 30R Autoid

8.8 Reader visual indicators

The reader has an operating status LED on the antenna.



8.8.1 STATUS visual indicator

	 <p>Blinks once fast (flashes) loop</p> <p>Indicates that the reader is in Continuous Read Mode.</p>
	 <p>Lit during flash</p> <p>Indicates that a Tag Read occurred while the reader was in read mode. During tag reading the reader sends the tag data through the communication interfaces.</p>
	 <p>Long lit - blinks once fast</p> <p>Indicates that the reader is in Trigger and Standby Reading Mode (not performing readers) until a trigger signal is generated and the LED starts blinking constantly as in continuous reading.</p>

8.9 POE Injector Visual Indicators

The injector has two status LEDs for operation.



Below, here is a table stating what each behavior of the LEDs located on the injector means

	<p>Yellow LED lit continuously and green LED off</p> <p>Indicates that the injector is being powered but is not connected to the reader</p>
	<p>Yellow and green LEDs lit continuously</p> <p>Indicates that the injector is being powered and connected to the reader</p>

Parte 2 - Operation and operation

Modes of operation of the reader

Setting the Reader

Data communication

Reader log messages - Syslog


Regional Regulations

Solutions to common problems

9 Modes of operation of the reader


9.1 Continuous reading mode

In this read mode, the reader performs read operations continuously, in other words, the reader is placed in a loop where it first performs the inventory operation and then sends the obtained results. This way, whenever a tag enters the reader's reading field, it will be read and its data sent through the communication ports. When there are no tags in the read field, the reader sends the Keepalive String at each Keepalive time interval by the Ethernet interface, both configurable on the reader's html page.



9.2 Trigger read mode

In this reading mode, the reader performs read operations only when it receives a signal from a connected sensor in its digital input, which can be accessed by the "SENSOR INPUT" connector of the PCI Interface. Thus, in this cycle of operation there is, in addition to the inventory and send operation, a state in which the reader waits for a shot on its digital input. Even without receiving any trigger signal, the reader keeps sending the Keepalive configured by the Ethernet interface.



10 Configuring the Reader

10.1 Reader IP address


Readers (firmware 2.1.6 or above) with factory settings automatically generates their IP address using the default Range of Local Link Address IPV4 169.254.0.0/16.

Readers use the following logic for generating their IP when they have factory settings:

IP = 169,254. **xx**. **xx** where **xx** are the last two decimal digits of the reader's MAC address, for example, MAC = 0.36.119.82. **Five, five** of them. **38** your generated IP will be 169,254. **Five, five** of them. **38**, if this same IP exists on the same local network as the reader, the fixed IP 10.0.0.101 will be used by the reader (very low probability).

Ways to get the READER MAC address:


1. **External label on the side of the reader**



NOTE: Due to the weather the label on the side of the reader may become unreadable, it is recommended to write this data right at the beginning of the installation.

2. **Software Device Explorer (Windows)**

Download: [Device Explorer](#)



Click Refresh to see all readers on the local network.

NOTE: UDP 65535 port must be released in operating system firewall rules.

NOTE: After the user has set up a static IP, the reader no longer generates the IPV4LL, only if a Hard reset is performed.

10.2 Configuring the reader via web browser

The reader settings are made by accessing the reader through LAN or WAN networks, placing its IP address in an internet browser (Web Browser). In reader access, a login page is shown before the settings page.

The factory settings (default) of the reader are

- IP address: **169.254.xxx.yyy** (xxx and yyy are the last decimal numbers of the MAC)
- Network mask: **none**
- Gateway address: **none**
- Login password: **acura@autoid**

You can make the following settings:

- Change password access to reader settings;
- Change the network parameters of the reader
- Change tag read parameters;
- Change IOs settings;
- View reader information/status;

With THE IP and PC Mask compatible with the current reader settings, follow the steps below to access the reader settings.

1. Initialize a web browser, enter the reader's IP in the address bar and press Enter. The reader's login page will open, as shown in the figures below:



2. The password of the Login page is of the user's choice, the reader leaves the factory with the login **password acura@autoid**, please refer to "Reader Parameters" for the complete list of the initial settings of the reader. After login, the settings page will be shown.
3. After modifying the desired fields, click "Apply" and after the page reloads, the modifications have already been made if the restart warning is shown click "Restart" so that the new saved settings are used by the reader.

NOTE: Only one user is able to connect to the reader configuration page. Login to the setup page expires after 3 (three) minutes. Thus, if another user wants to connect, they must wait for the first user to log out or pass the expiration time without any update on the page.

NOTE: Network segment 169.254.0.0/16 must be configured on the network interface computer.

NOTE: Always write down the settings saved in the reader, such as the IP and login password for access to the reader.

10.2.1 Checking the status of the reader

After login, the configuration home page with the equipment status parameters will be displayed.

**Edge-30R
AutoID Seguro**

- Status
- Segurança
- Rede
- Leitura
- Comunicação
- I/O
- Data e Hora
- Restart
- Logout

MAC: 00:24:77:53:42:3E
0:36.119.83.66.62

SN: 0000000

Nome: EDGE30R-53423E

© 2012 - 2022 ACURA

Status do leitor

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Informações Gerais	
RFID Firmware	01.0D.01.26
RFID Bootloader	12.12.13.00
RFID Hardware	20.00.00.01
Versão AutoID Seguro	4.0.1
MAC Address	00:24:77:53:42:3E
	0:36.119.83.66.62
Modo Ethernet	Leitor como Servidor
Conexão TCP #1 - Comunicação	#8080 - Desconectada
Conexão TCP #2 - Comunicação	#8080 - Desconectada
Conexão TCP - Configuração	#9090 - Desconectada
Descrição do leitor	
Nome do leitor	EDGE30R-53423E
Número de série do leitor	0000000
Status Leitor	OK - Modo de leitura automática
Região	BR (ANATEL)
Data e Hora do leitor	10-03-2012 23:52:35
Última sincronização SNTP	Falhou
Tempo de atividade do leitor	0d 00:00:36
Temperatura interna do leitor	40°C

Nota: O tempo da sessão é 3min. após esse tempo é necessário fazer o login novamente.

Below are the descriptions of the reader configuration parameters that can be checked and/or changed via browser and also using ASCII commands.

10.2.1.1 Status Parameters

Parameter	Description
RFID Firmware	Firmware version running on the RFID module of the reader.
RFID Bootloader	Bootloader version running on reader RFID module.

RFID Hardware Hardware version of the RF module of the reader.

AutoID Version Firmware version of the reader's internal controller.

Status parameters (Continued):

Parameter	Description
<i>MAC Address</i>	Physical address of the Ethernet interface, consisting of 6 bytes, is shown in decimal and hexadecimal format.
<i>Ethernet Mode</i>	Indicates whether the reader is configured as Client or Server.
<i>TCP Connection # Communication</i>	The reader accepts up to 2 simultaneous TCP/IP connections on the port configured on "TCP Port Data Communication" to receive tag read data.
<i>Reader description</i>	Alphanumeric characters of a maximum of 30 digits that describe the reader, for example its installation location.
<i>Reader name</i>	Name generated automatically by the reader, EDGE-30R + the last six digits of the MAC.
<i>Reader Status</i>	Shows the last state of the reader.
<i>Region</i>	Shows which region (frequencies allowed) the reader is using.
<i>Reader Date and Time</i>	Shows the current date and time of the reader.
<i>Last SNTP sync</i>	Shows whether the reader was able to synchronize with the configured SNTP servers.
<i>Reader uptime</i>	Displays how long the reader is running without serious errors or without being rebooted.
<i>Internal reader temperature</i>	Shows the temperature of the RF module internal to the reader, the body temperature of the reader is usually 15 to 20°C lower.

10.2.2 Security Settings

1. After login, click the Security option.

**Edge-30R
Autoid Seguro**

Status

Segurança

Rede

Leitura

Comunicação

I/O

Data e Hora

Restart

Logout

MAC: 00:24:77:53:42:3E
0:36.119.83.66.62

SN: 0000000

Nome: EDGE30R-53423E

© 2012 - 2022 ACURA

Segurança

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Configurações de Segurança

Senha login

Confirma senha login

Descrição do leitor

Habilita configuração do leitor pela porta TCP de configuração

Tipo do Sistema Autoid Normal Seguro Híbrido

Normal: O leitor efetua leituras de todos os tags UHF em seu campo de leitura.
Seguro: O leitor efetua leituras apenas de tags com o código de segurança Autoid.
Híbrido: O leitor efetua leituras nos dois modos descritos acima.

Código de segurança Autoid

!!! Os tags devem possuir o mesmo código de segurança Autoid !!!

Aplicar
Reload

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".
 Nota 2: A reinicialização do leitor será necessária somente quando o aviso de Restart aparecer na página.
 Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.
 Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinicializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

2. Change the settings.
3. Click Apply to make the changes.
4. If the Restart message is shown, click Restart.

Security page parameters:

Parameter	Description
<i>Login Password</i>	Alphanumeric characters of a maximum of six digits that can be written to the reader to form the password that will give access to the settings page. Factory configuration: No password, empty
<i>Reader description</i>	Alphanumeric characters of a maximum of 30 digits that describe the reader, for example its installation location. Factory configuration: None, empty
<i>Enables reader configuration by TCP configuration port</i>	If selected, configuration commands will be accepted by the reader on the TCP configuration port. Factory configuration: Enabled, selected

Security page parameters (Continued):

<i>Parameter</i>	<i>Description</i>
<i>Autoid system type</i>	<p>Type of reading algorithm that the reader will run.</p> <p>Normal: The reader does not check any kind of security in reading the tags, it reads any standard ISO-18000-6C tag (UHF Gen2) in its reading field and reports on its communication interfaces.</p> <p>Secure: The reader verifies that the standard ISO-18000-6C tag (UHF Gen2) has a previously recorded "Autoid Security Code" and reports on its communication interfaces only the tags validated with this security code, which is unique to each end user of the System.</p> <p>Hybrid: The reader performs the two modes mentioned above.</p> <p>Factory setup: Secure</p>
<i>Autoid security code</i>	<p>Six-digit numeric security code linked to tags written with that same code. Only tags with the same security code will be read by the reader.</p> <p>Note: Parameter used only when the "Autoid System Type" is "Safe"</p> <p>Factory setup: 900001</p>

10.2.3 Setting up the network

1. After logging in to the html page, click **Network**.

**Edge-30R
AutoID Seguro**

Status

Segurança

Rede

Leitura

Comunicação

I/O

Data e Hora

Restart

Logout

MAC: 00:24:77:53:42:55
0:36:119:83:66:85

SN: 0000000

Nome: EDGE30R-534255

© 2012 - 2022 ACURA

Rede Ethernet

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Configurações de Rede

Modo Ethernet (comportamento do leitor)	<input checked="" type="radio"/> Servidor <input type="radio"/> Cliente
Endereço IP do leitor	<input type="text"/>
Máscara de rede	<input type="text"/>
Endereço Gateway	<input type="text"/>
Servidor DNS	<input type="text"/>
Servidor SNTP	<input type="text" value="a.st1.ntp.br"/>
Servidor SYSLOG	<input type="text"/>

Portas TCP

Porta TCP Comunicação de dados (modo Servidor)	<input type="text" value="8080"/>
Porta TCP Configuração (modo Servidor)	<input type="text" value="9090"/>

Aplicar
Reload

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".
 Nota 2: A reinicialização do leitor será necessária somente quando o aviso de Restart aparecer na página.
 Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.
 Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinicializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

2. Change settings as needed by the network.
3. Click **Apply** to make the changes.
4. If the Restart message appears, click **Restart**.

Parâmetros de Rede:

Parameter	Description
<i>Ethernet Mode</i>	Defines the behavior of the reader on the network, and can act as server or client. Factory configuration: Server
<i>IP address</i>	Fixed IP address of the reader, this version of the reader does not support DHCP. Factory configuration: 169.254.xx.xx (Local Address Link, last two of the MAC)
<i>Network mask</i>	IP address of the subnet mask, devices on the same subnet can communicate locally without routing. Factory configuration: empty
<i>Gateway Address</i>	IP address of the gateway to the local network, is usually the address of the router. Factory configuration: empty
<i>DNS Server</i>	IP address of the DNS server, will be the server queried to resolve names. Factory configuration: empty
<i>SNTP Server</i>	Name or IP of the SNTP server, will be the server queried to synchronize the internal clock. Factory setup: a.st1.ntp.br
<i>SYSLOG Server</i>	Name the IP of the SYSLOG server that will receive the log messages from the reader. Factory configuration: empty
<i>TCP Data Communication Port</i>	Number of the port where up to two concurrent connections are accepted for receiving the Read String. Factory configuration: 8080
<i>TCP Port Configuration</i>	Port number where a connection is accepted for ascii message configuration. Factory configuration: 9090

10.2.4 Setting Up Reading

1. After login, click **Read**.

**Edge-30R
AutoID Seguro**

Status

Segurança

Rede

Leitura

Comunicação

I/O

Data e Hora

Restart

Logout

MAC: 00:24:77:53:42:3E
0:3E.119.83.66.62

SN: 0000000

Descrição:
Entrada Visitantes

Nome: EDGE30R-53423E

© 2012 - 2022 ACURA

Leitura de tag

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Configurações de Leitura

Modo de leitura	<input type="radio"/> Contínuo	<input checked="" type="radio"/> Trigger
Tempo de leitura trigger (1 a 600s)	<input type="text" value="1"/>	s
Tempo do filtro de mesmo tag (0 a 600s)	<input type="text" value="1"/>	s
Potência de leitura (500 a 3000 centidBm)	<input type="text" value="3000"/>	centidBm
Filtro pelo nível de sinal do tag (RSSI em dBm)	- <input type="text"/>	dBm

Aplicar
Reload

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".
 Nota 2: A reinitialização do leitor será necessária somente quando o aviso de Restart aparecer na página.
 Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.
 Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinitializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

1. Change the parameters.
2. Click **Apply** to save the changes.
3. If you see the message prompting you to restart the reader, click **Restart**.

Reading Parameters:

Parâmetro	Descrição
<i>Reading Mode</i>	Read operation mode that will be performed by the reader. Continuous mode: Operation mode where the reader performs read operations continuously. Trigger mode: Operation mode where the reader performs read operations only when it receives a signal from a sensor through its digital input. Factory Setup: Continuous Mode
<i>Trigger reading time</i>	It is the time in seconds that after a trigger signal on the digital input (ISO IN), the reader performs an inventory operation (tag reading). Note: Parameter used only when "Read mode" is "Trigger Mode". Factory configuration: 1s Values: 1 to 600s.
<i>Filter time of the same tag</i>	Is the time in seconds of the read filter of the same tag, that is, the tag id is sent to the PC/Controller on the first read and resent only after the time configured in this field. Factory configuration: 1s Values: 0 to 600s.

Read parameters (continued):

<i>Parameter</i>	<i>Description</i>
<i>Reading power</i>	<p>Power in centidBm (dBm / 100) referring to tag reading. The read power can be adjusted to change the read region of tags at the installation location.</p> <p>Factory configuration: 3000dBm Values: 500 to 3000 centidBm (5 to 30 dBm).</p>
<i>Filter by tag signal level</i>	<p>The signal level of the tag indicates whether the tag is near or away from the antenna, when closer to the antenna, the stronger the RSSI (closer to zero) and vice versa. If a value is specified for the filter, only tags with RSSI equal to or greater than that specified will be reported by the reader. The signal level of the tag is measured in dBm and is a negative value, the power in Watts is always less than 1mW.</p> <p>Note: To disable the filter, simply leave the field empty. Note: The specified value should not contain the minus sign.</p> <p>Factory setting: Empty (filter disabled) Values: 20 to 99 dBm (-20 to -99dBm).</p>
<i>Filter by reading tags that contain on your id the mask</i>	<p>Is the mask value that the tag id must contain to be read, if this field contains some value, the reader will read only tags that contain this mask from the given digit.</p> <p>Note: Parameter used only when the "Autoid System Type" is "Normal or Hybrid".</p> <p>Factory configuration: empty, unfiltered Values: hexadecimals max. 24 digits.</p>
<i>Initial digit of the mask in tag ID</i>	<p>Is the starting digit in which the mask provided above starts in the tag id.</p> <p>Note: Parameter used only when the "Autoid System Type" is "Normal or Hybrid".</p> <p>Factory configuration: 0 Values: 0 to 24.</p>

10.2.4 Configurando a Comunicação

1. After login, click **Communication**.

Configurações de Comunicação

Tipo interface comunicação (Antena Integrada) Wiegand Abatrack
 - A interface de comunicação Ethernet-TCP/IP sempre está habilitada.

Número de bits Wiegand ([P]1b [Dados]24b/32b [P]1b) 26 bits 34 bits

Formato dos Dados

String de dados
 Palavras chaves para a String de dados que o leitor substitui a cada leitura de tag e envia via TCP/IP e RS-232:

IDHEX	ID do tag no formato hexadecimal. (Tamanho: 8 caracteres para Autoid Seguro, EPC inteiro para o Autoid Normal).
IDWG	ID do tag no formato wiegand26 'FC[3díg. dec. antepenúltimo byte] ID[5díg. Dec. dois últimos bytes]'. (Tamanho: 8 caracteres)
IDABA	ID do tag no formato abatrack 'ID[10díg. dec. quatro últimos bytes]'. (Tamanho: 10 caracteres)
RDC	Número de leituras do tag. (Tamanho: 2 caracteres) [Opcional].
RSSI	Valor do nível de sinal (negativo) que o tag respondeu ao leitor. (Tamanho: 3 caracteres) [Opcional].
ANTID	Número da antena que o tag foi lido. (Tamanho: 1 caractere) [Opcional].
TMSTP	Timestamp [dd-mm-aaaa hh:mm:ss] (Tamanho: 19 caracteres) [Opcional].
TEMP	Temperatura em °C do módulo RF. (Tamanho: 2 caracteres) [Opcional].
TYPE	Tipo do tag lido, 'S' para Seguro e 'N' para Normal (Tamanho: 1 caractere) [Opcional].
ALIVE	Tempo de atividade do leitor em segundos. (Tamanho: 1 a 10 caracteres) [Opcional].
<CR>	Carriage Return [0x0D]. (Tamanho: 1 caractere) [Opcional].
<LF>	Line feed [0x0A]. (Tamanho: 1 caractere) [Opcional].
<STX>	Start of text [0x02]. (Tamanho: 1 caractere) [Opcional].
<ETX>	End of text [0x03]. (Tamanho: 1 caractere) [Opcional].

Os demais caracteres e palavras que não coincidam com as palavras chaves, serão espelhados na String de dados que o leitor envia a cada leitura de tag.

String Keep alive
 Palavras chaves para a String Keep alive que o leitor substitui e envia via TCP/IP a cada intervalo de tempo keep alive:

RN	Nome do leitor. (Tamanho: 14 caracteres)
RD	Descrição do leitor. (Tamanho: max. 30 caracteres)
TEMP	Temperatura em °C do módulo RF. (Tamanho: 2 caracteres)
ALIVE	Tempo de atividade do leitor em segundos. (Tamanho: 1 a 10 caracteres)
<CR>	Carriage Return [0x0D]. (Tamanho: 1 caractere)
<LF>	Line feed [0x0A]. (Tamanho: 1 caractere)

Os demais caracteres e palavras que não coincidam com as palavras chaves, serão espelhados na String keep alive que o leitor envia a cada intervalo de tempo keep alive.

Intervalo de tempo Keep alive (1 a 60s) s

Syslog

Enviar temperatura interna do módulo RF do leitor para o Syslog

Campo 'Tag' da mensagem Syslog Nome Leitor Descrição Leitor

Aplicar
Reload

1. Change the parameters.
2. Click **Apply** to save the changes.
3. If you see the message prompting you to restart the reader, click **Restart**.

Communication Parameters:

Parameter	Description																								
<i>Type communication interface</i>	<p>Reading results are made available through the Wiegand or Abatrack communication interfaces, and simultaneously through tcp/IP Ethernet interfaces.</p> <p>You can use the two signal lines (W0/CLK) and (W1/DATA) as digital outputs, selected None(GPO), thereby disabling Wiegand and Abatrack communications.</p> <p>Note: TCPIP communications are always active, in parallel to the interface chosen here.</p> <p>Factory setup: Wiegand.</p>																								
<i>Number of wiegand bits</i>	<p>Number of bits of the entire packet transmitted in Wiegand format.</p> <p>26 bits: Format: Parity[1bit] + Data[24bits] + Parity[1bit].</p> <p>34 bits: Format: Parity[1bit] + Data[32bits] + Parity[1bit].</p> <p>Note: Parameter used only when the "Communication interface type" is "Wiegand".</p> <p>Factory configuration: 26 bits.</p>																								
<i>Number of abatrack digits</i>	<p>Number of digits in decimal in Abatrack format.</p> <p>10 dig. : The reader sends 10 digits in decimal on the Abatrack interface.</p> <p>14 dig. : The reader sends 14 digits in decimal on the Abatrack interface.</p> <p>Note: Parameter used only when the "Communication interface type" is "Abatrack".</p> <p>Factory configuration: 10 dig.</p>																								
<i>Data String</i>	<p>It is the string that the reader will transmit only through the Ethernet interface at each tag reading. The keywords below will be replaced by their respective values:</p> <table border="1"> <thead> <tr> <th>Keyword</th> <th>Description</th> <th>Size characters</th> </tr> </thead> <tbody> <tr> <td>IDHEX</td> <td>Tag ID in hexadecimal format. * Variable size for Normal Autoid and 8-character size for Autoid Insurance.</td> <td>*</td> </tr> <tr> <td>IDWG</td> <td>Tag ID in Wiegand26 format "FC[3dig.] ID[5dig.]".</td> <td>08</td> </tr> <tr> <td>IDABA</td> <td>Tag ID in abatrack (decimal) format "ID[10dig.]".</td> <td>10</td> </tr> <tr> <td>RDCT</td> <td>Number of tag reads for each inventory.</td> <td>02</td> </tr> <tr> <td>RSSI</td> <td>Value of the signal level (negative) that the tag reported.</td> <td>03</td> </tr> <tr> <td>ANTID</td> <td>Number of the antenna on which the tag was read.</td> <td>01</td> </tr> <tr> <td>TMSTP</td> <td>Timestamp [dd-mm-aaaa hh:mm:ss] of reading.</td> <td>19</td> </tr> </tbody> </table>	Keyword	Description	Size characters	IDHEX	Tag ID in hexadecimal format. * Variable size for Normal Autoid and 8-character size for Autoid Insurance.	*	IDWG	Tag ID in Wiegand26 format "FC[3dig.] ID[5dig.]".	08	IDABA	Tag ID in abatrack (decimal) format "ID[10dig.]".	10	RDCT	Number of tag reads for each inventory.	02	RSSI	Value of the signal level (negative) that the tag reported.	03	ANTID	Number of the antenna on which the tag was read.	01	TMSTP	Timestamp [dd-mm-aaaa hh:mm:ss] of reading.	19
Keyword	Description	Size characters																							
IDHEX	Tag ID in hexadecimal format. * Variable size for Normal Autoid and 8-character size for Autoid Insurance.	*																							
IDWG	Tag ID in Wiegand26 format "FC[3dig.] ID[5dig.]".	08																							
IDABA	Tag ID in abatrack (decimal) format "ID[10dig.]".	10																							
RDCT	Number of tag reads for each inventory.	02																							
RSSI	Value of the signal level (negative) that the tag reported.	03																							
ANTID	Number of the antenna on which the tag was read.	01																							
TMSTP	Timestamp [dd-mm-aaaa hh:mm:ss] of reading.	19																							

Communication parameters (Continued):

<i>Parameter</i>	<i>Description</i>		
<i>Data string (Continued)</i>	Keyword	Description	Size [characters]
	TEMP	Temperature in °C of internal RF module.	02
	TYPE	Tag type read, 'S' for Safe and 'N' for Normal	01
	ALIVE	Reader uptime in seconds	1 a 10
	<CR>	Caractere control ASCII Carriage Return [0x0D].	01
	<LF>	ASCII Line feed control character [0x0A].	01
	<STX>	Caractere de controle ASCII Start of text [0x02].	01
	<ETX>	Caractere de controle ASCII End of text [0x03].	01

Note: Other characters or words that do not match the words keys will be mirrored in the Data String that the reader transmits to each tag read through the Ethernet interface.

Factory configuration: 0xIDHEX<CR><LF>

It is the String that the reader will transmit only through the Ethernet interface at each "Keepalive time interval". The key words below are replaced by their respective values:

<i>String Keepalive</i>	Keyword	Description	Size [character s]
	RN	Reader name, automatically generated.	14
	RD	Reader description, configured by user.	30 máx.
	TEMP	Temperature in °C of the RF module.	02
	ALIVE	Reader uptime in seconds.	1 a 10
	<CR>	Caractere control ASCII Carriage Return [0x0D].	01
	<LF>	ASCII Line feed control character [0x0A].	01

Note: Other characters or words that do not match the words keys will be mirrored in the keepalive string that the reader transmits at each keepalive time interval.

Factory configuration: <CR><LF>

Communication parameters (Continuation):

Parameter	Description
Keepalive time interval	Is the time interval in seconds for sending the Keepalive String. Factory configuration: 1s Values: 1 to 60s.
Send internal temperature of the reader's RF module to Syslog	If selected, the temperature in °C of the RF module will be sent to the Syslog server with each degree change. Factory setup: Send (Selected).
Syslog message tag field	What should be sent in the 'tag' field of the Syslog messages generated by the reader. Factory configuration: Reader name.

10.2.6 Configuring IO

1. After login, click **IO**.

Edge-30R AutoID Seguro

I/O

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Configurações da Entrada Digital

Lógica invertida do sinal de entrada trigger

Configurações do Relé

Duração do pulso (2 a 60s) s

Acionamento por leitura de tag

Aplicar **Reload**

MAC: 00:24:77:53:42:55
0:36:119:83:66:85

SN: 0000000

Nome: EDGE30R-534255

© 2012 - 2022 ACURA

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".
Nota 2: A reinicialização do leitor será necessária somente quando o aviso de Restart aparecer na página.
Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.
Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinicializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

2. Change the parameters.
3. Click **Apply** to save changes.
4. If you see the message prompting you to restart the reader, click **Restart**.

IO parameters:

Parameter	Description
Lógica invertida do sinal de entrada trigger	Reverses the trigger signal trigger ing logic (the NF contact of the lens can be used for example). Factory configuration: not selected (normal logic).

IO (Relé) parameters:	Description
Parameter	
Pulse Duration	
Set pot tag reading	When the reader is initialized, in which logical state the digital outputs should be configured. Note: Parameter used only when the "Communication interface type" is "None(GPO)". Factory setting: Low level (0V).

10.2.7 Setting Date and Time

1. After login click **Date and Time**.

Edge-30R
AutoID Seguro

- Status
- Segurança
- Rede
- Leitura
- Comunicação
- I/O
- Data e Hora**
- Restart
- Logout

MAC: 00:24:77:63:42:3E
0:35:119.83.66.62

SN: 00000000

Descrição:
Entrada Visitantes

Nome: EDGE30R-53423E

© 2012 - 2022 ACURA

Configurações de Data e Hora

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Data e Hora do leitor

Ajustar data e hora manualmente

Dia / Mês / Ano [dd/mm/aaaa] 10 / 03 / 2012

Hora : Minuto : Segundo [hh:mm:ss] 23 : 55 : 58

Horário de verão

Fuso Horário ▼

Nota: As configurações manuais de Data e Hora serão substituídas pelas informações obtidas do Servidor SNTP.

Aplicar Reload

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".

Nota 2: A reinicialização do leitor será necessária somente quando o aviso de Restart aparecer na página.

Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.

Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinicializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

2. Change the parameters.
3. Click **Apply** to save the changes.
4. If you see the message prompting you to restart the reader, click **Restart**.

Date and Time parameters:

Parameter	Description
<i>Adjust date and time manually</i>	If an SNTP server cannot be used for clock timing there is the possibility of manual adjustment of the watch. Note: When loading the page, the date and time fields are updated with the data from the reader's internal clock.
<i>Daylight saving time</i>	If selected, it will adjust the reader's internal clock to daylight saving time. Factory configuration: Not selected.
<i>Fuso horário</i>	Time zone (UTC) from where the reader is installed. Factory configuration: (UTC -03:00).

10.3 Configuring reader via ASCII messages

The reader can be configured via a TCP connection on the configuration port using ASCII messages, this configuration template can be used in applications where a Software will configure the reader or to debug and field adjustments after installing the reader.

The ascii message reader configuration is disabled with the reader's factory settings, to enable, simply change the parameter "Enable reader configuration by TCP port setting" via web browser on the Security page.

The default configuration port where the reader expects a TCP connection is 9090 and can be changed by the user on the Network page.

10.3.1 Operating logic

Setting up the READER via ASCII messages works with the Message/Response framework:

1. An external Host sends a message to the reader.
2. The reader interprets and executes the function and command inserted into the received message.
3. The reader responds to the external Host.

Messages and replies to use ASCII characters with a prefix and a terminator. The prefix is the sequence "\$ " (dollar sign followed by space). The terminator is the carriage return <CR>.

10.3.2 Syntax of messages and replies

Below is the syntax of messages from Host to Reader:

```
$ SET COMANDO=VALOR<CR>
$ GET COMANDO<CR>
```

Below is the syntax of reader response messages to host:

```
$ OK<CR>
$ ERROR<CR>
$ CKERR<CR>
$ {Valor parâmetro}<CR>
```

Messages and replies must contain the prefix "\$" (dollar sign followed by space) and the carriage return terminator <CR>

The "SET" and "GET" functions should be just after the prefix and before the command separated by a space character.

In the "SET" function, the command should be followed without space of the character "=" (equal) followed by the value of the parameter you want to change.

Messages sent to the reader may have upper and/or lower case letters.

The TCP connection to the configuration port has a 3-minute inactivity timeout, in which case after an established connection no data exchange occurs between the Host and the Reader for more than three minutes, the reader terminates the connection and the Host must reconnect with the Reader.

10.3.3 Checksum of messages

In ASCII message exchanges, you can use two checksum digits at the end of the message and before the terminator as a way of verifying the integrity of messages exchanged between the host and the reader. Checksum can be enabled to be used in messages that are transmitted and received from the reader. The checksum must be calculated and returned as two ASCII characters representing the hexadecimal value of the module of the sum of the ASCII codes of the message characters, without the prefix and terminator. Example, message "GET RDPOWER":

\$ GET RDPOWER23<CR> Host → Reader - Host sends message with checksum.

\$ 2700C9<CR> Host ← Reader - Reader responds with parameter value and checksum.

In this example, the sum of the message characters is 0x0323, the checksum of the message should be the least significant characters of the sum, in this case it is 23.

To disable checksum usage, use the message below:

\$ SET CHKSUM=OFFEF<CR> Host → Reader - Host sends the message with checksum.



When checksum is enabled, the reader response will also contain the two ASCII characters representing the sum in case a checksum error is detected in a message received by the reader, the error message "CKERR" is sent to the host. Example, with checksum enabled:

\$ GET RDPOWER<CR> Host → Reader - Host sends message without checksum.

\$ CKERR<CR> Host ← Reader - Reader responds with checksum error.

10.3.4 Example of use

Terminal emulator software, such as PuTTY or TeraTerm, should be used when a user wants to check or change reader parameters via ASCII messages.



10.3.5 Checking the status of the reader

Command	Function	Description						
		Version of rf module built into reader, is RFID firmware.						
RFVER	GET	<p>Example:</p> <pre>\$ GET RFVER<CR> \$ 01.07.03.25<CR></pre> <table border="1"> <thead> <tr> <th>Direction</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Host → Reader</td> <td>Host sends message.</td> </tr> <tr> <td>Host ← Reader</td> <td>Reader responds with the value of version.</td> </tr> </tbody> </table>	Direction	Description	Host → Reader	Host sends message.	Host ← Reader	Reader responds with the value of version.
Direction	Description							
Host → Reader	Host sends message.							
Host ← Reader	Reader responds with the value of version.							
		Firmware version of the reader is the firmware of the Autoid System.						
FWVER	GET	<p>Example:</p> <pre>\$ GET FWVER<CR> \$ 3.0.1<CR></pre> <table border="1"> <thead> <tr> <th>Direction</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Host → Reader</td> <td>Host sends message.</td> </tr> <tr> <td>Host ← Reader</td> <td>Reader responds with the value of the version.</td> </tr> </tbody> </table>	Direction	Description	Host → Reader	Host sends message.	Host ← Reader	Reader responds with the value of the version.
Direction	Description							
Host → Reader	Host sends message.							
Host ← Reader	Reader responds with the value of the version.							
		Reader name automatically generated.						
RDRNAME	GET	<p>Example:</p> <pre>\$ GET RDRNAME<CR> \$ EDGE30R-010101<CR></pre> <table border="1"> <thead> <tr> <th>Direction</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Host → Reader</td> <td>Host sends message.</td> </tr> <tr> <td>Host ← Reader</td> <td>Reader responds with the value of the name</td> </tr> </tbody> </table>	Direction	Description	Host → Reader	Host sends message.	Host ← Reader	Reader responds with the value of the name
Direction	Description							
Host → Reader	Host sends message.							
Host ← Reader	Reader responds with the value of the name							
		Reader serial number.						
RDRSN	GET	<p>Example:</p> <pre>\$ GET RDRSN<CR> \$ 3338646<CR></pre> <table border="1"> <thead> <tr> <th>Direction</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Host → Reader</td> <td>Host sends message.</td> </tr> <tr> <td>Host ← Reader</td> <td>Reader responds with your nu serial.</td> </tr> </tbody> </table>	Direction	Description	Host → Reader	Host sends message.	Host ← Reader	Reader responds with your nu serial.
Direction	Description							
Host → Reader	Host sends message.							
Host ← Reader	Reader responds with your nu serial.							

Checks the connection status of the data communication port.

		Example:	Direction	Description
STATCONN1 STATCONN2	GET	\$ GET STATCONN1<CR>	Host → Reader	Host sends the message.
		\$ DISCONNECTED<CR>	Host ← Reader	Disconnected port.
		\$ GET STATCONN2<CR>	Host → Reader	Host envied a message.
		\$ CONNECTED 192.168.0.84:63344<CR>	Host ← Reader	Connected to IP:PORT.

Checks at the time of command execution what the status of the reader's RF channel is, whether it is transmitting [ON] or idle [OFF].

		Example:	Direction	Description
RFSTAT	GET	\$ GET RFSTAT<CR>	Host → Reader	Host sends the message.
		\$ ON<CR>	Host ← Reader	O canal RF está transmitindo
		\$ GET RFSTAT<CR>	Host → Reader	Host sends message.
		\$ OFF<CR>	Host ← Reader	The RF channel is idle.

Checking the status of the reader (continued):

Checks for the presence of a tag being read by the reader, [ON] there is a tag present, and [OFF] there is no tag present.

		Example:	Direction	Description
TGPRSNT	GET	\$ GET TGPRSNT<CR>	Host → Reader	Host sends the message.
		\$ ON<CR>	Host → Reader	There is a tag present, being read.
		\$ GET TGPRSNT<CR>	Host → Reader	Host sends the message.
		\$ OFF<CR>	Host ← Reader	No tag present.

Checks the last status of the internal bed clock synchronization attempt with the SNTP server, returns [OK] for success, and [FAILED] for error in automatic adjusting the reader clock.

		Example:	Direction	Description
NTPSYNC	GET	\$ GET NTPSYNC<CR>	Host → Reader	Host sends the message.
		\$ OK<CR>	Host ← Reader	The clock has been successfully synchronized.

Verifica a temperatura interna do leitor.

		Example:	Direction	Description
TEMPMOD	GET	\$ GET TEMPMOD<CR>	Host → Reader	Host envia a mensagem.
		\$ 44<CR>	Host ← Reader	Internal temperature 44°C.

Verifica o status da conexão da porta de comunicação de dados.

		Example:	Direction	Description
TMALIVE TMALIVEFMT	GET	\$ GET TMALIVE<CR>	Host → Reader	Host sends the message.
		\$ 80577<CR>	Host ← Reader	80577 seconds without rebooting.
		\$ GET TMALIVEFMT<CR>	Host → Reader	Host sends message.
		\$ 0d 22:23:00<CR>	Host ← Reader	Time in days min hours. Mon.

10.3.6 Configuring Security

Changes or verifies the reader description, which must be a maximum of 30 characters.
Note: You do not need to reboot the reader.

		Example:	Direction	Description
RDRDSC	SET/GET	\$ SET RDRDSC=Entrada Frontal<CR>	Host → Reader	Host sends the message to change parameters.
		\$ OK<CR>	Host → Reader	Reader responds with OK, that is, parameter changed successfully.
		\$ GET RDRDSC<CR>	Host → Reader	Host envia a mensagem.
		\$ Entrada Frontal<CR>	Host ← Reader	Leitor responde com valor do parâmetro

Altera ou verifica o código de segurança Autoid, que deve possuir valor numérico de seis dígitos.
Nota: não necessita reinicializar o leitor.

		Example:	Direction	Description
CODSEC	SET/GET	\$ SET CODSEC=FF0102<CR>	Host → Reader	Host sends the message to change the Autoid security code.
		\$ ERROR<CR>	Host ← Reader	The reader returns error because the code must be numeric
		\$ SET CODSEC=900167<CR>	Host → Reader	Host sends the message to change the Autoid security code.
		\$ OK<CR>	Host ← Reader	The reader returns OK, that is, the parameter has changed.

AUTOID	SET/GET	Changes or checks the type of Autoid System that the reader will perform to do tag readings. [NORMAL] values for Autoid Normal,[SECURE] for Autoid Safe and [HYBRID] for Autoid Hybrid. <i>Note: You do not need to reboot the reader.</i>		
--------	---------	---	--	--

<i>Exemplo:</i>	<i>Direction</i>	<i>Description</i>
\$ GET AUTOID<CR>	Host → Reader	Host sends message to check which Autoid System is running.
\$ NORMAL<CR>	Host ← Reader	Reader replies that it is Autoid Normal.
\$ SET AUTOID=SECURE<CR>	Host → Reader	Host sends message to change the Autoid System to Safe mode.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

10.3.7 Setting Up Network

Changes or verifies the IP address of the reader [IPADDR], the network mask [MKADDR] and the gateway address [GWADDR], the addresses must be in IPv4 format.

Note: You must reset the reader after changing these parameters by sending the message with the restart command "\$ RSTRDR<CR>".

	<i>Example:</i>	<i>Direction</i>	<i>Description</i>
	\$ GET MKADDR<CR>	Host → Reader	Host sends the message to check the network mask.
	\$ 255.255.255.0<CR>	Host ← Reader	Reader responds with the mask value.
IPADDR MKADDR GWADDR	SET/GET		
	\$ SET IPADDR=192.168.1.100<CR>	Host → Reader	Host sends the message to change the IP address.
	\$ OK<CR>	Host ← Reader	Reader responds OK, address changed.
	\$ SET GWADDR=192.168.1.2<CR>	Host → Reader	Host sends the message to change the address of the gateway.
	\$ OK<CR>	Host ← Reader	Reader responds with OK, address changed.
	\$ RSTRDR<CR>	Host → Reader	Host envia a mensagem para reinicializar o leitor para que as alterações.
	\$ OK<CR>	Host ← Reader	Reader responds with OK.

DNS1ADDR	SET/GET	Changes or verifies the IP address of the DNS server that will be queried by the reader to resolve names. <i>Note: You do not need to reboot the reader.</i>
----------	---------	---

Example:	Direction	Description
\$ GET DNS1ADDR<CR>	Host → Leitor	Host sends the message to verify the address of the DNS server.
\$<CR>	Host ← Reader	Reader responds with the value of the address; in this case it is empty.
\$ SET DNS1ADDR=192.168.0.15<CR>	Host → Reader	Host envia a mensagem para alterar o endereço IP do servidor DNS.
\$ OK<CR>	Host ← Reader	Reader responds OK.

Setting Up Network (continued):

Changes or verifies the name or IP address of the SNTP server for synchronization of the reader's internal clock.

Note: You do not need to reboot the reader.

Note: If a name is used in this parameter, the DNS server must be configured correctly.

Example:	Direction	Description
\$ GET NTP1ADDR<CR>	Host → Reader	Host sends the message to change the Autoid security code.
<i>NTP1ADDR SET/GET</i> \$ a.st1.ntp.br<CR>	Host ← Reader	The reader returns with the name to change the name of the SNTP server.
\$ SET NTP1ADDR=b.st1.ntp.br<CR>	Host → Reader	Host sends the message to change the name of the SNTP server.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or verifies the name or IP address of the SYSLOG server to receive log messages from the reader.

Note: You do not need to reboot the reader.

Note: If a name is used in this parameter, the DNS server must be configured correctly.

Example:	Direction	Description
\$ GET SYSLGADDR<CR>	Host → Reader	Host sends the message to check the Syslog server.
<i>SYSLGADDR SET/GET</i> \$ <CR>	Host ← Reader	Reader returns with the Syslog address, in this case empty, there is no servidor cadastrado.

\$ SET SYSLGADDR=192..168.0.84<CR>	Host → Reader	Host sends the message to change the IP address of the Syslog server.
\$ ERROR<CR>	Host ← Reader	Reader responds with error because the address format was incorrect.
\$ SET SYSLGADDR=192.168.0.84<CR>	Host → Reader	Host sends the message to change the IP address of the Syslog server.
\$ OK<CR>	Host ← Reader	Leitor responde com OK.

Network Configuration (continued):

Changes or verifies the tcp communication port number [DTPORT] and the configuration TCP port number [CFPORT]. Values from 1000 to 65535.

Note: You do not need to reboot the reader.

Note: If there is already a connection established at the time of changing tcp ports, the new value will only be used by the reader on the next connection attempt, the existing connection will not be affected.

		Example:	Direction	Description
DTPORT CFPORT	SET/GET	\$ GET DTPORT<CR>	Host → Reader	Host sends the message to check the value of the TCP communication port of the tag read results.
		\$ 8080<CR>	Host ← Reader	Reader responds with the value of the TCP port.
		\$ SET DTPORT=8888<CR>	Host → Reader	Host sends the message to change the value of the TCP communication port.
		\$ OK<CR>	Host ← Reader	Reader replies that the change was successful.
		\$ GET PORT<CR>	Host → Reader	Host sends the message to read the value of the TCP port configuration.
		\$ 9090<CR>	Host ← Reader	Reader returns the value of the TCP port.

Checks the physical address of the reader's Ethernet interface in two formats, decimal "MACDEC" and hexadecimal "MACHEX".

		Example:	Direction	Description
MACDEC MECHEX	GET	\$ GET MACDEC<CR>	Host → Reader	Host sends the message to read the MAC in decimal.
		\$ 0.36.119.81.147.94<CR>	Host ← Reader	Reader responds with the decimal value.
		\$ GET MACHEX<CR>	Host → Reader	Host sends message to read MAC in hexadecimal.
		\$ 00:24:77:51:93:5E<CR>	Host ← Reader	Reader responds with the value in hexa.

10.3.8 Setting Up Reading

Changes or checks the read mode that will be used by the reader. [AUTO] values for continuous read mode and [TRIGGER] for read-only trigger mode in vehicle detection.

Note: You do not need to reboot the reader.

		Example:	Direction	Description
RDMD	SET/GET	\$ GET RDMD<CR>	Host → Reader	Host sends the message to check which read mode is running by the reader.
		\$ AUTO<CR>	Host ← Reader	Reader responds with continuous reading mode.
		\$ SET TDMD=TRIGGER<CR>	Host → Reader	Host sends the message to change the read mode to Trigger.
		\$ OK<CR>	Host ← Reader	Reader responds OK, successful change.

Changes or checks the time, in seconds, of the read trigger. Values from 1 to 600s are allowed.

Note: You do not need to reboot the reader.

Note: Parameter used only when read mode is Trigger.

		Example:	Direction	Description
RDTMTRG	SET/GET	\$ SET RDTMTRG=10<CR>	Host → Reader	Host sends the message to change the value to read 10s after the trigger signal.
		\$ OK<CR>	Host ← Reader	The reader returns OK.
		\$ SET RDTMTRG=0<CR>	Host → Reader	Host sends the message to change the value to 0s.
		\$ ERROR<CR>	Host ← Reader	The reader returns Error because the past value is outside the allowed range.

Changes or checks the time, in seconds, filtering the same tag. Values from 0 to 600s are allowed.

Note: You do not need to reboot the reader.

		Example:	Direction	Description
FTSMTG	SET/GET	\$ GET FTSMTG<CR>	Host → Reader	Host sends the message to read the time value of the same tag filter.
		\$ 1<CR>	Host ← Reader	Reader replies that the value is 1s.
		\$ SET FTSMTG=0<CR>	Host → Reader	Host sends the message to change the value to 0s, that is, no filter.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Setting Reading (continued):

Changes or checks the value of the reading power in centidBm. Values from 500 to 3000 centidBm are allowed.

Note: You do not need to reboot the reader.

		Example:	Direction	Description
RDPOWER	SET/GET	\$ GET RDPOWER<CR>	Host → Reader	Host sends the message to read the read power value.
		\$ 3000<CR>	Host ← Reader	Reader responds that the value is 30dBm.
		\$ SET RDPOWER=1000<CR>	Host → Reader	Host sends the message to change the value of 10dBm.
		\$ OK<CR>	Host ← Reader	Leitor responde com OK.

Changes or checks the filter value by signal level (RSSI). Values from 20 to 99 dbm are allowed, leaving the value empty disables the filter.
Note: You do not need to reboot the reader.

		Example:	Direction	Description
FTRSSI	SET/GET	\$ GET FTRSSI<CR>	Host → Reader	Host sends the message to read the rssi filter value.
		\$ 50<CR>	Host ← Reader	Reader replies that the value is -50dBm.
		\$ SET FTRSSI=<CR>	Host → Reader	Host sends the message to change the value to empty, disabling the filter by RSSI.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Time between transmission of ids read at the same time.
Note: You do not need to reboot the reader.
Note: Time used only when more than one tag is read at the same time.

		Example:	Direction	Description
DELAYTX	SET/GET	\$ GET DELAYTX<CR>	Host → Reader	Host sends the message to read the broadcast value of ids.
		\$ 200<CR>	Host ← Leitor	Reader responds that the value is 200.
		\$ SET DELAYTX=200<CR>	Host → Reader	Host sends the message to change the transmission value of read ids to 200.
		\$ OK<CR>	Host ← Reader	Leitor responde com OK.

Setting Reading (continued):

Changes or verifies which Id should be sent by the communication interface when a vehicular tag associated with a personal tag is identified and approved. [VEHICLE] values to send vehicle tag Id, [DRIVER] to send Driver Tag Id, and [BOTH] to send the two Ids, first from the vehicle and then from the driver.
Note: You do not need to reboot the reader.
Note: Parameter used only when the autoid system type is secure.

		Example:	Direction	Description
SNDOPT	SET/GET	\$ GET SNDOPT<CR>	Host → Reader	Host sends the message to check which id should be sent in case of membership.
		\$ VEHICLE<CR>	Host ← Reader	Reader responds with the vehicular tag id.

\$ SET SNOPT=DRIVER<CR>	Host → Reader	Host sends the message to change the parameter.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or verifies the id that will be sent when an associated vehicular tag is identified by the reader, and the driver tag associated with the car tag has not been identified. The Id value must be a maximum of 8 characters and in hexadecimal format.
Note: You do not need to reboot the reader.
Note: Parameter used only when the autoid system type is secure.

IDERR SET/GET

Example:	Direction	Description
\$ GET IDERR=99999999<CR>	Host → Reader	Host sends the message to change the value of the binding error id.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or checks the wait time in seconds to send the error id configured in "IDERR". Values allowed from 3 to 60s.
Note: You do not need to reboot the reader.
Note: Parameter used only when autoid system type is safe.

IDERRTM SET/GET

Example:	Direction	Description
\$ GET IDERRTM<CR>	Host → Reader	Host sends the message to read the time value.
\$ 3<CR>	Host ← Reader	Reader replies that the value is 3s.
\$ SET IDERRTM=10<CR>	Host → Reader	Host sends the message to change the value to 10s, that is, when an associated vehicular tag is identified, the reader will try for 10s to read the driver tag associated with the car tag.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

Setting Reading (continued):

Changes or checks the value of the mask that the Id must contain to be read. Values allowed hexadecimal characters of a maximum of 24 digits.

Note: You do not need to reboot the reader.

Note: Parameter used only when autoid system type is Normal.

		Example:	Direction	Description
SELFTMSK	SET/GET	\$ GET SELFTMSK<CR>	Host → Reader	Host sends the message to read the mask value.
		\$ 123456789ABC<CR>	Host ← Reader	Reader replies that the value is 3s.
		\$ SET SELFTMSK=00AABB<CR>	Host → Reader	Host sends the message to change the value of the mask, that is, only tags with this mask value starting in the digit configured in SELFTDG will be read by the reader.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or checks the value of the initial digit at which the mask provided above starts in tag Id. Values allowed 0 to 24.

Note: You do not need to reboot the reader.

Note: Time used only when more than one tag is read at the same time.

		Example:	Direction	Description
SELFTDG	SET/GET	\$ GET SELFTDG<CR>	Host → Reader	Host sends the message to read the mask value.
		\$ 0<CR>	Host ← Reader	Reader replies that the value is 0.
		\$ SET SELFTDG=5<CR>	Host → Reader	Host sends the message to change the digit value to 5, that is, only tags with that mask value starting at digit 5 will be read by the reader.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

10.3.9 Configurando Comunicação

Changes or verifies which communication interface the reader should use. Values [WIEGAND, WG, ABATRACK, ABA, GPO].

Note: None (GPO) to use w1/DATA and W0/CLK signals as digital outputs triggered via ASCII messages.

		Example:	Direction	Description
INTFPRTCL	SET/GET	\$ GET INTFPRTCL<CR>	Host → Reader	Host sends the message to check which interface it is using.
		\$ WIEGAND<CR>	Host ← Leitor	Reader responds.
		\$ SET INTFPRTCL=WIEGAND<CR>	Host → Reader	Host sends the message to change the parameter.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or checks the number of bits of Wiegand communication. Values [26, 34].
Note: Parameter used only when the communication interface type is Wiegand.

		Example:	Direction	Description
WGBILTEN	SET/GET	\$ SET WGBILTEN=26<CR>	Host → Reader	Host sends the message to change the number of bits to 26..
		\$ OK<CR>	Host ← Reader	Reader responds with OK, successful change.

Changes or checks the number of digits of the Abatrack interface (CLOCK/DATA). Values [10, 14].
Note: Parameter used only when the communication interface type is Abatrack.

		Example:	Direction	Description
ABADIGLEN	SET/GET	\$ SET ABADIGLEN=14<CR>	Host → Reader	Host sends the message to change the number of digits to 14.
		\$ OK<CR>	Host ← Reader	Reader responds with OK, successful change.

Changes or checks the Data String that the reader sends over the Ethernet interface at each data reading. Data String uses keywords that are replaced by read results.

		Example:	Direction	Description
STRDT	SET/GET	\$ SET STRDT=id do tag:IDWG<CR>	Host → Reader	Host sends the message to change the data string.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Configuring Communication (continued):

Change or check the Keepalive String, maximum 15 characters, for more details see section 10.1.
Note: You do not need to reboot the reader.

STRKP	SET/GET	Example:	Example:	Example:
		\$ SET STRKP=RN<CR>	Host → Reader	Host sends the message to change the keepalive string.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or checks the time in seconds of the Keepalive String send interval. Values from 1 to 60s.
Note: You do not need to reboot the reader.

TMKP	SET/GET	Example:	Direction	Description
		\$ SET TMKP=10<CR>	Host → Reader	Host sends the message to change the range to 10s.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or checks the sending of the internal temperature in °C from the rf module of the reader to the Syslog. Values [ON, OFF].
Note: You do not need to reboot the reader.

SYSLGTEMP	SET/GET	Example:	Direction	Description
		\$ SET SYSLGTEMP=ON<CR>	Host → Reader	Host sends the message to enable the sending of the temperature to Syslog.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Changes or verifies what should be sent in the 'tag' field of reader-generated Syslog messages. [NAME] values to send the reader's name and [DESC] to send the reader description.
Note: You do not need to reboot the reader.

SYSLGTAG	SET/GET	Example:	Direction	Description
		\$ SET SYSLGTAG=DESC<CR>	Host → Reader	Host sends the message to send reader description in the 'tag' field syslog messages.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

10.3.10 Configuring GPIO

Changes or checks the time in milliseconds when the reader's digital input signal must remain enabled for the read operation to fire in trigger mode. Values from 0 to 1000ms.

Note: You do not need to reboot the reader.

		Example:	Direction	Description
TMFTDB	SET/GET	\$ SET TMFTDB=500<CR>	Host → Reader	Host sends the message to change the debouncing time to 500ms.
		\$ OK<CR>	Host ← Reader	Reader responds with OK, successful change.

Configuring GPIO (continued):

Changes or checks the option to reverse the trigger signal trigger logic. Values [ON, OFF].

Note: You do not need to reboot the reader.

		Example:	Direction	Description
INVINPT	SET/GET	\$ SET INVINPT=ON<CR>	Host → Reader	Host sends the message to reverse the logic of triggering the reader's digital input.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

Checks the logical state of the reader's digital input (ISO IN). Values [0 and 1].

Note: You do not need to reboot the reader.

		Example:	Direction	Description
INPUT0	GET	\$ GET INPUT0<CR>	Host → Reader	Host sends the message to check the logical state of the digital input.
		\$ 0<CR>	Host ← Reader	Reader responds with 0, low level.

Changes or checks output output from the OUTPUT0. Values [0 or 1] high or low level, [~] to reverse the logical state of the output and [*] to trigger the pulse of the laser.

Note: Parameter used only when the communication interface type is None.

		Example:	Direction	Description
OUTPUT0 OUTPUT1	SET/GET	\$ SET OUTPUT0=0<CR>	Host → Reader	Host sends the message to configure the OUTPUT0 output to turn off the laser.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.
		\$ SET OUTPUT0=1<CR>	Host → Reader	Host sends message to set output0 output to turn on the laser.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

\$ SET OUTPUT0=~<CR>	Host → Reader	Host sends the message to reverse the logical state of the I.A.
\$ OK<CR>	Host ← Reader	Reader responds with OK.
\$ SET OUTPUT0=*<CR>	Host → Reader	Host sends the message to trigger the laser's pulse.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

Configuring GPIO (continued):

Individually changes or checks the initial logical state of OUTPUT0 to (W0/CLK) and OUTPUT1 to (W1/DATA). Values [0 or 1].
Note: Note: You do not need to reboot the reader.

Note: The initial logical state refers to the output state at reader startup.

INITOUTPUT0
 INITOUTPUT1 SET/GET

Example:	Direction	Description
\$ SET INITOUTPUT0=1<CR>	Host → Reader	Host sends the message to configure the initial logical state of the OUT0 output.
\$ OK<CR>	Host ← Reader	Reader responds with OK.

10.3.11 Miscellaneous settings

Command to reboot the reader, some settings require the reader to restart.

	Example:	Direction	Description
RSTRDR	\$ RSTRDR<CR>	Host → Reader	Host sends the message to restart the reader.
	\$ OK<CR>	Host ← Reader	Reader responds with OK and then reboots.

Checks the region of operation (frequencies and regulations) that was recorded at the factory for the operation of the reader.

	Example:	Direction	Description
REGION GET	\$ GET REGION<CR>	Host → Reader	Host sends the message to check what the operation region is. Reader responds with the Region of Brazil and Anatel regulations are being used.
	\$ BR (ANATEL)<CR>	Host ← Reader	Reader responds with the Region of Brazil and Anatel regulations are being used.

Changes or checks the use of daylight-saving time on the reader's internal clock. Values [ON, OFF].
Note: You do not need to reboot the reader.

<i>DLSV</i>	<i>SET/GET</i>	Example:	Direction	Description
		\$ SET DLSV<CR>	Host → Reader	Host sends the message to disable daylight saving time on the reader's internal clock.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.


Changes or checks the use of checksum in messages. Values [ON, OFF].

<i>CHKSUM</i>	<i>SET/GET</i>	Example:	Direction	Description
		\$ SET CHKSUM=ON<CR>	Host → Reader	Host sends the message to enable checksum usage in messages.
		\$ OK9A<CR>	Host ← Reader	Reader responds with ok and checksum.
		\$ SET CHKSUM=OFFEF<CR>	Host → Reader	Host sends the message to disable the use of checksum in messages.
		\$ OK<CR>	Host ← Reader	Reader responds with OK.

11 Data communication

11.1 TCP/IP connections to receive tag readings

The Edge-30R(-N)+ Autoid reader has the behavior of a Server and is capable of providing up to 2 (two) simultaneous TCP/IP connections for communication of the tag read data, in addition to the Serial Interfaces RS232 and Wiegand/Abatrack, that is, up to two different software (processes) that are on the same Ethernet network of the reader, can connect to it to receive the tag reading results. The TCP/IP port number is configurable on the "Network" html page or via ascii command "DTPORT".



NOTE: Some Anti-Virus and Firewalls may block the communication ports mentioned in the illustration above, and it is not possible to send and receive data. To solve the problem, add exceptions to the IP used by the reader.

NOTE: TCP/IP port available for data receipt can be configured on the html page and by SLT software.


11.2 TCP/IP connection, disconnection, and reconnection logic

Readers have the behavior of a Server, that is, it accepts TCP/IP connections on the user-configured port. Below are some important points regarding the reader server behavior:

- The reader accepts up to six (6) simultaneous connections on the configured port;
- For reconnection in case of passive disconnection, the Keepalive time interval must be respected.
- If after an already established connection, the physical link of the network drops (LED LINK of the PCI Interface erased), that is, there is no more physical connection between the reader and the host, it is recommended an attempt to reconnect by the host.

For connection/disconnect/reconnection logic it is recommended to constantly check the Keepalive String + Keepalive end of line sent by the reader constantly even when there is no tag, so it is possible to check if a connection has been lost. The send interval of keepalive is configured in Keepalive time interval, it is recommended a timeout interval of receiving data by the host of a time value equal to or greater than the value configured in this parameter.

Below is a simple flowchart with the host logic of receiving the data sent by the reader.



11.3 Format of reading results via TCP/IP and RS232

The format in which data is sent via Ethernet can be *configured using the Data String parameter* that uses key words to combine the results of reading tags with other desirable characters in the final string that the reader must send.

With this type of configuration, it is possible to create a compatibility between the reader and Software Systems already developed.

Palavras chaves:

Palavra chave	Descrição	Tamanho	Exemplo
IDHEX	ID do tag no formato hexadecimal.	8 bytes	3DAC0022
IDWG	ID do tag no formato wiegand26 'FC[3dig.]ID[5dig.]'	8 bytes	17200034
IDABA	ID do tag no formato abatrack 'ID[10dig.]'	10 bytes	1034682402
RDCT	Número de leituras do tag.	1 byte	8
RSSI	Valor do nível de sinal (negativo) do tag lido.	3 bytes	-64
ANTID	Número da antena que o tag foi lido.	1 byte	1
TMSTP	Timestamp [dd-mm-aaaa hh:mm:ss].	19 bytes	21-09-2015 14:58:23
TYPE	Tipo do tag lido, 'S' p/ Seguro e 'N' p/ Normal	1 byte	S
ALIVE	Tempo de atividade do leitor em segundos	1~10 bytes	67890
<CR>	Caractere de controle Carriage Return [0x0D].	1 byte	
<LF>	Caractere de controle Line feed [0x0A].	1 byte	
<STX>	Caractere de controle Start of text [0x02].	1 byte	
<ETX>	Caractere de controle End of text [0x03].	1 byte	

Exemplos:

- String de dados configurada na página html:
Tag ID: 0xIDHEX, Qt leitura: RDCT, Antena: ANTID, Sinal tag: RSSI;<CR><LF>
 String enviada pelo leitor após ler um tag 6 vezes com ID= 3DAC337A e RSSI= -65dBm na antena integrada:
Tag ID: 0x3DAC337A, Qt leitura: 06, Antena: 1, Sinal tag: -65;<CR><LF>
- String de dados configurada na página html:
0xIDHEX IDWG – Exemplo de leitura de tag... :)
 String enviada pelo leitor após ler um tag com ID= 3DAC337A:
0x3DAC337A 17213178 – Exemplo de leitura de tag... :)
- String de dados configurada na página html:
IDABa IDABA idaba IDHexa :)
 String enviada pelo leitor após ler um tag com ID= 3DAC337A:
IDABa 1034695546 idaba IDHexa :)

Regras de formato da String de dados:

1. Somente pode haver duplicidade dos caracteres de controle <CR> <LF> <STX> <ETX>, as demais palavras chaves não podem ser duplicadas;
2. A String de dados deve conter ao menos uma das palavras chaves IDHEX, IDWG ou IDABA;
3. As palavras chaves são diferenciadas de maiúsculo e minúsculo;
4. O tamanho máximo da String de dados enviada pelo leitor é de 115 caracteres;

11.4 Syslog

O leitor implementa o protocolo Syslog (RFC 5424) para enviar mensagens de log e status de seu funcionamento, o Servidor Syslog deve ser configurado no padrão UDP porta 514.

Formato das mensagens do leitor no padrão Syslog:

Facility	Código	Descrição
Local 1	17	O leitor sempre usará esse facility para as mensagens de Syslog.

Severity/Level	Código	Descrição
Alert	01	Indica um estado de alerta do leitor, uma ação deve ser tomada.
Error	03	Indica uma ocorrência de erro interno do leitor.
Warning	04	Indica uma ocorrência que requer atenção.
Informational	06	Indica ocorrências normais de funcionamento do leitor

Timestamp	Exemplo
Mmm dd hh:mm:ss	Jul 31 16:08:50

Tag	Exemplo (nome do leitor)
Nome do leitor ou Descrição do leitor	EDGE30R-5194EC

Origin / Hostname	Descrição
Endereço IP do leitor	Neste campo da mensagem, é enviado o endereço IP do leitor

Message	Category	Description
Messages are divided into categories	BOOT	Messages about the firmware boot of the reader.
	CLOCK	Messages related to the internal clock process.
	DNS	Messages related to the DNS name resolution process of the SNTP and Syslog servers.
	HMTL	Messages from the reader's internal Web server.
	INIT	Reader startup messages, before firmware boot.
	INPUT	Messages related to the digital input of the reader.
	MRF	Messages from the reader's main process.
	NET	Messages related to the reader's Ethernet interface.
	PARAM	Messages related to settings parameters.
	RST	Messages on pci interface reset button.
	SNTP	Messages related to the timing process of the reader's internal clock with SNTP server.
	TRIGGER	Messages related to Trigger read mode.
	SYS	Messages generated by the Syslog process.

Features of reader Syslog:

- Reader log/status messages are not stored in non-volatile memory by the messages are generated and sent in real time;
- The frequency of sending Syslog messages by the reader is 2Hz, i.e. every 500ms the reader's internal process consumes the message buffer and sends it to the Syslog Server;
- If the 'Send internal temperature of the reader's RF module to Syslog' parameter is enabled, a message is generated with each temperature degree change;
- Messages in the PARAM category show at the end of the message, between [], the current value modified of the parameter in question;

12 Mensagens de Log do leitor - Syslog

Collecting syslog messages from the reader is very important to make a diagnosis of how the reader is behaving in its operating environment. It is recommended to collect messages even if the reader is being used with Wiegand or Abatrack interface.

Reader Syslog messages have complete information about their behavior, from their temperature to parameter changes by the user, so to obtain a complete diagnosis for monitoring or analysis of reader errors is necessary to collect and store Syslog messages.

To collect the Syslog messages that the reader generates, you need software (Syslog Server) that will run on a Host on the same Ethernet network that the reader is on, this Software is responsible for receiving and storing the messages for further analysis.

The IP or hostname of the computer that will receive the messages must be properly configured on the reader, please refer to [the Network Configuring](#).

Below is a recommendation for Syslog Server software:

Visual Syslog Server: <https://visual-syslog-server.software.informer.com/1.6/>

To perform access to the Visual Syslog Server, you must place the COMPUTER IP with the Software installed in this field:

**Edge-30R
Autoid Seguro**

- Status
- Segurança
- Rede**
- Leitura
- Comunicação
- I/O
- Data e Hora
- Restart
- Logout

MAC: 00:24:77:53:42:55
0:36:119:83:66:85

SN: 0000000

Nome: EDGE30R-534255

© 2012 - 2022 ACURA

Rede Ethernet

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

Configurações de Rede

Modo Ethernet (comportamento do leitor)	<input checked="" type="radio"/> Servidor <input type="radio"/> Cliente
Endereço IP do leitor	<input type="text"/>
Máscara de rede	<input type="text"/>
Endereço Gateway	<input type="text"/>
Servidor DNS	<input type="text"/>
Servidor SNTP	<input type="text" value="a.st1.ntp.br"/>
Servidor SYSLOG	<input type="text"/>

Portas TCP

Porta TCP Comunicação de dados (modo Servidor)	<input type="text" value="8080"/>
Porta TCP Configuração (modo Servidor)	<input type="text" value="9090"/>

Aplicar
Reload

Nota 1: As novas configurações serão aplicadas, salvas e executadas no leitor após clicar em "Aplicar".
 Nota 2: A reinicialização do leitor será necessária somente quando o aviso de Restart aparecer na página.
 Nota 3: As configurações salvas nesta página são mantidas na memória Flash do leitor, não são perdidas com seu desligamento.
 Nota 4: O tempo da sessão é 3min, após esse tempo é preciso fazer o login novamente. Os botões "Reload" e "Aplicar" reinicializam o tempo da sessão.

© 2012 - 2022 ACURA (Your Trusted RFID Partner) - ACURA.COM.BR

After that, access the Visual Syslog Server and track the behavior of the reader.

13 Regional Regulations

13.1 Frequencies and operating region

When booting the Edge-30R Autoid reader, the operating frequencies (Hop-Table) are configured according to the pre-established region in the reader firmware. For the Brazil, the configured frequencies are:

ANATEL (Brazil) Edge-30R+ 902 to 907MHz and 915 to 928MHz
ANATEL (Brazil) Edge-30R-N 915 to 928MHz

13.2 RF reader power

For any combination of antenna and cable used with this reader, the maximum RF power issued by the reader must be determined by means of the following equation:

$$P_{max} = 36 \text{ dbm}^3 - \text{Antenna Gain}^4 + \text{Cable Loss}^5$$

The maximum configurable power on the reader is 30 dBm (for Edge-30R+) and 27 dBm (for Edge-30R-N+).

Thus, with the antenna and cable data, the power to be configured on the reader is calculated to its use, keeping in mind the maximums and minimums of the reader and respecting the standards regulations of the region in which the reader is being used.

Alert: It is the entire responsibility of the Edge 30R+ Autoid reader user to set the output RF power correctly to comply with regional RF emission standards.


³ Maximum effective power (EIRP) allowed by Anatel.

⁴ Antenna gain in dBi, some specifications may provide gain in other units.


⁵ Cable loss in dB.

14 Integrated antenna measurements


14.1 VSWR




14.2 Axial Ratio ($\pm 20^\circ$ Azimuth) 902MHz




14.3 Axial ratio ($\pm 20^\circ$ Elevation) 902MHz




14.4 Axial ratio ($\pm 20^\circ$ Azimuth) 915MHz




14.5 Axial ratio ($\pm 20^\circ$ Elevation) 915MHz




14.6 Axial ratio ($\pm 20^\circ$ Azimuth) 928MHz




14.7 Axial ratio ($\pm 20^\circ$ Elevation) 928MHz




14.8 Radiation diagram (Azimuth) 902MHz




14.9 Radiation diagram (Elevation) 902MHz




14.10 Radiation diagram (Azimuth) 915MHz




14.11 915MHz Radiation Diagram (Elevation)



14.12 Radiation diagram (Azimuth) 928MHz



14.13 928MHz Radiation Diagram (Elevation)



15 Solutions to common problems

15.1 I do not know the IP of the Reader

In this case there are two options.

1. You can use device explorer software (for Windows) to find readers that are on the same LAN network. The software shows readers and their IP and MAC addresses, with the MAC address can physically check the label on the reader's network cable. The figure below shows the device explorer software screen.




Figura 41-Tela Device Explorer

The software can be found at the link below:

https://drive.google.com/file/d/0B7DwMedDHj_ZZ0dBdi1ISjNsS2c/view?usp=sharing&resourcekey=0-crNiU87I49ZCUb2KipGOIQ

15.2 I do not know the password of the reader's page

You can restore factory settings via The Reader's Hard Reset, please refer to the to the Visual Indicators section of the reader.

15.3 Cannot connect to the Reader via Ethernet

1. Please check the "POWER" and "STATUS" LEDs of the PCI Interface, they must be lit and flashing respectively;
2. Check for a network cable connected to the PCI Interface 'HOST ETHERNET';
3. Make sure that the network cable connected to the "HOST ETHERNET" connector of the PCI Interface

-
- is properly made according to the Electrical Connections - Ethernet Network;
 4. Make sure that the two RJ45 connectors on the reader cable are connected to the PCI Interface and
in the correct order, connector "COMMAND READER" - black cable and connector "READER ETHERNET" – blue cape;
 5. Check that the "LINK" LED of the PCI Interface is lit, if it is off, check the network cable connection on switch/router/computer side;
 6. Make sure that the computer you are trying to access the reader with has the same network ID that reader;

15.4 In trigger mode, the input signal is not being activated by the sensor

1. Check the datasheet of the sensor if it has output of type "dry contact" or "NPN" or "PNP" and whether the connections made to the reader correspond to the sensor output type. Please refer to Electrical Connections - Digital Input for further explanations about connections;
2. If the sensor output is "dry contact", connect it to "ISO GND" and "ISO IN";
3. If the sensor output is of type "NPN" or "PNP", connect it to "ISO COM" and "ISO IN" and check that the sensor follows the logical levels set by the reader, as described in Electrical connections - Digital Input;
4. Finally, check on the web page of the reader if the parameter time "Filter time debouncing trigger signal" is set correctly for the sensor used.

15.5 The Reader is not reading tags

1. Check the reader's web page for the chosen "Reading Mode";
2. Check the reader's web page to see if the value of the "Filter by tag signal level" is too the reader to filter all tag readings. To check that you are filtering at the time of reading, please check the Syslog messages.



ACURA Global is the pioneer in the Radio Frequency Identification (RFID) market in Brazil and Latin America, and has successfully explored, since the late 1990s, its large-scale adoption in the most diverse sectors of the economy, from mining to agriculture to food processing, from logistics to retail, from transport to the distribution chain, from access control to asset management. Promoter of new technologies, innovative, agile and focused on the feasibility of vanguard.

Commercial and Development Office
Av. Antarctica, 381, 14th floor
Jardim do Mar - São Bernardo do Campo - SP
(11) 3028-4600

Factory and Service Center
Av. Nicolau Cesarino, 4197 - Extrema, MG
MOBILE: 37640-000
(35) 3435-1316

www.acura.com.br