### MARQUIS 5000MAH 20W PD POWER BANK W/ CHARGER & CABLES INSTRUCTION MANUAL EPB-MQ25

### READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL

#### IN THE BOX

- EPB-MQ25 Marquis 5000mAh 20W PD Power Bank w/ Charger & Cables (x1)
- Charging Cable (x1)

#### SAFFTY PRECAUTIONS

- This product is NOT a toy, keep away from children and pets.
  Only use the product according to the instructions in this manual. Never use
- the product for anything other than its intended purpose.


   Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the product should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose product or charging cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.

  Do not submerge in water. Do not use in a location where the product or charging cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.

  Do not use if the product or charging cable is damaged. If the product or
- charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Do not over charge battery.
   This product contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this product.
- Attachments on the back of your device can impede effectiveness of the wireless charger, and lead to overheating. Remove attachments from your
- device before charging on this wireless charger.

  The strong magnetic fields of neodymium magnets can damage items, such as television, computers, computer monitors, credit cards, bank cards, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switched to "test mode" in the presence of a strong magnetic force, if pace-maker or other electronical body implant is in use. Keep a minimum of 3 feet distance.

### PRODUCT DIAGRAMS



#### INSTRUCTIONS

Charge the power bank fully before using for the first time.

### CHARGING THE POWER BANK

- · Plug the small connector of the included charging cable into the USB-C port on
- Plug the other end of the cable into a USB power source, such as the USB port on a computer or into a certified USB adapter (not included), and plug into a wall socket.

  The LED indicator will **flash WHITE** while the power bank is in charging and
- stop flashing when the power bank is fully charged.

## CHARGING ELECTRONIC DEVICES WITH THE POWER BANK

- · Using the cable of the device you wish to charge, connect the charging cable to your device with the appropriate connector.

  Connect the other end of the cable to the USB-C port of the power bank.

- The power bank will begin to charge automatically.
  The LED indicator will illuminate WHITE when charging.
  Remove the cable from your mobile device when it is fully charged.

# 140 mm

## USING WIRELESS CHARGING

- Place a wireless charging enabled mobile device on the wireless charging surface, the mobile device will begin to charge automatically. The first LED indicator on the left will illuminate GREEN to indicate that your device is charging properly.
- · If your device does not begin to charge, try repositioning your device on the wireless charging surface. You may need to remove the charge properly.
- when your device is fully charged, the LED indicator will turn OFF. Remove your device from the wireless charging surface when it is fully charged.

## Note:

· If the first LED indicator on the left is flashing when the wireless charger is in use, either the device is NOT wireless charging enabled, or there is an object between the device and charging pad interfering with the charging process.

# NOTE ON SAFETY FEATURES:

The wireless charging will automatically power OFF when the wireless charging surface is overheated or when a metal object, such as a coin, is placed on the wireless charging surface. The first LED indicator on the left will **flash GREEN** alternatively to warn of automatic shutoff.

## **TECH SPECIFICATION**

- Battery Capacity: 5000mAh/3.7V/18.5Wh
   USB-C Input: DC 5V/3A 9V/2A 12V/1.5A
   USB-C Cable Input: DC 5V/3A 9V/2A 12V/1.5A

- USB-C Cable Output: DC 5V/3A 9V/2.22A 12V/1.67A
  Lightning Cable Output: DC 5V/2.4A 9V/2.22A

  USB-C Cable Output: DC 5V/2.4A 9V/2.22A
- USB Output: DC 5V/3A 9V/2A 12V/1.5A
   Wireless Output: 5W/7.5W/10W/15W
   Working Temperature: 14°F ~ 122°F (-10°C ~ 50°C)

# **FCC Warning Statement**

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
   Increase the separation between the equipment and receiver.
   Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2A9Q9-EPB-MQ25