



User Guide

R3000 Lite

Industrial Dual SIM Cellular VPN Router

1 Eth + 1 RS-232 + 1 RS-485 + 1 USB Host



robustOS

Guangzhou Robustel Technologies Co., Limited

www.robustel.com


About This Document

This document provides hardware and software information of the Robustel R3000 Lite Router, including introduction, installation, configuration and operation.

Copyright©2017 Guangzhou Robustel Technologies Co., Limited.

All rights reserved.

Trademarks and Permissions

 robustel, robustOS are trademarks of Guangzhou Robustel Technologies Co., Limited. All other trademarks and trade names mentioned in this document are the property of their respective owners.

Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner. The contents of this document are subject to change without notice due to continued progress in methodology, design and manufacturing. Robustel shall have no liability for any error or damage of any kind resulting from the use of this document.

Technical Support

Tel: +86-20-29019902

Fax: +86-20-82321505

E-mail: support@robustel.com

Web: www.robustel.com

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the router is used in a normal manner with a well-constructed network, the router should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Robustel accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the router, or for failure of the router to transmit or receive such data.

Safety Precautions

General

- The router generates radio frequency (RF) power. When using the router, care must be taken on safety issues related to RF interference as well as regulations of RF equipment.
- Do not use your router in aircraft, hospitals, petrol stations or in places where using cellular products is prohibited.
- Be sure that the router will not be interfering with nearby equipment. For example: pacemakers or medical equipment. The antenna of the router should be away from computers, office equipment, home appliance, etc.
- An external antenna must be connected to the router for proper operation. Only uses approved antenna with the router. Please contact authorized distributor on finding an approved antenna.
- Always keep the antenna with minimum safety distance of 20 cm or more from human body. Do not put the antenna inside metallic box, containers, etc.
- RF exposure statements
 1. For mobile devices without co-location (the transmitting antenna is installed or located more than 20cm away from the body of user and nearby person)
- FCC RF Radiation Exposure Statement
 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and human body.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Router may be used at this time.

Using the Router in Vehicle

- Check for any regulation or law authorizing the use of cellular devices in vehicle in your country before installing the router.
- The driver or operator of any vehicle should not operate the router while driving.
- Install the router by qualified personnel. Consult your vehicle distributor for any possible interference of electronic parts by the router.
- The router should be connected to the vehicle's supply system by using a fuse-protected terminal in the vehicle's fuse box.
- Be careful when the router is powered by the vehicle's main battery. The battery may be drained after extended period.

Protecting Your Router

To ensure error-free usage, please install and operate your router with care. Do remember the following:

- Do not expose the router to extreme conditions such as high humidity / rain, high temperature, direct sunlight, caustic / harsh chemicals, dust, or water.
- Do not try to disassemble or modify the router. There is no user serviceable part inside and the warranty would be void.
- Do not drop, hit or shake the router. Do not use the router under extreme vibrating conditions.
- Do not pull the antenna or power supply cable. Attach/detach by holding the connector.
- Connect the router only according to the instruction manual. Failure to do it will void the warranty.
- In case of problem, please contact authorized distributor.

Regulatory and Type Approval Information

Table 1: Directives



2011/65/EC	Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS)	
2012/19/EU	Directive 2012/19/EU the European Parliament and of the Council of 4 July 2012 on waste electrical and electronic equipment (WEEE)	

Table 2: Standards of the Ministry of Information Industry of the People's Republic of China


SJ/T 11363-2006	"Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products" (2006-06).	
SJ/T 11364-2006	<p>"Marking for Control of Pollution Caused by Electronic Information Products" (2006-06).</p> <p>According to the "Chinese Administration on the Control of Pollution caused by Electronic Information Products" (ACPEIP) the EPUP, i.e., Environmental Protection Use Period, of this product is 20 years as per the symbol shown here, unless otherwise marked. The EPUP is valid only as long as the product is operated within the operating limits described in the Hardware Interface Description.</p> <p>Please see Table 3 for an overview of toxic or hazardous substances or elements that might be contained in product parts in concentrations above the limits defined by SJ/T 11363-2006.</p>	

Table 3: Toxic or Hazardous Substances or Elements with Defined Concentration Limits

Name of the Part	Hazardous Substances					
	(Pb)	(Hg)	(Cd)	(Cr (VI))	(PBB)	(PBDE)
Metal parts	o	o	o	o	o	o
Circuit modules	x	o	o	o	o	o
Cables and cable assemblies	o	o	o	o	o	o
Plastic and polymeric parts	o	o	o	o	o	o

o:
Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.

x:
Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials for this part *might exceed* the limit requirement in SJ/T11363-2006.

Document History

Updates between document versions are cumulative. Therefore, the latest document version contains all updates made to previous versions.

Date	Firmware Version	Doc Version	Change Description
24 March, 2017	2.9.1	v.1.0.0	Initial release

Contents

Chapter 1	Product Concept	8
1.1	Overview	8
1.2	Package Contents	9
1.3	Specifications	11
1.4	Dimensions.....	12
1.5	Ordering Information	错误!未定义书签。
Chapter 2	Installation	13
2.1	LED Indicators.....	13
2.2	PIN Assignment	14
2.3	USB Interface.....	14
2.4	Reset Button.....	15
2.5	Ethernet Port.....	15
2.6	Mount the Router	16
2.7	Install the SIM Card	17
2.8	Connect the External Antenna (SMA Type).....	17
2.10	Grounding the Router	18
2.11	Connect the Router to PC.....	18
2.11	Power Supply.....	18
Chapter 3	Configuration Settings over Web Browser	19
3.1	Configuring for the PC.....	19
3.2	Factory Default Settings	22
3.3	Login Router	22
3.4	Control Panel.....	23
3.5	Status.....	24
3.6	Interface > Link Manager	27
3.7	Interface > LAN.....	31
3.8	Interface > Ethernet	35
3.9	Interface > Cellular	36
3.10	Interface > USB.....	39
3.11	Interface > Serial Port.....	39
3.12	Network > Route	41
3.13	Network > Firewall	42
3.14	Network > QoS	46
3.15	VPN > IPsec	48
3.16	VPN > OpenVPN	54
3.18	VPN > GRE	60
3.19	Services > Syslog.....	61
3.20	Services > Event.....	62
3.21	Services > NTP	64
3.22	Services > SMS.....	65
3.23	Services > DDNS	66
3.24	Services > VRRP	67
3.25	Services > SSH.....	68

3.26	Services > Web Server	69
3.27	Services > Advanced	70
3.28	System > Debug	71
3.29	System > Update	72
3.30	System > APP Center	73
3.31	System > Tools	73
3.32	System > Profile	77
3.33	System > Device Configuration	78
3.34	System > User Management	78
Chapter 4	Configuration Examples	80
4.1	Interface	80
4.1.1	Console Port	80
4.1.2	RS232	81
4.1.3	RS485	81
4.2	Cellular	82
4.2.1	Cellular Dial-Up	82
4.2.1	SMS Remote Control	84
4.3	Network	86
4.3.1	IPSEC VPN	86
4.3.2	OPENVPN	90
4.3.3	GRE VPN	93
Chapter 5	Introductions for CLI	96
5.1	What's CLI	96
5.2	How to Configure the CLI	96
5.3	Commands Reference	102
Glossary		104

Chapter 1 Product Concept

1.1 Overview


Robustel GoRugged R3000 Lite is a rugged cellular router offering state-of-the-art mobile connectivity for machine to machine (M2M) applications.

- Dual SIM redundancy for persistent 4G cellular network connections, enhanced keep alive feature support
- VPN tunnel - IPsec/OpenVPN/GRE/PPTP/L2TP/DMVPN
- Supports GRE over IPsec/L2TP over IPsec
- Supports 802.1Q VLAN Trunk
- Supports PPPoE Bridge
- Supports Modbus gateway (Modbus RTU/ASCII to Modbus TCP) and Modbus Master
- Auto reboot via SMS/Incoming Call/Timing
- Supports alarm via Email/SMS/SNMP trap
- Supports AAA and FTP
- Supports RobustLink (a centralized M2M management platform for remote monitoring, configuration and firmware upgrade)
- Supports RobustVPN (a Cloud VPN Portal providing easy and secure remote access for PLCs and machines)
- Flexible management methods - Web/CLI/SNMP/RobustLink
- Firmware upgrading via Web/CLI/USB/SMS/RobustLink

1.2 Package Contents


Before installing your R3000 Lite Router, verify the kit contents as following.

- 1 x Robustel GoRugged R3000 Lite Industrial Dual SIM Cellular VPN Router



Two antennas

OR



One antenna

- 1 x 3-pin pluggable terminal block with lock for power connector



- 1 x *Quick Start Guide* with download link of other documents or tools x 1

Note: If any of the above items is missing or damaged, please contact your Robustel sales representative.

Optional accessories (sold separately):

- SMA cellular antenna

The number of SMA antenna depends on the model of the router. For more details, please refer to **1.3 Specifications**.



Magnet antenna

- Wall mounting kit



- 35 mm DIN rail mounting kit




- Ethernet cable



- AC/DC power adapter (12V DC, 1.5 A; EU/US/UK/AU plug optional)



- Terminal block with a male DB9 connector for serial port connection
For details about the PIN assignment, see **2.2 PIN assignment**.



1.3 Specifications

Cellular Interface

- Number of ports: 2 (MAIN + AUX)
- Connector: SMA, female

Ethernet Interface

- Number of ports: 1 x 10/100 LAN Ethernet port
- Magnet isolation protection: 1.5 KV

Serial Interface

- Number of ports: 1 x RS232 + 1 x RS485
- Connector: DB9, female
- ESD protection: ± 15 KV
- Parameters: 8E1, 8O1, 8N1, 8N2, 7E2, 7O2, 7N2, 7E1
- Baud rate: 300 bps to 230400 bps
- RS232: TxD, RxD, RTS, CTS, GND
- RS485: Data+ (A), Data- (B)

System

- Reset button: 1 x RST
- SIM slot: 2 x SIM card slot (3 V & 1.8 V)
- LED indicators: 1 x RUN, 1 x PPP, 1 x USR, 3 x RSSI
- Expansion: 1 x USB 2.0 host up to 480 Mbps
- Built-in RTC, Watchdog, Timer

Software

- Network protocols: PPP, PPPoE, TCP, UDP, DHCP, ICMP, NAT, DMZ, RIP v1/v2, OSPF, DDNS, VRRP, HTTP, HTTPS, DNS, ARP, QoS, SNTP, Telnet, IP Passthrough, etc.
- VPN tunnel: IPsec/OpenVPN/GRE/PPTP/L2TP
- Firewall: SPI, anti-DoS, Filter, Access Control
- Management: Web, CLI, SNMP v1/v2/v3, SMS, RobustLink
- Serial port: TCP client/server, UDP, Modbus RTU/ASCII to Modbus TCP, Virtual COM (COM port redirector)
- RobustLink: a centralized M2M management platform developed by Robustel
- RobustVPN: a Cloud VPN Portal

Power Supply and Consumption

- Connector: 3.5 mm terminal block
- Power consumption: 150 mA @ 12 V


Physical Characteristics

- Housing & Weight: Metal, 300 g
- Dimensions: 105 x 98 x 29.5 mm
- Installations: desktop or wall mounting or 35 mm DIN rail mounting

Regulatory and Type Approvals

- Approvals & Certificates: CE, R&TTE, RCM, RoHS, WEEE
- EMC:
 - EMI: EN 55022: 2006/A1: 2007 (CE&RE) Class B
 - EMS: IEC 61000-4-2 (ESD) Level 3, IEC 61000-4-3 (RS) Level 4
 - IEC 61000-4-4 (EFT) Level 3, IEC 61000-4-5 (Surge) Level 3
 - IEC 61000-4-6 (CS) Level 3, IEC 61000-4-8 (M/S) Level 4


1.4 Dimensions



Chapter 2 Installation

2.1 LED Indicators




Name	Color	Status	Description
RUN	Green	On, solid	Router is powered on
		On, blinking	Router is starting up
		Off	Router is powered off
PPP	Green	On, solid	PPP connection is up
		On, blinking	Null
		Off	PPP connection is down
USR	Green	On, blinking	SIM: using backup SIM card NET: access to a low level network
		Off after blinking	SIM: working NET: working
		On	OpenVPN is connected IPsec is connected GRE is connected
		Off	OpenVPN is disconnected IPsec is disconnected GRE is disconnected
	Green	On	Signal level: 21-31 (High Signal)
	Yellow	On	Signal level: 11-20 (Medium Signal)
	Red	On	Signal level: 1-10 (Low Signal)
<p>When the network disconnected, those three signal LEDs are designed as a binary combination code to indicate a series of error report. (Green Yellow Red) On: 1 Off: 0</p> <p>001 AT command failed 010 no SIM card detected 011 it need to enter the PIN code 100 it need to enter the PUK code 101 registration failed 110 something wrong happened in the module</p>			

Note: You can choose the display type of USR LED. For more details, please refer to **3.27 Services > Advanced**.

2.2 PIN Assignment

The R3000 Lite has been designed to be placed on a desktop. Below is the bottom of the R3000 Lite.



Terminal block

PIN	Power
10	Positive
11	Negative
12	GND

DB9 Female Connector


PIN	Debug	RS-232	RS-485 (2-wire)	Terminal block	Direction
1	CR	--	Data+ (A)	485+	--
2	CT	RXD	--	RXD	R3000 Lite → Device
3	--	TXD	--	TXD	Device → R3000 Lite
4	DRXD	--	--	DT	Device → R3000 Lite
5	GND	GND	--	GND x2	--
6	--	--	Data- (B)	485-	--
7	--	RTS	--	RTS	Device → R3000 Lite
8	--	CTS	--	CTS	R3000 Lite → Device
9	DTXD	--	--	DR	R3000 Lite → Device

2.3 USB Interface




USB interface is used for batch firmware upgrade, cannot be used to send or receive data from slave devices which use the USB interface. Users can insert a USB storage device, such as a U disk or hard disk, into the router's USB interface, if there is a configuration file or firmware of R3000 Lite inside the USB storage device, R3000 Lite will automatically update the configuration file or firmware. For more details, please go to **3.10 Interface > USB**.

2.4 Reset Button



Function	Operation
Reboot	Press the button for at least 5 seconds in operating status
Restore to factory default setting	After powering up the router, press the RST button by a small non-conductive stick with a blunt end in about 60 seconds until all three LEDs (RUN, PPP, USR) on the left side blinking 5 times simultaneously. Then the router will be restored to factory default settings

2.5 Ethernet Port



The Ethernet port has two LED indicators. The yellow one is **Link Indicator** and the green one is **Speed Indicator**. Each indicator has three statuses, for details see the table below:

Indicator	Status	Description
Link Indicator	On	Connection is enabled
	On, blinking	Data is being transmitted
	Off	Connection is disabled
Speed Indicator	On	100 Mbps mode
	Off	10 Mbps mode

2.6 Mount the Router


R3000 Lite router supports for horizontal surface placement, DIN rail mounting and wall mounting.

- **Two ways for mounting the router**

1. **Wall mounting**

Use 3 pcs of M3*4 countersunk Phillips screws to fix the router on the wall mounting kit, and then use 2 pcs of M3 drywall screws to mount the router associated with the wall mounting kit on the wall.


Note: Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.



2. **DIN rail mounting**

Use 3 pcs of M3*4 countersunk phillips screws to fix the router on the DIN rail, and then hang the DIN rail on the bracket. It is necessary to choose the standard bracket.

Note: Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.



2.7 Install the SIM Card



- **Remove slot cover**

1. Make sure router is powered off.
2. To remove cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot.

- **Insert SIM card**

3. To insert SIM card, press the card with fingers until snap on and then tighten the screws associated with the cover by using a screwdriver.


- **Remove SIM card**

4. Make sure router is powered off.
5. To remove SIM card, press the card with fingers until pop out and then take out the SIM card.

Note:

1. Use the specific M2M SIM card when the device is working in extreme temperature, because the regular SIM card for long-time working in harsh environment will be disconnected frequently.
2. Do not forget to twist the cover tightly to avoid being stolen.
3. Do not touch the metal of the SIM card surface in case information in the card will lost or be destroyed.
4. Do not bend or scratch the SIM card.
5. Keep the SIM card away from electricity and magnetism.
6. Make sure router is powered off before inserting or removing the SIM card.

2.8 Connect the External Antenna (SMA Type)



Connect the SMA external antenna connector to the router's antenna interface and twist tightly. Make sure the antenna is within the correct frequency range provided by the operator and with 50 Ohm impedance.

Note: Recommended torque for mounting is 0.35 N.m.

2.10 Grounding the Router

Router grounding helps prevent the noise effect due to electromagnetic interference (EMI). Connect the router to the site ground wire by the ground screw before powering on.

Note: This product is appropriate to be mounted on a sound grounded device surface, such as a metal panel.


2.11 Connect the Router to PC

Connect the router's Ethernet port to a PC through a standard crossed network cable.

2.11 Power Supply

CONNECTING THE POWER CABLE

COLOR	POLARITY
RED	+
YELLOW	-



R3000 Lite router supports reverse polarity protection, but always refers to the figure above to connect the power adapter correctly. There are two cables associated with the power adapter. Following to the color of the head, connect the cable marked red to the positive pole through a terminal block, and connect the yellow one to the negative in the same way.

Chapter 3 Configuration Settings over Web Browser


The router can be configured through web browser including IE 8.0 or above, Chrome and Firefox, etc. And the supported operating systems are: Linux, Mac OS, Windows 98/NT/2000/XP/Me/Vista/7/8, etc. There are various ways to connect to the router, either through an external repeater/hub or to PC directly. When the router connects to the PC's Ethernet port directly, and if the router works as the DHCP server, then the PC can obtain IP from router directly; or the PC can be configured with a static IP address in the same network segment with the router, and then the PC and the router will form a small local area network. After the connection has been established successfully, enter the device's default login address in the browser and access the router's web login interface.

3.1 Configuring for the PC


There are two methods to configure the IP address on PC, one is to obtain an IP address automatically from Local Area Connection, and another is to configure a static IP address manually within the same subnet of R3000 Lite router. Please refer to the steps below:

Window 7 System (the configuration for Windows system is similar)


1. Click **Start > Control panel** (in classic view), double-click **Network and Sharing Center**, and then double-click **Local Area Connection**.



2. Click **Properties** in the window of **Local Area Connection Status**.




3. Choose **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.




4. Two ways for configuring the IP address of PC:

Obtain an IP address automatically:



Use the following IP address (configured a static IP address manually within the same subnet of R3000 Lite router):



5. Click **OK** to finish the configuration.

3.2 Factory Default Settings


Before configuring your router, you need to know the following default settings.

Item	Description
Username	admin
Password	admin
Ethernet	192.168.0.1/255.255.255.0, LAN mode
DHCP Server	Enabled.


3.3 Login Router

1. On the PC, open a web browser such as Internet Explorer, Google and Firefox etc.
2. From your web browser, enter the IP address of the router. The default IP address of R3000 Lite is 192.168.0.1, though the actual address may vary.

Note: If a public SIM card is inserted in the R3000 Lite router, you can enter the corresponding public IP address of the SIM card in the browser's address bar, so that to access the R3000 Lite router wirelessly by this public IP.





3. In the login page, enter the username and password of R3000 Lite router, choose language and then click **Login**. If enter the wrong username or password over six times, the login web will be locked for 5 minutes.






3.4 Control Panel

After logging in the R3000 Lite, the home page of the R3000 Lite router's web interface is displayed, just like the screenshot below.

This section allows users to save configuration, reboot router and logout. When you are first time to login R3000 Lite,

there will be a pop-up tab “  It is strongly recommended to change the default password. ”, click  to close the pop-up tab. And if you want to change the password, please refer to **3.31 System > User Management** section.



Control Panel		
Item	Description	Button
Save & Apply	Click to save the current configuration into router's flash and apply the modification on every configuration page, to make the modification taking effect.	
Reboot	Click to reboot the router. When the Reboot button is in yellow, it means that some completed configurations will take effect only by reboot.	

Logout	Click to exit safely, then it will switch to login page. Shut down web page directly without logout, the next one can login web on this browser without a password before timeout.	
Submit	Click to submit the modification on current configuration page.	
Cancel	Click to cancel the modification on current configuration page.	

Note: The steps of how to modify configuration are as bellow:

1. Modify in one page;
2. Click under this page;
3. Modify in another page;
4. Click under this page;
5. Complete all modification;
6. Click .

3.5 Status

This section displays the router’s status, which shows you a number of helpful information such as System Information, Cellular Information, Internet Status and LAN Status.

System Information

^ System Information

Device Model	R3000
System Uptime	0 days, 04:21:30
System Time	Fri Feb 26 14:59:27 2016
Firmware Version	2.0.0 (Rev 84)
Hardware Version	1.02.01
Kernel Version	4.1.0
Serial Number	

System Information	
Item	Description
Device Model	Show the model name of this device.
System Uptime	Show how long the router has been working since power on.

System Time	Show the current system time.
Firmware Version	Show the current firmware version.
Hardware Version	Show the current hardware version.
Kernel Version	Show the current kernel version.
Serial Number	Show the serial number of this device.

Cellular Information

^ Cellular Information	
Modem Status	Ready
Model	MU609
Firmware Version	12.105.29.00.00
IMEI	357784044323622
SIM Status	SIM1 using, total 0 SIMs
Network Registration	Registered to home network
Network Operator	CHN-UNICOM
Network Type	WCDMA
Signal Strength	31 (-51dBm)

Cellular Information	
Item	Description
Modem Status	Show the status of modem. There are 8 different status: <ol style="list-style-type: none"> 1. Initializing 2. Modem not found 3. No response 4. SIM not detected 5. SIM PIN required 6. SIM PUK required 7. Register failed 8. Ready
Modem Model	Show the current radio module type.
Firmware Version	Show the current radio firmware version.
IMEI	Show the IMEI number of the radio module.
SIM Status	Show the SIM card which the router works with currently: SIM1 or SIM2. And show the total SIM cards in the router.
Network Registration	Show the status of Registration. There are 6 different status: <ol style="list-style-type: none"> 1. Not registered, search stopped 2. Registered to home network

Cellular Information	
Item	Description
	3. Not registered, searching 4. Registration denied 5. Unknown 6. Registered, roaming
Network Operator	Show the current network provider.
Network Type	Show the current network service type, e.g. GPRS.
Signal Strength	Show the current signal strength.

Internet Status

^ Internet Status	
Active Link	WWAN1
Uptime	0 days, 00:12:23
IP Address	10.129.91.139/255.255.255.248
Gateway	10.129.91.137
DNS	210.21.4.130 221.5.88.88

Internet Status	
Item	Description
Active Link	Show the current WAN link: WWAN1, WWAN2 or WAN.
Uptime	Show how long the current WAN have been working.
IP Address	Show the current WAN IP address.
Gateway	Show the current gateway.
DNS	Show the current primary DNS server and Secondary server.

LAN Status

^ LAN Status	
IP Address	172.16.99.11/255.255.0.0
MAC Address	34:FA:40:04:AD:67

Router Information	
Item	Description
IP Address	Show the current IP Address and the Netmask.
MAC Address	Show the current MAC Address.

3.6 Interface > Link Manager

Link Manager

User can manage the link connection in this section. R3000 Lite support Cellular and Ethernet link connection.

Link Manager

Status

^ General Settings

Primary Link

v ?

Backup Link

v

Backup Mode

v ?

Emergency Reboot

ON OFF ?

Link Manager		
Item	Description	Default
Primary Link	Select from "WWAN1", "WWAN2". <ul style="list-style-type: none"> WWAN1: Select to make SIM1 as the primary wireless link. WWAN2: Select to make SIM2 as the primary wireless link. Note: insert SIM card please refer to the installation quick guide.	WWAN1
Backup Link	Select from "None", "WWAN1", "WWAN2". <ul style="list-style-type: none"> None: Do not select backup interface. WWAN1: Select to make SIM1 as backup wireless WAN. WWAN2: Select to make SIM2 as backup wireless WAN. 	None
Backup Mode	Cold backup: The inactive link is offline on standby. Warm backup: The inactive link is online on standby. Warm backup mode is not available for dual SIM backup.	Cold backup
Emergency Reboot	Enable to reboot the whole system if no links available.	OFF

Note: Click for help.

Link Setting section allows user to configure the parameter of link connection, include the WWAN1 and WWAN2.

It is recommended to enable Ping detection to keep router always online.

The Ping detection increases the reliability and also cost data traffic.

^ Link Settings

Index	Type	Description	Connection Type	
1	WWAN1		DHCP	
2	WWAN2		DHCP	

Click to enter the link configuration window.

WWAN1/WWAN2

Link Manager

^ **General Settings**

Index	<input type="text" value="1"/>
Type	<input style="border-bottom: 1px solid #ccc;" type="text" value="WWAN1"/>
Description	<input type="text"/>

When enable “Automatic APN Selection”, the window will display just like the following screenshot.

^ **WWAN Settings**

Automatic APN Selection	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Dialup Number	<input type="text" value="*99***1#"/>
Authentication Type	<input style="border-bottom: 1px solid #ccc;" type="text" value="Auto"/>
Aggressive Reset	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ?
Switch SIM By Data Allowance	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ?
Data Allowance	<input type="text" value="0"/> ?
Billing Day	<input type="text" value="1"/> ?

When disable “Automatic APN Selection”, the window will display just like the following screenshot.

^ **WWAN Settings**

Automatic APN Selection	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
APN	<input type="text" value="internet"/>
Username	<input type="text"/>
Password	<input type="text"/>
Dialup Number	<input type="text" value="*99***1#"/>
Authentication Type	<input style="border-bottom: 1px solid #ccc;" type="text" value="Auto"/>
Aggressive Reset	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ?
Switch SIM By Data Allowance	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ?
Data Allowance	<input type="text" value="0"/> ?
Billing Day	<input type="text" value="1"/> ?

WWAN Setting		
Item	Description	Default
Automatic APN Selection	R3000 Lite will recognize the access point name automatically.	ON
Dialup Number	Dialup number for cellular dial-up connection, provided by local ISP.	*99***1#
Authentication Type	Select from "Auto", "PAP" and "CHAP" as the local ISP required.	Auto
Aggressive Reset	The module will be reset when the link become unreachable.	OFF
Switch SIM By Data Allowance	Switch to another SIM when reach data allowance, only use for dual SIM backup.	OFF
Data Allowance	Set the monthly data traffic limitation. The system will record the data traffic statistics when data traffic limitation (MiB) is specified. The traffic record will display in Link Manager > Status > WWAN Data Usage Statistics section. 0 means disable data traffic record.	0
Billing Day	This option specifies the day of month for billing, the data traffic statistics will be recalculated from this day.	1
Redial Interval	Seconds to wait for redial.	10
APN	Access Point Name for cellular dial-up connection, provided by local ISP.	internet
Username	User Name for cellular dial-up connection, provided by local ISP.	Null
Password	Password for cellular dial-up connection, provided by local ISP.	Null

^ Ping Detection Settings ?

Enable ON OFF

Primary Server

Secondary Server

Interval ?

Retry Interval ?

Timeout ?

Max Ping Tries ?

^ Advanced Settings

Upload Bandwidth ?

Download Bandwidth

Overrided Primary DNS

Overrided Secondary DNS

Ping Detection Settings/Advanced Setting		
Item	Description	Default
Enable	To enable "ping detection". It was a keepalive policy of R3000 Lite router.	OFF


Ping Detection Settings/Advanced Setting		
Item	Description	Default
Primary Server	Router will ping this primary address/domain name to check that if the current connectivity is active.	8.8.8.8
Secondary Server	Router will ping this secondary address/domain name to check that if the current connectivity is active.	Null
Interval	Set the ping interval.	300
Retry Interval	Set the ping retry interval.	5
Tmeout	Set the ping timeout.	3
Max Ping Tries	Switch to another link or take emergency action if max continuous ping tries reached.	3
Upload Bandwith	used for QoS, unit: kbps	10000
Download Bandwith	used for QoS, unit: kbps	10000
Overrided Primary DNS	Overrided DNS will override the automatically obtained DNS.	Null
Overrided Secondary DNS	Overrided DNS will override the automatically obtained DNS.	Null

User can check the status of WWAN connection and clear the monthly data usage record in Status page.

The screenshot shows the 'Status' page with two tabs: 'Link Manager' and 'Status'. The 'Status' tab is active. Under 'Link Status', there is a table with one entry: Index 1, Link WWAN1, Status Connected, Uptime 0 days, 00:55:27, and IP Address 10.129.91.13.. Below this, 'WWAN Data Usage Statistics' are shown for SIM1 and SIM2, each with a 'Clear' button.

Status

The screenshot shows the 'Status' page with 'Link Manager' and 'Status' tabs. The 'Status' tab is active. Under 'Link Status', there is a table with one entry: Index 1, Link WWAN1, Status Disconnected. The 'Uptime' and 'IP Address' columns are empty.

Click the button  which is in the top right of the Link Status window. Select the connection status of the current link.

A close-up of the Link Status window showing a menu with two options: 'Connect' and 'Disconnect'.

Click the row of the link, and it will show the details information of the current link connection under the row.

Link Status

Index	Link	Status	Uptime	IP Address
1	WWAN1	Disconnected		

Index 1
Link WWAN1
Status Disconnected

WWAN Data Usage Statistics

SIM1 Monthly Stats

SIM2 Monthly Stats

Click button to clear SIM1 or SIM2 monthly data traffic usage statistics. Data statistics will display only if enable the Data Allowance function in **Link Manager > Link Setting > WWAN Setting**.

3.7 Interface > LAN

This section allows user to set the related parameters of LAN interfaces.
 R3000 Lite’s LAN interface IP default to 192.168.0.1.

LAN

LAN

Network Settings

Index	Interface	IP Address	Netmask
1	lan0	192.168.0.1	255.255.255.0

Click to edit the configuration of the current LAN interface. Click to delete the current LAN interface.

Note: Interface lan0 cannot be deleted.

LAN

General Settings

Index
Interface
IP Address
Netmask
MTU

General Settings		
Item	Description	Default
Interface	R3000 Lite's LAN interface names lan0.	lan0
IP Address	Set the IP Address of the LAN interface.	192.168.0.1
Netmask	Set the Netmask of the LAN interface.	255.255.255.0
MTU	Maximum Transmission Unit. It is the identifier of the maximum size of packet, which is possible to transfer in a given environment.	1500

When select DHCP Mode as Server, the window will display as the following screenshot.

^ DHCP Settings

Enable ON OFF

Mode Server v

IP Pool Start 192.168.0.2

IP Pool End 192.168.0.100

Subnet Mask 255.255.255.0

^ DHCP Advanced Settings

Gateway

Primary DNS

Secondary DNS

WINS Server

Lease Time 120 ?

Expert Options ?

Debug Enable ON OFF

DHCP Server		
Item	Description	Default
Enable	Click the switch to show "ON" and to enable DHCP function.	ON
Mode	Server: Lease IP address to DHCP clients which connect to LAN. Relay: Router can be DHCP Relay, which will provide a relay tunnel to solve problem that DHCP Client and DHCP Server is not in a same subnet.	DHCP Server
IP Pool Start	Define the beginning of the pool of IP addresses which will lease to DHCP clients.	192.168.0.2
IP Pool End	Define the end of the pool of IP addresses which will lease to DHCP clients.	192.168.0.100
Subnet Mask	Define the Subnet Mask which the DHCP clients will obtain from DHCP server.	255.255.255.0
Gateway	Define the Gateway which the DHCP clients will obtain from DHCP server.	Null
Primary DNS	Define the Primary DNS Server which the DHCP clients will obtain from DHCP server.	Null

DHCP Server		
Item	Description	Default
Secondary DNS	Define the Secondary DNS Server which the DHCP clients will obtain from DHCP server.	Null
WINS Server	Define the Windows Name Server which the DHCP clients will obtain from DHCP server.	Null
Lease Time	Define the time which the client can use the IP address which obtained from DHCP server.	120
Expert Options	You can enter some other options of DHCP server in this field. format: config-desc;config-desc, e.g. log-dhcp;quiet-dhcp	Null
Debug Enable	Enable this function; it will output the DHCP information to syslog.	OFF

When select DHCP Mode as Relay, the window will display as the following screenshot.

^ DHCP Settings

Enable ON OFF

Mode Relay v

DHCP Server For Relay

^ DHCP Advanced Settings

Debug Enable ON OFF

DHCP Server		
Item	Description	Default
DHCP Server for Relay	Enter the DHCP Relay server IP address.	Null
Debug Enable	Enable this function; it will output the DHCP information to syslog.	OFF

Multiple IP

LAN Multiple IP VLAN Trunk Status

^ Multiple IP Settings

Index	Interface	IP Address	Netmask	
1	lan0	172.16.99.67	255.255.0.0	+ ✎ ✕

Click to edit the Multiple IP of the LAN interface. Click to delete the Multiple IP of the LAN interface.

Click to add a multiple IP to the LAN interface.

Multiple IP

^ IP Settings

Index

Interface

IP Address

Netmask

Multiple IP		
Item	Description	Default
Interface	R3000 Lite’s LAN interface names lan0.	lan0
IP Address	Set the multiple IP Address of the LAN interface.	Null
Netmask	Set the multiple Netmask of the LAN interface.	Null

VLAN Trunk

LAN
Multiple IP
VLAN Trunk
Status

^ VLAN Settings

Index	Enable	Interface	VID	IP Address	Netmask	
						+

Click to add a VLAN. The maximum number of the VLAN is eight.

VLAN Trunk

^ VLAN Settings

Index

Enable

 ON OFF

Interface

VID

IP Address

Netmask

VLAN Trunk		
Item	Description	Default
Enable	Enable to make router can encapsulate and de-encapsulate the VLAN tag.	ON
Interface	R3000 Lite’s LAN interface names lan0.	lan0
VID	Set the Tag ID of VLAN, values range from 1 to 4094.	100
IP Address, Netmask	Set the IP address, Netmask of VLAN interface	Null

Status

This section shows the LAN connection status.

LAN	Multiple IP	VLAN Trunk	Status	
^ Interface Status				
Index	Interface	IP Address	MAC Address	
1	lan0	172.16.99.111/255...	34:FA:40:05:2C:0A	
^ Connected Devices				
Index	IP Address	MAC Address	Interface	Inactive Time
1	172.16.5.16	D0:50:99:4D:F9:35	lan0	0s
^ DHCP Lease Table				
Index	IP Address	MAC Address	Interface	Expired Time

Click the row of status, the details status information will be display under the row. Please refer to the screenshot below.

^ Interface Status			
Index	Interface	IP Address	MAC Address
1	lan0	192.168.0.1/255.2...	34:FA:40:0B:B9:E9
		Index	1
		Interface	lan0
		IP Address	192.168.0.1/255.255.255.0
		MAC Address	34:FA:40:0B:B9:E9
		RX Packets	0
		TX Packets	0
		RX Bytes	0
		TX Bytes	0
2	lan1	172.16.99.68/255....	34:FA:40:0B:E6:46

3.8 Interface > Ethernet

This section allow user to set the parameter of the Ethernet port. One port should be assigned to lan0 a least.

Ports	Status	
^ Port Settings		
Index	Port	Port Assignment
1	eth0	lan0


Click  button, configure the port setting.

Ports

^ Port Settings

Index

Port

Port Assignment 

Submit
Close

Ethernet		
Item	Description	Default
Index	The index of Ethernet port. Read only.	1
Port	R3000 Lite’s Ethernet port names eth0	eth0
Port Assignment	R3000 Lite’s Ethernet port eth0 with be assign to lan0.	lan0

User can check the status of Ethernets in this page.

Ports
Status

^ Port Status

Index	Port	Link
1	eth0	Up



3.9 Interface > Cellular


This section allows users to set the Cellular WAN and the related parameters.

When it is the first time to insert single SIM card, SIM card 1 and SIM card 2 slots are available.

Cellular
Status

^ Advanced Cellular Settings

Index	SIM Card	Phone Number
1	SIM1	
2	SIM2	

Click”  ” to edit the parameters.

Cellular

^ **General Settings**

Index

SIM Card

SIM1 v

Phone Number

Extra AT Cmd

 ?

When choose “Network Type type” is “Auto”;

^ **Cellular Network Settings**

Network Type

Auto v ?

Band Select Type

All v ?

When choose “band select type” is “Specify”.

^ **Cellular Network Settings**

Network Type

Auto v ?

Band Select Type

Specify v ?

GSM 850

ON

OFF

GSM 900

ON

OFF

GSM 1800

ON

OFF

GSM 1900

ON

OFF

WCDMA 850

ON

OFF

WCDMA 900

ON

OFF

WCDMA 1900

ON

OFF

WCDMA 2100

ON

OFF

Cellular		
Item	Description	Default
Index	Show the index of the SIM.	1
SIM Card	Set the current SIM card.	SIM1
Link Name	Set the current Link Name.	WWAN1
Phone Number	Define the phone number of the SIM card.	Null
Extra AT Cmd	AT commands used for cellular initialization.	Null
Network Type	Select from “Auto”, “4G Only”, “4G First”. Auto: Router will connect to the best signal network when choose Auto as network type. 4G Only: Router only connects to 4G network. 4G First: Router will connect to 4G Network preferentially.	Auto

Cellular		
Item	Description	Default
Band Select Type	Select from "All", "Specify". When select "Specify", user can choose certain bands.	All

Status

This section allow user to check the cellular status information.

Cellular
Status

^ Cellular Information

Modem Status	Ready
Current SIM	SIM2
Total SIMs	1
Phone Number	145
IMSI	460010432615366
ICCID	89860114851074491267
Network Registration	Registered to home network
Network Operator	CHN-UNICOM
Network Type	WCDMA
Signal Strength	3 (-107dBm)
Cell ID	A50B,0148A989
Model	MU709s-6
IMEI	866430020015865
Firmware Version	11.652.61.00.00

Status	
Item	Description
Modem Status	Show the status of the radio module.
Current SIM	Show the SIM card which the router works with currently: SIM1 or SIM2.
Total SIMs	Show the number of SIM cards that is installed in the router.
Phone Number	Show the phone number of the current SIM.
IMSI	Show the IMSI number of the current SIM.
ICCID	Show the ICCID number of the current SIM.
Network Registration	Show the current network status.
Network Operator	Show the name of Network Provider.
Network Type	Show the current network service type, e.g. GPRS.

Status	
Item	Description
Signal Strength	Show the current signal strength.
Cell ID	Show the current cell ID, which can locate the router.
Model	Show the model of the radio module.
IMEI	Show the IMEI number of the radio module.
Firmware Version	Show the current firmware version of the radio module.

3.10 Interface > USB

This section allows users to set the USB parameters.


Note: Users can insert a USB storage device, such as U disk and hard disk, into the router's USB interface. If there is firmware of R3000 Lite inside the USB storage devices, R3000 Lite will automatically update the firmware. We will provide another file "application note" to show how to do USB automatic update.



USB		
Item	Description	Default
Enable USB	Click to enable USB feature.	ON
Enable Automatic Firmware Updating	Click Enable to automatically update the firmware of R3000 Lite when insert the USB storage devices which has R3000 Lite's firmware.	ON

R3000 Lite has the key for USB automatic update. User can generate the key in this page.

Click **Generate**, it will generate a key below. Click **Download** to download the key.



3.11 Interface > Serial Port

This section allows users to set the serial (RS232/RS485) parameters, the type of COM1 is RS232 and the type of COM2 is RS485.

Serial Port

Serial Port
Status

^ Serial Port Settings

Index	Port	Enable	Baud Rate	Application Mode	
1	COM1	false	115200	Transparent	
2	COM2	false	115200	Transparent	

Serial Port

^ Serial Port Application Settings

Index:

Port:

Enable: ON OFF

Baud Rate:

Data Bits:

Stop Bits:

Parity:

Flow Control:

^ Data Packing

Packing Timeout:

Packing Length:

Serial setting@COM1		
Item	Description	Default
Port	Show the current serial's name. In default, COM1 is RS232 and COM2 is RS485.	/
Enable	Click to enable this serial port. When the status is OFF, the serial port is not available.	OFF
Baud Rate	Select from "300", "600", "1200", "2400", "4800", "9600", "19200", "38400", "57600", "115200" and "230400".	115200
Data bit	Select from "7" and "8".	8
Stop bit	Select from "1" and "2".	1
Parity	Select from "None", "Odd" and "Even".	None
Flow control	Select from "None", "Software" and "Hardware".	None
Packing Timeout	The serial port will queue the data in the buffer and send the data to the Cellular WAN/Ethernet WAN when it reaches the Interval Timeout in the field. Note: Data will also be sent as specified by the packet length even when data is not reaching the interval timeout in the field.	50
Packing Length	The Packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When a packet length between 1 and 3000 bytes is specified, data in the buffer will be sent as	1200

Serial setting@COM1		
Item	Description	Default
	soon it reaches the specified length.	

^ Server Setting

Application Mode v

Protocol v

Server Address

Server Port

Server Setting@COM1		
Item	Description	Default
Application Mode	Select from "Transparent", "Modbus RTU Gateway". <ul style="list-style-type: none"> Transparent: Router will transmit the serial data transparently. Modbus: Router will translate the Modbus RTU data to Modbus TCP data and sent out. Vice versa. 	Transparent
Protocol	Select from "TCP Client", "TCP Server", "UDP", "Robustlink". <ul style="list-style-type: none"> TCP Client: Router works as TCP client, initiate TCP connection to TCP server. Server address supports both IP and domain name. TCP Server: Router works as TCP server, listening for connection request from TCP client. UDP: Router works as UDP client. Robustlink: Router will automatically upload the serial data to Robustlink platform under the Robustlink protocol. Robustlink is a management platform from Robustel. This function only available when Router is connects to Robustlink. 	TCP Client
Server Address	Enter the address of server which will receive the data sent from R3000 Lite's serial port. IP address or domain name will be available.	Null
Server Port	Enter the specified port of server which is use to receive the serial data.	Null

Status

User can check the status of RS232 and RS485. The type of COM1 is RS232 and the type of COM2 is RS485.

Serial Port	Status			
^ Serial Port Status list				
Index	Type	TX	RX	Connection Status
1	RS232	0B	0B	
2	RS485	0B	0B	

3.12 Network > Route

This section allows user to set the static route. (The maximum number of the static route is twenty.)

Static Route

Static Route | **Status**

^ Static Route Table

Index	Description	Destination	Netmask	Gateway	Interface	+
-------	-------------	-------------	---------	---------	-----------	---

Click “+” to add static routes, the maximum number of static routes is 20.

Static Route

^ Static Route

Index:

Description:

Destination:

Netmask:

Gateway:

Interface:

Static Route		
Item	Description	Default
Index	Show the index of the static route.	1
Description	Enter some simple words about this route. It can be null.	Null
Destination	Define the destination IP address.	Null
Netmask	Define the Netmask of the destination.	Null
Gateway	Define the gateway of the destination.	Null
Interface	Select from “LAN”, “WAN”, “TUN”	LAN

Status

User can check the status of route in this page.

Static Route | **Status**

^ Route Table

Index	Destination	Netmask	Gateway	Interface	Metric
1	172.16.0.0	255.255.0.0	0.0.0.0	eth-br	0

3.13 Network > Firewall

This section allows users to set the Firewall and the related parameters, which includes “Filter”, “Port Mapping” and “DMZ”.

Filtering

Filtering
Port Mapping
DMZ

^ General Settings

Enable Filtering ON OFF

Default Filtering Policy v ?

^ Access Control

Enable Remote SSH Access ON OFF

Enable Local SSH Access ON OFF

Enable Remote Telnet Access ON OFF

Enable Local Telnet Access ON OFF

Enable Remote HTTP Access ON OFF

Enable Local HTTP Access ON OFF

Enable Remote HTTPS Access ON OFF

Enable Remote Ping Respond ON OFF ?

Enable DOS Defending ON OFF

General Setting & Access Control		
Item	Description	Default
Enable Filtering	Enable filtering rules.	ON
Default Filtering Policy	Select from "Accept" and "Drop". Cannot be changed when filtering rules table is not empty. Accept: Router will accept all the connecting requests except the hosts which fit the drop filter list. Drop: Router will drop all the connecting requests except the hosts which fit the accept filter list.	accept
Enable Remote SSH Access	Enable to allow users to access the router remotely on the internet side via SSH.	OFF
Enable Local SSH Access	Enable to allow users to access the router on the local Ethernet via SSH.	ON
Enable Remote Telnet Access	Enable to allow users to access the router remotely on the internet side via Telnet.	OFF
Enable Local Telnet Access	Enable to allow users to access the router on the local Ethernet via Telnet.	ON

General Setting & Access Control		
Item	Description	Default
Enable Remote Http Access	Enable to allow users to access the router remotely on the internet side via Http.	OFF
Enable Local Http Access	Enable to allow users to access the router on the local Ethernet via Http.	ON
Enable Remote Https Access	Enable to allow users to access the router remotely on the internet side via Https.	ON
Enable Remote Ping Respond	Enable to make router reply the Ping requests from the internet side.	ON
Enable DOS Defending	Enable to defend dos attack. Dos attack is an attempt to make a machine or network resource unavailable to its intended users.	ON

^ Filtering Rules

Index	Source Address	Source Port	Source MAC	Target Address	Target Port	Protocol	+
-------	----------------	-------------	------------	----------------	-------------	----------	---

Click “+” to add filtering rules. (The maximum number of the filtering rule is twenty.)

^ Filtering Rules

Index:

Description:

Source Address: ?

Source MAC: ?

Target Address: ?

Protocol: v

Action: v

Filtering Rules		
Item	Description	Default
Index	Show the index of the filtering rule or the MAC binding rule.	1
Description	Enter some simple words about this filtering rule. It can be null.	Null
Source Address	Defines if access is allowed from one or a range of IP addresses which are defined by Source IP Address, or every IP addresses.	Null
Source MAC	Enter the MAC address of the defined source IP address.	Null
Target Address	Defines if access is allowed to one or a range of IP addresses which are defined by Target IP Address, or every IP addresses.	Null
Protocol	Select from “All”, “TCP”, “UDP”, “ICMP”, “TCP-UDP”. If you don’t know what kinds of protocol of your application, we recommend you select “ALL”.	All

Filtering Rules		
Item	Description	Default
Action	Select from "Accept", "Drop". Accept: When Default Filtering Policy is drop, router will drop all the connecting requests except the hosts which fit this accept filtering list. Drop: When Default Filtering Policy is accept, router will accept all the connecting requests except the hosts which fit this drop filtering list.	Drop

Port Mapping

Filtering | **Port Mapping** | DMZ

^ Port Mapping Rules

Index	Description	Internet Port	Local IP	Local Port	Protocol	+
-------	-------------	---------------	----------	------------	----------	---

Click "+" to add port mapping rules. (The maximum number of the port mapping rule is forty.)

^ Port Mapping Rules

Index:

Description:

Internet Port: ?

Local IP:

Local Port: ?

Protocol: v

Port Mapping		
Item	Description	Default
Index	Show the index of the port mapping rule.	1
Description	Enter some simple words about this port mapping. It can be null.	Null
Internet Port	Set the internet port of router which can be accessed by other hosts from internet.	Null
Local IP	Enter router's LAN IP which will forward to the internet port of router.	Null
Local Port	Enter the port of router's LAN IP.	Null
Protocol	Select from "TCP", "UDP" and "TCP-UDP".	TCP-UDP

DMZ

Filtering
Port Mapping
DMZ

^ DMZ Settings

Enable DMZ ON OFF

Host IP Address

Source IP Address ?

DMZ		
Item	Description	Default
Enable DMZ	Select to enable the DMZ function. DMZ host is a host on the internal network that has all ports exposed, except those ports otherwise forwarded.	OFF
Host IP Address	Enter the IP address of the DMZ host which on the internal network.	Null
Source IP Address	Set the address which can talk to the DMZ host. Null means for any addresses.	Null

3.14 Network > QoS

This section allows users to set the QoS parameters.

Please remember to set QoS upload and download bandwidth in the **Interface > Link Manager WWAN/WAN** before Configure Qos parameters.

QoS

^ General Settings

Enable QoS ON OFF

^ Priority Definition ?

Index	Priority	Bandwidth	Borrow Spare Bandwidth	
1	Highest	20	true	
2	High	20	true	
3	Normal	20	true	
4	Low	20	true	
5	Lowest	20	true	

Select the priority, click to enter the priority definition configuration window.

QoS

^ **Priority Definition**

Index

Priority

Bandwidth ?

Borrow Spare Bandwidth ON OFF ?

QoS		
Item	Description	Default
Enable QoS	Click to enable "QoS" function.	Disable
Index	Show the index of priority.	/
Priority	Select from "Highest", "High", "Normal", "Low", "Lowest". User can select the priority level according to the requirement.	/
Bandwidth	Define bandwidth percent of "Highest", "High", "Normal", "Low" and "Lowest". All the bandwidth percent of priority are defaulted to 20%. User can configure the bandwidth percent of priority according to the requirement. The sum of bandwidth of all the priorities cannot be greater than 100%.	20
Borrow Spare Bandwidth	The traffic associated with this priority will borrow unused bandwidth from other priorities when this function is enabled, and will be limited to the specified bandwidth when this function is disabled. Limited specified bandwidth algorithm: priority defined percent x uoad/download bandwidth set in Interface > Link Manager WWAN/WAN .	ON

^ **QoS Rules**

Index
Source Address
Source Port
Target Address
Target Port
Protocol
Priority
+

Click + to add a new QoS rule.

QoS

^ **QoS Rules**

Index

Source Address ?

Source Port ?

Source MAC ?

Target Address ?

Target Port ?

Protocol


Priority

QoS		
Item	Description	Default
Source Address	Enter the IP address of the source host. format: x.x.x.x, x.x.x.x/xx, x.x.x.x-x.x.x.x, empty means anywhere	Null
Source Port	Enter the port number of the source host.	Null
Source MAC	Enter MAC address of the source host. Router supports up to 20 users set with QoS MAC Control. Priority of QoS MAC Control is higher than that of QoS IP control.	Null
Target Address	Enter the IP address of the target host.	
Target Port	Enter the port number of the target host.	
Protocol	Select from "All", "TCP", "UDP", "ICMP" and "TCP&UDP".	All
Priority	Select from "Highest", "High", "Normal", "Low", "Lowest". Those priorities had been defined in Network > QoS > Priority Definition .	Normal
<p>Note:</p> <ol style="list-style-type: none"> If services are in the same priority level, router will automatically start Stochastic Fairness Queueing (SFQ) strategy to make a fair bandwidth allocation. If the link between a source host and target host had set QoS 3 rules. At this time it won't consider the priority but will only choose the ranked first one to take effect. 		

3.15 VPN > IPsec

This section allows users to set the IPsec and the related parameters.

General

General	Tunnel	Status	x509
<p>^ General Settings</p> <p>Enable NAT Traversal <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF</p> <p>Keepalive <input type="text" value="60"/> </p> <p>Debug Enable <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF</p>			

General		
Item	Description	Default
Enable NAT Traversal	Tick to enable NAT Traversal for IPsec. This item must be enabled when router under NAT environment.	ON
Keepalive	The interval that router sends packets to NAT box so that to avoid it remove the NAT mapping.	60
Debug Enable	Enable this function, and it will output IPsec information to the debug port.	OFF

Tunnel

General Tunnel Status x509

^ Tunnel Settings

Index	Enable	Description

+

Click “+” to add tunnel settings. (The maximum number of the tunnel is three.)

^ Tunnel Settings

Index:

Enable: ON OFF

Description:

Gateway: ?

Mode: v

Protocol: v

Local Subnet: ?

Remote Subnet: ?

Tunnel Settings		
Item	Description	Default
Index	Show the index of the tunnel.	1
Enable	Enable IPsec Tunnel.	ON
Description	Enter some simple words about the IPsec Tunnel.	Null
Gateway	Enter the address of remote side IPsec VPN server.	Null
Mode	Select from “Tunnel” and “Transport”. Tunnel: Commonly used between gateways, or at an end-station to a gateway, the gateway acting as a proxy for the hosts behind it. Transport: Used between end-stations or between an end-station and a gateway, if the gateway is being treated as a host-for example, an encrypted Telnet session from a workstation to a router, in which the router is the actual destination.	Tunnel
Protocol	Select the security protocols from “ESP” and “AH”. ESP: Uses the ESP protocol. AH: Uses the AH protocol.	ESP
Local Subnet	Enter IPsec Local Protected subnet’s address with mask, e.g. 192.168.1.0/24	Null
Remote Subnet	Enter IPsec Remote Protected subnet’s address with mask, e.g. 10.8.0.0/24	Null

When choose “Authentication Type” to “PSK”.

^ IKE Settings

Negotiation Mode	Main	v
Authentication Algorithm	MD5	v
Encrypt Algorithm	3DES	v
IKE DH Group	MODP(1024)	v
Authentication Type	PSK	v
PSK Secret	<input type="text"/>	
Local ID Type	Default	v
Remote ID Type	Default	v
IKE Lifetime	86400	?

When choose "Authentication Type" to "CA".

^ IKE Settings

Negotiation Mode	Main	v
Authentication Algorithm	MD5	v
Encrypt Algorithm	3DES	v
IKE DH Group	MODP(1024)	v
Authentication Type	CA	v
Private Key Password	<input type="text"/>	
IKE Lifetime	86400	?

When choose "Authentication Type" to "xAuth PSK".

^ IKE Settings

Negotiation Mode	Main	v
Authentication Algorithm	MD5	v
Encrypt Algorithm	3DES	v
IKE DH Group	MODP(1024)	v
Authentication Type	xAuth PSK	v
PSK Secret	<input type="text"/>	
Local ID Type	Default	v
Remote ID Type	Default	v
Username	<input type="text"/>	?
Password	<input type="text"/>	?
IKE Lifetime	86400	?

When choose “Authentication Type” to “xAuth CA”.

^ IKE Settings

Negotiation Mode ▼

Authentication Algorithm ▼

Encrypt Algorithm ▼

IKE DH Group ▼

Authentication Type ▼

Private Key Password

Username ⓘ

Password ⓘ

IKE Lifetime ⓘ

IKE Settings		
Item	Description	Default
Negotiation Mode	Select from “Main” and “Aggressive” for the IKE negotiation mode in phase 1. If the IP address of one end of an IPsec tunnel is obtained dynamically, the IKE negotiation mode must be aggressive. In this case, SAs can be established as long as the username and password are correct.	Main
Authentication Algorithm	Select from “MD5” and “SHA1” to be used in IKE negotiation. MD5: Uses HMAC-SHA1. SHA1: Uses HMAC-MD5.	MD5
Encrypt Algorithm	Select from “3DES”, “AES128” and “AES256” to be used in IKE negotiation. 3DES: Uses the 3DES algorithm in CBC mode and 168-bit key. AES128: Uses the AES algorithm in CBC mode and 128-bit key. AES256: Uses the AES algorithm in CBC mode and 256-bit key.	3DES
IKE DH Group	Select from “MODP (1024)” and “MODP (1536)” to be used in key negotiation phase 1. MODP (1024): Uses the 1024-bit Diffie-Hellman group. MODP (1536): Uses the 1536-bit Diffie-Hellman group.	MODP (1024)
Authentication Type	Select from “PSK”, “CA”, “xAuth PSK” and “xAuth CA” to be used in IKE negotiation. PSK: Pre-shared Key. CA: Certification Authority. xAuth: Extended Authentication to AAA server.	PSK
PSK Secret	Enter the pre-shared key.	Null
Local ID Type	Select from “IP Address”, “FQDN” and “User FQDN” for IKE negotiation. “Default” stands for “IP Address”. IP Address: Uses an IP address as the ID in IKE negotiation. FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com. User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option	Default

IKE Settings		
Item	Description	Default
	is selected, type a name string with a sign “@” for the local security gateway, e.g., test@robustel.com.	
Remote ID Type	Select from “IP Address”, “FQDN” and “User FQDN” for IKE negotiation. IP Address: Uses an IP address as the ID in IKE negotiation. FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com. User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign “@” for the local security gateway, e.g., test@robustel.com.	Default
IKE Lifetime	Set the lifetime in IKE negotiation. Before an SA expires, IKE negotiates a new SA. As soon as the new SA is set up, it takes effect immediately and the old one will be cleared automatically when it expires.	86400
Private Key Password	Enter the private key.	Null
Username	User name used for xAuth.	Null
Password	Password used for xAuth.	Null

When choose the “Tunnel Setting > General Setting > Protocol” to “ESP”.

^ SA Settings

Encrypt Algorithm ▼

Authentication Algorithm ▼

PFS Group ▼

SA Lifetime ?

DPD Interval ?

DPD Failures

When choose the “Tunnel Setting > Protocol” to “AH”.

^ SA Settings

Authentication Algorithm	<input style="width: 100%;" type="text" value="MD5"/> ▼
PFS Group	<input style="width: 100%;" type="text" value="MODP(1024)"/> ▼
SA Lifetime	<input style="width: 100%;" type="text" value="28800"/> ⓘ
DPD Interval	<input style="width: 100%;" type="text" value="60"/> ⓘ
DPD Failures	<input style="width: 100%;" type="text" value="180"/>

^ Advanced Settings

Enable Compression	<input type="checkbox"/> OFF
Expert Options	<input style="width: 100%;" type="text"/> ⓘ

SA Settings		
Item	Description	Default
Encrypt Algorithm	Select from “3DES”, “AES128” and “AES256” when you select “ESP” in “Protocol”; Note: Higher security means more complex implementation and lower speed. DES is enough to meet general requirements. Use 3DES when high confidentiality and security are required.	3DES
Authentication Algorithm	Select from “MD5” and “SHA1” to be used in SA negotiation.	MD5
PFS Group	Select from “PFS (N/A)”, “MODP (1024)” and “MODP (1536)”. PFS (N/A): Disable PFS Group MODP (1024): Uses the 1024-bit Diffie-Hellman group. MODP (1536): Uses the 1536-bit Diffie-Hellman group.	MODP (1024)
SA Lifetime	Set the IPsec SA lifetime. Note: When negotiating to set up IPsec SAs, IKE uses the smaller one between the lifetime set locally and the lifetime proposed by the peer.	28800
DPD Interval	Set the interval after which DPD is triggered if no IPsec protected packets is received from the peer. DPD: Dead peer detection. DPD irregularly detects dead IKE peers. When the local end sends an IPsec packet, DPD checks the time the last IPsec packet was received from the peer. If the time exceeds the DPD interval, it sends a DPD hello to the peer. If the local end receives no DPD acknowledgment within the DPD packet retransmission interval, it retransmits the DPD hello. If the local end still receives no DPD acknowledgment after having made the maximum number of retransmission attempts, it considers the peer already dead, and clears the IKE SA and the IPsec SAs based on the IKE SA.	60
DPD Failures	Set the timeout of DPD packets.	180
Advanced Settings		
Enable Compression	Tick to enable compressing the inner headers of IP packets.	OFF
Expert Options	format: config-desc;config-desc, e.g. protostack=netkey;plutodebug=none	Null

Status

This section allow user to check the status of the IPsec tunnel.

General	Tunnel	Status	x509
^ Tunnel Status			
Index	Description	Status	Uptime

x509

User can upload the X509 certificate for the IPsec tunnel in this section.

General	Tunnel	Status	x509
^ X509 Settings			
Tunnel Name		<input type="text" value="Tunnel 1"/>	
Certificate Files		<input type="button" value="Choose File"/> No file chosen <input type="button" value="Upload"/>	
^ Certificate Files			
Index	File Name	File Size	Last Modification

x509		
Item	Description	Default
Tunnel Name	Select the name of the tunnel.	Tunnel 1
Certificate Files	Choose the correct file to import the certificate into the router. The correct file format as followings: @ca.crt @remote.crt @local.crt @private.key @crl.pem	Null
Index	Show the index of the certificate file.	Null
Filename	Show the name of the certificate file.	Null
File Size	Show the size of the certificate file.	Null
Last Modification	Show the timestamp of that the last time to modify the certificate file.	Null

3.16 VPN > OpenVPN

This section allows users to set the OpenVPN and the related parameters.

OpenVPN

OpenVPN	Status	x509
^ Tunnel Settings		
Index	Enable	Description

Click “+” to add tunnel settings. (The maximum number of the tunnel is three.)

When choose “Authentication Type” to “None”.

^ Tunnel Settings	
Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Mode	<input type="text" value="Client"/> v
Protocol	<input type="text" value="UDP"/> v
Server Address	<input type="text"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> v
Authentication Type	<input type="text" value="None"/> v ?
Keepalive Interval	<input type="text" value="20"/> ?
Keepalive Timeout	<input type="text" value="120"/> ?
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Verbose Level	<input type="text" value="0"/> v ?

When choose “Authentication Type” to “Preshared”.

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Mode	<input type="text" value="Client"/> ▼
Protocol	<input type="text" value="UDP"/> ▼
Server Address	<input type="text"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> ▼
Authentication Type	<input type="text" value="Preshared"/> ▼ ⓘ
Encrypt Algorithm	<input type="text" value="BF"/> ▼
Keepalive Interval	<input type="text" value="20"/> ⓘ
Keepalive Timeout	<input type="text" value="120"/> ⓘ
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Verbose Level <input type="text" value="0"/> ▼ ⓘ	

When choose "Authentication Type" to "Password".

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Mode	<input type="text" value="Client"/> ▼
Protocol	<input type="text" value="UDP"/> ▼
Server Address	<input type="text"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> ▼
Authentication Type	<input type="text" value="Password"/> ▼ ⓘ
Username	<input type="text"/>
Password	<input type="text"/>
Encrypt Algorithm	<input type="text" value="BF"/> ▼
Keepalive Interval	<input type="text" value="20"/> ⓘ
Keepalive Timeout	<input type="text" value="120"/> ⓘ
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Verbose Level <input type="text" value="0"/> ▼ ⓘ	

When choose "Authentication Type" to "X509CA".

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Mode	<input type="text" value="Client"/> ▼
Protocol	<input type="text" value="UDP"/> ▼
Server Address	<input type="text"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> ▼
Authentication Type	<input type="text" value="X509CA"/> ▼ ?
Encrypt Algorithm	<input type="text" value="BF"/> ▼
Keepalive Interval	<input type="text" value="20"/> ?

Keepalive Timeout	<input type="text" value="120"/> ?
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Verbose Level	<input type="text" value="0"/> ▼ ?

When choose "Authentication Type" to "X509CA Password".

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Mode	<input type="text" value="Client"/> ▼
Protocol	<input type="text" value="UDP"/> ▼
Server Address	<input type="text"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> ▼
Authentication Type	<input type="text" value="X509CA Password"/> ▼ ?
Username	<input type="text"/>
Password	<input type="text"/>
Encrypt Algorithm	<input type="text" value="BF"/> ▼
Keepalive Interval	<input type="text" value="20"/> ?

Keepalive Timeout	<input type="text" value="120"/> ?
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Verbose Level	<input type="text" value="0"/> ▼ ?

Tunnel Settings		
Item	Description	Default

Tunnel Settings		
Item	Description	Default
Index	Show the index of the tunnel.	1
Enable	Enable OpenVPN tunnel.	ON
Description	Enter some simple words about the OpenVPN Tunnel.	Null
Mode	Select from "P2P", "Client".	Client
Protocol	Select from "UDP", "TCP-Client".	UDP
Server Address	Enter the OpenVPN server address.	Null
Server Port	Enter the OpenVPN server port	1194
Interface Type	Select from "TUN", "TAP" which are two different kinds of device interface for OpenVPN. The difference between TUN and TAP device is this: a TUN device is a virtual IP point-to-point device and a TAP device is a virtual Ethernet device.	TUN
Authentication Type	Select from "None", "Preshared", "Password", "X509CA" and "X509CA Password". "None" and "Preshared" type just work with p2p mode.	None
Local IP	When the "Mode" is "P2P". Define the local IP address of OpenVPN tunnel.	Null
Remote IP	When the "Mode" is "P2P". Define the remote IP address of OpenVPN tunnel.	Null
Username	User name used for Authentication Type "Password" or "X509CA Password".	Null
Password	Password used for Authentication Type "Password" or "X509CA Password".	Null
Encrypt Algorithm	Select from "BF", "DES", "DES-EDE3", "AES128", "AES192" and "AES256". BF: Uses the BF algorithm in CBC mode and 128-bit key. DES: Uses the DES algorithm in CBC mode and 64-bit key. DES-EDE3: Uses the 3DES algorithm in CBC mode and 192-bit key. AES128: Uses the AES algorithm in CBC mode and 128-bit key. AES192: Uses the AES algorithm in CBC mode and 192-bit key. AES256: Uses the AES algorithm in CBC mode and 256-bit key.	BF
Keepalive Interval	Set keepalive (ping) interval to check if the tunnel is active.	20
Keepalive Timeout	Trigger OpenVPN restart after n seconds pass without reception of a ping or other packet from remote.	120
Private Key Password	Password of Private Key for Authentication Type "X509CA"	Null
Enable Compression	Enable to compress the data stream.	ON
Enable NAT	Tick to enable NAT for OpenVPN. The source IP address of host behind R3000 Lite will be disguised before accessing the remote OpenVPN client.	OFF

Tunnel Settings		
Item	Description	Default
Verbose Level	Select the level of the output log. Values range from 0 to 11. 0 -- No output except fatal errors. 1 to 4 -- Normal usage range. 5 -- Output R and W characters to the console for each packet read and write. 6 to 11 -- Debug info range	0

^ Advanced Settings

Enable HMAC Firewall ON OFF

Enable PKCS#12 ON OFF

Enable nsCertType ON OFF

Expert Options ?

Advanced Settings		
Item	Description	Default
Enable HMAC Firewall	Add an additional layer of HMAC authentication on top of the TLS control channel to protect against DoS attacks.	OFF
Enable PKCS#12	Enable the PKCS#12 certificate. It is an exchange of digital certificate encryption standard, used to describe personal identity information.	OFF
Enable nsCertType	Require that peer certificate was signed with an explicit nsCertType designation of "server".	OFF
Expert Options	You can enter some other options of OpenVPN in this field. Each expression can be separated by a ‘;’.	Null

Status

OpenVPN | Status | x509

^ Tunnel Status

Index	Description	Status	Uptime
-------	-------------	--------	--------

x509

OpenVPN | Status | x509

^ X509 Settings ?

Tunnel Name v

Certificate Files No file chosen

^ Certificate Files

Index	File Name	File Size	Last Modification
-------	-----------	-----------	-------------------

x509		
Item	Description	Default
Tunnel Name	Select the name of the Tunnel1 to Tunnel3. Because the maximum number of the tunnel is three.	Tunnel 1
Certificate Files	Choose the correct file to import the certificate into the router. The correct file format as followings: @ca.crt @remote.crt @local.crt @private.key @crl.pem	Null
Index	Show the index of the certificate file.	Null
Filename	Show the name of the certificate file.	Null
File Size	Show the size of the certificate file.	Null
Last Modification	Show the timestamp of that the last time to modify the certificate file.	Null

3.18 VPN > GRE

This section allows users to set the OpenVPN and the related parameters.

GRE
Status

^ GRE tunnel list

Index	Enable	Remote IP Address	+
-------	--------	-------------------	---

Click “+” to add tunnel settings. (The maximum number of the tunnel is three.)

GRE

^ Tunnel Settings

Index

Enable ON OFF

Description

Remote IP Address

Local Virtual IP Address

Remote Virtual IP Address

Enable Default Route ON OFF

Enable NAT ON OFF

Secrets

GRE		
Item	Description	Default
Index	Show the index of the tunnel.	1
Enable	Enable GRE tunnel. GRE (Generic Routing Encapsulation) is a protocol that	ON

	encapsulates packets in order to route other protocols over IP networks.	
Description	Enter some simple words about the GRE Tunnel.	Null
Remote IP Address	Set remote IP Address of the virtual GRE tunnel.	Null
Local Virtual IP	Set local IP Address of the virtual GRE tunnel.	Null
Remote virtual IP	Set remote IP Address of the virtual GRE tunnel.	Null
Enable Default Route	All the traffics of R3000 Lite router will go through the GRE VPN.	OFF
Enable NAT	Tick to enable NAT for GRE. The source IP address of host Behind R3000 Lite will be disguised before accessing the remote GRE server.	Disable
Secrets	Set Tunnel Key of GRE.	Null

This section allow user to check the status of GRE tunnel.

GRE						Status					
^ GRE tunnel status											
Index	Description	Status	Local IP Address	Remote IP Address	Uptime						

3.19 Services > Syslog

This section allows users to set the syslog parameters.

Syslog

^ Syslog Settings

Enable ON OFF

Syslog Level v

Save Position v ?

Log to Remote ON OFF ?

^ Application Debug Control

Enable Modem Debug ON OFF

Enable Link Manager Debug ON OFF

Enable App Debug ON OFF ?

Syslog		
Syslog Settings		
Item	Description	Default
Enable	Click to enable Syslog setting.	OFF
Syslog Level	Select form "Debug", "Info", "Notice", "Warning", "Error" which from low to high. The lower level will output more syslog in detail.	Notice

Save Position	Select the save position from “RAM”, “NVM” and “Console”. Choose “RAM”, the data will be cleared after reboot. But it's not recommended that saving syslog to NVM (Non-Volatile Memory) for a long time.	RAM
Log to Remote	Enable to allow router sending syslog to the remote syslog server. You need to enter the IP and Port of the syslog server.	OFF
Application Debug Control		
Enable Modem Debug	Click to enable router to debug Modem.	ON
Enable Link Manager Debug	Click to enable router to debug Link Manager.	ON
Enable APP Debug	Click to enable router’s debug control for all other applications.	ON

3.20 Services > Event

This section allows users to set the Event parameters.

Event
Notification
Query

^ General Settings

Signal Quality Threshold ?

Event @ Event		
Item	Description	Default
Signal Quality Threshold	Router will generate log event when signal quality less than the threshold, 0 means disable.	0

Event
Notification
Query

^ Event Notification Group Settings

Index	Description	Send SMS	Save to NVM	+
--------------	--------------------	-----------------	--------------------	----------

Click “**+**” button to add an Event parameters.

Notification

^ Event Notification Group Settings

Index	<input style="width: 100%;" type="text" value="1"/>
Description	<input style="width: 100%;" type="text"/>
Send SMS	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
Save to NVM	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ?

Notification@ Event		
Item	Description	Default
Index	The index of event notification group.	1

Description	Enter some simple words to describe the Notify Group.	Null
Sent SMS	Click to enable router to send event notification SMS. Set the phone number that is used for receiving event notification, and use ‘;’ to separate each number.	OFF
Save to NVM	Click to enable router to save event to nonvolatile memory.	OFF
Event Selector	Click to enable Event feature. There are numbers of R3000 Lite’s main running event code you can select, such as “System Startup”, “System Reboot”, “System Time Update”, etc.	OFF

Event
Notification
Query

^ Event Details

Save Position

RAM

▼

Filtering

```
Mar 10 13:51:23, system startup
Mar 10 13:51:28, LAN port link up, eth0
```

Clear

Refresh

Query @ Event		
Item	Description	Default
Save Position	Select the events’ save position from “RAM”, “NVM”. RAM: Random-access memory. NVM: Non-Volatile Memory.	RAM
Filter Message	Event will be filtered according to the Filter Message that the user set. Click the Refresh button, the filtered event will be displayed in the follow box. Use “&” to separate more than one filter message, such as message1&message2.	Null

3.21 Services > NTP

This section allows users to set the NTP parameters.

NTP

Status

^ Timezone Settings

Time Zone

UTC+08:00

v

Expert Setting

?

^ NTP Client Settings

Enable

ON
OFF

Primary NTP Server

pool.ntp.org

Secondary NTP Server

NTP Update Interval

0

?


^ NTP Server Settings

Enable

ON
OFF

Timezone Settings @ NTP		
Item	Description	Default
Time Zone	Select your local time zone.	UTC +08:00
Expert Setting	Specify the time zone with Daylight Saving Time in TZ environment variable format. The Time Zone option will be ignored in this case.	Null
NTP Client Setting @ NTP		
Enable	Click to enable the router to synchronize time from NTP server. Note: R3000 Lite doesn't have the RTC, so NTP client function must always be ON.	ON
Primary NTP Server	Enter primary NTP Server's IP address or domain name.	pool.ntp.org
Secondary NTP Server	Enter secondary NTP Server's IP address or domain name.	Null
NTP Update interval	Enter the interval (minutes) which NTP client synchronize the time from NTP server. Minutes wait for next update, 0 means update only once.	0
NTP Server Setting @ NTP		
Enable	Click to enable the NTP server function of router.	OFF

The status part of NTP allows user to check the current time of R3000 Lite and also synchronize the router time with PC.

Click  button to make the router time synchronize with PC.

NTP
Status

^ Time

System Time 2015-01-01 09:43:23

PC Time 2015-12-21 16:52:52 Sync

Last Update Time Not Updated

3.22 Services > SMS

This section allows users to set the SMS parameters.

SMS
SMS Testing

^ SMS Management Settings

Enable ON OFF

Authentication Type v ?

Phone Number ?

SMS		
Item	Description	Default
Enable SMS Management	Click to enable SMS Management function.	ON
Authentication Type	Select Authentication Type from “Password”, “Phonenum”, “Both”. Password: use the same username and password as WEB manager for authentication. For example, the format of the SMS should be “username: password; cmd1; cmd2; ...” Note: Set the WEB manager password in System > User Management section. Phonenum: use the Phone number for authenticating, user should set the Phone Number that is allowed for SMS management. The format of the SMS should be “cmd1; cmd2; ...” Both: use both the “Password” and “Phonenum” for authentication. User should set the Phone Number that is allowed for SMS management. The format of the SMS should be “username: password; cmd1; cmd2; ...”	Passwo rd
Phone Number	Set the Phone Number that is allowed for SMS management, and use ‘;’ to separate each number.	Null

User can test the current SMS service whether it is available in this section.

SMS
SMS Testing

^ SMS Testing

Phone Number

Message

Result

Send

SMS Testing		
Item	Description	Default
Phone Number	Enter the specified phone number which will receive the SMS from R3000 Lite router.	Null
Message	Enter the message that R3000 Lite router will send it to the specified phone number.	Null
Result	The result of the SMS test will display in the result box.	Null

3.23 Services > DDNS

This section allows users to set the DDNS parameters.

The Dynamic DNS function allows you to alias a dynamic IP address to a static domain name, allows users whose ISP does not assign them a static IP address to use a domain name. This is especially useful for hosting servers via your connection, so that anyone wishing to connect to you may use your domain name, rather than having to use your dynamic IP address, which changes from time to time. This dynamic IP address is the WAN IP address of the router, which is assigned to you by your ISP.

DDNS
Status

^ DDNS Settings

Enable

ON

OFF

Service Provider

DynDNS

v

Hostname

Username

Password

DDNS

Item	Description	Default
Enable	Click to enable DDNS function.	OFF
Service Provider	Select the DDNS service from “DynDNS”, “NO-IP”, “3322”. Note: the DDNS service only can be used after registered by Corresponding service provider.	DynDNS
Hostname	Enter the Host name of the DDNS server provided.	Null
Username	Enter the user name of the DDNS server provided.	Null
Password	Enter the password of the DDNS server provided.	Null

DDNS
Status

^ DDNS Status

Status

Last Update Time

Status		
Item	Description	Default
Status	Show current status of DDNS service.	Null
Last Update Time	Show the time that DDNS updated successfully at last time.	Null

3.24 Services > VRRP

This section allows users to set the VRRP parameters.

VRRP

^ VRRP Settings

Enable ON OFF

Interface v

Group ID

Priority

Interval ?

Virtual IP Address

VRRP		
Item	Description	Default
VRRP	VRRP (Virtual Router Redundancy Protocol) is an Internet protocol that provides a way to have one or more backup routers when using a statically configured router on a local area network (LAN).Using VRRP, a virtual IP address can be specified manually.	Null

VRRP		
Item	Description	Default
Enable	Click to enable VRRP protocol.	OFF
Interface	Display "lan0".	lan0
Group ID	Specify which VRRP group of this router belong to.	1
Priority	Enter the priority value from 1 to 255. The larger value has higher priority.	120
Interval	The interval that master router sends VRRP packets to backup routers.	5
Virtual IP Address	A virtual IP address is shared among the routers, with one designated as the master router and the others as backups. In case the master fails, the virtual IP address is mapped to a backup router's IP address. (This backup becomes the master router)	192.168.0.1

3.25 Services > SSH

SSH

Keys Management

^ SSH Settings

Enable
 ON OFF

Port

Disable Password Logins
 ON OFF

SSH		
Item	Description	Default
Enable	Enable the function that user can access R3000 Lite Router via SSH.	OFF
Port	Set the port of the SSH access.	22
Disable Password Logins	Switch to "ON" and disable password logins, so that user cannot access R3000 Lite via SSH. In this situation, you should import the authorized key into R3000 Lite in Keys Management part for accessing R3000 Lite. Switch to "OFF", you can access R3000 Lite via SSH normally.	OFF

SSH

Keys Management

^ Import Authorized Keys

Authorized Keys

Keys Management	
Item	Description

Authorized Keys	<p>Effective when SSH > Disable Password Logins is "ON".</p> <p>Select a key file from PC, then click Import button to import the key file in R3000 Lite. So that you can access R3000 Lite via SSH without password.</p>
-----------------	--

3.26 Services > Web Server

This section allows users to modify the parameters of Web Server.

Web Server
Certificate Management

^ General Settings

HTTP Port ?

HTTPS Port ?

Basic @ Web Server		
Item	Description	Default
HTTP Port	Enter the HTTP port number you want to change in R3000 Lite’s Web Server. On a Web server, port 80 is the port that the server "listens to" or expects to receive from a Web client. If you configure the router with other HTTP Port number except 80, only adding that port number then you can login R3000 Lite’s Web Server.	80
HTTPS Port	Enter the HTTPS port number you want to change in R3000 Lite’s Web Server. On a Web server, port 443 is the port that the server "listens to" or expects to receive from a Web client. If you configure the router with other HTTPS Port number except 443, only adding that port number then you can login R3000 Lite’s Web Server. <i>Note: HTTPS is more secure than HTTP. In many cases, clients may be exchanging confidential information with a server, which needs to be secured in order to prevent unauthorized access. For this reason, HTTP was developed by Netscape corporation to allow authorization and secured transactions.</i>	443
Login Timeout (s)	Enter the Login timeout you want to change in R3000 Lite’s Web Server. After "Login Timeout", R3000 Lite will force to log out the Web GUI and then you need to re-login again to Web GUI.	1800

This section allows users to import the certificate file into the route.

Web Server
Certificate Management

^ Import Certificate



Import Type CA v

HTTPS Certificate Choose File No file chosen Import



Certificate Management		
Item	Description	Default
Import Type	Select from "CA" and "Private Key". CA: a digital certificate issued by CA center. Private Key: a private key file.	CA
HTTPS Certificate	Click "Browse" to select the certificate file in your computer, and then click "Import" to import this file into your router.	

3.27 Services > Advanced

This section allows users to set the Advanced and parameters.

System	Reboot	AT over Telnet
^ System Settings		
Device Name	<input type="text" value="router"/>	
User LED Type	<input type="text" value="SIM"/>	

System @ Advanced		
Item	Description	Default
Device Name	Set the device name to distinguish different devices you have installed. Valid characters: a-z, A-Z, 0-9, ., -.	router
User LED Type	Select from "None", "SIM", "NET", "OpenVPN" and "IPSec".	SIM

System	Reboot	AT over Telnet
^ Periodic Reboot Settings		
Periodic Reboot	<input type="text" value="0"/>	
Daily Reboot Time	<input type="text"/>	

Reboot		
Item	Description	Default
Periodic Reboot	Set the reboot period of the router, 0 means disable.	0
Daily Reboot Time	Set the daily reboot time of the router, you should follow the format as HH:MM, in 24h time frame, otherwise the data will be invalid. Leave it empty means disable.	Null

System
Reboot
AT over Telnet

^ General Settings

Enable ON OFF

Port

AT Cmd COM Port

AT over Telnet @ Advanced		
Item	Description	Default
Enable	Click to enable AT over Telnet function.	OFF
Port	Enter a specific port number to allow user sent AT command to this router over telnet.	0
AT Cmd COM Port	Select a COM port used for identifying the AT command.	ttyUSB0

3.28 System > Debug

This section allow user to check and download the syslog details.

Syslog

^ Syslog Details

Log Level

Filtering ?

^ Syslog Files

Index	File Name	File Size	Last Modification
-------	-----------	-----------	-------------------

^ System Diagnostic Data

System Diagnostic Data Generate

System Diagnostic Data Download

Syslog Details @ Syslog		
Item	Description	Default
Log Level	Select form “Debug”, “Info”, “Notice”, “Warn”, “Error” which from low to high. The lower level will output more syslog in detail.	Debug
Filtering	Log will be filtered according to the Filter Message that the user set. Click the Refresh button, the filtered log will be displayed in the follow box. Use “&” to separate more than one filter message, such as “keyword1&keyword2”.	Null
Refresh	Select from “Manual Refresh”, “5 Seconds”, “10 Seconds”, “20 Seconds”and“30 Seconds”. User can select these intervals to refresh the log information displayed in the follow box. Select “manual refresh”, user should click the refresh button to refresh the syslog.	Manual Refresh
Syslog Files List @ Syslog		
Syslog Files List	It can show at most 5 syslog files in the list, the files’ name range from message0 to message 4. And the newest syslog file will be placed on the top of the list.	/
System Diagnosing Data @ Syslog		
Generate	Click to generate the syslog diagnosing file.	/
Download	Click to download system diagnosing file.	/

3.29 System > Update

Update

^ System Update

File Update

Update		
Item	Description	Default
System Update	Click “Browse” button to select the correct firmware in your PC, and then click “Update” button to update. After updating successfully, you need to click “save and apply”, and then reboot the router to take effect.	Null

3.30 System > APP Center

This section allow user to add a new function to R3000 Lite router. And the new function will be in the form of an APP file which could be installed in R3000 Lite router. In general, the App which had installed will display in **Service** section.

App Center

^ App Install

File

No file chosen
Install

^ Installed Apps

Index	Name	Version	Status	Description
1	robustlink	1.0.0	Stopped	RobustLink Client ✕

App Center		
Item	Description	Default
File	Choose the correct App file from your PC, and click Install button to import to R3000 Lite router. File format: xxx.rpk, e.g. R3000-robustlink-1.0.0.rpk.	/
Install Apps	Those Apps which had installed in R3000 Lite will be listed in Installed Apps .	Null
Index	Show the index of the App.	Null
Name	Show the name of the App.	Null
Version	Show the version of the App.	Null
Status	Show the Status of the App.	Null
Description	Show the description of the App.	Null

3.31 System > Tools

This section provides users three tools: Ping, Traceroute and Sniffer.

Ping
At Debug
Traceroute
Sniffer

^ Ping

IP Address

Number of Request

Timeout

Local IP

Ping @ Tools		
Item	Description	Default
IP address	Enter the ping destination IP address or domain name.	Null
Number of requests	Specify the number of ping requests.	5
Timeout	Specify timeout of ping request.	1
Local IP	Specify the local IP from cellular WAN, Ethernet WAN or Ethernet LAN. Null stands for selecting local IP address from these three automatically.	Null
Start	Click this button to start ping request, and the log will be displayed in the follow box.	Null
Stop	Click this button to stop ping request.	

Ping
At Debug
Traceroute
Sniffer

^ At Debug

Command

Result

At Debug @ Tools	
Item	Description
Command	Enter a At command in Command box, then click <input type="button" value="Send"/> button to send the At command to the cellular module.
Result	It will display the AT commands which respond from the cellular module in this box.

Ping
At Debug
Traceroute
Sniffer

^ Traceroute

Trace Address

Trace Hops

Trace Timeout

Traceroute @ Tools

Item	Description	Default
Trace Address	Enter the trace destination IP address or domain name.	Null
Trace Hops	Specify the max trace hops. Router will stop tracing if the trace hops has met max value no matter the destination has been reached or not.	30
Trace Timeout	Specify timeout of Traceroute request.	1
Start	Click this button to start Traceroute request, and the log will be displayed in the follow box.	
Stop	Click this button to stop Traceroute request	

Ping
At Debug
Traceroute
Sniffer

^ Sniffer

Interface v
Host
Packets Request
Protocol v
Status

Start
Stop

^ Capture Files

Index	File Name	File Size	Last Modification
1	14-01-01_09-56-26.cap	16682	Wed Jan 1 09:56:30 2014

Sniffer @ Tools		
Item	Description	Default
Interface	Select form "All", "ETH1", and "ETH2": All: contain all the interface; ETH1: Ethernet interface1; ETH2: Cellular WAN.	All
Host	Filter the packet that contain the specify IP address.	Null
Packets Request	Set the packet number that the router can sniffer at a time.	1000
Protocol	Select from "All", "IP", "TCP", "UDP" and "ARP".	All
Port	Set the port number for TCP or UDP that is used in sniffer.	Null
Status	Show the current status of sniffer.	Null
	Click this button to start the sniffer.	/
	Click this button to stop the sniffer. Once click the stop button, a new log file will be displayed in the follow List.	/
Capture Files	Every times of sniffer log will be saved automatically as a new file. You can find the file from this Sniffer Traffic Data List and click to download the log, click to delete the log file. It can cache a maximum of 5 files.	Null

3.32 System > Profile

This section allows users to import or export the configuration file, and restore the router to factory default setting.

Profile

^ Import Configuration File

Import Type

Keep Other Confgs

?

XML Configuration File

Browse...

Import

^ Export Configuration File

Export Type

Full

?

XML Configuration File

Generate

^ Factory Configuration

Factory Configuration

Restore

Import Configuration File @ Profile		
Import Type	Define what to do about the configs that is not contained in the imported file. There are two Import Types: Keep Other Confgs: Keep other configuration unchanged when import XML configuration file. Set Others To Default: Set other configuration to factory default when import XML configuration file.	Keep Other Confgs
XML Configuration File	Click "Browse" to select the XML file in your computer, and then click "Import" to import this file into your router.	
Export Configuration File @ Profile		
Export Type	There are four export Types : Essential: export the configuration file that only include enabled features. Essential && Detailed: export the configuration file that only include enabled features, and attach extra information such as range and default setting of those enable config option. Full: export the configuration file of all features; include both the enabled and disabled features. Full && Detailed: export the configuration file of all features, and attach extra information such as range and default setting of every config option.	Full
Export	Click "Export" and the configuration will be showed in the new popup browser window, then you can save it as a XML file.	
Factory Configuration @ Profile		
Restore	Click the "Restore" button to restore the router to factory default setting.	

3.33 System > Device Configuration

Device Configuration

All settings on this page can not be exported.
 You need to reboot system for the changes to take effect.
 Please note that some configurations may restore to default after reboot.
 You need to clear web browser's cache before next login at most of time.

^ Advanced Device Settings

IP Passthrough Enable ON OFF

Advanced Device Settings		
Item	Description	Default
IP Passthrough Enable	Click to enable the IP Passthrough feature.	OFF

3.34 System > User Management

This section allows users to modify or add management user accounts.

Super User **Common User**

^ Super User Settings

Old Password ?

New Password ?

Confirm Password ?

Super User		
Item	Description	Default
Super User	One router has only one super user account. Under this account, user has the highest authority include modify, add and manage those user accounts.	/
Old Password	The old password of super user which default is "admin", valid characters: a-z, A-Z, 0-9, @, ., -, #, \$, *.	Null
New Password	Enter a new password for the super user, valid characters: a-z, A-Z, 0-9, @, ., -, #, \$, *.	Null
Confirm Password	Enter the new password again which had added in New Password item.	Null

Super User Common User

^ Common Users Settings

Index	Role	Username	+
-------	------	----------	---

Click the “+” button to add a new common user.

Note: One router has 5 common user accounts at most.

Common User

^ Common Users Settings

Index:

Role: v

Username:

Password:

Common User		
Item	Description	Default
Role	Select from “Visitor” and “Editor”. Visitor: Users only can view the configuration of router under this level; Editor: Users can view and set the configuration of router under this level.	Visitor
Username	Set the Username. Valid characters: a-z, A-Z, 0-9, ., -.	Null
Password	Set the password which at least contains 5 characters. Valid characters: a-z, A-Z, 0-9, @, ., -, #, \$, *.	Null

Chapter 4 Configuration Examples


4.1 Interface

DB9 Female Connector

PIN	Debug	RS232	RS485 (2-wire)	Direction
1			Data+ (A)	-
2		RXD		R3000 Lite → Device
3		TXD		Device → R3000 Lite
4	DRXS			Device → R3000 Lite
5	GND	GND		-
6			Data- (B)	-
7		RTS		Device → R3000 Lite
8		CTS		R3000 Lite → Device
9	DTXD			R3000 Lite → Device


4.1.1 Console Port

User can use the console port to manage the router via CLI commands. Please check section Introductions for CLI.




4.1.2 RS232

R3000 Lite supports one RS232 for serial data communication. Please refer to the connection diagram at the right site.



4.1.3 RS485

R3000 Lite supports one RS485 for serial data communication. Please refer to the connection diagram at the right site.



4.2 Cellular

2.2.1 Cellular Dial-Up

This section shows users how to configure the primary and backup SIM card of Cellular Dial-up.

Interface > Link Manager > General Setting

Select WWAN1 as Primary Link.

Link Manager		Status		
^ General Settings				
Primary Link	WWAN1	<input type="button" value="v"/> <input type="button" value="?"/>		
Backup Link	None	<input type="button" value="v"/>		
Emergency Reboot	<input type="button" value="ON"/> <input checked="" type="button" value="OFF"/>	<input type="button" value="?"/>		
^ Link Settings				
Index	Type	Description	Connection Type	
1	WWAN1		DHCP	<input type="button" value="v"/>
2	WWAN2		DHCP	<input type="button" value="v"/>

Click to set the WWAN1's parameter according to the current ISP.

Link Manager	
^ General Settings	
Index	1
Type	WWAN1 <input type="button" value="v"/>
Description	
^ WWAN Settings	
Automatic APN Selection	<input checked="" type="button" value="ON"/> <input type="button" value="OFF"/>
Dialup Number	*99***1#
Authentication Type	Auto <input type="button" value="v"/>
Aggressive Reset	<input type="button" value="ON"/> <input checked="" type="button" value="OFF"/> <input type="button" value="?"/>
Switch SIM By Data Allowance	<input type="button" value="ON"/> <input checked="" type="button" value="OFF"/> <input type="button" value="?"/>
Data Allowance	0 <input type="button" value="?"/>
Billing Day	1 <input type="button" value="?"/>

^ Ping Detection Settings
?

Enable ON OFF

Primary Server

Secondary Server

Interval ?

Retry Interval ?

Timeout ?

Max Ping Tries ?

^ Advanced Settings

MTU

Overridden Primary DNS

Overridden Secondary DNS

The modifications will take effect after click “Submit” and “save and apply” button.

Interface > Cellular

Cellular	Status			
^ Advanced Cellular Settings				
Index	SIM Card	Phone Number	Network Type	Band Select Type
1	SIM1		Auto	All
2	SIM2		Auto	All

Click to set the SIM card’s parameter according to the application requirement.

Cellular

^ General Settings

Index

SIM Card v

Phone Number

Extra AT Cmd ?

^ Cellular Network Settings

Network Type v ?

Band Select Type v ?

The modifications will take effect after click “Submit” and “save and apply” button.

3.2.1 SMS Remote Control

R3000 Lite supports remote control via SMS. User can use following commands to get the status of R3000 Lite, and set all the parameters of R3000 Lite.

There are three authentication types for SMS control. You can select from “Password”, “Phonenum” and “Both”.


An SMS command has following structure:


1. Password mode—Username: Password;cmd1;cmd2;cmd3; ...cmdn (available every phone number).
2. Phonenum mode--cmd1; cmd2; cmd3; ... cmdn (available when the SMS was sent from the phone number which had been added in R3000 Lite’s phone group).
3. Both mode-- Username: Password;cmd1;cmd2;cmd3; ...cmdn (available when the SMS was sent from the phone number which had been added in R3000 Lite’s phone group).


SMS command Explanation:

1. User name and Password: it uses the same username and password as WEB manager for authentication.
2. cmd1, cmd2, cmd3 to Cmdn, the command format is the same as the CLI command, more details about CLI cmd please refer to **chapter 5 Introductions for CLI**.

Note: Download the configure XML file from the configured web browser. The format of SMS control command can refer to the data of the XML file.

Go to System > Profile > Export Configuration File, select Export type as **Full**, click  to generate

the XML file and then click  to export the XML file.



XML command:

```
<lan>
<network max_entry_num="2">
<id>1</id>
<interface>lan0</interface>
<ip>172.16.99.11</ip>
<netmask>255.255.0.0</netmask>
```

```
<mtu>1500</mtu>
```

SMS cmd:

```
set lan network 1 interface lan0
set lan network 1 ip 172.16.99.11
set lan network 1 netmask 255.255.0.0
set lan network 1 mtu 1500
```

3. The semicolon character (;) is used to separate more than one commands packed in a single SMS.
4. E.g.

admin:admin;status system

In this command, username is admin, password is admin, and the function of the command is getting the system status.

SMS received:

```
hardware_version = 1.0
firmware_version = "1.2.0 (Rev 399)"
kernel_version = 3.10.49
device_model = R3000 Lite
serial_number = 15090140040008
uptime = "0 days, 00:04:07"
system_time = "Tue Dec 22 15:02:36 2015"
```

admin:admin;reboot

In this command, username is admin, password is admin, and the command is reboot R3000 Lite.

SMS received:

```
OK
```

admin:admin;set firewall remote_ssh_access false;set firewall remote_telnet_access false

In this command, username is admin, password is admin, and the function of the command is disabling the remote_ssh and remote_telnet access.

SMS received:

```
OK
OK
```

admin:admin; set lan network 1 interface lan0;set lan network 1 ip 172.16.99.11;set lan network 1 netmask 255.255.0.0;set lan network 1 mtu 1500


In this command, username is admin, password is admin, and the function of those commands is configuring the LAN parameter.

SMS received:

```
OK
OK
OK
OK
```

4.3 Network

4.3.1 IPSEC VPN



Note: the configuration of server and client is as follows.

IPSecVPN_SERVER:

Cisco 2811:

```

Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
  authentication  Set authentication method for protection suite
  encryption     Set encryption algorithm for protection suite
  exit           Exit from ISAKMP protection suite configuration mode
  group          Set the Diffie-Hellman group
  hash           Set hash algorithm for protection suite
  lifetime       Set lifetime for ISAKMP security association
  no             Negate a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
  client  Set client configuration policy
  enable  Enable ISAKMP
  key     Set pre-shared key for remote peer
  policy  Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
  dynamic-map  Specify a dynamic crypto map template
  ipsec        Configure IPSEC policy
  isakmp       Configure ISAKMP policy
  key          Long term key operations
  map          Enter a crypto map
Router(config)#crypto ipsec ?
  security-association  Security association parameters
  transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
  ah-md5-hmac  AH-HMAC-MD5 transform
  ah-sha-hmac  AH-HMAC-SHA transform
  esp-3des    ESP transform using 3DES(EDE) cipher (168 bits)
  esp-aes     ESP transform using AES cipher
  esp-des     ESP transform using DES cipher (56 bits)
  esp-md5-hmac  ESP transform using HMAC-MD5 auth
  esp-sha-hmac  ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface fastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if)#crypto map cry-map
*Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON

```

IPSecVPN_CLIENT:

VPN > IPsec > Tunnel

General	Tunnel	Status	x509
---------	--------	--------	------

^ Tunnel Settings

Index	Enable	Description	
			+

Then click “+”.

Tunnel

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text"/>
Gateway	<input type="text" value="58.1.1.1"/> ?
Mode	<input type="text" value="Tunnel"/> v
Protocol	<input type="text" value="ESP"/> v
Local Subnet	<input type="text" value="192.168.1.0"/> ?
Remote Subnet	<input type="text" value="255.255.255.0"/> ?

^ IKE Settings

Negotiation Mode	<input type="text" value="Main"/> v
Authentication Algorithm	<input type="text" value="MD5"/> v
Encrypt Algorithm	<input type="text" value="3DES"/> v
IKE DH Group	<input type="text" value="MODP(1024)"/> v
Authentication Type	<input type="text" value="PSK"/> v
PSK Secret	<input type="text" value="•••••"/>
Local ID Type	<input type="text" value="Default"/> v
Remote ID Type	<input type="text" value="Default"/> v
IKE Lifetime	<input type="text" value="86400"/> ?

^ SA Settings

Encrypt Algorithm	<input type="text" value="3DES"/> v
Authentication Algorithm	<input type="text" value="MD5"/> v
PFS Group	<input type="text" value="MODP(1024)"/> v
SA Lifetime	<input type="text" value="28800"/> ?
DPD Interval	<input type="text" value="60"/> ?
DPD Failures	<input type="text" value="180"/> ?

^ Advanced Settings

Enable Compression	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF
--------------------	---

The modification will take effect after click **Submit > Save & Apply > Reboot**.

The comparison between server and client is as following picture:

Server(Cisco 2811)

```

Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
authentication  Set authentication method for protection suite
encryption     Set encryption algorithm for protection suite
exit           Exit from ISAKMP protection suite configuration mode
group         Set the Diffie-Hellman group
hash          Set hash algorithm for protection suite
lifetime      Set lifetime for ISAKMP security association
no            Negate a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
client        Set client configuration policy
enable        Enable ISAKMP
key           Set pre-shared key for remote peer
policy        Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
dynamic-map   Specify a dynamic crypto map template
ipsec         Configure IPSEC policy
isakmp        Configure ISAKMP policy
key           Long term key operations
map           Enter a crypto map
Router(config)#crypto ipsec ?
security-association  Security association parameters
transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
ah-md5-hmac          AH-HMAC-MD5 transform
ah-sha-hmac           AH-HMAC-SHA transform
esp-3des              ESP transform using 3DES (EDE) cipher (168 bits)
esp-aes               ESP transform using AES cipher
esp-des               ESP transform using DES cipher (56 bits)
esp-md5-hmac          ESP transform using HMAC-MD5 auth
esp-sha-hmac          ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface fastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if)#crypto map cry-map
*Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON
                    
```

Client (R2000 Lite)

Tunnel

^ Tunnel Settings

Index: 1

Enable: ON

Description:

Gateway: 58.1.1.1

Mode: Tunnel

Protocol: ESP

Local Subnet: 192.168.1.0

Remote Subnet: 255.255.255.0

^ IKE Settings

Negotiation Mode: Main

Authentication Algorithm: MD5

Encrypt Algorithm: 3DES

IKE DH Group: MODP(1024)

Authentication Type: PSK

PSK Secret: *****

Local ID Type: Default

Remote ID Type: Default

IKE Lifetime: 86400

^ SA Settings

Encrypt Algorithm: 3DES

Authentication Algorithm: MD5

PFS Group: MODP(1024)

SA Lifetime: 28800

DPD Interval: 60

DPD Failures: 180


^ Advanced Settings

Enable Compression: ON OFF

IKE Setting in Client must be consistent with server.

SA Setting in Client must be consistent with server.

4.3.2 OPENVPN




Note: the configuration of two points is as follows.

OPENVPN (p2p):

Point 1

VPN > OpenVPN > OpenVPN



Click “+”.

OpenVPN

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text" value="OpenVPN-Point 1"/>
Mode	<input type="text" value="P2P"/> v
Protocol	<input type="text" value="UDP"/> v
Server Address	<input type="text" value="59.1.1.1"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> v
Authentication Type	<input type="text" value="None"/> v ?
Local IP	<input type="text" value="10.8.0.1"/>
Remote IP	<input type="text" value="10.8.0.2"/>
Keepalive Interval	<input type="text" value="20"/> ?
Keepalive Timeout	<input type="text" value="120"/> ?
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF

^ Advanced Settings

Expert Options	<input type="text" value="route 192.168.1.0 255"/> ?
----------------	--

The modifications will take effect after click “Submit > Save & Apply”.

Point 2

VPN > OpenVPN > OpenVPN

OpenVPN	Status	x509	
^ Tunnel Settings			
Index	Enable	Description	+

Click “+”.

OpenVPN

^ Tunnel Settings

Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Description	<input type="text" value="OpenVPN-Point 2"/>
Mode	<input type="text" value="P2P"/> v
Protocol	<input type="text" value="UDP"/> v
Server Address	<input type="text" value="58.1.1.1"/>
Server Port	<input type="text" value="1194"/>
Interface Type	<input type="text" value="TUN"/> v
Authentication Type	<input type="text" value="None"/> v ?
Local IP	<input type="text" value="10.8.0.2"/>
Remote IP	<input type="text" value="10.8.0.1"/>
Keepalive Interval	<input type="text" value="20"/> ?
Keepalive Timeout	<input type="text" value="120"/> ?
Enable Compression	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF
Enable NAT	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF

^ Advanced Settings


Expert Options	<input type="text" value="route 192.168.2.0 255"/> ?
----------------	--

The modifications will take effect after click **Submit > Save & Apply**.

The comparison between point 1 and point 2 is as following picture:

Point 1	point 2
<p>OpenVPN</p> <p>^ Tunnel Settings</p> <p>Index: 1</p> <p>Enable: <input checked="" type="checkbox"/> ON</p> <p>Description: OpenVPN-Point 1</p> <p>Mode: P2P</p> <p>Protocol: UDP</p> <p>point 2 address: Server Address: 59.1.1.1</p> <p>Server Port: 1194</p> <p>Interface Type: TUN</p> <p>Authentication Type: None</p> <p>point 1 tunnel IP: Local IP: 10.8.0.1</p> <p>point 2 tunnel IP: Remote IP: 10.8.0.2</p> <p>Keepalive Interval: 20</p> <p>Keepalive Timeout: 120</p> <p>Enable Compression: <input checked="" type="checkbox"/> ON</p> <p>Enable NAT: <input checked="" type="checkbox"/> ON</p> <p>^ Advanced Settings</p> <p>Expert Options: route 192.168.1.0 255</p>	<p>OpenVPN</p> <p>^ Tunnel Settings</p> <p>Index: 1</p> <p>Enable: <input checked="" type="checkbox"/> ON</p> <p>Description: OpenVPN-Point 2</p> <p>Mode: P2P</p> <p>Protocol: UDP</p> <p>point 1 address: Server Address: 58.1.1.1</p> <p>Server Port: 1194</p> <p>Interface Type: TUN</p> <p>Authentication Type: None</p> <p>point 2 tunnel IP: Local IP: 10.8.0.2</p> <p>point 1 tunnel IP: Remote IP: 10.8.0.1</p> <p>Keepalive Interval: 20</p> <p>Keepalive Timeout: 120</p> <p>Enable Compression: <input checked="" type="checkbox"/> ON</p> <p>Enable NAT: <input checked="" type="checkbox"/> ON</p> <p>^ Advanced Settings</p> <p>Expert Options: route 192.168.2.0 255</p>

4.3.3 GRE VPN



VPN > GRE > GRE

GRE **Status**

^ Tunnel Settings

Index	Enable	Description	Remote IP Address	
				+

Click “+”.

GRE-1:

^ Tunnel Settings

Index: 1

Enable: ON OFF

Description: GRE-1

Remote IP Address: 59.1.1.1

Local Virtual IP Address: 10.8.0.1

Remote Virtual IP Address: 10.8.0.2

Enable Default Route: ON OFF

Enable NAT: ON OFF

Secrets:

The modifications will take effect after click **Submit > Save & Apply**.

GRE-2:

^ Tunnel Settings

Index: 1

Enable: ON OFF

Description: GRE-2

Remote IP Address: 58.1.1.1

Local Virtual IP Address: 10.8.0.2

Remote Virtual IP Address: 10.8.0.1

Enable Default Route: ON OFF

Enable NAT: ON OFF

Secrets:

The modifications will take effect after click **Submit > Save & Apply**.

The comparison between point 1 and point 2 is as following picture:

GRE-1

GRE-2

^ Tunnel Settings		^ Tunnel Settings	
Index	<input type="text" value="1"/>	Index	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/> ON	Enable	<input checked="" type="checkbox"/> ON
Description	<input type="text" value="GRE-1"/>	Description	<input type="text" value="GRE-2"/>
Remote IP Address	<input type="text" value="59.1.1.1"/>	Remote IP Address	<input type="text" value="58.1.1.1"/>
Local Virtual IP Address	<input type="text" value="10.8.0.1"/>	Local Virtual IP Address	<input type="text" value="10.8.0.2"/>
Remote Virtual IP Address	<input type="text" value="10.8.0.2"/>	Remote Virtual IP Address	<input type="text" value="10.8.0.1"/>
Enable Default Route	<input type="checkbox"/> OFF	Enable Default Route	<input type="checkbox"/> OFF
Enable NAT	<input type="checkbox"/> OFF	Enable NAT	<input type="checkbox"/> OFF
Secrets	<input type="text" value="*****"/>	Secrets	<input type="text" value="*****"/>

GRE-1 public IP
GRE-1 tunnel IP
GRE-2 tunnel IP
GRE-2 public IP
GRE-2 tunnel IP
GRE-1 tunnel IP
set the same secret as GRE-2
set the same secret as GRE-1

Chapter 5 Introductions for CLI

5.1 What's CLI

The R3000 Lite command-line interface (CLI) is a software interface providing another way to set the parameters of equipment from the [SSH](#) or through a [telnet](#) network connection.

Route login:

Router login: admin

Password: admin

#

CLI commands:

? (**Note:** the '?' won't display on the page.)

!	Comments
add	Add a list entry of configuration
clear	Clear statistics
config	Configuration operation
debug	Output debug information to the console
del	Delete a list entry of configuration
exit	Exit from the CLI
help	Display an overview of the CLI syntax
ping	Send messages to network hosts
reboot	Halt and perform a cold restart
route	Static route modify dynamically, this setting will not be saved
set	Set system configuration
show	Show system configuration
status	Show running system information
tftpupdate	Update firmware using tftp
traceroute	Print the route packets trace to network host
urlupdate	Update firmware using http or ftp
ver	Show version of firmware

5.2 How to Configure the CLI

Following is a list about the description of help and the error should be encountered in the configuring program.

Commands /tips	Description
?	Typing a question mark “?” will show you the help information.
Ctrl+c	Press these two keys at the same time, except its “copy” function but also can be used for “break” out of the setting program.
Syntax error: The command is not completed	Command is not completed.
Tick space key+ Tab key	It can help you finish you command. Example: # config (tick Enter key) Syntax error: The command is not completed # config (tick space key+ Tab key) commit save_and_apply loaddefault
# config save_and_apply / #config commit	When you finish your setting, you should enter those commands to make your setting take effect on the device. Note: commit and save_and_apply plays the same role.

5.2.1 QuickStart with Configuration Examples

The best and quickest way to master CLI is firstly to view all features from the webpage and then reading all CLI commands at a time, finally learn to configure it with some reference examples.

Example 1: Show current version

```
# status system
hardware_version = 1.0
firmware_version = "1.2.0 (Rev 399)"
kernel_version = 3.10.49
device_model = R3000 Lite
serial_number = 15090140040008
uptime = "0 days, 00:04:07"
system_time = "Tue Dec 22 15:02:36 2015"
```

Example 2: Update firmware via tftp

```
# tftpupdate (space+?)
firmware New firmware
# tftpupdate firmware (space+?)
String Firmware name
# tftpupdate firmware R3000-firmware-sysupgrade-unknown.bin host 192.168.100.99 //enter a new firmware name
Downloading
R3000-firmware-s 100% |*****| 5018k 0:00:00 ETA
Flashing
Checking 100%
Decrypting 100%
```

```
Flashing 100%
Verifying 100%
Verify Success
upgrade success //update success
# config save_and_apply
OK // save and apply current configuration, make you configuration effect
```

Example 3: Set link-manager

```
# set
# set
  at_over_telnet    AT Over Telnet
  cellular          Cellular
  ddns             Dynamic DNS
  ethernet         Ethernet
  event            Event Management
  firewall         Firewall
  gre              GRE
  ipsec            IPSec
  lan              Local Area Network
  link_manager     Link Manager
  ntp              NTP
  openvpn          OpenVPN
  reboot           Automatic Reboot
  robustlink       Robustlink
  route            Route
  sms              SMS
  snmp             SNMP agent
  ssh              SSH
  syslog           Syslog
  system           System
  user_management  User Management
  vrrp             VRRP
  web_server       Web Server
# set link_manager
  primary_link     Primary Link
  backup_link      Backup Link
  backup_mode      Backup Mode
  emergency_reboot Emergency Reboot
  link             Link Settings
# set link_manager primary_link (space+?)
Enum Primary Link (wwan1/wwan2/wan)
# set link_manager primary_link wwan1 //select "wwan1" as primary_link
OK //setting succeed
# set link_manager link 1
```

```

type                Type
desc                Description
connection_type     Connection Type
wwan                WWAN Settings
static_addr         Static Address Settings
pppoe               PPPoE Settings
ping                Ping Settings
mtu                 MTU
dns1_overridden     Overridden Primary DNS
dns2_overridden     Overridden Secondary DNS
# set link_manager link 1 type wwan1
OK
# set link_manager link 1 wwan
  auto_apn           Automatic APN Selection
  apn                APN
  username           Username
  password           Password
  dialup_number      Dialup Number
  auth_type          Authentication Type
  aggressive_reset   Aggressive Reset
  switch_by_data_allowance Switch SIM By Data Allowance
  data_allowance     Data Allowance
  billing_day        Billing Day
# set link_manager link 1 wwan switch_by_data_allowance true
OK
#
# set link_manager link 1 wwan data_allowance 100           //open cellular switch_by_data_traffic
OK                                                         //setting succeed
# set link_manager link 1 wwan billing_day 1                //setting specifies the day of month for billing
OK                                                         // setting succeed
...
# config save_and_apply
OK                                                         // save and apply current configuration, make you configuration effect

```

Example 4: Set LAN IP address

```

# show lan all
network {
  id = 1
  interface = lan0
  ip = 192.168.0.1
  netmask = 255.255.255.0
  mtu = 1500
  dhcp {
    enable = true

```

```

        mode = server
        relay_server = ""
        pool_start = 192.168.0.2
        pool_end = 192.168.0.100
        netmask = 255.255.255.0
        gateway = ""
        primary_dns = ""
        secondary_dns = ""
        wins_server = ""
        lease_time = 120
        expert_options = ""
        debug_enable = false
    }
}
multi_ip {
    id = 1
    interface = lan0
    ip = 172.16.99.11
    netmask = 255.255.0.0
}
#
# set lan
network    Network Settings
multi_ip   Multiple IP Address Settings
vlan       VLAN
# set lan network 1(space+?)
interface  Interface
ip         IP Address
netmask    Netmask
mtu        MTU
dhcp       DHCP Settings
# set lan network 1 interface lan0
OK
# set lan network 1 ip 172.16.99.22           //set IP address for lan
OK                                             //setting succeed
# set lan network 1 netmask 255.255.0.0
OK
#
...
# config save_and_apply
OK                                             // save and apply current configuration, make you configuration effect

```

Example 5: CLI for setting Cellular

```
# show cellular all
```

```
sim {
    id = 1
    card = sim1
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_lte_800 = false
    band_lte_850 = false
    band_lte_900 = false
    band_lte_1800 = false
    band_lte_1900 = false
    band_lte_2100 = false
    band_lte_2600 = false
    band_lte_1700 = false
    band_lte_700 = false
    band_tdd_lte_2600 = false
    band_tdd_lte_1900 = false
    band_tdd_lte_2300 = false
    band_tdd_lte_2500 = false
}
sim {
    id = 2
    card = sim2
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_lte_800 = false
    band_lte_850 = false
    band_lte_900 = false
    band_lte_1800 = false
    band_lte_1900 = false
    band_lte_2100 = false
    band_lte_2600 = false
    band_lte_1700 = false
    band_lte_700 = false
    band_tdd_lte_2600 = false
    band_tdd_lte_1900 = false
    band_tdd_lte_2300 = false
    band_tdd_lte_2500 = false
}
# set(space+?)
at_over_telnet      cellular      ddns          dhcp          dns
event               firewall     ipsec         lan           link_manager
```

```

ntp                openvpn          reboot          route            serial_port
sms                snmp            syslog          system           user_management
vrrp

# set cellular(space+?)
  sim    SIM Settings
# set cellular sim(space+?)
  Integer  Index (1..2)

# set cellular sim 1(space+?)
  card                SIM Card
  phone_number        Phone Number
  extra_at_cmd        Extra AT Cmd
  network_type        Network Type
  band_select_type    Band Select Type
  band_lte_800        LTE 800 (band 20)
  band_lte_850        LTE 850 (band 5)
  band_lte_900        LTE 900 (band 8)
  band_lte_1800       LTE 1800 (band 3)
  band_lte_1900       LTE 1900 (band 2)
  band_lte_2100       LTE 2100 (band 1)
  band_lte_2600       LTE 2600 (band 7)
  band_lte_1700       LTE 1700 (band 4)
  band_lte_700        LTE 700 (band 17)
  band_tdd_lte_2600   TDD LTE 2600 (band 38)
  band_tdd_lte_1900   TDD LTE 1900 (band 39)
  band_tdd_lte_2300   TDD LTE 2300 (band 40)
  band_tdd_lte_2500   TDD LTE 2500 (band 41)
# set cellular sim 1 phone_number 18620435279
OK
...
# config save_and_apply
OK // save and apply current configuration, make you configuration effect

```

5.3 Commands Reference

commands	syntax	description
Debug	Debug <i>parameters</i>	Turn on or turn off debug function
Show	Show <i>parameters</i>	Show current configuration of each function , if we need to see all please using “show running ”
Set	Set <i>parameters</i>	All the function parameters are set by commands set and add, the difference is that set is for the single parameter and add is for the list parameter
Add	Add <i>parameters</i>	

Note: Download the config.XML file from the configured web browser. The command format can refer to the config.XML file format.

Glossary

Abbreviations	Description
AC	Alternating Current
APN	Access Point Name of GPRS Service Provider Network
ASCII	American Standard Code for Information Interchange
CE	Conformité Européene (European Conformity)
CHAP	Challenge Handshake Authentication Protocol
CLI	Command Line Interface for batch scripting
CSD	Circuit Switched Data
CTS	Clear to Send
dB	Decibel
dBi	Decibel Relative to an Isotropic radiator
DC	Direct Current
DCD	Data Carrier Detect
DCE	Data Communication Equipment (typically modems)
DCS 1800	Digital Cellular System, also referred to as PCN
DI	Digital Input
DO	Digital Output
DSR	Data Set Ready
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi-frequency
DTR	Data Terminal Ready
EMC	Electromagnetic Compatibility
EMI	Electro-Magnetic Interference
ESD	Electrostatic Discharges
ETSI	European Telecommunications Standards Institute
EVDO	Evolution-Data Optimized
FDD LTE	Frequency Division Duplexing Long Term Evolution
GND	Ground
GPRS	General Packet Radio Service
GRE	generic route encapsulation
ID	identification data
IMEI	International Mobile Equipment Identification
IP	Internet Protocol
IPSec	Internet Protocol Security
kbps	kbits per second
L2TP	Layer 2 Tunneling Protocol
LAN	local area network

LED	Light Emitting Diode
M2M	Machine to Machine
MAX	Maximum
Min	Minimum
MO	Mobile Originated
MS	Mobile Station
MT	Mobile Terminated
OpenVPN	Open Virtual Private Network
PAP	Password Authentication Protocol
PC	Personal Computer
PCN	Personal Communications Network, also referred to as DCS 1800
PDU	Protocol Data Unit
PIN	Personal Identity Number
PLCs	Program Logic Control System
PPP	Point-to-point Protocol
PPTP	Point to Point Tunneling Protocol
PSU	Power Supply Unit
PUK	Personal Unblocking Key
R&TTE	Radio and Telecommunication Terminal Equipment
RF	Radio Frequency
RTC	Real Time Clock
RTS	Request to Send
RTU	Remote Terminal Unit
Rx	Receive Direction
SDK	Software Development Kit
SIM	subscriber identification module
SMS	Short Message Service
SNMP	Simple Network Management Protocol
TCP/IP	Transmission Control Protocol / Internet Protocol
TE	Terminal Equipment, also referred to as DTE
Tx	Transmit Direction
UART	Universal Asynchronous Receiver-transmitter
UMTS	Universal Mobile Telecommunications System
USB	Universal Serial Bus
USSD	Unstructured Supplementary Service Data
VDC	Volts Direct current
VLAN	Virtual Local Area Network
VPN	Virtual Private Network
VSWR	Voltage Stationary Wave Ratio
WAN	Wide Area Network

