

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

CHARGING THE EARBUDS

- ⚡ Charge the earbuds before using them for the first time.

- ⌚ Plug in the cable to the micro USB port and charge for at least 1 hours.

Connect the charging cable to charging port.



PAIRING YOUR EARBUDS


Your earbuds will work best if they are within 33 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

PAIRING YOUR EARBUDS (continued)

Make sure the earbuds are turned off before attempting to pair it with a smart phone or tablet.



Press and hold the "Multifunction" button for 5 seconds to turn on the earbuds. You will see the light flash red and blue. This indicates that your earbuds are ready to pair.



From your smart phone or tablet, find a list of nearby devices and choose "FB-LEDWRP". Enter "0000" if asked. The earbuds will flash a blue light when pairing is complete!

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

CONNECTION LOST?

- If pairing the earbuds does not work, turn off the earbuds and repeat the steps again in "Pairing your Earbuds."
- Make sure your earbuds are within range of your smart device.
- If you hear a long beep, you need to recharge your earbuds. Connection may be lost due to low battery.
- When charging your earbuds, only use the enclosed USB cable.

MEDIA KEY FUNCTIONS



- Press & Hold - Decrease Volume Press Once - Previous Track
- ⏻ Press Once - Play/Pause music / Answer/End Call Press Twice - Redial
- Press 3x - Turn LED Light on/off Press and Hold - Turn Device on/off and Reject Call
- + Press & Hold - Increase Volume Press Once - Next Track

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

SPECIFICATIONS

Bluetooth Version:	V 5.0
Wireless Distance:	Up to 33ft (10m)
Play Time:	Up to 2 hours
Talk Time:	Up to 2 Hours
Standby Time:	Up to 6 hours
Battery Capacity:	3.7V 55mAh
Charging Time:	Up to 1 Hour
BT ID:	D046366
FCC ID:	2AANZLEDWRP

WARNING

Keep away from water and moisture.
Keep away from heat sources.
Do not disassemble.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and

live love music™ QUICK START GUIDE

GLOW WIRELESS LED EARBUDS

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.