

Instructions

TRUE WIRELESS EARBUDS




Specifications

Bluetooth Range: Up to 33 feet (10 meters)
Charging Input: DC 5V 1A max
Play Time: Approximately 21 hours*

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.


A Quick Look




Charging



1. Insert the included charging cable's USB-C end into the port on the case.




2. Insert the charging cable's standard USB end into the USB port of a computer or suitable USB charging adapter.




3. The LED Indicator will flash red when the case is charging and turn solid red when the case is fully charged.

Bluetooth Pairing


*Your earbuds will automatically turn on when taken out of the charging case.




1. If the earbuds are already out of the case, press and hold both earbuds' Multi-function button for 3 seconds to turn the earbuds On.



Pairing Mode Flashing LED



3. Go to the Settings app and into the Bluetooth page. Make sure Bluetooth is on before connecting to "TWS Earbuds".



Paired Mode Flashing LED

4. Both earbuds' LED Indicator will slowly flash blue when paired to your phone.

Using Your Earbuds



1. Press either earbud's Multi-function button to pause and play music.



2. Press and hold the left earbud's Multi-function button for 1.5 seconds to go back to the previous song.



3. Press and hold the right earbud's Multi-function button for 1.5 seconds to go to the next song.



JUST ASK

4. Press the either earbud's Multi-function button three times to activate Siri or Google Assistant.

Important Safety Precautions

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARBU DS.
2. Do not use your earbuds near water. Do not place your earbuds on a wet surface.
3. Do not allow children to use the earbuds without proper adult supervision.
4. Do not expose your earbuds to excessive heat or fire.
5. Do not use in extremely dry environments, as this can lead to static discharge during usage.
6. Do not expose your earbuds to temperatures above 100 °F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if your earbuds are in need of service.
8. Do not drop, puncture or expose your earbuds to excessive trauma.
9. Your earbuds are not intended for commercial use.
10. Do not place the earbuds near objects that generate a strong magnetic field.
11. Use only the supplied charging cable. Unplug this cable when not in use for long periods of time and during lightning storms.
12. Use a soft cloth to clean your earbuds. Never use any abrasive chemicals.
13. Please recycle or dispose of your earbuds properly based on the laws and rules of your municipality. Contact local recycling facilities and the manufacturer of your earbuds for further information.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but not limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 in the U.S. & 0-800-917-4831 in the UK or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period (6), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned un-repaired.

Call Controls



1. Press either earbud's Multi-function button to answer and end an incoming call.



2. Press either earbud's Multi-function button twice to redial the last phone number called.



3. Press and hold either earbud's Multi-function button for 1.5 seconds to reject an incoming call.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.