

Contents

1 Products




Front panel




Back panel

2 Template Sticker




Door Handle & Mortise Lock Sticker



Strike Sticker


3 Accessories

(1) Mortise




1. Mortise
2. Mortise Plate (mounted)
3. Spindle of Knob
4. Spindle of Handle x2
11. Screw x2

(2) Cylinder




5. Cylinder Lock
6. Mechanical Key x2

(3) Handle




7. Waterproof Strap x2
8. Handle Screw x2
9. Elastic Spring x2
10. Allen Wrench

(4) Strike



11. Screw x2
12. Strike Box
13. Strike Plate

Installation



Cable : CN1

Wire Application	Cable	Color	Description
RS485	1	Thick Green	RS-485(B-)
	2	Thick Blue	RS-485(A+)
Power	3	Thick Black	Power DC0V
	4	Thick Red	Power DC12V


Cable : CN2

Connector of Reader

Cable : CN3

Connector of Mortise

Wiring




Door Handle Direction

Before installation please check which door hand you require.


RH (Right Push)



LH (Left Push)




RHR (Right Pull)




LHR (Left Pull)





- | | | | | | | |
|----------------------|---------------------|----------------------------|---------------------|-------------------|------------------|-------|
| Ⓐ Handle hole | Ⓔ Handle screw hole | 1. Mortise | 5. Cylinder Lock | 9. Elastic Spring | 13. Strike Plate | ⓧ CN1 |
| Ⓑ Deadbolt knob hole | Ⓕ Mortise hole | 2. Mortise Plate (mounted) | 6. Mechanical Key | 10. Allen Wrench | 14. Front Panel | Ⓨ CN2 |
| Ⓒ Cylinder hole | Ⓖ Strike hole | 3. Spindle of Knob | 7. Waterproof Strap | 11. Screw | 15. Back Panel | Ⓩ CN3 |
| Ⓓ Cable hole | | 4. Spindle of Handle | 8. Handle Screw | 12. Strike Box | | |




1. Paste hole-sticker on the door properly and make cuts depending on hole-stickers dimension.

2. Take away mortise plate, embed mortise into door frame and fix it with screws properly.

- (1) Only make "deadbolt knob hole" from inner door to mortise, don't cross to outer door.
- (2) Make sure accurate position & right hole direction of striker plate; before making cuts, latch bolt position can be made firstly.
- (3) Networking mode: Additional hinge cuts is required for PC connection.

- (1) Check the correct direction of mortise with latch download before fixed.
- (2) Prepare in advance connector of reader
- (3) Wire the power and communication cable to the hole of the door




4. Install cylinder into mortise, use the screw to fix cylinder properly

5. Installation Mortise plate


- (1) The depth of cylinder is not too deep or too shallow, we suggest to check inserted depth by the side of mortise, make sure that the position of lock picks must be over first screw and between screw and screw holes to ensure cylinder operate normally.

- (1) Make sure the key lock hole on the topside, and fixed tightly.
- (2) Please confirm the key can control 2 bolt.


4. 5 short beeps after 5sec: cards cleared
 ※ It is normal for the key lock hole to slightly have recessed arc
 P.S. Once MASTER CARD is presented after one warning beep, all card data will be cleared.



7. Insert the spindle of handle separately into the handle hole of mortise.



8. Connect connector of reader to the front panel and the mortise lock.




9. The spindle of handle insert deadbolt knob hole, front and back panel clamped and fixed on the door with inner hexagon screw properly.

- (1) Please read "warning sticker" before install the rotated type of mortise, follow arrow direction to insert spindle of handle.
- (2) Spindle of handle are divided into longest and short edge, insert short edge to square hole at the both sides of mortise.


- (1) Connect the front panel connector to mortise.
- (2) Plug in the connector of reader to the front panel

- (1) The spindle of knob insert to deadbolt knob hole of back panel firstly, then insert to deadbolt knob hole of mortise; finally the spindle of handle insert handle hole of mortise.
- (2) Please insert the connector cable from the interior (CN2) into the hole that connected to interior door lock.
- (3) Connect the power and communication cable (CN1) to DC power and RS485 communication. (Refer to the cable description)




10. Use tools "Plastic PICK" to guide rubber pad to fit with front and back panel and then fixed them together with the screws.

- (1) Before fix front and back panel with the screw, make sure to fit metal base and rubber pad on the door.




11. Installation front and back panel.

- (1) Stand-alone: Install battery before the upper cover of back panel.
- (2) Install the lower cover of back panel as above picture shown.
- (3) Install the lower cover of front panel.



12. Paste hole-sticker on the doorframe properly and make cuts depending on hole-stickers dimension.



13. Installation Strike and Strike box

- (1) Make sure position and right hole direction for Strike box.

Adding and Deleting Tag

M4/M8

• Add a Single Tag or Random tags

Input *123456# (or Master Code) → 19 *UUUUU*00001# → Present the tag(s) to Access Controller (single tag or random tags one by one) → Done
 [e.g.] Add 2 random cards to User Addresses No. 100 and No. 101:

Enter program mode → 19 *00100*00001# → Present the tags one by one → Done

• Add a batch of Sequential tags

Input *123456# (or Master Code) → 19 *UUUUU*QQQQQ# → Present the tag (only use the tag with the lowest number) → OK

[e.g.] Add 20 pcs sequential tags (62312~62331) to User Address NO.101 ~ NO.120:

Enter program mode → 19 *00101*00120# → Close Tag into RF Area (only use the tag NO.62312) → OK

• Delete Single Tag

Input *123456# (or Master Code) → 10 *SSSSS9)EEEE#

[e.g.] Delete User Address: 00058

Enter program mode → 10 *000589)00058#

• Delete a batch of Tags

Input *123456# (or Master Code) → 10 *SSSSS9)EEEE#

[e.g.] Delete User Address: 00101~00245

Enter program mode → 10 *001019)00245#

• Delete All Tags

Input *123456# (or Master Code) → 29 *29*#

Tag Information (125kHz) ※ For Mifare tags, the separator between Site Code & Card Code is comma **,



M6 ※In this mode, User Address = Card Code

※In this mode, Card and PIN, If you want to modify refer to password setting 17 *

• Add Tags

Input *123456# (or Master Code) → 11 *SSSSS*EEEE# → OK

[e.g.] Add User Address: 00100~01254

Enter program mode → 11 *00100*01254# → OK

• Add tag by presenting: Input *123456# (or Master Code) → 22 *1# → Present the tag to Access Controller → OK

• Delete tag by presenting: Input *123456# (or Master Code) → 22 *0# → Present the tag to Access Controller → OK

• Delete All Tags: Input *123456# (or Master Code) → 29 *29*#

• Delete Tags

Input *123456# (or Master Code) → 10 *SSSSS*(or 9)EEEE# → OK

[e.g.] Delete a tag with card code 62362

Enter program mode → 10 *62362*62362# → OK

Operation process

A. Enter / Exit Program Mode

• Enter the program mode

Input *123456# or *PPPPPP#

[e.g.] The Default Value= 123456, if the Master Code is already changed= 876112, input *876112# → program mode entered

• Exit the program mode

Input *#

• Master Code modification

Enter program mode → 09 *PPPPPPRRRRR# [Input the 6-digit new master code twice.]

[e.g.] Set the Master code to be 876112, input *123456# → 09 *876112876112#

B. Change the Node ID of Controller

Enter program mode *00# NNN

[Node ID: 001~254; if the access controller is connected to AR-716E, its Node ID will be 001~016.]

C. Set up M4/M6/M8

Enter program mode → 04 *N# [N=4/6/8]

D. Set up the password

• **M4/M8: Private PIN**

Card or PIN: Enter program mode → 12 * UUUUU * PPPP # [e.g. User Address: 00001 and pass code: 1234, input 12 * 00001 * 1234 #]

Card and PIN: Enter program mode → 13 * UUUUU * PPPP # [e.g. User Address: 00001 and pass code: 1234, input 13 * 00001 * 1234 #]

• **M6: Public PIN**

Card or PIN: Enter program mode → 15 * PPPP # [Input 4-digit PIN, default value: 4321; PPPP=0000: cancel the function of simply inputting PIN to get access]

Card and PIN: Enter program mode → 17 * PPPP # [Input 4-digit PIN, default value: 1234; PPPP=0000: access mode will be "Card Only"]

E. Double Door Control (M4/M8)

Controller with a reader to perform the "Double Door Control".

Enter program mode → 28 * 064 # [064= Double Door Control]

F. Anti-pass-back (M4/M8)

Usually, anti-pass-back is commonly applied to parking areas in order to prevent from multi-entry with one card at a time, or to locations that need entry and exit control.

• **Enable controller**

Enter program mode → 20 * DDD # [128= Anti-pass-back(0=Disable; 1=Enable)/ 064=Entrance/Exit(0=Exit; 1=Entrance).]

[e.g.] Enable Anti-pass-back, and set to Exit door= (128 x 1) + (064 x 0) = 128

Enter program mode → 20 * 128 # (Please refer to function default value for details.)

• **Enable card**

Enter program mode → 26 * SSSSS * EEEEE * N #

[SSSSS= Starting User Address; EEEEE= Ending User Address; N=0(control)/ 1(Not control)/ 2(reset)]

[e.g.] Enable the anti-pass-back function of User Address from 00152 to 00684: 26 * 00152 * 00684 * 0 #

[e.g.] The anti-pass-back function of User Address 00154 has been enabled. After presenting the card to get in, the user doesn't present the card to leave. When s/he tries to present the card to get in again, since the in-in sequence violates the anti-pass-back rule, s/he will be rejected. To solve this problem, you can reset it as follows. Enter program mode → 26 * 00154 * 00154 * 2 # → Reset

G. Auto-Open Time Zone

Door will remain open after the first flashing card. There are 2 time zones supported when Standalone, and 63 time zones when connected to AR-716E.

• **Enable/Disable auto-open time zone**

Enter program mode → 20 * 004 # [004= enable Auto-Open Time Zone; 000= disable Auto-Open Time Zone]

• **Enable/Disable auto open door without presenting card**

Enter program mode → 24 * 001 # [001= enable Auto-Open Time Zone; 000= disable Auto-Open Time Zone]

• **Set up auto-open time zone**

Enter program mode → 08 * N * HHMMhhmm * 7123456H #

N: 2 sets of auto-open zone (N=0=1st set; N=1=2nd set)

HHMMhhmm=Staring time to ending time (e.g. 08301200=08:30 to 12:00)

7123456H= 7 days of a week (Sun/Mon/Tue/Wed/Thu/Fri/Sat) + Holiday (H= 0: disable; 1: enable); Holidays can be set via 701Client software.

[e.g.] To set the second time zone as 9:30 AM to 4:20 PM, Monday, Wednesday and Friday: 08 * 1 * 09301620 * 01010100 # → Done

H. Lift control

Connect with AR-401-RO16 to control access floors of users.

• **Enable**

Enter program mode → 24 * 002 # [002= enable lift control]

• **Single floor**

Enter program mode → 27 * UUUUU * FF #

UUUU=User Address FF=Floor number (01~32 floor)

[e.g.] User Address NO. 45, allowed to access the 24th floor: 27 * 00045 * 24 #

• **Multi floors**

Enter program mode → 21 * UUUUU * S * FFFFFFFF #

[UUUU=User Address S: 4 sets of lift control (Input: 0~3) FFFFFFFF: 8 floors setting (F=0: Disable, F=1: Enable)

[e.g.] User Address NO. 168, only to the 6th and the 20th floor:

Enter program mode → 21 * 00168 * 0 * 00100000 # → 21 * 00168 * 2 * 00001000 #

Please refer to below floor chart

Set	Floor/ Stop							
	F	F	F	F	F	F	F	F
0	8	7	6	5	4	3	2	1
1	16	15	14	13	12	11	10	9
2	24	23	22	21	20	19	18	17
3	32	31	30	29	28	27	26	25

I. Setting Up the Arming

• **Alarm conditions:**

1. Arming is enabled
2. Alarm system connected

• **Application:**

1. **Door open too long:** Door is open longer than door relay time plus door close time.
2. **Force open** (Opened without a valid user card): Access by force or illegal procedure.
3. **Door position abnormal:** Arming is enabled and the power is suddenly off then on.

• **Enable/Disable Arming status (for M4/M8; default value of arming PWD is: 1234) :**

Standby Mode	
After door open	Do not open the door
The normal procedure to open door → Input 4-digit arming PWD #	* → Input 4-digit arming PWD → Present a valid card
Enter Program Mode	
Enable: Enter program mode → * * #	Disable: Enter program mode → * #

※ [The normal procedure to open door] can refer to [Access Mode].

Function Default Value

20 * DDD #				※Default Value
Function	Selection		Value	Application
Time Attendance	※0: Yes	1: No	001	Networking
Auto Relock	※0: Disable	1: Enable	002	Networking/Standalone
Auto Open	※0: Disable	1: Enable	004	Networking/Standalone
Exit by RTE Button	0: Disable	※1: Enable	016	Networking/Standalone
Master Controller of Network	※0: Slave	1: Mater	032	Networking
Entrance/Exit	※0: Exit	1: Entrance	064	Networking
Anti-pass-back	※0: Disable	1: Enable	128	Networking

28 * DDD #				※Default Value
Function	Selection		Value	Application
Double Door Control	※0: Disable	1: Enable	064	Networking/Standalone
Force Open Alarm Output	0: Disable	※1: Enable	128	Networking/Standalone

24 * DDD #				※Default Value
Function	Selection		Value	Application
Auto Open without Presenting in Auto-open Time Zone	※0: Disable	1: Enable	001	Networking/Standalone
Alarm Output/ Lift Control	※0: Alarm Output	1: Lift Control	002	Networking/Standalone
Stop Alarm by pressing RTE Button or Closing the Door	0: None	※ 1: Yes	064	Networking/Standalone
Doorbell	※0: Disable	1: Enable	128	Networking/Standalone

Select the desired function, Weighted Value = Selection Index (0 or 1) x Value.

[e.g.] DDD (total weighted value of all functions): Enable "Auto Open" + "Exit by RTE Button" + "Anti-pass-back" = 1*004 + 1*016 + 1*128=148; As a result of that, the command will be 20 * 148 #.

M4 / M6 / M8

Mode	Networking/ Standalone	User Capacity	Access Mode	Auto-show Duty time	Event log Capacity	120 Holidays	Duress Function	Time Zone	Lift Control	Anti-pass-back
M4	Networking/ Standalone	3,000	1. Card only 2. Card and PIN (4-digit PIN) + # 3. User Address (5-digit) + PIN (4-digit Private PIN) + #	Yes	1,500	Yes	Yes	11	32	Yes
M6	Standalone	65,535	1. Card only (using 17* command to set Arming PWD as 0000) 2. Card and PIN (4-digit public PIN= Arming PWD) + # 3. Card or PIN (4-digit public PIN= Duress code)	No	No	No	No	No	No	No
M8	Networking/ Standalone	3,000	1. Card only 2. Card and PIN (4-digit Private PIN) + # 3. Card or PIN (4-digit Private PIN)	Yes	1,500	Yes	Yes	11	32	Yes

※ **M6:** the user capacity can be 65535 because it only reads 5-digits **CARD CODE**, while in **M4/M8** it reads both **SITE CODE** and **CARD CODE**(10 digits).

Factory Reset by its commands

• **When the device is Standalone (not networking)**

Enter program mode → 20 * 016 # → 24 * 064 # → 26 * 00000 * 01023 * 1 # → 28 * 000 # → 29 * 29 * #

※Note: if the Master Code has been changed, factory reset won't restore the Master Code to 123456.


Command List

Function	Command	Description	Mode
Enter program mode	* P P P P P #	PPPPPP=Master Code, default value=123456	M4/M6/M8
Exit program mode	* #		M4/M6/M8
Exit program mode and enter arming mode	* * #		M4/M8
Node ID setting (Connected to 716E)	00 * N N N #	NNN=Node ID of Access Controller (range: 001~016)	M4/M8
Node ID setting (Connected to the PC directly without 716E)	00 * N N N * V V V * n n n #	NNN=Node ID of Access Controller (range: 001~254) VVV=Virtual 716E Node ID, nnn=Door number (range:001~254)	M4/M8
Mifare tag / card format (Optional)	01 * N #	N: 0=ISO14443A; 1=ISO14443B; 2=ISO15693; 3=I Code1; 4=I Code2 PS.1. Please select the transmission standard first. 2. Ensure both reader and card using the same transmission standard.	M4/M8
Door Relay Time setting	02 * T T T #	TTT=Door relay time 000= Output continuously 001~600=1~600 sec. 601~609=0.1~0.9 sec.	M4/M6/M8
Alarm Relay Time setting	03 * T T T #	TTT=Alarm relay time 000= Output continuously 001~600=1~600 sec.	M4/M6/M8
Control mode setting	04 * N #	N=4: M4; N=6: M6; N=8: M8	M4/M6/M8
Arming Delay Time setting	05 * T T T #	TTT=the buffer time before entering arming mode 001~600=1~600 sec.	M4/M6/M8
Alarm Delay Time setting	06 * T T T #	TTT=the buffer time before the alarm is activated 001~600=1~600 sec.	M4/M6/M8
Master card (Administrator) setting	07 * S S S S * E E E E #	SSSSS-EEEE=00000-01023 (00000-03000 for AR-725H); SSSSS=Starting User Address; EEEEE=Ending User Address	M4/M8
Auto-open time zone setting	08 * N * H H M M h h m m * 7 1 2 3 4 5 6 H #	N= 0 (1st time zone) / 1 (2nd time zone) HHMM= Starting time; hhmm= ending time (i.e.: 08301600=08:30 to 16:00) 7123456H= 7 days of week (Sun/Mon/Tue/Wed/Thu/Fri/Sat)+ Holiday (H= 0: disable; 1: enable); Holidays can be set by 701Client software.	M4/M6/M8
Master code setting	09 * P P P P P R R R R R R #	PPPPPP=6-digit new master code RRRRRR=Reconfirm the new master code	M4/M6/M8
Suspend / Delete tag	10 * S S S S * E E E E # (M6)	* =Suspend 9 =Delete;	M4/M6/M8
	10 * S S S S 9 E E E E # (M4/M8)	SSSSS=Starting User Address, EEEEE=Ending User Address	
Add a batch of sequential cards by inputting card number (M6)	11 * S S S S * E E E E #	SSSSS=Starting card number EEEE=Ending card number	M6
Recover the suspended cards	11 * S S S S * E E E E #	SSSSS=Starting User Address EEEE=Ending User Address	M4/M8
Set the access mode of the user at the designated User Address as "Card or PIN"	12 * U U U U * P P P P #	Access mode: Card or PIN ; UUUUU=User Address; PPPP=4-digit private PIN (0001~9999); 0000=Card Only for this user	M4/M8
Set the access mode of the user at the designated User Address as "Card & PIN"	13 * U U U U * P P P P #	Access mode: Card & PIN ; UUUUU=User Address; PPPP=4-digit private PIN (0000~9999)	M4/M8
Arming Pulse Time setting	14 * T T T #	TTT=Arming output time; 000=output continuously 001~250=0.1~2.5 sec.	M4/M8
M4/M8:Duress code setting M6:Public PIN setting for access mode "Card or PIN"	15 * P P P P #	PPPP=4-digit duress code (0001~9999; default value=4321; 0000=disable the function of simply inputting PIN to get access in M6)	M4/M6/M8
Card number modification	16 * U U U U * S S S S C C C C #	UUUUU= User Address; SSSSS=5-digit site code; CCCC=5-digit card code	M4/M8
M4/M8:Arming PWD setting M6:Public PIN setting for access mode "Card & PIN"	17 * P P P P #	PPPP=4-digit Arming PWD (0001~9999; default value=1234; 0000= access mode will become "Card Only" in M6)	M4/M6/M8
Door Close Time	18 * T T T #	TTT=Door Close Time: 001~600=1~600 sec.; default value: 15 sec.	M4/M6/M8
Add card by presenting(M4/M8)	19 * U U U U * Q Q Q Q #	UUUUU=User Address; QQQQ=Card quantity (0001: for adding a single card or a batch of random numbering cards)	M4/M8
Reader additional setting	20 * D D D #	Please refer to function default value for details.	M4/M6/M8
Lift control setting: multi-floor	21 * U U U U * S * F F F F F F F #	UUUUU=User Address, S=4 sets of lift control (0~3); FFFFFFFF=8 assigned floor (F=0: Disable, 1: Enable)	M4/M8
Add/Delete tag by presenting (M6 only)	22 * N #	N=0(Delete tag); N=1(Add tag)	M6
AR-401RO16 Lift Relay Activated TM	23 * N N N * T T T #	NNN=site number, TTT= relay time: 000~600=1~600 sec.	M4/M8
Controller parameter setting	24 * D D D #	Please refer to function default value for details.	M4/M6/M8
Controller time clock setting	25 * Y Y M M D D H H m m s s #	YYMMDDHHmmss: Year/ Month/ Day/ Hour/ Min./ Sec.	M4/M6/M8
Anti-pass-back (Enable user)	26 * S S S S * E E E E * N #	SSSSS=Starting User Address; EEEEE=Ending User Address; N=0: Enable; N=1: Disable; N=2: Reset	M4/M8
Lift control setting: single floor	27 * U U U U * F F #	UUUUU=User Address; FF=Floor (01~32 floor)	M4/M8
Double Door Control / Force Open Alarm	28 * D D D #	Please refer to function default value for details.	M4/M6/M8
Delete all tags	29 * 2 9 * #		M4/M6/M8

Function	Command	Description	Mode
Enable the security trigger signal (with AR-721RB)	34 * DDD #	Change the "Arming" (in 25) to the security trigger signal, when controller is connected with AR-721RB. Please refer to function default value for details.	M4/M6/M8

34 * DDD #		※Default Value		
Function	Selection	Value	Application	
Enable the RF after door sensor closed to GND	※0: Deactivate 1: Activate	001	Networking/Standalone	
Invalid card to activate alarm relay	※0: Deactivate 1: Activate	002	Networking/Standalone	
Turn off all sounds of beeper	※0: Deactivate 1: Activate	003	Networking/Standalone	
Mute the sounds of egress button (RTE)	※0: Deactivate 1: Activate	004	Networking/Standalone	
Reserved	※0: Deactivate 1: Activate	016	Networking/Standalone	
Keep beeing while arming is enabled	※0: Deactivate 1: Activate	032	Networking/Standalone	
Door relay connected to AR-721RB (suited to models without relay built-in)	※0: Deactivate 1: Activate	064	Networking/Standalone	
Arm relay connected to AR-721RB (suited to models with relay built-in)	※0: Deactivate 1: Activate	128	Networking/Standalone	

MASTER CARD Setting



- Use the MASTER CARD software



323DMaster

Test


Present the card, and the reader will flash green light 3 times and sound 3 beeps. Then the card becomes MASTER CARD and accesses programming mode. If MASTER CARD is presented again, it will exit programming mode.

- Input the MASTER CARD number, and press [Write].


- Cut off and transmit the power. Activate master the card number.

About Master Card / Master Card

Adding Tag



Deleting All Tags



FCC ID:2ACLEAR-323D

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement.

The device can be used in portable exposure condition without restriction

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.