

Installation instructions

IoT gateway indoor

1. General information

1.1. Intended use

Operational safety is only guaranteed if the product is used as intended by the manufacturer. No liability is assumed for damage caused by other applications. Any modifications are only permitted with approval from the manufacturer. Otherwise the manufacturer's declaration is invalidated.

1.2. Safety instructions

If it is necessary to establish a new power connection, the installation and commissioning must only be performed by trained qualified specialists. Only trained qualified electricians may work on electrical systems. They must be able to assess the work assigned to them at all times, detect any potential sources of danger and adopt appropriate safety measures. The installation work must only be performed in a de-energised state. Valid specifications and standards are to be observed.

2. Product description

2.1. Intended use

The ZENNER IoT Gateways use high-performance LoRaWAN® technology, whose excellent building penetration and long-range network coverage generally ensure the connectivity of IoT sensors even under challenging environmental and installation conditions. The Indoor Gateway is ideally suited for LoRa network coverage within a building to receive the values of sensors, some of which are difficult to access, on several floors and in basements - without the need for additional repeaters. The device can be used across various sectors for a variety of IoT applications and is an integral part of ZENNER IoT system solutions.

2.2. Scope of delivery

- ZENNER IoT Indoor Gateway incl. integrated SIM
- Mounting hardware (screws & dowels)
- Installation and operating instructions
- Declaration of conformity

3. Installation location

In order to gain optimum LoRaWAN network coverage, an installation location which is as high as possible is recommended due to various technological advantages. For example, if an attic is available with potential installation space, this installation location should be preferred.


Note: In stairwells and hallways, the current building regulations should be checked. It is not permitted to install the product in the service room of the lift.

After selecting the preferred installation location, you should test the mobile radio connection in this location prior to attaching it.

4. Installation

- 4.1. Check whether cables are routed to the selected installation point.
- 4.2. Note the length of the power cable (range for socket / junction box).
- 4.3. Mark drilling holes on the wall according to the hole spacing and use a spirit level (drilling template attached) (ill. 1).
- 4.4. Drill drilling holes, fit dowels and screws in the holes (included in scope of delivery).
- 4.5. Attach wall mounting bracket to the wall. Ensure that the correct side of the wall mounting bracket faces upwards. Pay attention to the following illustration (ill. 1).

Tip: In the case of uneven walls, use washers.



ill. 1

- 4.6. Snap the gateway into the wall mounting bracket. The electrical connection is then established.



ill. 2

5. Electrical connection

Gateway with plug-in power supply

This variant is operated with a plug-in power supply. The electrical connection can be established by a laymen. Commissioning is performed by inserting the power supply unit.



Gateway with plug-in power supply

ill. 3

6. Commissioning

The gateway starts immediately after insertion / connection.

The gateway passes through several phases during the boot process, which are indicated by the LEDs. Please observe the following sequence of the four LEDs. LED No. 4 signals the connection to the backend.

Phase	Stage	1	2	3	4
Boot process	1.	Off	Off	Off	Off
	2.	Red	Red	Off	Off
	3.	Green	Off	Red	Red
	4.	Green	Off	Red	Red
	5.	Green	Off	Off	Red
reserved	6.1	Green	Off	Off	Green
		Green	Green / Orange	Red	Green
Ready for operation - network connection	6.2	Green	Green / Orange	Red	Green
Ready for operation - network connection	6.3	Green	Green / Orange	Off	Green
reserved	A.	Flashes red / green	Off	Off	Green
Update via network	6.4	Flashes red / green	Green / Orange	Red	Green
reserved	6.5	Flashes red / green	Off	Red	Red

Explanation of the stages:

1. No power supply
2. Hardware initialisation
3. Hardware initialisation
4. Mobile radio connection not active, no connection to LoRa network server (LNS)
5. Mobile radio connection active, no connection to LNS
6. Normal operation (6.2, 6.3)

ill. 4

7. Technical data and performance characteristics

- Suitable for LoRaWAN® IoT solutions from ZENNER
- Plug & Play - Simple integration into the ZENNER system landscape through pre-configured software*
- Compatible with the Gateway Management System (GMS) from ZENNER (remote configuration)*
- Security patches and software updates are distributed in an automated manner*


Technical data

Mobile radio	N/A
LAN	RJ45
# LoRa channel	8 channels internal antenna
TX power	max. 27 dBm (500 mW) conducted
Frequency	US-902
Power supply	External power supply unit (230 V)
Antennas	Internal LoRa antenna
Protection class	IP40
Housing	Plastic with flame retardancy according to UL94-2013 edition 9-2019, class.: V-0
Operating temperature	0°C to +50°C
Storage temperature	-40°C to +80°C
LED	Power, LAN, reserved, backend connection
Installation	Wall (bracket incl. screws and dowels included in scope of delivery)
Maintenance	Remote firmware upgrades

Dimensions and weights:

Gateway with plug-in power supply:

Length	mm	184
Width	mm	127
Height	mm	48
Weight approx.	kg	0.474




Dimensions of gateway with plug-in power supply

* ZENNER IoT Gateways (Indoor and Outdoor) are only compatible as standard with the ZENNER system landscape or ZENNER LoRa network server (LNS) by means of Plug'n'Play. The gateways are automatically detected in the backend and can subsequently be monitored and configured by the integrated Gateway Management System (GMS). Software updates and security patches are also distributed in an automated manner. Network operation is performed by Minol ZENNER Connect GmbH.

8. Dismantling

- 8.1. Use a narrow flat head screwdriver to gently lift the far right lug on the assembly plate (wall mounting bracket).
- 8.2. Carefully pull the gateway downwards with an appropriate level of strength.
- 8.3. Remove the assembly plate from the wall and replace the gateway for a new one, if required.



ill. 5

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/CANADA

Industry Canada statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference*
- (2) This device must accept any interference, including interference that may cause undesired operation of the device*

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;*
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.