

Contents

1.	APPEARANCE AND KEYPAD OPERATIONS.....	1
2.	USING MEMORY CARD AS U DISK.....	2
3.	WIFI.....	3
5.	MAIL.....	6
7.	MESSAGING	9
8.	CONTACTS	11
10.	RECORDER	14
11.	CLOCK	14
12.	CACULATOR	15
13.	CAMERA	15
14.	IMAGES	17
15.	MUSIC	19
16.	CALENDER	21
17.	FM RADIO	22
18.	SETTINGS	23
19.	NOTICES FOR THE USE OF PHONE.....	31

1. Appearance and Keypad Operations

Keys	Functions
home	Press this button to return home from any application or interface.
	Press it to open recently opened application window.
menu	Press it to start the menu, which allows you to perform actions in the current interface or options' menu.
back	Press it to return to the previous interface, or to close dialog box、options' menu、notification panel or the keypad.
Search	For more information, please read 「searching button」.
power	Press it to open the phone's menu, then you could choose to lock the screen、turn off the phone, or set it to the silent mode.
up	Press it to increase the volume
	Press it to turn the phone to vibration mode from the silent mode.
down	Press it to decrease the volume.
proximity sensor	Cover it, and then the phone's backlight will turn off.
front camera	Entering the camera interface, switched to the front camera can photo yourself.

2. Using Memory Card as U Disk

If you want to send music, pictures or other files to the phone's memory card from the computer, you should set memory card as u disk first.

Set memory card as u disk

- 1) Connect the phone to the computer with USB cable. The notification icon will appear in the status box.
- 2) Open the notification panel.
- 3) In the notification panel, touch USB is connected ,

then touch “Open the USB Storage Device” .

- Notices: If you connect your phone to the computer then choose open the USB device, the phone can't read the memory card. You temporarily can not use some applications, such as camera.
- Uninstall the U Disk from computer

The same as the method of connecting it, see the following picture:

3. Wifi


Wi-Fi provides as far as 300feet (100M) range of wireless network access. If you use cell phone to connect wifi, you should connect to the wireless access point or 「hot spots」 .

- Notices: The availability and coverage of Wi-Fi signal depend on the number, infrastructure and other objects penetrated by the signal.

Open Wi-fi and to connect to the wireless network


- 1) Press home>menu , then touch settings>wifi and internet
- 2) Select the wi-fi box , to open Wi-Fi. Phone will automatically scan for available wireless networks.
- 3) Touch Wi-Fi settings. Then a list of Wi-Fi network will

show the founded network name and security settings. (open network or WEP、WPA/WPA2 with password).If you enable the notification in

Wi-Fi settings, The status box will show this icon () when open available wireless network founded.

- 4) Touch one of the Wi-Fi choices to connect the network. When you choose open network, phone will connect to it automatically. If you choose WEP、

WPA/WPA2 with password, you should type the password first, then touch to connect it.

Notices: when the phone is connected to the wireless network, the status box will show this Wi-Fi icon () and the approximate signal strength (the number of lit bars). If you touch the connected network, it will display the name of the Wi-Fi network, status, speed, signal strength, security, information and IP address. If you want to delete the wireless settings, please touch "not reserve" as in the right picture. If you want to connect to this network, you should re-enter these settings.

- Notices:

Unless you choose not to reserve the network, otherwise, there is no need to re-enter the corresponding password when next time connecting to the previously encrypted wireless network. Wi-Fi will search automatically, that is, the phone needn't to perform additional steps to connect Wi-Fi networks.

- Notices:

Unless you choose not to reserve the network with password, otherwise, there is no need to re-enter the corresponding password when next time connecting to the previously encrypted wireless network. Wi-Fi will search automatically, that is, the phone needn't to perform additional steps to connect Wi-Fi networks.

- Connect to other Wi-Fi networks


- 1) In the interface of wireless and network, touch Wi-Fi settings. The founded Wi-Fi networks will show on the Wi-Fi network list.
- 2) Touch other Wi-Fi networks, and then you can connect to this network.

- Notices: in addition, you can surf the internet

via GPRS. We default that the GPRS in SIM1 is opened after started, users can select manually ,the specific location is “ settings>wireless and internet>data connection”, touch “SIM1、SIN2、no data connection”, when the dot turns green, it's already opened.

4. Bluetooth

Turn on Bluetooth or set the phone can be detected

- 1) Press home>menu, the touch settings.
- 2) Touch wireless and internet, then choose Bluetooth box to open the Bluetooth function. After started, the status box will show this icon (). Touch “scan for devices” the it starts to scan for all devices within range.
- 3) Touch Bluetooth settings, all the devices founded will display in the list under the icon.

(select the box “can be detected”, set it to be detected, the other Bluetooth devices will be able to find the phone.)

important: the maximum detecting time of the phone is 2 minutes.


- Pairing and connection of Bluetooth headset

- 1) Press home>menu, then touch settings.
- 2) Touch wireless and internet>Bluetooth settings, then select Bluetooth box, then your phone will scan for the Bluetooth devices within range ,and show the founded devices in the list under the icon.

- Tips:

- a. If the list can't find your equipment, touch scanning equipment to re-scan it.
- b. Make sure that the devices wanted are under the detected mode.
- 3) Touch headset in the equipment list to finish the connection.

- Notices : generally Bluetooth devices need password to be paired, often

use 「0000」 as the default password.4)The pairing and connecting status will show under the headset in the Bluetooth devices list. When the headset connected to your phone, the status box will show this icon () means connected. Then you can use the headset to make or receive callings..

- Cut the connection to the Bluetooth

- 1) Press home>menu>settings>wireless and internet>Bluetooth settings.
- 2) In the list of Bluetooth equipment, touch or tap and hold the connected hand-free headset.
- 3) Press and select “cancel the pairing”.

- Bluetooth proximity sensor
After pairing the two device,you can test out the signal is strong or weak by the Bluetooth proximity sensor device

5. Mail

5.1 Gmail

- Create an electronic mail account

Select mail> settings. You can activate or edit existing e-mail accounts as well as create a new e-mail account.


- a. Select mail, Google account setting interface appears.
Then touch ‘next step’ > create account>enter name, last name and e-mail account.
 - b. Google servers determine whether the name can be used, if so, new interface appears prompting enter password, then judge the password’ security, users who doesn’t meet the requirements need to re-enter the password.
 - c. Successfully register a new Gmail account, a messenger created automatically for testing.
- Loading mail account

- a. Open Gmail skip introduction screen>loading interface appears >select load
- b. Enter name, password then load
E-mail account initialization ,prompting “login successful”
All Google accounts will be synchronized.

- Creating and sending ,mails

When creating mails, select mail > creating mails. Enter the address(recipient)、theme and contents. Press MENU you could ‘append’、‘Add Cc/Bcc’ , select send or discarded.

- Receive mails

There is tone for new mails, in the status box will show this button  , Press Menu > ‘refresh’ , refresh and update the number of the unread mails in a proper way.

- Delete mails

When loading a mail account, if you want to delete it, you need to restore factory settings . When loading a second one, you could press the menu button to delete it.

Notices: many functions depend on Gmail Account, for example: Electronic Market、Google Talk、Sync Contact and Calendar.

5.2 Email

- Load Email

Enter the correct address and password >settings correct port and POP server, check the server settings automatically.

Set the correct SMTP server, check the mails server’s sending and receiving settings, then enter the specified account name and displayed name on the outing e-mail.> Finish.

- Create and send mails

When creating mails, select mails > create mails. Enter the address(recipient)、theme and contents. Press MENU you

could ‘append’、‘Add Cc/Bcc’ , select send or discarded or save as draft.

6. Dialling

When the icon of internet server appears in the screen, you could dial or receive callings. The signal bar on the top right corner show the strength of network signal (the maximum with 4 signal bars) .

- Start dialing

Open application's main menu>dial. You could choose SIM1 or SIM2 to do the dialing.

- Dialing

At the interface of “dialer”, enter the phone number, and then click the dialing key , after that,you should choose one SIM card or internet call. If needed to call the extension,you could click the “dial pad” in the bottom of the screen to open the interface or press menu key to select “delay 2 seconds”, and then enter the number of the extension.

- Telephone calls in the call log

Every telephone number called and received in “SIM1、SIM2” will reserved in phone’s menu of call log. On the top left of every call record will show “SIM1 or SIM2”

All numbers in the call log can be dialed by clicking the button “dial” on the right side of the screen.

When number list appearing, click it to catch details; press it for long you could dial via “SIM1 or SIM 2”, meanwhile you can edit, delete, save the number or do other operations.

- Receive callings

When calling comes (top left will show from which SIM card) press “Answer” and slide towards right until the middle button, then you can receive callings.

- Proximity sensor

According to the distance between phone and human body, it

will adjust automatically the switch of the backlight.

During the call, close the phone to the ear, the backlight will turn off automatically, which could save batteries and prevent inadvertently touching.

- Refuse to answer the phone
 - a. When standby, calling comes , press “refuse” button and slide towards left side until the middle button, then you could refuse the calling.
 - b. When using,calling comes,click on the “refuse”button to refuse the calling.
- Two-way call/multiparty call(conference call)
- Notices: this function needs that SIM card open multiparty call features.

- 1) Already exist a call in the phone
- 2) Click “Add calls”, dial another call (or receive another call, phone default open “call waiting” (settings–dialing settings–other dialing settings), after both connected, could view the status of calling.
- 3) select “combine call” – you can combine two calls into one way.
- 4) after multiparty call connected , you could separate the calls or hang up one of them via “the small arrow of conference call” .

- Telephone recording

During the call, more>start record, you could record the dialog of the call.

settings>set other functions of the call in the dialing settings, for example: Call Transfer– after all the settings finished and turned on, you could transfer the call to a certain number.

7. Messaging

- Important: the message title of this phone is the phone number, will be reserved in s similar for of dialog, instead of the usual folder structure. Messages with blue background are those

received, and messages with white background are those sent.

- Send SMS to certain phone number

- 1) Press home>messaging, touch “new messages” .

- 2) In the interface of “edit”:

- a. Click “recipient” box to start input method, you can also click “enter” box to start input method, in that way you can enter characters.

- b. Click the button of “send from SiM1 or SIM2” to start sending.

- Send MMS to certain phone number

When creating message, it was defaulted as SMS, it will be turned to MMS when following operations were done. You can send MMS via clicking “send” after editing.

- 1) In the interface of “edit”, Click the button of “Menu”:

- 2) Click “append”, you can spend the following attachments, then it will be turned to MMS automatically.

Notices:

a, If you want send MMS with many pages, you should select “append PPT” in the “append” interface.

b, You can append 10 pictures, with the form of GIF, JPEG.

c, Click “adding themes”, the box of “theme” will appear under the box of “recipient”, meanwhile it is turned to MMS automatically.

- Send messages to multiple numbers

Enter multiple numbers in the box of entering, each number is divided by the comma in English.

- Notices : For now this phone can mass messages to almost 20 numbers, the correct number depends on the characters, you can

only enter 312 characters in the box of “recipient” .

When a message is sent or sent again, a little yellow letter will appear. The number 1 or 2 on the letter refers to SIM1 or SIM2.

When message sending failed, a red triangle with exclamation will appear.

when editing information other functions of Menu button

8. Contacts

- Open the menu of applications>contacts

Default display phone contacts and SIM card contacts, sort contacts by first letter of alphabet.

Click the Search icon to enter the contact search interface Click the "+" to create new contact

1) contacts>Menu>new contact>

Select Save contacts to phone or SIM card ,then into the interface of editing contacts

You can edit the contacts' picture, name, phone number, e-mail, postal address, then touch “finish”.

2) contacts>Menu>searcher

a. Enter numbers or letters,if match with contacts ,they will be displayed in the search results.

b. If there is no search to match the contacts, the interface will be 'no matching contacts'.

3) contact>Menu>delete contacts

a. You can select all, click the delete button to delete all contacts, including the contacts of phone and SIM card

b. You can select one or more individual contact, click Delete, delete all the selected contacts.

4) contacts>Menu>groups

- a. default group
include:VIP,Schoolmate,friends,Family,Co-work
er.
- b. Select Add Groups, edit the new group name, and go to
the contact search interface, you can add the
group contact.

5) contacts>menu>speed dial


- a. Voicemail
- b. No.2-9numbers,click"Tap to add speed dial",select a
contact as a speed dial.After successfully setting
the dialer interface, long press the number keys,
you can dial the contact number.

6) contacts>more

- a. click import/export,In the local phone, SIM card and SD card
three copies of each other to achieve contact information.You
can select "Copy Source" and then select Next, select the
contacts to copy, so shat complete the copy of contacts.
- b. Dispay options,can select the whole or parts contacts in
"Only contacts with phones ","Phone Contacts "or"SIMs
Contacts"
- c. Accounts,can choose the"Backgroup
data"and"Auto-sync".
- d. Share Visible contacts,all of the contacts can be
imported into the SD card,or sharing via
Bluetooth ,Text messageor Gmail.

● Add common contacts to the collection interface.

- 1) Touch contact tab.
- 2) Touch the contact that you want to add to the collection
(contacts reserved on the SIM card can not be added) .

3) In the detailed information of contacts, touch this icon  besides the contact.

4) Press for long the contact in the pop-up menu to add it to the collection.

- The interface of contacts>press Menu button>select search

9. Internet Explorer

Internet explorer

1) In the interface of internet explorer, touch address filed and enter the URL.

2) Use keypad to enter URL. The appropriate web sites will appear on the screen. You can touch it directly go to the page or continue to enter URL.

- Homepage

Select “homepage”, you could load in the set homepage. If you do not set it, you will use the vendor's pre-set sites.

- Functions of menu

1) Menu>Backward

After browsing through multiple pages, will return to the previous page the current page.

2) Menu>Farward

After browsing through multiple pages, will move to a web page after the current page.

3) Menu>Windows

You can view all open windows to the current.

4) Menu>Bookmarks

a. Click the “Bookmarks” to make the current URL as a bookmark saved.

b. Click the bookmark under the bookmarks list, will open the URL.

5) Menu>More

a. Add bookmarks, save the current URL as bookmark.

- b. Find on page,search what you need in current page.
- c. Select text,in the text, click and drag to select a piece of text.
- d. Page info,display page address and other information of the current browsing.
- e. Share page,select the Bluetooth or SMS to share the current page.
- f. Downloads,show all the content downloaded.
- g. History, Show your browsing history, and view the most visited pages of information.
- h. Setting,contains a variety of browser settings.

10. Recorder

Recorder can record voice, and send it quickly via Bluetooth or MMS as well as make it as ring tone.

- Notices: recorder can only save the audio files as AMR format.

- 1) Click the recorder application.
- 2) Keep the phone's microphone near the voice source.
- 3) Click recorder to record voices ,and click to stop or playback.

All recordings save in my recording folder in the default music program.

11.Clock



Open the menu of application, click

- 1) Brightness control : touch it to set the brightness of the interface.
 - 2) Alarm: touch alarm to enter the interface
 - 3) PPT: touch it to shuffle the pictures
 - 4) Home: go back to the interface of Idle
- Alarm

After functions set, phone will arrives in the setting time to alert you by ringing or vibrating to achieve it's function. Press Menu to add alarm, you can also add it from the

adding interface. You could set the alarm according to your needs. In the interface of alarm will show three closed alarms (two alarm clocks are Monday to Friday 8:30,9:00) . Edit

You can edit the current alarm, you could edit time、ringing tones、vibration、repeat form and tabs. s for long the time you could: stop the alarm、change alarm settings、cancel alarm. In the interface of alarm settings, you could perform the operations of changing time、repeat 、ring tones、vibration、tabs, et

12.Caculator

calculator

this function can turn your phone into calculator, it can do some simple calculations.

- Touch the number keys to make it appear in the blank box.

In the interface of calculator, press MENU button or hold down the screen to the left, then the senior panel appears.

13. Camera

13.1 camera

- Prior preparation

Install memory card before using the camera or video camera. All your photos or videos taken by the phone are stored in memory card.

- Open camera

Press home, touch menu, select camera. Choose the video mode if you want to make videos. The

screen will automatically switch to landscape mode.

- Take pictures

- 1) Aim your object with the screen.

- 2) Touch the “shutter” button on the screen.

- 3) After taking, photos will save to the camera's galley folder with the name of taking time.

- 4) You can view the photos by touching the preview box button.

- 5) Camera settings

You can touch the button of “set” in the interface of camera to do the settings

Under camera viewfinder mode, press Menu, you can switch to video or photos' gallery.

Camera settings: button 1: EV

button 2: Scene mode.

button 3: Picture Size.

button 4: Picture Quality.

button 5: Capture mode.

Touch “set” button, you can do settings in the camera.

13.2 Video camera

- Prior preparation

Install memory card before using the camera or video camera. All your photos or videos taken by the phone are stored in memory card.

- Open camera

Press home, touch menu, select camera. Choose video camera mode. The screen will automatically switch to landscape mode.

- Take pictures

- 1) Aim your object with the screen.

- 2) Touch the “shutter” button on the screen.

3) After taking, photos will save to the camera's galley folder with the name of taking time.

4) You can view the videos by touching the preview box button.

5) Video camera settings

You can touch the button of "set" in the interface of camera to do the settings

Under camera viewfinder mode, press Menu, you can switch to video or photos' gallery.

Video camera settings button 1: EV.

button 2: EIS.

button 3: Scene Mode.

button 4: Video quality.

button5: Video duration.

Touch "set" button, you can do settings in the camera.

14. Images

- Open images

Press home, touch label of applications, then touch photos' galley.

In the interface of camera, Press menu to open it, then touch to operate.

- Use images

After taking pictures, you can view them and share them with your friends.

- View images

1) In the picture interface, touch photo album to view images.

2) Touch the thumbnail to view pictures on full screen. You can choose to display small or large thumbnails. Hold down the screen towards the left side to view the next photo or towards right to view the previous one.

In the photo album or list, press and hold down the picture towards left to view the next picture, or towards right to view the previous one.

- Crop images

In the photos' gallery, press the photo you want to crop, choose menu, 'more' and 'crop', then the instruments of cropping will appear.

- a. To adjust the trimmer size, press and hold the edge of cutting tool. After the trimmer arrow appears, drag your finger from the center inward or outward, then you can adjust the size.
- b. To keep the ratio of the trimmer, please press any one of the four corners.。
- c. To move the trimmer to other areas of the picture, hold down the center of cutting device, then drag your finger to certain position.

- Send images via mails

1) In the images gallery, press the wanted photo, choose menu, then touch share. Touch Gmail when tips appear. Picture will be automatically attached to e-mail. Edit the mail, then touch send.

- Send images via messages

1) In the images gallery, press the wanted photo, choose menu, then touch share. Touch Gmail when tips appear. Picture will be automatically attached to message. Edit the mail, and then touch send.

- Use videos

After video taken, you can view it or share it with your friends.

Watch movies

1) In the interface of photos' gallery, touch videos

album. You can watch movies after touching the wanted video.

2) Touch the screen, then the play control keys appear.

15. Music

The phone can play digital audio files in memory card. The following formats are available :AMR、M4A、MIDI、MP3、WAV、OGG.

- Open Music

Press home, touch the label of applications, touch music. Then the interface of Music Media appears.

- Music Media

Your music files are classified according to the following four categories: Artists, albums, songs and play lists. Touch one of these categories; you can view the list inside.

Continue the operations, until your wanted music appears. Such as, if you choose Artists a list of artists sorted by the numbers in English will appear. Choose any one to open the list, then all the albums and songs will appear. Select one album, then the songs in it will be played.

- Tips: You can play all of the songs in the interface of music media, in random sequence . Press Menu, and then touch the Party Shuffle. Then will start playing the first song randomly selected . To close the Party Shuffle, press Menu, then touch to turn off the Party Shuffle.

- View lyrics

When the corresponding tracks have lyrics file, the player displays the lyrics sources. Click the up arrow, you can play music, view lyrics at the same time.

- Create a play list

- 1) Touch any category of music media on the screen.

- 2) In the list, you can press and slide up and down the screen to browse the artist, album or song that you want to add to the play list.

- 3) Press the artist, album or song, and then touch the options menu in the play list.

- 4) In the interface of adding to the play list window, touch the new play list.

- 5) Enter the new name of the play list, and then touch to save.

- Manage the play list

Enter the interface of music media then touch the play list.

- 1) To play songs of the play list, touch the name of play list.

- 2) To delete a play list, press and hold the Play list, and then touch Remove.

- 3) To refresh the list of songs or remove songs, hold down the play list, and then touch the options menu in the editor.

- 4) To delete the list of songs, hold down the songs, and then touch play list to delete it.

- 5) To rename a play list, press and hold the play list, then touch Options menu renamed. Enter the new play list name, and then touch "save".

- 6) If you want to set the song to the ring tones, and then touch the song as a ring tone. The song will be set as the default ring tone.

- 7)if you want to use the song as notice

ringtone,you can press menu and touch the song as ringtone.and then touch the Notice ringtone.The song will be set as the notice ringtone.

8)if you want to cut the song to the ringtone,you can press the menu and select the song as ringtone,and then touch the cut ringtone.As shown,you can choose the start time and the end time,at last touch the 'save',it will be saved to ringtone.It can be set to the default tingtone,can be assigned to the contact as the ringtone of the contacts.

16. Calender

Enter the calender application

Load Goggles accounts, enter the application, In the interface of month or week will use gray to highlight the day. Display default the date on the current month.

In the interface, press menu, 4 display modes will appear:

1) Schedule Infrface shows a certain schedule(click on the initial time and view forward,click the final time to view backwards)

2) day Interface displays a day's schedule (last clicked date),Slide around to turn page accoring day.

3) week Interface displays a week's schedule (last clicked date),Slide around to turn page accoring week.

4) today Interface displays a day's schedule, In the

interface of month or week use gray to highlight the day.

5) month interface displays a month's schedule (last clicked date) Slide around to turn page according month.

- New activities
 - 1) Press menu, more < touch new activities.
 - 2) Enter the name of activity in the activities' box.

Notices: Such as special occasions such as birthday or a day with events, set the all-day option to Yes. If the activity is at a certain time period, select the start time and end time.

3) Enter the event location, description, guests, repeat, remind time.

4) Click finish to return to calendar.

The details of activities box

Notices: All-day events appear in the calendar heading. It will not show the period of calendar.

Cancel activities: In the time frame, press for long to delete the activity.

17. FM Radio

FM Radio

Through this program, you may listen to FM radio on the device, FM radio use the wired headset as an antenna to receive signals, before opening this program, you can install the original equipment-headphones, when listening, you can switch it manually to speakers or the mode with wired headphones.

- Open FM radio



Touch this label  to open the application of FM radio.

Click the Back button, the radio program move to the

background, and you can still continue to listen to programs and other applications run at the same time. Press menu and click to exit radio.

- Collect the channel you are favorite
Press the menu button in the FM interface,click the “search&save” ,and then view the channel list,press long one channel ,click “Add to Favorite”to rename the channel.
- Press the menu,you will see below

18. Settings

Your service provider may default some device settings, so you may not be able to change these settings.

- SIM card manage



1) Touch it to choose or to disable the SIM card, the card is grey when disabled, the flight mode displays on status bar.

2) The default SIM card ,you can choose Voice call,Video call,Messaging,Data connection.

- Wireless and internet



1) Flight mode Touch to open or close.

2) Wi-Fi and Wi-Fi settings Touch Wi-Fi to



open . Open Wi-Fi ,it can search for available networks automatically, networks without password can be used directly, others need to enter the password first.

Notice: Open Wi-Fi then the flight mode, Wi-Fi will

close automatically; Open flight mode then connect Wi-Fi, it can be used normally.

WPS connection, wireless AP and mobile phone are needed to support AOSS, you can directly connect without entering a key.

- 3) Bluetooth and Bluetooth setting.
- 4) Tethering & portable hotspot Share your digital data via USB
- 5) Virtual Private Networks (VPN) Settings.
- 6) Mobile network enter "mobile network settings" which include: a Data roaming b Access point name c Network operators.
- 7) GPRS data priority mode



- Calling settings

- 1) Voice Call

- a. Voice mail, in the voice settings, you can enter the voice mail number.
- b. Call forward, You can set Always forward, Forward when busy, Forward when unanswered, Forward when unreachable.
- c. Call barring
- d. Additional settings, Call ID and Call waiting

- 2) Video Call

- a. Picture for replacing local video, set a picture to display when camera off use.
- b. Enable back camera, available to switch cameras if turn off.
- c. Peer video bigger than local video, turn on to make peer video bigger than local video

- d. Local video display, to make outgoing video call or incoming video call.
- e. Other settings, include call forwarding, call barring, additional settings.

3) Internet Call

Can add accounts

4) Other settings

- a. Fixed Dialing Numbers
- b. Call cost
- c. Cell broadcast
- d. Minute reminder
- e. Phone settings
- f. TTY settings

● Audion profiles



This option gives the phone tones' settings under the status of receiving calls or notification. Including: Vibration, volume, ring tones, ring tones notification and feedback (Button operation tone, select Sound, screen lock tone, touch). To adapt every environment.

- 1) Select "Standard / Mute / Conference / Outdoor, Touch the spot on the right, when turns green, it opens.

2) Volume: Including the ring volume and alarm clock settings, you can manually slide to select.

Displays



- a. Brightness Adjust the brightness
- b. Auto rotating screen Rotate phone to change direction
- c. Animation Choose to display animations
- d.

Screen Timeout Adjust the delay before the screen automatically locks

- Location



- 1) Use wireless Use wireless to find locations in the application (Google map) .

Touch it to open or close

- 2) When using the GPS satellite positioning, set accuracy to street level(cancel it to save battery).

Touch it to open or close

- 3) GPS EPO assistance,use GPS assistance data(EPO)to speed uo GPS poditioning

- 4) A-GPS Use auxiliary data can accelerate the process of GPS positioning.

Open it and remind you “it produce GPRS flows when using A—GPS” .

- safety



- 1) Set up screen locks Use images、PIN or password to lock the screen.

- a. Touch “images” , the first time there will be a simple unlock instructions and examples, click “ next step ” to continue the step “make the unlocking image” .

- b. Touch PIN Enter PIN numbers to unlock the screen.

- c. Touch password Set password to unlock the screen.

d. Touch "no" Stop this application.

2) Set up SIM card lock Enter (4-8 numbers) PIN to set the lock of SIM.

SIM card PIN (Personal Identification Number) is to prevent unauthorized use of SIM cards. PIN code provided with SIM. The service provider gives the initial value.

Change a blocked PIN code, you need to open the "SIM Lock ", then go to Change Password screen, the phone will automatically prompt enter the old PIN code and asked to enter a new PIN code twice, finally the phone will prompt that change the code successfully. If you enter the PIN with error for three times, SIM card PIN codes will be automatically locked, PUK codes is usually supplied with SIM card. If no, you should go to the service provider for the codes.

If you enter 10 times wrong PUK code, the SIM card will be permanently locked.

3) Password visible Password visible when enter it

4) Select device administration Add or delete device manager.

5) Use security credentials Allow application visit security credentials or other credentials.

6) Install from SD card Install the encrypted certificate from SD card.

7) set password Set or change Certificate store password

8) clear storage Clear all the contents of the certificate store and reset their passwords.

- Applications



1) Unknown sources Allow to install non-electronic market applications

2) Manage applications Manage and delete the installed applications.

3) Running services Touch any of the services listed in> pop up 'to stop the service? 'two-button operation box, touch the 'Stop 'the service is stopped, and disappear from the "running services" list.

4)Storage use you can view the program of downloaded,all,on sd card or running how many memory space they occupy

5)Battery use you can see the using power situation of cell Standby,Phone idle,Display and Browser.

6)development a. USB debug: USB debug only apply in the develop process. This function allows copy data in computer and mobile devices.

- Accounts and Synchronize



1) Background data Applications using the background data synchronization at any time, send and receive data, disable the background data extend battery life and reduce data usage. However, some applications will use the background data for the connection.

2)Automatic synchronization turn on/off Automatic synchronization, applications Automatically synchronize data or asynchronous data

- Privacy



1)Resetting to Factory Settings Clear all data stored on the phone.

- Storage



- 1) View SD Card and Phone Memory.
- 2) Uninstall or Format SD Card.



- Languages and keyboard

1) Selecting Language District Include all the languages on the phone and totally amount of 12 kinds.

2) Custom Dictionary Add words to custom dictionary or delete.

3) Keyboard Settings Vibrating when buttons are pressed, Playing sound when buttons are pressed, Capitalizing automatically, Speech Input(by microphone on the keyboard), Inputting words(speech can be altered by sliding finger on space key), Displaying

tips(activate predictive function when you input words);
Auto-Text(Automatically input certain words when press space key or specified keys)

4) Input method you can select Android keyboard or google pinyin input method.



- Speech Input and Output Settings

Test-to-Speech Conversion Setting

a.Listen to an example play a short demonstration of speech synthesis

b.Always use my settings default setting below override application settings

c.Default Engine sets the speech synthesis engine to be used for spoken text

d.Install voice data install the voice data required for speech synthesis

e.Speech rate speed at which the text is

spoken

f. Language sets the language-specific voice
for the spoken text

g. Pico TTS

- Auxiliary Function



1) End up calling when you press power key on/off

2) Quick boot



- Date and Time

1) Automation Use date and time provided by Network.

2) Setting Date Touch “+” and “-” to set date.

3) Selecting Time Zone Select Time Zone according to where you are. For China please select “GMT+08:00, China Standard Time”.

4) Setting Time Touch “+” and “-” to set time.

5) Use 24 Hour Time Format ON/OFF

6) Select Date Format There are 3 kinds of formats you can choose from: Month-Day-Year, Day-Month-Year and Year-Month-Day, among which Year-Month-Day is the default setting.



- Schedule power on/off

You can set time of boot or shutdown by touching it. You may also select to repeat it or a certain day during a week.



- About phone

You can check the information on status bar and

19. Notices for the use of phone

Your phone is a product of superior design and craftsmanship and should be treated with care. The following suggestions can help you comply with the terms of repair kits, to extend the life of mobile phone.

- 1) Place the mobile phone and their parts and components out of reach of small children.
- 1) Keep the phone dry, rain, humidity and all types of liquids which contain minerals will corrode electronic circuits.
- 2) Don't touch the phone with wet hands when charging, it will cause electric shock or damage the phone.
- 3) Avoid place the device in high temperature environment. Temperatures will shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- 4) Avoid place the device in too low temperature environment. When the temperature rises, the phone will produce water vapor that may damage electronic circuit.
- 5) Avoid place the phone in dusty, dirty places, otherwise parts may be damaged.
- 6) To avoid the phone in a lit cigarette, near open flame or any heat source.
- 7) Do not open the device, non-professional approach will do damage to the phone.
- 8) Do not throw it from height, knock or shake the phone, rough handling can damage internal circuit boards.
- 9) Do not paint the phone, because the paint will block headphones, microphones or other removable parts, and lead it not work.
- 10) Use clean, soft, dry cloth to clean the camera, light

sensor lenses. Prohibit the use of harmful chemicals and cleaning agents, cleaning fluids to clean the phone

- 11) If mobile phone, battery, charger, or mobile phone accessories are defective, send to the nearest qualified service center for inspection.
- 12) If necessary, Service Centre staff will assist you and will arrange for phone repairs.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and

receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Agora Ring Pro (FCC ID: **2ACOP1020AGORA**) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.421W/kg and when properly worn on the body is 0.966W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.0 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10 mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10 mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.