

Ultratab X7

Quick Start Guide



Product Overview



①	Micro USB 2.0 HS	②	Earphone 3.5mm Slot
③	Front-Camera	④	Power Key
⑤	Volume Key +	⑥	Volume Key -
⑦	Micro SD Slot	⑧	SIM card Slot
⑨	Speaker	⑩	Rear-Camera

Getting Started

■ Turning the tablet On/Off

To turn On the tablet

1. Press and hold the PWR key for a few seconds.
2. Unlock the screen with your finger.


To turn Off the tablet

1. Press and hold the PWR key, select Power Off.
2. Tap OK. The tablet will be off in a few seconds.

■ **Unlocking screen**

The screen is locked by default when you turn on the tablet. To unlock the screen,

1. Press the PWR key.
2. Drag the inner ring to the edge of the circle to unlock the screen.
Draw a pattern if the screen is protected by pattern lock. Enter a PIN or a password if the screen is locked by a PIN or a password.



■ **Locking screen**

To lock the screen, press the PWR key. It is recommended to lock the screen to protect information in the tablet and reduce battery usage. You can also configure your tablet to automatically lock after a certain period of time. Tap → Settings → Display → Sleep to set the sleep time from 15 seconds, 30 seconds, 1 minute, 2 minutes, 5 minutes, 10 minutes, or 30 minutes.

■ Using touch screen

All of the functions of the tablet, except for power and volume, are performed on the touch screen. Therefore, it is essential to know how to use the touch screen.

The following finger actions might help you easily understand how to use the touch screen.

- ❖ Tap: Touch an item (e.g. application or widget) once that appears on the screen with your finger to run it or access a menu or an option
- ❖ Double tap: Tap an item twice with your finger
- ❖ Drag: Tap and hold your finger on an item and move it without losing contact with the screen
- ❖ Flick: Place a finger on an empty space of the screen and move the screen up or down, or left or right
- ❖ Pinch: Place two fingers on the screen and move them apart to zoom in a picture, a document or a web page, or move them together to zoom out
- ❖ Select and tap: Tap an item in the list of options available
- ❖ Press and hold: Press a key or any item for a few seconds until a list of options appears

Cautions:

- ✓ Do not use sharp tools that can scratch the touch screen.
- ✓ Do not allow the touch screen to come in contact with chemicals. The screen may malfunction in chemicals.
- ✓ Do not sit on the tablet: the touch screen can be damaged.


■ Status bar

The status bar at the top of the screen notifications from various apps, time, and the states of various devices such as battery status, WLAN status,


Signal status and so on.



1. Notification panel displays notification icons to inform you of new Email, messages, and so on. Slide the panel down to view the notifications and then tap a notification icon to view details of the notification.



2. Status panel displays status icons to show the current state of your tablet, such as battery charging progress, alarms, Bluetooth, and so on. Slide the panel down to access more settings and configuration options.



■ Screen orientation

For optimal viewing experience, the screen orientation changes automatically depending on how you hold the tablet.

NOTE: To enable or disable auto-rotate, slide down the status panel and tap the Auto-rotate icon.

■ Keys and functions



1. Back key

- ❖ Tap to return to the previous screen and exit the running application.
- ❖ Tap to close the on-screen keyboard in text input mode.

2. Home key

- ❖ Tap to return to the main screen.
- ❖ Tap and hold to open the Google search.

3. Menu key

- ❖ Tap to open the applications list used recently.

■ Apps and widgets

- ❖ **Apps:** Software that allows you to perform a specific task. Your tablet is preloaded with a variety of applications, and additional applications can be downloaded from the Play Store.
- ❖ **Widgets:** A small application which resides on the home screen and provides quick and easy access to information.

Connecting to the Internet using WLAN

NOTE: The range and quality of the WLAN signal is affected by the distance between the tablet and the wireless router, the number of connected devices, infrastructure, and objects through which the signal is transmitted.

1. Tap  → Settings → WIRELESS & NETWORKS → WLAN.
2. Enable WLAN by moving the slider to On position. The tablet scans for WLAN networks in range.
3. Tap the network you want to connect to.
4. Type a password (if connecting to a secure network) and tap Connect to connect to the selected WLAN network.



NOTE: To connect to a secured WLAN network, you must provide the security key. If you do not have the security key, contact the person who manages your WLAN network or the router manufacturer.

NOTE: To start a new search for available WLAN networks, on the WLAN screen, tap  → Scan

Connecting to the Internet using mobile broadband

1. Tap  Settings → WIRELESS & NETWORKS → WLAN, then touch WLAN to disable it.
2. The tablet automatically searches for the carrier signal and connects to the network. When the tablet is connected to a mobile broadband network, the network type appears in the status bar.

NOTE: On the LTE/HSPA+ models, if both WLAN and mobile broadband networks are available, the tablet gives priority to WLAN connection.

Safety Information

The following list shows how to maintain your tablet, together with precautions to take.

- Keep your tablet and its accessories out of the reach of pets.
- Do not allow children to use your tablet. If children use the device, make sure that they use the tablet properly.
- Maintain your tablet in dry conditions and keep it within normal operating temperatures. Temperatures higher than **40°C or lower than -20°C** may damage your tablet.
- Do not try to dry your tablet in a microwave oven. If you do, sparks can occur and cause an explosion or fire.
- Do not use or store your tablet in dusty or dirty areas.
- Do not attempt to disassemble your tablet.
- Do not drop or cause severe impact to your tablet.
- Do not use chemical products, cleaning solvents or detergents to clean your tablet.
- If your tablet does not work properly, contact your dealer immediately.
- Use only authorized batteries, battery chargers and accessories. Any malfunction or damage caused by the use of unauthorized batteries, battery chargers and accessories will void the limited product warranty.

FCC Caution.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Ultratab X7 (FCCID: 2ADFMULTRATABX7) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification when properly worn on the body is 1.343 W/kg. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0 cm separation distance between the user's body and the back of the handset.

The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.