

## **Operation Principle**

When push forward/backward, left/right handle, IC TX2S will receive relative instruction, and then transmit corresponding coded signals, this coded signal and the local oscillator signal will be amplified and transmitted through antenna to control the heli launcher to move forward, backward, left and right. The oscillator is 27.145MHz.