

Hisense U30 (HLTE106E)

User Manual

Before using your phone, read the User Manual thoroughly.

Manufactured by Hisense Communications Co., Ltd.

Contents

Phone Basics

Your phone at a glance	5
Carrying out basic operations	6
Using the notification center	11
Using SIM and MicroSD cards	12
Battery charging	14
Other hardware features	16

Troubleshooting

I can't turn my phone on	17
My phone keeps turning off automatically	17
I can't use an application on my phone	17
My phone's standby time is too short	18
My phone isn't charging properly	18
Touchscreen error when charging	19
I've forgotten my password	19
My PIN is locked	19
I can't use the Internet or make calls	20
My calls don't connect	20
Phone doesn't make a sound when it rings	20

Phone

Making calls	21
IMEI Information	21
Making calls from contacts	21
Making calls from recents	22

Contacts

Importing contacts	22
Creating contacts	22
Searching for contacts	22

Messages

Sending messages	23
Viewing messages	23

Camera

Taking photos	24
Taking panorama	24
Recording videos	25

Photos

Viewing photos or videos	25
Deleting photos or videos	25
Sharing photos or videos	25

Chrome

Using Chrome	26
--------------	----

Clock

ALARM	26
CLOCK	27
TIMER	27
STOPWATCH	28

Recorder

Recording sound	28
Playing a recording	28
Managing recordings	29

Calculator

Making calculation	29
--------------------	----

FM Radio

Listening to radio	29
--------------------	----

Security and Privacy

Face unlock	30
-------------	----

Safety

Safety precautions	31
Safe battery charging	35
Protecting your hearing	35
Protecting the environment	35
Reducing your radiation exposure	36
Other important information	36
Disclaimer	37
ONLY FOR MEXICO	37
FCC Compliance	38
Specification	41

Safety symbols in this document

The following symbols are used throughout this document:



Warning: situations that could cause injury to yourself or others.



Caution: situations that could cause damage to your device or other equipment.




Notice: notes, usage tips, or additional information.

Phone Basics

Use the information in this section to get to know your phone better.

Your phone at a glance

Get to know your phone with the following figure and legend.



1. Loudspeaker/ Receiver	6. Flash lamp
2. Front camera	7. Microphone
3. Rear cameras	8. Volume button up
4. Headset socket	9. Volume button down
5. USB port	10. Power button



The figures and descriptions are for reference only, please refer to the descriptions of actual product.

Carrying out basic operations

This section describes how to carry out basic functions on your phone.




Before using your phone for the first time, fully charge your

battery. For more information on charging your battery, see **Battery charging**.

Turning your phone on

- To turn your phone on, press and hold the power button until the screen turns on.
- When turning your phone on for the first time, or after performing data reset, follow the onscreen instructions to set up you phone.
- To force restart your phone, press and hold the power button until your phone vibrates.

Turning your phone off


To power off your phone, press and hold the power button, and then tap the  icon.

Using touchscreen gestures

This section describes how to use touchscreen gestures to help control your phone.


Tapping

To open an app, to choose a menu item, to press an on-screen button, or to enter a character using the keyboard on the screen, tap it with your finger.





Tapping and holding

Tap and hold an item on the screen for more than 2 seconds to access available options.





Swiping

Swipe to the left or right on the home screen or the Apps screen to view other panels.




Swipe upwards or downwards to scroll through a web page or a list of items.




Spreading and pinching

Spread two fingers apart on a web page, map or image to zoom in a part.




Pinch to zoom out.






Dragging

To move an item, tap and hold it and drag it to the target position.



Using the navigation bar

You can find your navigation bar control at the bottom of you screen.

- To go back to the home screen, tap .
- To open the list of recent apps, tap .
- To go back to the previous screen, tap .

Locking and unlocking screen

Locking the screen

- To lock the screen, press the power button.
- Go to **Settings > Display > Screen timeout** to change how quickly your screen goes to sleep. The screen locks and goes into

sleep mode when you don't use your phone for a while. This is to save power and stop accidental phone use.

Unlocking the screen

To unlock the screen, press the power button and swipe up.

Using the notification center


The notification center is where you can view the latest notifications relating to the operation of your phone.

Opening the notification center

To open and view the notification center:

- 1 Swipe down from the top of the screen to see the notification center.
- 2 Swipe down again from the top of the screen to see the shortcuts tab.

Closing the notification center

Swipe up or tap  to close the notification center.

Setting notification options

To set notification options, go to **Settings > Apps & notifications >**

Notifications.

Using SIM and MicroSD cards

Inserting SIM and MicroSD cards

Always ensure that SIM and MicroSD cards are inserted correctly into your phone.

The following figure shows the correct way to insert SIM and MicroSD cards into your phone.



When inserting your card tray, make sure that the card is level and that the card is aligned correctly.




Do not use cut or modified SIM or MicroSD cards with your phone, as these may not be recognized and could damage the card tray.

Ejecting SIM and MicroSD cards

Always make sure that the SIM and MicroSD card are ejected correctly from the phone.

The following figure shows the correct way to eject SIM and MicroSD cards from your phone.



Battery charging

Follow instructions in this section to charge your battery safely and preserve battery life.

Charging your battery

Fully charge the battery before using it for the first time, or when the phone has not been used for a long time, or when the battery is low.

To charge your battery, do the following:

- 1 Connect your USB charging cable to your USB power adapter.

Plug the end of the USB cable into the USB port, and the USB power adapter into a power socket.



- 2 Once your battery is fully charged, disconnect your phone from your USB charging cable.

Important safety precautions

The following precautions are extremely important and must be followed at all times:

To charge your phone safely, it is also important to pay attention to the following points:

- Use only approved chargers, batteries, and cables. Using an unapproved or incompatible power adapter, charger, or battery may damage your phone, shorten its lifespan, or cause a fire, explosion or other hazards.
- Avoid using your phone when it is charging. Do not cover your

phone or power adapter.



- Connect your charger properly. Not connecting your charger properly can cause serious damage to your phone. Any damage caused by misuse is not covered by the warranty.



- Your phone can be safely charged at temperatures between 0°C and 40°C. Charging in environment where the temperature is below 0°C or higher than 40°C will harm battery. Performance and shorten battery life. Regular, long-term charging in extreme temperatures will damage your battery.
- Unplug your charger from the electric socket when not charging your phone.

Protecting your battery

For safe and effective charging that also protects your battery, you must also pay attention to the following points:

- If your AC power supply is lower voltage, or you charge from computer or other non-standard sources, you may need to charge your phone for longer.
- Your phone might not start straight away if the battery is low. Your phone will start normally once it has charged for a short while.
- The time your phone needs to charge may depend on room temperature and your battery level.

- The phone and charger may heat while charging. This is normal and shouldn't affect your phone's lifespan or performance. If your battery becomes much hotter than usual, stop charging your phone and put it in a cool place. If your phone surface is hot, avoid touching your phone for too long.

Troubleshooting

This section lists common problems you may have when using your phone. Check to see whether your issue is listed here before contacting the service center.

I can't turn my phone on

If you can't turn your phone on, try the following:

- Press and hold power key for two seconds or longer.
- Check that the battery is fully charged before turning your phone on.
- Press and hold the power button until your phone vibrates.
- Check that your battery is properly connected to your phone, and that the connecting points are clean. If your phone has a built-in battery, contact the service center.

My phone keeps turning off automatically

If your phone keeps turning off automatically, try the following:

- Check your battery power. If the power is low, charge your phone.

- Check softwares or applications to see if they are normal. If not, restart your phone.

I can't use an application on my phone

If you can't use an application on your phone, try the following:

- Check if your phone has sufficient storage. Delete some messages from your phone.
- Check if the application is damaged. Uninstall and reinstall the application. If cannot be fixed, try resetting system.
- Chances are that the application is not compatible. Uninstall the application and choose a compatible version.
- Check and enable applications management permissions.

My phone's standby time is too short

If your phone's standby time is too short, try the following:

- Chances are that the battery performance decreases. Contact service center to change the battery.
- If you play games or listen to music for a long period of time, shorten the time.
- If the screen is too bright, adjust the brightness of the screen.
- If the phone is used in weak signal environment, the standby time will be short. Please move to strong signal locations.

- Turn off cellular data, GPS, Bluetooth, Wi-Fi switch when not using them.
- Close the application not used.
- Uninstall the applications not used for a long period of time.

My phone isn't charging properly

If your phone isn't charging properly, try the following:

- Ensure that your phone is charging at a normal temperature.
- Plug the charger into a different socket.
- Recharge your phone for about half an hour.
- Chances are that the battery has a problem. If the battery has been built-in, contact service center.
- Ensure that the charger is not defective. If the charger is defective, replace it.
- If the charger fails to charge, please change or repair it.

Touchscreen error when charging

If there is touchscreen error when charging, try the following:

- If the charging equipment is incompatible with your phone, it may cause some problems. Use charger supplied and stable charging equipment.
- Check whether softwares or applications are normal or not.

Restart your phone.

I've forgotten my password

If you forget your password, contact service provider.

My PIN is locked

If you enter wrong PIN three times in a row, contact service provider.

I can't use the Internet or make calls

If you can't use the Internet or make calls, try the following:

- Chances are that signal is too weak. Move to an open area and try again.
- Chances are that the phone is out of service area. Check if the Internet is available.
- Chances are that airplane mode is on. Turn off airplane mode.
- Check if software is abnormal. If so, restart the phone.
- Check if SIM card has failure. If so, check or change SIM card.
- Ensure that the dialing is right.
- Check if cellular data setting has failure. If so, go to Settings to set up cellular data.
- Check if pre-paid charge has reached its limit. If so, contact service provider.

My calls don't connect

If your calls don't connect, try the following:

- Check if phone number is too long.
- Ensure international roaming service and international call service are enabled. If not, contact service provider.




Phone doesn't make a sound when it rings

If your phone doesn't make a sound when it rings, check if silent or vibrate mode is enabled.



Phone

Making calls

To make calls:

- 1 Tap .
- 2 Tap  to enter a phone number.
- 3 Tap  to make a call.



IMEI Information

- 1 Tap. 
- 2 Tap 

3 Input *#06#




Making calls from contacts

To make calls from contacts:

- 1 Tap .
- 2 Tap  to choose a contact.
- 3 Tap the contact number.

Making calls from recents



To make calls from call logs:

- 1 Tap .
- 2 Tap  to view all calls. Tap the name or number of the person You want to call.
- 3 Tap .

Contacts



Importing contacts

To import contacts to your phone:

- 1 Tap .
- 2 Tap , then tap **Settings > Import**.
- 3 Select an import option.


Creating contacts

To create a new contact:

- 1 Tap .
- 2 Tap .
- 3 Enter the contact's name, phone number and other contact information, and then tap **Save**.

Searching for contacts



To search for contacts:

- 1 Tap .
- 2 Use one of the following search methods:
 - Scroll up or down the contacts list.
 - Tap **Search contacts** at the top of the screen to search for a contact.
- 3 Select a contact. You can now call them, send them a text message, or edit their contact information.


Messages

Sending messages

To send messages:

- 1 Tap .
- 2 Tap  to create a message.

3 Add recipients and enter a message.

4 Tap  to send the message.

Viewing messages

To view messages:

1 Tap .

2 Select a contact on the message list.

3 View your conversation.



Camera

Taking photos

To take photos:

1 Tap .




2 Swipe to **Capture** on the screen. Spread two fingers apart on the screen to zoom in, and pinch to zoom out.

3 Tap  to take a photo. Your picture will be automatically saved to .

Taking panorama




To capture a panorama shot:

1 Tap .

- 2 Swipe to **Panorama** on the screen. Hold your phone steady and then tap  to start shooting. Slowly move your phone in the direction indicated, holding the phone steady and ensuring the arrow stays levels with the center line.
- 3 Tap  when you are finished. Your picture will be automatically saved to .

Recording videos

To record videos:

- 1 Tap .
- 2 Swipe to **Video** on the screen. Tap  to start recording the video. Spread two fingers apart on the screen to zoom in, and pinch to zoom out.
- 3 Tap  to finish recording.

Gallery

Viewing photos or videos

To view photos or videos:

- 1 Tap .
- 2 Select a photo or a video.

Deleting photos or videos

To delete photos or videos:

1 Tap .


2 Tap and hold the photo or video that you want to delete, tap .

Sharing photos or videos

To share photos or videos:

1 Tap .

2 Select the photo or video that you want to share.

3 Tap . Select your sharing method.

Chrome

Using Chrome

Connect the web to search for information and bookmark your favorite web pages to access them conveniently.



1 Tap .

2 Enter the address field in the search bar. You will have access to web pages; moreover, bookmarks, multiple window switching and other functions are supported.


Clock

This app includes the following functions:

ALARM

Tap  . From the  tab, you can do the following steps to set your alarms:


Adding an alarm

Tap  and set the alarm time, repeat times, alarm sound, and others.

Enabling or disabling an alarm

Turn on or turn off the switch next to an alarm.

Configuring the alarm settings



Tap  > **Settings** to configure the alarms.

Deleting an alarm


Tap and hold a alarm, select the alarm that you want to delete.

Then tap  .

CLOCK

Tap  . From the  tab, you can do the following steps to set your clock:





Adding a city

Tap  . Enter a city name in the search bar or select a city from the list.




Deleting a city

Tap  . Deselect the city, then the clock of the city will be deleted.

TIMER

- 1 Tap .
- 2 Tap .
- 3 Set the countdown time and tap  to start the timer. Tap  to pause the countdown.






STOPWATCH

- 1 Tap .
- 2 Go to the  tab.
- 3 Tap  to start the stopwatch. Tap **LAP** to count laps. Tap  to pause the stopwatch. Tap RESET to reset the stopwatch.




Sound Recorder

The device supports long periods of recording. Make sure your device has available storage before recording.



Recorder

- 1 Tap .
- 2 Tap  to start recording.
- 3 Tap  to stop recording, then tap  Save, the recording file is automatically saved in the phone. Tap  Delete, the recording file is deleted.

Playing a recording

- 1 Tap .
- 2 Tap to  find your recording.
- 3 Tap  to play the recording.


Managing recordings

- 1 Tap .
- 2 Tap .
- 3 Tap and hold a recording. You can rename, share or delete the recording file.

Calculator

Use calculator to do simple or complicated calculations.

Making calculation

Tap , you can do simple calculations:

- Tap the number and calculate sign to do simple calculations.
- Go to advanced calculator tab by swiping your screen left.

FM Radio

Listening to radio

To use the FM Radio, first you need to connect your headphones.

- 1 Tap  to activate.

- 2 Select the frequency following the app instructions and set the volume to a comfortable level.

Security and Privacy

Face unlock

Face unlock can be used to unlock your phone.

Adding a face

To add your face:

- 1 Tap **Settings** > **Security** > **Face unlock**.
- 2 To set a screen lock password, PIN or pattern along with your face, follow the onscreen instructions.
- 3 Read the instructions carefully.
- 4 Register your face. You can now use your face to unlock the screen.

Deleting a face

To delete your face:

- 1 Tap **Settings** > **Security** > **Face unlock**.
- 2 Enter your password, PIN or pattern.
- 3 Tap **DELETE FACE DATA**, and then tap **DELETE**.

Safety

This section contains information on the secure and safe operation of your phone.

Safety precautions

For your safety and that of others, ensure you read, understand, and follow all of the information in this section.



Failure to obey the following safety information could result in fire, electric shock, injuries, or damage to your device or other property. Read all the safety information below before using your phone.

- Using unapproved or incompatible power adapters, chargers, or batteries may damage your phone, shorten its lifespan, or cause a fire, explosion, or other hazards.
- Your phone's ideal operating temperature is -20°C to 55°C. Your phone's ideal storage temperature is -20°C to 45°C. Your phone's ideal charging temperature is 0°C to 40°C
- Pacemaker manufacturers recommend keeping a minimum distance of 15 cm between phone and pacemaker to prevent potential interference with the pacemaker. If you use a pacemaker, hold your phone on the side opposite to your pacemaker and do not carry your phone in your front pocket.

- Keep your phone and battery away from excessive heat and direct sunlight. Do not place your phone or battery on or in heating devices, such as microwave ovens, stoves, or radiators.
- Do not use your phone in a moist environment, such as bathroom.

Prevent your phone from being soaked or washed in liquid.

- Follow local laws and regulations while using your phone. To reduce the risk of accidents, do not use your wireless phone while driving.
- While flying in an aircraft or immediately before boarding, only use your phone according to instructions provided. Use of a wireless phone in an aircraft may disrupt wireless networks, can cause danger to aircraft operation, and may be illegal.
- To prevent damage to your phone's parts or internal circuits, do not use it in dusty, smoky, damp, or dirty environments or near magnetic fields.
- When charging your phone, plug the adapter into a socket which is near your phone and which is easy to reach.
- When not in use, unplug the charger from outlets and from the phone.
- Do not use, store or transport your phone in areas where flammables or explosives are stored (in a gas station, oil depot, or chemical plant, for example). Using your phone in these

environments increases the risk of explosion or fire.

- Dispose of your phone, battery, and accessories according to local regulations. Do not throw phones or batteries away in your household trash bin or other non-recycling trash bin. Improper battery use or disposal may lead to fire, explosion, or other hazards.
- Consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.
- Obey any rules or regulations set by hospitals and health care facilities.
- Do not crash, throw, puncture, drop, squeeze, or bend your phone.
- Do not try to take apart your phone or its accessories. Only authorized personnel are allowed to service or repair the phone.
- Use a dry soft cloth to clean your phone. Do not use water, alcohol, detergent or any chemicals.
- Keep your phone and charger out of the reach of children. Do not let children use the phone or charger without supervision.
- Phone accessories and phone accessory parts, especially small parts, must also be kept away from children to prevent choking.

- Power off your phone in any area where there is a risk of explosions. Do not charge your phone or use your phone in areas where there are chemicals or particles in the air. Obey all signs and instructions.
- Strictly obey relevant instructions in this guide while using USB cable. Failure to follow instructions may result in your phone or PC being damaged.
- Only use USB version 2.0. USB equipment with your phone.

Safe cleaning and maintenance

To ensure your safety and that of others, you must pay attention to the following safety tips when cleaning and maintaining your phone:

- Turn off your phone before cleaning and maintenance. Your charger should be unplugged from socket. Your phone and charger should be disconnected to prevent electric shocks or short circuiting.
- Do not wipe your phone or charger with benzyl alcohol, chemical substances, chemical agents or abrasive cleaning agents. This is to avoid damaging phone parts or the functioning of your phone. You may clean your phone with a slightly damp anti-static cloth.
- Do not scrape or alter the phone case, or the paint on the phone, as it may cause allergic reaction. If such reaction occurs, stop using your phone immediately and seek medical help.

- Wipe dust off power plug and keep it dry to avoid risk of fire.
- If your phone or accessories do not work properly, contact your local vendor.
- Do not disassemble device or its accessories by yourself.

Safe battery charging



Follow the information on safe battery charging in the

Battery charging, Safety precautions, and Protecting your battery sections of this user manual.

Protecting your hearing

- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Fully understand user manual before use.
- Ensure your player at low volume levels or power off before you leaving.

Protecting the environment



- Obey the local regulations on device packaging, battery and used device disposal and bring them to the collection point for proper recycling.

- Take your used, unwanted lithium batteries to a designated place. Do not dispose of used devices or batteries in a household rubbish bin.

- Proper collection and recycling of your device help ensure electrical and electronic equipment waste is recycled in a manner that conserves valuable materials and protects human health and the environment.

Reducing your radiation exposure

You can reduce your exposure to radiation from your phone by doing the following:

- Use your phone in areas with good reception. Be especially careful in underground car parks and on train and car journeys.
- Use your phone when all the signal strength bars are displayed.
- Use a hands-free kit.
- During calls, keep your phone away from your abdomen (for pregnant women) and your lower abdomen (for teenagers).

Other important information

Important data usage and billing information

Your phone regularly connects to mail and Internet servers to improve your experience. This creates data exchanges that may be charged along with your existing package, or which may use prepaid credit.

To avoid billing problems related to Internet services, it is strongly

recommended to use a suitable package or plan which includes unlimited Internet and emails and to avoid changing the default settings.

You can connect to Wi-Fi for faster, more streamlined service. If you can, use Wi-Fi for streaming, and for downloading games, videos and films.

Disclaimer

Unofficial headsets, chargers, and other accessories are not compatible with your phone. Using unofficial accessories can affect performance. The factory is in no way responsible for any damage that occurs as a result of using unofficial accessories.

This user manual is intended to provide a general overview. Actual specifications and functions of your phone may be different from those contained in the user manual.

Your phone was fully tested after production. If there are any damages or defects due to manufacturing, follow the terms and conditions in the warranty card.

If there are issues with your phones related to operator features and services, follow the operator terms and conditions.

Note that your phone has specification and function limitations. These limitations cannot be considered manufacturer damage or as damage or defect of any kind.

Only use your phone for the purposes or functions for which it was designed.

ONLY FOR MEXICO

“For use in Mexico, the operation of this product is subject to the following two conditions: (1) this equipment or device may not cause detrimental interference and (2) this equipment or device must accept any interference, including interference that may cause unwanted operation.”

FCC Compliance

This phone complies with section 15 of FCC Regulations. Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. -
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission(USA) .

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC - The highest SAR value reported to the FCC for this type of devices is 0.66 W/kg when used over the ear, 0.60 W/kg when used at 10 mm away from the body and 0.65 W/kg when used at a wireless access point (HOTSPOT) 10mm.

FCC ID:2ADOBHLTE106E

Importador: Hisense México S. de R.L. de C.V. Blvd. Miguel de Cervantes Saavedra, No. 301 Torre Norte, Piso 2, Col. Ampliación Granada, Municipio o Demarcación Territorial Miguel Hidalgo, C.P. 11520, Ciudad de México.

R.F.C. HME110512IY3 Tel: +52 55 55313515

MARCA: HISENSE

MODEL: HLTE106E

ELECTRICAL CHARACTERISTICS

ADAPTADOR:

BRAND: HISENSE

MODEL: TPA-97050100UU

INPUT: 100-240V~50/60Hz,0.15A

OUTPUT: 5.0 V \approx 1000mA


RECHARGEABLE BATTERY:

BRAND: HISENSE

MODEL: LPN440400

MADE IN CHINA

Specification

Brand	Hisense
Market	Hisense U30 32G
Model	HLTE106E
Dimensions	157.05×73.45×10mm
OS	Android 11 Go
CPU	SC9832E, Octa Core, CORTEX-A53 1.4GHz
Internal Memory	1GB RAM + 32GB ROM
Camera	Rear:8MP+CIF Front:5MP
Size	5 inch
Resolution	FWVGA (480*854)
Color	16.7M
3G	WCDMA: B1/2/4/5
4G	LTE: B1/2/4/5/7/12/28
2G	850/1900
No surport band	Band 10/38/66
Data Speed	Downlink: 150Mbps, Uplink:50Mbps
WLAN	802.11b/g/n
Bluetooth	V2.1+EDR, BLE V4.2
GPS	GPS, A-GPS
FM	Yes
Interface	Micro USB 2.0
Battery	3.85 V  2000 mAh

FCC Compliance	<p>Labeling requirements. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p>
	<p>Changes or modification warning. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>
	<p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p>
	<p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.
	<p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be located or operating in conjunction with any other antenna or transmitter.</p>
	<p>The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).</p>
	<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p>