



# Nokia WiFi Beacon

Beacon 24

## Beacon 24 Product Guide

---

3TN-00540-AAAA-TCZZA  
Issue 1  
December 2023

© 2023 Nokia. Nokia Confidential Information

Use subject to agreed restrictions on disclosure and use.

---

**Legal notice**

Nokia is committed to diversity and inclusion. We are continuously reviewing our customer documentation and consulting with standards bodies to ensure that terminology is inclusive and aligned with the industry. Our future customer documentation will be updated accordingly.

---

This document includes Nokia proprietary and confidential information, which may not be distributed or disclosed to any third parties without the prior written consent of Nokia.

This document is intended for use by Nokia's customers ("You"/"Your") in connection with a product purchased or licensed from any company within Nokia Group of Companies. Use this document as agreed. You agree to notify Nokia of any errors you may find in this document; however, should you elect to use this document for any purpose(s) for which it is not intended, You understand and warrant that any determinations You may make or actions You may take will be based upon Your independent judgment and analysis of the content of this document.

Nokia reserves the right to make changes to this document without notice. At all times, the controlling version is the one available on Nokia's site.

No part of this document may be modified.

NO WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF AVAILABILITY, ACCURACY, RELIABILITY, TITLE, NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS MADE IN RELATION TO THE CONTENT OF THIS DOCUMENT. IN NO EVENT WILL NOKIA BE LIABLE FOR ANY DAMAGES, INCLUDING BUT NOT LIMITED TO SPECIAL, DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL OR ANY LOSSES, SUCH AS BUT NOT LIMITED TO LOSS OF PROFIT, REVENUE, BUSINESS INTERRUPTION, BUSINESS OPPORTUNITY OR DATA THAT MAY ARISE FROM THE USE OF THIS DOCUMENT OR THE INFORMATION IN IT, EVEN IN THE CASE OF ERRORS IN OR OMISSIONS FROM THIS DOCUMENT OR ITS CONTENT.

Copyright and trademark: Nokia is a registered trademark of Nokia Corporation. Other product names mentioned in this document may be trademarks of their respective owners.

© 2023 Nokia.

---

# Contents

<b>About this document</b> .....	<b>13</b>
<b>1 What's new</b> .....	<b>19</b>
1.1 Overview .....	19
1.2 What's new in BBD Release 23.04 .....	19
<b>2 ANSI CPE safety guidelines</b> .....	<b>21</b>
2.1 Overview .....	21
2.2 Safety instructions.....	21
2.3 Safety standards compliance .....	23
2.4 Electrical safety guidelines .....	26
<b>3 ETSI CPE safety guidelines</b> .....	<b>29</b>
3.1 Overview .....	29
3.2 Safety instructions.....	29
3.3 Safety standards compliance .....	30
3.4 Electrical safety guidelines.....	32
<b>4 ETSI environmental and CRoHS guidelines</b> .....	<b>33</b>
4.1 Overview .....	33
4.2 Environmental labels.....	33
4.3 Hazardous Substances Table (HST).....	35
4.4 Other environmental requirements.....	35
<b>5 Beacon 24 unit data sheet</b> .....	<b>37</b>
5.1 Overview .....	37
5.2 Beacon 24 part numbers and identification.....	37
5.3 Beacon 24 general description.....	38
5.4 Beacon 24 software and installation feature support .....	42
5.5 Beacon 24 interfaces and interface capacity .....	42
5.6 Beacon 24 LEDs .....	44
5.7 Beacon 24 detailed specifications .....	45
5.8 Beacon 24 functional blocks .....	46
5.9 Beacon 24 responsible party.....	47
5.10 Beacon 24 special considerations.....	47

---

<b>6</b>	<b>Install or replace a Beacon 24</b> .....	<b>49</b>
6.1	Overview .....	49
6.2	Prerequisites .....	49
6.3	Recommended tools .....	49
6.4	Safety information .....	49
6.5	Install a Beacon 24.....	50
6.6	Replace a Beacon 24.....	52
6.7	Wall mount a Beacon 24 .....	54
<b>7</b>	<b>Configure Beacon 24</b> .....	<b>59</b>
7.1	Overview .....	59
	<b>GUI overview</b> .....	<b>62</b>
7.2	General configuration .....	62
7.3	Logging in to the web-based GUI.....	62
7.4	Beacon 24 WebGUI Menu .....	63
7.5	Viewing overview information.....	64
	<b>WAN Configuration</b> .....	<b>67</b>
7.6	Overview .....	67
7.7	Configuring WAN Services.....	67
7.8	Viewing WAN Statistics .....	72
7.9	Configuring TR-069.....	74
7.10	Configuring TR-369.....	76
7.11	Configuring IP Routing .....	77
7.12	Configuring QoS.....	78
	<b>LAN Configuration</b> .....	<b>81</b>
7.13	Overview .....	81
7.14	Configuring DHCP IPv4.....	81
7.15	Configuring DHCP IPv6.....	83
7.16	Configuring DNS .....	85
7.17	Viewing LAN Statistics .....	88
	<b>WiFi Configuration</b> .....	<b>91</b>
7.18	Overview .....	91
7.19	Configuring WiFi Network .....	91
7.20	Configuring Guest Network.....	97
7.21	Viewing Network Map, Adding WiFi Points, Renaming WiFi Points and Removing WiFi Points .....	98
7.22	Configuring Wireless 2.4 GHz.....	103
7.23	Configuring Wireless (5GHz-Low Band or 5GHz-High Band).....	105

---

7.24	Configuring Wireless 6GHz .....	107
7.25	Viewing WiFi Statistics .....	109
	<b>Devices</b> .....	<b>111</b>
7.26	Overview .....	111
7.27	Viewing Device Information .....	111
	<b>Security Configuration</b> .....	<b>114</b>
7.28	Overview .....	114
7.29	Configuring the Firewall .....	114
7.30	Configuring the MAC Filter .....	115
7.31	Configuring the IP Filter .....	117
7.32	Configuring Family Profiles .....	118
7.33	Configuring DMZ and ALG .....	129
7.34	Configuring Access Control .....	130
	<b>Advanced Settings</b> .....	<b>133</b>
7.35	Overview .....	133
7.36	Configuring Port Forwarding .....	133
7.37	Configuring Port Triggering .....	134
7.38	Configuring DDNS .....	135
7.39	Configuring NTP .....	137
	<b>Maintenance</b> .....	<b>139</b>
7.40	Overview .....	139
7.41	Configuring the Password .....	139
7.42	Backing Up the Configuration .....	141
7.43	Restoring the Configuration .....	141
7.44	Upgrading Firmware .....	142
7.45	Diagnosing WAN Connections .....	144
7.46	Viewing Log Files .....	147
7.47	Viewing Container Management .....	148
	<b>Troubleshooting</b> .....	<b>149</b>
7.48	Troubleshooting counters .....	149
7.49	Viewing Speed Test .....	150



---

## List of tables

Table 2-1	Safety labels.....	22
Table 3-1	Safety labels.....	30
Table 3-2	Safety labels.....	31
Table 5-1	Beacon 24 identification .....	37
Table 5-2	Beacon 24 power supply ordering information.....	38
Table 5-3	Beacon 24 function detail.....	40
Table 5-4	Beacon 24 interface connection capacity.....	42
Table 5-5	Beacon 24 physical connections.....	43
Table 5-6	Beacon 24 LED indications.....	44
Table 5-7	Beacon 24 physical specifications .....	45
Table 5-8	Beacon 24 dimension data specifications.....	45
Table 5-9	Beacon 24 power consumption specifications .....	46
Table 5-10	Beacon 24 environmental specifications.....	46
Table 5-11	Responsible party contact information .....	47
Table 7-1	Beacon 24 WebGUI Menu .....	63
Table 7-2	<i>WAN services</i> parameters .....	70
Table 7-3	<i>WAN services</i> parameters .....	74
Table 7-4	<i>TR-069</i> parameters .....	75
Table 7-5	<i>TR-369</i> parameters .....	76
Table 7-6	<i>IP routing</i> parameters.....	77
Table 7-7	<i>QoS config</i> parameters .....	79
Table 7-8	<i>DHCP IPv4</i> parameters.....	82
Table 7-9	<i>Static DHCP</i> parameters.....	83
Table 7-10	<i>DHCP IPv6</i> parameters.....	84
Table 7-11	<i>DNS</i> parameters .....	87
Table 7-12	<i>LAN statistics</i> parameters .....	90
Table 7-13	<i>Add WiFi network</i> parameters.....	94
Table 7-14	<i>Guest network</i> parameters.....	97
Table 7-15	<i>&lt;Device&gt;</i> parameters.....	101
Table 7-16	<i>Wireless 2.4 GHz</i> parameters .....	104
Table 7-17	<i>Wireless 5 GHz High Band and Low Band</i> parameters .....	107

---

Table 7-18	Wireless 6 GHz .....	108
Table 7-19	Firewall parameters.....	115
Table 7-20	MAC filter - Ethernet Interface parameters.....	116
Table 7-21	MAC filter - WiFi SSID parameters.....	117
Table 7-22	IP filter parameters .....	118
Table 7-23	ALG Configuration parameters .....	130
Table 7-24	DMZ Configuration parameters.....	130
Table 7-25	Access control parameters.....	132
Table 7-26	Trusted Network parameters.....	132
Table 7-27	Port forwarding parameters.....	133
Table 7-28	Port triggering parameters .....	135
Table 7-29	DDNS parameters.....	136
Table 7-30	NTP parameters.....	137
Table 7-31	Change password parameters .....	140
Table 7-32	Diagnostics parameters .....	144
Table 7-33	Log parameters.....	147
Table 7-34	Container management parameters .....	148
Table 7-35	Troubleshooting counters parameters.....	150
Table 7-36	Speed test parameters.....	151



---

## List of figures

Figure 2-1	Sample safety label .....	23
Figure 4-1	Products below MCV value label .....	34
Figure 4-2	Products above MCV value label .....	34
Figure 4-3	Recycling/take back/disposal of product symbol .....	36
Figure 5-1	Beacon 24 WiFi gateway/Beacon .....	39
Figure 5-2	Beacon 24 physical connections .....	43
Figure 5-3	Beacon 24 LEDs.....	44
Figure 5-4	Single-residence WiFi CPE with Gigabit Ethernet.....	47
Figure 6-1	Beacon 24 connections .....	51
Figure 6-2	Beacon 24 connections .....	53
Figure 6-3	Beacon 24 wall mounting bracket.....	55
Figure 6-4	Beacon 24 in wall mount bracket.....	56
Figure 6-5	Beacon 24 wall mount bracket .....	56
Figure 6-6	Beacon 24 to wall mount connection.....	57
Figure 7-1	Login page .....	62
Figure 7-2	Overview table in WAN services page.....	67
Figure 7-3	Create New Connection page .....	68
Figure 7-4	Create New Connection page - PPPoE Configuration .....	69
Figure 7-5	WAN Statistics page .....	72
Figure 7-6	WAN Statistics page info .....	73
Figure 7-7	TR-069 page.....	75
Figure 7-8	TR-369 page.....	76
Figure 7-9	IP routing page .....	77
Figure 7-10	QoS config page (L2 Criteria).....	78
Figure 7-11	QoS config page (L3 Criteria) .....	79
Figure 7-12	DHCP IPv4 page .....	82
Figure 7-13	DHCP IPv6 page .....	84
Figure 7-14	DNS page (IPv4) .....	86
Figure 7-15	DNS page (IPv6) .....	87
Figure 7-16	LAN statistics page.....	89
Figure 7-17	WiFi network page.....	91

---

Figure 7-18	<i>Add WiFi network</i> page.....	93
Figure 7-19	<i>WiFi network - example of SSID Configuration</i> page .....	95
Figure 7-20	<i>Guest network</i> page .....	97
Figure 7-21	<i>Network map</i> page .....	98
Figure 7-22	<i>&lt;Device&gt;</i> page .....	100
Figure 7-23	<i>Change the name of your WiFi point</i> page.....	101
Figure 7-24	<i>Advanced settings - 2.4 GHz</i> tab.....	104
Figure 7-25	<i>Wireless 5 GHz Low Band</i> page.....	106
Figure 7-26	<i>Wireless 5 GHz High Band</i> page .....	106
Figure 7-27	<i>Wireless 6 GHz</i> page.....	108
Figure 7-28	<i>WiFi statistics</i> page.....	109
Figure 7-29	<i>Devices</i> page .....	111
Figure 7-30	<i>Device information</i> page - L3 devices.....	112
Figure 7-31	<i>Device Rename</i> page .....	113
Figure 7-32	<i>Firewall</i> page .....	114
Figure 7-33	<i>MAC filter</i> page .....	116
Figure 7-34	<i>IP filter</i> page.....	117
Figure 7-35	<i>Family profiles (Parental control)</i> page .....	119
Figure 7-36	<i>Add a profile</i> page.....	119
Figure 7-37	<i>Assign devices to family profile</i> .....	120
Figure 7-38	<i>Family profiles table</i> .....	121
Figure 7-39	<i>Family profile configuration</i> page.....	121
Figure 7-40	<i>DMZ and ALG</i> page.....	129
Figure 7-41	<i>Access control</i> page .....	131
Figure 7-42	<i>Port forwarding</i> page .....	133
Figure 7-43	<i>Port triggering</i> page .....	134
Figure 7-44	<i>DDNS</i> page .....	136
Figure 7-45	<i>NTP</i> page .....	137
Figure 7-46	<i>Change password</i> page.....	140
Figure 7-47	<i>Backup and restore</i> page .....	141
Figure 7-48	<i>Backup and restore</i> page .....	142
Figure 7-49	<i>Firmware upgrade</i> page .....	142
Figure 7-50	<i>Example of upgrade status messages</i> .....	143

---

---

Figure 7-51	<i>Diagnostics</i> page .....	144
Figure 7-52	Example of ping results .....	146
Figure 7-53	Example of traceroute results .....	146
Figure 7-54	<i>Log</i> page.....	147
Figure 7-55	<i>Container management</i> page .....	148
Figure 7-56	<i>Troubleshooting counters</i> page .....	149
Figure 7-57	<i>Speed test</i> page .....	151



---

# About this document

## Purpose

This documentation set provides information about safety, features and functionality, ordering, hardware installation and maintenance, and software installation procedures for the current release.

## Intended audience

This documentation set is intended for planners, administrators, operators, and maintenance personnel involved in installing, upgrading, or maintaining the Nokia WiFi Beacon.

The reader must be familiar with general telecommunications principles.

## Safety information

For your safety, this document contains safety statements. Safety statements are given at points where risks of damage to personnel, equipment, and operation may exist. Failure to follow the directions in a safety statement may result in serious consequences.

## Safety Information Examples



### DANGER

#### Hazard

*Danger indicates that the described activity or situation may result in serious personal injury or death; for example, high voltage or electric shock hazards.*



### WARNING

#### Equipment Damage

*Warning indicates that the described activity or situation may, or will, cause equipment damage or serious performance problems.*



### CAUTION

#### Service Disruption

*Caution indicates that the described activity or situation may, or will, cause service interruption.*

**Note:** A note provides information that is, or may be, of special interest.

## Acronyms and initialisms

The expansions and optional descriptions of most acronyms and initialisms appear in the glossary

## Nokia quality processes

Nokia’s WiFi Beacon manufacturing, testing, and inspecting practices are in compliance with TL 9000 requirements. These requirements are documented in the Fixed Networks Quality Manual 3FQ-30146-6000-QRZZA.

The quality practices adequately ensure that technical requirements and customer end-point requirements are met. The customer or its representatives may be allowed to perform on-site quality surveillance audits, as agreed upon during contract negotiations.

## Documents

Documents are available using ALED or OLCS.

## To download a ZIP file package of the customer documentation

- 1 \_\_\_\_\_  
Navigate to <http://customer.nokia.com/s/> and enter your user name and password. If you are a new user and require access to this service, contact your Nokia sales representative.
- 2 \_\_\_\_\_  
Select **Products**.
- 3 \_\_\_\_\_  
Type your product name in the **Find and select a product** field and click the search icon.  
Select a product.
- 4 \_\_\_\_\_  
Click **Downloads: ALED** to go to the Electronic Delivery: Downloads page.
- 5 \_\_\_\_\_  
Select **Documentation** from the list.
- 6 \_\_\_\_\_  
Select a release from the list.
- 7 \_\_\_\_\_  
Follow the on-screen directions to download the file.

**END OF STEPS** \_\_\_\_\_

## To access individual documents

Individual PDFs of customer documents are also accessible through the Nokia Support Portal website.

- 
- 1 \_\_\_\_\_  
Navigate to <http://customer.nokia.com/s/> and enter your user name and password. If you are a new user and require access to this service, contact your Nokia sales representative.
  - 2 \_\_\_\_\_  
Select **Products**.
  - 3 \_\_\_\_\_  
Type your product name in the **Find and select a product** field and click the search icon.  
Select a product.
  - 4 \_\_\_\_\_  
Click **Documentation: Doc Center** to go to the product page in the Doc Center.
  - 5 \_\_\_\_\_  
Select a release from the **Release** list and click **SEARCH**.
  - 6 \_\_\_\_\_  
Click on the PDF icon to open or Save the file.

END OF STEPS \_\_\_\_\_

## Procedures with options or substeps

When there are options in a procedure, they are identified by letters. When there are required substeps in a procedure, they are identified by roman numerals.

### Example of options in a procedure

At [Step 1](#), you can choose option a or b. At [Step 2](#), you must do what the step indicates.

- 1 \_\_\_\_\_  
This step offers two options. You must choose one of the following:
  - a. This is one option.
  - b. This is another option.
- 2 \_\_\_\_\_  
You must perform this step.

END OF STEPS \_\_\_\_\_

### Example of required substeps in a procedure

At [Step 1](#), you must perform a series of substeps within a step. At [Step 2](#), you must do what the step indicates.

**1** \_\_\_\_\_

This step has a series of substeps that you must perform to complete the step. You must perform the following substeps:

- a. This is the first substep.
- b. This is the second substep.
- c. This is the third substep.

**2** \_\_\_\_\_

You must perform this step.

**END OF STEPS** \_\_\_\_\_

### Multiple PDF document search

You can use Adobe Reader Release 6.0 and later to search multiple PDF files for a common term. Adobe Reader displays the results in a single display panel. The results are grouped by PDF file, and you can expand the entry for each file.

**Note:**The PDF files in which you search must be in the same folder.

### To search multiple PDF files for a common term

**1** \_\_\_\_\_

Open Adobe Acrobat Reader.

**2** \_\_\_\_\_

Choose **Edit**→**Search** from the Acrobat Reader main menu. The Search PDF panel displays.

**3** \_\_\_\_\_

Enter the search criteria.

**4** \_\_\_\_\_

Select **All PDF Documents In**.

**5** \_\_\_\_\_

Select the folder in which to search using the drop-down menu.

**6** \_\_\_\_\_

Click **Search**.

Acrobat Reader displays the search results. You can expand the entries for each document by clicking on the + symbol.

**END OF STEPS** \_\_\_\_\_



---

## Technical support

For details, refer to the [Nokia Support portal \(https://customer.nokia.com/support/s/\)](https://customer.nokia.com/support/s/).

For ordering information, contact your Nokia sales representative.

## How to comment

To comment on this document, go to the [Online Comment Form \(https://documentation.nokia.com/comments/\)](https://documentation.nokia.com/comments/) or e-mail your comments to the [Comments Hotline \(mailto:comments@nokia.com\)](mailto:comments@nokia.com).



---

# 1 What's new

## 1.1 Overview

### 1.1.1 Purpose

This chapter provides the details of features and other documentation changes updated in the product guide in each release.

### 1.1.2 Contents

<a href="#">1.1 Overview</a>	19
<a href="#">1.2 What's new in BBD Release 23.04</a>	19

## 1.2 What's new in BBD Release 23.04

The product guide is a new guide in BBD Release 23.04. In future releases, this section will provide tables of the feature and document changes applicable to this guide.



---

## 2 ANSI CPE safety guidelines

### 2.1 Overview

#### 2.1.1 Purpose

This chapter provides information about the mandatory regulations that govern the installation and operation of devices in the North American or ANSI market.

#### 2.1.2 Contents

<a href="#">2.1 Overview</a>	21
<a href="#">2.2 Safety instructions</a>	21
<a href="#">2.3 Safety standards compliance</a>	23
<a href="#">2.4 Electrical safety guidelines</a>	26

### 2.2 Safety instructions

This section describes the safety instructions that are provided in the CPE customer documentation and on the equipment.

#### 2.2.1 Safety instruction boxes in customer documentation

The safety instruction boxes are provided in the CPE customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger box.



*Possibility of personal injury.*

The Danger box indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of the Warning box.



## WARNING

### Equipment Damage

*Possibility of equipment damage.*

*Possibility of data loss.*

The Warning box indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution box.



## CAUTION

### Service Disruption

*Possibility of service interruption.*

*Service interruption.*

The Caution box indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note box.



**Note:** Information of special interest.

The Note box provides information that assists the personnel working with devices. It does not provide safety-related instructions.

## 2.2.2 Safety-related labels

The customer premises equipment is labeled with specific safety compliance information and instructions that are related to a variant of the CPE. Observe the instructions on the safety labels.

[Table 2-1, "Safety labels" \(p. 22\)](#) provides examples of the text in the various CPE safety labels.

*Table 2-1* Safety labels

Label text	Description
ETL compliance	Communication service equipment US listed.
ESD warning	Caution: This assembly contains electrostatic sensitive device.
FCC standards compliance	Tested to comply with FCC standards for home or office use.

[Figure 2-1, "Sample safety label" \(p. 23\)](#) shows a sample safety label located on the bottom of the Beacon 24.

Figure 2-1 Sample safety label



## 2.3 Safety standards compliance

This section describes the CPE compliance with North American safety standards.



### WARNING

#### Equipment Damage

*Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

### 2.3.1 FCC/ISED warning

This section describes the FCC warning.



## WARNING

### Equipment Damage

*FCC regulations restrict the operation of this device to indoor use only.*

*The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet in the 5.925-6.425 GHz band.*

*Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.*

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

### ISED warning

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Les dispositifs fonctionnant dans la bande de 5150 à 5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

1. Operation shall be limited to indoor use only.
2. Operation on oil platforms, automobiles, trains, maritime vessels and aircraft shall be prohibited except for on large aircraft flying above 3,048 m (10,000 ft).
1. leur utilisation doit être limitée à l'intérieur seulement;
2. leur utilisation à bord de plateformes de forage pétrolier, d'automobiles, de trains, de navires maritimes et d'aéronefs doit être interdite, sauf à bord d'un gros aéronef volant à plus de 3 048 m (10 000 pi) d'altitude.

This equipment complies with Innovation, Science and Economic Development Canada RF exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated to ensure a minimum of 31cm spacing to any person at all times.

Cet équipement est conforme aux limites d'exposition RF d'Innovation, Science et Développement économique Canada établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé de manière à assurer un espacement d'au moins 31cm avec toute personne en tout temps.



---

### 2.3.2 EMC, EMI, and ESD standards compliance

The customer premises equipment complies with the following requirements:

- Federal Communications Commission (FCC) CFR 47, Part 15, Subpart B, Class B requirements for equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

### 2.3.3 Energy-related products standby and off modes compliance

Hereby, Nokia declares that the Beacon 24 devices are in compliance with the essential requirements and other relevant provisions of Directive 2009/125/EC together with Commission Regulation (EC) No 1275/2008 and Commission Regulation (EC) No 801/2013.

The Beacon 24 devices qualify as high network availability (HiNA) equipment. Since the main purpose of Beacon 24 devices is to provide network functionality with HiNA 7 days/24 hours, the modes Off/Standby, Power Management, and Networked Standby are inappropriate.

For information about the type and number of network ports, see [5.5 “Beacon 24 interfaces and interface capacity”](#) (p. 42) in [Chapter 5, “Beacon 24 unit data sheet”](#).

For information about power consumption, see [5.7 “Beacon 24 detailed specifications”](#) (p. 45) in [Chapter 5, “Beacon 24 unit data sheet”](#).

### 2.3.4 FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### 2.3.5 FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 31 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.



#### CAUTION

#### Service Disruption

*Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

### 2.3.6 Resistibility requirements compliance

The customer premises equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to overvoltage and overcurrents.

## 2.4 Electrical safety guidelines

This section provides the electrical safety guidelines for the customer premises equipment.

Beacon 24 devices are compliant with the following standards

- IEC-62368-1
- UL-62368-1



**Note:** The devices comply with the U.S. National Electrical Code. However, local electrical authorities have jurisdiction when there are differences between the local and U.S. standards.

---

### 2.4.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

### 2.4.2 Cabling

The following are the guidelines regarding cables used for the customer premises equipment:

- Use only cables approved by the relevant national electrical code.



## 3 ETSI CPE safety guidelines

### 3.1 Overview

#### 3.1.1 Purpose

This chapter provides information about the mandatory regulations that govern the installation and operation of devices.

#### 3.1.2 Contents

3.1 Overview	29
3.2 Safety instructions	29
3.3 Safety standards compliance	30
3.4 Electrical safety guidelines	32

### 3.2 Safety instructions

This section describes the safety instructions that are provided in the CPE customer documentation and on the equipment.

#### 3.2.1 Safety instructions

The safety instructions are provided in the customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger instruction.



*Possibility of personal injury.*

The Danger instruction indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of a Warning instruction.



## WARNING

### Equipment Damage

*Possibility of equipment damage.*

*Possibility of data loss.*

The Warning instruction indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution instruction.



## CAUTION

### Service Disruption

*Possibility of service interruption.*

*Service interruption.*

The Caution instruction indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note instruction.



**Note:** Information of special interest.

The Note box provides information that assists the personnel working with devices. It does not provide safety-related instructions.

### 3.2.2 Safety-related labels

The WiFi Beacon is labeled with the specific safety instructions and compliance information that is related to a variant of the WiFi Beacon. Observe the instructions on the safety labels.

Table 3-1, “Safety labels” (p. 30) provides sample safety labels.

Table 3-1 Safety labels

Label text	Description
CE marking	Indicates compliance to the European Council Directives including EN60950-1 safety
ESD warning	Caution: This assembly contains an electrostatic sensitive device.

## 3.3 Safety standards compliance

This section describes the WiFi Beacon compliance with the European safety standards.

### 3.3.1 EMC, EMI, and ESD compliance

The customer premises equipment complies with the following EMC, EMI, and ESD requirements:

- EN 300-386 V1.6.1: Electromagnetic Compatibility and Radio Spectrum Matters (ERM): Telecommunications Network Equipment; Electromagnetic Compatibility (EMC) requirements; Electrostatic Discharge (ESD) requirements
- EN 301489-1: Electromagnetic Compatibility and Radio Spectrum Matters (ERM): Telecommunications Network Equipment; Electromagnetic Compatibility (EMC) Standard for Radio Equipment and Services; part 1: Common Technical Requirements
- EN 301489-17: Electromagnetic Compatibility and Radio Spectrum Matters (ERM); Electromagnetic Compatibility (EMC) Standard for Radio Equipment; Part 17: Specific Conditions for Broadband Data Transmission Systems.
- Radio Equipment Directive (RED) 2014/53/EU (applicable from 13 June 2016)
- EN 55032 (2015): Electromagnetic compatibility of multimedia equipment - Emission Requirements
- EN 55024 (2010): Information Technology Equipment, Immunity Characteristics, limits and methods of measurement
- Electromagnetic Compatibility (EMC) directive 2014/30/EU
- European Council Directive 2004/108/EC
- Low Voltage (LVD) directive 2014/35/EC

### 3.3.2 Equipment safety standard compliance

The customer premises equipment is labeled with specific safety compliance information and instructions that are related to a variant of the CPE. Observe the instructions on the safety labels.

[Table 3-2, "Safety labels" \(p. 31\)](#) provides examples of the text in the various CPE safety labels.

Table 3-2 Safety labels

Label text	Description
TUV compliance	Type 3R enclosure - Rainproof.
ESD warning	Caution: This assembly contains electrostatic sensitive device.
CDRH compliance	Complies with 21 CFR 1040.10 and 1040.11.
CE marking	There are various CE symbols for CE compliance.
UKCA marking	There is UKCA symbol for UKCA compliance.

The customer premises equipment complies with the requirements of EN 60950-1, Safety of Information Technology Equipment for use in a restricted location.

- ETS 300 019-2-1 Storage Class T1.1
- ETS 300 019-2-2 Transport Class T2.3
- ETS 300 019-2-3 Stationary Class T3.2

---

### 3.3.3 Environmental standard compliance

The customer premises equipment complies with the EN 300 019 European environmental standards.

### 3.3.4 CE RED RF Radiation Exposure Statement

This device complies with CE RED radiation exposure limits set forth for an uncontrolled environment. To comply with CE RED RF exposure compliance requirements, this grant is applicable only for mobile configurations. The antennas used for the transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

### 3.3.5 Resistibility requirements compliance


The customer premises equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to over voltage and overcurrents.

### 3.3.6 Acoustic noise emission standard compliance

The customer premises equipment complies with EN 300 753 acoustic noise emission limit and test methods.

## 3.4 Electrical safety guidelines

This section provides the electrical safety guidelines for the customer premises equipment.

 **Note:** The devices comply with the U.S. National Electrical Code. However, local electrical authorities have jurisdiction when there are differences between the local and U.S. standards. The devices comply with BS EN 61140.

### 3.4.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

### 3.4.2 Cabling

The following are the guidelines regarding cables used for the customer premises equipment:

- All cables must be approved by the relevant national electrical code.



---

## 4 ETSI environmental and CRoHS guidelines

### 4.1 Overview

#### 4.1.1 Purpose

This chapter provides information about the ETSI environmental China Restriction of Hazardous Substances (CRoHS) regulations that govern the installation and operation of devices. This chapter also includes environmental operation parameters of general interest.

#### 4.1.2 Contents

<a href="#">4.1 Overview</a>	33
<a href="#">4.2 Environmental labels</a>	33
<a href="#">4.3 Hazardous Substances Table (HST)</a>	35
<a href="#">4.4 Other environmental requirements</a>	35

### 4.2 Environmental labels

This section describes the environmental instructions that are provided with the customer documentation, equipment, and location where the equipment resides.

#### 4.2.1 Overview

CRoHS is applicable to Electronic Information Products (EIP) manufactured or sold and imported in the territory of the mainland of the People's Republic of China. EIP refers to products and their accessories manufactured by using electronic information technology, including electronic communications products and such subcomponents as batteries and cables.

#### 4.2.2 Environmental labels

Environmental labels are located on appropriate equipment. The following are sample labels.

##### Products below Maximum Concentration Value (MCV) label

[Figure 4-1, "Products below MCV value label"](#) (p. 34) shows the label that indicates a product is below the maximum concentration value, as defined by standard SJ/T11363-2006 (Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products). Products with this label are recyclable. The label may be found in this documentation or on the product.

Figure 4-1 Products below MCV value label



18986

**Products containing hazardous substances above Maximum Concentration Value (MCV) label**

Figure 4-2, “Products above MCV value label” (p. 34) shows the label that indicates a product is above the maximum concentration value, as defined by standard SJ/T11363-2006 (Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products). The number contained inside the label indicates the Environment-Friendly User Period (EFUP) value. The label may be found in this documentation or on the product.

Figure 4-2 Products above MCV value label



18985

---

Together with major international telecommunications equipment companies, Nokia has determined it is appropriate to use an EFUP of 50 years for network infrastructure equipment and an EFUP of 20 years for handsets and accessories. These values are based on manufacturers' extensive practical experience of the design, manufacturing, maintenance, usage conditions, operating environments, and physical condition of infrastructure and handsets after years of service. The values reflect minimum values and refer to products operated according to the intended use conditions. See the following section for more information.

### 4.3 Hazardous Substances Table (HST)

This section describes the compliance of the OLT and CPE to the CRoHS standard when the product and subassemblies contain hazardous substances beyond the MCV value. This information is found in this user documentation where part numbers for the product and subassemblies are listed. It may be referenced in other OLT and CPE documentation.

In accordance with the People's Republic of China Electronic Industry Standard Marking for the Control of Pollution Caused by Electronic Information Products (SJ/T11364-2006), customers may access the Nokia Hazardous Substance Table, in Chinese, from the following location:

- <http://www.nokia-sbell.com/wwwroot/images/upload/private/1/media/ChinaRoHS.pdf>

### 4.4 Other environmental requirements

Observe the following environmental requirements when handling the WiFi Beacon.

#### 4.4.1 WiFi Beacon environmental requirements

See the CPE technical specification documentation for more information about temperature ranges.

#### 4.4.2 Storage

According to ETS 300-019-1-1 - Class 1.1, storage of CPE equipment must be in Class 1.1, weather-protected, temperature-controlled locations.

#### 4.4.3 Transportation

According to EN 300-019-1-2 - Class 2.3, transportation of the equipment must be in packed, public transportation with no rain on packing allowed.

#### 4.4.4 EU RoHS

European Union (EU) Directive 2011/65/EU, "Restriction of the use of certain Hazardous Substances" (RoHS), restricts the use of lead, mercury, cadmium, hexavalent chromium, and certain flame retardants in electrical and electronic equipment. Nokia products shipped to the EU comply with the EU RoHS Directive.

Nokia has implemented a material/substance content management process. The process is described in: Nokia process for ensuring RoHS Compliance (1AA002660031ASZZA). This ensures compliance with the European Union Directive 2011/65/EU on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment.

#### 4.4.5 End-of-life collection and treatment

Electronic products bearing or referencing the symbol shown in the following figure, when put on the market within the European Union (EU), shall be collected and treated at the end of their useful life, in compliance with applicable EU and local legislation. They shall not be disposed of as part of unsorted municipal waste. Due to materials that may be contained in the product, such as heavy metals or batteries, the environment and human health may be negatively impacted as a result of inappropriate disposal.

**i** **Note:** In the European Union, a solid bar under the symbol for a crossed-out wheeled bin indicates that the product was put on the market after 13 August 2005.

Figure 4-3 Recycling/take back/disposal of product symbol



About mark is used in compliance to European Union WEEE Directive (2012/19/EU).

There can be different requirements for collection and treatment in different member states of the European Union.

In compliance with legal requirements and contractual agreements, where applicable, Nokia will offer to provide for the collection and treatment of Nokia products bearing the logo shown in [Figure 4-3, "Recycling/take back/disposal of product symbol" \(p. 36\)](#) at the end of their useful life, or products displaced by Nokia equipment offers. For information regarding take-back of equipment by Nokia, or for more information regarding the requirements for recycling/disposal of product, contact your Nokia account manager or Nokia take back support at [sustainability.global@nokia.com](mailto:sustainability.global@nokia.com).

## 5 Beacon 24 unit data sheet

### 5.1 Overview

#### 5.1.1 Purpose

This chapter describes the Beacon 24 unit data sheet.

#### 5.1.2 Contents

<a href="#">5.1 Overview</a>	37
<a href="#">5.2 Beacon 24 part numbers and identification</a>	37
<a href="#">5.3 Beacon 24 general description</a>	38
<a href="#">5.4 Beacon 24 software and installation feature support</a>	42
<a href="#">5.5 Beacon 24 interfaces and interface capacity</a>	42
<a href="#">5.6 Beacon 24 LEDs</a>	44
<a href="#">5.7 Beacon 24 detailed specifications</a>	45
<a href="#">5.8 Beacon 24 functional blocks</a>	46
<a href="#">5.9 Beacon 24 responsible party</a>	47
<a href="#">5.10 Beacon 24 special considerations</a>	47

### 5.2 Beacon 24 part numbers and identification

[Table 5-1, “Beacon 24 identification” \(p. 37\)](#) provides part numbers and identification information for Beacon 24.

*Table 5-1* Beacon 24 identification

Ordering part number	Provisioning number	Description	CLEC	CPR	ECI/ Bar code
3TN00539AA	3TN00540AA	Beacon 24, US Plug, 10G WAN, 1*10G LAN, 2x2.5G LAN, 4+4+4+4, WiFi7	BVMNW00DRA	—	—
3TN00539AB	3TN00540AB	Beacon 24, Canada/US, US Plug, 10G WAN, 1*10G LAN, 2x2.5G LAN, 4+4+4+4 WiFi7	BVMNX00DRA	—	—
3TN00539CA (Customer-specific variant)	3TN00540CA	Beacon 24, UK plug, 10G WAN, 10G LAN, 2x2.5G LAN, 4+4+ 4+4 WiFi7	—	—	—

[Table 5-2, “Beacon 24 power supply ordering information” \(p. 38\)](#) provides power supply ordering information for Beacon 24.

Table 5-2 Beacon 24 power supply ordering information

Ordering part number	Manufacturer	Applicable power supply model	Power information	Compliance detail	Notes
Kit: 3TN00539AA EMA: 3TN00540AA	MOSO	MS-V4000R120-050A0-US/SC338-U0	12V 4A wall mounted DC power adapter	ANSI municipality US, FCC/ETL	2-pin US input plug
	SOY	SOY-1200400US-433/BC120400-UC6A-LL01	12V 4A wall mounted DC power adapter		
Kit: 3TN00539AB EMA: 3TN00540AB	MOSO	MS-V4000R120-050A0-US/SC338-U0	12V 4A wall mounted DC power adapter	ANSI municipality US, Canada	2-pin US input plug
	SOY	SOY-1200400US-433/BC120400-UC6A-LL01	12V 4A wall mounted DC power adapter		
Kit: 3TN00539CA EMA: 3TN00540CA	MOSO	MS-V4000R120-050A0-GB/SC338-B0	12V 4A wall mounted DC power adapter	UK, CE certified	3-pin UK input plug
	SOY	SOY-1200400GB-433/BC120400-YD6A-LL01	12V 4A wall mounted DC power adapter		

### 5.3 Beacon 24 general description

WiFi is abundantly deployed in home networks. Users crave a seamless experience at home including effortlessly connecting their wireless devices to the network. Traditional WiFi networks require unique SSIDs for each of the access points or tedious set-up of WiFi extenders, which complicate the user experience. The Nokia WiFi network simplifies the user experience by providing a seamless mesh network with easy device onboarding and automated network optimization.

The overall Nokia WiFi solution is composed of one Nokia WiFi gateway (or Nokia WiFi Beacon) as root AP, one or more Nokia WiFi Beacons, the Nokia WiFi Care Portal for the operator’s customer care team, and a mobile application for the end-user’s self care.

**i Note:** The Nokia WiFi Care Portal can be accessed by the end user and the operator.

Beacon 24 can be deployed as either an Ethernet residential gateway or a WiFi Beacon in the Nokia WiFi solution. The residential gateway is the central point of the mesh network providing access to the broadband network (Internet) while the Beacon aids with extending the WiFi coverage to every corner of the home, providing seamless roaming to wireless connected devices.

The Beacon 24 has built-in concurrent quadband Wi-Fi 802.11 be networking with triple-play capability. Beacon 24 devices can be configured using the Nokia WiFi Mobile App, which can be downloaded on both iOS and Android devices.

The following figure shows the Beacon 24:

Figure 5-1 Beacon 24 WiFi gateway/Beacon



38917

The Beacon 24 provides the following functions and benefits:

- Quad-band WiFi7: concurrent IEEE802.11b/g/n/ax/be 4x4 2.4GHz, IEEE802.11a/n/ac/ax/be 4x4 5GHz low, IEEE802.11a/n/ac/ax/be 4x4 5GHz high, IEEE802.11ax/be 4x4 6GHz
- Automatically decide on wireless router mode and Beacon mode in a mesh network
- One 10Gbase-T interface with RJ-45 connector for WAN, one 10Gbase-T and two 2.5Gbase-T interfaces with RJ-45 connectors for LAN
- Nokia intelligent EasyMesh
- Embedded edge analytics optimize network performance in real-time

Benefits:

- Latest Wi-Fi 7 technology that supports MLO operation allowing of up to 3 radio links to be assigned to a client enabling both higher speeds and lower latencies. An MLO link with 5GHz High + 5GHz Low + 6 GHz can provide a maximum PHY rate of 23 Gbps
- Additional features supported: Multiple RUs (MRU) per STA operation to avoid interference and increase efficiency, Static Puncturing to increase spectrum efficiency, 320 MHz bandwidth in 6GHz radio, Higher efficiency with 4K QAM waveform, Ready to support AFC
- PHY rate up to 1376 Mb/s for 2.4 GHz, 5765 Mb/s for 5GHz low/5GHz high and 11529 Mb/s for 6GHz
- Improves connection speeds throughout the home and provides WiFi where typically there would be none
- Better mesh performance by using 4x4 5GHz High band and 4x4 6GHz band as MLO
- Client steering, channel optimization

- Real-time wireless spectrum scan and analysis
- High quality of service (QoS) video over WiFi
- Ease of setup and user intuitive information

The table below lists additional function detail:

Table 5-3 Beacon 24 function detail

Function	Detail
Installation	Desk and wall mounted
Interfaces	<ul style="list-style-type: none"> <li>• One RJ45 2.5 Gigabit Ethernet LAN port and 2 RJ45 Gigabit Ethernet LAN ports</li> <li>• Supports 4x4 802.11b/g/n/ax/be 2.4 GHz wireless LAN (WLAN) interface</li> <li>• Supports 4x4 802.11a/n/ac/ax/be 5 GHz wireless LAN (WLAN) interface</li> <li>• Supports 4x4 802.11ax/be 6 GHz wireless LAN (WLAN) interface</li> <li>• Maximum Effective Isotropic Radiated Power (EIRP) on 2.4 GHz up to 800 mW, 5 GHz up to 1300 mW, and 6 GHz up to 300 mW</li> <li>• WPA support including WPA2 and WPA3 Personal encryption</li> <li>• Nokia Design for Security (DFSEC) requirement compliant</li> <li>• 64-bit and 128-bit Wired Equivalent Privacy (WEP) support</li> </ul>
Router mode	<ul style="list-style-type: none"> <li>• IPv4 and IPv6</li> <li>• Point-to-Point Protocol over Ethernet (PPPoE) and IP over Ethernet (IPoE)</li> <li>• Network Address Translation (NAT), demilitarized zone (DMZ) and firewall</li> <li>• Dynamic Host Configuration Protocol (DHCP) and domain name system (DNS) proxy</li> <li>• Internet Group Management Protocol (IGMP) v2/v3</li> <li>• LXC container and TR157 Software module management</li> <li>• Supports TR-069 with TR-181 datamodel. Supports USP/TR-369</li> <li>• Supports virtual private network (VPN) pass-through for Point-to-Point Tunneling protocol (PPTP), Layer 2 Tunneling Protocol (L2TP) and IPSec</li> <li>• Port forwarding and DMZ/dynamic domain name system (DDNS)</li> <li>• Flexible video delivery options over Ethernet or wireless</li> <li>• Nokia WiFi mesh middleware</li> </ul>
Beacon mode	<ul style="list-style-type: none"> <li>• Supports IPv4</li> <li>• Supports TR-069 with TR-181 datamodel. Supports USP/TR-369</li> <li>• Supports VPN pass-through for PPTP, L2TP and IPSec</li> <li>• IGMP v2/v3 snooping</li> <li>• Flexible video delivery options over Ethernet or wireless</li> <li>• Nokia WiFi mesh middleware</li> </ul>
LED	<ul style="list-style-type: none"> <li>• Single multi-color LED for simple and intuitive status indication</li> </ul>



Table 5-3 Beacon 24 function detail (continued)

Function	Detail
Regulatory compliance	<ul style="list-style-type: none"> <li>• ETL</li> <li>• FCC Part 15</li> <li>• ISED</li> </ul>

### 5.3.1 TR-069 object support for WiFi parameters

The Beacon 24 supports the status retrieval and configuration of the following WiFi parameters via TR-069:

- Channel
- SSID
- Password for WPA and WEP
- Tx power (transmission rate in dBm)

These are the same TR-069 object parameters that are supported in the GUI.

### 5.3.2 Communication method to Nokia cloud management solution

The Beacon 24 communicates to the Nokia cloud management solution through MQTT and https.

The supported mechanism is specific to a customer deployment and the detailed description is available in the Customer Release Notes (CRN) of each release.

### 5.3.3 TR-157 Software Module Managements

Beacon 24 can support LXC container for third party software components. Life cycle of these software components are managed by ACS with the parameters defined in TR-157.

The TR-157 objects are:

- Mange each software component via SoftwareModules.DeploymentUnit.
- Set software component execution environment via SoftwareModules.ExecEnv.
- Run software component and get the execution status via SoftwareModules.ExecutionUnit.

**i** **Note:** The available memory for third party applications needs a detailed study, considering the actual memory load of the current hardware, software, Beacon software evolution over long time and the projected use by a third party application of the software. Therefore, Nokia suggests to review this case by case. Contact your Nokia support representative for more information.

### 5.3.4 TR-069 authentication using TLS and CA certificates

Beacon 24 devices support encrypted remote TR-069 management using TLS, as well as ACS authentication using SHA-256 pre-installed certificates.

If the ACS URL is set to the https://... format, by default, the connection will use TLS without authentication mode. The Beacon 24 can also authenticate the ACS using a pre-installed CA certificate.

## 5.4 Beacon 24 software and installation feature support

For information on installing or replacing the Beacon 24, see [Chapter 6, “Install or replace a Beacon 24”](#).

## 5.5 Beacon 24 interfaces and interface capacity

The table below describes the supported interfaces and interface capacity for Beacon 24 devices.


Table 5-4 Beacon 24 interface connection capacity

Device type and model	Maximum capacity							
	POTS	100/ 10 BASE-T	RF video (CATV)	10GE WAN	2.5GE LAN	10GE LAN	Local craft	USB3. 1(gen1)
Beacon 24	—	—	—	1	2	1	—	—

### 5.5.1 Beacon 24 connections and components

[Figure 5-2, “Beacon 24 physical connections” \(p. 43\)](#) shows the physical connections for Beacon 24.

Figure 5-2 Beacon 24 physical connections



38919

The table below describes the physical connections for Beacon 24 devices.

Table 5-5 Beacon 24 physical connections

Connection	Description
On/Off button	This button powers the unit on or off.
LAN 1/ LAN 2/ LAN 3	This connection is provided through Ethernet RJ-45 connectors. Up to two 1000M/100M/10M Base-T LAN interface and one 10M/100M /1G/2.5G Base-T LAN interface with RJ45 connector are supported. The Ethernet ports can support both data and in-band video services on all three interfaces.
WAN port	This connection is provided through an 10GE interface.
WPS ON/Off button	This button is used to start the WiFi Protected Setup (WPS) for new WiFi devices.
Reset button	Pressing the Reset button for less than 10 seconds reboots the Beacon; pressing the Reset button for 10 seconds or more restores the Beacon to its factory defaults.

Table 5-5 Beacon 24 physical connections (continued)

Connection	Description
Power input	This connection is provided through the power connector. A power cable fitted with a barrel connector is used to make the connection.

## 5.6 Beacon 24 LEDs

The front of the Beacon 24 functions as a multi-color LED indicator. The LED color and pulse rate acts as a signal to the home user, which indicates the state of the Beacon 24 and the quality of its backhaul link.

Figure 5-3 Beacon 24 LEDs



38917

Table 5-6, “Beacon 24 LED indications” (p. 44) provides LED descriptions for the Beacon 24.

Table 5-6 Beacon 24 LED indications

LED color	LED behavior	Router mode	Extender mode	LED behavior description
Off	Off	✓	✓	Power off.
Blue-Green	Solid	✓		Good backhaul connection to the Internet.
	Solid		✓	Good backhaul connection. A link to the next node is available.

Table 5-6 Beacon 24 LED indications (continued)

LED color	LED behavior	Router mode	Extender mode	LED behavior description
Yellow	Solid		✓	Backhaul connection is successful but not optimal. A link to the next node is below standard
	Slow pulsing	✓	✓	Configuration mode. The unit is waiting to be configured.
Red	Solid	✓		No connection to the Internet
	Solid		✓	Backhaul connection is successful but not optimal. A link to the next node is not operational.
	Fast pulsing	✓	✓	Factory reset.
White	Slow pulsing	✓	✓	WPS enabled.
	Solid	✓	✓	Powering on.
	3 sec quick pulse	✓	✓	WPS successful.

## 5.7 Beacon 24 detailed specifications

The table below lists the physical specifications for the Beacon 24.

Table 5-7 Beacon 24 physical specifications

Description	Specification
Length	142 mm (5.59 in.)
Width	142 mm (5.59 in.)
Height	249 mm (9.80 in.)
Weight [within ± 0.5 lb (0.23 kg)]	1650g (3.63 lb)

[Table 5-8, “Beacon 24 dimension data specifications” \(p. 45\)](#) lists the dimension data specifications for Beacon 24.

Table 5-8 Beacon 24 dimension data specifications

Dimension	Specification
Packet size supported	1518
Number of IP addresses supported (or ranges)	In LAN network, the supported range is: <ul style="list-style-type: none"> <li>• IPv4: 253 (support the IPv4 private network IP ranges)</li> <li>• IPv6: any allocated Global Unicast Addresses (GUA)</li> </ul>
Number of supported WiFi clients (per radio, per device, per mesh)	128 per radio, 128 per device, 256 per mesh
Number of supported beacons /APs in a mesh	4 (including root AP)

Table 5-8 Beacon 24 dimension data specifications (continued)

Dimension	Specification
Number of supported WAN interfaces	8
Number of supported VLANs	2-4094
Number of LLIDs in the device	-
Number of priority queues, and overall buffer size	LAN port queues: 8; total buffer: 4MB WAN port queues: 8; total buffer: 4MB
Number of multicast groups (DAACL entries)	1024

Table 5-9, “Beacon 24 power consumption specifications” (p. 46) lists the power consumption specifications for the Beacon 24.

Table 5-9 Beacon 24 power consumption specifications

Maximum power (Not to exceed)	Condition	Minimum power	Condition
48W	1-port 10G and 2-port 2.5G ethernet ports	17W	Interfaces/services not provisioned

Table 5-10, “Beacon 24 environmental specifications” (p. 46) lists the environmental specifications for Beacon 24.

Table 5-10 Beacon 24 environmental specifications


Mounting method	Temperature range and humidity	Altitude
On desk or shelf	Operating: -5°C to 45°C (23°F to 113°F) ambient temperature 95% relative humidity, non-condensing at 40°C	Contact your Nokia technical support representative for more information
	Storage: -20°C to 70°C (-68°F to 185°F)	

## 5.8 Beacon 24 functional blocks

Beacon 24 devices are single-residence units that support Wireless (WiFi) service. WiFi service on these devices is compliant with the IEEE 802.11 standard. In addition to the WiFi service, these devices transmit Ethernet packets to three RJ-45 Ethernet ports.

Figure 5-4, “Single-residence WiFi CPE with Gigabit Ethernet” (p. 47) shows the functional blocks for the Beacon 24.

Figure 5-4 Single-residence WiFi CPE with Gigabit Ethernet



38944

## 5.9 Beacon 24 responsible party

Table 5-11, “Responsible party contact information” (p. 47) lists the party in the US responsible for this device.

Table 5-11 Responsible party contact information

Legal Company name	Nokia Solutions and Networks OY	Nokia of America Corporation
Offices	<a href="https://www.nokia.com/contact-us/offices/#north-america">Offices   Nokia (https://www.nokia.com/contact-us/offices/#north-america)</a>	
Support	<a href="https://www.nokia.com/networks/business-support/">Business Support   Nokia (https://www.nokia.com/networks/business-support/)</a>	
Other contacts	<a href="https://www.nokia.com/contact-us/">Contact us   Nokia (https://www.nokia.com/contact-us/)</a>	

## 5.10 Beacon 24 special considerations

This section describes the special considerations for Beacon 24 devices.

---

### 5.10.1 WiFi service

Beacon 24 devices feature WiFi service as well as data services. WiFi is a wireless networking technology that uses radio waves to provide wireless HSI and network connections. This device complies with the IEEE 802.11 standards, which the WiFi Alliance defines as the basis for WiFi technology.

#### WiFi standards and certifications

The WiFi service on Beacon 24 devices supports the following IEEE standards and Wi-Fi Alliance certifications (WFA100049 for 2x2, WFA100571 for 4x4):

- Compliant with IEEE 802.11 standards
- Certified for Wi-Fi6
- Certified for IEEE 802.11b,g,n,ac
- Certified for WPA™ – Enterprise, Personal
- Certified for WPA2™ – Enterprise, Personal
- Certified for WPA3™ – Enterprise, Personal (Aug 2019)
- Certified for Protected Management Frames
- Certified for Wi-Fi Agile Multiband™, WMM®, WMM®-Power Save, Wi-Fi Protected Setup™

#### Nokia WiFi app configuration

The Nokia WiFi mobile app can be used to set up the Beacon 24 and manage the network.

It can be downloaded from the App Store for iOS (<https://apps.apple.com/us/app/nokia-wifi/id1345278192>) and the Google Play store for Android (<https://play.google.com/store/apps/details?id=com.nokia.wifi>).

Information about the Nokia WiFi app can be found on the Nokia WiFi Help Center <https://wifi-helpcenter.nokia.com>

#### WiFi GUI features

Beacon 24 devices have HTML-based WiFi configuration GUIs.

### 5.10.2 Beacon 24 considerations and limitations

For details about the considerations and limitations, see the CRN (Customer Release Notes).



---

## 6 Install or replace a Beacon 24

### 6.1 Overview

#### 6.1.1 Purpose

This chapter provides the steps to:

- Install a Beacon 24
- Replace a Beacon 24

#### 6.1.2 Contents

<a href="#">6.1 Overview</a>	49
<a href="#">6.2 Prerequisites</a>	49
<a href="#">6.3 Recommended tools</a>	49
<a href="#">6.4 Safety information</a>	49
<a href="#">6.5 Install a Beacon 24</a>	50
<a href="#">6.6 Replace a Beacon 24</a>	52
<a href="#">6.7 Wall mount a Beacon 24</a>	54

### 6.2 Prerequisites

Ensure that you have all required cables.

### 6.3 Recommended tools

You need the following tools:

- RJ-45 cable
- Paper clip

### 6.4 Safety information

Read the following safety information before installing the unit.



## DANGER

### Hazard

*Hazardous electrical voltages and currents can cause serious physical harm or death. Always use insulated tools and follow proper safety precautions when connecting or disconnecting power circuits.*

*Make sure all sources of power are turned off and have no live voltages present on feed lines or terminals. Use a voltmeter to measure for voltage before proceeding.*

*Always contact the local utility company before connecting the enclosure to the utilities.*



## CAUTION

### Service Disruption

*Keep indoor devices out of direct sunlight. Prolonged exposure to direct sunlight can damage the unit.*



**Note:** Observe the local and national laws and regulations that may be applicable to this installation.

Observe the following:

- The device should be installed in accordance with the applicable requirements of the NEC or CEC. Local authorities and practices take precedent when there is conflict between the local standard and the NEC or CEC.
- The device must be installed by qualified service personnel.
- Indoor units must be installed with cables that are suitably rated and listed for indoor use.
- See the detailed specifications in the [Chapter 5, "Beacon 24 unit data sheet"](#) for the temperature ranges for these devices.

## 6.5 Install a Beacon 24

1

---

Place the unit on a flat surface, such as a desk or shelf.



**Note:** The Beacon 24 cannot be stacked with another or with other equipment. The installation requirements are:


- Allow a minimum 100 mm clearance above the top cover.
- Allow a minimum 50 mm clearance from the side vents.
- Do not place any heat source directly above the top cover or below the bottom cover.

2

---

Review the connection locations, as shown in [Figure 6-1, "Beacon 24 connections"](#) (p. 51).

Figure 6-1 Beacon 24 connections



38919

3 \_\_\_\_\_  
Connect the Ethernet cables to the RJ-45 ports; see [Figure 6-1, “Beacon 24 connections” \(p. 51\)](#) for the location of the RJ-45 ports.

4 \_\_\_\_\_  
Connect the WAN cable to the RJ-45 WAN port; see [Figure 6-1, “Beacon 24 connections” \(p. 51\)](#) for the location of the RJ-45 WAN port.

5 \_\_\_\_\_  
Connect the power cable to the power connector.

**i** **Note:** Units must be powered by a Listed or CE approved and marked limited power source power supply with a minimum output rate of 12 V dc, 4 A. The polarity of the power adapter plug must match the Beacon 24.


---

6 \_\_\_\_\_  
Power up the unit by using the On/Off power switch.

7 \_\_\_\_\_  
Verify the LED and voltage status.

8 \_\_\_\_\_  
Activate and test the services.

9 \_\_\_\_\_  
If necessary, reset the Beacon 24.

 **Note:** Resetting the device will return all settings to factory default values; any configuration customization will be lost.


- a. Locate the **Reset** button as shown in [Figure 6-1, “Beacon 24 connections” \(p. 51\)](#).
- b. Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the device.

END OF STEPS \_\_\_\_\_

## 6.6 Replace a Beacon 24

1 \_\_\_\_\_  
Power down the unit by using the on/off power switch. See [Figure 6-2, “Beacon 24 connections” \(p. 51\)](#) for the connections on the Beacon 24.

Figure 6-2 Beacon 24 connections



38919

- 2 \_\_\_\_\_  
Disconnect the WAN, Ethernet, and power cables from the Beacon 24; see [Figure 6-2, “Beacon 24 connections”](#) (p. 53) for the connector locations on the Beacon 24.
- 3 \_\_\_\_\_  
Replace the Beacon 24 with the new device. The device can be placed on any flat surface, such as a desk or shelf.
- 4 \_\_\_\_\_  
Connect the Ethernet cables directly to the RJ-45 ports; see [Figure 6-2, “Beacon 24 connections”](#) (p. 53) for the location of the RJ-45 ports.

---

5 \_\_\_\_\_  
Connect the WAN cable directly to the RJ-45 port; see [Figure 6-2, “Beacon 24 connections” \(p. 53\)](#) for the location of the RJ-45 WAN port.

6 \_\_\_\_\_  
Connect the power cable to the power connector.

**i** **Note:** Units must be powered by a Listed or CE approved and marked limited power source power supply with a minimum output rate of 12 V dc, 4 A. The polarity of the power adapter plug must match the Beacon 24.

7 \_\_\_\_\_  
Power up the unit by using the On/Off power button.

8 \_\_\_\_\_  
Verify the LED and voltage status.

9 \_\_\_\_\_  
Activate and test the services.

10 \_\_\_\_\_  
If necessary, reset the Beacon 24.

**i** **Note:** Resetting the device will return all settings to factory default values; any configuration customization will be lost.

- a. Locate the Reset button on a Beacon 24 as shown in [Figure 6-2, “Beacon 24 connections” \(p. 53\)](#).
- b. Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the device.


END OF STEPS \_\_\_\_\_

## 6.7 Wall mount a Beacon 24

This section provides the steps to mount a Beacon 24.

---

Figure 6-3 Beacon 24 wall mounting bracket



38921

### 6.7.1 Procedure


Use this procedure to mount a Beacon 24 on a wall.

1

---

You can wall mount the Beacon 24 as shown in [Figure 6-4, “Beacon 24 in wall mount bracket”](#) (p. 56).

Figure 6-4 Beacon 24 in wall mount bracket




38921

2

Mount the Beacon 24 on a wall using the wall mount bracket as shown in [Figure 6-5, "Beacon 24 wall mount bracket"](#) (p. 56).

Figure 6-5 Beacon 24 wall mount bracket




38920



- a. Determine the location of the two anchor holes for the wall mount bracket. The bracket can be used as a template for marking and drilling the holes.  
It is recommended to use a level to ensure that the ONT unit is installed horizontally.
- b. Drill two holes into the wall and with the centers spaced 65 mm.
- c. Insert the two mounting screws and optional anchors into the holes.
- d. At this point, perform a test to ensure that the wall mount bracket fits securely over the screw heads. Mount the bracket flush to the wall so that it does not warp or twist.
- e. Install the Beacon 24 onto the wall mount bracket by placing the unit on the edge of the bracket and drill it in place with a screw from below to mount tightly. See [Figure 6-6, "Beacon 24 to wall mount connection" \(p. 56\)](#).

Figure 6-6 Beacon 24 to wall mount connection



38931

- f. Connect the power cord and other cables to the Beacon 24.

END OF STEPS



---

# 7 Configure Beacon 24

## 7.1 Overview

### 7.1.1 Purpose

This chapter describes the WebGUI configuration procedures.

### 7.1.2 Contents

7.1 Overview	59
<b>GUI overview</b>	62
7.2 General configuration	62
7.3 Logging in to the web-based GUI	62
7.4 Beacon 24 WebGUI Menu	63
7.5 Viewing overview information	64
<b>WAN Configuration</b>	67
7.6 Overview	67
7.7 Configuring WAN Services	67
7.8 Viewing WAN Statistics	72
7.9 Configuring TR-069	74
7.10 Configuring TR-369	76
7.11 Configuring IP Routing	77
7.12 Configuring QoS	78
<b>LAN Configuration</b>	81
7.13 Overview	81
7.14 Configuring DHCP IPv4	81
7.15 Configuring DHCP IPv6	83
7.16 Configuring DNS	85
7.17 Viewing LAN Statistics	88
<b>WiFi Configuration</b>	91
7.18 Overview	91
7.19 Configuring WiFi Network	91

7.20 Configuring Guest Network	97
7.21 Viewing Network Map, Adding WiFi Points, Renaming WiFi Points and Removing WiFi Points	98
7.22 Configuring Wireless 2.4 GHz	103
7.23 Configuring Wireless (5GHz-Low Band or 5GHz-High Band)	105
7.24 Configuring Wireless 6GHz	107
7.25 Viewing WiFi Statistics	109
<b>Devices</b>	111
7.26 Overview	111
7.27 Viewing Device Information	111
<b>Security Configuration</b>	114
7.28 Overview	114
7.29 Configuring the Firewall	114
7.30 Configuring the MAC Filter	115
7.31 Configuring the IP Filter	117
7.32 Configuring Family Profiles	118
7.33 Configuring DMZ and ALG	129
7.34 Configuring Access Control	130
<b>Advanced Settings</b>	133
7.35 Overview	133
7.36 Configuring Port Forwarding	133
7.37 Configuring Port Triggering	134
7.38 Configuring DDNS	135
7.39 Configuring NTP	137
<b>Maintenance</b>	139
7.40 Overview	139
7.41 Configuring the Password	139
7.42 Backing Up the Configuration	141
7.43 Restoring the Configuration	141
7.44 Upgrading Firmware	142
7.45 Diagnosing WAN Connections	144

---

7.46 Viewing Log Files	147
7.47 Viewing Container Management	148
<b>Troubleshooting</b>	149
7.48 Troubleshooting counters	149
7.49 Viewing Speed Test	150

---

## GUI overview

This section provides an overview of the Beacon 24 WebGUI.

### 7.2 General configuration


For HTTP/ HTTPS configuration procedures, refer to the **Nokia ONT Configuration, Management, and Troubleshooting Guide**.

### 7.3 Logging in to the web-based GUI

1

Open a web browser and enter the IP address of the Beacon in the address bar.  
The *Login* page displays.

Figure 7-1 Login page



The default gateway IP address must be same as the one printed on the device label. You can connect to this IP address using your web browser after connecting your PC to one of Ethernet ports of the Beacon. The static IP address of your PC must be in the same default gateway subnet as the Beacon.

2



#### CAUTION

#### Service Disruption

*If you forget the current username and password, press the **Reset** button for 10 seconds to reset the values to the default username and password provided at startup.*

*Pressing the **Reset** button for less than 10 seconds reboots the device.*

*Pressing the **Reset** button for 10 seconds resets the device to the factory defaults.*

Enter your username and password in the *Login* page, as shown in [Figure 7-1, “Login page” \(p. 62\)](#).


The superadmin account is meant for the operator and the password is unique per device unless specified differently in customer specific pre configuration. Contact your Nokia representative to obtain the superadmin password for device.

The default end-user account name and the default password for this account are printed on the device label.

The superadmin user has access to all WebGUI features while the end-user account has only limited access to WebGUI features. This access for the end-user can be adapted with a WebGUI configuration file. Contact your Nokia representative to know the factory default settings of which WebGUI access is available to your end user or how to get a WebGUI configuration file.

**3**

Click **Sign in**. The *Overview* page displays.

 **Note:** To help protect the security of your Internet connection, the application displays a pop-up reminder to change both the WiFi password and the Beacon password. To increase password security, use a minimum of 10 characters, consisting of a mix of numbers and upper and lower case letters.

END OF STEPS

## 7.4 Beacon 24 WebGUI Menu

The following table lists the main menu and sub-menu options in the Beacon 24 WebGUI:

Table 7-1 Beacon 24 WebGUI Menu

Main Menu	Sub-menu	Procedure Reference
Overview	-	<a href="#">7.5 “Viewing overview information” (p. 64)</a>
WAN	WAN services	<a href="#">7.7 “Configuring WAN Services” (p. 67)</a>
WAN	WAN statistics	<a href="#">7.8 “Viewing WAN Statistics” (p. 72)</a>
WAN	TR-069	<a href="#">7.9 “Configuring TR-069” (p. 74)</a>
WAN	TR-369	<a href="#">7.10 “Configuring TR-369” (p. 76)</a>
WAN	IP routing	<a href="#">7.11 “Configuring IP Routing” (p. 77)</a>
WAN	Qos config	<a href="#">7.12 “Configuring QoS” (p. 78)</a>
LAN	DHCP IPv4	<a href="#">7.14 “Configuring DHCP IPv4” (p. 81)</a>
LAN	DHCP IPv6	<a href="#">7.15 “Configuring DHCP IPv6” (p. 83)</a>
LAN	DNS	<a href="#">7.16 “Configuring DNS” (p. 85)</a>
LAN	LAN statistics	<a href="#">7.17 “Viewing LAN Statistics” (p. 88)</a>
WiFi	WiFi networks	<a href="#">7.19 “Configuring WiFi Network” (p. 91)</a>

Table 7-1 Beacon 24 WebGUI Menu (continued)


Main Menu	Sub-menu	Procedure Reference
WiFi	Guest network	7.20 "Configuring Guest Network" (p. 97)
WiFi	Network map	7.21 "Viewing Network Map, Adding WiFi Points, Renaming WiFi Points and Removing WiFi Points" (p. 98)
WiFi	Advanced settings	7.22 "Configuring Wireless 2.4 GHz" (p. 103)
WiFi	WiFi statistics	7.25 "Viewing WiFi Statistics" (p. 109)
Devices	-	7.27 "Viewing Device Information" (p. 111)
Security	Firewall	7.29 "Configuring the Firewall" (p. 114)
Security	MAC filter	7.30 "Configuring the MAC Filter" (p. 115)
Security	IP filter	7.31 "Configuring the IP Filter" (p. 117)
Security	Family profiles	7.32 "Configuring Family Profiles" (p. 118)
Security	DMZ and ALG	7.33 "Configuring DMZ and ALG" (p. 129)
Security	Access control	7.34 "Configuring Access Control" (p. 130)
Advanced settings	Port forwarding	7.36 "Configuring Port Forwarding" (p. 133)
Advanced settings	Port triggering	7.37 "Configuring Port Triggering" (p. 134)
Advanced settings	DDNS	7.38 "Configuring DDNS" (p. 135)
Advanced settings	NTP	7.39 "Configuring NTP" (p. 137)
Maintenance	Change password	7.41 "Configuring the Password" (p. 139)
Maintenance	Backup and restore	7.42 "Backing Up the Configuration" (p. 141) 7.43 "Restoring the Configuration" (p. 141)
Maintenance	Firmware upgrade	7.44 "Upgrading Firmware" (p. 142)
Maintenance	Diagnostics	7.45 "Diagnosing WAN Connections" (p. 144)
Maintenance	Log	7.46 "Viewing Log Files" (p. 147)
Maintenance	Container management	7.47 "Viewing Container Management" (p. 148)
Troubleshooting	Troubleshooting counters	7.48 "Troubleshooting counters" (p. 149)
Troubleshooting	Speed test	7.49 "Viewing Speed Test" (p. 150)

## 7.5 Viewing overview information

1

Click **Overview** from the left pane. The Overview page displays the following cards:





END OF STEPS

### 7.5.1 Network Map

Displays information about the status of the mesh network and connection to the internet. The status of the internet connection is defined by the presence of an IP address on the internet service. *Up* is indicated with green and *Down* is indicated with red.

#### Root device

Displays the mnemonic of the device. The colored indicator as well as the status under the name reflects the physical status of the WAN connection (4G/5G, PON port, WAN port). *Up* is Green, *Down* is Red.

#### Extender device

Displays the mnemonic of the device. The colored indicator as well as the status under the name reflects the physical status of the backhaul connection (Strong Signal = Green, Poor Signal = Amber, Not connected = red).

### 7.5.2 Radio Access

Displays the 4G, 5G or 6G signal connection status when a device is connected to an FWA receiver. Click the button to view the connection details.

---

### 7.5.3 Service Status

Displays the active status of the triple-play services.

#### Internet service

The internet service represents the presence of a WAN IP address for the routed network that has the internet attached to it. The card shows the WAN IP address (IPv4 and/or IPv6).

#### IPTV service

Shows the status of the IPTV service. If the IPTV flag is enabled on a routed service, the online or offline state is indicated by the presence of a WAN IP address for that routed service. If the IPTV is attached to a bridged service, the online or offline state is defined by the WAN uplink status.

### 7.5.4 WiFi Networks

Displays a network card per activated single or dual band WiFi network containing the bands supported, the name of the network and the type of network (bridge or routed).

### 7.5.5 Connected Clients

Displays the total number of online and offline clients connected to this device (single device or mesh system).

### 7.5.6 LAN Interface Status

Displays information about all the LAN ports of the device.

#### WiFi 2.4GHz

Shows the status of the 2.4GHz (Up/Down) network and the current band setting. This can either be auto which indicates Radio Resource Management is enabled or in the range 1-13 when manually configured.

#### WiFi 5GHz low

Shows the status of the 5GHz low network (Up/Down) and the current band setting. This can either be auto which indicates Radio Resource Management is enabled or is in the range 36-64 when manually configured.

#### WiFi 6GHz

Shows the status of the 6GHz high network (Up/Down) and the current band setting. This can either be auto which indicates Radio Resource Management is enabled or is in the range of 100-165 when manually configured.

#### Ethernet Port

Shows the status of the Ethernet ports (Up/Down), the sync rate (10Mbps, 100Mbps, 1Gbps, 2.5Gbps, 5Gbps, 10Gbps) and the duplex mode (Half duplex, Full duplex).

## WAN Configuration

### 7.6 Overview

This section describes the WAN configuration procedures that can be performed from the following sub-menu options under the **WAN** menu:

Sub-menu	Procedure
<b>WAN services</b>	<a href="#">7.7 "Configuring WAN Services" (p. 67)</a>
<b>WAN statistics</b>	<a href="#">7.8 "Viewing WAN Statistics" (p. 72)</a>
<b>TR-069</b>	<a href="#">7.9 "Configuring TR-069" (p. 74)</a>
<b>TR-369</b>	<a href="#">7.10 "Configuring TR-369" (p. 76)</a>
<b>IP routing</b>	<a href="#">7.11 "Configuring IP Routing" (p. 77)</a>
<b>Qos config</b>	<a href="#">7.12 "Configuring QoS" (p. 78)</a>

### 7.7 Configuring WAN Services

1

Click **WAN**→**WAN services** in the left pane. The *WAN services* page displays the existing WAN connections in the *Overview* table. You can click on a connection to modify the connection configuration.

Figure 7-2 Overview table in WAN services page

Service Name	Connection mode	Enable/Disable status	Service	IP address
1_INTERNET_R_VID_980	Route	Enable	Internet	192.168.125.19
2_TR069_R_VID_1001	Route	Enable	TR-069	192.168.91.194
3_INTERNET_R_VID_1002	Route	Enable	Internet	192.168.92.101

2

Click **Add +** to create a WAN connection. The *Create New Connection* page displays.

Figure 7-3 Create New Connection page

The screenshot shows the 'Create New Connection' page in the configuration interface. The page is titled 'WAN / WAN services / 1\_INTERNET\_R\_VID\_960'. It contains several sections for configuring WAN services:

- WAN connection list:** Shows the connection name '1\_INTERNET\_R\_VID\_960' and a status toggle set to 'On'.
- Connection type:** A dropdown menu set to 'PPPoE'.
- IP mode:** A dropdown menu set to 'IPv4'.
- MTU:** A toggle switch set to 'On'.
- TLS DNS:** A toggle switch set to 'Off'.
- Internet:** A toggle switch set to 'On'.
- PTV:** A toggle switch set to 'Off'.
- Enable VLAN:** A toggle switch set to 'On'.
- VLAN ID:** A text input field containing '50'.
- VLAN PVID:** A text input field containing '5'.
- WAN IP mode:** A dropdown menu set to 'PPPoE'.
- Connection trigger:** A dropdown menu set to 'AlwaysOn'.
- Username:** A text input field containing '0442520403'.
- Password:** A text input field with masked characters '\*\*\*\*\*'.
- Keep alive time:** A text input field containing '30'.
- Keep alive interval:** A text input field containing '3'.
- Echo value:** A text input field containing '50'.
- Manual DNS:** A toggle switch set to 'Off'.
- Primary DNS:** A text input field.
- Secondary DNS:** A text input field.

Figure 7-4 Create New Connection page - PPPoE Configuration

← WAN / WAN services / 2\_INTERNET\_R\_VID\_3000 Delete Save

WAN connection list: 2\_INTERNET\_R\_VID\_3000

Enabled:

Connection type: PPPoE

Connection mode: Route Mode

IP mode: IPv4&IPv6

NAT:

TR-069:

Internet:

IPTV:

Enable VLAN:

VLAN ID: 3000

VLAN PRI: 0

WAN IP mode: PPPoE

Connection trigger: AlwaysOn

Username: atc

Password: .....

Keep alive time: 50 (5-60 seconds)

Keep alive retry: 3 (1-10 times)

Echo value: 150

Address method: AutoConfigured

Enable prefix delegation:

Prefix type: PrefixDelegation

3

Configure the following parameters:

Table 7-2 WAN services parameters

Field	Description
WAN connection list	Select a WAN connection from the list.
Enabled	Select the toggle button to enable the WAN connection.
Connection type	Select a connection type from the list: <ul style="list-style-type: none"> <li>• <b>IPoE</b></li> <li>• <b>PPPoE</b></li> </ul>
NAT	Select the toggle button to enable NAT. This option is applicable only if the connection mode is <b>Route Mode</b> .
TR-069	Select the toggle button to enable TR-069. This option is applicable only if the connection mode is <b>Route Mode</b> .
Internet	Select the toggle button to enable Internet. This option is applicable only if the connection mode is <b>Route Mode</b> .
IPTV	Select the toggle button to enable IPTV.
Enable VLAN	Select the toggle button to enable VLAN. This option is applicable only if the connection mode is <b>Route Mode</b> .
VLAN ID	Enter the VLAN ID. Allowed values: 2 to 4094
VLAN PRI	Enter the VLAN PRI. VLAN priority allows to assign a priority to outbound packets containing the specified VLAN ID. Allowed values: 0 to 7 In the bridge mode, this option is applicable only if the VLAN mode is <b>VLAN binding</b> .
WAN IP mode	Select an IP mode from the list: <ul style="list-style-type: none"> <li>• <b>DHCP</b></li> <li>• <b>PPPoE</b></li> </ul> This option is visible only if you select PPPoE as the connection type. <ul style="list-style-type: none"> <li>• <b>Static</b></li> </ul>
Manual DNS	If the selected IP mode is <b>IPv4</b> and the WAN IP mode is <b>DHCP</b> , enter the Domain Name Server (DNS) to be configured manually.
IPv4 Address	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the static IPv4 address.
Netmask	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the netmask.
Gateway	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the gateway IP address.

Table 7-2 WAN services parameters (continued)

Field	Description
Pri DNS	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the primary Domain Name Server (DNS).
Sec DNS	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the secondary Domain Name Server (DNS).
Ter DNS	If the selected IP mode is <b>IPv4</b> or <b>IPv4&amp;IPv6</b> and the WAN IP mode is <b>Static</b> , enter the tertiary Domain Name Server (DNS).
Connection trigger	Select the connection trigger type from the list. The default option is <b>Always On</b> .
Username	Enter the username to log in to the configuration server. This option is applicable only if the WAN IP mode is <b>PPPoE</b> .
Password	Enter the password to log in to the configuration server. Allowed values are limited to numbers, letters and special characters ! # + , - . / : = @ _ . This option is applicable only if the WAN IP mode is <b>PPPoE</b> .
Keep alive time	The PPPoE connection type triggers one heartbeat each, at the configured time interval to keep the session online. Allowed values: 5 to 60 seconds This option is applicable only if the WAN IP mode is <b>PPPoE</b> .
Keep alive retry	Configure the number of retries to check the Keep Alive status of the PPPoE session after time-out. Allowed values: 1 to 10. This option is applicable only if the WAN IP mode is <b>PPPoE</b> .
Echo value	Indicates the number of times the device sends messages to the server to check if the IP address is available or not. This option is applicable only if the WAN IP mode is <b>PPPoE</b> .
Address method	If the selected IP mode is <b>IPv6</b> or <b>IPv4&amp;IPv6</b> , select the address method from the list: <ul style="list-style-type: none"> <li>• <b>AutoConfigured</b></li> <li>• <b>DHCPv6</b></li> <li>• <b>DHCPv6_PD</b></li> <li>• <b>DHCPv6_NA</b></li> <li>• <b>Static</b></li> </ul>
Enable prefix delegation	If the selected address method is <b>AutoConfigured</b> , select the toggle button to enable inclusion of the Identity Association (IA) for Prefix Delegation option in Solicit messages.
Prefix type	Displays mechanism through which the prefix was assigned or most recently updated.
IP Address (v6)	If the selected address method is <b>Static</b> , enter the IPv6 address.
Gateway (v6)	If the selected address method is <b>Static</b> , enter the gateway IPv6 address.
IPv6 address prefix	If the selected address method is <b>Static</b> , enter the IPv6 address prefix.
Pri DNS (v6)	If the selected address method is <b>Static</b> , enter the primary DNS IP address.
Sec DNS (v6)	If the selected address method is <b>Static</b> , enter the secondary DNS IP address.
DHCP option 50 persistent	Select the toggle button to enable DHCP Option 50 persistent.

Table 7-2 WAN services parameters (continued)

Field	Description
Enable DHCP option 60	Select the toggle button to enable DHCP Option 60 (vendor class identifier).
Enable DHCP option 61	Select the toggle button to enable DHCP Option 61 (client identifier).
Enable DHCP option 77	Select the toggle button to enable DHCP Option 77 (user class information).
Enable DHCP option 90	Select the toggle button to enable DHCP Option 90 (authentication information).

4

Click **Save**. The connection is listed in the *Overview* table of the *WAN services* page.

END OF STEPS

## 7.8 Viewing WAN Statistics

1

Click **WAN**→**WAN statistics** in the left pane. The *WAN Statistics* page displays the following information for WAN ports.

Figure 7-5 WAN Statistics page

WAN / WAN statistics				
Overview				
Service Name	Connection mode	Enable/Disable status	Service	IP address
1_INTERNET_R_VID_980	Route	Enable	Internet	192.168.125.19
2_TR069_R_VID_1001	Route	Enable	TR-069	192.168.91.194
3_INTERNET_R_VID_1002	Route	Enable	Internet	192.168.92.101

2

Click on the service name to display the WAN statistics details page.



Figure 7-6 WAN Statistics page info

← WAN / WAN statistics / 1\_TR069\_INTERNET\_OTHER\_R\_VID\_0 ↻

**Service**

WAN connection list 1\_TR069\_INTERNET\_OTHER\_R\_VID\_0 ▾

Enabled

**Service details**

Access type	access_dev1
Connection mode	Dynamic DHCP
VLAN	0
WAN link status	Up
IPv4 address	11.18.93.207
Netmask	255.255.255.0
Gateway	11.18.93.254
Primary DNS	11.18.90.253
Secondary DNS	40.0.0.10

© 2021 Nokia [Recommended browsers](#)

**Port statistics**

Counters	1_TR069_INTERNET_OTHER_R_VID_0
Bytes Sent	129054
Bytes received	336914
Packets sent	1246
Packets received	3190
Errors sent	0
Errors received	0
Discard packets sent	0
Discard packets received	0
Rx drops	0
Tx drops	0
Rx errors	0
Tx errors	0

Table 7-3 WAN services parameters

Field	Description
WAN connection list	Select a WAN connection from the list.
Enabled	Displays whether WAN connection is either enabled or disabled.
<b>Service details</b>	
Access type	Displays the access type.
Primary DNS	Displays the primary DNS address.
Secondary DNS	Displays the secondary DNS address.
Ethernet link status	Displays the Ethernet status link whether it is Up or Down.
Pri DNS(v6)	Displays the primary DNS address. This option is available when the IP mode is <b>IPv4 &amp; IPv6</b> or <b>IPv6</b> .
<b>Port statistics</b>	
Counters	Displays the counters details.
Bytes sent/received	Displays the bytes sent and received.
Packets sent/received	Displays the packets sent and received.
Errors sent/received	Displays the errors sent and received.
Unicast packets sent/received	Displays the unicast packets sent and received.
Discard packets sent/received	Displays the discard packets sent and received.
Broadcast packets sent/received	Displays the broadcast packets sent and received.
Unknown proto packets received	Displays the proto packets received.
Rx/Tx drops	Displays the Rx/Tx dropped packets.
Rx/Tx errors	Displays the Rx/Tx error packets.

END OF STEPS

## 7.9 Configuring TR-069

1

Click **WAN**→**TR-069** in the left pane. The *TR-069* page displays.

Figure 7-7 TR-069 page

**2**

Configure the following parameters:

Table 7-4 TR-069 parameters

Field	Description
Enable	Select the toggle button to enable CWMP function.
Periodic inform enable	Select the toggle button to enable periodic inform updates.
Periodic inform interval(s)	Enter the time between periodic inform updates, in seconds.
URL	Enter the URL of the auto-configuration server.
Username	Enter the username to log in to the Beacon.
Password	Enter the password to log in to the Beacon.
Connect request username	Enter the username to log in to the auto-configuration server.
Connect request password	Enter the password to log in to the auto-configuration server.

**3**

Click **Save**.

**END OF STEPS**

## 7.10 Configuring TR-369

**i** **Note:** The TR-369 configuration option is available only if the TR-181 data model is active.

1

Click **WAN**→**TR-369** in the left pane. The *TR-369* page displays.

Figure 7-8 TR-369 page

2

Configure the following parameters:

Table 7-5 TR-369 parameters

Field	Description
Enable TR369/USP	Select the toggle button to enable TR-369/USP and click <b>Save</b> .
Controller endpoint ID	Enter the controller endpoint ID.
MTP Protocol	Select the MTP protocol from the list (currently only <b>MQTT</b> is supported).
Transport	Select the transport option from the list: <ul style="list-style-type: none"> <li>• <b>TCP/IP</b></li> <li>• <b>TLS</b></li> </ul>
Broker address	Enter the broker IP address.
Broker port	Enter the broker port number.
Username	Enter the username to authenticate with MQTT broker.

Table 7-5 TR-369 parameters (continued)

Field	Description
Password	Enter the password to authenticate with MQTT broker.

3

Click **Save**.

END OF STEPS

## 7.11 Configuring IP Routing

1

Click **WAN**→**IP routing** in the left pane. The *IP routing* page displays.

Figure 7-9 IP routing page

2

Configure the following parameters:

Table 7-6 IP routing parameters

Field	Description
Enable IP routing	Select the toggle button to enable IP routing.
Destination IP address	Enter the destination IP address.
Destination netmask	Enter the destination netmask.



Table 7-6 IP routing parameters (continued)

Field	Description
Gateway	Enter the gateway IP address.
IPv4 interface	Select an IPv4 interface from the list.
Forwarding policy	Select a forwarding policy from the list.

3

Click **Add**. The IP route is added to the *IP routing table*.

END OF STEPS

## 7.12 Configuring QoS

1

Click **WAN**→**QoS config** in the left pane. The *QoS config* page displays.

Figure 7-10 QoS config page (L2 Criteria)

The screenshot shows the 'WAN / QoS config' page. At the top right, there is a refresh icon and an 'Add' button. The page is divided into several sections:

- Type:** A dropdown menu set to 'L2 Criteria'.
- Classification criteria:**
  - Source Mac:** A text input field with the example 'Ex. AA:BB:CC:DD:EE:FF'.
  - Enable source MAC mask:** A toggle switch that is currently turned on (blue).
  - Source MAC mask:** An empty text input field.
  - Exclude:** A toggle switch that is currently turned off (grey).
  - Interface:** A dropdown menu set to 'Select option'.
- Classification row:**
  - DSCP remark:** A greyed-out text input field.
  - Range 0-63:** A greyed-out text input field.
  - 802.1p Remark:** A text input field.
  - Range 0-7:** A text input field.

Figure 7-11 QoS config page (L3 Criteria)

The screenshot shows the 'WAN / QoS config' page with the following fields and options:

- Type:** L3 Criteria (dropdown)
- Classification criteria:**
  - Protocol:** None (dropdown)
  - Application:** Customer Setting (dropdown)
  - Source IP:** (text input)
  - Source IP Mask:** (text input)
  - Dest IP:** (text input)
  - Dest IP mask:** (text input)
  - Source Port:** (text input)
  - Source Port Max:** (text input)
  - Destination Port:** (text input)
  - Dest Port Max:** (text input)
  - 802.1p:** (toggle button)
  - Interface:** Select option (dropdown)

2

Configure the following parameters:

Table 7-7 QoS config parameters

Field	Description
Type	Select a QoS service layer type from the list: <ul style="list-style-type: none"> <li>• L2 Criteria</li> <li>• L3 Criteria</li> </ul>
<b>Classification criteria (L2)</b>	
Source MAC	Enter the source MAC address.
Enable source MAC mask	Select the toggle button to enable the source MAC mask. This button is disabled by default.
Source MAC mask	Enter the source MAC mask address. The syntax is for example: FF:FF:FF:00:00:00 which must be a continuous bit mask pattern on this device. This field is visible only if the <b>Enable source MAC mask</b> button is enabled.
Interface	Select an interface from the list.
<b>Classification criteria (L3)</b>	

Table 7-7 QoS config parameters (continued)

Field	Description
Protocol	Select a protocol from the list.
Application	Select an application from the list or select <b>Custom Settings</b> and enter an application name.
Source IP	Enter the source IP address.
Source IP mask	Enter the source IP address netmask.
Destination IP	Enter the destination IP address.
Destination IP mask	Enter the destination IP address netmask.
Source port	Enter the source port number.
Source port max	Enter the values for the source port max (highest port number)
Destination port	Enter the destination port number.
Destination port max	Enter the values for the destination port max (highest port number)
802.1p	Indicates whether 802.1p is enabled.
Interface	Select an interface from the list.
<b>Classification row</b>	
DSCP remark	Enter the value for the DSCP remark (applicable only for L3 criteria). Allowed values: 0 to 63
802.1p Remark	Enter the value for the 802.1p remark. Allowed values: 0 to 7
Forwarding policy	Enter the number for the forwarding policy. Allowed values: 1 to 7

3

Click **Add** to add a QoS policy.

**END OF STEPS**



---

## LAN Configuration

### 7.13 Overview

This section describes the LAN configuration procedures that can be performed from the following sub-menu options under the **LAN** menu:

Sub-menu	Procedure
<b>DHCP IPv4</b>	<a href="#">7.14 "Configuring DHCP IPv4" (p. 81)</a>
<b>DHCP IPv6</b>	<a href="#">7.15 "Configuring DHCP IPv6" (p. 83)</a>
<b>DNS</b>	<a href="#">7.16 "Configuring DNS" (p. 85)</a>
<b>LAN statistics</b>	<a href="#">7.17 "Viewing LAN Statistics" (p. 88)</a>

### 7.14 Configuring DHCP IPv4

1 \_\_\_\_\_

Click **LAN**→**DHCP IPv4** in the left pane. The *DHCP IPv4* page displays.

Figure 7-12 DHCP IPv4 page

2

Configure the following LAN parameters:

Table 7-8 DHCP IPv4 parameters

Field	Description
IPv4 address	Enter the IPv4 address of the Beacon.
Subnet mask	Enter the subnet mask of the Beacon.
DHCP enable	Select the toggle button to enable DHCP. If this toggle button is not enabled, the DHCP functionality cannot be used. you need not configure DHCP start IP address, DHCP end IP address and DHCP lease time if this toggle button is not enabled.

Table 7-8 DHCP IPv4 parameters (continued)

Field	Description
DHCP start IP address	Enter the starting range of the DHCP IP address.
DHCP end IP address	Enter the ending range of the DHCP IP address.
DHCP lease time	Enter the DHCP lease time (in minutes). Allowed values: 5 to 129600 minutes or 0 for 1 day
Primary DNS	Enter the primary DNS IP address.
Secondary DNS	Enter the secondary DNS IP address.

3

Click **Save**.

4

Configure the Static DHCP parameters.

Table 7-9 Static DHCP parameters

Field	Description
MAC address	Enter the hexadecimal MAC address to associate with the LAN.
IPv4 address	Enter the IPv4 address to associate with the bound MAC address.

5

Click **Add**. Repeat steps 4 and 5 for all MAC addresses to be bound.

END OF STEPS

## 7.15 Configuring DHCP IPv6

1

Click **LAN**→**DHCP IPv6** in the left pane. The *DHCP IPv6* page displays.

Figure 7-13 DHCP IPv6 page

2

Configure the following parameters:

Table 7-10 DHCP IPv6 parameters

Field	Description
<b>LAN prefix configuration</b>	
Prefix Config	Select a prefix configuration option from the list: <ul style="list-style-type: none"> <li>• <b>Use WAN provided prefix</b> (prefix is obtained from the WAN.), or</li> <li>• <b>Static</b> (enables you to enter the prefix.)</li> </ul>
Interface	This field displays if you select the <b>Use WAN provided prefix</b> option from the Prefix Config list. Select a WAN connection interface from the list.
Received IPv6 prefix	This field displays the received IPv6 prefix. This field is displayed only when <b>Prefix Config</b> is set to <b>Use WAN provided prefix</b> .
Static IPv6 prefix	This field displays the static IPv6 prefix. This field is displayed only when <b>Prefix Config</b> is set to <b>Static</b> .
<b>IPv6 address method</b>	

Table 7-10 DHCP IPv6 parameters (continued)

Field	Description
Address method	Select a address method option from the list: <ul style="list-style-type: none"> <li>• <b>Stateless Address Autoconfig (SLAAC)</b></li> <li>• <b>Stateful DHCPv6</b></li> </ul>
DHCP Start IP Address	Enter the starting range of the DHCP IP address. This parameter is visible only if the address method is <b>Stateful DHCPv6</b> .
DHCP End IP Address	Enter the ending range of the DHCP IP address. This parameter is visible only if the address method is <b>Stateful DHCPv6</b> .
Enable stateless and stateful DHCPv6 simultaneously	Select the toggle button to enable stateless or stateful DHCPv6 simultaneously. This parameter is visible only if the address method is <b>Stateful DHCPv6</b> .
Received additional options via DHCPv6	Select the toggle button to enable additional options via DHCPv6. This field is displayed only when <b>Address method</b> is set to <b>Stateless Address Autoconfig (SLAAC)</b> .
Enable stateless and stateful DHCPv6 simultaneously	Select the toggle button to enable stateless and stateful DHCPv6 simultaneously. This field is displayed only when <b>Address method</b> is set to <b>Stateful DHCPv6</b> .
<b>Advanced router advertisement configuration</b>	
Maximum interval for periodic RA messages	Enter the maximum interval (in seconds) for periodic Router Advertisement messages. Allowed values: 4 to 1800 seconds
Minimum interval for periodic RA messages	Enter the minimum interval (in seconds) for periodic Router Advertisement messages. Allowed values: 4 to 1800 seconds

3

Click **Save**.

END OF STEPS

## 7.16 Configuring DNS

### 7.16.1 IPv4 DNS configuration

1

Click **LAN**→**DNS**→**IPv4** in the left pane. The *DNS* page displays.

Figure 7-14 DNS page (IPv4)

LAN / DNS

IPv4 IPv6

DNS Proxy

Save

Domain Name

IPv4 address

Add

Origin Domain

New Domain

Add

Static DNS entries

Domain Name	IPv4 address	Delete
www.webgui.nokia.com	192.168.18.1	Delete

## 2

Configure the following parameters:

- a. Select the **DNS proxy** toggle button to enable the DNS proxy and click **Save**.
- b. Configure the following:
  1. Enter the domain name in the Domain Name field
  2. Enter the domain IP address in the IPv4 Address field.
  3. Click **Add**.
- c. Configure the following:
  1. Enter the origin domain name in the Origin Domain field
  2. Enter the new domain name in the New Domain field.

3. Click **Add** to associate an origin domain with a new domain.  
The *DNS* table displays the configured domain names and the associated IPv4 address. Click **Delete** to delete the table entries.


END OF STEPS

## 7.16.2 IPv6 DNS configuration

1

Click **LAN**→**DNS**→**IPv6** in the left pane. The *DNS* page displays.

Figure 7-15 DNS page (IPv6)



2

Configure the following parameters

Table 7-11 DNS parameters

Field	Description
DNS Server	Select DNS server option from the list: <ul style="list-style-type: none"> <li>• <b>Wan Connection</b> (Server address is obtained from the WAN.)</li> <li>• <b>Static</b> (enables you to enter the address.)</li> <li>• <b>HGWProxy</b> (The Home Gateway acts as DNS Proxy).</li> </ul>
Preferred DNS	Enter the preferred IPv6 address. This parameter is visible only if the DNS Server is <b>Static</b> .
Alternate DNS	Enter the Alternate IPv6 address. This parameter is visible only if the DNS Server is <b>Static</b> .
Interface	This field is displayed if you select the <b>Wan Connection</b> option from the DNS Server list.

---

3

Click **Save**.

END OF STEPS

---

## 7.17 Viewing LAN Statistics

1

Click **LAN**→**LAN statistics** in the left pane. The *LAN statistics* page displays the following information.



Figure 7-16 LAN statistics page

LAN / LAN statistics ↻

SSID name NOKIA-C433 ▾

---

**LAN wireless info**

Wireless status	On
Wireless channel	11
Wireless encryption status	WPA2-PSK
Wireless Rx packets	0
Wireless Tx packets	21
Wireless Rx bytes	0
Wireless Tx bytes	1756
Power transmission(mW)	100

---

**LAN ethernet info**

Ethernet status	Up
Ethernet IP address	192.168.18.1
Ethernet subnet mask	255.255.255.0

© 2021 Nokia [Recommended browsers](#)

Ethernet Rx packets	10114
Ethernet Tx packets	16645
Ethernet Rx bytes	1316576
Ethernet Tx bytes	19144435

---

Info	LAN 1	LAN 2
Status	Up	Up
Duplex mode	Full Duplex	Full Duplex
Max bit rate	1000	1000
Bytes Sent	10163004	238820
Bytes received	401945	532830
Packets sent	8008	2020
Packets received	4480	1856
Errors sent	0	0
Discard packets sent	0	0
Discard packets received	0	7
Multicast packets sent	0	0
Multicast packets received	665	114
CRC errors received	0	0

Table 7-12 LAN statistics parameters

Field	Description
SSID name	Select an SSID from the list.
LAN Wireless info	Displays the wireless status, wireless channel, encryption status, received and transmitted bytes and packets and power transmission in mW.
LAN Ethernet info	Displays the Ethernet status IP address, subnet mask, MAC address, received and transmitted bytes and packets.
Info	Displays the information of each such as status, duplex mode, maximum bit rate, packets received and sent, CRC errors, and so on.

**END OF STEPS**

## WiFi Configuration

### 7.18 Overview

This section describes the WiFi configuration procedures that can be performed from the following sub-menu options under the **WiFi** menu:


Sub-menu	Procedure
<b>WiFi networks</b>	7.19 "Configuring WiFi Network" (p. 91)
<b>Guest network</b>	7.20 "Configuring Guest Network" (p. 97)
<b>Network map</b>	7.21 "Viewing Network Map, Adding WiFi Points, Renaming WiFi Points and Removing WiFi Points" (p. 98)
<b>Advanced settings</b>	7.22 "Configuring Wireless 2.4 GHz" (p. 103)
<b>WiFi statistics</b>	7.25 "Viewing WiFi Statistics" (p. 109)

### 7.19 Configuring WiFi Network

1

Click **WiFi**→**WiFi network** in the left pane. The *WiFi network* page displays the existing WiFi networks. You can click **Detail** on a network to view the network details.

Figure 7-17 WiFi network page



---

2

Click **Add WiFi network +** to create a WiFi network. The *Add WiFi network* page displays.

Figure 7-18 Add WiFi network page

## Add WiFi network ×

Please select a preferred network type from the options below.

- Multi Band**  
Recommended - intelligently routes your devices on 2.4 GHz, 5 GHz and 6GHz bands based on usage, speed, coverage and distance.
- 2.4 GHz
- 5 GHz Low
- 5 GHz High
- 6 GHz

**Next**

---

3

Configure the following parameters:

Table 7-13 Add WiFi network parameters

Field	Description
Multiband	Select this option to configure a multiband wireless network. This option is recommended your devices on 2.4 GHz or 5 GHz bands based on usage, speed, coverage and distance.
2.4 GHz	Select this option to configure a 2.4 GHz wireless network.
5 GHz Low	Select this option to configure a low 5 GHz wireless network.
5 GHz High	Select this option to configure a high 5 GHz wireless network.
6 GHz	Select this option to configure a 6 GHz wireless network.

4

Click **Next**.

5

Enter the name of your network in the Name field and click **Save**.

6

Enter the password for the network in the Password field and click **Save**.

The WiFi network is created and is displayed as a card in the **Enabled** tab of the *WiFi networks* page.



**Note:** You can click the ellipsis icon on the card of your WiFi network and select **Edit** to edit and save the network name and password.

7

Click **Detail** to view and edit the SSID configuration for your network.

Figure 7-19 WiFi network - example of SSID Configuration page

The screenshot shows a configuration page for a WiFi network. At the top, there is a breadcrumb trail: "Network / WiFi networks / NOKIA-7272". To the right of the breadcrumb is a refresh icon and a blue "Save" button. Below the breadcrumb is a section titled "SSID configuration". This section contains several fields and toggle switches:

- SSID name:** A text input field containing "NOKIA-7272".
- Enable WiFi network:** A toggle switch that is currently turned on (blue).
- Band type:** A dropdown menu showing "2.4 / 5 low / 5 high / 6 GHz(MLO)".
- SSID index:** A text input field containing "1,5,9,13".
- MLO enabled:** A toggle switch that is currently turned on (blue).
- Broadcast the WiFi network:** A toggle switch that is currently turned on (blue).
- WPA key:** A text input field containing a series of dots, with an eye icon to its right for visibility control.

8

Configure the following parameters:

Field	Description
SSID name	Displays the SSID name.
Enable WiFi network	Select the toggle button to enable the WiFi network.
Band type	Displays the band type.
SSID index	Displays the SSID index.
MLO enabled	Select the toggle button to enable MLO.
Broadcast the WiFi network	Select the toggle button to enable broadcasting of the WiFi network.

Field	Description
Encryption Mode	<p>In case of 2.4 GHz band type, select an encryption mode from the list:</p> <ul style="list-style-type: none"> <li>• <b>WPA2 Personal</b></li> <li>• <b>WPA/WPA2 Personal</b></li> <li>• <b>WPA3 Personal</b></li> <li>• <b>WPA2/WPA3 Personal</b></li> <li>• <b>WPA/WPA2 Enterprise</b></li> <li>• <b>Open</b></li> </ul> <p>In case of 5 GHz band type, select an encryption mode from the list:</p> <ul style="list-style-type: none"> <li>• <b>WPA2-AES</b></li> <li>• <b>WPA2+WPA</b></li> <li>• <b>WPA/WPA2 Enterprise</b></li> <li>• <b>WPA3+WPA2</b></li> <li>• <b>WPA3</b></li> <li>• <b>NONE-OPEN</b></li> </ul> <p>In case of 6 GHz band type, select an encryption mode from the list:</p> <ul style="list-style-type: none"> <li>• <b>WPA3</b></li> </ul>
WPA version	<p>WPA version is displayed when the encryption mode is selected:</p> <ul style="list-style-type: none"> <li>• <b>WPA2</b></li> <li>• <b>WPA/WPA2</b></li> <li>• <b>WPA3</b></li> <li>• <b>WPA2/WPA3</b></li> </ul> <p>This parameter is visible only if the band type is 2.4 GHz.</p>
WPA Encryption Mode	<p>Select a WPA encryption mode from the list:</p> <ul style="list-style-type: none"> <li>• <b>AES</b></li> <li>• <b>TKIP/AES</b></li> </ul> <p>This parameter is visible only if the band type is 2.4 GHz.</p>
WPA key	Enter the WPA key.

**Notes:**

1. When Encryption Mode is set to “WPA/WPA2 Enterprise”, the following options are no longer available: WPA encryption mode, WPA key, Enable WPS, WPS mode.
2. When Encryption Mode is set to “WPA/WPA2 Enterprise”, the following options become available: Primary RADIUS server, port and password; RADIUS accounting port.

9

Click **Save**.

**END OF STEPS**



## 7.20 Configuring Guest Network

1

Click **WiFi**→**Guest network** in the left pane. The *Guest network* page displays the network details.

Figure 7-20 Guest network page

The screenshot shows the 'WiFi / Guest network' configuration interface. On the left, there is a 'Network details' section with a 'Name' field containing 'NOKIA-5C91\_Guest' and a 'Password' field with masked characters. Below the password field is a note: 'Use 8 or more characters.' and a blue 'Save' button. At the bottom left, there is an 'Enable guest network' toggle switch that is turned on, with a note: 'Allow guests to access the Internet. Devices connected to this network will not be able to access other devices in your home network.' On the right side, there is a 'Share QR code' section with a QR code and the text: 'Share the QR code below for others to join the guest network'.

2

Configure the following parameters:

Table 7-14 Guest network parameters

Field	Description
Name	Enter the name for guest network.
Password	Enter a password for guest network. Click <b>Save</b> .
Enable guest network	Select this toggle button to enable guest WiFi. Enabling the Guest SSID creates a multiband network (2.4GHz and 5GHz). At least one 2.4GHz and one 5GHz SSID index must be available to enable Guest network. After enabling the Guest Network a new WiFi card can be seen in WiFi networks page and Overview page with Guest SSID details.

3

Share the QR code for others to join the guest network.


**END OF STEPS**

## 7.21 Viewing Network Map, Adding WiFi Points, Renaming WiFi Points and Removing WiFi Points

1

Click **WiFi**→**Network map** in the left pane. The *Network map* page displays the WiFi points added to the network.


Figure 7-21 Network map page




2

Perform the following steps to add a WiFi point:

- a. Click **Add WiFi point** at the top right corner of the *Device Info* page. A message displays that it is recommended to use the Nokia WiFi mobile app to add a WiFi point.
- b. To add a WiFi point using the WebGUI, click **Continue with WebGUI**.



c. In the *Add WiFi point* page, enter the serial number and click **Add**.




The WiFi point is displayed in the *Detected* or *Not detected* list of the *Onboarding Status* panel in the *Device Info* page.

3

Click on a WiFi point to view the device details. The *<Device>* page displays the details of the selected device in the network, including connection status.

Figure 7-22 *<Device>* page



4

The WiFi point name can be edited by clicking the edit icon .

Perform the following steps to change the name of your WiFi point:


- Click the Edit icon  to edit the name of the WiFi point. The **Change the name of your WiFi point** page displays.
- On the page **Change the name of your WiFi point**, click the drop-down menu to select a name for the WiFi point, or enter a **Custom name** to create your own customized name.
- Click **Save**.

Figure 7-23 Change the name of your WiFi point page

Table 7-15 <Device> parameters

Field	Description
Device name	Name on the device
Serial number	Serial number of the device
MAC address	MAC address of the device
IP address	IP address of the device
Software version	Software version of the device (displays only for a root device)
Hardware version	Hardware version of the device (displays only for a root device)
Boot version	Boot version of the device (displays only for a root device)
Uptime	Amount of time the device has run since last reset in hours, minutes, and seconds (displays only for a root device)
Chipset	Chipset of the device (displays only for a root device)
Vendor	Name of the vendor (displays only for a root device)
Onboarding status	Onboarding status of the device in the WiFi network (displays only for an extender device)
Backhaul status	Backhaul status of the device (displays only for an extender device)

Table 7-15 <Device> parameters (continued)

Field	Description
Location nickname	Name of the location of the device (displays only for an extender device)

5

Click **LED Light** to enable the LED light on the device.

6

Perform any of the following, as applicable:

- **Reboot the device:**

1. Click **Reboot**. A message displays asking if you want reboot the device.
2. Click **OK** to reboot the Beacon. The device reboots and displays the login page.

- **Reset the device to factory default settings:**

1. Click **Factory default**. A message displays asking if you want to reset the system configuration to the factory default settings.
2. Click **OK** to reset the Beacon to the factory default settings.

- **Reset the device to deep factory default settings:**


1. Click **Deep factory reset**. A message displays asking if you want to reset the system configuration to the factory default settings.
2. Click **OK** to reset the Beacon so that all the downloaded configuration files such as Web customization, delta-config, voice XML, certification file and so on will be removed.

END OF STEPS

### 7.21.1 Remove WiFi points

To remove WiFi points, perform the following:

1. Click any extender device and the following *Network map* page is displayed.



The device name can be renamed by clicking the edit icon .

2. Ensure to power off the extender and wait for a few minutes to get the extender in offline status and click **Remove** to permanently remove the WiFi point from your network.

When the extender is in powered on state, a message is displayed to power off the extender and then remove it permanently.


The WiFi point is removed from your network. If you want to use the WiFi point on a different network, factory reset it first.

## 7.22 Configuring Wireless 2.4 GHz

1. \_\_\_\_\_  
Click **WiFi**→**Advanced settings** in the left pane. The *Advanced settings* page displays.
2. \_\_\_\_\_  
Select the **2.4 GHz** tab to configure the wireless 2.4 GHz parameters.



Figure 7-24 Advanced settings - 2.4 GHz tab



3

Configure the following parameters:

Table 7-16 Wireless 2.4 GHz parameters

Field	Description
Enable	Select the toggle button to enable Wireless (2.4 GHz).
Mode	Select a wireless mode from the list: <ul style="list-style-type: none"> <li>• <b>Auto (b/g/n/ax/be)</b></li> <li>• <b>b/g/n</b></li> <li>• <b>b</b></li> <li>• <b>g</b></li> <li>• <b>n</b></li> <li>• <b>b/g</b></li> <li>• <b>g/n</b></li> <li>• <b>n/ax</b></li> </ul>
Channel bandwidth	Select the bandwidth range from the list: <ul style="list-style-type: none"> <li>• <b>Auto</b> (auto-assigns the bandwidth range)</li> <li>• <b>20 MHz</b></li> <li>• <b>40 MHz</b></li> </ul>



Table 7-16 Wireless 2.4 GHz parameters (continued)

Field	Description
Channel	Select a channel from the list or select <b>Auto</b> to auto-assign the channel.
Transmit power	Select a percentage for the transmitting power from the list: <ul style="list-style-type: none"><li>• 12%</li><li>• 25%</li><li>• 50%</li><li>• 100%</li></ul>
Enable MU-MIMO	Select an option from the list to enable or disable MU-MIMO: <ul style="list-style-type: none"><li>• <b>Enable</b></li><li>• <b>Disable</b></li></ul>
Total max users	Enter the maximum number of users.

4

Click **Save**.

END OF STEPS

## 7.23 Configuring Wireless (5GHz-Low Band or 5GHz-High Band)

1

Click **WiFi**→**Advanced settings** in the left pane. The *Advanced settings* page displays.

2

Select any of the following tabs:

- **5 GHz Low-Band** to view the 5 GHz low band parameters.
- **5 GHz High-Band** to view the 5 GHz high band parameters.

Figure 7-25 Wireless 5 GHz Low Band page

WiFi / Advanced settings

2.4 GHz 5 GHz Low-Band 5 GHz High-Band

**Wireless (5GHz-Low Band)**

Enable

Channel bandwidth Auto

Channel Auto

Transmit power 100%

WMM Enable

Enable MU-MIMO

Total max users 128

Save

Figure 7-26 Wireless 5 GHz High Band page

WiFi / Advanced settings

2.4 GHz 5 GHz Low-Band 5 GHz High-Band

**Wireless (5GHz-High Band)**

Enable

Channel bandwidth Auto

Channel Auto

Transmit power 100%

WMM Enable

Enable MU-MIMO

Total max users 128

Save

3

Configure the following parameters:

Table 7-17 Wireless 5 GHz High Band and Low Band parameters

Field	Description
Enable	Select this toggle button to enable WiFi.
Channel bandwidth	Select an option from the list: <ul style="list-style-type: none"><li>• 20 MHz</li><li>• 40 MHz</li><li>• 80 MHz</li><li>• 160 MHz</li><li>• Auto</li></ul>
Channel	Select a channel from the list or select <b>Auto</b> to auto-assign the channel.
Transmit power	Select a percentage for the transmitting power from the list: <ul style="list-style-type: none"><li>• 12%</li><li>• 25%</li><li>• 50%</li><li>• 100%</li></ul>
Enable MU-MMO	Select the toggle button to enable MU-MIMO. This can be enabled when multiple users are trying to access the wireless network. When this parameter is enabled, multiple users can access router functions without the congestion.
Total max users	Enter the total number of MAX users. The maximum users allowed is 128.

4

Click **Save**.

END OF STEPS

## 7.24 Configuring Wireless 6GHz


1

Click **WiFi**→**Advanced settings** in the left pane. The *Advanced settings* page displays.

2

Select the 6 GHz tab to configure the wireless 6 GHz parameters

Figure 7-27 Wireless 6 GHz page



3

Configure the following parameters:

Table 7-18 Wireless 6 GHz

Field	Description
Enable	Select this toggle button to enable WiFi.
Channel bandwidth	Select an option from the list: <ul style="list-style-type: none"> <li>• 20 MHz</li> <li>• 40 MHz</li> <li>• 80 MHz</li> <li>• 160 MHz</li> <li>• 320 MHz-1</li> <li>• 320 MHz-2</li> <li>• Auto</li> </ul>
Channel	Select a channel from the list or select <b>Auto</b> to auto-assign the channel.
Transmit power	Select a percentage for the transmitting power from the list: <ul style="list-style-type: none"> <li>• 12%</li> <li>• 25%</li> <li>• 50%</li> <li>• 100%</li> </ul>

Table 7-18 Wireless 6 GHz (continued)

Field	Description
Enable MU-MMO	Select the toggle button to enable MU-MMO. This can be enabled when multiple users are trying to access the wireless network. When this parameter is enabled, multiple users can access router functions without the congestion.
Total max users	Enter the total number of MAX users. The maximum users allowed is 128.

4

Click **Save**.

END OF STEPS

## 7.25 Viewing WiFi Statistics

1

Click **WiFi**→**WiFi statistics** in the left pane. The *WiFi statistics* page displays.

Figure 7-28 WiFi statistics page

The screenshot shows the 'WiFi / WiFi statistics' page. At the top, there is a navigation bar with a back arrow, the title 'WiFi / WiFi statistics', and icons for notifications, help, refresh, and a 'Scan' button. Below the title, there is a section for 'WLAN statistics' with a search input field labeled 'Enter band type and name'. The main content is a table with columns for different WLAN bands and rows for various statistics. Each row has a checkbox on the left to toggle the statistics.

	2.4 GHz NOKIA-D0E0 ⓘ	5 GHz low NOKIA-D0E0_Guest ⓘ	5 GHz high NOKIA-D0E0 ⓘ	6 GHz NOKIA-D0E0_Guest ⓘ
<input type="checkbox"/> Counters				
<input type="checkbox"/> Bytes sent	74416711	46395786	4294967259	46395445
<input type="checkbox"/> Bytes received	1258705640	3129	3731085096	242
<input type="checkbox"/> Packets sent	224095	137973	15227739	137977
<input type="checkbox"/> Packets received	4046525	30	12731963	4
<input type="checkbox"/> Errors sent	0	0	0	0
<input type="checkbox"/> Discard packets sent	0	0	0	0
<input type="checkbox"/> Discard packets received	0	0	0	0
<input type="checkbox"/> Rx drops	0	0	0	0
<input type="checkbox"/> Tx drops	0	0	0	0

---

**2**

Select the **WLAN statistics** tab to display WLAN statistics.

**END OF STEPS**

---

---

## Devices

### 7.26 Overview


This section describes how to view device information from the **Device** menu.

### 7.27 Viewing Device Information

1

Click **Devices** in the left pane. The *Devices* page displays the devices.


*Figure 7-29* Devices page



2

The *Devices* page lists the devices. Click on a Device to view the respective device Info page. The *Device Info* page displays the details of the selected device in a network.

Figure 7-30 Device information page - L3 devices



The device name can be renamed by clicking the edit icon .

Perform the following steps to rename the client device:


- Click the Edit icon  to rename the client device. The **Edit** page displays.
- On the **Edit** page, enter the name to create your own customized name or select a category listed in the drop-down menu.
- Click **Save**.



Figure 7-31 Device Rename page

**Edit** x

Name

61-30-PC

Category

Other ^

Appliance

Audio

Camera

Game console

Health

Save

END OF STEPS

## Security Configuration

### 7.28 Overview

This section describes the security configuration procedures that can be performed from the following sub-menu options under the **Security** menu:

Sub-menu	Procedure
Firewall	7.29 "Configuring the Firewall" (p. 114)
MAC filter	7.30 "Configuring the MAC Filter" (p. 115)
IP filter	7.31 "Configuring the IP Filter" (p. 117)
Family profiles	7.32 "Configuring Family Profiles" (p. 118)
DMZ and ALG	7.33 "Configuring DMZ and ALG" (p. 129)
Access control	7.34 "Configuring Access Control" (p. 130)

### 7.29 Configuring the Firewall

1

Click **Security**→**Firewall** in the left pane. The *Firewall* page displays.

Figure 7-32 Firewall page

Security / Firewall

Security level

High: Traffic denied inbound and minimally permit common service outbound.  
Low: All outbound traffic and pinhole-defined inbound traffic is allowed.  
Off: All inbound and outbound traffic is allowed.

Off

Attack Protection

Enable

Save

2

Configure the following parameters.

Table 7-19 Firewall parameters

Field	Description
Security level	Select the security level from the list: <ul style="list-style-type: none"><li>• <b>High:</b> Pre-routing and application services are not supported. UDP Port 8000 can be used to access the services. For example, FTP can use 8021 and Telnet can use 8023. Regular UDP cannot be used. RG access is permitted via the LAN side but not via the WAN side.</li><li>• <b>Low:</b> All outbound traffic and pinhole-defined inbound traffic is allowed. Pre-routing is supported: port forwarding, DMZ, host application, and host drop. Also supported are application services: DDNS, DHCP, DNS, H248, IGMP, NTP client, SSH, Telnet, TFTP, TR-069, and VoIP. The following types of ICMP messages are permitted: echo request and reply, destination unreachable, and TTL exceeded. Other types of ICMP messages are blocked. DNS proxy is supported from LAN to WAN but not from WAN to LAN.</li><li>• <b>Off:</b> All inbound and outbound traffic is allowed. No firewall security is in effect.</li></ul>
Attack Protection	Select <b>Enable</b> or <b>Disable</b> from the list to enable or disable protection against DoS or DDoS attacks. Default value: <b>Enable</b> .

3

Click **Save**.


END OF STEPS

## 7.30 Configuring the MAC Filter

1

Click **Security**→**MAC filter** in the left pane. The *MAC filter* page displays.

Figure 7-33 MAC filter page



2

Configure the following parameters:

Table 7-20 MAC filter - Ethernet Interface parameters

Field	Description
<b>Ethernet Interface</b>	
MAC filter mode	Select the MAC filter mode from the list: <ul style="list-style-type: none"> <li>• <b>Blocked</b></li> <li>• <b>Allowed</b></li> </ul>
LAN port	Select the toggle button to enable any of the LAN ports.
MAC address	Select a MAC address from the list or enter the MAC address in the text field.

3

Click **Save**.

4

Configure the following parameters:

Table 7-21 MAC filter - WiFi SSID parameters

Field	Description
<b>WiFi SSID</b>	
MAC filter mode	Select the MAC filter mode from the list: <ul style="list-style-type: none"> <li>• <b>Blocked</b></li> <li>• <b>Allowed</b></li> </ul>
SSID select	Select the SSID from the list.
Enabled	Select the toggle button to enable the MAC filter.
MAC address	Select a MAC address from the list or enter the MAC address in the text field.

5

Click **Save**.

END OF STEPS

## 7.31 Configuring the IP Filter

1

Click **Security**→**IP filter** in the left pane.

2

Click **Add Filter** to add a IPv4 or IPv6 filter. The *Add IP filter* page displays.

Figure 7-34 IP filter page

3

Configure the following parameters:

Table 7-22 IP filter parameters

Field	Description
<b>Add IPv4 filter or Add IPv6 filter parameters</b>	
Enable IP filter	Select the toggle button to enable an IP filter.
Mode	Select an IP filter mode from the list: <ul style="list-style-type: none"> <li>• <b>Drop for upstream</b></li> <li>• <b>Drop for downstream</b></li> </ul>
Source	Select an internal client from the list: <ul style="list-style-type: none"> <li>• <b>Custom Settings</b>: uses the IP address input below</li> <li>• <b>IP</b>: uses the connecting devices' IP to the Beacon</li> </ul>
<b>Add IPv4 filter parameters</b>	
Local IP address	Enter the local IP address.
Local subnet mask	Enter the local subnet mask.
Remote IP address	Enter the remote IP address.
Remote subnet mask	Enter the remote subnet mask.
Protocol	Select an application protocol or select <b>ALL</b> from the list.
<b>Add IPv6 filter parameters</b>	
Source IP address	Enter the source IP address.
Source Prefix	Enter the source prefix.
Destination IP address	Enter the destination IP address.
Destination prefix	Enter the destination prefix.
Protocol	Select an application protocol or select <b>ALL</b> from the list.

4

Click **Save**.


END OF STEPS

## 7.32 Configuring Family Profiles

1

Click **Security**→**Family profiles (Parental control)** from the left pane. The *Family profiles (Parental control)* page displays.

Figure 7-35 Family profiles (Parental control) page



2 \_\_\_\_\_  
Click **Add profile +** to add a profile with parental controls.

3 \_\_\_\_\_  
In the *Add a profile* page, enter a name for the profile and click **Add**.


Figure 7-36 Add a profile page

4

In the *Select the devices used by <profile>* page, select the check box next to the device name and click **Save** to assign the device to the profile.

**i** **Note:** A device can be assigned to only one profile. Unassigned devices are added to the *Home* profile.

Figure 7-37 Assign devices to family profile



The new profile name is listed in the table in the *Family profiles (Parental control)* page.



Figure 7-38 Family profiles table

The screenshot shows a table titled "Security / Family profiles (Parental control)" with a refresh icon and an "Add profile +" button. The table lists four profiles: Home, Client\_1, Client\_2, and profile\_3. Each profile row includes a profile icon, name, status, and counts for Device, Schedules, Bedtime, Blocked websites, and Visit attempts. Client\_1, Client\_2, and profile\_3 have a "Delete" button on the right.

Profile name	Device	Schedules	Bedtime	Blocked websites	Visit attempts (blocked sites)	
Home Enabled	0	0	0	0	0	
Client_1 Enabled	1	2	3	4	0	Delete
Client_2 Enabled	1	1	2	1	0	Delete
profile_3 Enabled	0	0	0	1	0	Delete

5

Click a profile to configure parental control for the profile. A page displays the profile parameters.

Figure 7-39 Family profile configuration page

The screenshot shows the configuration page for the "Client\_1" profile. It includes a profile icon, name, and status. Below are sections for "Assigned Devices" (1 Device), "Internet Access" (Enabled for this profile, with a toggle switch), "Schedules" (None), "Bedtime" (None), and "Website blocking" (None). Each section has an edit icon on the right.


6

Select the **Internet Access** toggle button to enable internet access.

## Assign more devices

7

Assign more devices to the profile, if required:

- a. In the profile page, click the edit icon  next to **Assigned Devices** to assign devices to the profile. The *Select the devices used by <profile>* page displays.

## Select the devices used by Client\_1 ✕

A device can only belong to one profile. Unassigned devices will be added to the "Home" profile.



- b. Select the check box next to the device to assign to the profile.
- c. Click **Save**.


---

## Configure and enable schedules

### 8

---

Configure schedules for the profile:

- a. In the profile page, click the edit icon  next to **Schedules** to create one or more schedules for the profile to set specific days and time slots when the Internet should be turned off.
- b. Click **Create Schedule**.
- c. In the *Add a schedule* page, configure the following:

## Add a schedule ✕

Name

Start time

End time


Days of the week

M  TU  W  TH  F  SA  SU

1. Enter the name of the schedule in the Name field.
2. Select the start time, end time, and select the days of the week on which the schedule will be in effect.
3. Click **Save**. The schedule is created and listed in the Schedules page.

9

In the *Schedules* page, select the toggle button to enable the schedule and click **Done**. To add more schedules, you can click **Add +**.




---

## Configure and enable bedtime

10


Configure bedtime for the profile:

a. In the profile page, click the edit icon  next to **Bedtime** to configure bedtime for the profile to automatically pause internet access at this time.

Only one bedtime can be assigned per day.

b. Click **Create Bedtime**.

c. In the *Add a bedtime* page, configure the following:



**Add a bedtime** ×

Bedtime

21 : 00

Wake Up

06 : 00

Days of the week

M TU W TH F SA SU

Cancel Save


- 
1. Select the Bedtime, Wake Up time, and select the days of the week on which the bedtime will be in effect.
  2. Click **Save**. The bedtime is created and listed in the *Bedtime* page.
  - d. In the *Bedtime* page, select the toggle button to enable the bedtime and click **Done**.


## Configure website blocking

### 11

---

Configure website blocking for the profile:

- a. In the profile page, click the edit icon  next to **Website blocking** to control websites and services that devices assigned to the profile can access.
- b. Click **Continue**.
- c. In the *Website blocking* page, perform the following:



1. Select the toggle button next to **Filtering** to enable filtering to control the profile's website access.
2. Click **Add +** to add a website URL to be blocked.
3. Enter the URL in the Website URL field and click **Save**.



4. Click **Add +** to add more website URLs to be blocked or click **Done**.


END OF STEPS

## 7.33 Configuring DMZ and ALG

1

Click **Security**→**DMZ and ALG** in the left pane. The *DMZ and ALG* page displays.

Figure 7-40 DMZ and ALG page



2

Configure the following parameters:

Table 7-23 ALG Configuration parameters

Field	Description
ALG Configuration	Select the toggle button next to the protocol name to enable the protocols to be supported by ALG: <ul style="list-style-type: none"> <li>• FTP</li> <li>• TFTP</li> <li>• SIP</li> <li>• H323</li> <li>• RTSP</li> <li>• L2TP</li> <li>• IPSEC</li> <li>• PPTP</li> </ul>

3 \_\_\_\_\_  
 Click **Save**.

4 \_\_\_\_\_  
 Configure the following parameters:

Table 7-24 DMZ Configuration parameters

Field	Description
WAN connection list	Select a WAN connection from the list.
Enable DMZ	Select the toggle button to enable DMZ on the WAN connection.
DMZ IP address	Select <b>Custom Settings</b> and enter the DMZ IP address or select the IP address of a connected device from the list.

5 \_\_\_\_\_  
 Click **Save**.

END OF STEPS \_\_\_\_\_

## 7.34 Configuring Access Control

This procedure describes how to configure the access control level (ACL).

**i** **Note:** ACL takes precedence over the firewall policy.  
 The trusted network will be shared for all WAN connections; it is not applied individually to a WAN connection.

1 \_\_\_\_\_  
 Click **Security**→**Access control** in the left pane. The *Access control* page displays.

Figure 7-41 Access control page

Security / **Access control** ↻

WAN connection list 1\_TR069\_INTERNET\_OTHER\_R\_VID\_0 ▾

Enable trusted network

WAN		LAN	
ICMP	Allow ▾	ICMP	Allow ▾
Telnet	Deny ▾	Telnet	Deny ▾
SSH	Deny ▾	SSH	Allow ▾
HTTP	Deny ▾	HTTP	Allow ▾
TR-069	Allow ▾	TR-069	Deny ▾
HTTPS	Deny ▾	HTTPS	Allow ▾
SFTP	Deny ▾	SFTP	Deny ▾

**Save**

**Trusted network**

Source IP start

Source IP end

**Add +**

2

Configure the following parameters:

Table 7-25 Access control parameters

Field	Description
WAN connection list	Select a WAN connection from the list.
Enable trusted network	Select the toggle button to enable a trusted network.
WAN	The following protocols are supported: ICMP, Telnet, SSH, HTTP, TR-069, HTTPS, SFTP. Select an access control level for each protocol: <b>Allow, Deny, or Trusted Network Only</b> LAN side: <b>Allow</b> or <b>Deny</b>
LAN	The following protocols are supported: ICMP, Telnet, SSH, HTTP, TR-069, HTTPS, SFTP. Select an access control level for each protocol: LAN side: <b>Allow</b> or <b>Deny</b>

3

Click **Save** to save the ACL configuration.

4

If the **Enable trusted network** option is enabled, add one or more subnet trusted networks. You can add up to 32 trusted networks.

Table 7-26 Trusted Network parameters

Field	Description
Source IP start	Enter a start IP address range for the new subnet trusted network.
Source IP end	Enter an end IP address range for the new subnet trusted network.

5

Click **Add +**.

**END OF STEPS**

## Advanced Settings

### 7.35 Overview

This section describes the advanced settings that can be performed from the following sub-menu options under the **Advanced settings** menu:

Sub-menu	Procedure
<b>Port forwarding</b>	7.36 "Configuring Port Forwarding" (p. 133)
<b>Port triggering</b>	7.37 "Configuring Port Triggering" (p. 134)
<b>DDNS</b>	7.38 "Configuring DDNS" (p. 135)
<b>NTP</b>	7.39 "Configuring NTP" (p. 137)

### 7.36 Configuring Port Forwarding

1

Click **Advanced settings** → **Port forwarding** in the left pane. The *Port forwarding* page displays.

Figure 7-42 Port forwarding page

Advanced settings / Port forwarding ↻ Save

WAN port  -

LAN port  -

Internal client  Custom Settings ▾

Protocol  ▾

WAN connection list  ▾

2

Configure the following parameters:

Table 7-27 Port forwarding parameters

Field	Description
WAN port	Enter the WAN port range.

Table 7-27 Port forwarding parameters (continued)

Field	Description
LAN port	Enter the LAN port range.
Internal client	Select a connected device from the list and enter the associated IP address. The default is <b>Custom Settings</b> .
Protocol	Select the port forwarding protocol from the list: <ul style="list-style-type: none"> <li>• TCP</li> <li>• UDP</li> <li>• TCP/UDP</li> </ul>
WAN connection list	Select a WAN connection from the list. Only active devices are displayed in the list.

3

Click **Save**.

END OF STEPS

## 7.37 Configuring Port Triggering

1

Click **Advanced settings**→**Port triggering** in the left pane. The *Port triggering* page displays.

Figure 7-43 Port triggering page

Advanced settings / Port triggering

Open port: [ ] - [ ]

Triggering port: [ ] - [ ]

Expiration time: 600  
Range: 1-999999 secs

Open protocol: TCP

Trigger protocol: TCP

WAN connection list: 1\_INTERNET\_OTHER\_R\_VID\_400

Save

2

Configure the following parameters:

Table 7-28 Port triggering parameters

Field	Description
Open port	Enter the open port range.
Triggering port	Enter the triggering port range.
Expire time	Enter the expiration time in seconds. Allowed range: 1 to 999999 seconds
Open protocol	Select the open port protocol from the list: <ul style="list-style-type: none"><li>• TCP</li><li>• UDP</li><li>• TCP/UDP</li></ul>
Trigger protocol	Select the triggering port protocol from the list: <ul style="list-style-type: none"><li>• TCP</li><li>• UDP</li><li>• TCP/UDP</li></ul>
WAN connection list	Select a WAN connection from the list. Only active devices are displayed in the list.

3

Click **Save**.

END OF STEPS

## 7.38 Configuring DDNS

1

Click **Advanced settings** → **DDNS** in the left pane. The *DDNS* page displays.

Figure 7-44 DDNS page

2

Configure the following parameters:

Table 7-29 DDNS parameters

Field	Description
WAN connection list	Select a WAN connection from the list.
Enable DDNS	Select the toggle button to enable DDNS on the WAN connection.
ISP	Select an ISP from the list.
Domain Name	Enter the domain name of the DDNS server.
Username	Enter the username.
Password	Enter the password.

3

Click **Save**.

**END OF STEPS**



## 7.39 Configuring NTP

1

Click **Advanced settings**→**NTP** in the left pane. The *NTP* page displays.

Figure 7-45 NTP page

Advanced settings / **NTP**

Enable NTP service

Current date & time 07/19/2022 12:33:04 PM

Primary Time Server time.nist.gov

Secondary Time Server Custom Settings  
ntp1.tummy.com

Third time server None

Interval time 0  
0,15-259200 secs

Time zone (GMT-00:00) Greenwich Mean Time: Dublin

Save

2

Configure the following parameters:

Table 7-30 NTP parameters

Field	Description
Enable NTP service	Select the toggle button to enable the NTP service.
Current date & time	Displays the current local date and time.
Primary Time Server Secondary Time Server Third Time Server	Select a time server from the list or select <b>Custom Settings</b> and enter the IP address of the time server. You can select <b>None</b> if you do not want configure a secondary or tertiary time server.

---

Table 7-30 NTP parameters (continued)

Field	Description
Interval time	Enter the interval at which to get the time from the time server, in seconds. Allowed values: 0 to 259200 seconds
Time zone	Select the local time zone from the list.

**3** \_\_\_\_\_

Click **Save**.

**END OF STEPS** \_\_\_\_\_

## Maintenance

### 7.40 Overview

This section describes the maintenance procedures that can be performed from the following sub-menu options under the **Maintenance** menu:

Sub-menu	Procedure
<b>Change password</b>	7.41 "Configuring the Password" (p. 139)
<b>Backup and restore</b>	7.42 "Backing Up the Configuration" (p. 141) 7.43 "Restoring the Configuration" (p. 141)
<b>Firmware upgrade</b>	7.44 "Upgrading Firmware" (p. 142)
<b>Diagnostics</b>	7.45 "Diagnosing WAN Connections" (p. 144)
<b>Log</b>	7.46 "Viewing Log Files" (p. 147)

### 7.41 Configuring the Password

A password must adhere to the following password rules:

- The password may consist of uppercase letters, lowercase letters, digital numbers, and the following special characters ! # + , - / @ \_ : = ]
- The password length must be from 8 to 24 characters
- The first character must be a digital number or a letter
- The password must contain at least two types of characters: numbers, letters, or special characters
- The same character must not appear more than 8 times in a row

When the password meets the password rules, the application displays the message "Your password has been changed successfully".

When the password does not meet the password rules, the application displays a message to indicate which password rule has not been followed, for example:

- The password is too short
- The password is too long
- The first character cannot be a special character
- There are not enough character classes

1

Click **Maintenance**→**Change password** in the left pane. The *Change password* page displays.

Figure 7-46 Change password page

Maintenance / **Change password**

Original password

New password

Letters (upper or lower case)  
 Numbers  
 Special characters (!#+,-./;=@\_)  
 At least 8 characters in length

Repeat new password

Password hint

This is the hint for your password if you forgot it.

**Save**

2

Configure the following parameters:

Table 7-31 Change password parameters

Field	Description
Original password	Enter the current password.
New password	Enter the new password as per the password rules.
Repeat new password	Re-enter the new password (must match the password entered above).
Password hint	Enter the password hint message.

3

Click **Save**.

**END OF STEPS**


---

## 7.42 Backing Up the Configuration

1

Click **Maintenance**→**Backup and restore** in the left pane. The *Backup and restore* page displays.

Figure 7-47 Backup and restore page



2

Click **Export** to export the current Beacon configuration to your PC. The configuration filename is *config.cfg*.

END OF STEPS

## 7.43 Restoring the Configuration




**Note:** Ensure that you have a previously backed-up configuration file.

1

Click **Maintenance**→**Backup and restore** in the left pane. The *Backup and restore* page displays.

Figure 7-48 Backup and restore page



2 \_\_\_\_\_

Click **Select** and select the previously backed-up configuration file.

3 \_\_\_\_\_

Click **Import** to import the configuration file and restore the Beacon to the backed-up configuration.

A confirmation message displays after successful restore and the Beacon reboots.


END OF STEPS \_\_\_\_\_

## 7.44 Upgrading Firmware

1 \_\_\_\_\_

Click **Maintenance**→**Firmware upgrade** in the left pane. The *Firmware upgrade* page displays.

Figure 7-49 Firmware upgrade page



---

2 Click **Select** and select the file for firmware upgrade.

3 Click **Upgrade** to upgrade the firmware. The status displays in the *Upgrade status* panel. The device reboots after firmware upgrade and displays the login page.

Figure 7-50 Example of upgrade status messages

## Upgrade status

### Upgrade Done!

---

get\_cert\_type\_from\_buildinfo NCG

Image check pass, everything is OK

Saving config files...

Performing system upgrade...

Upgrade completed

4

mkdir: can't create directory '/configs/swdl': File exists

sh: using fallback suid method

sync: using fallback suid method

date: using fallback suid method

Upgrade ok, Rebooting...

END OF STEPS

---

## 7.45 Diagnosing WAN Connections

1

Click **Maintenance**→**Diagnostics** in the left pane. The *Diagnostics* page displays.

Figure 7-51 *Diagnostics* page

The screenshot shows the 'Maintenance / Diagnostics' page. The 'WAN' section is active. It contains the following fields and controls:

- Protocol:** A dropdown menu set to 'IPv4'.
- WAN connect list:** A dropdown menu set to 'LAN/WAN Interface'.
- IP or domain name:** An empty text input field.
- Ping:** A toggle switch that is turned on.
- Traceroute:** A toggle switch that is turned on.
- Ping try times:** A numeric input field set to '4', with a range of '1-1000' below it.
- Packet length:** A numeric input field set to '64', with a range of '64-1500' below it.
- Max number of trace hops:** A numeric input field set to '30', with a range of '1-255' below it.

At the bottom of the form are two buttons: 'Start test' (in blue) and 'Cancel'.

2

Configure the following parameters.

Table 7-32 *Diagnostics* parameters

Field	Description
WAN connection list	Select a WAN connection to diagnose from the list.
IP or domain name	Enter the IP address or domain name.



Table 7-32 *Diagnostics* parameters (continued)

Field	Description
Ping	Select this toggle button to enable ping.
Traceroute	Select this toggle button to enable traceroute.
Ping try times	Enter the number of ping attempts. This field is enabled only if you select the <b>Ping</b> toggle button. Allowed values: 1 to 1000 Default value: 4
Packet length	Enter a packet length. Allowed values: 64 to 1500 Default value: 64
Max number of trace hops	Enter the maximum number of trace hops. This field is enabled only if you select the <b>Traceroute</b> toggle button. Allowed values: 1 to 255 Default value: 30

3

Click **Start test** to start the test. Results are displayed at the bottom of the page.

---

Figure 7-52 Example of ping results

```
PING 192.168.18.10 (192.168.18.10): 64 data bytes
72 bytes from 192.168.18.10: seq=0 ttl=64 time=49.398 ms
72 bytes from 192.168.18.10: seq=1 ttl=64 time=75.414 ms
72 bytes from 192.168.18.10: seq=2 ttl=64 time=102.160 ms

72 bytes from 192.168.18.10: seq=3 ttl=64 time=123.691 ms
```

```
--- 192.168.18.10 ping statistics ---
```

```
4 packets transmitted, 4 packets received, 0% packet loss
```

```
round-trip min/avg/max = 49.398/87.665/123.691 ms
```

Figure 7-53 Example of traceroute results

```
traceroute to 192.168.18.10 (192.168.18.10), 30 hops max, 64 byte packets
```

```
1 192.168.18.10 52.241 ms 5.023 ms 3.396 ms
```

**END OF STEPS**

---

## 7.46 Viewing Log Files

1

Click **Maintenance**→**Log** in the left pane. The *Log* page displays.

Figure 7-54 Log page

2

Configure the following parameters:

Table 7-33 Log parameters

Field	Description
Writing level	Select a writing level from the list to determine the event types recorded in the log file: <ul style="list-style-type: none"> <li>• <b>Emergency</b></li> <li>• <b>Alert</b></li> <li>• <b>Critical</b></li> <li>• <b>Error</b></li> <li>• <b>Warning</b></li> <li>• <b>Notice</b></li> <li>• <b>Informational</b></li> <li>• <b>Debug</b></li> </ul>
Reading level	Select a reading level from the list to determine the event types displayed in the log file: <ul style="list-style-type: none"> <li>• <b>Emergency</b></li> <li>• <b>Alert</b></li> <li>• <b>Critical</b></li> <li>• <b>Error</b></li> <li>• <b>Warning</b></li> <li>• <b>Notice</b></li> <li>• <b>Informational</b></li> <li>• <b>Debug</b></li> </ul>

3 \_\_\_\_\_  
Click **Save**. The log file is displayed at the bottom of the page.

4 \_\_\_\_\_  
Click **Export log** to download the log file to your PC. The filename of the log is *onu\_info.log*.

END OF STEPS \_\_\_\_\_

## 7.47 Viewing Container Management

1 \_\_\_\_\_  
Click **Maintenance**→**Container management** in the left pane. The *Container management* page displays.

Figure 7-55 Container management page



2 \_\_\_\_\_  
Configure the following parameters:

Table 7-34 Container management parameters

Field	Description
App name	Indicates the name of the application.
Version	Indicates the version of the application.
Status	Displays the status of the application: <ul style="list-style-type: none"><li>• Active</li><li>• Idle</li></ul>

END OF STEPS \_\_\_\_\_

## Troubleshooting

### 7.48 Troubleshooting counters

The Troubleshooting counters feature enables service providers and end users to monitor the performance of their broadband connection for about 10 seconds from the time the test is triggered.

Tests are run to retrieve upstream and downstream throughput, latency, and DNS response time. The Troubleshooting counters page also displays upstream and downstream packet loss and Internet status.

1

Click **Troubleshooting**→**Troubleshooting counters** in the left pane. The *Troubleshooting counters* page displays.

Figure 7-56 Troubleshooting counters page



2

Configure the following parameters:

Table 7-35 Troubleshooting counters parameters

Field	Description
WAN Connection List	Select a WAN connection from the list.
WAN Status	Displays the WAN status: <ul style="list-style-type: none"> <li>• Up</li> <li>• Down</li> </ul>
<b>Troubleshoot counters</b>	
US throughput	This test is used to determine the upstream throughput/speed. Click <b>US speed test</b> to specify the time for the upstream test.
DS throughput	This test is used to determine the downstream throughput/speed. Click <b>DS speed test</b> to specify the time for the downstream test.
US packet loss	Displays the number of upstream packages lost.
DS packet loss	Displays the number of downstream packages lost.
Latency	This test is used to determine the lowest round-trip time in milliseconds by pinging the target server multiple times. Click <b>Latency test</b> to specify the time for the test.
DNS response time	This test is used to determine the lowest round-trip time in milliseconds by sending a request to the target DNS server. Click <b>DNS response test</b> to specify the time for the test.
<b>Port mirrors</b>	
Source port	Select a source port for port mirroring from the list.
Destination port	Select a destination port for port mirroring from the list.
Direction	Select a direction from the list: <ul style="list-style-type: none"> <li>• <b>Upstream</b></li> <li>• <b>Downstream</b></li> </ul>
Status	Select a port mirroring status from the list: <ul style="list-style-type: none"> <li>• <b>Enable</b></li> </ul>

3

Click **Save**.

END OF STEPS

## 7.49 Viewing Speed Test

1

Click **Troubleshooting** → **Speed test** in the left pane. The *Speed test* page displays.

Figure 7-57 Speed test page




Table 7-36 Speed test parameters

Field	Description
Upload speed	Displays the upload speed.
Download speed	Displays the download speed.
Latency	Displays the latency.

2

Click **Start test** to start the speed test.

**END OF STEPS**

