

## Wall Mounted Reader Installation

This installation guide applies to the following types of readers:

- ET20 – Single Gang Reader
- ET25 – Single Gang Reader with Keypad

### Included:

- (2) #6 Screws
- Reader, Backplate, and Wall Plate
- (1) #4-40, (1) pin-in-torx
- (4) #4 Screws


The Following tools will be needed to install a wall mount reader:

- Phillips Screwdriver
- 1" (25mm), 1/8" drill bits
- T8 Security Torx Bit (optional for increased tamper detection)


## 1 Install Metal Wall Plate to Single Gang Box

Connect the wall plate to the single gang box using the provided #6 screws. Alternatively, you can use the provided #4 screws in the four outer holes for other installation requirements. Drywall installations will require molly bolts.

Standard Single Gang Box Installation



Alternative for situations outside of a single gang box installation



## 2 Wire the Cable to the Control Panel


Common Cable Connections	
Red	Power In
Black	Ground
Shield	Shield Ground
Brown*	Tamper Out
Green	Wiegand Data 0 / RS 485A
White	Wiegand Data 1 / RS 485B
Yellow*	Beeper Control
Blue*	Green LED Control
Orange*	Red LED Control

\*these wires are only used in Wiegand readers.

Max Length to Panel	
Length	AWG
200' (60 m)	22
300'	20
500'	18
Current @ 12 V and 25 C	
Avg. mA	Max. mA
110	160
Current for ET25 @ 12 V and 25 C	
Avg. mA	Max. mA
140	190


## 3 Attach the Reader to the Wall plate

Align the reader so that the tabs of the base plate slide into the slots on the wall plate and slide the reader into position.



## 4 Install the Reader Screw

Install the #4-40 screw or pin-in-torx at the bottom of the reader.



Screw or pin-in-torx

## 5 Test the Reader

Power the reader and wait for the power up LED beep sequence to complete. Present a valid credential to the reader and the light-bar will turn green.

### Installation tips:

When connecting the reader to a Wiegand panel, simply connect the Green wire to Data 0, and the White wire to Data 1, to enable Wiegand communication. When connecting the reader to an OSDP panel, connect the Green wire to RS485A, and the White wire to RS485B. Verify that the panel is successfully communicating with the reader prior to reading a badge or pressing a key.

The number of beeps during the power-up reset sequence indicates what mode the reader is in:

- 4 beeps (with green LED flash) indicate that the reader is in Wiegand communication mode (with OSDP auto-detect)
- 2 beeps (with green LED flash) indicate that the reader is in OSDP-only communication mode

By default (out-of-the-box) the reader will transmit credential and keypad data in Wiegand communication mode. Upon each power up, and before the reader reads a credential or a key is pressed, the reader will be listening for an incoming OSDP message. If a message is received during this period, the reader will automatically switch to OSDP-only communication mode. To return to OSDP auto-detect mode, tilt the reader 45 degrees to simulate tamper and cycle power in this state. The power up sequence should indicate OSDP auto-detect with 4 beeps.

Upon a power reset, the Ethos® Readers provide a reset sequence using the LED indicator and the beeper, to provide information about the reader type and its communication mode. The first sequence (sequence A) describes the credential technologies built in the reader:

- A single red LED flash indicates Bluetooth credential support
- A single green LED flash indicates 13.56 MHz credential support
- A single amber LED flash indicates 125 kHz credential support

Sequence A is followed by sequence B. Sequence B indicates the reader communication protocol:

- Two beeps (with green LED Flash) indicate that the reader is in OSDP-only communication mode
- Four beeps (with green LED Flash) indicate that the reader is in Wiegand communication mode (with OSDP auto-detect)

### Patents - US9558377, & US9747738B1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Wavelynx could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.