



# Wireless Phone Monopod

## TO USE

1. To turn on, hold the handle button for 3 seconds. A blinking indicator means pairing mode.
2. Activate Bluetooth on your device and search and pair to "Flexion SelfieStick".
3. Place and adjust your phone in the holder. Adjust the stick to your desired range.
4. Press the handle button for perfect selfies.
5. To turn off, hold the handle down for 3 seconds until the lights turn off. Use the provided charging cable to charge your device.

CHARGING TIME: 1 hour  
STANDBY TIME: 100 hours

CHARGING VOLTAGE: DC 5.0V  
SELFIE POTENTIAL: ∞



# Wireless Phone Monopod

## SAFETY GUIDELINES

Let's face it, this is no GoPro; you're taking selfies like a tourist or doing other less extreme activities. As such, do not use this anywhere you would not comfortably use your phone.

1. This includes very high temperatures and humidity. We can't promise that sauna selfie is going to turn out well anyway.
2. Avoid use during inclement weather such as heavy rain. May #StormSelfie never be a thing.
3. Our selfie stick has sensitive skin. Avoid dismantling the product or cleaning it with corrosive

#### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.