



Brookstone®

Wireless 3D Headphones

VIRTUAL 3D SURROUND SOUND
ACTIVE NOISE CANCELLATION



324395_Wireless 3D Headphones
Size: 101mm W x 114 mm H_Output:100%_Prints:1/1,Blk

TABLE OF CONTENTS

Cautions.....	1
FCC Information.....	1
Lithium-Ion Battery Warning.....	3
Location of Parts and Controls	4
Charging the Battery.....	5
Pairing with Bluetooth®	6
Operation	7
Connecting Without Bluetooth®	8
Use with Android Devices	9
Care and Maintenance.....	10
Specifications	11
Warranty.....	12

CAUTION

- When used in Noise Cancelling mode, these earbuds diminish your ability to hear background noise. For your safety and the safety of others, do not use Noise Cancelling mode while driving, cycling, or in any situation where reduced ability to hear your surroundings may be hazardous.
- Listening to audio at a high volume may affect your hearing.
- Do not reach for a unit that has fallen into water while charging. Unplug it immediately.
- Do not drop, crush, bend or apply excessive force to the device.
- Do not expose the device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storage in damp, humid or wet locations.
- Do not remove the cover from the headphones. There are no serviceable parts inside.

FCC INFORMATION

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

WARNING: To comply with FCC's RF radiation exposure limits for general population/uncontrolled exposure.

FCC ID: 2AFVN-AR120A2XXA

LITHIUM-ION BATTERY WARNING

This device contains a rechargeable Lithium-Ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

Use only the supplied cable to recharge the battery. Improper charging may damage the battery and the device.


Do not attempt to open the rechargeable battery or battery pack. There are no serviceable parts inside.

Keep the battery out of reach of children. If swallowed, consult a physician immediately.

Do not dispose of battery in a fire as it may explode. Battery may also explode if damaged.



LOCATION OF PARTS AND CONTROLS



CHARGING THE BATTERY

Charge the battery before first use.

If the device is not used for a long period of time, the battery may require recharging. The ANC Indicator flashes red and green alternately when the battery is low. To prolong battery life, recharge the headphones at least once every six months.

To charge the battery:

1. Plug the Micro-USB end of the Charging Cable into the Micro-USB Charging Port.
2. Plug the USB end of the Charging Cable into a USB port on an active device. The Charging Indicator glows red while charging.
3. When fully charged, the Charging Indicator light turns off. Disconnect the Charging Cable from both ports.

PAIRING WITH BLUETOOTH®

1. Prepare your device (e.g., smartphone) to pair using Bluetooth®, making sure that the device is within 33 feet of the headphones. Refer to your device's owner's manual for information on using the Bluetooth® function.
2. Slide the Power Switch to the ON position (down). The Bluetooth® Indicator quick flashes blue, indicating that the headphones are in pairing mode.
3. On your device, search the list of available devices and select Noise Cancel Headphones. Note that it may take a few seconds for the headphones to be listed as an available device. Depending on your device, you may have to tap SCAN to update the device list. Consult your device's owner's manual.
4. If prompted, type the password or PIN 0000.
5. When the devices are successfully paired, the Bluetooth® Indicator glows solid blue.

Once paired, the devices will remain paired, even after being turned off, until you delete the connection.

To pair the headphones with another device, press and hold the Multi-Function Button (MFB) for more than 5 seconds to re-enter the search state, then repeat Steps 3 through 5 above. You can reconnect with the previous device at a later time without repeating the pairing step.

To delete all Bluetooth connections, press ANC and VOL + at the same time for more than 5 seconds. Remember to remove the Noise Cancel Headphones from the connections list on your device. To reconnect you will have to repeat the pairing step.

NOTE: You can also use your headphones without a Bluetooth® connection. See Page 8.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.

OPERATION

1. Slide the Power Switch to the ON position (down).
2. The ANC Indicator glows green, indicating that the Active Noise Cancelling (ANC) function is activated. To turn off ANC, press the ANC Button.
3. Position the headphones on your head. Note that the headphones are marked with R and L, indicating the right and left ears. Position accordingly.
4. Adjust the headband for a comfortable fit. Ensure that the headphones properly cover your ears to achieve the best noise reduction.
5. To play music:

Function	Button
Play/pause music	Press the MFB.
Next song	Double-click the MFB.
Replay current song	Triple-click the MFB.
Volume up	Press Vol +. Hold Vol + to continue to increase volume. A tone sounds when the maximum volume, as set on your device, is reached.
Volume down	Press Vol -. Hold Vol - to continue to decrease volume. A tone sounds when the minimum volume is reached.

6. To answer calls:

Function	Button
Answer a call	Press the MFB when there is an incoming call.
Reject a call	Press and hold the MFB.
End a call	Press the MFB while in a call.

CONNECTING WITHOUT BLUETOOTH

When a Bluetooth® connection is unavailable or your battery is low, you can connect the headphones to your device using the Audio Cable.

To use the Audio Cable:

1. Plug one end of the Audio Cable into the Audio Jack in the headphones. The Bluetooth® Indicator automatically turns off.
2. Plug the other end of the Audio Cable into a 3.5 mm audio jack in your device (e.g., smartphone or other device).
3. Enjoy your music.

NOTE: The MFB and Volume buttons require Bluetooth® and are not functional when using the Audio Cable.

You can use the Audio Cable with the power switched off or on. The music quality will be enhanced with the power switched on because you can use the ANC feature to reduce background noise.

USE WITH ANDROID™ DEVICES

If you are using an Android™ device, note the following:

- When there is an incoming call, the ringtone heard through the headphones will be slightly delayed.
- While playing music, the sound may be interrupted. Turn the headphones off and back on to restart.
- While playing music while playing a video, the sound may be interrupted. Stop the background program and turn the headphones off and back on to restart.

Android™ is a trademark of Google, Inc.

CARE AND MAINTENANCE

Clean the headphones with a soft cloth or damp chamois leather. Never use solvents or harsh cleaning products.

Do not submerge in water or other liquids.

Store in a cool, dry location.

SPECIFICATIONS

Bluetooth	4.2
Maximum Range	> 10m
Support Encoding Format	aptX,AAC,SBC
Frequency Range	20-20K Hz
Sensitivity	103dB/mW
Driver Specification	40mm
Driver Impedance	32 Ohms
ANC Peak Value	>25dB
ANC Bandwidth	20-1K Hz
Battery	600mAh Lithium Battery
Weight	Approx. 9.2 oz (260g)
Battery Life	Up to 24 hours

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative

of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or lightbulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Find thousands more
great ideas online

Brookstone®

324395

Rev 1

©Brookstone 2017

Brookstone.com • 1-800-846-3000
1 Innovation Way, Merrimack, New Hampshire 03054