


Parrot

DISCO



USER GUIDE

GUIDE UTILISATEUR

GUÍA DEL USUARIO

BENUTZERHANDBUCH

GUIDA UTENTE


HANDLEIDING

GUIA DO USUÁRIO


دليل المستخدم المختصر

PRESENTATION OF THE PARROT DISCO

GENERAL



CHUCK AUTOPILOT UNIT



BEFORE GETTING STARTED

DOWNLOAD THE FREEFLIGHT PRO APPLICATION

Login to the App Store® or Google Play™ and download the free FreeFlight Pro application to your smartphone or tablet.

CHARGING THE PARROT DISCO'S BATTERY

⚠ The battery must be disconnected from the Parrot Disco.


1. Select the plug for your country and put it on the charger.
2. Connect the cable to the charger.
3. Connect the battery to the charger's cable, and then plug the charger into the mains.

The warning light is red while charging and then turns green when the battery is charged.


The battery charge time is approximately 55 minutes.

The flight time is approximately 45 minutes.


FITTING THE BATTERY



1. Remove the Parrot Disco's cowling.




2. Place the battery in the slot provided for this purpose.




3. Plug the battery into the Parrot Disco.

4. Close the Parrot Disco's cowling.

ATTACHING THE WINGS



Attach the wings to either side of the Parrot Disco.



Make sure the wings are properly secured in the servomotors.

To remove the wings, pull on them.

⚠ Do not move the servomotors with your hand to avoid damaging them.

PRE-FLIGHT CHECKS

Before each flight with Parrot Disco, make the following checks:

REGULATIONS

- Make sure that the use of Parrot Disco is allowed where you are going to fly.
- Check the restrictions regarding the use of Wi-Fi® frequencies in the place where you are going to fly.
- Check the regulations on the use of FPV goggles when flying a drone where you are going to fly.

FLIGHT CONDITIONS


- Make sure you have at least 80 meters in diameter of clear space for your Parrot Disco to take off and land. Make sure the airfield has no obstacles that may hinder piloting or prevent visual flight.
- Do not fly the Parrot Disco at night.
- Do not fly the Parrot Disco over an urban area or in certain places in the public domain (for example: train stations, airports, etc.).
- Check weather conditions. Do not fly the Parrot Disco in rain, fog, snow or wind over 12 meters per second or 43 km/h.

PARROT DISCO


- Make sure the Parrot Disco's wings are properly secured (see the Attaching the wings section).
- Make sure the Parrot Disco's battery and your remote control's battery are charged (see the Fitting the battery section).
- Make sure the Parrot Disco's cowling is properly closed.
- Make sure the Parrot Disco's warning light is green. This means the Parrot Disco has acquired the GPS signal.

PILOTING CONFIGURATIONS


There are three piloting configurations.
Familiarise yourself with no. 1 and no. 2 before using no. 3.



Parrot Skycontroller 2
alone



Parrot Skycontroller 2
and smartphone



Parrot Skycontroller 2 and
Parrot Cockpitglasses

CONNECTING TO THE PARROT DISCO

CONNECTING THE PARROT SKYCONTROLLER 2 TO THE PARROT DISCO


1. Place the Parrot Disco on a flat surface.
2. Press the Parrot Disco's On/off button.
> The button flashes red and green once the GPS is connected.
3. Press the Parrot Skycontroller 2's ON/OFF button to turn it on.
4. Wait until the warning light is a steady green.

You are connected to the Parrot Disco.


If the warning light continues to flash red, you need to calibrate the Parrot Disco. To do this:

1. In the FreeFlight Pro application, go to **Settings > Position, Distances and limits > Gyroscope > Calibrate.**

2. Rotate the Parrot Disco on the Z-axis (yaw).




3. Rotate the Parrot Disco on the Y-axis (pitch).




4. Rotate the Parrot Disco on the X-axis (roll).


> The warning light flashes green. The Parrot Disco is calibrated.




DÉCOLLER

⚠ Vous devez décoller face au vent.

1. Placez-vous face au vent en maintenant le corps du Parrot Disco d'une main.
2. Assurez-vous que le moteur du Parrot Disco est complètement dégagé.
3. Appuyez sur le bouton  de votre Parrot Skycontroller 2.
 - > Le moteur du Parrot Disco tourne lentement pendant 3 secondes puis accélère.
 - > Une fenêtre pop-up «**Ready to take off**» s'affiche sur l'écran de votre smartphone. Vous pouvez décoller.
4. Lancez le Parrot Disco légèrement vers le haut.




> Le Parrot Disco décolle. Il s'élève à 50 mètres d'altitude puis effectue des cercles de 60 mètres de diamètre. Vous pouvez alors le piloter.

Note : Pour arrêter le moteur du Parrot Disco, appuyez à nouveau sur le bouton  de votre Parrot Skycontroller 2.

Si vous ne lancez pas le Parrot Disco 10 secondes après avoir appuyé sur Take Off, le moteur se coupe. Appuyez à nouveau sur Take Off pour démarrer une nouvelle procédure de décollage.

CONTROL SCREEN







PILOTING MODES





AUTOPILOT

This mode allows you to securely fly the Parrot Disco. During flight, the Parrot Disco maintains its speed and maintains its altitude.

LEFT CONTROL



LEFT CONTROL



You can configure and customise the commands in the FreeFlight Pro application.

FLIGHT PLAN


You can plan your flights thanks to the In-app Flight Plan, available for purchase in FreeFlight Pro.

⚠️ You must create and load your flight plan before taking off.

PRELOADING A MAP

1. Make sure your smartphone is connected to the Internet.
2. Enable your smartphone's GPS.
3. In the FreeFlight Pro application, go to Menu > Settings.
4. Press Preload map.
 - > A map opens. The blue dot indicates the position of your smartphone.
5. Zoom in on your flight area.
6. Press Preload.
7. After preloading is complete, press [flèche] to return to the previous screen.

CREATING A FLIGHT PLAN

1. Press  to enable waypoint editing.
2. On the map, tap where you want to place your first waypoint.
 - > A numbered bubble appears. The number represents the altitude of the Parrot Disco when passing this point.
3. Continue placing your waypoints.
4. Once you have drawn your path, press and hold the last point of your journey.
 - > A pop-up window appears. Choose the desired landing mode (linear or circular). Warning! Circular landing requires an area of 60 metres in diameter free of obstacles.

Your flight plan is created.

FLYING WITH FLIGHT PLAN

1. Make sure your flight plan is created and loaded.
2. Turn on your Parrot Disco.
3. Wait until the Parrot Disco's warning light turns green. This means that the GPS is connected.
4. Connect your smartphone to the Parrot Disco and start the Free-Flight Pro application.
5. On the Home screen, press Flight Plan.
6. Press Start.
7. Stand facing upwind
8. Make the Parrot Disco take off.
 - > The Parrot Disco begins the course you set.

MANUAL MODE

You can use an RC remote (not included) to fly the Parrot Disco.

Manual mode offers no piloting assistance for the Parrot Disco. Configure the channels of your RC remote for the Parrot Disco. To do this, refer to the manual for your RC remote.

⚠ The Parrot Disco is difficult to control without the assistance of the autopilot. This mode is for expert pilots.

PHOTOS AND VIDEOS

The Parrot Disco can be used in photo mode or video mode.

TAKING PHOTOS

On your Parrot Skycontroller 2, press the **(A)** button to take a photo. The internal memory of the Parrot Disco has a capacity of 32 GB. The maximum number of stored photos depends on the format selected.

For good quality photos, make sure the Parrot Disco is in photo mode.

RECORDING VIDEOS


Recording starts automatically when you press the Take off button. The **●** icon flashes while recording video.

To stop recording, press the **(B)** button.


To record a new video, press **(B)** again.

Note : You cannot take videos when the Parrot Disco is in burst mode.

RETURN HOME

To make the Parrot Disco return to its starting point, press the  button on the Parrot Skycontroller 2 or on the FreeFlight Pro application.

- > The Parrot Disco sets its altitude to 50 meters, comes back towards its starting position and makes 60-meter diameter circles above this position.




 Make sure you are in an open environment.


LANDING


 To avoid damaging the Parrot Disco, land on a suitable surface, such as grass, for example.

LINEAR LANDING

1. Position the Parrot Disco facing upwind.
2. Press the  button on the Parrot Skycontroller 2.
 - > The Parrot Disco descends in a straight line and then straightens and lands softly.

Note : During the descent of the Parrot Disco, you can over-correct: go up, go down, turn left and turn right.





To cancel the landing, press the  button on the Parrot Skycontroller 2.

The Parrot Disco goes up to 50 meters and makes 60-meter diameter circles.

CIRCULAR LANDING

During circular landing, the Parrot Disco makes sure, by itself, that it lands facing upwind so as to limit its landing speed.

1. Make sure you have an area of at least 80 meters in diameter to land the Parrot Disco.
2. In the FreeFlight Pro application, press Circular landing .
 - > The Parrot Disco lands in a spiral.



 Circular landing requires a lot of space.

LOSS OF CONNECTION

If the connection is lost during flight between your Parrot Skycontroller 2 and your Parrot Disco, the Parrot Disco will fly in 60-meter diameter circles for a specified time period (10 seconds by default).

If the connection is not restored, the Parrot Disco returns to its starting position and then flies in 60-meter diameter circles.

If the connection is not restored after 5 minutes, the Parrot Disco performs a circular landing.

TURNING OFF THE PARROT DISCO

To turn off the Parrot Disco, press and hold down the On/Off button.


> The red light flashes, and then the Parrot Disco turns off.

RETRIEVING YOUR PHOTOS AND VIDEOS

ON YOUR COMPUTER

⚠ Always use the micro USB port to the left of the Parrot C.H.U.C.K.

1. Connect the Parrot Disco to your computer with the USB/micro USB (provided).



2. Turn on the Parrot Disco.
 - > Your computer will automatically detect the Parrot Disco.
3. Open the folder as if it were a USB flash drive.
4. Copy the photo and video recordings onto your computer.

ON YOUR SMARTPHONE

To retrieve photos and/or videos from the FreeFlight Pro application:

1. Turn on your Parrot Disco and connect it via Wi-Fi to your smartphone.
2. On your smartphone, launch the FreeFlight Pro application and go to **Menu** ≡ > **Internal Memory**.
 - > The list of photos and videos stored in the internal memory of the Parrot Disco appears.
3. Select one or multiple photos and/or videos.
4. Press Transfer to retrieve the photos and/or videos.

UPDATING THE PARROT DISCO

VIA A SMARTPHONE

1. Connect your smartphone to the Internet.
2. Launch the FreeFlight Pro application.
5. Go to **Menu** ≡ > **Updates**.
6. Select the new version and press **Start**.
 - > The application downloads the update file.
1. Connect your smartphone to the Parrot Disco's Wi-Fi network.
2. Restart the FreeFlight Pro application.
7. Go to **Menu** ≡ > **Updates**.
 - > A pop-up window prompts you to install the update.
8. Press **OK** and wait until the installation is complete.
 - > The Parrot Disco automatically restarts.
9. Make sure the new version has actually been installed: in the FreeFlight Pro application, go to **Menu** ≡ > **Settings**. The version number is shown in the general information.

VIA A COMPUTER

⚠ Always use the micro USB port to the left of the Parrot C.H.U.C.K.

1. Go to the Parrot Disco's support page on www.parrot.com and download the update file available in .plf format.
2. Connect the Parrot Disco to your computer with the USB/micro USB (provided).
3. Turn on the Parrot Disco.
 - > Your computer will automatically detect the Parrot Disco.
4. Open the folder as if it were a USB flash drive.
5. Copy the file to the root, without putting it in a folder. Do not rename the file.
 - > The update launches automatically. The Parrot Disco automatically restarts.
6. Make sure the new version has actually been installed: in the FreeFlight Pro application, go to **Menu** ≡ > **Settings**. The version number is shown in the general information.

VIA A MICRO USB FLASH DRIVE

1. Connect your micro USB flash drive (not provided) to a computer. Make sure that your flash drive does not contain any files in .plf format.
2. Go to the Parrot Disco's support page on www.parrot.com and download the update file available in .plf format.
3. Copy this file to the root of your micro USB flash drive.
4. Turn on the Parrot Disco.
5. Connect the micro USB flash drive to one of the Parrot Disco's ports.
 - > The Parrot Disco automatically restarts and the warning light flashes yellow. Then, the Parrot Disco restarts again.
6. Wait until the Parrot Disco has completely restarted.
7. Disconnect the micro USB flash drive
 - > The update is complete. Make sure the new version has actually been installed: in the FreeFlight Pro application, go to Menu > Settings. The version number is shown in the general information.

WARNING LIGHT INDICATIONS

Flashing red light	The Parrot Disco is starting up. Or The Parrot Disco has detected an error. > Restart the Parrot Disco on a flat, immobile surface, out of the wind. If the problem persists, visit the Parrot Disco's support page on www.parrot.com.
Flashing green light	The Parrot Disco has detected the GPS signal and is ready to take off.
Flashing yellow light	The Parrot Disco update is underway. Do not turn off the Parrot Disco.

SPARE PARTS

You can buy spare parts for the Parrot Disco from our online store : www.parrot.com.

For more information on the assembly of spare parts, see the video tutorials on our support page.

TECHNICAL SPECIFICATIONS

SENSORS

- Ultrasound
- Altimeter
- Hi-speed vertical camera
- Pitot Tube: speed sensor

INERTIAL NAVIGATION SYSTEM

- Three-axis gyroscope
- Three-axis accelerometer.
- Three-axis magnetometer

HARDWARE

- Dual core ARM 9 CPU
- Internal flash memory: 32GB

WI-FI AND TRANSMISSIONS

- Network access point
- AC Wi-Fi, 2 dual band antennae (2.4 and 5 GHz), multiple inputs and outputs
- Up to 2km of range with the Parrot Skycontroller and the Parrot Skycontroller 2.

REMOVABLE BATTERY

- 3 cell 2700mAh / 25A LipoBattery
- Battery life: 45 minutes
- Rated voltage: 11.1V
- 21.6A continuous discharge
- 3.5A max charge
- Operating range: -20°C-60°C

DIMENSIONS

- Weight: 750 gr.
- Size: 1150 mm x 580 mm x 120 mm
- Wingspan: 1150 mm

GPS

- Integrated GPS
- GPS + GLONASS

PERFORMANCE

- Engine: 1280kv
- Servomotor: 5V
- Option of installing an SBUS, SUMD, CPPM radio receiver

VIDEO & PHOTOS

- Full HD 1080p Camera
- Video feed: 360p / 720p

FIRMWARE

- Linux & Open Source SDK for development

BATTERY CHARGER

- Input: 100-240V, 50h-60Hz, 1.2A
- Output: Max 12.6Vdc, 3.5A
- Maximum altitude: 2000m above sea level
- Operating range: 0°C-40°C

PARROT DISCO

- Operating range: 0°C-40°C
- Max current: 15A
- Rated voltage: 11.1V

ACCESSORIES AND SPARE PARTS

The pilot must operate his/her Parrot Disco in his/her line-of-sight at all times in order to avoid any obstacles, and must take care only to use it in suitable locations chosen to ensure that people, animals and property remain safe at all times.

Before flying your Parrot Disco, check your local civil aviation regulation for your country.

ACCESSORIES AND SPARE PARTS

Accessories and spare parts are available from your Parrot retailer or on www.parrot.com.

PRECAUTIONS FOR USE AND MAINTENANCE

The Parrot Disco is a model aircraft designed for recreation and leisure. The pilot must, at all times, maintain eye contact with the Parrot Disco and control its trajectory.

The Parrot Disco must be used according to the rules of civil aviation in your country. The places where it is used must be suitable to its progression in order to continuously ensure the safety of people, animals and property.

Using the Parrot Disco in some public places (for example: train stations, airports, etc.) or on public roads may not be allowed.

As soon as the Parrot Disco's propeller is moving, it can cause damage to people, animals or objects. Always stay a safe distance away from the Parrot Disco. Always pay attention to the Parrot Disco's propeller during take-off. Only use accessories specified by Parrot Drone SAS.

If sand or dust gets into the Parrot Disco, it may be irreparably damaged and no longer function properly.

Do not use the Parrot Disco in adverse weather conditions (rain, strong wind or snow) or when visibility is poor (at night).

Keep the Parrot Disco away from high voltage power lines, buildings or any other potentially hazardous areas.

Do not use this device near liquids. Do not place the Parrot Disco on water or on a wet surface as this could cause irreparable damage.

Avoid making the Parrot Disco undergo significant changes in altitude.

Do not leave the Parrot Disco in the sun.

Risk of ingestion of small objects. The packaging is not part of the product and must be discarded as a safety measure.

WI-FI®

Before you fly your Parrot Disco, check the restrictions regarding the use of Wi-Fi® frequencies in the place where you are going to fly it. Certain frequencies may be restricted or prohibited. In some countries, for example, the use of the 5 GHz Wi-Fi® band may be prohibited outdoors.

WARNING REGARDING PRIVACY AND RESPECT FOR IMAGES OF PROPERTY

Recording and broadcasting an individual's image without their permission may constitute an invasion of privacy and you may be held liable. Ask permission before filming people, especially if you intend to keep your recordings and/or broadcast them. Do not broadcast degrading images which may affect an individual's reputation or dignity.

Recording and broadcasting the image of property without permission from its owner and or any third party holding intellectual property rights on the property may constitute a violation of the property's image rights and you may be held liable. Ask permission from its owner and/or any third party with ownership rights.

BATTERY

WARNING: Failure to follow all the instructions may result in serious injury, irreparable damage to the battery and may cause a fire, smoke or explosion.

Always check the battery's condition before charging or using it. Replace the battery if it has been dropped, or in case of odour, overheating, discolouration, deformation or leakage. Never use anything other than the approved LiPo charger to charge the battery. Always use a balancing charger for LiPo cells or a LiPo cell balancer. It is recommended that you do not use any other charger than the one provided with the product. Never trickle charge or charge under 2.5 V per cell. The battery temperature must never exceed 60 °C (140 °F) otherwise the battery could be damaged or ignite. Never charge on a flammable surface, near flammable products or inside a vehicle (preferably place the battery in a non-flammable and non-conductive container). Never leave the battery unattended during the charging process. Never disassemble or modify the housing's wiring, or puncture the cells. Always ensure that

the charger output voltage corresponds to the voltage of the battery. Do not short circuit the batteries. Never expose the LiPo battery to moisture or direct sunlight, or store it in a place where temperatures could exceed 60 °C (car in the sun, for example). Always keep it out of reach of children.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

WARRANTY

For the warranty conditions, please read the Terms and Conditions of sale of the retailer where you purchased the Parrot Disco.

HOW TO RECYCLE THIS PRODUCT



This symbol on the product or its documentation indicates that it must not be disposed of with household waste. Uncontrolled waste disposal may harm the environment or human health. Please separate your device from other types of waste to recycle it responsibly. This will help to foster the sustainable re-use of material resources. We invite you to contact your retailer or inquire at your local town hall to find out where and how the Parrot Disco can be recycled.

DECLARATION OF CONFORMITY UE



This device can be used in: DE, AT, BE, BG, CY, HR, DK, ES, EE, FI, FR, GR, HU, IE, IT, LV, LT, LU, MT, NL, PL, PT, CZ, RO, GB, SK, SI, SE.

The outdoor use restriction in member states of the European Union relates only to the first in the 5GHz band (5150-5250MHz).

Parrot DRONES, 174 quai de Jemmapes, 75010 Paris, France, hereby declares that it is solely responsible for the compliance of the product described in this user guide with technical standards, EN 301489-1 (v1.9.2), EN 301489-3 (v1.6.1), EN301489-17 (v2.2.1), EN300440-1 (v1.6.1), EN 62311, EN300328 (v1.9.1), EN301893 (v1.7.1), EN300440-2 (v1.4.1), EN 60950-1: 2006/A11: 2009/A1: 2010/A12: 2011/A2: 2013, EN50581 under the provisions of the (R&TTE) Directive 1999/5/EC, the General Product Safety Directive 2001/95/EU and the ROHS Directive 2011/65/EU.

DECLARATION OF CONFORMITY IN CANADA

This device complies with the Industry Canada RSS applicable to license-exempt radio apparatus. Operation is permitted subject to the following two conditions: (1) the device must not produce interference, and (2) the user of the device must accept any radio interference encountered, even if the interference is likely to compromise operations. This category B digital device is compliant with the NMB-003 standard of Canada.

FCC/IC

To comply with FCC/IC RF exposure guidelines for transmission equipment, a distance of at least 20 cm must be maintained between the product antenna and individuals. To remain compliant it is not recommended to use the product at any distance less than this.

TRADEMARKS

Parrot Disco, Parrot Skycontroller, Parrot Cockpitglasses, Parrot C.H.U.C.K as well as their respective logos are trademarks of Parrot Drones SAS.

Parrot and the Parrot logos are trademarks of Parrot S.A.

iPhone is a trademark of Apple Inc., registered in the USA and other countries.

App Store is a trademark of Apple Inc.

Google Play is a trademark of Google Inc.

Samsung, Galaxy S and Galaxy Note are registered trademarks of Samsung Electronics.

Wi-Fi® is a registered trademark of Wi-Fi Alliance®

Linux is a trademark of Linus Torvalds registered in the USA and other countries.

All other trademarks mentioned in this guide are the property of their respective owners. is a trademark of Linus Torvalds registered in the USA and other countries.

MANUFACTURER INFORMATION

The Parrot Disco is manufactured by: PARROT DRONES SAS - 174 Quai de Jemmapes - 75010 Paris (France) - Corporate and Trade Register Paris 808 408 074
www.parrot.com