

## **User Manual**

### **Battery installation**

#### **For Boat unit**

- Turn the rear latch to the side and remove the top cover
- Remove the screws and open the battery door
- Insert 4 AAA batteries (1.5V) and close battery door
- Put the screws back

#### **For Remote unit**

- Remove the screws and open the battery door
- Insert 2 AA batteries (1.5V) and close battery door
- Put the screws back

### **Operation procedure**

- Put the Boat unit in water and make sure the two metal contacts on the bottom of the boat detect water when the boat and remote are turned on
- Use the remote to control the boat
  - The boat will turn left when you press left button
  - The boat will turn right when you press right button
  - The boat will moving forward when you press both buttons
  - The boat will stopped when you release the button

#### **Notes:**

- Please make sure the boat and remote within 10~15meter range.
- Age Recommendation: “5+ years ”and adult supervision required
- If you do not plan to use the boat for a week or longer, remove the batteries from the remote and the boat.

#### **Package Include:**

- Boat unit 1pcs
- Remote unit 1pcs
- User manual 1pcs

#### **Product dimension:**

- Boat unit: L\*W\*H 41cm\*13cm\*10cm
- Remote unit: L\*W\*H 10cm\*8cm\*3cm

#### **Description:**

- Remote Battery:2pc AA (Batteries not included)
- Toy Boat Battery:3PC AA(Batteries not included)
- Range: 10~15 meters
- Duration: 15~18 mins
- Suitable for children of 5 years old & up

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.