










Safety instruction



 Please keep the device in horizontal position
Please use the provided power adapter
Please keep the device away from the heat source to avoid any damage to the machine
Keep the device in a properly ventilated area
Please keep the device away from damp and dusty environment to avoid fire and electric shock
Promptly shut down the device and unplug power adapter if the machine starts emitting smoke or in case there is a burning smell coming out of the device
Please unplug the power adapter in case device is not used for longer time

 Do not put any heavy stu on the top of the device
Please avoid to plug power adapter with wet hands
Please do not disassemble, modify the device by yourself to avoid any shock or damage to the device
Do not use the damaged power cable and plug

Accessory List

The box contains the below accessories

-  Android box
-  Power Adaptor
-  Remote Control
-  HDMI Cable
-  User Manual



System Connection

Please refer to below pictures and instructions to connect TV, Power, Network and other devices.

Note: Before connecting please switch o all the equipment to be connected (such as this device and TV power)

- Connection with TV**
Connect HDMI/AV cable to HDMI/AV port of the Android TV box and TV set.
- Connection with network**
Plug the Ethernet cable to LAN port of the Android TV box, the other side to LAN port of router or Ethernet port of home broadband network.
- Connection with Power**
Connect the power adapter to the Android TV box. After power is on, it can start automatically.

Note: Before powering on, Please switch the signal input of the TV to correct source.
Tips: The Android TV box supports Wi-Fi as well. Go to settings > Network and then select the relevant SSID. Select connect, enter password to Wi-Fi.

Technical Specifications

CPU	Quad core ARM Cortex-A53 up to 1.7GHZ(DVFS)
Android OS	Android 8.1
A/V Output	HDMI2.0b, AV
Video Format	VP9 4K @60fps, H.265 10-bit 4K@60fps, H.264, MPGE, MKV, MP4 and other video formats
Audio Format	AAC, WAV, MP3 and other audio formats
Photo format	JPG, BMP, PNG and other photo formats
Network	Wi-Fi 2.4G 802.11 a/b/g/n/ac RJ45 Interface 10M/100M/1000M adaptive + Bluetooth
Operation temperature	0°C - 40°C
Power Input	AC100-240V 50/60Hz
Power Output	DC 5V/2.5A

Troubleshooting

Issue	Possible reason	Soultion
After turned on, no display	• The power cord is not connected or socket without electricity	• Connect power plug, ensure normal voltage electrical outlet
Tv with images without voice	• Audio cable is not connected • Android TV box in MUTE state • Volume is too low	• Re-connect the Audio cable • Please press mute button • Turn up the volume
Fail to connect the network	• Cable connect is abnormal • Wi-Fi closed or the signal is too weak	• Please reconnect internet • Please restart the Wi-Fi or adjust the position of the router
Controller failure	• Remote control is not in the correct direction • Remote control is with low battery • Remote control is broken	• Please aim at the front panel's SENSOR, then try again • Please change the batteries • Please send it to the local maintenance station for checking

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons