
# **Quick Installation Guide**






# 1. Computer Setting (Windows 7)


1) Click: [Start] - [Control Panel] - [Network and Internet ] - [Network and Sharing Center] - [Change adapter settings] - [Local Area Connection], select the connected network card, Then right click [Local Area Connection] select [Properties]



2) Select [Internet Protocol Version 4(TCP/IPv4)], click [Properties]



 Select [Obtain an IP address automatically], [Obtain DNS Server address automatically], click [OK]. Return back to the previous interface and click [OK]



### 2. Router Setting

- 1. Open the browser, input and connect "http://192.168.1.1", Click [ GO]
- Input the username and password on the login screen (the default username and the password are admin).



### Click [ OK]

3. Router Management screen will appear (Router defauit to relay mode, Select the default and wireless network interface for Wlan2-2. 4G)



4. Set your router network name(SSID)and password

Network Name (2.4G SSID):	W-NET-8014-2.4G	1
Key Value:	12345678	

# **Quick Installation Guide**



 WAN Interface Setup Method1: Automatic obtain (DHCP)

Host Name:	W-NET-8013		(DHCP)	PPPoE Dial-Up
MAC Address Clone:	00:00:00:00:00:00	00000000	00:00:00)	Auto Fill Clear
1ethod2: Fixed IP				
you choose the fixed	IP connection, the subnet Mask, Defauit			

### Method3: PPPoE connection

If you use the PPPoE(ADSL)connection,the PPPoE settings page will appear Show in,please enter the user name and the password provided by your ISP



Choose your best WAN connection, then click "save/apply


## 3.wireless connection: (for example with Windows Windows 7)



2. Select the wireless network name (SSID) in the wireless network list, click 【Connect】



3. Enter Wi-Fi key, click "OK."
Note: the default SSID and Network Key is on the product label on the bottom



4. Connection is successful



### 4. FAQs

4.1 How to reset to defaults

Keep pressing the Reset Button near to the wan port and gurantee the device is in power, releasing it after 5~10 seconds.

- 4.2 Laptop can not search out the wifi signal.
- a. If your laptop is with built-in wireless adapter, please confirm that the wireless adapter is working or not.
- b. Check the wireless service in the laptop is open or not. Methods are as belows: Right-click "my computer", choose "management", then choose 'service and application", check the "wireless Zero Configuration" in the "Service "page. If the stage is not open, please right-click "wireless zero configuration "and click "open". If the open type shows it is forbidden, please right-click and choose the attribute, change the open type to automatic, then change the state to open.
- c. Confirm the wilress function of Router is opening.
- d. Check the driver of the wireless adapter in the device manager is successfully installed or not

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator's your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.