

Front

BLAUPUNKT WIRELESS SPEAKER

for use with Bluetooth® enabled devices



WIRELESS Speaker USER MANUAL


Wireless Speaker

Thank you for purchasing the **BLAUPUNKT** Wireless Speaker. For best use of this device we recommend carefully reading this user manual and keeping it for your records

- Package contains
- a. Wireless Speaker
 - b. USB charging cable
 - c. AUX cable

Product Specifications:

- Bluetooth: V4.2
- Support: L2CAP/A2DP(AVCTP/AVDTP/AVRCP), can receive AUDIO signal and control the AUDIO device.
- Working distance: 10M
- SNR: ≥85db
- Battery: 3.7V 1200mah
- Normal volume playing time: 3H
- Speaker driver: ϕ52mm*2
- Power: 4Ω/5W *2
- Frequency response: 150HZ-20KHZ
- Unit size: 75mm*75mm*162mm
- Unit weight: 501g
- Charging: 5V/500MA – 2A



FCC INFORMATION

FCC ID: 2AML6BB108

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

WARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard, FOR HOME OR OFFICE USE.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

BATTERY INFORMATION

- The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.
- Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.
- Never use any charger or charging cord that is damaged.
- Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 59°F and 77°F. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- Do not dispose of the device in a fire as it may explode. Batteries may also explode if damaged. Always dispose of electronics according to local regulations.
- Do not discard this rechargeable device as trash. Consult your local waste collection agency for proper disposal or recycling methods. You may also contact Call2Recycle at 877-273-2925 or online at call2recycle.org for a battery recycling drop off location near you.

All other trademarks are property of their respective companies.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.




It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for listening to music.



Back

Guide



Product Feature:

- International advanced bluetooth chip and circuit design techniques, support all wireless devices.
- With FM function, can search radio station broadcast automatically
- With Hi-Fi speaker, to make sure the clear and bright sound.
- Support Micro TF card and USB flash drive, play MP3 format audio.
- The wireless working distance is 10 meters.
- With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones.

CHARGING THE BATTERY

1. Plug the charger cable into the MicroUSB port.
2. Connect the charger to a USB power source. The red indicator light will display during charging. Charging the battery fully may take up to 2 hours.
3. When the battery is fully charged, the red indicator light will turn off. Disconnect the charger from the power source and the Speaker. The fully charged battery has power for up to 3 hours of music.

BATTERY SAFETY

Improper usage may result in the Wireless Speaker becoming hot, ignite or burst and cause injury if exposed to conditions of abuse. Be sure to follow the safety warnings listed below:

- Do not disassemble, throw away or damage the Wireless Speaker.
- Store the Wireless Speaker in a dry place, keeping it away from damp corrosive materials and environments such as salt air.
- Keep the Wireless Speaker away from direct sunlight, fire and high voltage equipment. Do not store the Wireless Speaker inside a car during hot weather. Remember a closed car acts as a green house allowing the inside temperature to possibly reach over 200°F.
- The Wireless Speaker is not a toy. Please keep it out of the reach of young children.
- Please do not discard the Wireless Speaker. Consult your local waste collection agency for proper disposal or recycling methods.

2. Instruction

■ Key Function

- 1) To turn on the speaker, Press the Power On/Off button for seconds to turn on the speaker. To turn off the speaker, press and hold the Power On/Off button. To switch between Bluetooth and other speaker modes short press the mode button.
- 2) Activate the Bluetooth® feature on your phone, and set the phone to search for wireless devices (See the User Manual for your device) The speaker will show on your device as **BP1253**. (if pass code is requested enter 0000) A voice prompt will signal that the connection is successful. If not paired, the speaker will turn off automatically after 30 minutes.
- 3) Press the Play/Pause button to play your device's music.
- 4) When the speaker is paired to your mobile device, press Answer/End Calls button to answer the call and press again to end call. Press and hold Answer/End Calls button to reject calls. Press the Answer/End Calls button twice quickly to redial the last number.
- 5) Short press the "+" button to go to the next song or long press the "+" button to turn the volume up.
- 6) Short press the "-" button to go to the last song or long press the "-" button to turn the volume down.

Plug the charging cable into the Micro USB charging port to act an antenna for the speaker. Short press the Mode button once to go to FM radio mode. Short press the Play/Pause button to search for an FM station, the LED light will flash blue quickly while searching for an available station. Press the + or - button to go to the next/last frequency or short press the Play/Pause button to find another available frequency. You can also use a USB flash drive, Memory card or AUX input to play your music. If using AUX feature, connect one end of the Aux cable to the Aux port and the other end of the Aux cable into your music device. A voice prompt will signal that the connection is successful.

LIMITED WARRANTY

World Wide Accessories, Inc. warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser, will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor to any product the exterior of which has been damaged or defaced which has been subjected to misuse, abnormal service or handling or which has been altered or modified in design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty last, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of

The warranties described herein shall be the sole and exclusive warranties granted by World Wide Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of World Wide Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liability or otherwise. In no event shall World Wide Accessories, Inc. be liable or in any way responsible for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

Bubble wrap & Send your device and the product to:

WorldWide Accessories, Inc. Tech Support: 1-800-751-3247
PO Box 194 Techsupport@WorldWideAcc.com
244 Madison Ave.
New York, NY 10016

* Enclose proof of purchase and \$11.95 for Shipping and Handling.