TO CUSTOMERS

Thank you very much for using our transceiver. This transceiver offers latest design, enhanced features, solid performances and easy accessibility.

It is designed to meet different customers' requirements. We believe that you will be pleased with its high quality and stable functions.

SUPPLIED ACCESSORIES

QUANTITY		
1		
1		
1		
1		
1		
1		
1		

Notes before using:

- Do not use the walkie talkie in an explosive environment (such as gas, dust, steam, etc.) or to charge the battery.
- Please turn off the walkie-talkie while refueling or parking at the gas station.
- Do not adapt or modify the machine whether there is any reason.
- Do not let the walkie talkie by prolonged direct sunlight, do not place it near a heating appliance too.
- Do not put the walkie talkie at the extremely dusty, damp and splashing place and do not place it on an unstable surface.
- The repair of the walkie talkie only can be carried out by professional technicians, do not disassemble byyourself.

Note:




Please read above content carefully. It is very important for walkie talkie users to gain generalknowledge and understanding of risk about the use of walkie talkie.

01

1.The Main Function

- Full Band
- High power
- 16 storage channels
- PC programming
- CTCSS/DCS function
- High/low power selective
- Busy channel lockout
- TOT
- Chinese and English voice prompt
- FM radio functions (optional)
- Scan(optional)

03



Voice Operated Transmission

voice prompt on , it will prompt when the channel is changed. chinese or English woice prompt can be selected. This feature can be operated by computer .

■ Time-out Timer (TOT):

The purpose of the Time-out Timer is to prevent any caller from using a channel for a long time. It can be programmed by software(15 seconds ,30 seconds till 600 seconds , the grade difference is 15 seconds)If you continuously transmit for a period of time, the transceiver will stop transmitting and alert . To stop the tone, release the PTT switch. When you press switch again , it will transmit.

Busy Channel Lockout (BCL):

When activated ,BCL prevents you from interfering with other parties who may be using the same channel that you selected. Pressing the PTT switch while the channel is in use will cause your transceiver to emit an alert tone and transmission will be inhibited (you can't transmit). Release the PTT switch to stop the tone and return to receive mode.

2.Basic operation

Switching power ON/OFF:

- 1.Turn on: Turn on the transceiver by turning the power switch/volume control knob clockwise, then a beep sound, if Voice Annunciation is on, the transciver can notify the current channel.
- 2.Turn off: Turn off the transceiver by turning the power switch/volumecontrol knob counterclockwise until a click sounds, the transceiver is power-off.

Adjusting the volume:

Rotate the Power switch/Volume control to adjust the volume. Clockwise increases the volume and counter-clockwise decreases it.

Selecting a channel:

Turn the Channel switch to select channels that you want if your turn on the Voice Annunciation function .it can notify the current channel.

The key to launch the PTT

- Hold PTT buttons and with normal voice speaking. (when firing red light)
- End spoke, loosen PTT key-press, waiting to receive.

Monitor

Hold MONI buttons in the monitoring mode (instantaneous static denoising open)

Voice Operated Transmission

voice prompt on , it will prompt when the channel is changed. chinese or English woice prompt can be selected. This feature can be operated by computer .

■ Time-out Timer (TOT):

The purpose of the Time-out Timer is to prevent any caller from using a channel for a long time. It can be programmed by software(15 seconds ,30 seconds till 600 seconds , the grade difference is 15 seconds)If you continuously transmit for a period of time, the transceiver will stop transmitting and alert . To stop the tone, release the PTT switch. When you press switch again , it will transmit.

Busy Channel Lockout (BCL):

When activated ,BCL prevents you from interfering with other parties who may be using the same channel that you selected. Pressing the PTT switch while the channel is in use will cause your transceiver to emit an alert tone and transmission will be inhibited (you can't transmit). Release the PTT switch to stop the tone and return to receive mode.

2.Basic operation

Switching power ON/OFF:

- 1.Turn on: Turn on the transceiver by turning the power switch/volume control knob clockwise, then a beep sound, if Voice Annunciation is on, the transciver can notify the current channel.
- 2.Turn off: Turn off the transceiver by turning the power switch/volumecontrol knob counterclockwise until a click sounds, the transceiver is power-off.

Adjusting the volume:

Rotate the Power switch/Volume control to adjust the volume. Clockwise increases the volume and counter-clockwise decreases it.

Selecting a channel:

Turn the Channel switch to select channels that you want if your turn on the Voice Annunciation function .it can notify the current channel.

The key to launch the PTT

- Hold PTT buttons and with normal voice speaking. (when firing red light)
- End spoke, loosen PTT key-press, waiting to receive.

Monitor

Hold MONI buttons in the monitoring mode (instantaneous static denoising open)

FM radio function (optional)

Press Monitor key and turn on the transceiver to enter into radio status. Press PTT switch to reset, and press Monitor key to search radio frequency from low to high. The radio frequency range is: 87.5 MHz When in radio status, if the current channel has signals, press PTT switch to transmits and radio function stops. If the current channel has no signal, it is uneffective to press PTT key after 15s.

3.Note

Low Battery Warning:

Low Battery Warning alerts when the battery needs to be recharged or replaced. While operating the transceiver, if the battery power becomes low, an alert tone will be heard in every 15 seconds and the LED indicator will blink red. Replace or recharge the battery pack.

Battery Save:

If activated by your dealer ,the Battery Save function will decrease the amount of power used when a signal is not being received and no operations are being performed (no keys are being pressed ,and no switches are being turned). While the channel is not busy and no operation is performed for 10 seconds ,Battery. Save turns ON, When a signal is received or an operation is performed, Battery Save turns OFF.

Quiet Talk(QT)/Digital Quiet Talk (DQT):

The transceiver can be selected by 39 groups of CTCSS/83 groups of DCS (can be set by Programming software)

5.Shedule

CTCSS

1	67.0	26	156.7
2	69.3	27	159.8
2	71.9	28	162.2
4	74.4	29	165.5
5	77.0	30	167.9
6	79.7	31	171.3
7	82.5	32	173.8
8	85.4	33	177.3
9	88.5	34	179.9
10	91.5	35	183.5
11	94.8	36	186.2
12	97.4	37	189.9
13	100.0	38	192.8
14	103.5	39	196.6
15	107.2	40	199.5
16	110.9	41	203.5
17	114.8	42	206.5
18	118.8	43	210.7
19	123.0	44	218.1
20	127.3	45	225.7
21	131.8	46	229.1
22	136.5	47	233.6
23	141.3	48	241.8
24	146.2	49	250.3
25	151.4	50	254.1

4.Charging Instructions

- 1. When the charger is connected to the mains supply, place the transceiver into the charging slot to charge. Make sure the interphone is turned off during charging. Pull out the transceiver in time after it is fully charged, and unplug the power switch of the charger.
- 2. Charging status indicators are as follows:
 - A.Standby: the green lamp is on.
 - B.Charging: the red lamp is on.
 - C.Fully charged: the green lamp is always on.

Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For a Class B digital device or peripheral, the instructions furnished to the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This radio is designed for and classified as "General population/uncontrolled Use"

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may
 also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by
 the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio.
- DO NOT transmit for more than 75% of total radio use time, more than 75% of the time can cause RF
 exposure compliance requirements to be exceeded.
- This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between user and the device or its antenna shall be at least 2.5 cm.

DCS

1	D023N	43	D251N	85	D532N	127	D1321	169	D4111
2	D025N	44	D252N	86	D546N	128	D1341	170	D4121
3	D026N	45	D255N	87	D565N	129	D1431	171	D4131
4	D031N	46	D261N	88	D606N	130	D1451	172	D4231
5	D032N	47	D263N	89	D612N	131	D1521	173	D4311
6	D036N	48	D265N	90	D624N	132	D1551	174	D4321
7	D043N	49	D266N	91	D627N	133	D1561	175	D4451
8	D047N	50	D271N	92	D631N	134	D1621	176	D4461
9	D051N	51	D274N	93	D632N	135	D1651	177	D4521
10	D053N	52	D306N	94	D654N	136	D1721	178	D4541
11	D054N	53	D311N	95	D662N	137	D1741	179	D4551
12	D065N	54	D315N	96	D664N	138	D2051	180	D4621
13	D071N	5.5	D325N	97	D703N	139	D2121	181	D4641
14	D072N	56	D331N	98	D712N	140	D2231	182	D4651
15	D073N	57	D332N	99	D723N	141	D2251	183	D4661
16	D074N	58	D343N	100	D731N	142	D2261	184	D5031
17	D114N	59	D346N	101	D732N	143	D2431	185	D5061
18	D115N	60	D351N	102	D734N	144	D2441	186	D5161
19	D116N	61	D356N	103	D743N	145	D2451	187	D5231
20	D122N	62	D364N	104	D754N	146	D2461	188	D5261
21	D125N	63	D365N	105	D0231	147	D2511	189	D5321
22	D131N	64	D371N	106	D0251	148	D2521	190	D5461
23	D132N	65	D411N	107	D0261	149	D2551	191	D5651
24	D134N	66	D412N	108	D0311	150	D2611	192	D6061
25	D143N	67	D413N	109	D0321	151	D2631	193	D6121
26	D145N	68	D423N	110	D0361	152	D2651	194	D6241
27	D152N	69	D431N	111	D0431	153	D2661	195	D6271
28	D155N	70	D432N	112	D0471	154	D2711	196	D6311
29	D156N	71	D445N	113	D0511	155	D2741	197	D6321
30	D162N	72	D446N	114	D0531	156	D3061	198	D6541
31	D165N	73	D452N	115	D0541	157	D3111	199	D6621
32	D172N	74	D454N	116	D0651	158	D3151	200	D6641
33	D174N	75	D455N	117	D0711	159	D3251	201	D7031
34	D205N	76	D462N	118	D0721	160	D3311	202	D7121
35	D212N	77	D464N	119	D0731	161	D3321	203	D7231
36	D223N	78	D465N	120	D0741	162	D3431	204	D7311
37	D225N	79	D466N	121	D1141	163	D3461	205	D7321
38	D226N	80	D503N	122	D1151	164	D3511	206	D7341
39	D243N	81	D506N	123	D1161	165	D3561	207	D7431
40	D244N	82	D516N	124	D1221	166	D3641	208	D7541
41	D245N	83	D523N	125	D1251	167	D3651		
42	D246N	84	D526N	126	D1311	168	D3711		

10