


## **INTRODUCTION**

This remote control system was developed to provide a safe, reliable, and user-friendly remote control system for gas heating appliances. The system is operated manually from the transmitter. The system operates on radio frequencies (RF) within a 50-foot range using non-directional signals. The system operates on one of 1,048,576 security codes that are programmed into the transmitter at the factory; the remote receiver's code must be matched to that of the transmitter prior to initial use.

Review COMMUNICATION SAFETY under GENERAL INFORMATION section. This safety feature shuts down the appliance when a potentially unsafe condition exists.

## **TRANSMITTER**

This remote control SYSTEM offers the user a battery-operated remote control to power a latching solenoid such as those used with gas valves used in some heater rated gas logs, gas fireplaces and other gas heating appliances.




The solenoid circuit uses the battery power from the receiver to operate a solenoid. The circuit has reversing polarity software which reverses the positive (+) and negative (-) output of the receiver's battery power to drive a latching solenoid ON/OFF. The SYSTEM is controlled by the remote transmitter.

The transmitter operates on a (2) 1.5V AAA batteries.

ALKALINE batteries should always be used for longer battery life and maximum operational performance. Re-chargeable batteries should not be used

Before using the transmitter, install the (2) AAA transmitter batteries into the battery compartment. (Use caution that batteries are installed in the proper direction)



### **KEY SETTINGS**


ON - Operates unit to on position, Manually operated solenoid ON.

OFF - Operates unit to off position, Manually operated solenoid OFF.


MODE - Changes unit from manual mode to thermo mode.

SET - Sets temperature in thermo mode.

## LCD-Liquid Crystal Display



1. **DISPLAY** Indicates CURRENT room temperature.
2. **°F OR °C** Indicates degrees Fahrenheit or Celsius.
3. **FLAME** Indicates burner/valve in operation.
4. **ROOM** Indicates remote is in THERMO operation.
5. **TEMP** Appears during manual operation.
6. **SET** Appears during time the of setting the desired Temperature in the thermo operation.



### SETTING °F/°C SCALE

The factory setting for temperature is °F. To change this setting to °C, first

. Press the ON key and OFF key on the transmitter at the same time this will change from °F to °C. Follow this same procedure to change from °C back to °F.

## MANUAL FUNCTION

To operate the system in the manual" MODE" do the following.



SCREEN WHILE  
DEPRESSING ON  
KEY




SCREEN AFTER 3  
SECOND DEFAULT

### **ON OPERAION**

Press the ON key the appliance flame will come on. During this time the LCD screen will show ON, after 3 seconds the LCD screen will default to display room temperature and the word TEMP will show. **(Flame icon will appear on LCD screen in manual on mode)**



SCREEN WHILE  
DEPRESSING OFF  
KEY



SCREEN AFTER 3  
SECOND DEFAULT


### **OFF OPERATION**

Press the OFF key the appliance flame will shut off. During this time the LCD screen will show OF, after 3 seconds the LCD screen will default to display room temperature and the word TEMP will show.


## **THERMOSTAT FUNCTION**

### SETTING DESIRED ROOM TEMPERATURE

When used as a vented decorative appliance, use of the thermostat function is prohibited, operate manually only.



**THERMO SET**




**THERMO MODE**

This remote control system can be thermostatically controlled when the transmitter is in the THERMO mode (The word **ROOM must be displayed on the screen**). To set the THERMO MODE and DESIRED room temperature.

Press the MODE key until the LCD screen shows the word ROOM, then the remote is in the thermostatic mode

Press and hold the SET key until the desired set temperature is reached.(By pressing and holding the set key the LCD screen set numbers will increase from 45°to 99°then restart over at 45°).Next release the SET key.The LCD screen will display the set temperature for 3 seconds and the LCD screen will flash the set temperature for 3seconds,then the LCD screen will default to display the room temperature.

### **TO CHANGE THE SET TEMPERATURE**



**THERMO ON**



**THERMO OFF**

Press and hold the SET key until the desired set temperature is reached.(By pressing and holding the set key the LCD screen set numbers will increase from 45°to 99°then restart over at 45°)Next release the SET key.The LCD screen will display the set temperature for 3 seconds,then will flash the set temperature for 3 seconds,then the LCD screen will default to display the room temperature.

Press the MODE key to disengage the thermo mode.The word ROOM on the LCD screen will not show when the thermo is not in operation.

NOTE:The highest SET temperature is 99°Fahrenheit(32°Celsius) and the lowest temperature is(45°Fahrenheit(6°Celsius)

### **OPERATIONAL NOTES:**

The Thermo Feature on the transmitter operates the appliance whenever the ROOM TEMPERATURE varies a certain number of degrees from the SET TEMPERATURE.This variation is called the “SWING”or TEMPERATURE DIFFERENTIAL.The normal operating cycle of an appliance may be 25-30 times per hour depending on how well the room or home is insulated from the cold or drafts.The factory setting for the”swing number”is 2.This represents a temperature variation of +/-2°F(1°C)between SET temperature and ROOM temperature,which determines when the fireplace will be activated.

The transmitter has ON and OFF manual functions that are activated by pressing either button on the face of the transmitter.When a button on the transmitter is pressed the word ON or OF will appear on the LCD screen to show while the signal is being sent.Upon initial use,there may be a delay of three seconds before the remote receiver will respond to the transmitter.This is part of the system’s design

### **POWER SETTING-GH03-R**

The electronics in the remote control system have the capability of”powering”two different types of DC-powered components.If any operational problems are noted,contact Customer Service.

The RECEIVER comes from the factory programmed to provide pulse DC voltage(5.5VDC to 6.3VDC)to a latching solenoid.


## REMOTE RECEIVER

### IMPORTANT

**THE REMOTE RECEIVER SHOULD BE POSITIONED WHERE AMBIENT TEMPERATURE DO NOT EXCEED 130°F.**


The remote receiver (right) operates on (4) 1.5V AA-size batteries. It is recommended that ALKALINE batteries be used for longer battery life and maximum microprocessor performance. **IMPORTANT:** New or fully charged batteries are essential to proper operation of the remote receiver as a latching solenoid power consumption is substantially higher than standard remote control systems. Re-chargeable batteries should not be used.

**NOTE:** The remote receiver will only respond to the transmitter when the 3-position slide button on the remote receiver is in the REMOTE position. The remote receiver houses the microprocessor that responds to commands from the transmitter to control system operation.



## FUNCTIONS

- . With the slide switch in the REMOTE position, the system will only operate if the remote receiver commands from the transmitter.
- . Upon initial use or after an extended period of no use, the ON button may have to be pressed for up to three seconds before activating servo motor. If the system does not respond to the transmitter on initial use, see LEARNING TRANSMITTER TO
- . With the slide switch in the ON position you can manually turn ON the system.
- . With the slide in the OFF position, the system is OFF.
- . It is suggested that the slide switch be placed in the OFF position if you will be away from your home for an extended period of time.
- . Placing the slide switch in the OFF position also functions as a safety "lock out" by both turning the system OFF and rendering the transmitter inoperative.



## INSTALLATION INSTRUCTIONS

### WARNING

**DO NOT CONNECT REMOTE RECEIVER DIRECTLY TO 110-120VAC POWER. THIS WILL BURN OUT THE RECEIVER. FOLLOW INSTRUCTIONS FROM MANUFACTURER OF GAS VALVE FOR CORRECT WIRING PROCEDURES. IMPROPER INSTALLATION OF ELECTRIC COMPONENTS CAN CAUSE DAMAGE TO GAS VALVE AND REMOTE RECEIVER.**

## INSTALLATION


The remote receiver can be mounted on or near the fireplace hearth. **PROTECTION FROM EXTREME HEAT IS VERY IMPORTANT.** Like any piece of electronic equipment, the remote receiver should be kept away from temperature exceeding 130°F inside the receiver case. Battery life is also significantly shortened if batteries are exposed to high temperatures.

## HEARTH MOUNT

The remote receiver can be placed on the fireplace hearth or under the fireplace, behind the control access panel. Position where the ambient temperature inside the receiver case does not exceed 130°F. **NOTE:** Black Button is used on Hearth Mount Applications.

## **WIRING INSTRUCTIONS**



Make sure the remote receiver switch is in the OFF position. For best results it is recommended that 18 gauge stranded wires should be used to make connections and no longer than 50-feet.



This GH03-R remote receiver is to be connected to a manual valve with a latching ON/OFF solenoid

Connect two 18 gauge stranded or solid wires from the remote receiver terminals to the latching solenoid. (See figure to the right)

**IMPORTANT NOTE:** Operation of this control is dependent on which wire is attached to which terminal. If operation of control does not correspond to operating buttons on transmitter, reverse wire installation at the receiver



## GENERAL INFORMATION

### COMMUNICATION-SAFETY-TRANSMITTER

This remote control has a COMMUNICATION-SAFETY function built into its software. It provides an extra margin of safety when the TRANSMITTER is out of the normal 50-foot operating range of the receiver.

The COMMUNICATION-SAFETY feature operates in the following manner, in all OPERATING MODES-ON/ON THERMO

At all times and in all OPERATING MODES, the transmitter sends an RF signal every 2 minutes, to the receiver, indicating that the transmitter is within the normal operating range of 50-feet. Should the receiver NOT receive a transmitter signal every 2 minutes, the IC software, in the RECEIVER, will begin a 2-HOUR (120-minute) countdown timing function. If during this 2-hour period, the receiver does not receive a signal from the transmitter, the receiver will shut down the appliance being controlled by the receiver. The **RECEIVER** will then emit a series of rapid "beeps" for a period of 10 seconds. Then after 10 seconds of rapid beeping, the RECEIVER will continue to emit a single "beep" every 4 seconds until a transmitter ON or MODE Button is pressed to reset the receiver. The intermittent 4-second beeping will go on for as long as the receiver's batteries last which could be in excess of one year.

To "reset" the RECEIVER and operate the appliance, you must press the ON or MODE button on the transmitter. By turning the system to ON, the COMMUNICATION-SAFETY operation is overridden and the system will return to normal operation depending on the MODE selected at the transmitter. The COMMUNICATION-SAFETY feature will reactivate should the transmitter be taken out of the normal operating range or should the transmitter's batteries fail or be removed.

## **CP(CHILDPROOF)FEATURE**

This remote control includes a CHILDPROOF"LOCK-OUT"feature that allows the user to "LOCK-OUT"operation of the appliance,from the TRANSMITTER.

### **SETTING" LOCK-OUT" -(CP)**

. To activate the "LOCK-OUT"feature,press and hold the ON button and the MODE button at the same time for 5 seconds.The letters CP will appear in the TEMP frame on the LCD screen.

. To disengage the "LOCK-OUT",press and hold the ON button and the MODE button at the same time for 5 seconds and the letters CP will disappear from the LCD screen and the transmitter will return to its normal operating condition.

.To verify that transmitter is in the CP lock-out mode press any key and the LCD screen will show "CP"

NOTE:If the appliance is already operating in the ON or THERMO MODES,engaging the "LOCK-OUT"will not cancel the operating MODE.Engaging the "LOCK-OUT"prevents only the manual operation of the TRANSMITTER.If in the auto modes,the THERMO operation will continue to operate normally.To tatally"LOCK-OUT"the operation of the TRANSMITTER'S operating signals;the transmitter's MODE must be set to OFF.


## **LEARNING TRANSMITTER TO RECEIVER**

Each transmitter uses a unique security code.In order for the receiver to accept the transmitter security code,be sure the slide button on the receiver is in the REMOTE position upon initial use or if batteries are replaced,The receiver won't receive the security code if the slide button is in the ON or OFF position.The LEARN button in located on the front face of the receiver,inside the smallhole labeled LEARN.Using a small screwdriver or end of a paperclip gently press and release the black LEARN button inside the hole.When you release the LEARN button the receiver will emit and audible"beep".After the receiver emits the beep press the transmitter ANY button and release.The receiver will emit several beeps indicating that the transmitter's code has been accepted into the receiver.

The microprocessor that controls the security code matching procedure is controlled by a timing function.If you are unsuccessful in matching the security code on the first attempt,wait 1-2 minutes before trying again-this delay allows the microprocessor to reset its timer circuitry-and try up to two or three more times.

## **TRANSMITTER WALL CLIP**

The transmitter can be hung on a wall using the clip provided.If the clip is installed on a solid wood wall,drill 1/8"pilot holes and install with the screws provided.If it is installed on a plaster/wallboard wall,first drill two 1/4"holes into the wall.Then use a hammer to tap in the two plastic wall anchors flush with the wall;then install the screws provided.



## **BATTERY LIFE**

Replace all batteries regularly.When the transmitter no longer operates the remote receiver from a distance it did previously(i.e.the transmitter's range has decreased)or the remote receiver does not function at all,the batteries should be checked.It is important that the remote receiver batteries are fully charged,providing combined output voltage of at least 5.5volts.The hand held transmitter should operate with as little as 2.5 volts battery power.

## **TROUBLE SHOOTING**

If you encounter problems with your fireplace system, the problem may be the fireplace itself or it could be with the CON1001-TH remote system. Review the fireplace manufacturer's operation manual to make sure all connections are properly made. Then check the operation of the remote in the following manners:

- . Make sure the batteries are correctly installed in the RECEIVER. One reversed battery will keep receiver from operating properly.
- . Check battery in TRANSMITTER to ensure contacts are touching (+) and (-) ends of battery. Bend metal contacts in for tighter fit.
- . Be sure RECEIVER and TRANSMITTER is within 50-feet operating range.
- . Clear Codes: Memory in the receiver might be full if the learn button is pressed too many times. If this happens it will not allow any more codes to be learned and no audible beep will be heard. To clear memory, place the receiver slide switch into the REMOTE position, press the learn button and release after 10 seconds. You should hear three (3) long audible beeps indicating all codes have cleared. You can now "learn" the transmitter to the receiver as described in the General Information Section.
- . KEEP RECEIVER from temperature exceeding 130°F. Battery life shortened when ambient temperature are above 115°F.
- . If RECEIVER is installed in tightly enclosed metal surround, the operating distance will be shortened.
- . Rechargeable batteries should not be used as they do not supply sufficient power to operate the remote system.

## **SPECIFICATIONS**

BATTERIES: Transmitter (2) 1.5 volt AAA batteries

Remote Receiver 6V-4. AA 1.5 Alkaline

Operating Frequency: 315MHZ

FCC ID:

### **FCC REQUIREMENTS**

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE DEVICE.

## FCC Warnings

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.