

# WB-20 SMART WIFI MODULE

## **Operation Manual**

Rev.	Description	Date
1.0	Preliminary release	2019/12/13
1.1	Define model name	2020/2/6

## Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

#### FCC RF Safety Caution statement:

To satisfy FCC RF exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this transmitter must not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement.

## Contents

4
5
5
5
5

## 1. General Layout







Bridge Mode



In this mode, module connects AP with WIFI and emission WIFI itself, the ETH port is LAN,PC and other device could connect module with Ethernet cable

### 2. Features

- Onboard A64 Quad-core ARM Cortex-A53 1.2GHz (Fanless)
- 1G DDR3L co-layout memory
- 8G co-layout eMMC NAND flash
- WIFI 2.4G/5G 802.11a/b/g/n/ac
- Bluetooth 4.2
- TF CARD
- OS: Android 6.0

## 3. Operating Conditions

• Power Source	: DC5V/0.15A
Operating Temperature	: $0 \sim +50^{\circ}C$
<ul> <li>Operating Humidity</li> </ul>	: 15 ~ 85% RH
<ul> <li>Power Consumption</li> </ul>	: 0.75W

## 4. Connectors

- DC 5V input connector (Pin head)
- 1x RS-232C interface (Pin head)
- 2x USB2.0 interface (One is pin head, the other is Mirco-USB)
- 2x LAN interface (One is pin head, the other is RJ45)
- 1x TF card socket

### 5. Network Setup

- 5.1 Link with Wired Cable Only
  - Set as normal scale
  - 1. Set SPEC135=xxx (xxx is the last 3 digits of Lan IP)
  - 2. Set SPEC50=1 (usually act as server) SPEC50=0 (only for cloud)
  - 3. Set Rezero+0416=LAN IP
  - 4. Set Rezero+0418=LAN Subnet Mask
  - 5. Set Rezero+0421=LAN Gateway if necessary
  - 6. Make sure in Rezero+0457, WIFI switch= Inhibit

First Line screen		Second Line Screen	Remark			
S0.1	AMS HOST 0		Host name which could by found by other device in LAN like computer name			
S0.2	AMS STATIC	SELECT ETHERNET TYPE	Please always use X key to set it as STATIC			
S0.3	AMS 00000000000	ENTER ETHERNET DNS1	Reserved			
S0.4	AMS 00000000000	ENTER ETHERNET DNS2	Reserved			
S0.5	AMS INHIBIT	SELECT WIFI SWITCH	Use X key to set it to ALLOW			

5.2 Link with Wireless Only

5.2.1 Method 1: Set on Scale side Set Rezero+0457 as below

500						
	First Line screen		Second Line Screen	Remark		
S0.1	AMS	HOST 0		Host name which could by found by other device in LAN like computer name		
S0.2	AMS	STATIC	SELECT ETHERNET TYPE	Please always use X key to set it as STATIC		
S0.3	AMS 000	0000000000	ENTER ETHERNET DNS1	Reserved		
S0.4	AMS 000	0000000000	ENTER ETHERNET DNS2	Reserved		
S0.5	AMS	ALLOW	SELECT WIFI SWITCH	Use X key to set it to ALLOW		
S0.6	AMS	SSID 0		Input SSID (Specail symbol can be set by ASCII) P32 key to swtich between local or ASCII		
S0.7	AMS	NO	SELECT WIFI ENCRYPTION	NO/WEP/WPA-PSK		
S0.8	CH-01	PWD 0		Enter password of WIFI		

PE Dept, SHANGHAI TERAOKA ELECTRONIC CO., LTD.

CONFIDENTIAL

S0.9 AMS	STATIC	SELECT WIFI TYPE	Please always use X key to set it as STATIC
S0.10 AMS 0000	00000000	ENTER WIFI IP1	Set WIFI IP address
S0.11 AMS 0000	00000000	ENTER WIFI SUBNET MASK1	Set WIFI subnet mask
S0.12 AMS 0000	00000000	ENTER WIFI DNS1	Set DNS if needed
S0.13 AMS 0000	00000000	ENTER WIFI IP2	
S0.14 AMS 0000	00000000	ENTER WIFI SUBNET MASK2	Set only if customer use dual network segment
S0.15 AMS 0000	00000000	ENTER WIFI DNS2	
S0.16 AMS 0000	00000000	ENTER WIFI GATEWAY	Set WIFI gateway
S0.17 AMS	ALLOW	SELECT AM FTP SWITCH	Please always use X key to set it as Allow
S0.18 AMS	3000	SELECT AM FTP PORT	Port available : 3000-4000 except for 3721
S0.19 AMS	USER 5	admin	Set FTP account
S0.20 AMS	PWD 5	admin	Set FTP password
S0.21 AMS	INHIBIT	SELECT SM101 P SWITCH	Select whether support to accept SM-101 protocol

#### 5.2.2 Method 2: Send by AMS file

AMS file is the Android Module Setting file which contains the WIFI setting of scale.

- A. Pull back AMS file
  - Below is a sample to pull back the AMS file from scale, then you got the template to modify to yours.

C:\Windows\system32\cmd.exe



binary commend is very important here and can't be omitted

Commend Inputted	Explain
ftp 10.10.92.50	Use FTP protocol to visit scale Lan IP 10.10.92.50 (Rezero+0416)
admin	Enter FTP account
admin (hidden here)	Enter FTP password
lcd c:\	Set local path for transfer data
binary	Use binary to transfer data (Important and necessary)
get ams0uall.csv	Pull back AMS file
by	End the session

#### CONFIDENTIAL

#### B. Modify AMS file

Use Notepad++ to open the csv file to edit

#### C:\ams0uall.csv - Notepad++

C:\ams0uall.csv - Notepad++	-	٥	×
File Edit Search View Encoding Language Settings Tools Macro Run Plugins Window ?			Х
🕞 🚔 🖶 🐚 🕞 🖕 🕹 🐘 🏠 📮 🗲 🛔 🍢 🔍 🛸 📴 🚍 💷 11 플 🐺 💹 💌 👁 💌 🗈 🕬			
🔚 ams0uall.csv 🖸			
1 1,, "SM-120T", 1,010010092050,255255255000,192168001001,008008008008,004004004004,1, "TESTTESTTEST",2,	'11111111',	1,192	168063
2			
C:\ams0uall.csv - Notepad++	-	٥	Х
File Edit Search View Encoding Language Settings Tools Macro Run Plugins Window ?			Х
];;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;			
🔚 ams0uall.csv 🔀			
1 11",1,192168063050,255255255000,00000000000,0000000000	872,"admin	", "adm	in",1
2			

Below is the data content:

1,,"SM-

dmin",1

#### Below is the column definiton

<and< th=""><th>Iroid Module Setting&gt;: "AMS0xyyy</th><th>.CSV"</th><th></th><th></th></and<>	Iroid Module Setting>: "AMS0xyyy	.CSV"		
#	Settings	Data Style	Number of digit	REMARKS
1	code	9	6	Always 1
2	Flag for delete	9	-	No data/0: Add or Change 1: Delete
3	Host name	Х	16	
4	Eth type	9	1	0:DHCP , 1:Static
5	Eth IP	Х	ASCII=12	lp address(Ex.192168001023) (read only)
6	Eth subnet mask	Х	ASCII=12	(read only)
7	Eth Gateway	Х	ASCII=12	(read only)
8	Eth DNS1	Х	ASCII=12	
9	Eth DNS2	Х	ASCII=12	
10	wifiswitcher	9	1	0:off , 1 : on
11	Wifissid	Х	Max.25	
12	Wifi encryption	9	1	0:no , 1: WEP , 2 :WPA-PSK
13	Wifi password	Х	Max.25	
14	Wifi type	9	1	0:DHCP , 1:Static
15	Wifi IP1	Х	ASCII=12	
16	Wifi subnet mask1	Х	ASCII=12	
17	Wifi IP2	Х	ASCII=12	
18	Wifi subnet mask2	Х	ASCII=12	
19	Wifi Gateway	Х	ASCII=12	
20	Wifi DNS1	Х	ASCII=12	
21	Wifi DNS2	Х	ASCII=12	
22	AM FTP switcher	9	1	0:off , 1 : on
23	AM FTP port	9	8	
24	AM FTP user	Х	Max.25	
25	AM FTP password	Х	Max.25	
26	SM101 protocol switcher	9	1	0:off , 1 : on
27	Bluetooth switcher	9	1	0:off , 1 : on
28	Bluetooth device name	Х	Max.25	

S	o t	hat	means:	

Column	Column Value	Related Data Explaination
1	1	Code
2	(null)	No data = Add or Change
3	"SM-120T"	Host name
4	1	Ethernet type = Static
5	010010092050	Ethernet IP (read only)
6	255255255000	Ethernet Subnet Mask (read only)
7	192168001001	Ethernet Gateway (read only)
8	008008008008	Ethernet DNS1
9	004004004004	Ethernet DNS2
10	1	WIFI on
11	"TESTTESTTEST"	WIFI SSID
12	2	WIFI Encryption = WPA-PSK
13	"11111111"	WIFI Password

14	1	WIFI Type = Static
15	192168063050	WIFI IP1
16	255255255000	WIFI Subnet Mask1
17	00000000000	WIFI IP2
18	00000000000	WIFI Subnet Mask2
19	192168063001	WIFI Gateway
20	192168063001	WIFI DNS1
21	00000000000	WIFI DNS2
22	1	AM FTP Swtich = On
23	3872	AM FTP Port = 3872
24	"admin"	FTP Account
25	"admin"	FTP Password
26	1	SM101 Protocol Switch
<b>T A</b>		

P.S. "" (Quotation mark) using for characters input, can't be omitted.

Some WIFI SSID has special symbol which SM-120 keyboard do not support. And if you don't use ACSII method to input in scale, you may modify the AMS file and send back to scale.

C. Send back modified AMS file

Same produce and change 'get' command to 'put' (file should be store in same folder as received)



binary commend is very important here and can't be omitted

D. Load AMS file on scale side

Under Z mode, use RZ+1457 (only effect after received AMS file)

First Line screen	Second Line Screen	Remark
Z1.0 RESET SALE DAILY	RESET SALES DAILY REPORT	Rezero+1457
AMS SAVE? Y-P N-C	SAVE? PRINT/CLEAR KEY	Click Print key to load
Remember to Reboot scale by ON/OFF key		

Remember to Reboot scale by Orworr key

#### 2.2.3 WB-20 PC Setting for Transfer AMS File

- To WB-20, if scale side is not available to input related characters in Rezero+0457:
- A. Single byte language countries can use P32 key to convert to ASCII code (countries use Standard version)
- B. Double byte language countries could only use AMS file to set.

#### 2.3.1 Upgrade APK by Lan

For example,

- 1. Rezero+0416=010010092050
- 2. Set or check AMS FTP status, port, account and password in Rezero+0457

S0.17	AMS	ALLOW	SELECT AM FTP SWITCH
S0.18	AMS	3872	SELECT AM FTP PORT
S0.19	AMS	USER 5	admin
S0.20	AMS	PWD 5	admin

- 3. Click keyboard ON/OFF to restart
- 4. Link scale with network cable and keep PC in same Lan with different IP
- 5. Use FTP utility to visit AMS FTP (here use filezilla, 10.10.92.50:3872, 3872 is the AMS port set in S0.18 in Rezero+0457)

Z ftp://admin@10.10.92.50:3872 - FileZilla	– 🗆 X
File Edit View Transfer Server Bookmarks Help	
₩ • 🖹 🗂 🗮 😂 🎎 🕄 🐛 💭 🏋 🍳 🤌	
Host: Username: Password: Port:	Quickconnect
Local site: \ \ \ Filename Filesize F Remote site: / Documents Downloads Favorites Intel Downloads Favorites IntelGraphicsP Links Local Settings Music My Document NetHood OneDrive PrintHood Recent Saved Games Filesize F Remote site: / Remote si	Filename Filesize Fi mage S image S image Ju S video S
Searches	
T I I T T T T T T T T T T T T T T T T T	
< > I file. I otal size: 8.8 MB	4 directories
Server/Local file  Cueued files Failed transfers Successful transfers	Status: Connecting to 10.10.92.50:3872 ^ Status: Connection established, waiting for welcome message Status: Logged in Status: Retrieving directory listing Status: Directory listing of */* successful
	🔕 🕐 Queue: empty 🛛 🔍 🖉

#### 6. Put scale.apk to root folder



7. Wait for it disconnect, that means the upgrade has been finished. The software is restarting.

Status:	Connecting to 10.10.92.50:3872	^
Status:	Connection established, waiting for welcome message	
Status:	Insecure server, it does not support FTP over TLS.	
Status:	Logged in	- 14
Status:	: Starting upload of C:\Users\Administrator\Desktop\scale.apk	
Status:	: File transfer successful, transferred 14.8 MB in 1 second	
Status:	Retrieving directory listing of "/"	
Status:	Directory listing of "/" successful	
Status:	Disconnected from server	
Status:	Connection closed by server	
		$\checkmark$
	🔕 🕐 Queue: empty	. •

8. Use hardware switch to reboot scale. (Do not need to wait for apk restarting)9. Check current Android apk version (ReZero+100 in Z mode)

Z1.0 RESET SALES DAILY	RESET SALES DAILY REPORT
STE58 BOOT VR1.01	
STE58 MAIN VR01.21 B08	STD VERSION, COUNTRY:2
STE58 CONST VR01.21 B08	DESC01
STE58 FONT VR1.02	STD
STE58 BMAP VR1.01	U1
STE58 ANDROID MODULE	001.000.001.006

Here 001.000.001.006 is current apk version.

#### 2.3.2 Upgrade APK by WIFI

For example,

1. Rezero+0457

S0.5	AMS ALLOW	SELECT WIFI SWITCH
S0.6	AMS SSID 12	TESTTESTTEST
S0.7	AMS WPA-PSK	SELECT WIFI ENCRYPTION
S0.8	AMS PWD 8	11111111
S0.9	AMS STATIC	SELECT WIFI TYPE
S0.10	AMS 192168063050	EMTER WIFI IP1
S0.11	AMS 255255255000	ENTER WIFI SUBNET MASK1
S0.16	AMS 192168063001	ENTER WIFI GATEWAY
S0.17	AMS ALLOW	SELECT AM FTP SWITCH
S0.18	AMS 3872	SELECT AM FTP PORT
S0.19	AMS USER 5	admin
S0.20	AMS PWD 5	admin

- 2. Set LAN IP = WIFI IP (Important) ReZero+0416=192168063050
- 3. Do not insert network cable (Important)
- 4. Use hardware switch to reboot scale.

5. Use FTP utility to visit AMS FTP (here use filezilla, 192.168.63.50:3872, 3872 is the AMS port set in S0.18 in Rezero+0457)

Z ftp://admin@192.168.63.50:3872 - FileZilla	- 🗆 🗙
File Edit View Transfer Server Bookmarks Help	
Host Username: Password: Port	Quickconnect
Local site: \\vee Filename Filesize F Remote site: /	√ Filename Filesize F
Documents Documents Documents Favorites Intel Intel IntelGraphicsP Links Lead Settings Music My Document Nethood OneOnive Pictures Searches Searches	2 image 33 image.mg 33 image.plu 33 video 33
Videos v < >	< >
< > 1 file. Total size: 8.8 MB	4 directories
Cerver/Local file Covered files Covered files Failed transfers Successful transfers	Status: Connecting to 192.166.65.05.872 ^ Status: Connection established, waling for welcome message Status: Inscription envery fit of the status o
Toggles processing of the transfer queue	() Queue: empty

#### CONFIDENTIAL

#### 6. Put scale.apk to root folder

Zi ftp://admin@192.168.63.50:3872 - FileZilla File Edit View Transfer Server Bookmarks Help	- <b>-</b> ×
⊞ -	
Host: Username: Password: Port:	Quickconnect
Local site:         \         F         Remote site:         /           1         -	Filename Filesize Fi inage Simage Si
Favorites - ? image_plu	image_plu 3
Intel GraphicsP Links Local Settings Music Music Music NoteDate Settings Music Detroited Settings Music Detroited Settings Music Settings Music	∎ vdeo ⊊ © scale.apk 14.8 M8 A
Pictures PrintHood Recent Saved Games Searches SendTo Templates Videos <	< >
I file. Total size: 8.8 MB	1 file and 4 directories. Total size: 14.8 MB
Server/Local file  Coursed file  Duesed file  Failed transfers  Successful transfers (1)	Status:     Directory listing of 1/° successful     A       Status:     Connecting to 192.168.63.50.3872     Status:       Status:     Connection established, waiting for welcome message     Status:       Status:     Insecure server, it does not support FTP over TLS.       Status:     Logged in       Status:     Status:       Status:     File transfer successful, transferred 14.8 MB in 13 seconds       Status:     Retrieving directory listing of 1/° successful       Status:     Directory listing of 1/° successful       Status:     Directory listing of 1/° successful       Status:     Directory listing of 1/° successful
deced mes raise dansers seccessial dalisers (i)	0 0 0 mm mm tr

- 7. Wait for it disconnect, that means the upgrade has been finished.
- The software is restarting.

Status:	Connecting to 10.10.92.50:3872	^
Status:	Connection established, waiting for welcome message	
Status:	Insecure server, it does not support FTP over TLS.	
Status:	Logged in	
Status:	Starting upload of C:\Users\Administrator\Desktop\scale.apk	
Status:	: File transfer successful, transferred 14.8 MB in 1 second	
Status:	Retrieving directory listing of "/"	
Status:	Directory listing of "/" successful	
Status:	Disconnected from server	
Status:	Connection closed by server	
		*
	🔕 🕐 Queue: empty	

8. Use hardware switch to reboot scale. (Do not need to wait for apk restarting)

9. Check current Android apk version (REZERO+100 in Z mode)

Z1.0 RESET SALES DAILY	RESET SALES DAILY REPORT
STE58 BOOT VR1.01	
STE58 MAIN VR01.21 B08	STD VERSION, COUNTRY:2
STE58 CONST VR01.21 B08	DESC01
STE58 FONT VR1.02	STD
STE58 BMAP VR1.01	U1
STE58 ANDROID MODULE	001.000.001.006

Here 001.000.001.006 is current apk version.