




VHT-40 MHz CHANNEL 5 CARRIER LEVEL




VHT-40 MHz CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 6 CARRIER LEVEL




VHT-40 MHz CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 7 CARRIER LEVEL




VHT-40 MHz CHANNEL 7, SPURIOUS
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 7, SPURIOUS
2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 8 CARRIER LEVEL




VHT-40 MHz CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 9 CARRIER LEVEL




VHT-40 MHz CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 1 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz



802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz





802.11ax-20 MHz(SU) CHANNEL 3 CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz

802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz





802.11ax-20 MHz(SU) CHANNEL 8 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz

802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz





802.11ax-20 MHz(SU) CHANNEL 10 CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz


802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 11 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 3 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 3, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 3, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 4 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 4, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 4, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 5 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 6 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 7 CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 7, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 7, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 8 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 8, SPURIOUS
30 MHz ~ 3 GHz



802.11ax-40 MHz(SU) CHANNEL 8, SPURIOUS
2 GHz ~ 25 GHz





802.11ax-40 MHz(SU) CHANNEL 9 CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz

802.11ax-40 MHz(SU) CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz




Aux. Antenna


802.11b CHANNEL 1 CARRIER LEVEL



802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL



802.11b CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11b CHANNEL 11 CARRIER LEVEL



802.11b CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL



802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 2 CARRIER LEVEL



802.11g CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL



802.11g CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz



802.11g CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 8 CARRIER LEVEL




802.11g CHANNEL 8, SPURIOUS

30 MHz ~ 3 GHz



802.11g CHANNEL 8, SPURIOUS


2 GHz ~ 25 GHz




802.11g CHANNEL 9 CARRIER LEVEL




802.11g CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 10 CARRIER LEVEL



802.11g CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz




802.11g CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz




802.11g CHANNEL 11 CARRIER LEVEL



802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 1 CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 2 CARRIER LEVEL




802.11n-20 MHz CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 6 CARRIER LEVEL



802.11n-20 MHz CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz



802.11n-20 MHz CHANNEL 8 CARRIER LEVEL




802.11n-20 MHz CHANNEL 8, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 8, SPURIOUS
2 GHz ~ 25 GHz



802.11n-20 MHz CHANNEL 9 CARRIER LEVEL



802.11n-20 MHz CHANNEL 9, SPURIOUS
30 MHz ~ 3 GHz



802.11n-20 MHz CHANNEL 9, SPURIOUS
2 GHz ~ 25 GHz

