

User Manual

IM2U-N10-091921-NF-01

(Rosenberger Active Das With Intelligent Antenna system-Radiant System)

Manual Version 1.0

**No part of this documentation may be
excerpted, reproduced, translated, annotated or duplicated.**

**In any form or by any means
without the prior written permission of Rosenberger Technology Co., Ltd**

Contents

| | | |
|----------------|---|-----------|
| 1 | Safety instructions | 5 |
| 2 | Product Overview | 6 |
| 2.1 | General Information | 6 |
| 2.2 | Main Features | 7 |
| 2.3 | Product Outline Drawing | 8 |
| 2.4 | Product Interface | 11 |
| 2.4.1 | IM2U Interface | 11 |
| 2.4.2 | NEU Interface | 12 |
| 2.4.3 | IRU-O Interface | 13 |
| 2.5 | Equipment Layout | 15 |
| 2.5.1 | IM2U Layout | 15 |
| 2.5.2 | NEU Layout | 17 |
| 2.5.3 | IRU-O Layout | 17 |
| 3 | Installation | 18 |
| 3.1 | Engineering Installations | 18 |
| 3.2 | Before Installation | 22 |
| 3.2.1 | Choosing a site location | 22 |
| 3.2.2 | Installation | 22 |
| 3.2.2.1 | Installation of IM2U and NEU | 22 |
| 3.2.2.2 | Installing onto the ceiling(quad-band) | 24 |
| 3.2.2.3 | Installing onto the ceiling(Hexa-band) | 25 |
| 3.2.2.4 | Installing onto the wall (Hexa-band) | 27 |
| 4 | Commissioning | 32 |
| 4.1 | Adding Device | 34 |
| 4.1.1 | Adding Device Manually | 34 |
| 4.2 | Device Management | 42 |
| 4.2.1 | Device info | 43 |
| 4.2.1.1 | IM2U parameters | 43 |
| 4.2.1.2 | NEU parameters | 44 |
| 4.2.1.3 | IRU-O parameters | 44 |
| 4.2.2 | Monitoring Para | 45 |
| 4.2.2.1 | IM2U monitoring parameters | 45 |
| 4.2.2.2 | NEU monitoring parameters | 46 |
| 4.2.2.3 | IRU-O monitoring parameters | 46 |
| 4.2.3 | Alarm Status | 47 |

| | | |
|----------------|--|-----------|
| 4.2.3.1 | IM2U Alarm Status | 48 |
| 4.2.3.2 | NEU Alarm Status | 48 |
| 4.2.3.3 | IRU-O Alarm Status | 49 |
| 4.2.4 | RF Setting Parameters | 51 |
| 4.2.4.1 | NEU RF Setting Parameters..... | 51 |
| 4.2.4.2 | IRU-O RF Setting Parameters | 52 |
| 4.2.5 | RF Status | 53 |
| 4.2.5.1 | IM2U RF Status | 53 |
| 4.2.5.2 | NEU RF Status | 54 |
| 4.2.5.3 | IRU-O RF Status..... | 54 |
| 5 | System Monitor Introduce | 56 |

Revision Record

| Title | Rosenberger Active Das With Intelligent MIMO Antenna system | | | |
|--------------|---|----------|--------|-------------|
| Document NO. | | | | |
| Revision | Description | Date | Writer | Approved by |
| V1.0 | Initial version | 2016-4-8 | Gary | Tracy |
| V2.0 | Update new IRU | 2018-4-8 | Gary | Vincent |
| | | | | |
| | | | | |

1 Safety instructions

It is important to read safety instructions before installing the equipment. These instructions are supplementary to any local safety regulations in place. In case of any conflict, local safety regulations shall prevail.

Installation personnel should be qualified support personnel about safety operations and must have received training on Rosenberger equipment installation, maintenance and operations.

Some important safety instructions are discussed in the chapter. Rosenberger shall not bear any liabilities incurred by violation of universal safety operation requirements, or violation of safety standards for designing, manufacturing and equipment usage.



1. The equipment must follow system requirements with proper grounding & thunder-proof facilities.



2. Power supply voltage must satisfy safety requirements. Anybody who operates equipment must cut off power supply first. Only certified maintenance staff can operate with power-on.



3. The equipment radiates electromagnetic wave, which will cause damage to human body. People other than maintenance staff please keep away.



4. Do not expose yourself long time to the RADIANT system in working condition because the electromagnetic field emitted by equipment may do harm to your health.



5. If installed at height (onto the pole), the equipment shall be securely fixed to prevent body injuries from dropping parts.



6. The equipment must be away from fire, as electronic components may explode upon fire.



7. Static electricity produced by human body can damage sensitive components on the circuit board, such as large integrated circuits (ICs). The equipment must be away from fire, as electronic components may explode upon fire.

2 Product Overview

2.1 General Information

Rosenberger **A**ctive **D**AS with **I**ntegrated **A**ntenna system (**RADIANT** abbreviation below) consists of Intelligent multi-sector unit (**IM2U** abbreviation below) and remote unit with optical input (**IRU-O** abbreviation below) and network extender unit(NEU). The number of **IRU-O** depends on the hardware and software configuration. One **IM2U** is capable of supporting up to 4 NEUs, and NEU is capable of supporting up to 16 **IRU-Os**.

Rosenberger RADIANT system is combined with base stations, used for amplifying GSM, DCS, WCDMA and LTE signals. It effectively enhances the shadow signals in urban areas like hotel, office buildings, shopping centers, Stadium as well as basements.

Refer to the application diagram in figure 1; **IM2U** captures the signals from donor BTS and converts the RF signal to optical signal and transmit to NEU via optical cable, and NEUs get the optical signals, split to each **IRU-O** through the hybrid cable, **IRU-O** reconverts the optical signal to RF signal and amplifies it, in the case extends signal coverage.




Figure 1 Radiant System Application

Rosenberger RADIANT has remote control and monitoring function, and it can be self-diagnosis. In case of an external power off, RADIANT can keep sending alarm message to network management center for four hours, facilitating monitoring, configuring and maintenance.

Rosenberger RADIANT is modular design, users can deploy diversified RF output rate and power supply options for various projects. That provides a low-cost and highly-capable solution of mobile communication network optimization. RADIANT is a new platform of BTS coverage extension system to improve the signal in large building.




Figure 2 RADIANT System Diagram

2.2 Main Features

- Complete Frequency Range
Rosenberger RADIANT system can cover full band GSM&DCS&WCDMA<E frequency band.
- Sleek, Efficient, Compact Design
The IRU-O provides an innovative design to integrate both a low power remote unit and antenna into a single package. The IRU-O can provide up to 28.5dBm EIRP for omni applications and up to 31dBm for panel applications to ensure coverage and maximum throughput for multiple LTE and WCDMA carriers. The unit weighs less than 3kg and consumes less than 20W DC power, suitable for hybrid DC/fiber applications
- Precise RF tuning and coverage
Due to the inherent distributed design, each IRU-O can be individually fine-tuned for gain adjustment in each zone to provide precise coverage. The gain adjustment can be fine tuned to a resolution within 0.25dB within each band. Traditional high power remote units with passive distribution are unable to achieve this level of precision and control per antenna as any change in gain in the remote unit affects an entire group of antennas
- No additional feeder losses
Traditional remote units do not have an antenna, so an external feeder cable is required to connect with the servicing antenna. This results in less RF power due to the inherent loss of the feeder cable. The IRU-O antenna mates directly with the active portion and guarantees full RF power at

the antenna interface. This allows the maximum available RF power for any application.

- PIM-Free, VSWR free Installation
The IRU-O assembly is factory tested for PIM and VSWR. This eliminates the possibility of facing PIM or Return Loss issues related to mismatched components and poor installation practices. This significantly improves installation and commissioning time.
- Low Noise Figure and Low System Noise Rise
The IRU-O features a lower noise figure than traditional remote units, that combined with the distributed active architecture provides a significant improvement in DAS noise rise and SNR compared with high power traditional solutions with passive distribution. The combination of which can improve KPI's and throughput.
- Fault Tolerance
The active distribution architecture of RADiAnt provides fault tolerance. In the event that one remote unit fails, only a single antenna/coverage area is affected. In a traditional solution with high power DAS and passive distribution, if the remote unit fails, an entire group of antennas is down affecting the service in a much larger area.
- Easy Installation and Low Project Cost
Radiant is much more than replacing coax with fiber, the core network (IM2U and NEU) will only deal with the signal processing and covert RF signals to fiber signals and transmit over fiber with very small loss and no increased noises, and the network extender unit (NEU) only use hybrid cable (integrated cable with power and fiber) to connect IRU-O, each NEU can connect 16 pieces IRU-O, it means that save project time and cost.

2.3 Product Outline Drawing



Figure 3 IM2U Outline



Figure 4 NEU Outline



2*QM Connector



2*Nf Connector

Figure 5 IRU-O Outline(Quad-band Cabinet)



Figure 6 IRU-O Outline(Hexa-band Cabinet)

2.4 Product Interface

2.4.1 IM2U Interface




Figure 7 IM2U Front Panel




Figure 8 IM2U Rear Panel for SISO

Table 1 IM2U Interface Description

| | Identifier | Functional Description |
|-------------|------------|---|
| Front Panel | MODEM_SIM | SIM card port |
| | USB_H | USB port |
| | USB_D | USB port |
| | RJ45 | LAN port, local monitor port, or network monitor port |
| | MOD | Modem running indicator, Blinking, Control unit communicates normally; OFF, Control unit cannot communicate |
| | ALM | Peripheral alarm indicator, normally ,the indicator is green; the indicator is red when got alarms. |
| | RUN | Monitor boarding running indicator, normally, keep blinking; off, Device does not work |
| | PWR | IM2U power supply indicator, normally, the LED is green, no power , off. |
| | POWER | Power Switch |
| Rear Panel | POWER | DC -48V input terminal |
| | FUSE | Fuse Port, Normally, the fuse model is 5x20 , 250VAC3A |
| | GND | Grounding connector. |
| | MODEM | Modem antenna port. |
| | Op1~ op4 | This port is the fiber connector port for SISO (FC/APC type optical |

| | | |
|--|-------|---|
| | | connectors). |
| | TX/RX | This port is service antenna port. For simplex repeater, this port is DL (downlink) input port of SISO. |

2.4.2 NEU Interface




Figure 9 NEU Front Panel




Figure 10 NEU Rear Panel for MIMO

Table 2 NEU Interface Description

| Identifier | | Functional Description |
|-------------|---------------------|---|
| Front Panel | USB_H | USB port |
| | USB_D | USB port |
| | RJ45 | LAN port, local monitor port, or network monitor port |
| | ALM | Peripheral alarm indicator, normally, the indicator is green; the indicator is red when got alarms. |
| | RUN | Monitor boarding running indicator, normally, keep blinking; off, Device does not work |
| | PWR | IM2U power supply indicator, normally, the LED is green, no power, off. |
| | POWER | Power Switch |
| | IRU1-IRU8 SISO/MIMO | IRU-O connection indicator for SISO/MIMO, the indicator will on when the corresponding to IRU-O is connected. |
| Rear Panel | GND | Grounding connector. |
| | POWER | AC220V input terminal |
| | FUSE | Fuse Port, Normally, the fuse model is 5x20, 250VAC10A |
| | BATTERY | Battery Switch |
| | OP MIMO | Optical port of MIMO (FC/APC type) |
| | OP SISO | Optical port of SISO (FC/APC type) |
| | IRU1~IRU8 48VDC | IRU-O connectors (DC port) |
| | IRU1-IRU8 SISO/MIMO | SISO/MIMO IRU-O connectors (FC/APC type) |

2.4.3 IRU-O Interface



Figure 11 IRU-O Panel(Quad-band Cabinet)



Figure 12 IRU-O Panel (Hexa-band Cabinet)


Table 3 IM2U Interface

| Identifier | Functional Description |
|------------|---------------------------------|
| POWER | DC-48V input port |
| OP SISO | SISO Optical Port (FC/APC type) |
| OP MIMO | MIMO Optical Port (FC/APC type) |

2.5 Equipment Layout

2.5.1 IM2U Layout

The MU is constructed into a 19" shelf and 3U, it is connected via the connector located on the front and rear panel, the RF connector is N female type, and the optic connector is FC/APC type. **IM2U** is composed of optic module of **IM2U**, duplexer, control unit (contain modem) , RF control unit and a WDM. Please see the following figure.






Figure 13 Internal layout for IM2U

Table 4 Modules for IM2U

| Identifier | Function Description |
|------------|--|
| 1 | 900MHz,1800MHz,2100MHz Tri-band Diplexer, filter 900MHz,1800MHz,2100MHz signals Or 700MHz, 850MHz, 1900MHz Tri-band Diplexer, filter 700MHz, 850MHz, 1900MHz signals. |
| 2 | 2100 Duplexer Or 700MHz Duplexer |
| 3 | 70W Power module, DC-48V input, DC12V output |
| 4 | Main Monitor Board, control the whole operation and provides the various functions such as the alarm detection, local control, remote control etc. This module contains Modem. Wireless Modem. |
| 5 | Battery module |
| 6,7 | 2pcs optical module 1x4, convert RF signal to optical signal for downlink, and reconvert optical signal to RF signal for uplink. |
| 8 | 900MHz,1800MHz,2100MHz uplink splitter Or 700MHz,850MHz,1900MHz uplink splitter |
| 9 | 900MHz,1800MHz,2100MHz downlink combiner Or 700MHz,850MHz,1900MHz downlink combiner |

2.5.2 NEU Layout




Figure 14 Internal layout for NEU

Table 5 Modules for NEU

| Identifier | Function Description |
|------------|--|
| 1 | 2pcs optical module 1x8 |
| 2 | 2pcs optical module 1x1 |
| 3 | Power supply, DC 90V~250V, output DC48V |
| 4 | Power Management Module, one input port, 16 output ports |
| 5 | Main Monitor Board (no wireless modem) |

2.5.3 IRU-O Layout




Figure 65 Internal layout for IRU-O

Table 6 Modules for IRU-O

| Identifier | Function Description |
|------------|---|
| 1 | RF modules, RF signal amplify and control, has ALC, AGC function. |
| 2 | Optical module 1x1 for SISO |
| 3 | Optical module 1x1 for MIMO |

3 Installation

3.1 Engineering Installations

Overview

This chapter introduces installation and commissioning flow of equipment to help installation personnel understand the entire process. Brief introduction to some physical parameters of Radiant system, such as size, weight, humidity and temperature is also included in this chapter.

Equipment Installation and Commissioning Flow

Normal and reliable operation of Radiant system is based on the quality of installation project. It is important to establish a set of systematic and standardized installation and commissioning procedures.

Workflow for installation, debugging, acceptance and handing over of the equipment is shown above Figures .

The installation and commissioning workflow is as follows:

1. Engineering survey

Inspect the suggested site environment to provide related data for design and engineering.

2. Engineering design

Planning department shall design according to the engineering inspection results and make out relevant design comments and drawings.

3. packing acceptance

After equipment delivery at the site, construction team is responsible to specify the unpacking time according to engineering preparations. The construction team, the operator, the engineering team and Rosenberger shall all be present at the time of unpacking inspection. If any damage to equipment or shortage in shipment is found during unpacking by a single party, only the unpacking party shall bear all the liability.

4. Hardware installation

Qualified engineering personnel shall supervise the whole installation process, including positioning, base installation, BSC rack installation, BSC board installation, DC power installation, and connection of internal and external cables.

5. System and power-on check

Conduct necessary check and power-on the equipment after installation.

6. Parameters settings

Set related parameters after installation.

7. System test

Test the system to check if the system operates normally. If it fails the test, adjust the system to meet the requirements.

8. Trial run

In the first few months after equipment commissioning, the equipment remains in trial run stage. Rosenberger is responsible for offering full technical support to the user.

9. Final acceptance

It means that operation of the equipment is stable and meets all requirements. The user and Rosenberger agree upon this and sign the final acceptance certificate.



Note: Refer to the related contract terms for details about project survey, engineering design, trial run and final acceptance




Figure 16 Equipment Installations and Commissioning Flow

3.2 Before Installation

3.2.1 Choosing a site location

Make sure access is restricted to qualified personnel

Install the product where power supply and feeder cable are accessible.

Site location should be far away from heat source and damp environment.

IRU-O should be put in a well-ventilated work area. It should be hung on the wall or ceiling to ensure being ventilated. If the IRU-O is mounted on the ceiling, there should be care the ceiling capability of the weight , should be greater than 3kg.

Installation tools

| No. | parts | Model | Quantity | Comments |
|-----|------------------|-------|----------|-----------------------------------|
| 1 | Tape | | 1 | To measure the installation holes |
| 2 | Monkey Wrench | | 1 | To tighten or loose hex bolts |
| 3 | Electric drill | | 1 | Drill holes on the wall |

3.2.2 Installation

3.2.2.1 Installation of IM2U and NEU

IM2U AND NEU are 19"3U in size. It shall be generally installed in the 19-inch communication rack, as show on the following figure 9. Use four expansion bolts (M6*12) to fix the panel of the master unit.

IM2U AND NEU dimensions are 440x360x132 mm and 15 kg in weight.

Make sure access is restricted to qualified personnel

Install the product where power supply and feeder cable are accessible.

Site location should be far away from heat source and damp environment. Repeater should be put in a well-ventilated area with indoor temperature range at 0~+40°C and relative humidity $\leq 85\%$. Please avoid direct sunlight.

If the repeater is mounted on the wall, there should be at least 80cm ~100cm away from the wall or other equipment.




Figure 17 Installation of IM2U and NEU

3.2.2.2 Installing onto the ceiling(quad-band)




Figure 18 Installing onto the ceiling and video

1. Using paper template to position mounting and cable passage holes, drill four 4.4mm diameter holes and cut one 23mm diameter by 37mm long oblong opening in the opening in ceiling.
2. Position IRU-O above ceiling as shown and fasten to ceiling by passing two M4X55mm flathead screws up through ceiling and threading into bosses on IRU- case.
3. View of IRU-O installed above ceiling.
4. Position antenna below ceiling as shown and connect two mcx cables from IRU-O. Position antenna against ceiling by carefully forming excess cable into oblong opening in ceiling, fasten to ceiling by passing two M4X60MM pan head screws up through antenna and ceiling and threading into bosses on IRU-O case.
5. Position antenna below ceiling as shown and connect two mcx cables from IRU-O. Position antenna against ceiling by carefully forming excess cable into oblong opening in ceiling, fasten to ceiling by passing two M4X60MM pan head screws up through antenna and ceiling and threading into bosses on IRU-O case.

3.2.2.3 Installing onto the ceiling(Hexa-band)

Step 1 Use the tools to drill the square holes one the ceiling, as shown in figure 19,




Figure 19

Step 2 Use M4 screw fit bracket A, bracket B and Bracket C together. As Shown in figure 20.




Figure 20

Step 3 Use metal wire mount the bracket unit onto the ceiling keel, as shown in figure 21.




Figure 21

Step 4 Joint the connector with system, as shown in figure 22.




Figure 22

Step 5 The active module clamp on the bracket, as shown in figure 23.




Figure 23

Step 6 Use Phillips screw driver to tighten the captive screw, as shown in figure 24




Figure 24

3.2.2.4 Installing onto the wall (Hexa-band)

Step 1 Use the tools to drill the holes on the wall, as shown in figure 25.




Figure 25

Step 2 The M8 expansion blot put into the hole, as shown in figure 26.




Figure 26

Step 3 Align the holes on the bracket A with the expansion blot, as shown in Figure 27




Figure 27

Step 4 Use M8 washer, M8 spring washer and M8 nut to bracket A onto the wall, as shown in figure 28




Figure 28

Step 5. Use M4 screw fit bracket A and bracket B together, as shown in Figure 29




Figure 29

Step 6. Joint the connector with system, as shown in Figure 30.




Figure 30

Step 7. The active module clamp on the bracket, as shown in Figure 31.




Figure 31

Step 8, Use the Phillips screw driver to tighten the captive screw, as shown in figure 32




Figure 32

4 Commissioning

Before commissioning, the engineer should be checking IM2U&NEU&IRU-O according to the following chart, you can be commissioning when finish checking:




Figure 33 IM2U & NEU&IRU-O checking Chart

4.1 Adding Device

For a **Radiant** site, it contains IM2U, NEU and IRU-O. NEU is the sub device under IM2U, and IRU-O is the sub device under NEU.

4.1.1 Adding Device Manually

Through this function, you can add a main device and its sub devices manually.

Procedure

- Adding Device through Short-cut Button

1. Click  to open the **Create New Device** page, as shown in Figure.




Figure 34 Creating New Device Page

2. Configure parameters for the adding device, as shown in Figure 19.

For the description of device, see Table.




Figure 35 Configure Parameter

Table7 Parameter Description of Creating New Device

| Parameter | Description | Input Method |
|------------|--|--|
| Device No. | Indicates the unique code for each repeater. | Enter a unique number in the text box. |
| Sub No. | It is the equipment type. | <ul style="list-style-type: none"> When the adding device is a single device, select FF from the drop down list box. When the adding device has sub device, select 00. |
| Site Name | It is recommended a name associated with the installation site. It is also used for identifying the location of the repeater and displayed on the device list. | Enter a site name in the text box. |

| Parameter | Description | Input Method |
|--------------------|--|---|
| Phone Number | Configure the phone number which is used to connect the device in remote mode. The phone number must match with the SIM install on the device. | Enter the phone number in the text box. |
| Device Factory | Indicates the manufacturer of the device. | Enter the manufacturer in the text box. |
| Site Location | Indicates the detailed installation address of the adding device. | Enter the address in the text box. |
| Device Type | Indicates the type of the device. | Select the repeater type from drop down list box. |
| Communication Mode | Indicates the communication mode of the device. The communication mode must be the same as that set on the adding device. After selected a mode, click Test to check whether the communication is normal. | Select the communication mode from the dropdown list box. For the configuration of the popup page. |
| Protocol Type | Indicates the supported protocol. | Select the protocol from drop down list box. |

3. Click  to enter the **Slave Properties** page, as shown in Figure 20.





Figure 367 Slave Properties Page

4. Adding slave device.

- When the adding site is a repeater site, it contains two-level device, and you can add four RUs as slave device for it.

Click  to add RUs, as shown in Figure 21.




Figure 37 Adding NEUs

- When the site is a Radiant site, it contains three-level device, and you can add NEU and IRU-O as slave device for it.

The maximum of NEU or IRU-O can be set according to the actual situation. The setting in the following steps is a default value.

1. Select **16** from **Level 3** drop down list box, as shown in Figure 22




Figure 38 Set IRU-O Number

5. Click **Save** and return to the **Create New Device** page, as shown in Figure 23.

Create New Device

Repeater Properties

Device No. * 1

Sub No. * 00

Site Name Factory test

Phone Number 0000000000

Device Factory China

Site Location China

Device Type * 3. Fiber Optic Repeater - Master

Communication mode * UDP **Test**

Device IP 192 . 168 . 1 . 100 Port 4066

Local Port :11000

Timeout :30

Protocol Type * CMCC3GRAP

Slave Config [FF][01][02][03][04][00][00][0] ...

Save Cancel

Figure 39 Adding NEU

6. Click **Test button** to check settings whether there are ok, if not available , you may get a pop-up information as show in Figure 24.




Figure 40 Testing Configuration for A New Device

---End

4.2 Device Management

After successfully adding device, you can start to get and set the device parameters.

Procedure:

1. Right-click a newly added device and then select **Get MOID From Device** from the short-cut menu, as shown in Figure 25.




Figure 41 Get MOID from Device Menu

After getting parameter successfully, a pop-up information box is displayed, click **OK** and the parameter of the device is displayed, as shown in following figures and descriptions.

4.2.1 Device info.

4.2.1.1 IM2U parameters




Figure 42 IM2U Device parameters

4.2.1.2 NEU parameters




Figure 43 NEU Device Parameters

4.2.1.3 IRU-O parameters




Figure 44 IRU-O Device Parameters

Table 8 Description of the Device information

| Parameter items | Description | Note |
|----------------------------|--------------------------------------|----------------------------------|
| Vender ID | Supplier ID | Reference |
| Type ID | Product Description | Reference |
| Device Type ID | Product Number | Reference |
| Serial ID | Product serial number | Reference |
| Longitude | Product installation location | Option item: enter the Longitude |
| Latitude | Product installation location | Option item: enter the Latitude |
| Firmware Curr Soft Version | Product firmware current version | Reference |
| Firmware Release Date | Product firmware release Date | Reference |
| Firmware Config File | Product Firmware config file version | Reference |

4.2.2 Monitoring Para.

4.2.2.1 IM2U monitoring parameters




Figure 45 IM2U monitoring parameters

4.2.2.2 NEU monitoring parameters




Figure 46 NEU monitoring parameters

4.2.2.3 IRU-O monitoring parameters




Figure 47 IRU-O monitoring parameters

Table 9 Description of the monitoring information

| Parameter items | Description | Note |
|-----------------------|---|--|
| Device NO. | It is a site ID | Enter a unique number for each site, different site need different number. IM2U: can be set the number from 1 to 254 NEU: same as the IM2U IRU: will be auto set by NEU |
| Sub NO. | Device ID | Every equipment needs an ID for identifying code. IM2U: Default:0, cannot be set. NEU: can be set the number from 1 to 254 IRU: will be auto set by NEU |
| Smsc Tel | SMSC is short for Short message server Center | enter the operator 's SMSC number or NA |
| Receive Port | Device receive port | Default :4066 |
| Device IP | Device IP | Default:192.168.1.100 |
| Device network mask | Device network mask | Default: 255.255.255.0 |
| Salve equipment count | Indicates that master unit can connect how many pieces slave equipment. | IM2U: normally, one IM2U can connect 4 pieces NEU. NEU: normally, |
| Start sub NO. | Sub equipment start number | Enter a number from 1-256 |
| Query Tel.1~5 | Modem Sim Card number | Enter the Modem Sim Card number |
| Communication Mode | Remote Communication mode | Select one mode for remote control |
| Notify Tel. | Sim Card Number | If want to monitor alarm all the time, please enter a Sim Card number, the cellphone can receive every piece alarm and notice |
| Ems IP | The public network IP address | Enter a IP address if want to use the GPRS mode or TCP mode |
| Ems port | the device communication port number | Enter a port number if want to use the GPRS ,TCP or UDP mode |
| Access Point Name | The access point name of the mobile network operator. | Enter a APN if want to use GPRS ,TCP or UDP mode |

4.2.3 Alarm Status

Device alarm status column corresponds to the Device alarm En/Disable column, if don't want to get an alarm, you can set the item is disable.

4.2.3.1 IM2U Alarm Status




Figure 48 IM2U Alarm Status

4.2.3.2 NEU Alarm Status




Figure 49 NEU Alarm Status

4.2.3.3 IRU-O Alarm Status




Figure 50 IRU-O Alarm Status

Table 10 Description of the monitoring information

| Parameter items | Description | Note |
|------------------------------------|---|---|
| Power Fail alarm | If the main power supply down, will alarm. | If got the alarm, it means that it has no main power supply. |
| Power Fault alarm | If the internal power supply voltage is not stable, and the voltage ripple is greater than 10%, will alarm. | If got the alarm, it means that the power supply voltage is not stable, should check the voltage by multimeter. |
| Monitor module battery fault alarm | If the battery voltage is lower than 8.5V, will alarm | If got the alarm, it means that the battery is not good, should replace a new one. |
| Master slave link alarm | If the master unit cannot detect the remote unit, will alarm. | If got the alarm, maybe the extender unit or remote unit failed. |
| Master slave module comm. Failure | If the monitor board cannot detect the module, will alarm. | If got the alarm, maybe have following several status: 1. There is something wrong about the data cable between the monitor board and modules. 2. The modules failed. |
| PD1~PD16 alarm | If the master unit cannot receive the optical signal, will alarm. | If got the alarm, maybe have following several status: 1. There is something wrong about the fiber optical cable among the Master unit, extender unit and remote unit. 2. The remote unit failed. |
| LD, LD1, LD2 alarm | If the master unit cannot send the optical signal, will alarm. | If got the alarm, it means the master unit or extender unit failed. |
| Position changed alarm | Position alarm, if the Device had been moved, will alarm. | If got the alarm, maybe have following several status: 1. Forgot to connect the position |

| Parameter items | Description | Note |
|-----------------------------------|---|---|
| | | <p>cable to Ground.</p> <p>2. The Device had been moved by somebody.</p> |
| Device temperature alarm | If the equipment temperature is higher than setting temperature, will alarm | <p>If got the alarm ,maybe have following several status:</p> <ol style="list-style-type: none"> 1. Unsuitable temperature value has be set .normally: 55°C 2. The Device is too hot, and the fan failed if have 3. The Device's program has something wrong. |
| IRU 1 ~ IRU 16 over current alarm | If the IRU's current is higher than 500mA, will alarm. | If got the alarm, it means the remote unit has something wrong. |
| Downlink PA Fault alarm | It indicates the PA maybe fail. | If got the alarm, it means the downlink PA has something wrong. |
| PA temperature alarm | It will alarm if the PA temperature is higher than setting value. | <p>If got the alarm ,maybe have following several status:</p> <ol style="list-style-type: none"> 1. Unsuitable temperature value has be set .normally: 55°C 2. The Device is too hot, and the fan failed if have 3. The PA's program has something wrong. |
| Downlink low output alarm | It indicates the down link output power is lower than the setting value, | <p>If got alarm, the Remote unit maybe have following several status:</p> <ol style="list-style-type: none"> 1. check Downlink output min.value whether it is appropriate, 2. check downlink attenuation setting ,maybe set too more 3. PA failed. 4. Reference IM2U or NEU, check the input power, maybe the input power is too low. |
| Downlink over output alarm | It indicates the downlink output power is higher than the setting value. | <p>If got alarm , the Remote unit maybe have following several status</p> <ol style="list-style-type: none"> 1. need to check the setting value , the setting value should not be greater than the rated out power plus 2 2. If the PA runs well, maybe the PA's program has something wrong. 3. PA failed |

4.2.4 RF Setting Parameters

4.2.4.1 NEU RF Setting Parameters




Figure 51 NEU RF Setting Parameters

4.2.4.2 IRU-O RF Setting Parameters




Figure 52 IRU-O RF Setting Parameters

Table 11 Description of the monitoring information

| Parameter items | Description | Note |
|------------------------------|---|-----------------------------------|
| Device Temperature threshold | NEU's temperature setting | Normally, set the number is 55 |
| RF Module switch | IRU's RF module switch | Normally ON |
| PA Temp. Threshold | IRU's Temperature setting | Normally, set the number is 55 |
| Uplink Att | IRU's uplink attenuation setting | According to the actual situation |
| Downlink Att | IRU's downlink attenuation setting | According to the actual situation |
| Downlink Output min | IRU's Downlink Output minimum alarm threshold value | default |
| Downlink output max | IRU's Downlink Output maximum alarm threshold value | default |

4.2.5 RF Status

4.2.5.1 IM2U RF Status




Figure 53 IM2U RF Status

4.2.5.2 NEU RF Status




Figure 54 NEU RF Status

4.2.5.3 IRU-O RF Status




Figure 55 IRU-O RF Status

Table 12 Description of the monitoring information

| Parameter items | Description | Note |
|-----------------------|---|----------------|
| Mobile Network Code | Master unit Modem parameters, only read | Reference |
| Location Area Code | Master unit Modem parameters, only read | Reference |
| BTS ID | Master unit Modem parameters, only read | Reference |
| RFCN/CH NO. | Master unit Modem parameters, only read | Reference |
| RSSI | Master unit Modem parameters, only read | Reference |
| CELL ID | Master unit Modem parameters, only read | Reference |
| Optical TX Power | Device optical output power | Real time data |
| Optical Rx Power | Device optical receiving power | Real time data |
| PA Temp. | IRU's PA temperature | Real time data |
| Uplink Rated Gain | Device uplink rated gain | reference |
| Downlink Actual Gain | Device downlink actual Gain | Real time data |
| Downlink Rated Output | Device downlink actual Gain | reference |
| Downlink output | Device downlink RF output power | Real time data |
| Downlink input | Device downlink RF input power | Real time data |

5 System Monitor Introduce

Operation & maintenance terminal (OMT) interact with the Radiant to set and lookup its status and RF parameters. It can display alarms real-time. OMT can set local connection, SMS connection with the device for operation and maintenance at any time, or at any location.

OMT and FOR connection topology showed as Figure 39:




Figure 56 OMT Connection mode

Please refer to

Operation/Maintenance Terminal OMT Software User Manual

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 30cm between the radiator& your body.