

General	
Weight	2.5KG (150WH) 3KG (178WH/ 222WH)
Specification	120x125x180mm
Working temperature	Operating temperature in charging state: 0-40°C
	Operating temperature in non-charging state :-10-50°C
Storage temperature	0~35°C
Certification	CE PSE FCC RoHS UN38.3
Input	
DC input port (adapter/solar/cigarette lighter)	DC 5521 port Charging voltage:DC11-30V /constant 40W
Type-C input port	Type-C port (5V/9V/12V/15V/20V)
Output	
Type-C output port	Type-C port (5V/9V/12V/15V/20V,3A)
USB-QC3.0 quick charging output (x2)	USB port (5V/3A,9V/2A,12V/1.5A)
DC 12V output (x2)	DC 5521 port/12V/10A)
AC DC inverter AC output	AC universal socket/AC socket (US)
Wireless charge output	Fast charge 10W(222WH)
Car jump starter port	EC5(178WH)
internal	
Battery type	18650 batteries
Battery capacity	150WH/178WH/222WH
Warranty	1 year

Please charge the battery before using or storing. The indicator will light up and battery symbol running. The LCD screen will display the current charging percent and power at the same time indicator ligh lighting up. When the LCD screen displays 100%, it means the power is full. It will take about 7.5 hours to charge fully. The curren power can be viewed through LCD screen.		
<b>*</b>	Standard recharger About 7 hours (MAX)	
	TYPE-C-PD 60W recharger About 4.5 hours by standard charger (MAX)	
Â	Vehicle's cigarette lighter recharge About 8–10 hours (11–30V)	
9m	60W Solar panel About 8-10 hours	
	ime is determined by the sunlight intensity) IPPT charging of solar panel.(11–30V)	

6

Recharging method

Malfunction	Expel the breakdown	Solutions
Cannot be recharged	1.Charger, equipment and electricity do not connect properly lat this time, the battery indicator is not runningl.	Check whether the charger, equipment and electricity connected well.
	2.Connected properly, but the battery indicator does not run.	Charger is broken, please contact after-sale service.
	3.Connected properly, still unable to recharge.	Battery temperature is too high (caused by high storage temperature or the battery just discharged, not cooled yet).
No output	1.The connecting line between equipment and devices unproperly.	Make sure the equipment and devices connected property.
	2. The output port switch do not open (type-C port not need open, it can be identified automatically).	Turn on the output port switch, and the indicator light will be on.
	3.Low power (when the power is less than 10%, the AC output will be turned off automatically, and the DC can work normally. If the AC needed in emergency, it can be forced to start by pressing the AC key long time for 5 seconds).	Recharge the equipment in time.
	4.Still no output after checking 1,2.3. steps.	Demaged or other mailunction, please contact the after-sales department.
Interrupt with device	1. The device rated or instant power exceed the rated power of equipment it will interrupt.	Choose higher power products.
	2. The output will stop automatically when the load power of AC port is too low.	For non-product problems, the output can be forced start by pressing the key for a long time 55. It needs to be closed manually after use.
	3.lt will turn off the output due to operating temperature protection by battery or key components.	It will start work when the equipment cool down.
	4.Overload or short circuit.	The output recovers after mailunction solved
	5. The load power is too low or in standby state ( if static&low power states, the equipment cannot recognize device, so shut down automatically).	Wake up load or forced power on loness the AC key 5s to starts.
	6.The output still shut down after checking 1.2.3.4.5. steps.	Damaged or other matlanction, please contact the after-sales department.

isions appearance of the product is damaged after use. assembled and repaired on your own. ormance failure caused by haman factors. age caused by natural disasters, lightning, accidents and other
ssembled and repaired on your own. ormance failure caused by human factors.
thild factors. ement exe complex with purt 18 and part 18 of the FCC Rules. Operation is Subject To the two conditions: levice may not cause harmful interference, and (2) this devicemust accept any interference received, interference that may cause understeid operation. Changes or molicity and interference that may cause understeid operation. Changes or molicity interference that may cause understeid operation. Changes or molicity and exployment has born tested and found to comply with the limits for a Class B digital assemble protection against harmful interference in a residential installation. This is generate, use and a chardly and therefore to radio communications assemble protection against harmful interference to radio communications to explore the instructions, may cause harmful interference to radio communications to explore the instructions, may cause harmful interference to radio communications to explore the most of the 640 cold magnetic sequence of the sectores the explorement to the following masseures: the explorement of and on, the user is recouraged tory to correct the explorement to the following masseures: a the explorement of educois metastrow, making and the excellent is the bedger can metastrow following adminum. If the ophisment in an outle on a circuid different from has to which the receiver is the top particle of the device matter explored. This top sequence of 15 cm marconding the device and 20 the top simulation of device a dimatter explored. Charmful interference to radio communications. Fifth explorement on each and a necourage to the following the explorement of the marconding the explorement the user is encouraged to try to correct the interference, by one or more of the masseure.
L
vie nac 1se eni on 1g

Warranty

The warranty period is 12 months. The warranty period starts from the

purchase date. To estimate the start time, your purchase certificate or

Warning & Caution

Please follow basic precautions including: A.Please read all instructions before using product.