4.10.5. Remote Management

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Advanced > System > Administration, and focus on the Remote Management
- section.
- Note:

If your ISP assigns a private WAN IP address (such as 192.168.x.x or 10.x.x.x), you cannot use this feature because private addresses are not routable.

• Forbid all devices to manage the router remotely:

Do not tick the Enable checkbox of Remote Management.

	management
Access an	d manage the router over the internet.
	note Managamant is not supported when you are connected to the internet only via IDuC. If you
Note: Ren	note management is not supported when you are connected to the internet only via IPV6. If you
Note: Ren want to us	e Remote Management, please make sure you have set up an IPv4 connection first.

Allow all devices to manage the router remotely:

Remote Management		
Access and manage the router over the	internet.	
Note: Remote Management is not supp want to use Remote Management, please	orted when you are connected to the internet only v se make sure you have set up an IPv4 connection fi	ria IPv6. If you irst.
Remote Management:	Enable	
Remote Management: HTTP Port:	Enable 8888	
Remote Management: HTTP Port: Web Address for Management:	 Enable 8888 10.0.2.225 	

- 1. Tick the Enable checkbox of Remote Management.
- 2. Keep the HTTP port as default setting (recommended) or enter a value between 1024 and 65535.
- 3. Select All Devices for Remote Managers.
- 4. Click SAVE.

Devices on the internet can log in to <u>http://Router's WAN IP address: port number</u> (such as <u>http://113.116.60.229:1024</u>) to manage the router.

Ø Tips:

[•] You can find the WAN IP address of the router on Network Map > Internet.

- The router's WAN IP is usually a dynamic IP. Please refer to <u>Dynamic DNS</u> if you want to log in to the router through a domain name.
- Allow a specific device to manage the router remotely:

Remote Management		
Access and manage the router over the i	nternet.	
Note: Remote Management is not suppo want to use Remote Management, pleas	orted when you are connected to the inte e make sure you have set up an IPv4 co	ernet only via IPv6. If you onnection first.
Remote Management:	Enable	
HTTP Port:	8888	
Web Address for Management:	10.0.2.225	
Remote Managers:	Specified Device V	

- 1. Tick the Enable checkbox of Remote Management.
- 2. Keep the HTTP port as default setting (recommended) or enter a value between 1024 and 65535.
- 3. Select Specified Device for Remote Managers.
- 4. In the Only this IP Address field, enter the IP address of the remote device to manage the router.
- 5. Click SAVE.

Devices using this WAN IP can manage the router by logging in to <u>http://Router's WAN</u> IP:port number (such as http://113.116.60.229:1024).

© **Tips:** The router's WAN IP is usually a dynamic IP. Please refer to <u>Dynamic DNS</u> if you want to log in to the router through a domain name.

4.10.6. System Log

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Advanced > System > System Log, and you can view the logs of the router.

	en acuviues.		
Curi	rent Time: 2019-09-02 09:21	:46	
Search	Q	😯 Refresh	🗳 Clear Al
1 WARNING 0days, 00:00	0:00, Invalid Ian mac, now sta	nt by default mac 00-19-66-CA-8B-07	
2 INFO 0days, 00:00:00, L	LAN: Attach mirror0 to stack.	-100 169 0 1 potmack 255 255 0	
4 INFO 0days, 00:00:00, 1	HTTPD: Http server startl	- 192. 166.0. T Helinask 200.200.200.0.	
5 INFO 0days, 00:00:05, V	WAN: Attach interface eth1.		
6 INFO 0days, 00:00:07, V	WAN: Wan ethernet port plug	on.	
7 INFO 0days, 00:00:08, [DHCPC: Send DISCOVER w	ith unicast flag 0.	
8 INFO 0days, 00:00:08, [DHCPC: Recv OFFER from s	server 10.0.0.1 with ip 10.0.2.225.	
9 INFO 0days, 00:00:08, [DHCPC: Send REQUEST to	server 10.0.0.1 with request ip 10.0.2	.225.
10 INFO 0days, 00:00:08,	DHCPC: eth1 set ip 10.0.2.2	225 mask 255.255.252.0 gateway 10.0	J.U.1.
12 INFO 0days, 00:07:26	DHCPS: Send ACK to 192.1	168 0 101	
,,,,,,,			
Save Log			
Save system log locally.			

3. Click SAVE TO LOCAL to save the system logs to a local disk.

4.10.7. CWMP Settings

The modem router supports CWMP (CPE WAN Management Protocol), also called TR-069. This collects information, performs diagnostics and configures the devices automatically via ACS (Auto-Configuration Server).

- 1. Visit <u>http://tplinkmodem.net</u>, and log in with your TP-Link ID or the password you set for the router.
- 2. Go to Advanced > System Tools > CWMP Settings page.

CWMP:		
Inform:		
Inform Interval:	3600	(seconds)
Data Model:	TR098	~
ACS URL:		
ACS Username:		
ACS Password:		ø
Interface used by TR-069 client:	WAN	~
Connection Request Authentication:	Digest	~
Username:	tplink	
Password:	•••••	ø
Path:	/tp_cwmp	
Port:	7547	

- CWMP: Toggle On to enable the CWMP (CPE WAN Management Protocol) feature.
- Inform: Enable this feature to send an Inform message to the ACS (Auto Configuration Server) periodically.
- Inform Interval: Enter the time interval in seconds when the Inform message will be sent to the ACS.
- Data Model: Select the CWMP data model.
- ACS URL: Enter the web address of the ACS which is provided by your ISP.
- ACS Username/Password: Enter the username/password to log in to the ACS server.
- Interface used by TR-069 client: Select which interface to be used by the TR-069 client.
- Connection Request Authentication: Select this check box to enable authentication for the connection request.
- Username/Password: Enter the username/password for the ACS server to log in to the router.
- Path: Enter the path for the ACS server to log in to the router.
- Port: Enter the port that connects to the ACS server.

Click Save to make the settings effective.

4.10.8. Diagnostic

Diagnostic is used to test the connectivity between the router and the host or other network devices.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to Advanced > System > Diagnostics.

Troublesheet network connectivity proble	700		
Troubleshoot network connectivity proble	1115.		
Diagnostic Tools:	Ping	\checkmark	
IP Address/Domain Name:			
Ping Packet Number:	4		
Ping Packet Size:	64	Bytes	

3. Enter the information:

- 1) Choose Ping or Tracert as the diagnostic tool to test the connectivity;
- Ping is used to test the connectivity between the router and the tested host, and measure the round-trip time.
- Tracert is used to display the route (path) your router has passed to reach the tested host, and measure transit delays of packets across an Internet Protocol network.
- 2) Enter the IP Address or Domain Name of the tested host.
- 3) Modify the Ping Count number and the Ping Packet Size. It's recommended to keep the default value.
- 4) If you have chosen Tracert, you can modify the Traceroute Max TTL. It's recommended to keep the default value.

4. Click START to begin the diagnostics.

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Ping.

```
Finding host yahoo.com by DNS server (1 of 2).

Pinging yahoo.com [98.138.219.231] with 64 bytes of data:

Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=0).

Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=2).

Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=2).

Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=3).

Ping statistics for 98.138.219.231:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss).

Approximate round trip times in milli-seconds:

Minimum = 233ms, Maximum = 233ms, Average = 233ms
```

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Tracert.

```
Finding host yahoo.com by DNS server (1 of 2).
Tracing route to yahoo.com [72.30.35.10]
over a maximum of 20 hops:
1 1 ms 1 ms 1 ms 10.0.1
2 1 ms 1 ms 1 ms 116.24.64.1
3 1 ms 1 ms 1 ms 202.105.155.185
4 1 ms 1 ms 1 ms 183.56.65.2
5 * 1 ms * 202.97.94.150
6 16 ms 16 ms 16 ms 202.97.94.94
7 150 ms 150 ms 150 ms 202.97.750.74
9 150 ms 150 ms 150 ms 4.53.210.145
```

4. 10. 9. Time and Language Settings

System time is the time displayed while the router is running. The system time you configure here will be used for other time-based functions like Parental Controls. You can choose the way to obtain the system time as needed.

System language is the language displayed when you log into the router. You can change the system language as needed.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Advanced > System > Time & Language.
- To set System Language:

Language			
Set the router's system language.			
Language:	English	~	

Select the language of your country/region.

• To set System Time:

System Time		
Set the router's system time.		
Current Time:	2019-09-02 09:22:39	
24-Hour Time:		
Set Time:	Get from Internet	
Time Zone:	(GMT+00:00) Greenwich Mean Time:	Dublin, I 🗸
NTP Server I:	time.nist.gov	
NTP Server II:	time-nw.nist.gov	(Optional)

- 1. Select the way in which the router gets its time: Get from Internet, Get from Managing Device, Manually.
- 2. Select your local Time Zone.
- 3. Enter the address or domain of the NTP Server 1 or NTP Server 2.
- 4. Click SAVE.
- To set up Daylight Saving Time:
- 1. Select Enable Daylight Saving.

utomatically synchronize the system tin	ne with day	light savi	ng time.		
Daylight Saving Time:	Enable	le			
Start: 2019	Mar	~	2nd	\sim	
	Sun	~	02:00	\checkmark	
End: 2019	Nov	~	First	\checkmark	
	Sun	~	02:00	\sim	

- 2. Select the start time from the drop-down list in the Start fields.
- 3. Select the end time from the drop-down list in the End fields.

4. Click SAVE.

Note:

This setting will be used for some time-based functions such as firewall. You must specify your time zone once you log in to the router successfully; otherwise, time-based functions will not take effect.

4.10.10. Reboot

Some settings of the router will take effect only after rebooting, and the system will reboot automatically. You can also reboot the router to clear cache and enhance running performance.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Advanced > System > Reboot, and you can restart your router.

• To reboot the router manually:

Click REBOOT, and wait a few minutes for the router to reboot.

Reboot			
Reboot to clear	cache and enhance runni	ng performance.	

- To set the router to reboot regularly:
- 1. Tick the Enable box of Reboot Schedule.
- 2. Specify the Reboot Time when the router reboots and Repeat to decide how often it reboots.
- 3. Click SAVE.

Reboot Schedule		
Set when and how often the router reboo	ts automatically.	
Reboot Schedule:	Enable	
Note: Make sure Time Settings are corre	ct before using this function.	
Current Time: 2019-09-02 09:23:51		
Reboot Time:	00 🗸 : 00	~
Repeat:	Every Day	\checkmark
Repeat:	Every Day	~

4. 10. 11. LED Control

The LED of the router indicates its activities and status. You can enable the Night Mode feature to specify a time period during which the LED is off.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Advanced > System > LED Control.
- 3. Enable Night Mode.

Turp the router's LEDs on or off				
TUIN THE TOULET'S LEDS ON OF OTT.				
LED Status:				
Night Mode				
Set a time period when the LEDs will be	off automa	atically		
Night Mode:	🗹 Enab	le		
Night Mode: Note: Make sure Time Settings are corre	Enab ect before i	using this function.		
Night Mode: Note: Make sure Time Settings are corre Current Time: 2019-09-02 09:24:35	Enab	le using this function.		
Night Mode: Note: Make sure Time Settings are correct Current Time: 2019-09-02 09:24:35 LED Off From:	Enable ect before (23	using this function.	~	

4. Specify the LED off time, and the LED will be off during this period every day.

Note: The effective LED off time is based on the time of the router. You can go to Advanced > System > Time & Language to modify the time.

5. Click SAVE.

Chapter 5

Configure the Router in Access Point Mode

This chapter presents how to configure the various features of the router working as an access point.

It contains the following sections:

- Operation Mode
- <u>Firmware Upgrade</u>
- Backup & Restore
- Administration
- <u>System Log</u>
- <u>Diagnostic</u>
- Time and Language Settings
- <u>Reboot</u>
- LED Control

5.1. Operation Mode

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > Operation Mode.
- 3. Select the working mode as needed and click SAVE.

Operation Mode						
Select an operation mode according to your needs.						
Router Mode(Current) In this mode, the router can provide internet access for multiple wired and wireless devices. This mode is required most commonly.						
Access Point Mode In this mode, the router changes an existing wired network into a wireless one.						
Range Extender Mode In this mode, the router boosts the existing wireless coverage in your home.						

5. 2. Firmware Upgrade

TP-Link is dedicated to improving and richening the product features, giving users a better network experience. We will release the latest firmware at TP-Link official website <u>www.tp-link.com</u>. You can download the latest firmware file from the <u>Support</u> page of our website and upgrade the firmware to the latest version.

- 1. Download the latest firmware file for the router from our website <u>www.tp-link.com</u>.
- 2. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 3. Go to System > Firmware Upgrade.
- 4. Click BROWSE to locate the downloaded firmware file, and click UPGRADE.

.ocal Upgrade		
pgrade firmware from a local file.		
Firmware Version:		
Hardware Version:	%. NYERIAN-10.0000000	
New Firmware File:		
	BROWSE	
	UPGRADE	

5.3. Backup & Restore

The configuration settings are stored as a configuration file in the router. You can backup the configuration file in your computer for future use and restore the router to the previous settings from the backup file when needed.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Backup & Restore.

• To backup configuration settings:

Click BACK UP to save a copy of the current settings in your local computer. A ".bin" file of the current settings will be stored in your computer.

заскир		
Save current router settings to a	file.	

- To restore configuration settings:
- 1. Click BROWSE to locate the backup configuration file stored in your computer, and click RESTORE.
- 2. Wait a few minutes for the restoring and rebooting.

Postoro sottings from a h	ackup filo		
Restore settings from a t	аскир ше.		
	File:		
		BROWSE	

• To reset the router to factory default settings:

1. Click FACTORY RESTORE to reset the router.

Factory Default Restore	
Restore all settings to default values.	

2. Wait a few minutes for the restoring and rebooting.

Note:

- During the resetting process, do not turn off or reset the router.
- We strongly recommend you backup the current configuration settings before resetting the router.

5.4. Administration

5. 4. 1. Change Password

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Administration, and focus on the Change Password section.

Change Password			
Change the router's local management p	assword.		
Old Password:	•••••	ø	
New Password:		ø	
Confirm New Password		Ø	

3. Enter the old password, then a new password twice (both case-sensitive). Click SAVE.

4. Use the new password for future logins.

5. 4. 2. Local Management

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > Administration, and focus on the Local Management section.
- Allow all LAN connected devices to manage the router:

Select All Devices for Local Managers.

Local Management					
Access and manage the router from local network devices.					
Local Managers:	All Devices	\sim			

• Allow specific devices to manage the router:

1. Select All Devices for Local Managers and click SAVE.

cos and manage		network devices.		
	Local Managers:	Specified Devices	~	
				🕂 Add Device
Description		MAC Address		Operation

2. Click Add Device.

Add Device								×
	Description:							
		VIEW		NECTI	ED DEV	ICES		
	MAC Address:	-	-	-	-	-		
					C	ANCEL	SAVE	

- 3. Click VIEW CONNECTED DEVICES and select the device to manage the router from the Connected Devices list, or enter the MAC address of the device manually.
- 4. Specify a Description for this entry.
- 5. Click SAVE.

5.5. System Log

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > System Log, and you can view the logs of the router.

Current Time: 2019-09-02 09:21:46	
Quarter O	
Search Q	Clear All
1 WARNING 0days, 00:00:00, Invalid lan mac, now start by	v default mac 00-19-66-CA-8B-07.
2 INFO 0days, 00:00:00, LAN: Attach mirror0 to stack.	,
3 INFO 0days, 00:00:00, LAN: Set interface mirror0 ip=192	2.168.0.1 netmask 255.255.255.0.
4 INFO 0days, 00:00:00, HTTPD: Http server start!	
5 INFO 0days, 00:00:05, WAN: Attach interface eth1.	
6 INFO 0days, 00:00:07, WAN: Wan ethernet port plug on.	
7 INFO 0days, 00:00:08, DHCPC: Send DISCOVER with u	unicast flag 0.
8 INFO 0days, 00:00:08, DHCPC: Recv OFFER from serve	er 10.0.0.1 with ip 10.0.2.225.
9 INFO 0days, 00:00:08, DHCPC: Send REQUEST to serv	Ver 10.0.0.1 with request ip 10.0.2.225.
10 INFO 0days, 00:00:08, DHCPC: eth1 set Ip 10.0.2.225 I	mask 255.255.252.0 gateway 10.0.0.1.
12 INFO 00ays, 00:07:26 DHCPS: Send ACK to 192 168 (
12 INFO 00435, 00.07.20, DHCP3. Send ACK to 152.100.0	
Savalor	
Save Log	
Save system log locally.	

3. Click SAVE TO LOCAL to save the system logs to a local disk.

5.6. Diagnostic

Diagnostic is used to test the connectivity between the router and the host or other network devices.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Diagnostics.

	enis.		
Diagnostic Tools:	Ping	~	
IP Address/Domain Name:			
Ping Packet Number:	4		
Ping Packet Size:	64	Bytes	

- 3. Enter the information:
 - 1) Choose Ping or Tracert as the diagnostic tool to test the connectivity;
 - Ping is used to test the connectivity between the router and the tested host, and measure the round-trip time.

- Tracert is used to display the route (path) your router has passed to reach the tested host, and measure transit delays of packets across an Internet Protocol network.
- 2) Enter the IP Address or Domain Name of the tested host.
- 3) Modify the Ping Count number and the Ping Packet Size. It's recommended to keep the default value.
- 4) If you have chosen Tracert, you can modify the Traceroute Max TTL. It's recommended to keep the default value.
- 4. Click START to begin the diagnostics.

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Ping.

Finding host yahoo.com by DNS server (1 of 2). Pinging yahoo.com [98.138.219.231] with 64 bytes of data: Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=0). Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=1). Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seq=2). Reply from 98.138.219.231: bytes=64 time=233ms TTL=48 (seg=3). Ping statistics for 98.138.219.231: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss) Approximate round trip times in milli-seconds: Minimum = 233ms, Maximum = 233ms, Average = 233ms

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Tracert.



5.7. Time and Language Settings

This page allows you to set the time manually or to configure automatic time synchronization. The router can automatically update the time from an NTP server via the internet.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Time & Language.

• To set System Language:

Language			
Set the router's system language.			
Language:	English	~	

Select the language of your country/region.

• To set System Time:

Set the router's system time	
Current Time:	2019-09-02 09:22:39
24-Hour Time:	
Set Time:	Get from Internet
Time Zone:	(GMT+00:00) Greenwich Mean Time: Dublin, I 🗸
NTP Server I:	time.nist.gov
NTP Server II:	time-nw nist gov (Optional)

- 1. Select the way in which the router gets its time: Get from Internet, Get from Managing Device, Manually.
- 2. Select your local Time Zone.
- 3. Enter the address or domain of the NTP Server 1 or NTP Server 2.
- 4. Click SAVE.
- To set up Daylight Saving Time:
- 1. Select Enable Daylight Saving.

~	Quet	
~	Ord	
	200	\sim
~	02:00	\mathbf{v}
~	First	\checkmark
\checkmark	02:00	~
		02:00 First 02:00

2. Select the start time from the drop-down list in the Start fields.

3. Select the end time from the drop-down list in the End fields.

4. Click SAVE.

Note:

This setting will be used for some time-based functions such as firewall. You must specify your time zone once you log in to the router successfully; otherwise, time-based functions will not take effect.

5.8. Reboot

Some settings of the router will take effect only after rebooting, and the system will reboot automatically. You can also reboot the router to clear cache and enhance running performance.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Reboot, and you can restart your router.

• To reboot the router manually:

Click REBOOT, and wait a few minutes for the router to reboot.

Reboot			
Reboot to clear cach	nd enhance running performance.		
		TOOT	
	KE	:6001	

- To set the router to reboot regularly:
- 1. Tick the Enable box of Reboot Schedule.
- 2. Specify the Reboot Time when the router reboots and Repeat to decide how often it reboots.
- 3. Click SAVE.

Set when and how often the router reboots automatically.				
Reboot Schedule:	 Enable 			
Note: Make sure Time Settings are corre	ect before using this function.			
Current Time: 2019-09-02 09:23:51				
Reboot Time:	00 🗸 : 00	~		

5.9. LED Control

The LED of the router indicates its activities and status. You can enable the Night Mode feature to specify a time period during which the LED is off.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > LED Control.
- 3. Enable Night Mode.

LED Status:	
Night Mode	
Set a time period when the LEDs will be	off automatically.
Night Mode:	Enable
Night Mode: Note: Make sure Time Settings are corre	Enable ect before using this function.
Night Mode: Note: Make sure Time Settings are corre Current Time: 2019-09-02 09:24:35	Enable ect before using this function.
Night Mode: Note: Make sure Time Settings are corre Current Time: 2019-09-02 09:24:35 LED Off From:	 Enable ect before using this function. 23 23 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 <

4. Specify the LED off time, and the LED will be off during this period every day.

Note: The effective LED off time is based on the time of the router. You can go to Advanced > System > Time & Language to modify the time.

5. Click SAVE.

Chapter 6

Configure the Router in Range Extender Mode

This chapter presents how to configure the various features of the router working as a range extender.

It contains the following sections:

- Operation Mode
- <u>Firmware Upgrade</u>
- Backup & Restore
- Administration
- <u>Diagnostic</u>
- <u>System Log</u>
- <u>Time and Language Settings</u>
- <u>Reboot</u>
- LED Control

6.1. Operation Mode

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > Operation Mode.
- 3. Select the working mode as needed and click SAVE.

<text><section-header><text><text><text><section-header><text><text><text><text></text></text></text></text></section-header></text></text></text></section-header></text>	Operation Mode
<section-header><section-header><section-header><section-header><text><image/><section-header><text><text><text></text></text></text></section-header></text></section-header></section-header></section-header></section-header>	Select an operation mode according to your needs.
<image/> <section-header><section-header><section-header><text><text><text></text></text></text></section-header></section-header></section-header>	Router Mode(Current) In this mode, the router can provide internet access for multiple wired and wireless devices. This mode is required most commonly.
 Access Point Mode In this mode, the router changes an existing wired network into a wireless one. Internet LAN USAN USAN USAN USAN USAN USAN USAN US	
Internet LAN I	Access Point Mode In this mode, the router changes an existing wired network into a wireless one.
Range Extender Mode In this mode, the router boosts the existing wireless coverage in your home.	
	Range Extender Mode In this mode, the router boosts the existing wireless coverage in your home.

6.2. Firmware Upgrade

TP-Link is dedicated to improving and richening the product features, giving users a better network experience. We will release the latest firmware at TP-Link official website <u>www.tp-link.com</u>. You can download the latest firmware file from the <u>Support</u> page of our website and upgrade the firmware to the latest version.

- 1. Download the latest firmware file for the router from our website www.tp-link.com.
- 2. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 3. Go to System > Firmware Upgrade.
- 4. Click BROWSE to locate the downloaded firmware file, and click UPGRADE.

Local Upgrade		
Jpgrade firmware from a local file.		
Firmware Version:		
Hardware Version:	1. WHELEN	
New Firmware File:		
	BROWSE	
	UPGRADE	

6.3. Backup & Restore

The configuration settings are stored as a configuration file in the router. You can backup the configuration file in your computer for future use and restore the router to the previous settings from the backup file when needed.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Backup & Restore.

• To backup configuration settings:

Click BACK UP to save a copy of the current settings in your local computer. A ".bin" file of the current settings will be stored in your computer.

заскир		
Save current router settings to a	file.	

- To restore configuration settings:
- 1. Click BROWSE to locate the backup configuration file stored in your computer, and click RESTORE.
- 2. Wait a few minutes for the restoring and rebooting.

	l 61-		
Restore settings from a b	аскир тие.		
	File:		
		BROWSE	

• To reset the router to factory default settings:

1. Click FACTORY RESTORE to reset the router.

Factory Default Restore	
Restore all settings to default values	

2. Wait a few minutes for the restoring and rebooting.

Note:

- During the resetting process, do not turn off or reset the router.
- We strongly recommend you backup the current configuration settings before resetting the router.

6.4. Administration

6.4.1. Change Password

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Administration, and focus on the Change Password section.

Change Password			
Change the router's local management p	assword.		
Old Password:	••••	ø	
New Password:		ø	
Confirm New Password:		Ø	

3. Enter the old password, then a new password twice (both case-sensitive). Click SAVE.

4. Use the new password for future logins.

6. 4. 2. Local Management

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > Administration, and focus on the Local Management section.
- Allow all LAN connected devices to manage the router:

Select All Devices for Local Managers.

Access and manage t	he router from local	network devices.	

• Allow specific devices to manage the router:

1. Select All Devices for Local Managers and click SAVE.

tess and manage the rec				
Loca	I Managers:	specified Devices	~	
				🕂 Add Device
Description		MAC Address		Operation

2. Click Add Device.

Add Device								×
	Description:							
		VIEW	CONN	IECTI	ED DE	VICES		
	MAC Address:	-	-	-	-	-		
					C	ANCEL	SAVE	

- 3. Click VIEW CONNECTED DEVICES and select the device to manage the router from the Connected Devices list, or enter the MAC address of the device manually.
- 4. Specify a Description for this entry.

5. Click SAVE.

6.5. Diagnostic

Diagnostic is used to test the connectivity between the router and the host or other network devices.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > Diagnostics.

Diagnostics			
Troubleshoot network connectivity proble	ms.		
Diagnostic Tools:	Ping	~	
IP Address/Domain Name:			
Ping Packet Number:	4		
Ping Packet Size:	64	Bytes	

- 3. Enter the information:
 - 1) Choose Ping or Tracert as the diagnostic tool to test the connectivity;
 - Ping is used to test the connectivity between the router and the tested host, and measure the round-trip time.
 - Tracert is used to display the route (path) your router has passed to reach the tested host, and measure transit delays of packets across an Internet Protocol network.
 - 2) Enter the IP Address or Domain Name of the tested host.
 - 3) Modify the Ping Count number and the Ping Packet Size. It's recommended to keep the default value.
 - 4) If you have chosen Tracert, you can modify the Traceroute Max TTL. It's recommended to keep the default value.
- 4. Click START to begin the diagnostics.

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Ping.

Finding host yar	ioo.com by DNS server (1 of 2).	
Pinging yahoo.c	om [98.138.219.231] with 64 bytes of data:	
Reply from 98.1	38.219.231: bytes=64 time=233ms TTL=48 (seq=0).	
Reply from 98.1	38.219.231: bytes=64 time=233ms TTL=48 (seq=1).	
Reply from 98.1	38.219.231: bytes=64 time=233ms TTL=48 (seq=2).	
Reply from 98.1	38.219.231: bytes=64 time=233ms TTL=48 (seq=3).	
Ping statistics fo	r 98.138.219.231:	
Packets: Sent =	4, Received = 4, Lost = 0 (0% loss).	
Approximate rou	ind trip times in milli-seconds:	
Minimum = 233r	ns. Maximum = 233ms. Average = 233ms	

The figure below indicates the proper connection between the router and the Yahoo server (www.Yahoo.com) tested through Tracert.

Finding host	yahoo.com by DNS server (1 of 2).	
Tracing route	e to yahoo.com [72.30.35.10]	
over a maxin	num of 20 hops:	
1 1 ms 1 ms	1 ms 10.0.0.1	
2 1 ms 1 ms	1 ms 116.24.64.1	
3 1 ms 1 ms	1 ms 202.105.155.185	
4 1 ms 1 ms	1 ms 183.56.65.2	
5 * 1 ms * 20	2.97.94.150	
6 16 ms 16 n	ns 16 ms 202.97.94.94	
7 150 ms 15	0 ms 150 ms 202.97.27.242	
8 166 ms 16	6 ms 166 ms 202.97.50.74	
9 150 ms 15	0 ms 150 ms 4.53.210.145	

6.6. System Log

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > System Log, and you can view the logs of the router.

	Current Time: 2019-09-02 09:2	1:46	
Search	Q	🗘 Refresh	🇳 Clear A
1 WARNING 0day	vs. 00:00:00. Invalid lan mac. now st	art by default mac 00-19-66-CA-8B	.07
2 INFO 0days, 00	:00:00, LAN: Attach mirror0 to stack.	art by deladit mae bo-15-00-074-05	
3 INFO 0days, 00	:00:00, LAN: Set interface mirror0 ip	=192.168.0.1 netmask 255.255.255	i.O.
4 INFO 0days, 00	:00:00, HTTPD: Http server start!		
5 INFO 0days, 00	:00:05, WAN: Attach interface eth1.		
6 INFO 0days, 00	:00:07, WAN: Wan ethernet port plug	g on.	
7 INFO 0days, 00	:00:08, DHCPC: Send DISCOVER w	/ith unicast flag 0.	
8 INFO 0days, 00	:00:08, DHCPC: Recv OFFER from	server 10.0.0.1 with ip 10.0.2.225.	
9 INFO 0days, 00	:00:08, DHCPC: Send REQUEST to	server 10.0.0.1 with request ip 10.0).2.225.
10 INFO 0days, 0	0:00:08, DHCPC: eth1 set Ip 10.0.2.	225 mask 255.255.252.0 gateway 1	10.0.0.1.
12 INFO 0days, 0	0.07.26 DHCPS: Send ACK to 192	168 0 101	
12 111 0 00030, 0	0.01.20, 01101 0. 001010101010102.	100.0.101.	
save Log			

3. Click SAVE TO LOCAL to save the system logs to a local disk.

6.7. Time and Language Settings

This page allows you to set the time manually or to configure automatic time synchronization. The router can automatically update the time from an NTP server via the internet.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Time & Language.

• To set System Language:

Language			
Set the router's system language.			
Language:	English	\sim	

Select the language of your country/region.

• To set System Time:

Set the router's system time.	
Current Time:	2019-09-02 09:22:39
24-Hour Time:	
Set Time:	Get from Internet
Time Zone:	(GMT+00:00) Greenwich Mean Time: Dublin, t 🗸
NTP Server I:	time.nist.gov
NTP Server II:	time-nw nist gov (Ontional)

- 1. Select the way in which the router gets its time: Get from Internet, Get from Managing Device, Manually.
- 2. Select your local Time Zone.
- 3. Enter the address or domain of the NTP Server 1 or NTP Server 2.
- 4. Click SAVE.
- To set up Daylight Saving Time:
- 1. Select Enable Daylight Saving.

utomatically synchronize the system tin	ne with day	light savi	ng time.		
Daylight Saving Time:	Enabl	e			
Start: 2019	Mar	~	2nd	~	
	Sun	~	02:00	~	
End: 2019	Nov	~	First	~	
	Sun	~	02:00	~	

2. Select the start time from the drop-down list in the Start fields.

3. Select the end time from the drop-down list in the End fields.

4. Click SAVE.

Note:

This setting will be used for some time-based functions such as firewall. You must specify your time zone once you log in to the router successfully; otherwise, time-based functions will not take effect.

6.8. Reboot

Some settings of the router will take effect only after rebooting, and the system will reboot automatically. You can also reboot the router to clear cache and enhance running performance.

1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.

2. Go to System > Reboot, and you can restart your router.

• To reboot the router manually:

Click REBOOT, and wait a few minutes for the router to reboot.

Reboot			
Reboot to clear cach	nd enhance running performance.		
		TOOT	
	KE	:6001	

- To set the router to reboot regularly:
- 1. Tick the Enable box of Reboot Schedule.
- 2. Specify the Reboot Time when the router reboots and Repeat to decide how often it reboots.
- 3. Click SAVE.

Set when and now often the fouter rebot	its automatically.	
Reboot Schedule:	 Enable 	
Note: Make sure Time Settings are corre	ect before using this function.	
Current Time: 2019-09-02 09:23:51		
Reboot Time:	00 🗸 : 00	~

6.9. LED Control

The LED of the router indicates its activities and status. You can enable the Night Mode feature to specify a time period during which the LED is off.

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to System > LED Control.
- 3. Enable Night Mode.

LED Status:	
Night Mode	
Set a time period when the LEDs will be	off automatically.
	Enable
Night Mode:	
Night Mode: Note: Make sure Time Settings are corre	ect before using this function.
Note: Make sure Time Settings are corre	ect before using this function.
Note: Make sure Time Settings are corre Current Time: 2019-09-02 09:24:35 LED Off From:	23 23

4. Specify the LED off time, and the LED will be off during this period every day.

Note: The effective LED off time is based on the time of the router. You can go to Advanced > System > Time & Language to modify the time.

5. Click SAVE.

FAQ

Q1. What should I do if I forget my wireless password?

The default wireless password is printed on the label of the router. If the password has been altered, please connect your computer to the router using an Ethernet cable and follow the steps below:

- 1. Visit <u>http://tplinkwifi.net</u>, and log in with the password you set for the router.
- 2. Go to Wireless or Advanced > Wireless > Wireless Settings or to retrieve or reset your wireless password.

Q2. What should I do if I forget my login password of the web management page?

1. Reset the router to its factory default settings.

2. Visit <u>http://tplinkwifi.net</u>, and create a password for future login.

Note: You'll need to reconfigure the router to surf the Internet once the router is reset, and please mark down your new password for future use.

Q3. What should I do if I cannot log in to the router's web management page?

This can happen for a variety of reasons. Please try the methods below to log in again.

- Make sure your computer has connected to the router correctly and the corresponding LED light up.
- Make sure the IP address of your computer is configured as Obtain an IP address automatically and Obtain DNS server address automatically.
- Make sure you enter the correct IP address to log in: <u>http://tplinkwifi.net</u> or 192.168.0.1.
- Check your computer's settings:
 - 1) Go to Start > Control Panel > Network and Internet, and click View network status and tasks.
 - 2) Click Internet Options on the bottom left.
 - 3) Click Connections and select Never dial a connection.

eneral	Security	Privacy	Content	Connections	Programs	Advanced
	To set up Setup.	an Inter	net connec	tion, click	Set	up
Dial-up a	and Virtua	Private N	Vetwork se	ttings		
🎒 E	Broadbar	nd Conn	ection		Add	ł
					Add V	PN
					Remo	ve
Choose server	Settings for a conr	if you nee lection.	ed to config	jure a proxy	Sett	ings
Nev	ver dial a d	connectio	n			
🔘 Dia	wheneve	r a netwo	ork connect	ion is not prese	ent	
O Alv	ays dial m	y default	connection	1		
Curr	ent	None			Set de	efault
Local Ar	ea Netwo	rk (LAN) s	ettings -			
LAN Se Choose	ettings do e Settings	not apply above fo	to dial-up r dial-up se	connections. ettings.	LAN se	ttings

4) Click LAN settings and deselect the following three options, and click OK.

use of manua	nfiguration may override manual settings. To ensure the al settings, disable automatic configuration.
Automatic	cally detect settings
Use autor	natic configuration script
Address	
Proxy server	
Use a pro dial-up or	xy server for your LAN (These settings will not apply to VPN connections).
	Port: 80 Advanced
Address:	

5) Go to Advanced > Restore advanced settings, and click OK.

🔁 Interne	et Properti	es				? <mark>×</mark>		
General	Security	Privacy	Content	Connections	Programs	Advanced		
Settings	Settings							
	Accessibilit Alway: Enable Move : Reset Reset Browsing Autom Close : Disable Disable	ty s expand c Caret Br system ca text size text size zoom leve atically re unused for e script de e script de	ALT text fro owsing for aret with for to medium to medium el for new v ecover from olders in His abugging (1 abugging (1	or images new windows a cus/selection d for new window while zooming* windows and ta n page layout e story and Favor internet Explore Other)	and tabs nanges vs and tabs bs rrors with Co ites* er)	E ompa		
	Display	/ a notific / Accelera	ation abou ator button	t every script e on selection	rror	-		
•						<u>b</u>		
*Tak Reset II Rese condi You s	kes effect a nternet Exp its Internet ition. should only	after you plorer set Explorer use this i	tings	to their default	advanced so Rese usable state	ettings et		
			Ok	Ca	incel	Apply		

- Use another web browser or computer to log in again.
- Reset the router to factory default settings and try again. If the login still fails, please contact the technical support.

Note: You'll need to reconfigure the router to surf the internet once the router is reset.

Q4. What should I do if I cannot access the internet even though the configuration is finished?

- 1. Visit <u>http://tplinkwifi.net</u>, and log in to with the password you set for the router.
- 2. Go to Advanced > Network > Status to check the Internet status:

If IP Address is a valid one, please try the methods below and try again:

- Your computer might not recognize any DNS server addresses, please manually configure DNS server.
 - 1) Go to Advanced > Network > DHCP Server.
 - 2) Enter 8.8.8.8 as Primary DNS, and click Save.
 - Tips: 8.8.8 is a safe and public DNS server operated by Google.

Dynamically assgin IP addresses to the o	devices connected to the router.	
DHCP Server:	C Enable	
IP Address Pool:	192.168.0.100 - 192.168.0.1	199
Address Lease Time:	120 min	utes
Default Gateway:	0.0.0.0	(Optional)
Primary DNS:	0.0.0.0	(Optional)
Secondary DNS:	0.0.0.0	(Optional)

- Restart the modem and the router.
 - 1) Power off your modem and the router, and leave them off for 1 minute.
 - 2) Power on your modem first, and wait about 2 minutes.
 - 3) Power on the router, and wait another 1 or 2 minutes and check the Internet access.
- Reset the router to factory default settings and reconfigure the router.
- Upgrade the firmware of the router.
- Check the TCP/IP settings on the particular device if all other devices can get internet from the router.

If the IP Address is 0.0.0.0, please try the methods below and try again:

- Make sure the physical connection between the router and the modem is proper.
- Clone the MAC address of your computer.
 - 1) Visit <u>http://tplinkwifi.net</u>, and log in with the username and password you set for the router.
 - Go to Advanced > Network > Internet, select Clone Current Device MAC and click SAVE.

MAC Clone			
	Router MAC Address:	Use Default MAC Address	\sim
		Use Default MAC Address	
		Clone Current Device MAC	
NAT		Use Custom MAC Address	

- Ø Tips:
- Some ISP will register the MAC address of your computer when you access the Internet for the first time through their Cable modem, if you add a router into your network to share your Internet connection, the ISP will not accept it as the MAC address is changed, so we need to clone your computer's MAC address to the router.

• The MAC addresses of a computer in wired connection and wireless connection are different.

• Modify the LAN IP address of the router.

Note:

Most TP-Link routers use 192.168.0.1/192.168.1.1 as their default LAN IP address, it may conflict with the IP range of your existent ADSL modem/router. If so, the router is not able to communicate with your modem and cause you can't access the Internet. To resolve this problem, we need to change the LAN IP address of the router to avoid such conflict, for example, 192.168.2.1.

- 1) Visit <u>http://tplinkwifi.net</u>, and log in with the username and password you set for the router.
- 2) Go to Advanced > Network > LAN.
- 3) Modify the LAN IP address as the follow picture shows. Here we take 192.168.2.1 as an example.
- 4) Click Save.

View and configure LAN s	ettings.			
1	MAC Address:	00-19-66-CA-8B-07		
	IP Address:	192.168.2.1		
	Subnet Mask:	255 255 255 0	~	

- Restart the modem and the router.
 - 1) Power off your modem and the router, and leave them off for 1 minute.
 - 2) Power on your modem first, and wait about 2 minutes.
 - 3) Power on the router, and wait another 1 or 2 minutes and check the internet access.
- Double check the Internet Connection Type.
 - 1) Confirm your Internet Connection Type, which can be learned from the ISP.
 - 2) Visit <u>http://tplinkwifi.net</u>, and log in with the username and password you set for the router.
 - 3) Go to Advanced > Network > WAN.
 - 4) Select your Internet Connection Type and fill in other parameters.
 - 5) Click SAVE.

Internet Set up an internet connection with the su	ervice information provided by your ISP (internet service provider
	(
Internet Connection Type:	Dynamic IP 🗸
IP Address:	10.0.2.224
Subnet Mask:	255.255.252.0
Default Gateway:	10.0.0.1
Primary DNS:	10.0.0.1
Secondary DNS:	0.0.0.0
	RENEW
	RELEASE
	 Advanced Settings
DNS Address:	Get Dynamically from ISP
Dito Address.	
Primary DNS:	10.0.0.1
Secondary DNS:	0.0.0.0
MTU Size:	1500 bytes
	The default is 1500, do not change unless necessary.
Host Name:	111100000000000000000000000000000000000
	Get IP with Unicast DHCP

- 6) Restart the modem and the router.
- Please upgrade the firmware of the router.

If you've tried every method above but cannot access the internet, please contact the technical support.

Q5. What should I do if I cannot find my wireless network or I cannot connect to the wireless network?

If you fail to find any wireless network, please follow the steps below:

- Make sure the wireless function of your device is enabled if you're using a laptop with a built-in wireless adapter. You can refer to the relevant document or contact the laptop manufacturer.
- Make sure the wireless adapter driver is installed successfully and the wireless adapter is enabled.
 - On Windows 7
 - 1) If you see the message No connections are available, it is usually because the wireless function is disabled or blocked somehow.
 - 2) Clicking Troubleshoot and windows might be able to fix the problem by itself.
 - On Windows XP

- 1) If you see the message Windows cannot configure this wireless connection, this is usually because windows configuration utility is disabled or you are running another wireless configuration tool to connect the wireless.
- 2) Exit the wireless configuration tool (the TP-Link Utility, for example).
- 3) Select and right click My Computer on Desktop, and select Manage to open Computer Management window.
- 4) Expand Services and Applications > Services, and find and locate Wireless Zero Configuration in the Services list on the right side.
- 5) Right click Wireless Zero Configuration, and then select Properties.
- 6) Change Startup type to Automatic, click Start and make sure the Service status is Started. And then click OK.

If you can find other wireless network except your own, please follow the steps below:

• Make sure your computer/device is still in the range of your router/modem. Move closer if it is currently too far away.

If you can find your wireless network but fail to connect, please follow the steps below:

- Authenticating problem/password mismatch:
 - Sometimes you will be asked to type in a PIN number when you connect to the wireless network for the first time. This PIN number is different from the Wireless Password/Network Security Key. Usually you can only find it on the label of your router.



- 2) If you cannot find the PIN or PIN failed, you may choose Connecting using a security key instead, and then type in the Wireless Password/Network Security Key.
- 3) If it continues to show note of Network Security Key Mismatch, it is suggested to confirm the wireless password of your wireless router.

Note: Wireless Password/Network Security Key is case sensitive.

- Windows unable to connect to XXXX / Can not join this network / Taking longer than usual to connect to this network:
 - Check the wireless signal strength of your network, if it is weak (1~3 bars), please move the router closer and try again.
 - Change the wireless Channel of the router to 1,6,or 11 to reduce interference from other networks.
 - Re-install or update the driver for your wireless adapter of the computer.

FCC compliance information statement



Product Name: AC750 Dual Band Wi-Fi Router

Model Number: Archer C24

Component Name	Model
I.T.E. Power	T090060-2B1

Responsible party:

TP-Link USA Corporation, d/b/a TP-Link North America, Inc. Address: 145 South State College Blvd. Suite 400, Brea, CA 92821 Website: http://www.tp-link.com/us/ Tel: +1 626 333 0234 Fax: +1 909 527 6803 E-mail: sales.usa@tp-link.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be colocated or operating in conjunction with any other antenna or transmitter."

We, **TP-Link USA Corporatio**n, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2023-02-22

FCC compliance information statement

Product Name: I.T.E. Power Supply Model Number: T090060-2B1 Responsible party: TP-Link USA Corporation, d/b/a TP-Link North America, Inc. Address: 145 South State College Blvd. Suite 400, Brea, CA 92821 Website: http://www.tp-link.com/us/ Tel: +1 626 333 0234 Fax: +1 909 527 6803 E-mail: sales.usa@tp-link.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

We, **TP-Link USA Corporation**, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2023-02-22

CE Mark Warning

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

OPERATING FREQUENCY (the maximum transmitted power)

2400 MHz -2483.5 MHz (20dBm)

5150 MHz -5250 MHz (23dBm)

Frequency band 5150 - 5250 MHz:

Indoor use: Inside buildings only. Installations and use inside road vehicles and train carriages are not permitted. Limited outdoor use: If used outdoors, equipment shall not be attached to a fixed installation or to the external body of road vehicles, a fixed infrastructure or a fixed outdoor antenna. Use by unmanned aircraft systems (UAS) is limited to within the 5170 - 5250 MHz band.

EU Declaration of Conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863.

The original EU declaration of conformity may be found at https://www.tp-link.com/en/ce

RF Exposure Information

This device meets the EU requirements (2014/53/EU Article 3.1a) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

The device complies with RF specifications when the device used at 20 cm from your body.

Industry Canada Statement

CAN ICES-3 (B)/NMB-3(B)



Korea Warning Statements:

당해 무선설비는 운용중 전파혼신 가능성이 있음.

National Restrictions

Attention: This device may only be used indoors in all EU member states and EFTA countries.

	AT	BE	BG	СН	CY	CZ	DE	DK
 n	EE	EL	ES	FI	FR	HR	HU	IE
	IS	IT	LI	LT	LU	LV	MT	NL
	NO	PL	PT	RO	SE	SI	SK	UK

UKCA Mark UK CA

UK Declaration of Conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.

The original UK Declaration of Conformity may be found at https://www.tp-link.com/ support/ukca/

National restrictions

Attention: This device may only be used indoors in Great Britain.



Canadian Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement

économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution:

1. The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

Avertissement:

1. Le dispositif fonctionnant dans la bande 5150-5250 MHz est réservé uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

NCC Notice & BSMI Notice:

注意!

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻 率、加大功率或變更原設計之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立 即停用,並改善至無干擾時方得繼續使用。

前述合法通信,指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

應避免影響附近雷達系統之操作。

高增益指向性天線只得應用於固定式點對點系統。

安全諮詢及注意事項

- •請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- •清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
- 注意防潮,請勿將水或其他液體潑灑到本產品上。
- •插槽與開口供通風使用,以確保本產品的操作可靠並防止過熱,請勿堵塞或覆蓋開口。
- 請勿將本產品置放於靠近熱源的地方。除非有正常的通風,否則不可放在密閉位置中。
- •請不要私自拆開機殼或自行維修,如產品有故障請與原廠或代理商聯繫。

設備名稱: Equipmer	AC750 [nt name	Dual Band \	Archer C24 ion (Type)						
單元	限用物質及其化學符號 Restricted substances and its chemical symbols								
Unit	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁺⁶)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)			
PCB	0	0	0	0	0	0			
外殻	0	0	0	0	0	0			
電源供應 器		ο	0	0	0	0			
天線	0	0 0 0 0 0							
備考 1. "超出 0.1 wt %"及"超出 0.01 wt %"係指限用物質之百分比含量超出百分比含量基準值									

備考 1. "超出 0.1 wt %"及"超出 0.01 wt %"係指限用物質之百分比含量超出百分比含量基準值 Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.

備考 2. "O" 係指該項限用物質之百分比含量未超出百分比含量基準值。

Note 2: "o" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考3. "一"係指該項限用物質為排除項目。

Note 3: The "-" indicates that the restricted substance corresponds to the exemption.



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.

EHC

Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.

- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended
- Do not use the device where wireless devices are not allowed.
- Adapter shall be installed near the equipment and shall be easily accessible.
- Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.
- This product uses radios and other components that emit electromagnetic fields. Electromagnetic fields and magnets may interfere with pacemakers and other implanted medical devices. Always keep the product and its power adapter more than 15 cm (6 inches) away from any pacemakers or other implanted medical devices. If you suspect your product is interfering with your pacemaker or any other implanted medical device, turn off your product and consult your physician for information specific to your medical device.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

Symbol	Explanation
\sim	Alternating current
	Class II equipment
\$- C -\$	Polarity of d.c. power connector
VI	Energy efficiency Marking
	DC voltage
\bigtriangleup	Indoor use only
	Operator's manual
	RECYCLING
X	This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/
	User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Explanations of the symbols on the product label