ige∩e

IGENE 62
INSTRUCTION MANUAL FOR TRUE WIRELESS HEADSET

TIPS //

2. During daily use, please regularly clean the charging port and the charging pins of the charging case with an alcohol swab to prevent sweat and dirt affecting charging.

3. After connecting the earphones to some Android/HarmonyOS phones, you need to open the option to synchronize the volume of the Wireless device with the phone in the Wireless settings.

PRODUCT LIST //

1. Please fully charge before first use

4. Please do not use the product outdoors during thunderstorms.

① Charging case ② Earohones ③ Charging cable ④ Ear tips ⑤ Manual

START // NAME: IGENE-G2

ACTIVATE EARPHONES

Use a 5V=1A charging head to charge the case and activate the earphones

PAIR EARPHONES Remove both earphones from the charging case and they will automatically pair

Turn on your phone's Wireless, search for the name "IGene-G2" and click to connect

Note: Some phones will prompt you to confirm pairing with the earphones. Click "Pair" to complete the connection CONNECT EARPHONES

FUNCTION //

POWER ON

Remove the earphone from the charging bay or press and hold it for about 4 seconds to turn it on

Cancel dialing by double-clicking the touch key on either earphone during dialing Answer incoming calls by double-clicking either earphone touch key

Reject incoming calls by long-pressing either earphone touch key for 2 seconds Hang up by double-clicking either earphone touch key during a call

VOICE ASSISTANT

Wake up voice assistant by triple-clicking the left earphone touch key Turn off voice assistant by single-clicking the left earphone touch key Note: Siri of Apple will be waken up and the voice assistant that comes with your Android phone will be turned on – Earphone touch key

MUSIC PLAY

Play music: Play/pause by single-clicking either earphone touch key while playing music

Skip to the previous track by double-clicking the left earphone touch key while music is playing Skip to the next track by double-clicking the right earphone touch key while music is playing

Switch to game (low latency) by triple-clicking the right earphone MFB touch key while in music mode

Return to music mode by triple-clicking the right earphone touch key while in game mode

SWITCH BETWEEN GAME AND MUSIC Music mode is the default mode when the device is turned on

CHARGING INSTRUCTIONS Charging: Charge the earphones by put them back in the charging case and closing the lid



NOTES //

HEALTH AND SAFETY

1. Stop using the product if it shows obvious damage; 2. Do not listen to music at high volume for a long time; 3. Do not use it while driving or engaging in other activities that require concentration;

2. Use the original or certified charging cable;

3. Do not submerge the product in water;

4. Do not use the product outdoors during thunderstorms;

1.Store the product at room temperature, keep it dry, and avoid prolonged exposure to high or low temperatures or humid environments;

The product has a built-in lithium battery, and its composition may change due to surrounding temperatures. Do not use it in environments with extremely high or low temperatures, as this may cause permanent damage to the battery.

Keep the product away from children under 12 and pets to prevent accidental ingestion. Product protection PRODUCT PROTECTION

The battery case can be charged with a 5V = 1A charging head



WHY CAN'T THE LEFT AND RIGHT EARPHONES CONNECT SUCCESSFULLY?

CAN I USE A FAST CHARGER TO CHARGE THE CHARGING CASE? Re: Please use a 5V = 1A charging head to charge the case. High-power charging devices may cause damage to the product.

WARRANTY //

FAQS

Re: The earphones need to be close to each other when pairing and connecting. Please keep the earphones close together during pairing and connection. Once paired successfully, they can be used normally.

iGene reserves the right of final interpretation

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WORRY-FREE AND CONSIDERATE WARRANTY

BRAND NAME


PRODUCT MODEL:

DATE OF PURCHASE

CONTACT NUMBER

USER ADDRESS

WARRANTY



ology (Beijing) Technology Co., Ltd Made in China.