

# INTELLIGENT MUSIC BOXING TARGET



## USER MANUAL

### Product Introduction:



#### Instructions for Use:

1. Press and hold the button to turn on the device; lights will turn on and music will start to play.
2. Press and hold the button for 2-3 seconds to turn off the device.
3. When the device is on, press the SPEED button to adjust speed levels from 1 to 9.
4. When the device is on, press the MODE button for the following modes: P01 for single-player mode; P02 for two-player mode; P03 for Bluetooth mode.  
\*For Bluetooth devices, look for a device name starting with "Boxing Target"; open your phone's settings to connect to the device via Bluetooth, and you can play music from your phone.
5. When the device is on, press the button to adjust the volume from levels 1 to 9.

### Installation Instructions:

#### Installation Method One

1. First, peel off the double-sided tape from the top half of the EVA pad.
2. Stick the EVA pad onto the back of the product, ensuring it is aligned.
3. Peel off the double-sided tape from the bottom half of the EVA pad.
4. Position it correctly, align with the wall, and firmly stick it in place.

#### Installation Method Two

1. Align the adhesive sanding pad with the back of the product.
2. Peel off the double-sided tape from the top half.
3. Position it correctly, align with the wall, and firmly stick it in place.

### Troubleshooting:

NO.	FAULT SYMPTOM	CAUSE ANALYSIS	TROUBLESHOOTING METHOD
1	NO LIGHTS OR SOUND	THE PRODUCT IS NOT POWERED ON	BRIEFLY PRESS THE POWER BUTTON
2	NO LIGHTS OR SOUND	THE BATTERY IS DEPLETED	PLEASE CHARGE
3	LOW BATTERY ALARM SOUND	LOW BATTERY LEVEL	PLEASE CHARGE
4	KNOCKING SOUND INSIDE THE DEVICE	CAUSED BY INTERNAL MOVING STRUCTURES UNDER STRESS	NORMAL PHENOMENON

### Precautions:

1. Please secure the product to a sturdy and reliable wall surface. When striking, hit within the designated hitting area. Do not strike the edge or corner areas to prevent injury to the hands or damage to the equipment.
2. This product is suitable for adults. Children should use it under adult supervision.
3. Beginners should not strike with excessive force to avoid injuring their hands. Safety should be the primary concern during exercise; kicking and knee strikes are strictly prohibited.
4. Do not strike the speaker area.
5. If the equipment cannot power on or is functioning abnormally, check if the battery is low and charge it in time. Charging should not exceed 8 hours, and if the product is not in use for long periods, it is recommended to charge it once every 1-2 months.
6. This product is not waterproof. When wiping the punching target, use a dry cloth and do not dampen with water.
7. Please keep the instruction manual safe for emergency reference.

#### Certificate of Conformity

This product has been rigorously tested and is approved for release from the factory.

PRODUCT NAME: SMART MUSIC BOXING TARGET

INSPECTOR: \_\_\_\_\_

DATE OF MANUFACTURE: \_\_\_\_\_



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction