Charging and Activation **USE MANUAL**

SMART WATCH

- **Buttons and Touch**
- App Download and Connection



Features

vibration reminder. If it says 'Not wearing the watch,' you need to wear the will light up. It takes 30 to 60 seconds, and there will be a vibration reminde The watch can sync notifications from common social apps. Message Note: You can enable/disable sync notifications in the app.

100+ sports modes such as walking, running, cycling, skipping, basketball, etc. are included. Click the icon to start exercising. When connected to the app. you can view more detailed content. After the watch is connected to the app, you can control the phone's

After the smartwatch is connected to the app, you can set single mor'

app. it will prompt that the phone is not connected.

When the device is connected to the app, click 'Find Phone,' and the phone will ring to indicate a successful search. If the watch is not connected to t

alarms or recurring alarms.

Waterproof

Adjustment, Flashlight, Electronic Business Card, Settings,

() During general measurements, the sensor on the watch may not be in corr

Common Issues

and health data syncing will not work.

- 2) Pay attention to ensuring the sensor is in full contact with the wrist during

For more common issues, please refer to the App's 'My' > 'FAO' section.

instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a

FCC Warning

interference by one or more of the following measures.

-Consult the dealer or an experienced radio/TV technician for he