

Facebook page : http://bit.ly/FifinePage

Contact Info: 🔀 E-mail: web@fifine.cc

Please take a few minutes to watch the video before you start using the microphone.

Operation video:

http://bit.ly/k025problemsolving

More product FAQs can be found on the website.

Company Website:

https://fifinemicrophone.com/

mic set exactly:

WARRANTY

Easily get a 2-year extended warranty with online registration within 90 days of purchase.

- 1. Input the link: https://fifinemicrophone.com/
- 2. Please roll down to the bottom of the page, fill in E-mail address and submit it.



- 3. Check your inbox or spam to confirm subscription email.
 - 4. After you click the button "Subscribe me to the list"and next "manage your preferences" to finish registration, tell us the model you are interested, we will send you the promo info/discount code and 2year warranty code as well. PS: If you cannot update your

preferences, just re-do the subscription process.

PRODUCT DISPLAY

1.Microphone



- LED Screen(when frequency changed, the screen is only blinking and remain CH001)
- Slide on-off button
- Battery Compartment
- Channel Button (Every short press the channel button brings 1MHz frequency variation.)
- Microphone Anti-rolling Protection Ring 2.Receiver



green when pairing with transmitter.It turns RED when paired successfully)

On-off Button

- Antenna (Pull it out to extend the range of signal transmission and get better connection with transmitter.) Quarter Inch Jack-plug(6.35mm)
- **Battery Compartment**

QUICK START

- . Insert batteries confirming to "+" and "-". Incorrect installation will result in not working or damaging the microphone set.
- Install the 2AA batteries to microphone.




Make sure the battery polarity is correct installation and the door is closed completely



your speaker before you plugging the receiver into the 1/4" (6.35mm) mic input

2. Make sure to turn down the volume of




We do not recommend to use with portable bluetooth speakers lower than 15 watt, such as JBL charge, Doss 3. Turn the microphone and receiver on

When the light on receiver turn from green to RED, they successfully paired. The light stay on **RED** when it is functioning



from zero to the desired loudness to avoid feedback noise (howling). The best distance between microphone and speaker should be at least 10'. Now your voice would be heard through the speaker when you talk to the microphone. Extend the antenna of receiver to increase the transmission distance if you need.

4. Slowly adjust the mic volume of the speaker



WARNING OF LOW BATTERY POWER

1. Please change microphone battery when the led screen flashes.



2. The battery of receiver need to be changed when the indicator blink green.

- Operation time is limited relative to battery life; To save power, please turn off mic and receiver after use and take the batteries out in time. Not used for a long time will cause battery leaked acid, destroyed microphone equipment.
- 1. Sometimes a battery gets poor contact with the connector inside microphone/ receiver and results in the same symptoms just like if it was drained
- 5.Dying batteries will often register a lower voltage. Some batteries will show nearly full voltage until just before they die. Please replace the new fresh battery in time when low voltage or the mic cut in and out some time.
- 6. Higher coverage will likely result in quicker battery draining. Please prepare a replacement battery in case microphone set that runs out of charge.

if you want to use 2 mic sets. When using multiple microphones simultaneously and there is interference (the mic/s cutting in and out or the range is short), please try other available channels by the below procedure:

You will need 2 transmitters and 2 receivers

MULTIPLE MICROPHONES USED

Both mic and receiver are on.

SIMULTANEOUSLY

2. Unscrew the mic's battery cover, One click on its channel button and the led screen flash once, but the figures on led display will not be changed



- 3. The light on the receiver flash from green to RED at the same time.
- 4. The indicator light stay on red when paired successfully.

S/N Ratio: More than 58dB

Type: Dynamic

Model number: K025

Frequency Response: 50~18KHz

Power Supply: 2*AAA Batteries

WIRELESS FREQUENCY AND CHANNEL GUIDE

The are 20 frequency of k025 for your

choice, you can one click channel button to change. But the alteration would not display on the led screen. 565.000 566.000 567.000 568.000 569.000 570.000 571.000 572.000

573.000 574.000 575.000 576.000 577.000 578.000 579.000 580.000 581.000 582.000 583.000 584.000

RESTORE TO FACTORY SETTINGS

sure you've done all the below steps: 1. You have changed with new fresh

Before enter reset mode, please make

- batteries and you still suffer from interference and disconnection. 2. You have tried other available channels
- by pressing the channel button of the microphone, and they don't pair with each other successfully

K025

USER'S GUIDE

3. If you have multiple K025 and some of microphone set don't work. Please follow the below steps to reset the

- 1. Turn OFF the mic and the receiver before the process.
- 2. Turn the microphone on, unscrew the microphone battery cover, long press channel button for three seconds to enter reset mode



3. The Led screen is blinking if you do it right.(Note:The figures on Led display will not change)

Note: The receiver must remain OFF



3. Turn the receiver on while the screen is flashing. The receiver indicator will flash green and red alternately and then turn green again.



one click the channel button). successfully paired.





4. Pick up microphone again and then one click on it's channel button to confirm. (The Led screen stops flashing after you The indicator of receiver turns red when



TROUBLESHOOTING

| PROBLEM | INDICATOR STATUS | SOLUTION | |
|----------|------------------------------------|--|--|
| No sound | The screen could not turn on | Make sure battery is inserted properly. Observing battery("+/-"). If battery is inserted properly, replace with fresh battery. | |
| No sound | Receiver light blinks green | Make sure battery is inserted properly and the battery cover fully closed. Observing battery("+/-"). If battery is inserted properly, replace with fresh AAA battery. | |
| No sound | Receiver light blinks green | Unscrew the mic's battery cover,one click on it's channel button to change frequency to avoid interference. | |
| No sound | Receiver light is red | Turn up the speaker volume. Turn off the bluetooth function of speaker. Provide the speaker info to FIFINE cs for more suggestion. | |
| No sound | Mic is on, receiver light is green | Using the mic closer to receiver. Reset the mic set. | |

| | PROBLE | М | INDICATOR STATUS | SOLUTION | |
|--|---|---|---|-----------------------------|--|
| | Distortion le increases gradually | evel | Receiver light is red, but mic screen is flashing | Replace transmitter battery | |
| Bursts of nois other audible signals prese | radio | Receiver light is red | Identify potential sources of interference and turn off, remove or use a wireless system operating on a different frequency. | | |
| Momentary los sound as trans is moved arou performing are | smitter und | Receiver light is green when the sound cuts out. | Reposition receiver and perform walk- through test again.If audio dropoutspersist. mark"dead" spots and avoid them during performance. | | |
| $\left \cdot \right $ | Note: If the al | Note: If the above troublechootings don't help, please contact FIFINE customer service team | | | |

Note: If the above troubleshootings don't help, please contact FIFINE customer service team (web@fifine.cc) for further assistance.

IMPORTANT NOTICE

- 1. The transmitter and receiver need to be in direct line of 'sight' for them to work. Wireless mic easily gets interference and blocked by object like a person walking in front of it antenna, make sure to put its receiver as high as possible and keep away from any large piece metal object.
- 2. Turn down the volume and treble of the speaker before connecting the receiver to it could avoid feedback noise.
- Do not point the mic at the speakers, otherwise it will cause feedback noise. 4. When use the mic outdoors, we suggest to
- keep out from the rain and keep it dry. Not compatible with phones, computers, cameras, tablets, Apple products and all

the line in /aux in jacks.

6. If you found the microphone suddenly doesn't work when multiple sets used together, pls change the frequency to have a try. Reference the page 8 for quick set.

SPECIFICATION

Frequency: 565.000-584.000MHz Sensitivity: -95db

Standard impedance: 600 ±30% Sensitivity: -50.60±1db (At 1KHz) Frequency response: 50~18KHz Direction: Uni-direction Operating temperature range: -29 ~43 Construction: Suspension type Power Supply: 2*AA Batteries Response curve: (shown below) Test Range

Version:20-I

13 15

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.