

component maintenance manual

TDR-94/94D (-004 Status and Higher) ATC/Mode S Transponder (ICA)

34-50-96

(with illustrated parts list)

Notice

INFORMATION SUBJECT TO EXPORT LAWS

The technical data in this document (or file) is controlled for export under the Export Administration Regulations (EAR), 15 CFR Parts 730-774. Violations of these laws may be subject to fines and penalties under the Export Administration Act.

Export Control Classification Notice (ECCN) for this document is 6E991.

© Copyright 2010 Rockwell Collins, Inc. All rights reserved.

**Rockwell
Collins**

May 20, 2010

TO: HOLDERS OF THE ROCKWELL COLLINS® TDR-94/94D (-004 STATUS AND HIGHER) ATC/MODE S TRANSPONDER (ICA) COMPONENT MAINTENANCE MANUAL WITH IPL (CPN 523-0778502)

DESCRIPTION OF REVISION NO 13, MAY 20, 2010

This page shows all pages of the manual that are added, changed, or removed. Replace the specified pages of the manual with the new pages supplied. Record the applicable data on the Record of Revisions page.

All changed pages keep data necessary to do maintenance on all equipment models. Black bars on the side of the page identify changes.

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
LEP-1 thru LEP-14	Updated to reflect current revision.	None	All models
LOI-3 thru LOI-5/LOI-6	Updated to reflect current revision.	None	All models
LOT-1, LOT-2	Updated to reflect current revision.	None	All models
INTRO-3	Revised Note explaining the use of XXX.	None	All models
2	Revised Equipment Covered Table 1 to add new CPNs.	None	622-9352-310, 622-9352-410, 622-9210-310, 622-9210-410
23 thru 26, 28	Revised Assembly Identification Tables, Table 6 to include new CPNs.		622-9352-310, 622-9352-410, 622-9210-310, 622-9210-410
2007, 2009/ 2010	Revised Assembly Revision Level and Diagram Reference Table 2002 to add new cards.		All models
2008	Relocation of data.	None	All models
2048.1/2048.2	Added Power Amplifier Circuit Card A2 (CPN 687-0722-006), Maintenance Aid and Schematic Changes Table 2006.1.	None	All models

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
2048.3/2048.4 thru 2048.7/2048.8	Added Power Amplifier Circuit Card A2 (CPN 687-0722-006), Maintenance Aid Diagram Figure 2008.1.	None	All models
2048.9/2048.10 thru 2048.13/2048.14	Added Power Amplifier Circuit Card A2 (CPN 687-0722-006), Schematic Diagram Figure 2008.2.	None	All models
2146.1/2146.2	Added CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Maintenance Aid and Schematic Changes Table 2012.1.	None	All models
2146.3/2146.4 thru 2146.9/2146.10	Added CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Maintenance Aid Diagram Figure 2021.1.	None	All models
2146.11/2146.12 thru 2146.27/2146.28	Added CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Schematic Diagram Figure 2021.2 .	None	All models
2195/2196	Revised Video Processor Circuit Card A6 (CPN 687-0726-006) and Video Processor Circuit Card Assembly A6 (CPN 983-8019-001), Maintenance Aid and Schematic Changes Table 2015.	None	All models
2220.1/2220.2	Added Video Processor Circuit Card A6 (CPN 687-0726-007), Maintenance Aid and Schematic Changes Table 2015.1.	None	All models
2220.3/2220.4 thru 2220.9/2220.10	Added Video Processor Circuit Card A6 (CPN 687-0726-007), Maintenance Aid Diagram Figure 2028.1.	None	All models
2220.11/2220.12 thru 2220.25/2220.26	Added Video Processor Circuit Card A6 (CPN 687-0726-007), Schematic Diagram Figure 2028.2.	None	All models

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
2239/2240	Revised IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005), Maintenance Aid and Schematic Changes Table 2017.	None	All models
2259/2260, 2261/2262	Revised IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005), Schematic Diagram (Sheets 6 and 7).	None	All models
9005	Revised Special Test Equipment Required. (Preferred List) Table 9002.	None	All models
10004 thru 10005/10006	Updated Equipment Designator Prefixes table to reflect current revision and addition of top levels CPN 622-9210-310, -410, CPN 622-9352-310, -410; addition of Chassis Assembly, Main CPN 653-2254-039, -040, -041, -042 and addition of new figures 20 thru 24 CPN 687-0726-007, CPN 828-2700-004, CPN 687-0722-006, CPN 653-0030-002 and CPN 653-0030-003.	None	All models
10007 thru 10011/10012	Updated Manufacturer's Code, Name and Address Index to reflect current revision.	None	All models
10008.1/ 10008.2	New pages added to Manufacturer's Code, Name and Address Index due to new/revised data added on previous pages (data pushed from previous page).	None	All models
10014 thru 10016, 10023 thru 10040, 10050	Updated Equipment Designator Index to reflect current revision.	None	All models

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
10014.1/ 10014.2, 10024.1/ 10024.2, 10026.1/ 10026.2, 10028.1/ 10028.2, 10032.1/ 10032.2, 10034.1/ 10034.2, 10036.1/ 10036.2, 10038.2/ 10038.2	New pages added to Equipment Designator Index due to new/revised data added on previous pages (data pushed from previous page). These pages also updated to reflect current revision.	None	All models
10016.1/ 10016.2, 10040.1/ 10040.2	New pages added to Equipment Designator Index due to new/revised data added on previous pages (data pushed from previous page).	None	All models
10051 thru 10083/10084	Updated Numerical Index to reflect current revision.	None	All models

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
10052.1/ 10052.2, 10054.1/ 10054.2, 10056.1/ 10056.2, 10058.1/ 10058.2, 10060.1/ 10060.2, 10062.1/ 10062.2, 10064.1/ 10064.2, 10068.1/ 10068.2, 10074.1/ 10074.2, 10076.1/ 10076.2, 10078.1/ 10078.2, 10080.1/ 10080.2, 10082.1/ 10082.2	New pages added to Numerical Index due to new/revised data added on previous pages (data pushed from previous page). These pages also updated to reflect current revision.	None	All models
10085 thru 10090, 10091 thru 10101/ 10102	Updated Optional Vendor Index to reflect current revision.	None	All models
10103/10104	Updated Figure 1 illustration and illustration title to reflect current revision and addition of top levels CPN 622-9210-310, -410, CPN 622-9352-310, -410.	None	All models
10105 thru 10107/10108	Updated Figure 1 to reflect current revision, addition of top levels (items 1Y thru 2A) and correction of item 1X nomenclature.	None	All models

PAGE NUMBER	DESCRIPTION OF REVISION AND REASON FOR CHANGE	SERVICE BULLETIN	EFFECTIVITY
10111/10112, 10113 thru 10114.1/ 10114.2	Updated Figure 2 to reflect current revision for top level CPN 653-2255-006.	None	All models
10121/10122	Updated Figure 4 illustration and illustration title to reflect current revision and addition of top levels CPN 653-2254-039, -040, -041, -042.	None	All models
10123 thru 10127/10128	Updated Figure 4 to reflect current revision and addition of top level items 1U thru 1X.	None	All models
10124.1/ 10124.2, 10126.3/ 10126.4	New pages added to Figure 4 due to new/revised data added on previous pages (data pushed from previous page). These pages updated to reflect current revision.	None	All models
10157, 10158	Updated Figure 7 to reflect current next higher assembly reference for item 1.	None	All models
10158.1/ 10158.2	New pages added to Figure 7 due to new/revised data added on previous pages (data pushed from previous page).	None	All models
10349 thru 10366	Added new Figure 20, CPN 687-0726-007.	None	All models
10367 thru 10382	Added new Figure 21, CPN 828-2700-004.	None	All models
10383 thru 10396	Added new Figure 22, CPN 687-0722-006.	None	All models
10397/10398	Added new Figure 23, CPN 653-0030-002 (no illustration required).	None	All models
10399/10400	Added new Figure 24, CPN 653-0030-003 (no illustration required).	None	All models

TDR-94/94D (-004 Status and Higher) ATC/Mode S Transponder (ICA)

component maintenance manual (with illustrated parts list)

This manual includes data for the equipment that follows:

<u>Unit</u>	<u>Model</u>	<u>Collins Part No</u>
ATC/Mode S Transponder	TDR-94	622-9352-004, -005, -006, -007, -008, -108, -207, -308, -309, -310, -408, -409, -410
ATC/Mode S Transponder	TDR-94D	622-9210-004, -005, -006, -007, -008, -108, -207, -308, -309, -310, -408, -409, -410

Printed in the United States of America

© Copyright 2010 Rockwell Collins, Inc. All rights reserved.



TDR - 94 CMM MAY 20 / 2010

34-50-96

Rockwell Collins, Inc.
Cedar Rapids, Iowa 52498
CAGE Code: 4V792

523-0778502-Dg1113
1st Edition, Jul 01/1998
13th Revision, May 20/2010

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

Notice

INFORMATION SUBJECT TO EXPORT LAWS

The technical data in this document (or file) is controlled for export under the Export Administration Regulations (EAR), 15 CFR Parts 730-774. Violations of these laws may be subject to fines and penalties under the Export Administration Act.

Export Control Classification Notice (ECCN) for this document is 6E991.

PROPRIETARY NOTICE

FREEDOM OF INFORMATION ACT (5 USC 552) AND DISCLOSURE OF CONFIDENTIAL INFORMATION GENERALLY (18 USC 1905)

This document and the information disclosed herein are proprietary data of Rockwell Collins, Inc. Neither this document nor the information contained herein shall be used, reproduced, or disclosed to others without the written authorization of Rockwell Collins, Inc., except to the extent required for installation or maintenance of recipient's equipment. This document is being furnished in confidence by Rockwell Collins, Inc. The information disclosed herein falls within exemption (b) (4) of 5 USC 552 and the prohibitions of 18 USC 1905.

SOFTWARE COPYRIGHT NOTICE

© COPYRIGHT 2000-2010 ROCKWELL COLLINS, INC. ALL RIGHTS RESERVED.

All software resident in this equipment is protected by copyright.

We try to supply manuals that are free of errors, but some can occur. If a problem is found with this manual, you can send the necessary data to Rockwell Collins. When you report a specified problem, give short instructions. Include the manual part number, the paragraph or figure number, and the page number.

To send data to Rockwell Collins about this manual:

Address: Rockwell Collins, Inc.
 350 Collins Road NE, M/S 153-250
 Cedar Rapids, IA 52498-0001

Email: techmanuals@rockwellcollins.com

To get more manuals:

Address: Rockwell Collins, Inc.
 Customer Response Center
 400 Collins Road NE, M/S 133-100
 Cedar Rapids, IA 52498-0001

TELEPHONE: 1.888.265.5467
INTERNATIONAL: 1.319.265.5467
FAX NO: 319.295.4941

Email: response@rockwellcollins.com

**ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352**

RECORD OF REVISIONS

REV NO	ISSUE DATE	DATE INSERTED	BY	REV NO	ISSUE DATE	DATE INSERTED	BY
1 Ed	Jul 1/98						
1 Rev	May 18/06						
2 Rev	Nov 02/06						
3 Rev	Nov 10/06						
4 Rev	Apr 17/07						
5 Rev	May 07/07						
6 Rev	Jul 31/07						
7 Rev	Mar 14/08						
8 Rev	Jun 20/08						
9	Sep 25/08						
10	Oct 13/08						
11	Nov 7/08						
12	Dec 16/09						
13	May 20/10						

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RECORD OF TEMPORARY REVISIONS

TEMPORARY REV NO	PAGE NUMBER	ISSUE DATE	BY	DATE REMOVED	BY
1	Title Page	Feb 25/99	Rockwell Collins	Nov 1/00	Rockwell Collins
1	1	Feb 25/99	Rockwell Collins	Nov 1/00	Rockwell Collins
2	198.44	Oct 28/99	Rockwell Collins	Nov 8/02	Rockwell Collins
2	198.52	Oct 28/99	Rockwell Collins	May 18/06	Rockwell Collins
3	198.35	Nov 30/99	Rockwell Collins	Dec 22/99	Rockwell Collins
3	602	Nov 30/99	Rockwell Collins	May 18/06	Rockwell Collins
4	198.35	Dec 22/99	Rockwell Collins	Apr 17/01	Rockwell Collins
5	198.103	Jan 4/00	Rockwell Collins	May 18/06	Rockwell Collins
5	198.114	Jan 4/00	Rockwell Collins	May 18/06	Rockwell Collins
6	198.1	Jan 31/00	Rockwell Collins	Apr 6/00	Rockwell Collins
7	198.11	Feb 28/00	Rockwell Collins	May 18/06	Rockwell Collins
8	107	Mar 1/00	Rockwell Collins	Jun 27/00	Rockwell Collins
9	198.1	Apr 6/00	Rockwell Collins	Aug 29/02	Rockwell Collins
10	198.25	Apr 24/00	Rockwell Collins	May 18/06	Rockwell Collins
11	107	Jun 27/00	Rockwell Collins	Dec 22/00	Rockwell Collins
11	902	Jun 27/00	Rockwell Collins	Dec 22/00	Rockwell Collins
12	101	Sep 27/00	Rockwell Collins	Nov 8/02	Rockwell Collins
13	Title Page	Nov 1/00	Rockwell Collins	Dec 19/00	Rockwell Collins
13	1	Nov 1/00	Rockwell Collins	Dec 19/00	Rockwell Collins
14	Title Page	Dec 19/00	Rockwell Collins	Jan 17/01	Rockwell Collins
14	1	Dec 19/00	Rockwell Collins	Nov 8/02	Rockwell Collins
14	198.32	Dec 19/00	Rockwell Collins	Aug 20/04	Rockwell Collins
14	1011	Dec 19/00	Rockwell Collins	Jan 17/01	Rockwell Collins
14	1015	Dec 19/00	Rockwell Collins	Mar 16/01	Rockwell Collins
15	107	Dec 22/00	Rockwell Collins	Nov 26/01	Rockwell Collins
15	902	Dec 22/00	Rockwell Collins	Nov 26/01	Rockwell Collins
16	Title Page	Jan 17/01	Rockwell Collins	Nov 8/02	Rockwell Collins

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RECORD OF TEMPORARY REVISIONS

TEMPORARY REV NO	PAGE NUMBER	ISSUE DATE	BY	DATE REMOVED	BY
16	1011	Jan 17/01	Rockwell Collins	Mar 16/01	Rockwell Collins
17	198.60	Feb 26/01	Rockwell Collins	May 18/06	Rockwell Collins
17	198.73	Feb 26/01	Rockwell Collins	May 18/06	Rockwell Collins
18	198.6	Mar 16/01	Rockwell Collins	May 18/06	Rockwell Collins
18	198.17	Mar 16/01	Rockwell Collins	May 18/06	Rockwell Collins
18	198.27	Mar 16/01	Rockwell Collins	May 18/06	Rockwell Collins
18	TR-14, pg 5	Mar 16/01	Rockwell Collins	Aug 20/04	Rockwell Collins
18	198.33	Mar 16/01	Rockwell Collins	Aug 20/04	Rockwell Collins
18	1011	Mar 16/01	Rockwell Collins	Oct 3/02	Rockwell Collins
18	1013	Mar 16/01	Rockwell Collins	May 18/06	Rockwell Collins
18	1015	Mar 16/01	Rockwell Collins	Jun 28/05	Rockwell Collins
19	198.35	Apr 17/01	Rockwell Collins	May 17/01	Rockwell Collins
20	137	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.91	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.95	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.102	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.107	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.113	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
20	198.117	May 8/01	Rockwell Collins	May 18/06	Rockwell Collins
21	108	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	136	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	198.16	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	198.34	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	198.35	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	198.37	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
21	198.88	May 17/01	Rockwell Collins	May 18/06	Rockwell Collins
22	107	Nov 26/01	Rockwell Collins	May 18/06	Rockwell Collins

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RECORD OF TEMPORARY REVISIONS

TEMPORARY REV NO	PAGE NUMBER	ISSUE DATE	BY	DATE REMOVED	BY
22	902	Nov 26/01	Rockwell Collins	May 14/03	Rockwell Collins
23	106	Dec 10/01	Rockwell Collins	May 18/06	Rockwell Collins
23	107	Dec 10/01	Rockwell Collins	May 18/06	Rockwell Collins
23	901	Dec 10/01	Rockwell Collins	Aug 20/04	Rockwell Collins
23	902	Dec 10/01	Rockwell Collins	Nov 22/02	Rockwell Collins
24	198.1	Aug 29/02	Rockwell Collins	Nov 13/02	Rockwell Collins
25	198.64	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.65	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.66	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.67	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.78	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.79	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.80	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
25	198.81	Sep 26/02	Rockwell Collins	May 18/06	Rockwell Collins
26	1011	Oct 3/02	Rockwell Collins	Jun 28/05	Rockwell Collins
27	Title Page	Nov 8/02	Rockwell Collins	Jan 19/05	Rockwell Collins
27	1	Nov 8/02	Rockwell Collins	Jan 19/05	Rockwell Collins
27	101	Nov 8/02	Rockwell Collins	May 18/06	Rockwell Collins
27	198.44	Nov 8/02	Rockwell Collins	May 18/06	Rockwell Collins
28	140	Nov 13/02	Rockwell Collins	Jun 25/04	Rockwell Collins
29	902	Nov 22/02	Rockwell Collins	Aug 20/04	Rockwell Collins
30	198.71	Mar 7/03	Rockwell Collins	May 18/06	Rockwell Collins
30	198.82	Mar 7/03	Rockwell Collins	May 18/06	Rockwell Collins
31	902	May 14/03	Rockwell Collins	Aug 20/04	Rockwell Collins
32	129	Jun 25/04	Rockwell Collins	May 18/06	Rockwell Collins
32	140	Jun 25/04	Rockwell Collins	Aug 20/04	Rockwell Collins
32	198.61	Jun 25/04	Rockwell Collins	May 18/06	Rockwell Collins

**ROCKWELL COLLINS
 COMPONENT MAINTENANCE MANUAL with IPL
 TDR-94, PART NO 622-9352**

RECORD OF TEMPORARY REVISIONS

TEMPORARY REV NO	PAGE NUMBER	ISSUE DATE	BY	DATE REMOVED	BY
32	198.75	Jun 25/04	Rockwell Collins	May 18/06	Rockwell Collins
33	198.32	Aug 20/04	Rockwell Collins	May 18/06	Rockwell Collins
33	901	Aug 20/04	Rockwell Collins	May 18/06	Rockwell Collins
33	902	Aug 20/04	Rockwell Collins	Oct 20/04	Rockwell Collins
34	140	Oct 20/04	Rockwell Collins	Jan 19/05	Rockwell Collins
34	902	Oct 20/04	Rockwell Collins	Apr 18/05	Rockwell Collins
35	Title Page	Jan 19/05	Rockwell Collins	Jun 28/05	Rockwell Collins
35	1	Jan 19/05	Rockwell Collins	May 18/06	Rockwell Collins
35	140	Jan 19/05	Rockwell Collins	May 18/06	Rockwell Collins
35	198.41	Jan 19/05	Rockwell Collins	May 18/06	Rockwell Collins
36	902	Apr 18/05	Rockwell Collins	Oct 7/05	Rockwell Collins
37	Title Page	Jun 28/05	Rockwell Collins	May 18/06	Rockwell Collins
37	198.38	Jun 28/05	Rockwell Collins	May 18/06	Rockwell Collins
37	1011	Jun 28/05	Rockwell Collins	May 18/06	Rockwell Collins
37	1015	Jun 28/05	Rockwell Collins	May 18/06	Rockwell Collins
37	1016	Jun 28/05	Rockwell Collins	May 18/06	Rockwell Collins
38	902	Oct 7/05	Rockwell Collins	Jan 3/06	Rockwell Collins
39	902	Jan 3/06	Rockwell Collins	Feb 22/06	Rockwell Collins
40	902	Feb 22/06	Rockwell Collins	May 18/06	Rockwell Collins

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SERVICE BULLETIN LIST

SERVICE BULLETIN NO	SUBJECT	MANUAL REVISION NUMBER	MANUAL REVISION DATE
1 thru 12	These service bulletins are marked out on the unit identification plate of each -004 status TDR-94 and TDR-94D.	1/0	Jul 1/98
13	Converts TDR-94 (-003 status) and TDR-94D (-003 status) to -004 status	1/0	Jul 1/98
14	Reduce uncommanded transitions to standby in burst tune applications	1/0	Jul 1/98
15	Reduce electromagnetic emissions	1/0	Jul 1/98
16	Add Diode Isolation to Strap Inputs	1/1	May 18/06
17	Convert -004 Status to -005 Status	1/1	May 18/06
18	Convert TDR-94 to TDR-94D	1/1	May 18/06
19	TCAS Bus Operation During Standby Mode (Convert -004/005 Status to -006 Status)	1/1	May 18/06
20	SW Update and TCAS Bus Operation During Standby Mode (Convert -004/005 Status to -006 Status and Update -006 SW)	1/1	May 18/06
21	Intermittent TCAS Bus Failure	1/1	May 18/06
22	Reduce Electromagnetic Emmisions	1/1	May 18/06
23	Update Nameplate for JTSO Approval	1/1	May 18/06
24	Repair Instructions to Replace Obsolete Synthesizer Board	1/1	May 18/06
25	Facilitate A7 Replacement Board Due to Non-Procurement Part U104	1/1	May 18/06
26	Reduce Occurrences of Extremely Cold Temp Failures at Start Up	1/1	May 18/06
501	Incorporate Elementary/Enhanced Surveillance (Converts -004/005 Status to -007 Status)	1/1	May 18/06
502	Incorporate Elementary/Enhanced Surveillance (Converts -007 Status to -008 Status)	1/1	May 18/06
503	Addition of ADS-B Capability (Convert -007/008 Status to -108)	1/1	May 18/06
<p>NOTE: Alert Service Bulletins are produced on blue colored paper with the heading ALERT. When an ALERT Service Bulletin is received, take immediate action.</p>			

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SERVICE BULLETIN NO	SUBJECT	MANUAL REVISION NUMBER	MANUAL REVISION DATE
504 Rev 3	Add GAMA Label 102G "Selected Altitude" Compatibility (Converts -007 Status to -207 Status, -008 Status to -308 Status and -108 Status to -408 Status)	1/5	May 07/07

NOTE: Alert Service Bulletins are produced on blue colored paper with the heading ALERT. When an ALERT Service Bulletin is received, take immediate action.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>		<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
TITLE	*	T-1	May 20/10			
	*	T-2	May 20/10	LIST OF TABLES	* LOT-1	May 20/10
RECORD OF REVISIONS	*	RR-1	May 20/10		* LOT-2	May 20/10
		RR-2	Blank	INTRODUCTION	INTRO-1	May 18/06
RECORD OF TEMPORARY REVISIONS					INTRO-2	May 18/06
		RTR-1	May 18/06		* INTRO-3	May 20/10
		RTR-2	May 18/06		INTRO-4	May 18/06
		RTR-3	May 18/06		INTRO-5	May 18/06
		RTR-4	May 18/06		INTRO-6	May 18/06
SERVICE BULLETIN LIST		SBL-1	May 07/07		INTRO-7	May 18/06
		SBL-2	May 07/07		INTRO-8	May 18/06
LIST OF EFFECTIVE PAGES	*	LEP-1	May 20/10	DESCRIPTION AND OPERATION	INTRO-9	May 18/06
	*	LEP-2	May 20/10		INTRO-10	Blank
	*	LEP-3	May 20/10		1	May 18/06
	*	LEP-4	May 20/10		* 2	May 20/10
	*	LEP-5	May 20/10		3	May 07/07
	*	LEP-6	May 20/10		4	May 18/06
	*	LEP-7	May 20/10		5	May 18/06
	*	LEP-8	May 20/10		6	May 18/06
	*	LEP-9	May 20/10		7	May 18/06
	*	LEP-10	May 20/10		8	May 18/06
	*	LEP-11	May 20/10		9	May 18/06
	*	LEP-12	May 20/10		10	May 18/06
	*	LEP-13	May 20/10		11	May 18/06
	*	LEP-14	May 20/10		12	May 18/06
TABLE OF CONTENTS		TC-1	Jun 20/08		13	May 18/06
		TC-2	May 18/06		14	May 18/06
		TC-3	Apr 17/07		15	May 18/06
		TC-4	May 18/06		16	May 18/06
LIST OF ILLUSTRATIONS		LOI-1	May 18/06		17	May 18/06
		LOI-2	Jun 20/08		18	May 18/06
	*	LOI-3	May 20/10		19	May 18/06
	*	LOI-4	May 20/10		20	May 18/06
	*	LOI-5	May 20/10		F 21	May 18/06
		LOI-6	Blank		F 22	Blank
					* 23	May 20/10
					* 24	May 20/10
					* 25	May 20/10
					* 26	May 20/10

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	27	Jun 20/08		67	May 18/06
*	28	May 20/10		68	Blank
	28.1	Jun 20/08	TESTING AND		
	28.2	Blank	FAULT ISOLATION	1001	Jun 20/08
	29	May 18/06		1002	May 18/06
	30	May 18/06		1003	May 18/06
	31	May 18/06		1004	Blank
	32	May 18/06		F 1005	May 18/06
	33	May 18/06		F 1006	Blank
	34	May 18/06		F 1007	May 18/06
	35	May 18/06		F 1008	Blank
	36	May 18/06		1009	May 18/06
	37	May 18/06		1010	May 18/06
	38	May 18/06		1011	May 18/06
	39	May 18/06		1012	Jun 20/08
	40	May 18/06		1013	May 18/06
	41	May 18/06		1014	Mar 14/08
	42	May 18/06		1015	May 18/06
	43	May 18/06		1016	May 18/06
	44	May 18/06		1017	May 18/06
	45	May 18/06		1018	May 18/06
	46	May 18/06		1019	May 18/06
	47	May 18/06		1020	May 18/06
	48	May 18/06		1021	May 18/06
	49	May 18/06		1022	May 18/06
	50	May 18/06		1023	May 18/06
	51	May 18/06		1024	May 18/06
	52	May 18/06		1025	May 18/06
	53	May 18/06		1026	Nov 10/06
	54	May 18/06		1027	May 18/06
	55	May 18/06		1028	Dec 16/09
	56	May 18/06		1028.1	Jun 20/08
	57	May 18/06		1028.2	May 07/07
	58	May 18/06		1028.3	May 07/07
	59	May 18/06		1028.4	Blank
	60	May 18/06		1029	Nov 10/06
	61	May 18/06		1030	May 18/06
	62	May 18/06		1031	Dec 16/09
	63	May 18/06		1032	Jun 20/08
	64	May 18/06		1032.1	May 07/07
	65	May 18/06		1032.2	May 07/07
	66	May 18/06		1033	Nov 10/06

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	1034	May 18/06		1070	May 18/06
	1035	May 18/06		1071	May 18/06
	1036	Dec 16/09		1072	May 07/07
	1036.1	Jun 20/08		1072.1	May 07/07
	1036.2	May 07/07		1072.2	May 07/07
	1036.3	May 18/06		1072.3	May 07/07
	1036.4	Blank		1072.4	May 07/07
	1037	Jun 20/08		1072.5	Jun 20/08
	1038	May 07/07		1072.6	Jun 20/08
	1038.1	May 07/07		1072.7	May 07/07
	1038.2	Blank		1072.8	Blank
	1039	May 18/06		1073	Apr 17/07
	1040	Jun 20/08		1074	May 18/06
	1041	May 18/06		1075	Apr 17/07
	1042	May 18/06		1076	May 18/06
	1043	May 18/06		1077	Apr 17/07
	1044	Jun 20/08		1078	May 18/06
	1045	May 18/06		1079	May 18/06
	1046	Jun 20/08		1080	May 18/06
	1047	May 18/06		1081	May 18/06
	1048	Jun 20/08		1082	May 18/06
	1049	Jun 20/08		1083	Dec 16/09
	1050	Jun 20/08		1084	Blank
	1051	May 18/06	SCHEMATIC AND		
	1052	May 18/06	WIRING DIAGRAMS	2001	May 18/06
	1053	May 18/06		2002	May 18/06
	1054	May 18/06		2003	May 18/06
	1055	May 18/06		2004	May 18/06
	1056	May 18/06		2005	May 18/06
	1057	May 18/06		2006	May 18/06
	1058	May 18/06		* 2007	May 20/10
	1059	May 18/06		* 2008	May 20/10
	1060	May 18/06		* 2009	May 20/10
	1061	May 18/06		2010	Blank
	1062	May 18/06		2011	May 18/06
	1063	May 18/06		2012	Blank
	1064	May 18/06		F 2013	May 18/06
	1065	May 18/06		F 2014	Blank
	1066	May 18/06		F 2015	May 18/06
	1067	May 18/06		F 2016	Blank
	1068	May 18/06		2017	May 18/06
	1069	May 18/06		2018	Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
F 2019		May 18/06		* F 2048.13	May 20/10
F 2020		Blank		F 2048.14	Blank
F 2021		May 18/06		2049	May 18/06
F 2022		Blank		2050	Blank
2023		May 18/06		F 2051	May 18/06
2024		Blank		F 2052	Blank
F 2025		May 18/06		F 2053	May 18/06
F 2026		Blank		F 2054	Blank
F 2027		May 18/06		F 2055	May 18/06
F 2028		Blank		F 2056	Blank
F 2029		May 18/06		F 2057	May 18/06
F 2030		Blank		F 2058	Blank
F 2031		May 18/06		F 2059	May 18/06
F 2032		Blank		F 2060	Blank
F 2033		May 18/06		F 2061	May 18/06
F 2034		Blank		F 2062	Blank
2035		May 18/06		2063	May 18/06
2036		Blank		2064	Blank
F 2037		May 18/06		F 2065	May 18/06
F 2038		Blank		F 2066	Blank
F 2039		May 18/06		F 2067	May 18/06
F 2040		Blank		F 2068	Blank
F 2041		May 18/06		F 2069	May 18/06
F 2042		Blank		F 2070	Blank
F 2043		May 18/06		F 2071	May 18/06
F 2044		Blank		F 2072	Blank
F 2045		May 18/06		F 2073	May 18/06
F 2046		Blank		F 2074	Blank
2047		May 18/06		F 2075	May 18/06
2048		Blank		F 2076	Blank
* 2048.1		May 20/10		2077	May 18/06
2048.2		Blank		2078	Blank
* F 2048.3		May 20/10		F 2079	May 18/06
F 2048.4		Blank		F 2080	Blank
* F 2048.5		May 20/10		F 2081	May 18/06
F 2048.6		Blank		F 2082	Blank
* F 2048.7		May 20/10		2083	May 18/06
F 2048.8		Blank		2084	Blank
* F 2048.9		May 20/10		F 2085	May 18/06
F 2048.10		Blank		F 2086	Blank
* F 2048.11		May 20/10		F 2087	May 18/06
F 2048.12		Blank		F 2088	Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
F 2089		May 18/06		F 2131	May 18/06
F 2090		Blank		F 2132	Blank
2091		May 18/06		F 2133	May 18/06
2092		May 18/06		F 2134	Blank
F 2093		May 18/06		F 2135	May 18/06
F 2094		Blank		F 2136	Blank
F 2095		May 18/06		F 2137	May 18/06
F 2096		Blank		F 2138	Blank
F 2097		May 18/06		F 2139	May 18/06
F 2098		Blank		F 2140	Blank
F 2099		May 18/06		F 2141	May 18/06
F 2100		Blank		F 2142	Blank
F 2101		May 18/06		F 2143	May 18/06
F 2102		Blank		F 2144	Blank
F 2103		May 18/06		F 2145	May 18/06
F 2104		Blank		F 2146	Blank
F 2105		May 18/06		* 2146.1	May 20/10
F 2106		Blank		2146.2	Blank
F 2107		May 18/06		* F 2146.3	May 20/10
F 2108		Blank		F 2146.4	Blank
F 2109		May 18/06		* F 2146.5	May 20/10
F 2110		Blank		F 2146.6	Blank
F 2111		May 18/06		* F 2146.7	May 20/10
F 2112		Blank		F 2146.8	Blank
F 2113		May 18/06		* F 2146.9	May 20/10
F 2114		Blank		F 2146.10	Blank
F 2115		May 18/06		* F 2146.11	May 20/10
F 2116		Blank		F 2146.12	Blank
F 2117		May 18/06		* F 2146.13	May 20/10
F 2118		Blank		F 2146.14	Blank
2119		May 18/06		* F 2146.15	May 20/10
2120		Blank		F 2146.16	Blank
F 2121		May 18/06		* F 2146.17	May 20/10
F 2122		Blank		F 2146.18	Blank
F 2123		May 18/06		* F 2146.19	May 20/10
F 2124		Blank		F 2146.20	Blank
F 2125		May 18/06		* F 2146.21	May 20/10
F 2126		Blank		F 2146.22	Blank
F 2127		May 18/06		* F 2146.23	May 20/10
F 2128		Blank		F 2146.24	Blank
F 2129		May 18/06		* F 2146.25	May 20/10
F 2130		Blank		F 2146.26	Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
* F 2146.27		May 20/10		F 2187	May 18/06
F 2146.28		Blank		F 2188	Blank
2147		May 18/06		F 2189	May 18/06
2148		May 18/06		F 2190	Blank
F 2149		May 18/06		F 2191	May 18/06
F 2150		Blank		F 2192	Blank
F 2151		May 18/06		F 2193	May 18/06
F 2152		Blank		F 2194	Blank
F 2153		May 18/06		* 2195	May 20/10
F 2154		Blank		2196	Blank
F 2155		May 18/06		F 2197	May 18/06
F 2156		Blank		F 2198	Blank
F 2157		May 18/06		F 2199	May 18/06
F 2158		Blank		F 2200	Blank
F 2159		May 18/06		F 2201	May 18/06
F 2160		Blank		F 2202	Blank
F 2161		May 18/06		F 2203	May 18/06
F 2162		Blank		F 2204	Blank
F 2163		May 18/06		F 2205	May 18/06
F 2164		Blank		F 2206	Blank
F 2165		May 18/06		F 2207	May 18/06
F 2166		Blank		F 2208	Blank
F 2167		May 18/06		F 2209	May 18/06
F 2168		Blank		F 2210	Blank
F 2169		May 18/06		F 2211	May 18/06
F 2170		Blank		F 2212	Blank
2171		May 18/06		F 2213	May 18/06
2172		Blank		F 2214	Blank
F 2173		May 18/06		F 2215	May 18/06
F 2174		Blank		F 2216	Blank
F 2175		May 18/06		F 2217	May 18/06
F 2176		Blank		F 2218	Blank
F 2177		May 18/06		F 2219	May 18/06
F 2178		Blank		F 2220	Blank
F 2179		May 18/06		* 2220.1	May 20/10
F 2180		Blank		2220.2	Blank
F 2181		May 18/06		* F 2220.3	May 20/10
F 2182		Blank		F 2220.4	Blank
F 2183		May 18/06		* F 2220.5	May 20/10
F 2184		Blank		F 2220.6	Blank
F 2185		May 18/06		* F 2220.7	May 20/10
F 2186		Blank		F 2220.8	Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
* F 2220.9	May 20/10			F 2245	May 18/06
F 2220.10	Blank			F 2246	Blank
* F 2220.11	May 20/10			F 2247	May 18/06
F 2220.12	Blank			F 2248	Blank
* F 2220.13	May 20/10			F 2249	May 18/06
F 2220.14	Blank			F 2250	Blank
* F 2220.15	May 20/10			F 2251	May 18/06
F 2220.16	Blank			F 2252	Blank
* F 2220.17	May 20/10			F 2253	May 18/06
F 2220.18	Blank			F 2254	Blank
* F 2220.19	May 20/10			F 2255	May 18/06
F 2220.20	Blank			F 2256	Blank
* F 2220.21	May 20/10			F 2257	May 18/06
F 2220.22	Blank			F 2258	Blank
* F 2220.23	May 20/10			* F 2259	May 20/10
F 2220.24	Blank			F 2260	Blank
* F 2220.25	May 20/10			* F 2261	May 20/10
F 2220.26	Blank			F 2262	Blank
2221	May 18/06				
2222	Blank		DISASSEMBLY	3001	May 18/06
F 2223	May 18/06			3002	May 18/06
F 2224	Blank			3003	May 18/06
F 2225	May 18/06			3004	May 18/06
F 2226	Blank				
F 2227	May 18/06		CLEANING	4001	May 18/06
F 2228	Blank			4002	Blank
F 2229	May 18/06		INSPECTION/ CHECK	5001	May 18/06
F 2230	Blank			5002	Blank
F 2231	May 18/06				
F 2232	Blank				
F 2233	May 18/06		REPAIR	6001	May 18/06
F 2234	Blank			6002	May 18/06
F 2235	May 18/06			6003	May 18/06
F 2236	Blank			6004	Blank
F 2237	May 18/06				
F 2238	Blank		ASSEMBLY	7001	May 18/06
* 2239	May 20/10			7002	May 18/06
2240	Blank		FITS AND CLEARANCES	8001	May 18/06
F 2241	May 18/06			8002	May 18/06
F 2242	Blank			8003	May 18/06
F 2243	May 18/06			8004	May 18/06
F 2244	Blank				

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
SPECIAL TOOLS, FIXTURES, EQUIPMENT AND CONSUMABLES				10021	Apr 17/07
				10022	Apr 17/07
				* 10023	May 20/10
				* 10024	May 20/10
				* 10024.1	May 20/10
				10024.2	Blank
				* 10025	May 20/10
				* 10026	May 20/10
				* 10026.1	May 20/10
			10026.2	Blank	
			* 10027	May 20/10	
			* 10028	May 20/10	
			* 10028.1	May 20/10	
			10028.2	Blank	
			* 10029	May 20/10	
			* 10030	May 20/10	
			* 10030.1	May 20/10	
			10030.2	Blank	
			* 10031	May 20/10	
			* 10032	May 20/10	
			* 10032.1	May 20/10	
			10032.2	Blank	
			* 10033	May 20/10	
			* 10034	May 20/10	
			* 10034.1	May 20/10	
			10034.2	Blank	
			* 10035	May 20/10	
			* 10036	May 20/10	
			* 10036.1	May 20/10	
			10036.2	Blank	
			* 10037	May 20/10	
			* 10038	May 20/10	
			* 10038.1	May 20/10	
			10038.2	Blank	
			* 10039	May 20/10	
			* 10040	May 20/10	
			* 10040.1	May 20/10	
			10040.2	Blank	
			10041	Apr 17/07	
			10042	Apr 17/07	
			10043	Apr 17/07	
			10044	Apr 17/07	
ILLUSTRATED PARTS LIST	10001	Apr 17/07			
	10002	Apr 17/07			
	10003	Apr 17/07			
	* 10004	May 20/10			
	* 10004.1	May 20/10			
	10004.2	Blank			
	* 10005	May 20/10			
	10006	Blank			
	* 10007	May 20/10			
	* 10008	May 20/10			
	* 10008.1	May 20/10			
	10008.2	Blank			
	* 10009	May 20/10			
	* 10010	May 20/10			
	* 10010.1	May 20/10			
	10010.2	Blank			
	* 10011	May 20/10			
	10012	Blank			
	10013	Apr 17/07			
	* 10014	May 20/10			
* 10014.1	May 20/10				
10014.2	Blank				
* 10015	May 20/10				
* 10016	May 20/10				
* 10016.1	May 20/10				
10016.2	Blank				
10017	Apr 17/07				
10018	Apr 17/07				
10019	Apr 17/07				
10020	Apr 17/07				

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	
	10045	Apr 17/07		*	10069	May 20/10
	10046	Apr 17/07		*	10070	May 20/10
	10047	Apr 17/07		*	10070.1	May 20/10
	10048	Apr 17/07			10070.2	Blank
	10049	Apr 17/07		*	10071	May 20/10
*	10050	May 20/10		*	10072	May 20/10
*	10051	May 20/10		*	10072.1	May 20/10
*	10052	May 20/10			10072.2	Blank
*	10052.1	May 20/10		*	10073	May 20/10
	10052.2	Blank		*	10074	May 20/10
*	10053	May 20/10		*	10074.1	May 20/10
*	10054	May 20/10			10074.2	Blank
*	10054.1	May 20/10		*	10075	May 20/10
	10054.2	Blank		*	10076	May 20/10
*	10055	May 20/10		*	10076.1	May 20/10
*	10056	May 20/10			10076.2	Blank
*	10056.1	May 20/10		*	10077	May 20/10
	10056.2	Blank		*	10078	May 20/10
*	10057	May 20/10		*	10078.1	May 20/10
*	10058	May 20/10			10078.2	Blank
*	10058.1	May 20/10		*	10079	May 20/10
	10058.2	Blank		*	10080	May 20/10
*	10059	May 20/10		*	10080.1	May 20/10
*	10060	May 20/10			10080.2	Blank
*	10060.1	May 20/10		*	10081	May 20/10
	10060.2	Blank		*	10082	May 20/10
*	10061	May 20/10		*	10082.1	May 20/10
*	10062	May 20/10			10082.2	Blank
*	10062.1	May 20/10		*	10083	May 20/10
	10062.2	Blank			10084	Blank
*	10063	May 20/10		*	10085	May 20/10
*	10064	May 20/10		*	10086	May 20/10
*	10064.1	May 20/10		*	10087	May 20/10
	10064.2	Blank		*	10088	May 20/10
*	10065	May 20/10		*	10088.1	May 20/10
*	10066	May 20/10			10088.2	Blank
*	10066.1	May 20/10		*	10089	May 20/10
	10066.2	Blank		*	10090	May 20/10
*	10067	May 20/10			10090.1	Dec 16/09
*	10068	May 20/10			10090.2	Blank
*	10068.1	May 20/10		*	10091	May 20/10
	10068.2	Blank		*	10092	May 20/10

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
*	10093	May 20/10	*	10124.1	May 20/10
*	10094	May 20/10		10124.2	Blank
*	10094.1	May 20/10	*	10125	May 20/10
	10094.2	Blank	*	10126	May 20/10
*	10095	May 20/10	*	10126.1	May 20/10
*	10096	May 20/10	*	10126.2	May 20/10
*	10096.1	May 20/10	*	10126.3	May 20/10
	10096.2	Blank		10126.4	Blank
*	10097	May 20/10	*	10127	May 20/10
*	10098	May 20/10		10128	Blank
*	10098.1	May 20/10		10129	Apr 17/07
	10098.2	Blank		10130	Apr 17/07
*	10099	May 20/10	F	10131	Apr 17/07
*	10100	May 20/10	F	10132	Blank
*	10101	May 20/10		10133	Apr 17/07
	10102	Blank		10134	Apr 17/07
* F	10103	May 20/10		10135	Apr 17/07
F	10104	Blank		10136	Apr 17/07
*	10105	May 20/10		10137	Apr 17/07
*	10106	May 20/10		10138	Apr 17/07
*	10106.1	May 20/10		10139	Apr 17/07
*	10106.2	May 20/10		10140	Blank
*	10107	May 20/10	F	10141	Apr 17/07
	10108	Blank	F	10142	Blank
F	10109	Apr 17/07	F	10143	Apr 17/07
F	10110	Blank	F	10144	Blank
* F	10111	May 20/10		10145	Apr 17/07
F	10112	Blank		10146	Apr 17/07
*	10113	May 20/10		10147	Jun 20/08
*	10114	May 20/10		10148	Apr 17/07
*	10114.1	May 20/10		10149	Apr 17/07
	10114.2	Blank		10150	Apr 17/07
	10115	Apr 17/07		10151	Apr 17/07
	10116	Blank		10152	Blank
F	10117	Apr 17/07	F	10153	Apr 17/07
F	10118	Blank	F	10154	Blank
	10119	Apr 17/07	F	10155	Apr 17/07
	10120	Apr 17/07	F	10156	Blank
* F	10121	May 20/10	*	10157	May 20/10
F	10122	Blank	*	10158	May 20/10
*	10123	May 20/10	*	10158.1	May 20/10
*	10124	May 20/10		10158.2	Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	10159	Apr 17/07		F 10201	Apr 17/07
	10160	Apr 17/07		F 10202	Blank
	10161	Apr 17/07		F 10203	Apr 17/07
	10162	Apr 17/07		F 10204	Blank
	10163	Apr 17/07		10205	Apr 17/07
	10164	Apr 17/07		10206	Apr 17/07
	10165	Apr 17/07		10207	Apr 17/07
	10166	Blank		10208	Apr 17/07
F 10167	Apr 17/07			10209	Apr 17/07
F 10168	Blank			10210	Blank
F 10169	Apr 17/07			10211	Apr 17/07
F 10170	Blank			10212	Apr 17/07
F 10171	Apr 17/07			10213	Apr 17/07
F 10172	Blank			10214	Blank
F 10173	Apr 17/07			F 10215	Apr 17/07
F 10174	Blank			F 10216	Blank
	10175	Apr 17/07		F 10217	Apr 17/07
	10176	Apr 17/07		F 10218	Blank
	10177	Apr 17/07		F 10219	Apr 17/07
	10178	Apr 17/07		F 10220	Blank
	10179	Apr 17/07		F 10221	Apr 17/07
	10180	Apr 17/07		F 10222	Blank
	10181	Apr 17/07		10223	Apr 17/07
	10182	Apr 17/07		10224	Apr 17/07
	10183	Apr 17/07		10225	Apr 17/07
	10184	Blank		10226	Jun 20/08
	10185	Apr 17/07		10227	Apr 17/07
	10186	Blank		10228	Blank
F 10187	Apr 17/07			10229	Apr 17/07
F 10188	Blank			10230	Apr 17/07
	10189	Apr 17/07		10231	Apr 17/07
	10190	Apr 17/07		10232	Apr 17/07
	10191	Apr 17/07		F 10233	Apr 17/07
	10192	Blank		F 10234	Blank
	10193	Apr 17/07		F 10235	Apr 17/07
	10194	Apr 17/07		F 10236	Blank
	10195	Apr 17/07		F 10237	Apr 17/07
	10196	Blank		F 10238	Blank
F 10197	Apr 17/07			F 10239	Apr 17/07
F 10198	Blank			F 10240	Blank
F 10199	Apr 17/07			10241	Dec 16/09
F 10200	Blank			10242	Dec 16/09

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	10242.1	Dec 16/09		10283	Apr 17/07
	10242.2	Blank		10284	Blank
	10243	Jun 20/08		F 10285	Apr 17/07
	10244	Apr 17/07		F 10286	Blank
	10245	Apr 17/07		10287	Apr 17/07
	10246	Apr 17/07		10288	Apr 17/07
	10247	Apr 17/07		10289	Apr 17/07
	10248	Blank		10290	Blank
F 10249	Apr 17/07			10291	Apr 17/07
F 10250	Blank			10292	Apr 17/07
F 10251	Apr 17/07			10293	Apr 17/07
F 10252	Blank			10294	Apr 17/07
	10253	Apr 17/07		F 10295	Apr 17/07
	10254	Apr 17/07		F 10296	Blank
	10255	Jun 20/08		F 10297	Apr 17/07
	10256	Apr 17/07		F 10298	Blank
	10257	Apr 17/07		F 10299	Apr 17/07
	10258	Blank		F 10300	Blank
	10259	Apr 17/07		F 10301	Apr 17/07
	10260	Apr 17/07		F 10302	Blank
	10261	Apr 17/07		10303	Apr 17/07
	10262	Blank		10304	Jun 20/08
F 10263	Apr 17/07			10305	Apr 17/07
F 10264	Blank			10306	Apr 17/07
F 10265	Apr 17/07			10307	Apr 17/07
F 10266	Blank			10308	Apr 17/07
	10267	Apr 17/07		10309	Apr 17/07
	10268	Apr 17/07		10310	Apr 17/07
	10269	Apr 17/07		10311	Apr 17/07
	10270	Apr 17/07		10312	Apr 17/07
	10271	Apr 17/07		F 10313	Apr 17/07
	10272	Apr 17/07		F 10314	Blank
	10273	Apr 17/07		F 10315	Apr 17/07
	10274	Blank		F 10316	Blank
	10275	Apr 17/07		F 10317	Apr 17/07
	10276	Apr 17/07		F 10318	Blank
	10277	Jun 20/08		F 10319	Apr 17/07
	10278	Apr 17/07		F 10320	Blank
	10279	Apr 17/07		10321	Dec 16/09
	10280	Apr 17/07		10322	Apr 17/07
	10281	Apr 17/07		10323	Apr 17/07
	10282	Blank		10324	Apr 17/07

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	10325	Apr 17/07		* 10367	May 20/10
	10326	Apr 17/07		* 10368	May 20/10
	10327	Apr 17/07		* 10369	May 20/10
	10328	Apr 17/07		10370	Blank
	10329	Apr 17/07		* F 10371	May 20/10
	10330	Apr 17/07		F 10372	Blank
F 10331	Apr 17/07			* F 10373	May 20/10
F 10332	Blank			F 10374	Blank
F 10333	Apr 17/07			* F 10375	May 20/10
F 10334	Blank			F 10376	Blank
F 10335	Apr 17/07			* F 10377	May 20/10
F 10336	Blank			F 10378	Blank
F 10337	Apr 17/07			* 10379	May 20/10
F 10338	Blank			* 10380	May 20/10
	10339	Apr 17/07		* 10381	May 20/10
	10340	Apr 17/07		* 10382	May 20/10
	10341	Apr 17/07		* 10383	May 20/10
	10342	Apr 17/07		10384	Blank
	10343	Apr 17/07		* F 10385	May 20/10
	10344	Apr 17/07		F 10386	Blank
	10345	Apr 17/07		* F 10387	May 20/10
	10346	Apr 17/07		F 10388	Blank
	10347	Apr 17/07		* F 10389	May 20/10
	10348	Apr 17/07		F 10390	Blank
* 10349	May 20/10			* F 10391	May 20/10
* 10350	May 20/10			F 10392	Blank
* 10351	May 20/10			* 10393	May 20/10
* 10352	May 20/10			* 10394	May 20/10
* F 10353	May 20/10			* 10395	May 20/10
F 10354	Blank			* 10396	May 20/10
* F 10355	May 20/10			* 10397	May 20/10
F 10356	Blank			10398	Blank
* F 10357	May 20/10			* 10399	May 20/10
F 10358	Blank			10400	Blank
* F 10359	May 20/10		SPECIAL		
F 10360	Blank		PROCEDURES	11001	May 18/06
* 10361	May 20/10			11002	Blank
* 10362	May 20/10				
* 10363	May 20/10		REMOVAL	12001	May 18/06
* 10364	May 20/10			12002	Blank
* 10365	May 20/10				
* 10366	May 20/10		INSTALLATION	13001	May 18/06

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF EFFECTIVE PAGES

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
	13002	Blank		15002	Blank
SERVICING	14001	May 18/06	REWORK	16001	May 18/06
	14002	Blank		16002	Blank
STORAGE INCLUDING TRANSPORTATION	15001	May 18/06	APPENDIX A	A-1 A-2	May 18/06 Blank

*The asterisk indicates pages with content changed or added by the current change.

F = Foldout Page

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PAGE</u>
INTRODUCTION	INTRO-1
1. Introduction	INTRO-1
A. General	INTRO-1
B. Uncommon Abbreviations/Acronyms	INTRO-3
C. General Advisories	INTRO-8
DESCRIPTION AND OPERATION.....	1
1. General	1
2. Purpose of Equipment	4
3. Equipment Specifications	4
4. Equipment Description	20
A. Mechanical Description.....	20
B. Electrical Description	28.1
C. Controls and Indicators.....	28.1
5. Installation Data	29
6. System Theory of Operation.....	29
A. Introduction	29
B. Radar Systems	29
C. ATCRBS Operation.....	31
D. ATCRBS with Mode S.....	37
E. Typical TDR 94/94D ATC/Mode S Transponder Installations.....	57
7. Integrated Circuit Descriptions.....	63
TESTING AND FAULT ISOLATION	1001
1. Introduction	1001
2. Test Equipment	1001
3. Test Procedures.....	1001
A. Use of Test Procedures	1001
B. Final Performance (Customer Acceptance) Test	1001
C. Detailed Performance Test.....	1001
D. Alignment Procedures	1002
4. Fault Isolation.....	1002
A. Fault Isolation Philosophy	1002
B. Troubleshooting Approach	1002
C. Troubleshooting Aids.....	1003
5. Procedures	1009
A. TDR-94/94D Final Performance (Customer Acceptance) Test Procedure.....	1009
B. TDR-94/94D Alignment Procedures	1072.7
6. Reply Pulse Characteristics.....	1081
A. ATCRBS Replies.....	1081
B. ATCRBS SPI.....	1081
C. ATCRBS Reply Pulse Shape	1081

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PAGE</u>
D. ATCRBS Reply Pulse Spacing Tolerances	1082
E. Mode S Replies	1082
F. Mode S Preamble	1082
G. Mode S Data Pulses	1082
H. Mode S Reply Pulse Shape	1082
7. Non-Procurable Parts Replacements	1083
SCHMATIC AND WIRING DIAGRAMS.....	2001
1. Introduction	2001
2. Modification History	2001
3. Schematic Changes Page, Maintenance Aid, and Schematic Diagrams	2005
A. Schematic Changes Page	2005
B. Maintenance Aid Diagrams.....	2005
C. Schematic Diagrams.....	2005
D. Configuration Effectivity	2005
DISASSEMBLY.....	3001
1. Introduction	3001
2. Precautions and General Techniques.....	3001
3. Disassembly Procedures	3001
A. General	3001
B. Separation of the RFPA Chassis Assembly from the Main Chassis Assembly....	3002
C. Separation of the IF Receiver Chassis Assembly from the Main Chassis Assembly	3003
D. RFPA Chassis Disassembly.....	3004
E. IF Receiver Chassis Disassembly	3004
F. MMT-150 Mounting Tray Disassembly Instructions	3004
CLEANING	4001
1. Introduction	4001
INSPECTION/CHECK	5001
1. Introduction	5001
2. Procedures	5001
REPAIR.....	6001
1. Introduction	6001
2. Repair Tools and Supplies	6001
3. Procedures	6003
4. Electrically Programmable Integrated Circuits	6003
ASSEMBLY.....	7001

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PAGE</u>
1. Introduction	7001
2. Precautions and General Techniques	7001
3. Assembly Procedures	7001
A. General	7001
B. Installation of the RFPA Chassis and IF Receiver Chassis Assemblies to the Main Chassis Assembly	7001
4. Storage	7002
FITS AND CLEARANCES	8001
1. Introduction	8001
2. Procedures	8001
SPECIAL TOOLS, FIXTURES, EQUIPMENT AND CONSUMABLES	9001
1. Introduction	9001
2. Standard Test Equipment	9001
3. Special Test Equipment	9001
4. Tools	9008
5. Consumables	9008
ILLUSTRATED PARTS LIST	10001
1. Introduction	10001
A. General	10001
B. How to Use This Illustrated Parts List	10001
C. Manufacturer's Code, Name, and Address Index	10001
D. Equipment Designator Index	10001
E. Numerical Index	10002
F. Optional Vendor Index	10002
G. Detailed Parts List	10002
H. Equipment Designator Prefixes	10004
2. Manufacturer's Code, Name, and Address Index	10007
3. Equipment Designator Index	10013
4. Numerical Index	10051
5. Optional Vendor Index	10085
6. Detailed Parts List	10103
SPECIAL PROCEDURES	11001
1. Introduction	11001
2. Procedures	11001
REMOVAL	12001
1. Introduction	12001
INSTALLATION	13001

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TABLE OF CONTENTS

<u>SUBJECT</u>	<u>PAGE</u>
1. Introduction	13001
SERVICING	14001
1. Introduction	14001
STORAGE INCLUDING TRANSPORTATION	15001
1. Introduction	15001
2. Storage After Assembly	15001
REWORK	16001
1. Introduction	16001
APPENDIX A	A-1
1. Integrated Circuit Descriptions.....	A-1

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF ILLUSTRATIONS

<u>FIGURE</u>		<u>PAGE</u>
1	TDR-94/94D ATC Mode S Transponder.....	1
2	Assembly Identification Diagram.....	21
3	ATCRBS, PSR and SSR System	30
4	Air Traffic Presentation on the ATC Radarscope	32
5	ATCRBS, SSR Antenna Radiation Pattern	34
6	ATCRBS Interrogator Pulse	35
7	Transponder 4096 Reply Code, Signal Format	36
8	Gillham Altitude, ARINC 572, Encoding Scheme	37
9	Mode S, PSR and SSR System	38
10	Mode S, All-Call, and Discrete Addressing, Interrogation Format	45
11	Mode S Discrete Addressing, Pulse P6 Definition	46
12	Mode S, SSR Antenna Radiation Pattern	49
13	Mode S, Transponder Reply Code Pulse Format	50
14	Mode S, Reply Code Summary	55
15	TDR-94/94D ATC Mode S Transponder Strapping Options	58
16	TDR-94 ATC/Mode S Transponder, with CTL-92/92A Transponder Control Unit, Typical Installation Diagram	59
17	TDR-94 ATC/Mode S Transponder, With CTL-92/92A Transponder Control and CADC Altitude Source, Typical Installation Diagram	60
18	TDR-94D ATC/Mode S Transponder, Datalink and TCAS Installation, With CSDB Control and CADC Altitude Data Source, Typical Installation Diagram ...	61
19	TDR-94D ATC/Mode S Transponder, with ARINC 429 Tuning Source, Typical Installation Diagram	62
20	Basis Logic Gate Descriptions.....	66
21	Basis Operational Amplifier Descriptions.....	66
1001	TDR-94/94D Test Setup Diagram (Preferred Method).....	1005
1002	TDR-94/94D Test Setup Diagram (Alternate Method)	1007
1003	Airborne Position Extended Squitter Test 9.3, Input Data and Results.....	1057
1004	GPS Bus/Airborne Position Extended Squitter/Time Tag Verification Test 9.3A, Input Data and Results	1057

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF ILLUSTRATIONS

<u>FIGURE</u>		<u>PAGE</u>
1005	GPS Bus/Airborne Position Extended Squitter/Time Tag Verification Test 9.3B, Input Data and Results	1059
1006	Surface Position Extended Squitter Test 9.5, Input Data and Results	1060
1007	GPS Bus/Airborne Surface Position Extended Squitter/Time Tag Verification Test 9.5A, Input Data and Results	1061
1008	GPS Bus/Airborne Surface Position Extended Squitter/Time Tag Verification Test 9.5B, Input Data and Results	1062
1009	FMS/INS Primary Data Test 9.6, Input Data and Results	1063
1010	FMS/INS Primary Data Test 9.6A, Input Data and Results.....	1064
1011	Aircraft Identification Squitter Test 9.7, Input Data and Results.....	1065
1012	Aircraft Identification Squitter Test 9.7A, Input Data and Results	1066
1013	Aircraft Identification Message Test 9.7B, Input Data and Results	1067
1014	AIS/ADSS Primary Data Test 9.8, Input Data and Results	1068
1015	SIL Designator Requirements Test 14A.0, Input Data and Results	1069
1016	Configuration Select S0 Discrete Test 16.10A.1, Input Data and Results	1070
1017	Configuration Select S1 Discrete Test 16.10A.2, Input Data and Results	1071
1018	Airborne Position Extended Squitter Test 9.3C, Input Data and Results	1072
1019	GPS Bus / Airborne Position Extended Squitter / Time Tag Test 9.3D, Input Data and Results	1072.1
1020	GPS Bus / Surface Position Extended Squitter / Time Tag Verification Test 9.5C, Input Data and Results.....	1072.2
1021	GPS Bus / Surface Position Extended Squitter / Time Tag Verification Test 9.5D	1072.3
1022	Aircraft Identification Message (-408 ONLY) Test 9.7C.....	1072.4
1023	Aircraft Identification Message (-308, -309 ONLY) Test 9.7D	1072.5
1024	AIS/ADSS Primary Data (-308, -309, -408, -409) Test 9.8B.....	1072.6
2001	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-002), Maintenance Aid Diagram	2013
2002	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-002), Schematic Diagram	2015
2003	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-003), Maintenance Aid Diagram	2019

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF ILLUSTRATIONS

<u>FIGURE</u>		<u>PAGE</u>
2004	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-003), Schematic Diagram	2021
2005	Power Amplifier Circuit Card A2 (CPN 687-0722-003), Maintenance Aid Diagram	2025
2006	Power Amplifier Circuit Card A2 (CPN 687-0722-003), Schematic Diagram	2031
2007	Power Amplifier Circuit Card A2 (CPN 687-0722-004), Maintenance Aid Diagram	2037
2008	Power Amplifier Circuit Card A2 (CPN 687-0722-004), Schematic Diagram	2043
2008.1	Power Amplifier Circuit Card A2 (CPN 687-0722-006), Maintenance Aid Diagram	2048.3
2008.2	Power Amplifier Circuit Card A2 (CPN 687-0722-006), Schematic Diagram	2048.9
2009	Modulator Circuit Card A3 (CPN 687-0723-004), Maintenance Aid Diagram	2051
2010	Modulator Circuit Card A3 (CPN 687-0723-004), Schematic Diagram	2055
2011	Modulator Circuit Card A3 (CPN 687-0723-005), Maintenance Aid Diagram	2065
2012	Modulator Circuit Card A3 (CPN 687-0723-005), Schematic Diagram	2069
2013	Synthesizer Circuit Card A4 (CPN 687-0724-002), Maintenance Aid Diagram ..	2079
2014	Synthesizer Circuit Card A4 (CPN 687-0724-002), Schematic Diagram	2081
2015	Synthesizer Circuit Card A4 (CPN 687-0724-003), Maintenance Aid Diagram ..	2085
2016	Synthesizer Circuit Card A4 (CPN 687-0724-003), Schematic Diagram	2087
2017	CPU-I/O Programmed Assembly A5 (CPN 653-3674-001 thru -018), Maintenance Aid Diagram	2092
2018	CPU-I/O Circuit Card A5A1 (CPN 828-2700-002), Maintenance Aid Diagram ...	2093
2019	CPU-I/O Programmed Assembly A5 (CPN 653-3674-001 thru -018) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-002), Schematic Diagram	2101
2020	CPU-I/O Circuit Card A5A1 (CPN 828-2700-003), Maintenance Aid Diagram ...	2121
2021	CPU-I/O Circuit Card A5A1 (CPN 828-2700-003), Schematic Diagram	2129
2021.1	CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Maintenance Aid Diagram	2146.3
2021.2	CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Schematic Diagram	2146.11

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF ILLUSTRATIONS

<u>FIGURE</u>		<u>PAGE</u>
2022	Partial Schematic of Video Processor Circuit Card A6, (CPN 687-0726-004 at REV D).....	2147
2023	Video Processor Circuit Card A6 (CPN 687-0726-004), Maintenance Aid Diagram	2149
2024	Video Processor Circuit Card A6 (CPN 687-0726-004), Schematic Diagram	2157
2025	Video Processor Circuit Card A6 (CPN 687-0726-005), Maintenance Aid Diagram	2173
2026	Video Processor Circuit Card A6 (CPN 687-0726-005), Schematic Diagram	2181
2027	Video Processor Circuit Card A6 (CPN 687-0726-006) and Video Processor Circuit Card Assembly A6 (CPN 983-8019-001), Maintenance Aid Diagram	2197
2028	Video Processor Circuit Card A6 (CPN 687-0726-006) and Video Processor Circuit Card Assembly A6 (CPN 983-8019-001), Schematic Diagram	2205
2028.1	Video Processor Circuit Card A6 (CPN 687-0726-007), Maintenance Aid Diagram	2220.3
2028.2	Video Processor Circuit Card A6 (CPN 687-0726-007), Schematic Diagram	2220.11
2029	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-004), Maintenance Aid Diagram.....	2223
2030	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-004), Schematic Diagram.....	2231
2031	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005), Maintenance Aid Diagram.....	2241
2032	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005), Schematic Diagram.....	2249
1	TDR-94/94D ATC/Mode S Transponder (CPN 622-9210-004, -005, -006, -007, -008, -108, -207, -309, -409, -308, -408, -310, -410, 622-9352-004, -005, -006, -007, -008, -108, -207, -309, -409, -308, -408, -310, -410).....	10103
2	Chassis Assembly, RFPA (CPN 653-2255-001, -003, -004, -005, -006).....	10109
3	Chassis Assembly, Receiver (CPN 653-2256-005, -006)	10117
4	Chassis Assembly, Main (CPN 653-2254-011, -012, -015, -016, -017, -018, -019, -020, -021, -022, -023, -024, -025, -026, -027, -028, -029, -030, -039, -040, -041, -042)	10121
5	Synthesizer Circuit Card A4 (CPN 687-0724-003)	10129
6	Modulator Circuit Card A3 (CPN 687-0723-005)	10137

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF ILLUSTRATIONS

<u>FIGURE</u>		<u>PAGE</u>
7	Power Amplifier Circuit Card A2 (CPN 687-0722-004)	10151
8	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005) ..	10161
9	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-003)	10185
10	CPU-I/O Circuit Card A5 (CPN 828-2700-002)	10193
11	CPU I/O Circuit Card A5 (CPN 828-2700-003)	10211
12	Video Processor Circuit Card A6 (CPN 687-0726-006)	10229
13	Power Amplifier Circuit Card A2 (CPN 687-0722-003)	10247
14	Modulator Circuit Card A3 (CPN 687-0723-004)	10259
15	Synthesizer Assembly A4 (CPN 687-0724-002)	10275
16	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-002)	10283
17	Video Processor Circuit Card A6 (CPN 687-0726-004)	10291
18	Video Processor Circuit Card A6 (CPN 687-0726-005)	10309
19	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-004) ..	10327
20	Video Processor Circuit Card A6 (CPN 687-0726-007)	10349
21	CPU I/O Circuit Card A5 (CPN 828-2700-004)	10367
22	Power Amplifier Circuit Card A2 (CPN 687-0722-006)	10383
23	Test Select Resistor (CPN 653-0030-002)	10397
24	Test Select Resistor (CPN 653-0030-003)	10399

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
1	Equipment Covered	2
2	Related Publications	3
3	** Deleted ** Abbreviations and Symbols	3
4	Equipment Specifications	4
5	Environmental Qualifications Form	18
6	Assembly Identification Tables.....	23
7	Mode S, Interrogation Code Summary	42
8	Integrated Circuit Descriptions.....	63
1001	Final Performance (Customer Acceptance) Test.	1009
1002	Alignment Procedure	1072.7
1003	TDR-94/94D Non-Procurement Parts Replacements	1083
2001	Modification History	2001
2002	Assembly Revision Level and Diagram Reference	2006
2003	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-002), Maintenance Aid and Schematic Changes.....	2011
2004	High Voltage Power Supply Circuit Card A1 (CPN 687-0721-003), Maintenance Aid and Schematic Changes.....	2017
2005	Power Amplifier Circuit Card A2 (CPN 687-0722-003), Maintenance Aid and Schematic Changes.....	2023
2006	Power Amplifier Circuit Card A2 (CPN 687-0722-004), Maintenance Aid and Schematic Changes.....	2035
2006.1	Power Amplifier Circuit Card A2 (CPN 687-0722-006), Maintenance Aid and Schematic Changes.....	2048.1
2007	Modulator Circuit Card A3 (CPN 687-0723-004), Maintenance Aid and Schematic Changes.....	2049
2008	Modulator Circuit Card A3 (CPN 687-0723-005), Maintenance Aid and Schematic Changes.....	2063
2009	Synthesizer Circuit Card A4 (CPN 687-0724-002), Maintenance Aid and Schematic Changes.....	2077
2010	Synthesizer Circuit Card A4 (CPN 687-0724-003), Maintenance Aid and Schematic Changes.....	2083

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
2011	CPU-I/O Programmed Assembly A5 (CPN 653-3674-001 thru -018) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-002), Maintenance Aid and Schematic Changes.....	2091
2012	CPU-I/O Circuit Card A5A1 (CPN 828-2700-003), Maintenance Aid and Schematic Changes.....	2119
2012.1	CPU-I/O Programmed Assembly A5 (CPN 653-3674-025, -026) and CPU-I/O Circuit Card A5A1 (CPN 828-2700-004), Maintenance Aid and Schematic Changes.....	2146.1
2013	Video Processor Circuit Card A6 (CPN 687-0726-004), Maintenance Aid and Schematic Changes.....	2147
2014	Video Processor Circuit Card A6 (CPN 687-0726-005), Maintenance Aid and Schematic Changes.....	2171
2015	Video Processor Circuit Card A6 (CPN 687-0726-006) and Video Processor Circuit Card Assembly A6 (CPN 983-8019-001), Maintenance Aid and Schematic Changes.....	2195
2015.1	Video Processor Circuit Card A6 (CPN 687-0726-007), Maintenance Aid and Schematic Changes.....	2220.1
2016	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-004), Maintenance Aid and Schematic Changes.....	2221
2017	IF Receiver, DPSK Detector, and LVPS Circuit Card A7 (CPN 687-0727-005), Maintenance Aid and Schematic Changes.....	2239
6001	Repair Materials Required.....	6001
8001	Circuit Board Fits and Clearances.....	8001
9001	Standard Test Equipment Required.....	9001
9002	Special Test Equipment Required. (Preferred List).....	9002
9003	Special Test Equipment Required. (Alternate List).....	9005

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

INTRODUCTION

TASK 34-50-96-99C-801-A01

1. Introduction

SUBTASK 34-50-96-99C-001-A01

A. General

NOTE: Specialized sophisticated test equipment and extensive depot level repair training are required for testing the equipment covered in this manual. Therefore, this manual may not be used to test or repair the subject equipment unless the using facility has been specifically authorized by Rockwell Collins, Inc. to do so. This manual does not need to be kept current if it is only used for reference purposes.

- (1) This component maintenance manual (with illustrated parts list) includes maintenance instructions prepared with ATA Specification 2200 Information Standards for Aviation Maintenance for the Rockwell Collins TDR-94/94D.
- (2) This component maintenance manual gives procedures that let an approved repair person, who does not know the equipment, repair the equipment to a serviceable condition. The procedures help approved repair personnel with maintenance of a line replaceable unit (LRU). The procedures are not for an aircraft mechanic.
- (3) The sections that follow give maintenance instructions:
 - (a) The Description and Operation section gives the function, description, operation, and control of the unit. Mechanical and electrical descriptions of primary subassemblies are also given.
 - (b) The Testing and Fault Isolation section contains the procedures to identify the condition of the unit and isolate a fault (if there is one). Then the repair person can find the applicable steps to correct the problem.
 - (c) The Schematics and Wiring Diagrams section contains the schematic diagrams, wiring, and interconnecting diagrams of circuit cards, modules, and subassemblies of the unit.
 - (d) The Disassembly section contains the procedures to disassemble the unit for a repair or part replacement.
 - (e) The Cleaning section contains special procedures necessary to clean the unit and general procedures to handle the unit.
 - (f) The Inspection/Check section contains the procedures necessary to examine the unit for damage and see if the part or assembly is serviceable.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- (g) The Repair section contains the repair procedures and instructions for the repair of disassembled equipment assemblies.
- (h) The Assembly section contains the procedures to make the disassembled assemblies/modules into a full unit.
- (i) The Fits and Clearances section gives all fits, clearances, and torque values used in procedures to assemble the unit.
- (j) The Special Tools, Fixtures, Equipment and Consumables section gives a summary list of tools, fixtures, test equipment, and consumable items. These items are necessary to complete maintenance procedures given in the component maintenance manual.
- (k) The Illustrated Parts List section contains the data necessary to get replacement parts. An equipment designator index, a numerical index, and an optional vendor index (where applicable) are given. Views given of each assembly, subassembly or unit help you find and identify parts in the detailed parts list.
- (l) The Special Procedures section contains procedures that are necessary as a result of other maintenance procedures. These procedures are not included in other sections of the component maintenance manual.
- (m) The Storage Including Transportation section contains data to prepare the unit for storage or transportation. This section includes special handling, packaging, storage, and preservation instructions.

CAUTION: THE MATERIAL IN THIS MANUAL CAN POSSIBLY CHANGE. BEFORE YOU DO MAINTENANCE OPERATIONS ON THE EQUIPMENT INCLUDED IN THIS MANUAL, MAKE SURE THAT YOU HAVE A COMPLETE AND UP TO DATE MANUAL. REFER TO THE APPLICABLE MANUAL AND SERVICE BULLETIN INDEXES.

- (4) Engineering source data as of May 18/06 was used to prepare this manual. Rockwell Collins has made sure that the procedures given in this manual are serviceable.
 - Procedures given in the Testing/Fault Isolation section have been done on Jul 1/98 to make sure the procedures are serviceable.
 - Procedures given in the Disassembly section have been done on Jul 1/98 to make sure the procedures are serviceable.
 - Procedures given in the Assembly section have been done on Jul 1/98 to make sure the procedures are serviceable.
- (5) This manual uses the Maintenance Task Oriented Support System (MTOSS) for task and subtask identification. The maintenance tasks and other data have special MTOSS

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

numbers given for use with electronic data processing (EDP). The user of this manual can ignore the MTOSS numbers.

- (6) Obey all warnings and cautions given in each section of the manual, and the general warnings and cautions given in this Introduction section.

NOTE: References to unit part numbers that end in XXX are applicable to all statuses listed in this manual.

SUBTASK 34-50-96-99C-002-A01

B. Uncommon Abbreviations/Acronyms

ABBREVIATIONS/SYMBOLS	IDENTIFICATION
ACAS	Airbourne Collision Avoidance System
Address	See Mode S address
A/D (or a/d)	Analog-to-digital (Usually this refers to the process of, or circuit involved in, converting an analog signal into a digital form.)
ADLP	Airbourne Data Link Processor
ADS-B	Automatic Dependent Surveillance-Broadcast
AP	Alignment Procedures: This is a series of procedures appropriate for those circuits or functions equipped with adjustable components; variable or test select resistors, trim capacitors, etc. An adjustment step is performed as a result of a detailed test step which has shown that a particular performance parameter has drifted beyond the specified normal limits. Depending on adjustment component accessibility, disassembly may be required. The primary objective of these procedures is to optimize unit performance. Parameter tolerances may be more stringent for alignment than for normal testing.
Altitude	This normally refers to pressure altitude as supplied by an external sensor and data supplied by an altitude encoder.
ARINC	Aeronautical Radio, Incorporated
ASA (or asa)	Airplane Separation Assurance
ATCRBS	Air Traffic Control Radar Beacon System
ATE	Automatic test equipment
BCD	Binary coded decimal
BITE (or bite)	Built-In Test Equipment
BNR (or Bnr or Bin)	Binary

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

ABBREVIATIONS/SYMBOLS	IDENTIFICATION
CAT or ATP	Customer Acceptance Test or Acceptance Test Procedure. A maintenance test procedure used on a new or newly repaired unit to evaluate its ability to perform its intended purpose. No disassembly is allowed. All external input and output parameters are evaluated. Successful completion of this test gives reasonable assurance that the unit will operate satisfactorily when properly installed. Adaptation is allowed for unique features and applications.
CFDIU	Central Fault Display Interface Unit
CFDS	Centralized Fault Display System
CRT	Cathode ray tube
CSDB	Commercial standard digital bus
DDT (or ddt)	Downlink Data Transfer
DLP	Data Link Processor
downlink	Refers to the message signal path (radio contact) from an airborne transmitter to a ground receiver (see also uplink which refers to the opposite path)
DPSK (or dpsk)	Differential Phase Shift Keying. (Refers to the method of logic differentiation used in mode S message transfer.)
DPT	Detailed Performance Test. A comprehensive maintenance procedure used only on a repair bench for detailed evaluation of performance capability. Disassembly is required. The objective of this procedure is to verify and locate a failure detected in a higher level test; CAT or FPT. This procedure may lead to an alignment or repair procedure and must be followed by the FPT after the necessary repair action.
ELM (or elm)	Extended Length Message (112 bits, as opposed to the normal 56-bit message length)
FIFO (or fifo)	First In, First Out (Refers to a particular data transfer method.)
FPT	Final Performance Test. The most detailed test necessary for a fully assembled unit. The objective of this test is to prove that any repair action has successfully corrected a detected fault and the final assembly process has not adversely affected unit performance. This test must be performed in its entirety and with no interruption after any repair or disassembly action.
GNSS	Global Navigation Satellite System
Host airplane	An airplane equipped with a collision warning system
I/O	Input/Output
Intruder airplane	An airplane entering a defined volume of protected airspace near a host airplane

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

ABBREVIATIONS/SYMBOLS	IDENTIFICATION
IRS	Inertial Reference System
LRU	Line replaceable unit
MCDU	Maintenance Control Display Unit
Mode S (or mode S)	Mode Select. Identifies an air traffic control transponder with unique airplane identification and data handling capabilities. The mode S transponder is an important first step toward eventual air traffic control automation.
Mode S address	The unique code assigned to a mode S/TCAS-equipped airplane. The address is assigned by the appropriate regulatory agency at the time of installation and is not alterable by the crew. The TCAS and ground control uses this address to selectively interrogate the airborne transponder.
MOPS	Minimum Operation Performance Specification. Performance standards published by the Radio Technical Commission for Aeronautics (RTCA), used for avionics certification and by the FAA as the basis for technical standard orders (TSO's)
MSSS	Mode-S Specific Services
MTL (or mtl)	Minimum Trigger Level (often understood to be synonymous with MDS - Minimum Discernible Signal). (Refers to unit sensitivity.)
NM	Nonvolatile Memory
NMI (or nmi)	Nautical Mile: An international unit of linear measure equal to one minute of arc of a great circle of the earth = 6,076.11549 ft. (1,852 m.), as opposed to statute mile = 5,280 ft. (1,609 m.)
PAM	Pulse Amplitude Modulation
PA (or pa)	In the radio electronics environment, PA refers to Power Amplifier or Pulse Amplitude. In the TCAS environment, PA refers to Proximity Advisory. PA is a TCAS I function that provides a warning of the approach of an intruder airplane with less than 1200 feet of vertical separation and within four nmi of the host airplane.
PDP (or pdp)	Parallel Data Processing
PPI (or ppi)	Plan Position Indicator: Typically refers to the ground ATC scope
PPM (or ppm)	Pulse Position Modulation
PSR	Primary Surveillance Radar. That part of the ATC radar system that locates the airplane by radar echo detection. See also SSR.
PWM (or pwm)	Pulse-width modulation
RA	Resolution Advisory. RA is a TCAS II function that provides a warning of, and suggested evasive maneuver(s) to provide adequate separation from, a threatening intruder airplane.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

ABBREVIATIONS/SYMBOLS	IDENTIFICATION								
Reply	Refers to the response of an airborne transponder to an interrogation from a ground or airborne interrogator								
RIP	Receiving Inspection Procedure. A procedure to detect possible shipping damage. Includes shipping carton unpacking instructions.								
RP or RI	Repair Procedures or Repair Instructions. Refers to those unique procedures or instructions appropriate for product repair, that may be beyond normal shop maintenance practices. These procedures can require unique tools and supplies and are located in the Repair section.								
RTS	<p>Return To Service (Test). A maintenance procedure used in a flightline environment, either in the airplane or on a bench, to detect a possible failure in an LRU. No disassembly is allowed. The primary objective is to isolate a reported or suspected failure to either the installation or the LRU. Possible result and disposition can be:</p> <table style="width: 100%; border: none;"> <tr> <td style="text-align: center; width: 50%;"><u>RESULT</u></td> <td style="text-align: center; width: 50%;"><u>DISPOSITION</u></td> </tr> <tr> <td>No trouble found</td> <td>Unit can be returned to service unless trouble report suggests need for further testing; like a possible intermittent fault.</td> </tr> <tr> <td>Inconclusive or marginal results</td> <td>Unit should be sent to repair for additional and more detailed testing</td> </tr> <tr> <td>Failure detected</td> <td>Unit should be sent to repair.</td> </tr> </table>	<u>RESULT</u>	<u>DISPOSITION</u>	No trouble found	Unit can be returned to service unless trouble report suggests need for further testing; like a possible intermittent fault.	Inconclusive or marginal results	Unit should be sent to repair for additional and more detailed testing	Failure detected	Unit should be sent to repair.
<u>RESULT</u>	<u>DISPOSITION</u>								
No trouble found	Unit can be returned to service unless trouble report suggests need for further testing; like a possible intermittent fault.								
Inconclusive or marginal results	Unit should be sent to repair for additional and more detailed testing								
Failure detected	Unit should be sent to repair.								
SAW (or saw)	Surface Acoustic Wave								
SDI	Source destination identifier. Refers to that part of the CSDB data word which defines the unit location (left side, right side, or remote). In ARINC 429, the equivalent function is called SSM (Sign Status Matrix).								
SLS (or sls)	Side Lobe Suppression								
SLC	Sensitivity Level Control								
SMD	Surface Mounted Device								
spr	sync (synchronization) phase reversal. Refers to the technique used to identify a logic 1 in uplink or downlink message protocol.								
squitter	A recognition transmission not in response to an interrogation for use in TCAS surveillance. This term is also used to describe the continuous transmissions by DME ground stations.								
SSM	Sign status matrix. Refers to that part of the ARINC 429 data word which defines the unit location (left or right side). In CSDB, the equivalent function is called SDI (Source/Destination Identifier)								
SSR	Secondary Surveillance Radar. That part of the ATC radar system that solicits a reply from the airborne transponder. See also PSR.								

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

ABBREVIATIONS/SYMBOLS	IDENTIFICATION
TA	Traffic Advisory. A TCAS II function that provides a warning of an approaching intruder airplane with less than 1200 feet of vertical separation. The warning time varies depending upon altitude and precedes the time of anticipated protected airspace penetration.
TCAS	Traffic alert and Collision Avoidance System
TCAS I	A proximity warning system capable of at least 45-degree intruder bearing resolution with a minimum warning range of at least four nmi.
TCAS II	A proximity warning, threat-and-resolution advisory and alerting system capable of 8-degree intruder bearing resolution performance, producing a maximum 40-second warning, and issuing vertical escape maneuver advisories.
TCAS III	Also known as Enhanced TCAS. A proximity warning system similar to TCAS II, but issuing horizontal as well as vertical escape maneuver advisories.
Tdoa	Time difference of arrival. A means of calculating location based on plotting hyperbolic lines of position computed by measuring the time of arrival of a baseline transmitter signal and subsequent signals from other transmitters.
TSP	Trouble Shooting Procedures. Sometimes synonymous with Fault Isolation Procedures. Refers to procedures for detailed circuit analysis and is used to locate or identify a faulty component, module, or circuit function. Disassembly is required. This is usually a branch of the DPT, where the failure may be initially detected, and is followed by an alignment or repair action.
UART	Universal Asynchronous Receiver-Transmitter. Refers to the integrated circuit device which receives, temporarily stores, translates, and transmits the serial data. Data is processed between either CSDB or ARINC 429 and the format needed by the internal data processing circuits.
Udt	Uplink data transfer (see also ddt)
uplink	Refers to the message signal path (radio contact) from a ground transmitter to an airborne receiver (see also downlink which refers to the opposite path)
UUT	Unit Under Test
WOW	Weight-On-Wheels

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SUBTASK 34-50-96-99C-003-A01

C. General Advisories

WARNING: BEFORE HANDLING ANY UNIT OR UNIT COMPONENT, GROUND THE REPAIR OPERATOR THROUGH A CONDUCTIVE WRIST STRAP OR OTHER DEVICE THAT USES A 470K- Ω OR 1M- Ω SERIES RESISTOR TO PREVENT PERSONNEL INJURY BY LIMITING CURRENT THROUGH THE WRIST STRAP TO GROUND.

WARNING: THIS UNIT EXHIBITS A HIGH DEGREE OF FUNCTIONAL RELIABILITY. NEVERTHELESS USERS MUST KNOW THAT IT IS NOT PRACTICAL TO MONITOR FOR ALL CONCEIVABLE SYSTEM FAILURES AND, HOWEVER UNLIKELY, IT IS POSSIBLE THAT ERRONEOUS OPERATION COULD OCCUR WITHOUT A FAULT INDICATION. THE PILOT HAS THE RESPONSIBILITY TO FIND SUCH AN OCCURRENCE BY MEANS OF CROSS-CHECKS WITH REDUNDANT OR CORRELATED DATA AVAILABLE IN THE COCKPIT.

WARNING: SERVICE PERSONNEL ARE TO OBEY STANDARD SAFETY PRECAUTIONS, SUCH AS WEARING SAFETY GLASSES, TO PREVENT PERSONAL INJURY WHILE INSTALLING OR DOING MAINTENANCE ON THIS UNIT.

WARNING: THIS UNIT MAY HAVE PIECE PARTS THAT CONTAIN MATERIALS (SUCH AS BERYLLIUM OXIDE, ACIDS, LITHIUM, RADIOACTIVE MATERIAL, MERCURY, ETC) THAT CAN BE HAZARDOUS TO YOUR HEALTH. IF THE PIECE PART ENCLOSURE IS BROKEN, HANDLE THE PIECE PART IN ACCORDANCE WITH OSHA REQUIREMENTS 29CFR 1910.1000 OR SUPERSEDING DOCUMENTS TO PREVENT PERSONAL CONTACT WITH OR INHALATION OF HAZARDOUS MATERIALS. SINCE IT IS VIRTUALLY IMPOSSIBLE TO DETERMINE WHICH PIECE PARTS DO OR DO NOT CONTAIN SUCH HAZARDOUS MATERIALS, DO NOT OPEN OR DISASSEMBLE PIECE PARTS FOR ANY REASON.

WARNING: USE CARE WHEN USING SEALANTS, SOLVENTS AND OTHER CHEMICAL COMPOUNDS. DO NOT EXPOSE TO EXCESSIVE HEAT OR OPEN FLAME. USE ONLY WITH ADEQUATE VENTILATION. AVOID PROLONGED BREATHING OF VAPORS AND AVOID PROLONGED CONTACT WITH SKIN. OBSERVE ALL CAUTIONS AND WARNINGS GIVEN BY THE MANUFACTURER.

WARNING: REMOVE ALL POWER TO THE UNIT BEFORE DISASSEMBLING IT. DISASSEMBLING THE UNIT WITH POWER CONNECTED IS DANGEROUS TO LIFE.

CAUTION: TURN OFF POWER BEFORE DISCONNECTING ANY UNIT FROM WIRING. DISCONNECTING THE UNIT WITHOUT TURNING POWER OFF MAY CAUSE VOLTAGE TRANSIENTS THAT CAN DAMAGE THE UNIT.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



CAUTION: ESDS DEVICES ARE SUBJECT TO DAMAGE BY EXCESSIVE LEVELS OF VOLTAGE AND/OR CURRENT, JUST AS ARE MORE CONVENTIONAL SEMICONDUCTOR DEVICES. HOWEVER, THE PRECAUTIONS NORMALLY USED TO PROTECT SEMICONDUCTORS ARE NOT SUFFICIENT FOR THE PROTECTION OF ESDS DEVICES BECAUSE OF THEIR VERY HIGH ELECTRICAL RESISTANCE. THE LOW-ENERGY SOURCE THAT MOST COMMONLY DESTROYS ESDS DEVICES IS THE HUMAN BODY WHICH, IN CONJUNCTION WITH NONCONDUCTIVE GARMENTS AND FLOOR COVERINGS, GENERATES AND RETAINS STATIC ELECTRICITY. IN ORDER TO ADEQUATELY PROTECT ESDS DEVICES, THE DEVICE AND EVERYTHING THAT CONTACTS IT MUST BE BROUGHT TO GROUND POTENTIAL BY PROVIDING A CONDUCTIVE SURFACE AND DISCHARGE PATHS. THE FOLLOWING PRECAUTIONS MUST BE FOLLOWED:

- DEENERGIZE OR REMOVE ALL POWER AND SIGNAL SOURCES AND LOADS.
- PLACE THE UNIT ON GROUNDED CONDUCTIVE SURFACE.
- GROUND THE REPAIR OPERATOR THROUGH A CONDUCTIVE WRIST STRAP OR OTHER DEVICE THAT USES A 470-K Ω OR 1-M Ω SERIES RESISTOR TO PREVENT UNIT OR UNIT COMPONENT DAMAGE.
- GROUND ANY TOOLS, SUCH AS SOLDERING EQUIPMENT, THAT WILL CONTACT THE UNIT. CONTACT WITH THE OPERATOR'S HAND PROVIDES A SUFFICIENT GROUND FOR TOOLS THAT ARE OTHERWISE ELECTRICALLY ISOLATED.
- WHEN ESDS DEVICES AND ASSEMBLIES ARE NOT IN THE UNIT, THEY SHOULD BE ON THE CONDUCTIVE WORK SURFACE OR IN CONDUCTIVE CONTAINERS.
- WHEN A DEVICE OR ASSEMBLY IS INSERTED OR REMOVED FROM A CONTAINER, THE OPERATOR SHOULD MAINTAIN CONTACT WITH THE CONDUCTIVE PORTION OF THE CONTAINER.
- DO NOT USE PLASTIC BAGS UNLESS THEY HAVE BEEN IMPREGNATED WITH A CONDUCTIVE MATERIAL.
- DO NOT HANDLE ESDS DEVICES UNNECESSARILY OR REMOVE THEM FROM THEIR PACKAGES UNTIL ACTUALLY USED OR TESTED.
- TO PREVENT DAMAGE BY TRANSIENT VOLTAGES, ONLY SOLDERING IRONS THAT MEET THE GUIDELINES STATED IN THE JOINT INDUSTRY STANDARD, J-STD-001, APPENDIX A, SHOULD BE USED.

(1) Observe all warnings and cautions listed within each section as well as the general warnings and cautions listed in the Introduction section of this manual.


ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

DESCRIPTION AND OPERATION

TASK 34-50-96-870-801-A01

1. General

- A. The TDR 94/94D ATC/Mode S Transponder is a solid state, airborne, air traffic control (ATC) transponder that responds to ATCRBS (Air Traffic Control Radar Beacon System) Mode A and Mode C interrogations as well as Mode S (Mode Select) interrogations. The Mode-S transponder differs from earlier ATCRBS transponders in the capability of responding to discretely addressed interrogations and by the capability of receiving and sending data link communications. The TDR 94D Mode S Transponder is also capable of operating through either of two antennas for use in diversity installations for air to air surveillance and communications.
- B. Figure 1/GRAPHIC 34-50-96-99B-001-A01 shows an overall view of the equipment. Table 1/Table 34-50-96-99A-001-A01 is a list of equipment covered in this manual. Table 2/Table 34-50-96-99A-002-A01 is a list of related publications. Table 3, Abbreviations and Symbols, has been moved to the Introduction section of this manual.



CG0-2666-01-AC

TDR-94/94D ATC Mode S Transponder
Figure 1/GRAPHIC 34-50-96-99B-001-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

EQUIPMENT TYPE	DESCRIPTION	COLLINS PART NUMBER
TDR-94	<p>TDR-94 Mode A, C, and S transponder primarily for non-TCAS applications; including CLASS 3A Automatic Dependent Surveillance-Broadcast (ADS-B) capability. The -005 unit is the same as the -004 unit but has improved software to properly report altitude resolution, when the altitude data is derived from a Gillham-based altitude encoder.</p> <p>The -006 is the same as a -005 but has improved software to prevent non-Collins TCAS systems displaying a TCAS flag, or intermittent TCAS flag, when the TCAS is in the Standby mode.</p> <p>The -007 unit has the capability to process aircraft Flight Identification inputs and to support expanded ground station Surveillance Identifier (SI) codes.</p> <p>The -008 status provides Elementary and Enhanced Surveillance functionality for Proline4/21 integrated systems that use IOC-851A, 3100, 4000, or 4100 Input/Output Concentrators. The -008 status may also be used in non-integrated installations.</p> <p>The -108 status is the same as the -008 but adds Automatic Dependent Surveillance-Broadcast (ADS-B) functionality.</p> <p>The -207, -308 and -408 is the same as the -007, -008, and -108 respectively but adds GAMA Label 102G "Selected Altitude" compatibility.</p>	622-9352-004, -005, -006, 007, -008, -108, -207, -308, -309, -310, -408, -409, -410
TDR-94D (Cont)	<p>TDR-94D Mode A, C, and S diversity transponder with full TCAS compatibility features; including CLASS 3A/ADS-B capability. The -005 unit is the same as the -004 unit but has improved software to properly report altitude resolution, when the altitude data is derived from a Gillham-based altitude encoder.</p> <p>The -006 is the same as a -005 but has improved software to prevent non-Collins TCAS systems displaying TCAS flag, or intermittent TCAS flag, when the TCAS is in the Standby mode.</p>	622-9210-004, -005, -006, -007, -008, -108, -207, -308, -309, -310, -408, -409, -410

Equipment Covered Cont.
Table 1/Table 34-50-96-99A-001-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

EQUIPMENT TYPE	DESCRIPTION	COLLINS PART NUMBER
TDR-94D (Cont)	<p>The -007 unit has the capability to process aircraft Flight Identification inputs and to support expanded ground station Surveillance Identifier (SI) codes.</p> <p>The -008 status provides Elementary and Enhanced Surveillance functionality for Proline 4/21 integrated systems that use IOC-851A, 3100, 4000, or 4100 Input/Output Concentrators. The -008 status may also be used in non-integrated installations.</p> <p>The -108 status is the same as the -008 but adds Automatic Dependent Surveillance-Broadcast (ADS-B) functionality.</p> <p>The -207, -308, and -408 is the same as the -007, -008, and -108 respectively but adds GAMA Label 102G "Selected Altitude" compatibility.</p>	

Equipment Covered
Table 1/Table 34-50-96-99A-001-A01

PUBLICATION	ATA NO	COLLINS PART NUMBER
Rockwell Collins Avionics Standard Shop Practices Manual, Instruction Manual	None	523-0768039
Collins Pro Line II Comm/Nav/Pulse System, Installation Manual	None	523-0772719
Collins TDR-94/94D Mode S Transponder System, Instruction Book (Flightline Maintenance)	None	523-0775652
Collins CTL-92T TCAS Control, Component Maintenance Manual	34-40-84	523-0776595
Collins RTU-870A/870T Radio Tuning Unit, Component Maintenance Manual	23-80-80	523-0774068
Collins CTL-X2/X2A/22C Controls, Instruction Book (Repair Manual)	23-80-80	523-0772495

Related Publications
Table 2/Table 34-50-96-99A-002-A01

Table 3/Table 34-50-96-99A-003-A01 ** Deleted **

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TASK 34-50-96-870-802-A01

2. Purpose of Equipment

- A. The TDR-94/94D ATC/Mode S Transponder is the airborne transponder for ATCRBS and provides the data link processing function for ATC. The TDR-94/94D provides mode A, mode C, and special identification replies to ATCRBS interrogations for tracking, identification, and altitude reporting purposes. In addition, the TDR-94/94D is capable of receiving and sending mode S message formats that will be required for air traffic control automation. The added data link capability allows the transponder to perform additional air traffic control and airplane separation assurance (ASA) functions. In mode S operation each airplane is assigned a unique address code. This code can be used to direct interrogations to a specific airplane. The reply also contains this unique address to identify the sending airplane.

TASK 34-50-96-870-803-A01

3. Equipment Specifications

- A. Table 4/Table 34-50-96-99A-036-A01 lists the environmental and equipment specifications for the TDR-94/94D Transponder.

CHARACTERISTIC	SPECIFICATION
Certification	
TSO	
FAA	TDR-94 TSO-C112, 3A2, 121, 010 TDR-94D TSO-C112, 3A2, 121, 011
RTCA	DO-181A (through change 2c "TCAS Change No. 7 Compatibility"), DO-144
Software, RTCA	DO-178A (Level 2), DO-178B (Level B)
Software, EUROCAE	ED-12A, ED-12B
Deutsche Bundespost FTZ	A44652010
ICAO	Annex 10
Environmental	
RTCA	DO-160C, refer to Table 5/Table 34-50-96-99A-037-A01 for additional information
EUROCAE	ED-14B
Physical	

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Size	
Height	84.6 mm (3.33 in)
Width	124.5 mm (4.90 in)
Length	353.2 mm (13.91 in)
Weight	3.8 kg (8.5 lb)
Mounting	MMT-150 Mounting Tray; 1/2 ATR, short, dwarf (Refer to Pro Line II Comm/NAV/Pulse Installation Manual for additional information.)
Mating Connector	Thinline II, qty 2, 60-pin (Kits: CPN: 628-8661-001/002 or 628-8660-001/002) (Refer to Pro Line II Comm/Nav/Pulse Installation Manual for additional information.)
Cooling	Convection If installed transponder is in an enclosed area with minimum air flow, it is advisable for the installer to mount a small fan in the vicinity to generate air flow around the unit. Although not required, use of the fan will result in reduced component temperatures and corresponding increase in reliability.
Time between overhaul	On condition of failure or as required by Federal Regulations (see example below), other regulations may apply. Consult appropriate regulatory documents and agencies for complete information.
Regulatory requirement for flightline test	FAR 91.413 ATC TRANSPONDER TESTS AND INSPECTIONS. "(a) No person may use an ATC transponder that is specified in Part 125 §91.24 (a), §121.345, §127.123 (b), or §135.143 (c) of this chapter unless, within the preceding 24 calendar months, that ATC transponder has been tested and inspected and found to comply with Appendix F of Part 43 of this chapter; and following any installation or maintenance on an ATC transponder where data correspondence error could be introduced, the integrated system has been tested, inspected, and found to comply with paragraph Appendix E of Part 43 of this chapter."
Power requirements	27.5 ±2.5 V dc at 28 watts nominal, 100 watts peak
Transmitter	
Frequency	1090 ±1 MHz
Power output	250 watts min and 625 watts max (measured at the unit's antenna connector terminated into a 50-ohm resistive load.)
Load impedance	50 nominal
VSWR	1.5:1 service max; 3:1 survival
Receiver	

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Frequency	1030 ±0.2 MHz from ATCRBS interrogators and 1030 ±0.01 MHz from Mode-S interrogators
IF	60 MHz nominal
Sensitivity	73 dBm ±4 dBm
Reply modes	ATCRBS mode A ATCRBS mode C ATCRBS mode A/Mode S All Call ATCRBS mode C/Mode S All Call Mode S, short (56-bit) Mode S, long (112-bit)
Reply rate	
ATCRBS	500 15-pulse replies/sec, or 1200 15-pulse replies in 100 ms - burst

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Mode S	50 short including 16 long replies in 1 sec, or 18 short including 6 long replies in 100 ms, or 8 short including 4 long replies in 25 ms, or 4 short including 2 long in 1.6 ms
ATCRBS SLS	
Max of 10% replies and sls initiated	P1 pulse is MTL +3 dB to -21 dBm and P2 equal to or greater than P1
Max of 10% replies and sls may be initiated	P1 pulse is MTL to MTL +3 dB and P2 equal to or greater than P1
Minimum of 90% replies and no sls	P1 pulse is MTL +3 dB to -21 dBm, and P1 pulse is min of 9 dB greater than P2
	No P2 pulse occurs at $2.0 \pm 0.7 \mu\text{s}$ after leading edge of P1, or P2 pulse duration is less than 0.3 μs
Mode S side lobe suppression	Max of 10%
Electrical	
Primary power (P1-58)	27.5, ± 2.5 , V dc
Primary power common (P1-60)	27.5 V dc common
Data bus:	
CSDB:	
Structure	8-bits/byte, 6-bytes/block
Rate	12.5 kbps, 10-frames/s nominal, 18-blocks/frame max
Data blocks	(All labels are in hexadecimal form.) A0: altitude data; input 1E: ATC code/altitude; input or output 1F: ATC data; output F3: diagnostic data; output
ARINC 429:	
Structure	8-bits/byte, 4-bytes/word
Rate	5-words/sec min

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Data labels	<p>(All labels are in octal form.)</p> <p>*013: TDR and TCAS control, input/output</p> <p>*015: Altitude select limits, input/output</p> <p>*016: Mode S control, input/output</p> <p>*031: ATC Transponder Control, input/output</p> <p>*200: Gillham altitude encoder data, input/output</p> <p>*203: TDR altitude data to TCAS, input/output</p> <p>204: TDR corrected barometric altitude to TCAS, output</p> <p>272: TCAS coordination data, part 1, output</p> <p>273: TCAS data for downlink message formats 16, 20, 21, input</p> <p>274: TCAS coordination data, part 2, output</p> <p>274: TCAS data for downlink message formats 0 and 16, input</p> <p>275: TCAS control, part 1, output</p> <p>275: TCAS acknowledge, input</p> <p>276: TCAS control, part 2, output</p> <p>277: TCAS acknowledge, input</p> <p>277: Diagnostic data request, input</p> <p>350: Maintenance data, output</p> <p>352: Control maintenance word pass-through</p> <p>371: Equipment ident, output</p> <p>* These labels are normally echoed and/or passed through to the TCAS as received, except for the SSM which may be different depending on the state of the transponder.</p>
Tuning inputs	Monitored only if Burst Mode (P2-59) is not selected; i.e., P2-59 is open
P2-31	CSDB, A
P2-32	CSDB, B
P2-17	ARINC 429, A (tune input port A)
P2-18	ARINC 429, B (tune input port A)
P2-13	ARINC 429, A (tune input port B)
P2-14	ARINC 429, B (tune input port B)
P2-21	ARINC 429, A (tune input port C)
P2-22	ARINC 429, B (tune input port C)
P2-27*	*ARINC 429, A (FMS/IRS data in)
P2-28*	*ARINC 429, B (FMS/IRS data in)
P2-39*	*ARINC 429, A (AIS/ADS data in)
P2-40*	*ARINC 429, B (AIS/ADS data in)
P2-49*	*ARINC 429, A (GPS data in)
P2-50*	*ARINC 429, B (GPS data in)

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION																				
*These busses can be set for low speed (12.5 kHz) or high speed (100 kHz) operation using their associated low/high speed selection straps (see Chart 1).	<p>Chart 1. Low/High Speed Bus Selection.</p> <table border="1"> <thead> <tr> <th><u>Bus Name</u></th> <th><u>Bus Pins</u></th> <th><u>Strap Name</u></th> <th><u>Strap Pin</u></th> <th><u>GND</u></th> </tr> </thead> <tbody> <tr> <td>GPS Data In</td> <td>J2-49/50</td> <td>GPS_Lo/Hi_Sel</td> <td>J1-18</td> <td>High Speed</td> </tr> <tr> <td>FMS/IRS Data In</td> <td>J2-27/27</td> <td>FMS/IRS_Lo/Hi_Sel</td> <td>J1-24</td> <td>High Speed</td> </tr> <tr> <td>AIS/ADS Data In</td> <td>J2-39/40</td> <td>AIS/ADS_Lo/Hi_Set</td> <td>J1-57</td> <td>High Speed</td> </tr> </tbody> </table>	<u>Bus Name</u>	<u>Bus Pins</u>	<u>Strap Name</u>	<u>Strap Pin</u>	<u>GND</u>	GPS Data In	J2-49/50	GPS_Lo/Hi_Sel	J1-18	High Speed	FMS/IRS Data In	J2-27/27	FMS/IRS_Lo/Hi_Sel	J1-24	High Speed	AIS/ADS Data In	J2-39/40	AIS/ADS_Lo/Hi_Set	J1-57	High Speed
<u>Bus Name</u>	<u>Bus Pins</u>	<u>Strap Name</u>	<u>Strap Pin</u>	<u>GND</u>																	
GPS Data In	J2-49/50	GPS_Lo/Hi_Sel	J1-18	High Speed																	
FMS/IRS Data In	J2-27/27	FMS/IRS_Lo/Hi_Sel	J1-24	High Speed																	
AIS/ADS Data In	J2-39/40	AIS/ADS_Lo/Hi_Set	J1-57	High Speed																	
<p>Altitude inputs</p> <p>P2-33 P2-34 P2-35 P3-36 P2-25** P2-26** P2-29** P2-30**</p> <p>** On the -008/-108 statuses only, the Altitude Port A/B High Speed Select discrete input (P1-26) selects the bus speed (100 or 12.5 kbps).</p>	<p>CSDB, A (altitude input port A) CSDB, B (altitude input port A) CSDB, A (altitude input port B) CSDB, B (altitude input port B) ARINC 429/575, A (altitude input port A) ARINC 429/575, B (altitude input port A) ARINC 429/575, A (altitude input port B) ARINC 429/575, B (altitude input port B)</p>																				
<p>Data outputs</p> <p>P2-23 P2-24 P2-15 P2-16 P2-19 P2-20</p>	<p>CSDB, A (Bus 1) CSDB, B (Bus 1) ARINC 429, A (Port A) ARINC 429, B (Port B) ARINC 429, A (Port A) ARINC 429, B (Port B)</p>																				

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Peripheral data	
P2-1	ARINC 429, A (Comm A/B input)
P2-2	ARINC 429, B (Comm A/B input)
P2-3	ARINC 429, A (Comm A/B output)
P2-4	ARINC 429, B (Comm A/B output)
P2-5	ARINC 429, A (Comm C/D input)
P2-6	ARINC 429, B (Comm C/D input)
P2-7	ARINC 429, A (Comm C/D output)
P2-8	ARINC 429, B (Comm C/D output)
P2-9	ARINC 429, A (TCAS coord data input)
P2-10	ARINC 429, B (TCAS coord data input)
P2-11	ARINC 429, A (TCAS coord data output)
P2-12	ARINC 429, B (TCAS coord data output)
Discrete inputs	
P1-1	B4, ARINC 572 altitude input
P1-2	B2, ARINC 572 altitude input
P1-3	B1, ARINC 572 altitude input
P1-4	A4, ARINC 572 altitude input
P1-5	A2, ARINC 572 altitude input
P1-6	A1, ARINC 572 altitude input
P1-7	D4, ARINC 572 altitude input
P1-8	D2, ARINC 572 altitude input
P1-9	C4, ARINC 572 altitude input
P1-10	C2, ARINC 572 altitude input
P1-11	C1, ARINC 572 altitude input
P1-12	Common, ARINC 572 altitude input

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
Mode S address discrettes	
P1-32	Common
P1-33	B1
P1-34	B2
P1-35	B3
P1-36	B4
P1-37	B5
P1-38	B6
P1-39	B7
P1-40	B8
P1-41	B9
P1-42	B10
P1-43	B11
P1-44	B12
P1-45	B13
P1-46	B14
P1-47	B15
P1-48	B16
P1-49	B17
P1-50	B18
P1-51	B19
P1-52	B20
P1-53	B21
P1-54	B22
P1-55	B23
P1-56	B24
Single discrete straps	
P2-51	Antenna, dual/single select (gnd = single bottom antenna used and all diversity functions are inhibited)
P2-56	CSDB/ARINC 429 control select (gnd = CSDB control bus is selected for control of data input)
P2-60	ADLP select (gnd = ADLP included in installation)
P1-13	TCAS installed (gnd = TCAS included in installation)
	<u>NOTE:</u> There is no provision for TCAS control in CSDB. Therefore, the TDR-94D will not report TCAS capability in its replies to interrogations when CSDB is enabled (P2-56 grounded), even if TCAS is selected (P1-13 grounded) and dual antenna enabled (P2-51 open).

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
P1-17 (-004 thru -007 status only)	IRS enable (gnd = transponder uses IRS/FMS data input on P1-2-27 and P2-28)
P1-17 (-008/-108 status only)	Configuration select 1 (See Combination Discretes below)
P1-18	GPS Lo/Hi speed select (gnd = enables the transponder to send high speed DGPS information to an on-board GNNS receiver via the Comm-C/D Output bus (P2-7 and P2-8) using a modified Williamsburg protocol).
P1-19 (-004 thru -007 status only)	MSSS enable (gnd = transponder is enables to perform Mode-S specific functions)
Functional I/O	
P2-55	Standby discrete (gnd = in standby)
P1-28 (-004 thru -007 status only)	Automatic altitude select enable (gnd = auto alt select enabled)
P1-28 (-008/-108 status only)	Configuration select 0 (See Combination Discretes below)
P1-14	Control Altitude Select (See Combination Discretes below) (gnd = port A altitude data supplied on control port, port B same as open), (open = ports A and B altitude selectable via altitude type select discretes, P2-41/42)
P2-53	Air/ground discrete #1 (gnd = WOW); continue replying to all interrogations while on the ground.
P1-27	Air/ground discrete #2 (gnd = WOW); inhibit replies to ATCRBS, ATCRBS/Mode-S All-call, and Mode-S only All-call interrogations when on the ground
P2-48	Reporting altitude port select (gnd = port B)
P2-59	Burst tune enable (gnd = burst)
	<u>NOTE:</u> In Burst Tune mode the control port strapping (P2-57/58) is ignored. Burst tune data is accepted on ports A, B, and C as 30 ARINC-429 words spaced over an interval of 1.5 seconds with 500 msec dwell time on each port (dwell time is suspended when data is present). Continuous data is always accepted if available. If continuous data is available on part B, then the burst data on ports A and C will be ignored.

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
P1-15 P1-30	Cross-side input (connected to opposite TDR P1-30, gnd input = command to standby) Cross-side output (connected to opposite TDR P1-15, gnd output = active mode) (These connections are used in dual burst-tune TDR installations to ensure that only one transponder is operating at a time)
P1-31	Fault monitor output (28 V dc = valid, 200 mA max)
P1-26 (-004 thru -007 status only)	Acquisition squitter inhibit (when grounded, this discrete commands the transponder to stop executing the acquisition squitter (DF=11) function).
P1-26 (-008/ -108 status only)	Altitude port A/B high speed select. When ground, the transponder accepts altitude data from altitude ports A and B at a 100 kbps rate. When open, the transponder accepts altitude data from altitude ports A and B at a 12.5 kbps rate.
P1-59	Extended squitter disable discrete input (gnd = transponder must not perform the extended squitter functions but it must continue to perform all required acquisition squitter functions; open = transponder must perform all extended squitter functions as well as all acquisition squitter functions.)
P1-29	Suppression input/output pulse (connected to all other L-band equipment)
P1-25	Suppression shield (this pin is used for proper termination of suppression input/output shield)
P1-16	SPI (remote ident) input (gnd = ident on)
Maintenance specific:	
P2-38 (-004 thru -007 status) P1-19 (-008/-108 status)	Self-test inhibit (gnd = all self-test and squitter functions are inhibited) (for maintenance purposes only)
P2-37, 38 (-008/-108 status)	GPS time tag high and low inputs (respectively). This differential input pair is conditioned on the CPU-I/O card to provided a positive-going pulse to the NMI input of the CPU.
P2-54 (-004 thru -008 status)	Self-test discrete (gnd = enable self-test or diagnostic mode) (for bench test/maintenance purposes only)
P2-54 (-108 status)	ADS-B SIL Designator

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION				
Combination discrete straps: P1-14, P2-41, P2-42,) (-004 thru -007 status only)	<u>P1-14</u>	<u>P2-41</u>	<u>P2-42</u>	<u>Altitude Type Selected</u>	
	open	gnd	gnd	ARINC 429 on ARINC ports A and B	
	open	open	gnd	CSDB on CSDB ports A and B	
	open	gnd	open	ARINC 575 on ARINC ports A and B	
	open	open	open	ARINC 572 (Gillham) on the Gillham parallel port	
	gnd	gnd	gnd	Port A altitude on the selected control bus (either ARINC 429 or CSDB) and port B altitude type ARINC 429 on ARINC port B.	
	gnd	open	gnd	Port A altitude on the selected control bus (either ARINC 429 or CSDB) and port B altitude type CSDB on CSDB port B.	
Combination discrete straps: P1-17, P1-28, P2-41, P2-42) (-008/-108 status only)	<u>P2-42</u>	<u>P2-41</u>	<u>P1-17</u>	<u>P1-28</u> <u>Configuration Selected</u>	
	See Note 1		Open	Open Standard TDR Configuration per -007 and Note 6	
	See Note 1		Open	Ground Standard TDR Configuration with GAMA 429 FMS (ignores label 335)	
	Ground	Open	Ground	Open Proline 4/21 Concentrated Inputs on FMS/IRS and AIS/ADS Buses. A dual AHS installation is indicated when P2-42 is ground	
	Ground	Ground	Ground	Open Proline 4/21 Concentrated Inputs on FMS/IRS and AIS/ADS Buses. A ground on P2-41 disables GPS data on the FMS/IRS and AIS/ADS Buses. GPS data is then accepted only on the GPS and A429 Altitude Port B inputs (P2-29, 30). When P2-41 is open circuit, GPS selection is restricted.	
					A dual AHS installation is indicated when P2-42 is ground
	Open	Open	Ground	Open Proline 4/21 Concentrated Inputs on FMS/IRS and AIS/ADS Buses. A tripple installation is indicated with P2-42 open circuit.	

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION
	<p>Open Ground Ground Open Proline 4/21 Concentrated Inputs on FMS/IRS and AIS/ADS Buses. A ground on P2-41 disables GPS data on the FMS/IRS and AIS/ADS Buses. GPS data is then accepted only on the GPS and A429 Altitude Port B inputs (P2-29, 30). When P2-41 is open circuit, GPS selection is restricted. A tripple installation is indicated with P2-42 open circuit.</p> <p>See Note 1 Ground Ground Reserved for future configuration assignment.</p> <p>Notes:</p> <ol style="list-style-type: none"> 1. When Config Sel 1 and 0 are '00' or '01', the standard TDR configuration is selected and Altitude Sel 1 or 0 function in the normal manner to select the altitude type provided to the altitude ports. When Config Sel 1 and 0 are '10', concentrated inputs supply data to the transponder. In this configuration, altitude data (labels 203 and 204) is supplied to the transponder via the selected control bus or the concentrated inputs. All other air data parameters are provided on the concentrated buses. The Control/Altitude Select input (P1-14) controls whether the transponder accepts altitude data from the Selected Control Bus or as directed by the Config Sel 0 and 1 discrettes. When the configuration discrete inputs indicate that all other altitude data is accepted via the concentrated buses, the altitude select discrete inputs are not needed and can be reassigned to other select functions. No configuration is currently assigned to configuration select input of '11'. This is reserved for a future configuration assignment. 2. Note that configuration discrettes P1-17 and P1-28 are logic 1 with the input grounded and logic 0 with the input open circuit. 3. Note that altitude select discrettes P2-42 and P2-41 are logic 1 with the input open circuit and logic 0 with the input grounded. 4. The -008 and -108 status TDR-94/94D adds the following capabilities to the standard configuration: <ul style="list-style-type: none"> •Low/high speed selection of the ARINC 429 Altitude Port A and B inputs. •Acceptance of label 102 via the ARINC 429 Altitude Port A and B inputs. <p><u>Standard TDR Configuration for the -007 status release</u> is defined in the above row (labelled -004 thru -007 status only) by discrete straps P1-14, P2-41, and P2-42.</p>

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION																																				
P2-43, P2-44, P2-45	<p><u>GAMA Configuration:</u>This configuration is the same as the standard TDR Configuration for the -007 status release, except that the transponder will not accept label 335, since the data contained in this label does not represent track angle rate in the GAMA configuration.</p> <p>Max airspeed programming (gnd to P2-52)</p> <table border="1"> <thead> <tr> <th><u>P2-43</u></th> <th><u>P2-44</u></th> <th><u>P2-45</u></th> <th><u>Definition</u></th> </tr> </thead> <tbody> <tr> <td>open</td> <td>open</td> <td>open</td> <td>none selected</td> </tr> <tr> <td>gnd</td> <td>open</td> <td>open</td> <td>0 to 75 knots</td> </tr> <tr> <td>open</td> <td>gnd</td> <td>open</td> <td>75 to 150 knots</td> </tr> <tr> <td>gnd</td> <td>gnd</td> <td>open</td> <td>150 to 300 knots</td> </tr> <tr> <td>open</td> <td>open</td> <td>gnd</td> <td>300 to 600 knots</td> </tr> <tr> <td>gnd</td> <td>open</td> <td>gnd</td> <td>600 to 1200 knots</td> </tr> <tr> <td>open</td> <td>gnd</td> <td>gnd</td> <td>more than 1200 knots</td> </tr> <tr> <td>gnd</td> <td>gnd</td> <td>gnd</td> <td>(not defined)</td> </tr> </tbody> </table>	<u>P2-43</u>	<u>P2-44</u>	<u>P2-45</u>	<u>Definition</u>	open	open	open	none selected	gnd	open	open	0 to 75 knots	open	gnd	open	75 to 150 knots	gnd	gnd	open	150 to 300 knots	open	open	gnd	300 to 600 knots	gnd	open	gnd	600 to 1200 knots	open	gnd	gnd	more than 1200 knots	gnd	gnd	gnd	(not defined)
<u>P2-43</u>	<u>P2-44</u>	<u>P2-45</u>	<u>Definition</u>																																		
open	open	open	none selected																																		
gnd	open	open	0 to 75 knots																																		
open	gnd	open	75 to 150 knots																																		
gnd	gnd	open	150 to 300 knots																																		
open	open	gnd	300 to 600 knots																																		
gnd	open	gnd	600 to 1200 knots																																		
open	gnd	gnd	more than 1200 knots																																		
gnd	gnd	gnd	(not defined)																																		
P2-46, P2-47	<p>SDI input (gnd to P2-52)</p> <table border="1"> <thead> <tr> <th><u>P2-46</u></th> <th><u>P2-47</u></th> <th><u>Definition</u></th> </tr> </thead> <tbody> <tr> <td>open</td> <td>open</td> <td>(not used)</td> </tr> <tr> <td>open</td> <td>gnd</td> <td>side 1</td> </tr> <tr> <td>gnd</td> <td>open</td> <td>side 2</td> </tr> <tr> <td>gnd</td> <td>gnd</td> <td>(not used)</td> </tr> </tbody> </table>	<u>P2-46</u>	<u>P2-47</u>	<u>Definition</u>	open	open	(not used)	open	gnd	side 1	gnd	open	side 2	gnd	gnd	(not used)																					
<u>P2-46</u>	<u>P2-47</u>	<u>Definition</u>																																			
open	open	(not used)																																			
open	gnd	side 1																																			
gnd	open	side 2																																			
gnd	gnd	(not used)																																			
P2-57, P2-58	<p>Control port select (gnd to P2-52)</p> <table border="1"> <thead> <tr> <th><u>P2-57</u></th> <th><u>P2-58</u></th> <th><u>Definition</u></th> </tr> </thead> <tbody> <tr> <td>gnd</td> <td>open</td> <td>Port A selected (P2-17, P2-18)</td> </tr> <tr> <td>open</td> <td>open</td> <td>Port B selected (P2-13, P2-14)</td> </tr> <tr> <td>open</td> <td>gnd</td> <td>Port C selected (P2-21, P2-22)</td> </tr> <tr> <td>gnd</td> <td>gnd</td> <td>(reserved for internal self-test)</td> </tr> </tbody> </table>	<u>P2-57</u>	<u>P2-58</u>	<u>Definition</u>	gnd	open	Port A selected (P2-17, P2-18)	open	open	Port B selected (P2-13, P2-14)	open	gnd	Port C selected (P2-21, P2-22)	gnd	gnd	(reserved for internal self-test)																					
<u>P2-57</u>	<u>P2-58</u>	<u>Definition</u>																																			
gnd	open	Port A selected (P2-17, P2-18)																																			
open	open	Port B selected (P2-13, P2-14)																																			
open	gnd	Port C selected (P2-21, P2-22)																																			
gnd	gnd	(reserved for internal self-test)																																			

Equipment Specifications Cont.
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CHARACTERISTIC	SPECIFICATION																																																																																																				
P1-22, P1-21, P1-20, P1-23	<p>The configuration of these pins tells the transponder the vehicle type in which it is installed.</p> <p>Chart 2. Type_X Select Straps (Type Set A)</p> <p>Aircraft Type Set A (Type_3 (P1-23) = open)</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Type_2</th> <th style="text-align: center;">Type_1</th> <th style="text-align: center;">Type_0</th> <th style="text-align: center;">Code</th> <th style="text-align: center;">Meaning</th> </tr> <tr> <th style="text-align: center;"><u>P1-22</u></th> <th style="text-align: center;"><u>P1-21</u></th> <th style="text-align: center;"><u>P1-20</u></th> <th></th> <th></th> </tr> </thead> <tbody> <tr><td>open</td><td>open</td><td>open</td><td style="text-align: center;">0</td><td>No aircraft type information</td></tr> <tr><td>open</td><td>open</td><td>gnd</td><td style="text-align: center;">1</td><td>Small (<12 500 lb)</td></tr> <tr><td>open</td><td>gnd</td><td>open</td><td style="text-align: center;">2</td><td>Medium (12 500 to 75 000 lb)</td></tr> <tr><td>open</td><td>gnd</td><td>gnd</td><td style="text-align: center;">3</td><td>Large (75 000 to 190 000 lb)</td></tr> <tr><td>gnd</td><td>open</td><td>open</td><td style="text-align: center;">4</td><td>Extra large (190 000 to 300 000 lb)</td></tr> <tr><td>gnd</td><td>open</td><td>gnd</td><td style="text-align: center;">5</td><td>Heavy (>300 000 lb)</td></tr> <tr><td>gnd</td><td>gnd</td><td>open</td><td style="text-align: center;">6</td><td>High performance</td></tr> <tr><td>gnd</td><td>gnd</td><td>gnd</td><td style="text-align: center;">7</td><td>Rotor craft</td></tr> </tbody> </table> <p>Chart 3. Type_X Select Straps (Type Set B)</p> <p>Aircraft Type Set B (Type_3 (P1-23) = gnd)</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Type_2</th> <th style="text-align: center;">Type_1</th> <th style="text-align: center;">Type_0</th> <th style="text-align: center;">Code</th> <th style="text-align: center;">Meaning</th> </tr> <tr> <th style="text-align: center;"><u>P1-22</u></th> <th style="text-align: center;"><u>P1-21</u></th> <th style="text-align: center;"><u>P1-20</u></th> <th></th> <th></th> </tr> </thead> <tbody> <tr><td>open</td><td>open</td><td>open</td><td style="text-align: center;">0</td><td>No aircraft type information</td></tr> <tr><td>open</td><td>open</td><td>gnd</td><td style="text-align: center;">1</td><td>Glider/sail plane</td></tr> <tr><td>open</td><td>gnd</td><td>open</td><td style="text-align: center;">2</td><td>Lighter-than-air</td></tr> <tr><td>open</td><td>gnd</td><td>gnd</td><td style="text-align: center;">3</td><td>Parachutist/skydiver</td></tr> <tr><td>gnd</td><td>open</td><td>open</td><td style="text-align: center;">4</td><td>Surface vehicle</td></tr> <tr><td>gnd</td><td>open</td><td>gnd</td><td style="text-align: center;">5</td><td>Fixed ground or tethered obstruction</td></tr> <tr><td>gnd</td><td>gnd</td><td>open</td><td style="text-align: center;">6</td><td>Unmanned aerial vehicle</td></tr> <tr><td>gnd</td><td>gnd</td><td>gnd</td><td style="text-align: center;">7</td><td>Unassigned</td></tr> </tbody> </table>	Type_2	Type_1	Type_0	Code	Meaning	<u>P1-22</u>	<u>P1-21</u>	<u>P1-20</u>			open	open	open	0	No aircraft type information	open	open	gnd	1	Small (<12 500 lb)	open	gnd	open	2	Medium (12 500 to 75 000 lb)	open	gnd	gnd	3	Large (75 000 to 190 000 lb)	gnd	open	open	4	Extra large (190 000 to 300 000 lb)	gnd	open	gnd	5	Heavy (>300 000 lb)	gnd	gnd	open	6	High performance	gnd	gnd	gnd	7	Rotor craft	Type_2	Type_1	Type_0	Code	Meaning	<u>P1-22</u>	<u>P1-21</u>	<u>P1-20</u>			open	open	open	0	No aircraft type information	open	open	gnd	1	Glider/sail plane	open	gnd	open	2	Lighter-than-air	open	gnd	gnd	3	Parachutist/skydiver	gnd	open	open	4	Surface vehicle	gnd	open	gnd	5	Fixed ground or tethered obstruction	gnd	gnd	open	6	Unmanned aerial vehicle	gnd	gnd	gnd	7	Unassigned
Type_2	Type_1	Type_0	Code	Meaning																																																																																																	
<u>P1-22</u>	<u>P1-21</u>	<u>P1-20</u>																																																																																																			
open	open	open	0	No aircraft type information																																																																																																	
open	open	gnd	1	Small (<12 500 lb)																																																																																																	
open	gnd	open	2	Medium (12 500 to 75 000 lb)																																																																																																	
open	gnd	gnd	3	Large (75 000 to 190 000 lb)																																																																																																	
gnd	open	open	4	Extra large (190 000 to 300 000 lb)																																																																																																	
gnd	open	gnd	5	Heavy (>300 000 lb)																																																																																																	
gnd	gnd	open	6	High performance																																																																																																	
gnd	gnd	gnd	7	Rotor craft																																																																																																	
Type_2	Type_1	Type_0	Code	Meaning																																																																																																	
<u>P1-22</u>	<u>P1-21</u>	<u>P1-20</u>																																																																																																			
open	open	open	0	No aircraft type information																																																																																																	
open	open	gnd	1	Glider/sail plane																																																																																																	
open	gnd	open	2	Lighter-than-air																																																																																																	
open	gnd	gnd	3	Parachutist/skydiver																																																																																																	
gnd	open	open	4	Surface vehicle																																																																																																	
gnd	open	gnd	5	Fixed ground or tethered obstruction																																																																																																	
gnd	gnd	open	6	Unmanned aerial vehicle																																																																																																	
gnd	gnd	gnd	7	Unassigned																																																																																																	

Equipment Specifications
Table 4/Table 34-50-96-99A-036-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CONDITIONS	DO-160C PARA NO	SPECIFICATION
Temp and Altitude Low Operating Temp High Operating Temp Low Storage Temp High Storage Temp Altitude	4.0 4.5.1 4.5.3 4.5.1 4.5.2 4.6.1	Categories 'A2' and 'E1'. -55 °C (-67 °F) +70 °C (+158 °F) -65 °C (-85 °F) +85 °C (+185 °F) Category 'A2'. Certified for installation in a controlled temperature location in an aircraft where pressures are no lower than an altitude equivalent of 4600 m (15 000 ft) msl. Category 'E1'. Certified for installation in a nonpressurized but noncontrolled temperature location in an aircraft that is operated at altitudes up to 21 300 m (70 000 ft) msl.
Temperature Variation	5.0	Category 'B'. Certified for installation in a controlled or noncontrolled temperature location in the aircraft.
Humidity	6.0	Category 'B'. Certified for a Severe Humidity Environment.
Shock Operational Crash Safety: Impulse Sustained	7.0 7.2 7.3 7.3.1 7.3.2	Tested at 6 g peak (11 ±2 ms duration, 6 positions) Tested at 15 g, 6 positions Tested at 12 g, 6 positions
Vibration	8.0	Categories C, L, M, and Y Category C: Certified for fuselage mounting in a fixed wing turbojet or turbofan aircraft. Category L: Certified for fuselage mounting in a fixed wing aircraft having multiple reciprocating or turbopropeller engines and a weight over 5700 kg (12 500 lb). Category M: Certified for fuselage mounting in a fixed wing aircraft having multiple, or a single reciprocating or turbopropeller engines and a weight less than 5700 kg (12 500 lb). Category Y: Certified for fuselage mounting in piston or turbojet rotary wing aircraft.
Explosion Proofness	9.0	Category E1: Certified for installation in an environment in which uncovered flammable fluids or vapors exist, either continuously or intermittently.
Waterproofness	10.0	Category X (no test required): Certified for installation in locations not subject to falling water (including condensation), rainwater, or sprayed water.

Environmental Qualifications Form Cont.
Table 5/Table 34-50-96-99A-037-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CONDITIONS	DO-160C PARA NO	SPECIFICATION
Fluids Susceptibility	11.0	Category X (no test required): Certified for installation in locations not exposed to fluid contamination from fuel, hydraulic fluids, oil, solvents, etc.
Sand and Dust	12.0	Category X: (no test required): Certified for installation in locations not subject to blowing sand and dust.
Fungus Resistance	13.0	Category F: Fungus test not performed. However, the unit is composed entirely of non-nutrient materials and is therefore classified as Category F.
Salt Spray	14.0	Category X: Certified for installation in locations not subject to a salt atmosphere.
Magnetic Effect	15.0	Category Z: Unit causes a 1° deflection of an uncompensated compass at a distance less than 0.3 m (1.0 ft).
Power Input	16.0	Category Z: Certified for use on aircraft electrical systems not applicable to any other category. For example, a dc system from a variable range generator where a small capacity or no battery is floating on the dc bus.
Voltage Spike	17.0	Category A: Certified for installation in systems where a high degree of voltage spike protection is required.
Audio Frequency Conducted Susceptibility - power inputs	18.0	Category Z: Certified for use on aircraft electrical systems not applicable to any other category. For example, a dc system from a variable range generator where a small capacity or no battery is floating on the dc bus.
Induced Signal Susceptibility	19.0	Category Z: Certified for operation in systems where interference-free operation is required.
RF Susceptibility (radiated and conducted)	20.0	Category R: Certified for operation in systems where bench testing is allowed to meet the high intensity radiated field (HIRF) associated with the normal environment intended for the unit installation.
Emission of RF Energy	21.0	Category Z: Certified for operation in systems where interference-free operation is required.
Lightning Induced Transient Susceptibility	22.0	Category Z3Z3: Certified for installation in a moderate environment, such as the more electromagnetically open areas of an aircraft composed principally of metal (e.g., cockpit).

Environmental Qualifications Form Cont.
Table 5/Table 34-50-96-99A-037-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

CONDITIONS	DO-160C PARA NO	SPECIFICATION
Lightning Direct Effects	23.0	Category X (no test required): Certified for operation in which lightning effects are insignificant or not applicable.
Icing	24.0	Category X (no test performed): Certified for installation in a location not subject to ice formation.

Environmental Qualifications Form
Table 5/Table 34-50-96-99A-037-A01


TASK 34-50-96-870-804-A01

4. Equipment Description

A. Mechanical Description

- (1) The TDR-94/94D is a half-ATR short low rack mounted unit. Electrical connections are made through two ThinLine II, 60-pin connectors. Refer to Table 4/Table 34-50-96-99A-036-A01, Equipment Specifications, for additional mount and mating connector information.
- (2) Refer to the Collins Pro Line II Comm/Nav/Pulse System Installation Manual, 523-0772719, for mounting and dimensional information.
- (3) Figure 2/GRAPHIC 34-50-96-99B-002-A01 lists the three major subassemblies in the TDR-94/94D. The main chassis occupies the center of the unit and includes the high-voltage power supply card A1 at the front, the CPU-I/O card A5, and video processor card A6 assemblies in the center-rear. One of the two main rear connectors is mounted on each of these circuit cards. As viewed from the front, A5 is on the left side, and A6 is on the right.
- (4) The two outer subassemblies are the RFPA chassis assembly on the left and the IF receiver chassis assembly on the right. Each of these also contains various circuit card assemblies. These are all illustrated in Figure 2/GRAPHIC 34-50-96-99B-002-A01. Table 6/Table 34-50-96-99A-004-A01 also gives listings showing the top level configuration as well as the configurations of each of these major subassemblies.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



Assembly Identification Diagram
Figure 2/GRAPHIC 34-50-96-99B-002-A01

34-50-96

Page 21/22
May 18/06

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TDR-94 Top Level, Configuration Matrix				
TDR-94 622-9352-	REV	MAIN CHASSIS CPN 653-2254-	RFPA CHASSIS CPN 653-2255-	IF/RCVR/DPSK/ LVPS CHASSIS CPN 653-2256-
004	V (SB 13)	012	004	005
004	W (SB 14)	016	004	005
004	AC	016	005	005
004	AT	016	005	006
005	AE (SB17)	018	005	005
005	AT	018	005	006
006	AG	020	005	005
006	AH	022	005	005
006	AT	022	005	006
007	AL	024	005	005
007	AT	024	005	006
008	AR	026	005	006
108	AR	028	005	006
207	BF	030	005	006
308	BJ	032	005	006
408	BJ	034	005	006
309	BM	036	005	006
409	BM	038	005	006
310	BW	040	005	006
410	BW	042	005	006

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TDR-94D Top Level, Configuration Matrix				
TDR-94D 622-9210-	REV	MAIN CHASSIS CPN 653-2254-	RFPA CHASSIS CPN 653-2255-	IF/RCVR/DPSK/ LVPS CHASSIS CPN 653-2256-
004	U (SB13)	011	001	005
004	V (SB 14)	015	001	005
004	AB	015	003	005
004	AK	015	006	005
004	AV	015	006	006
005	AD (SB17)	017	003	005
005	AK	017	006	005
005	AV	017	006	006
006	AG	019	003	005
006	AJ	021	003	005
006	AK	021	006	005
006	AV	021	006	006
007	AN	023	006	005
007	AV	023	006	006
008	AU	025	006	006
108	AU	027	006	006
207	BF	029	006	006
308	BJ	031	006	006
408	BJ	033	006	006
309	BM	035	006	006
409	BM	037	006	006
310	BW	039	006	006
410	BW	041	006	006

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

Main Chassis Assembly (With SB 13 and SB 14 Installed), Configuration Matrix.						
MAIN CHASSIS CPN 653-2254-	REV	HVPS CCA A1 CPN 687-0721-	VIDEO PROC CCA A6		CPU-I/O PROG ASSY A5	
			CPN 687-0726-	CPN 983-8019-		CPN 653-3674-
011 (-94D)	AA	002	005			001
015 (-94D)	-	002	004			003
015 (-94D)	B	002	005			003
015 (-94D)	F	003	005			003
015 (-94D)	J	003	006			003
017 (-94D)	-	002	005			005
017 (-94D)	C	003	005			005
017 (-94D)	F	003	006			005
019 (-94D)	-	003	005			007
019 (-94D)	C	003	006			007
021 (-94D)	-	003	005			009
021 (-94D)	B	003	005			011
021 (-94D)	E	003	006			011
023 (-94D)	-	003	005			013
023 (-94D)	B	003	006			013
025 (-94D)	-	003	006			015
025 (-94D)	A	003		001		015
027 (-94D)	-	003	006			015
027 (-94D)	A	003	006			017
029 (-94D)	-	003	006			019
029 (-94D)	A	003	006			019
031 (-94D)	-	003		001		021
033 (-94D)	-	003	006			021
035 (-94D)	-	003		001		023
037 (-94D)	-	003	006			023
039 (-94D)	-	003		001		025
041 (-94D)	-	003	007			025

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

Main Chassis Assembly (With SB 13 and SB 14 Installed), Configuration Matrix. (Cont.)						
MAIN CHASSIS CPN 653-2254-	REV	HVPS CCA A1 CPN 687-0721-	VIDEO PROC CCA A6		CPU-I/O PROG ASSY A5	
			CPN 687-0726-	CPN 983-8019-		CPN 653-3674
012 (-94)	-	002	005			002
016 (-94)	-	002	004			004
016 (-94)	B	002	005			004
016 (-94)	E	003	005			004
016 (-94)	H	003	006			004
018 (-94)	-	002	005			006
018 (-94)	B	003	005			006
018 (-94)	E	003	006			006
020 (-94)	-	003	005			008
020 (-94)	D	003	006			008
022 (-94)	-	003	005			010
022 (-94)	B	003	005			012
022 (-94)	E	003	006			012
024 (-94)	-	003	005			014
024 (-94)	B	003	006			014
026 (-94)	-	003		001		016
028 (-94)	-	003	006			016
028 (-94)	A	003	006			018
030 (-94)	-	003	006			020
030 (-94)	A	003	006			020
032 (-94)	-	003		001		022
034 (-94)	-	003	006			022
036 (-94)	-	003		001		024
038 (-94)	-	003	006			024
040 (-94)	-	003		001		026
042 (-94)	-	003	007			026

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

Programmed Assembly, Configuration Matrix			
CPU-I/O PROGRAMMED ASSEMBLY A5 CPN 653-3674-	REV	PROGRAMMED ASSEMBLY CPN 831-6270-	CPU-I/O CCA A5A1 CPN 828-2700-
001	-		002
002	-		002
003	-		002
004	-		002
005	-		002
006	-		002
007	-	007	002
008	-	007	002
009	-	008	002
010	-	008	002
011	-	009	002
012	-	009	002
013	-	010	002
014	-	010	002
015	-		003
015	B	108	003
016	-		003
016	B	108	003
017	-		003
017	A	109	003
018	-		003
018	A	109	003
019	-	011	002
019	A	011	002
020	-	011	002
020	A	011	002
021	-	110	003
022	-	110	003

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

Programmed Assembly, Configuration Matrix (Cont.)				
CPU-I/O PROGRAMMED ASSEMBLY A5 CPN 653-3674-	REV	PROGRAMMED ASSEMBLY CPN 831-6270-	CPU-I/O CCA A5A1 CPN 828-2700-	
023	-	111	003	
024	-	111	003	
025	-	112	004	
026	-	112	004	
RFPA Chassis Assembly, Configuration Matrix				
RFPA CHASSIS ASSEMBLY CPN 653-2255-	REV	SYNTHESIZER CCA A4 CPN 687-0724-	MODULATOR CCA A3 CPN 687-0723-	POWER AMPLIFIER CCA A2 CPN 687-0722-
001	V	002	004	003
001	AD	002	005	003
001	AE	003	005	003
003	W	002	004	004
003	AE	003	004	004
004	Y	002	004	003
004	AE	003	004	003
005	Y	002	004	004
005	AD	002	005	004
005	AE	003	005	004
006	AC	002	005	004
006	AE	003	005	004
005	AK	003	005	004 or 006
006	AK	003	005	004 or 006

Assembly Identification Tables Cont.
Table 6/Table 34-50-96-99A-004-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

IF Receiver Chassis Assembly, Configuration Matrix		
IF RECEIVER CHASSIS 653-2256-	REV	IF RCVR/LVPS CCA A7 CPN 687-0727-
005	P	004
006	W	005

Assembly Identification Tables
Table 6/Table 34-50-96-99A-004-A01

B. Electrical Description

- (1) Refer to Table 4/Table 34-50-96-99A-036-A01, Equipment Specifications, for detailed listing and descriptions of all input/output signals used in the TDR-94/94D Transponder.

C. Controls and Indicators

- (1) Refer to the system pilot's guide or operation section of the system installation manual for complete descriptions of indicators and displays.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TASK 34-50-96-870-805-A01

5. Installation Data

- A. Refer to the TDR-94/94D Installation Section in the Pro Line II Comm/Nav/Pulse System Installation Manual for installation information relative to the TDR-94/94D Mode S Transponder.

TASK 34-50-96-870-806-A01

6. System Theory of Operation

SUBTASK 34-50-96-870-001-A01

A. Introduction

- (1) The air traffic control radar beacon system (ATCRBS) is a surveillance system in wide use to locate and identify airplanes within an airspace. However, because of increasing air traffic, this system is expanding to include additional facilities for airborne collision avoidance. To gain a good understanding of Mode S transponder operation, it is necessary to understand the operation of the existing air traffic control (ATC) system.
- (2) If this is your first contact with the ATCRBS and related equipment, this paragraph will give you an overall description of the present ATCRBS and then expand that understanding into the new Mode S system.


SUBTASK 34-50-96-870-002-A01

B. Radar Systems

- (1) Refer to Figure 3/GRAPHIC 34-50-96-99B-070-A01. The ATCRBS consists of a primary surveillance radar (PSR) and a secondary surveillance radar (SSR). The large rotating radar antenna that can be seen at or near most air terminals is that of the PSR. This system uses conventional radar to locate all airplanes within its range in terms of range and azimuth. It transmits a burst of energy and then measures the time to an echo. The time thus measured is converted into range (refer to the note below for additional information). The direction the antenna is pointing at the time of echo detection establishes the azimuth to the reflecting target. This target information is displayed Figure 3/GRAPHIC 34-50-96-99B-070-A01 on the air traffic controller's PPI (Plan Position Indicator).

NOTE: The time is easily converted into range. The mathematical formula for distance is: $D = \text{velocity} \times \text{time}$. The propagation velocity of radio energy is usually expressed as 12.359 μs / radar mile.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
 TDR-94, PART NO 622-9352



CG0-0486-01-AC

ATCRBS, PSR and SSR System
 Figure 3/GRAPHIC 34-50-96-99B-070-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SUBTASK 34-50-96-870-003-A01

C. ATCRBS Operation

(1) ATCRBS Interrogation Modes


- (a) The SSR system interrogates the airplane transponder for airplane identity and altitude. The interrogations are in the form of two modes: mode A for airplane identity and mode C which is used to request altitude information (refer to the note below for additional information).

NOTE: In the original definition of ATC modes, two other modes were defined; mode B and mode D. These also differ only in pulse spacing with mode B pulses spaced 17 μ s, and mode D pulses spaced 25 μ s. Mode D was widely used in Great Britain but recently the aviation industry has settled on mode A for ATCRBS operation and mode C for altitude reporting. Modes B and D have been largely abandoned.

The US Military uses a system similar to ATCRBS. It is known as IFF (Identification - Friend or Foe). As this name implies, it is concerned primarily with mission security. Three modes are defined; modes 1, 2, and 3. Mode 3 is common to the civil mode A with a pulse spacing of 8 μ s. This allows air traffic control visibility of all airplanes, both civil and military.

- (b) All pulses are 0.8 μ s wide. The interrogations from the ground station are at a frequency of 1030 MHz. The transponder replies at a frequency of 1090 MHz. The received signal from the airborne transponder is decoded by the ground system and displayed on the ATC radar screen (see Figure 4/GRAPHIC 34-50-96-99B-071-A01). The replies produce either a single or double slash target display on the controller screen. The controller can also elect to display the airplane identification number (as selected by the aircrew) and altitude.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



CGO-2741-01-AC

Air Traffic Presentation on the ATC Radarscope
Figure 4/GRAPHIC 34-50-96-99B-071-A01


(2) SSR System Interrogation Description

- (a) Refer to Figure 5/GRAPHIC 34-50-96-99B-072-A01 and Figure 6/GRAPHIC 34-50-96-99B-073-A01. The SSR uses a rotating directional antenna to transmit two pulses which are identified as P1 and P3. The spacing of these pulses determines the mode. In mode A the pulses are spaced 8 μ s while in mode C the pulses are spaced 21 μ s. The SSR also uses an omnidirectional antenna to transmit a third pulse designated P2. This pulse is transmitted 2 μ s after the P1 pulse and provides a reference for side lobe suppression (SLS). The amplitude of the P2 pulse is about the same as the peak side lobe of the directional antenna. Typically, this is about 18 dB below the peak of the directional (main) beam.
- (b) Refer to Figure 5/GRAPHIC 34-50-96-99B-072-A01. Notice the two airplanes on the drawing. Airplane A is shown within the main lobe of the directional antenna. The amplitude of the P1 and P3 pulses will be substantially greater here than the P2 pulse radiated from the omnidirectional antenna. Therefore, the transponder in this airplane will interpret this interrogation as valid.
- (c) Airplane B, however, is outside the main lobe and within one of the side lobes. The P1 and P3 pulses detected here will be the result of side lobe radiation. Recall that the P2 pulse is transmitted by an omnidirectional antenna and is about

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352


equal in amplitude to that of the peak side lobe. Therefore, the P2 pulse detected by airplane B will be at least as great in amplitude as the P1/P3 pulses. The transponder in airplane B will detect this relationship in pulses and discard the interrogation as invalid, because the P2 pulse is not substantially less than the P1/P3 pulses. As a further safeguard against replies to late-arriving echoes to this invalid interrogation, the transponder suppresses replies to all interrogations for an additional 25 to 45 μ s. In addition, the receiver is desensitized for reception of P1/P3 pulses. The rationale here is that if the side lobes are detectable, then the main lobe must be much greater.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



ATCRBS, SSR Antenna Radiation Pattern
Figure 5/GRAPHIC 34-50-96-99B-072-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



ATCRBS Interrogator Pulse
Figure 6/GRAPHIC 34-50-96-99B-073-A01


(3) ATC Transponder Replies

- (a) As mentioned earlier, the most common transponder modes are mode A and mode C. Mode A provides ident (identification) information, while mode C provides altitude data. The reply formats are very similar, differing only in pulse spacing (delay).
- (b) The ATCRBS mode A transponder reply signal is shown in Figure 7/GRAPHIC 34-50-96-99B-074-A01. Notice that the signal can consist of from 2 to 16 pulses. The two framing pulses F1 and F2 are always present and spaced 20.3 μs. An identification pulse may be transmitted 4.35 μs after the last framing pulse F2. The intervening pulses, A1 through D4, make up the coded reply. The X pulse is not used. The coded reply consists of twelve pulses; four groupings of three pulses each. These groupings give four digits of octal data. The digits are formed by the sum of the pulse (bit) values; 1, 2, or 4, which can produce a digit value from 0 through 7. The A group (A1, A2, and A4) makes up the first digit, the B group makes up the second digit, etc. (On the figure, a pulse outlined with a solid line indicates that the pulse is present. A pulse outlined with dashed lines indicates the position for that pulse when it is present.) The pulse configuration on the figure indicates a reply code 1324. The first digit, 1, is formed by the presence of only the A1 pulse. The second digit, 3, is formed by the presence of B1 and B2 (1 + 2 = 3). A digit 7 is formed when all three pulses of the group are present (1 + 2 + 4 =

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

7). Therefore, a reply sequence with all pulses present constitutes a code 7777. The X pulse is not defined in ATCRBS replies. This combination of four digits, each ranging from 0 through 7, makes 4096 (212) different codes possible which explains the label 4096 code.

- (c) The ATCRBS mode C transponder reply consists of the same framing pulses F1 and F2 but spaced 21 μs . The intervening pulses, A1 through D4 (except for D1), make up the coded reply. The coding scheme is defined by ARINC 572, commonly referred to as the Gillham code, and provides encoded altitude data in the range of -1000 to 127 000 feet, to the nearest 100 feet. Recall that in mode A the individual bits assume a binary value which combines into four, three-bit groups, each group forming an octal digit. In mode C the individual pulses are combined into three groups. The A, B, and D (except for bit D1) pulses are grouped into two four-bit groups to encode the altitude to the nearest 500 feet. The C pulses provide the 100-foot deviation (above or below) from the 500-foot level. The mode C encoding scheme is described in Figure 8/GRAPHIC 34-50-96-99B-075-A01. Notice that the bit pattern does not follow a conventional binary progression. This scheme was designed to provide a sequence in which only one bit changes at a time as the altitude increases or decreases.
- (d) The upper part of the table consists of a matrix of numbers arranged into rows and columns. These numbers can be referred to as segment numbers. To find the altitude to the nearest 500 feet, represented by a given bit pattern, you must first find the segment that corresponds to that bit sequence. Multiply the segment number by 500 and subtract 1000 (or subtract 2 from the segment number and then multiply by 500).
- (e) The 100-foot altitude is not as easy. To determine the 100-foot level, it is first necessary to decide whether the 500-foot segment is odd or even. Knowing that, you add or subtract 0, 100, or 200 feet to or from the 500-foot level depending on the C bit sequence as shown in the lower portion of the table.



Transponder 4096 Reply Code, Signal Format
Figure 7/GRAPHIC 34-50-96-99B-074-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

D_2, D_4, A_1, A_2	A ₄ , B ₁ , B ₂ , B ₄															
	0000	0001	0011	0010	0110	0111	0101	0100	1100	1101	1111	1110	1010	1011	1001	1000
0000	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
0001	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0011	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
0010	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
0110	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
0111	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80
0101	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
0100	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
1100	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
1101	159	158	157	156	155	154	153	152	151	150	149	148	147	146	145	144
1111	160	161	162	163	164	165	166	167	168	169	170	171	171	171	174	175
1110	191	190	189	188	187	186	185	184	183	182	181	180	179	178	177	176
1010	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
1011	223	222	221	220	219	218	217	216	215	214	213	212	211	210	209	208
1001	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
1000	255	254	253	252	251	250	249	248	247	246	245	244	243	242	241	240
256 segments, at 500 - foot intervals, from - 1000 feet to 127,000 feet.																
<u>100 - feet bits</u>			<u>100 - feet value if 500 - foot segment is:</u>													
C_1	C_2	C_4	<u>Odd</u>				<u>Even</u>									
0	0	1	7 (+200)				8 (-200)									
0	1	1	6 (+100)				9 (-100)									
0	1	0	5 (00)				0 (00)									
1	1	0	4 (-100)				1 (+100)									
1	0	0	3 (-200)				2 (+200)									
It is important to note that this scheme has no provision for C_1 , C_2 , and C_4 , bit patterns 000, 111, or 101.																

TPH6598_01

Gillham Altitude, ARINC 572, Encoding Scheme
 Figure 8/GRAPHIC 34-50-96-99B-075-A01


SUBTASK 34-50-96-870-004-A01

D. ATCRBS with Mode S

(1) Introduction

- (a) Refer to Figure 9/GRAPHIC 34-50-96-99B-076-A01. Mode S substantially enhances the capability of the ATCRBS by adding data link and select interrogation features. The data link capability includes air to air information exchange, ground to air (data uplink or Comm A), air to ground (data downlink or Comm B), and multisite (ground station-to-ground station) message protocol. The mode S transponder can also function as part of an airborne separation assurance (ASA) system when interfaced with a Traffic alert and Collision Avoidance System (TCAS).

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
 TDR-94, PART NO 622-9352



Mode S, PSR and SSR System
 Figure 9/GRAPHIC 34-50-96-99B-076-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

(2) Mode S Interrogation Modes

(a) Eight different formats of interrogation are used in mode S. These eight can be summarized as three basic types. These are shown in Figure 10/GRAPHIC 34-50-96-99B-077-A01 and Figure 11/GRAPHIC 34-50-96-99B-078-A01. Table 7/Table 34-50-96-99A-038-A01 is a summary of all eight. The three basic types are as follows:

1 Universal ATCRBS All Call

This interrogation is in the form of P1, P3, and an 0.8 μ s P4 pulse. This interrogation is recognized by all non mode S transponders in the airspace. ATCRBS transponders reply as usual with the 4096 identification code for mode A interrogations and altitude data for mode C. Mode S transponders do not react to this interrogation.

2 Mode S Only All Call

The second type is the same as the previous universal ATCRBS All Call interrogation except that the P4 pulse is 1.6 μ s long. This interrogation is recognized only by mode S transponders. However, mode S transponders may suppress replies if in the lockout condition. Mode S transponders in lockout reply only to the select address interrogation.

3 Mode S (Select) Interrogation

The third interrogation type is directed to a specific Mode-S equipped airplane. This interrogation is in the form of P1, P2, and P6. The presence of the P2 pulse at the normal ATCRBS SLS location effectively suppresses the non mode S transponder reply.

(b) This variety of interrogation capability gives the ground controller the flexibility of addressing airplanes of immediate interest, as opposed to processing replies from every airplane in the area.

(c) All of the Mode-S uplink or interrogation message formats are summarized in Table 7/Table 34-50-96-99A-038-A01. The fields are described in the following paragraphs. These descriptions mirror Document RTCA/DO 181 with minor changes to clarify the text.

1 Address/Parity (AP)

The 24 bit AP field contains the parity overlaid on the address. The field appears at the end of all transmissions for uplink interrogations and downlink replies, except for Downlink Format (DF) number 11.

2 Acquisition Special (AQ)

The 1 bit AQ field designates uplink format (UF) numbers 0 and 16 as acquisition transmissions and repeats as received by the transponder in DF numbers 0 and 16.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- 3 Comm B Data Selector (BDS)
This 8 bit BDS field in UF number 1 contains the identity of the ground-initiated Comm B register whose contents appear in the MV field of the corresponding reply.
- 4 Designator Identification (DI)
The 3 bit DI field identifies the coding within the special designator (SD) field in UF numbers 4, 5, 20, and 21. The codes are defined as follows:
- | <u>DI</u> | <u>DEFINITION</u> |
|-----------|--|
| 0 | SD contains Interrogator Identification (IIS) information. IIS data is basically the same as the II field except that it appears as a subfield in multisite data protocol. |
| 1 | SD contains multisite information |
| 2 | SD contains extended squitter control information |
| 3-6 | (not assigned) |
| 7 | SD contains extended data readout requests |
- 5 Interrogator Identification (II)
The 4 bit II field identifies the interrogator and appears in UF number 11 (Mode S only all call).
- 6 Message, Comm A (MA)
The 56 bit MA field contains messages directed to the airplane during Comm A interrogations (UF numbers 20 and 21).
- 7 Message, Comm C (MC)
The 80 bit MC field contains one of a sequence of segments transmitted to the transponder in the extended length message (ELM) (112 bits) using UF number 24.
- 8 Message, Comm U (MU)
The 56 bit MU field contains information used in air to air message exchanges and is part of the long special surveillance interrogation using UF number 16. This message field does not use the Comm A protocol.
- 9 Number of C Segment (NC)
The 4 bit NC field provides the number of a segment transmitted in an uplink ELM message and is part of the Comm C interrogation using UF number 24.
- 10 Protocol (PC)
The 3 bit PC field contains operating commands to the transponder and is part of surveillance and Comm-A interrogations using UF numbers 4, 5, 20, and 21. The codes used in this field are as follows:

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

<u>PC</u>	<u>DESCRIPTION</u>
0	No changes in transponder state
1	Nonselective all call lockout
2 - 3	(not assigned)
4	Close out B
5	Close out C
6	Close out D
7	(not assigned)

11 Probability of Reply (PR)

The 4 bit PR field contains commands to the transponder to specify the reply probability to the mode S only all call interrogation, UF number 11. A command to disregard any lockout state can also be given. The assigned codes are as follows:

<u>PR</u>	<u>DESCRIPTION</u>
0	Reply with probability = 1
1	Reply with probability = 1/2
2	Reply with probability = 1/4
3	Reply with probability = 1/8
4	Reply with probability = 1/16
5 -7	Do not reply
8	Disregard lockout, reply with probability = 1
9	Disregard lockout, reply with probability = 1/2
10	Disregard lockout, reply with probability = 1/4
11	Disregard lockout, reply with probability = 1/8
12	Disregard lockout, reply with probability = 1/16
13 -15	Do not reply

After receiving a mode S only all call containing a PR code other than 0 or 8, the transponder will execute a random process and make a reply decision, for this interrogation, in accordance with the command probability. Random occurrence of replies enables the interrogator to acquire closely-spaced airplanes whose replies would otherwise synchronously garble each other.

12 Reply Control (RC)

The 2 bit RC field designates the transmitted segment as initial (0), intermediate (1), or final (3). An RC field (3) is used to request a Comm D downlink action by the transponder. RC is part of the Comm C interrogation, UF number 24.

13 Reply Length (RL)

The 1 bit RL field commands a reply in DF number 0 if the bit is logic 0, and a reply in DF number 16 if the bit is logic 1.

14 Reply Request (RR)

The 5 bit RR field contains the length and content of the reply

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

requested by the interrogators. The RR field is part of the surveillance and Comm A interrogations using UF numbers 4, 5, 20, and 21. The codes used in the RR field are described as follows:

<u>RR</u>	<u>REPLY LENGTH</u>	<u>MB CONTENT</u>
0 - 15	short	-----
16	long	Air-initiated Comm B
17	long	Extended capability
18	long	Flight ID
19	long	TCAS resolution advisory report
20 - 31	long	Not assigned

If the first bit of the RR code is logic 1, then the decimal equivalent of the last four bits designates the requested source.

15 Special Designator (SD)

The 16 bit SD field contains control codes affecting the transponder protocol and is part of surveillance and Comm A interrogations using UF numbers 4, 5, 20, and 21. The content is specified by the DI field. A 4-bit IIS subfield is within all SD fields of UF numbers 4, 5, 20, and 21 if the DI code is 0, 1, or 7. The IIS is used to specify the interrogator identifier.

16 Uplink Format (UF)

UF is a general term referring to the first field in all uplink formats and is the transmission descriptor in all interrogations. UF refers to all messages described in Table 7/Table 34-50-96-99A-038-A01.

FORMAT NUMBER	UPLINK BIT FORMAT								
	HEX/DEC	UF	SHORT MESSAGE STRUCTURE						MESSAGE TYPE
0 / 0	0 0000	-3-	RL: 1	-4-	AQ: 1	BDS: 8	-10-	AP: 24	SHORT SPECIAL (Air-Air) SURVEILLANCE
1 / 1	0 0001	Length, content, and structure undefined						AP: 24	NOT PRESENTLY DEFINED OR NOT USED
2 / 2	0 0010							AP: 24	
3 / 3	0 0011							AP: 24	
4 / 4	0 0100	PC: 3	RR: 5	DI: 3	SD: 16		AP: 24	SURVEILLANCE, ALTITUDE REQUEST	

Mode S, Interrogation Code Summary Cont.
Table 7/Table 34-50-96-99A-038-A01


ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FORMAT NUMBER	UPLINK BIT FORMAT								
5 / 5	0 0101	PC: 3	RR: 5	DI: 3	SD: 16			AP: 24	SURVEILLANCE, IDENTITY REQUEST
6 / 6	0 0110	Length, content, and structure undefined						AP: 24	NOT PRESENTLY DEFINED OR NOT USED
7 / 7	0 0111							AP: 24	
8 / 8	0 1000							AP: 24	
9 / 9	0 1001							AP: 24	
A / 10	0 1010							AP: 24	
B / 11	0 1011	PR: 4	II: 4	-19 (ALL ONES)-			AP: 24	MODE S ONLY, ALL-CALL	
C / 12	0 1100	Length, content, and structure undefined						AP: 24	NOT PRESENTLY DEFINED OR NOT USED
D / 13	0 1101							AP: 24	
E / 14	0 1110							AP: 24	
F / 15	0 1111							AP: 24	
LEGEND: XX: M designates a field containing M bits, -N- denotes free space with N available bits.									
<u>FIELD DESIGNATORS:</u>									
AP = Address/Parity			II = Interrogator Identification			RR = Reply Request			
AQ = Acquisition Special			PC = Protocol			SD = Special Designator			
BDS = Comm-B Data Selector			PR = Probability of Reply			UF = Uplink Format			
DI = Designator Identification			RL = Reply Length						
HEX/ DEC	UF	LONG MESSAGE STRUCTURE							MESSAGE TYPE
01/ 16	1 0000	-3-	RL: 1	-4-	AQ: 1	-18-	MU-56	AP: 24	LONG SPECIAL SURVEILLANCE
11/ 17	1 0001	Length, content, and structure undefined						AP: 24	NOT DEFINED OR NOT USED
12/ 18	1 0010							AP: 24	
13/ 19	1 0011							AP: 24	
14/ 20	1 0100	PC: 3	RR: 5	DI: 3	SD: 16	MA: 56		AP: 24	COMM-A, ALTITUDE REQUEST
15/ 21	1 0101	PC: 3	RR: 5	DI: 3	SD: 16	MA: 56		AP: 24	COMM-A, IDENTITY REQUEST

Mode S, Interrogation Code Summary Cont.
Table 7/Table 34-50-96-99A-038-A01


ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

ATCRBS/MODE S, ALL-CALL INTERROGATION PULSE SPACING



P1, P3, AND P4 ARE RADIATED BY THE ROTATING BEAM ANTENNA. P2 IS RADIATED BY THE OMNIDIRECTIONAL ANTENNA. THE AMPLITUDE OF P2 IS APPROXIMATELY EQUAL TO THE PEAK AMPLITUDE OF THE MAXIMUM ROTATING SIDE LOBE.

MODE S DISCRETE ADDRESS DPSK INTERROGATION SIGNAL




P1, P2, AND P6 ARE RADIATED BY THE ROTATING BEAM ANTENNA. P5 IS RADIATED BY THE OMNIDIRECTIONAL ANTENNA. THE AMPLITUDE OF P5 IS 3 DB GREATER THAN THE PEAK AMPLITUDE OF THE MAXIMUM ROTATING SIDE LOBE.

CG0-0450-01-AC

Mode S, All-Call, and Discrete Addressing, Interrogation Format
Figure 10/GRAPHIC 34-50-96-99B-077-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



Mode S Discrete Addressing, Pulse P6 Definition
Figure 11/GRAPHIC 34-50-96-99B-078-A01

(3) Mode S SSR Radiation Pattern and SLS

- (a) Refer to Figure 12/GRAPHIC 34-50-96-99B-079-A01. In mode S, the omnidirectional antenna transmits pulse P5 as the SLS reference pulse. The P5 pulse occurs within the P6 pulse and is timed 0.4 μ s before the first spr. Thus, if the amplitude of P5 is sufficient to blank the first spr of P6, the interrogation is most likely from a side lobe and not from the main lobe. In this case the spr is hidden from the transponder and the reply is suppressed.
- (b) The transmission of mode S interrogation uses a technique known as binary differential phase shift keying (DPSK). This technique is illustrated in Figure 11/GRAPHIC 34-50-96-99B-078-A01. For greater detail, refer to the information below.
- (c) The SSR mode S interrogation pulse spacing and identification is different from earlier ATCRBS. Notice that the rotating beam transmits two different pulse combinations. For all call interrogations, the transmitted pulses are P1, P3, and P4. In these interrogations the SLS reference pulse P2 is transmitted by the omnidirectional antenna as in conventional ATCRBS. The P1-to-P3 pulse spacing is either 8 μ s (for mode A) or 21 μ s (for mode C), also as in ATCRBS. The P4 pulse follows the P3 pulse by 2 μ s and can be either 0.8 μ s (the same as P1 and P3) or 1.6

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352


μ s. The pulse width of P4 determines the all-call objective. A 0.8 μ s pulse is only for non-mode S transponders, while the 1.6 μ s pulse is only for mode S transponders.

- (d) The mode S discrete addressing interrogation takes yet another form. For this interrogation the rotating beam antenna transmits pulses P1, P2, and P6. P1 and P2 are 0.8 μ s pulses spaced 2 μ s between leading edges. P6 is a single pulse that is either 16.00 or 30.00 μ s long. A data technique known as DPSK decodes the information transmitted in the P6 pulse. This technique involves the detection of the phase relationship of the signal at certain intervals. These intervals are referred to as chips. Therefore, timing is the critical factor in this decoding process. Each chip is defined as an unmodulated interval of 0.25 μ s and may be in phase or out of phase with the preceding chip. If it is out of phase, it is recognized as representing a bit value of 1. A chip that is in phase with the preceding chip represents a bit value of 0.
- (e) As shown in Figure 10/GRAPHIC 34-50-96-99B-077-A01, P6 begins 1.5 μ s after the start of pulse P2. At 1.25 μ s after the start of P6, the first phase reversal (pr) occurs. This first pr is identified as the sync phase reversal (spr). This spr must be detected in order to enable a reply response. The final chip is followed by a 0.5 μ s guard interval. This prevents the trailing edge of P6 from interfering with the demodulation process.
- (f) The ground mode S interrogator system uses a monopulse processing scheme to determine the azimuth bearing to the airplane. This scheme requires only a single reply from an airborne transponder, as opposed to the two replies necessary in the earlier ATCRBS system to establish the azimuth to the airplane. In this scheme, the monopulse system generates two separate patterns; a single (sum) pattern and a dual lobe (difference) pattern. The ratio of the energy received by the sum pattern to the energy received by the difference pattern determines the bearing of the airplane from the antenna beam centerline. The address (derived from the reply) and location (azimuth and range) of the mode S airplane is entered into a roll-call file. This file can be visualized as a list of the mode S-equipped airplanes within their assigned airspace. On a later scan, the mode S airplane is discretely addressed. This discrete address contains a command field that is used to desensitize the mode S transponder to further mode S all-call interrogations. This desensitization is called Mode S Lockout. The ATCRBS-only transponders are not affected by this lockout technique and mode S transponders continue to reply to ATCRBS interrogations.
- (g) When a mode S-equipped airplane moves from one assigned airspace into another, the first ground interrogator can communicate with the next interrogator and pass airplane information to that second interrogator. This communication link can be via ground lines or radio link. If this method is used, the mode S lockout is not disabled on the affected airplane and the second interrogator will schedule discrete roll-call interrogations for that airplane as needed. This technique makes it possible to increase the airplane handling capacity of the ground interrogator.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- (h) In regions where mode S interrogators are not connected via ground or radio link, the protocol for the transponder allows it to be in mode S lockout only for those interrogators that have the airplane on the roll-call list. This enables a second ground interrogator to acquire an airplane into its assigned airspace using the all-call technique as previously described.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
 TDR-94, PART NO 622-9352




CG0-2743-01-AC

Mode S, SSR Antenna Radiation Pattern
 Figure 12/GRAPHIC 34-50-96-99B-079-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

(4) Mode S Transponder Replies

- (a) Typically, the ground-based interrogator tracks an airplane throughout its assigned airspace. The mode S transponder equipped airplane responds to mode S interrogations with the ATCRBS 4096 code and the mode S reply format. During each scan, the SSR interrogations are in both mode A and mode C. The mode S transponder reply uses a technique known as pulse position modulation (PPM). This is illustrated in Figure 13/GRAPHIC 34-50-96-99B-080-A01. A pulse transmitted in the first half of the interval represents a logic 1, while a pulse transmitted in the second half represents a logic 0. In addition to the message data contained within each reply transmission, the mode S interrogation also contains a 24-bit discrete address. This uniquely identifies the reply and provides for a large number of airplanes, each with its own distinct address. The mode S reply format is described in the following paragraphs.



Mode S, Transponder Reply Code Pulse Format
Figure 13/GRAPHIC 34-50-96-99B-080-A01

(5) Mode S Reply Description

- (a) The reply pulse pattern is shown in Figure 13/GRAPHIC 34-50-96-99B-080-A01. The reply data block is formed by PPM encoding of the reply data. The first pulse occurs 128 μs after the start of the P4 interrogation pulse. The mode S transponder reply to an ATCRBS interrogation is identical to the reply transmitted by a non mode S transponder (see Figure 7/GRAPHIC 34-50-96-99B-074-A01). However, the reply to a mode S interrogation can assume several different formats as summarized in Figure 14/GRAPHIC 34-50-96-99B-081-A01. The fields are described in the following paragraphs.

- 1 **Announced Address (AA)**
The 24-bit AA field contains the airplane address in the clear (no special coding) and is used in DF number 11.
- 2 **Altitude Code (AC) Field**
The 13 bit AC field contains the altitude code and is used in downlink format

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

(DF) numbers 0, 4, 16, and 20. The field is similar to that shown in Figure 7/GRAPHIC 34-50-96-99B-074-A01 except that the X bit is defined as the M bit. In mode S the M bit may be used in the future for encoding the altitude in metric units. Zero is transmitted in each of the 13 bits if altitude information is not available.

3 Address/Parity (AP) Field

The 24 bit AP field contains the parity overlaid on the address and appears at the end of all transmissions on both uplink interrogations and downlink replies (except for DF number 11).

4 Capability, Transponder (CA) Field

The 3 bit CA field reports transponder capability and is used in DF number 11, i.e. the Mode S All Call reply. The CA codes are defined as follows:

<u>CA</u>	<u>DESCRIPTION</u>
0	No communications capability (surveillance only)
1 - 3	Not used
4	Comm A and Comm B capability, ability to set code 7 on the ground
5	Comm A and Comm B capability, ability to set code 7 airbourne
6	Comm A, Comm B, ability to set code 7 on the ground or airbourne
7	Indicates DR is not = 0; or FS = 2, 3, 4, or 5, either airborne or on ground

CA codes 1 - 3 were used by earlier mode S transponders that did not have the ability to set code 7.

5 Crosslink Capability (CC) Field

This 1-bit CC field indicates the ability of the transponder to support the crosslink capability, i.e. decode the contents of the BDS field in UF number 0 interrogation and respond with the contents of the specified ground-initiated Comm B register in the MV field of the corresponding DF number 16 reply. Codes are: logic 0 if aircraft supports crosslink capability; logic 1 if aircraft cannot support crosslink capability.

6 Downlink Format (DF)

Field DF is a general term referring to the first field in all downlink format and is the transmission descriptor in all replies. DF refers to all messages described in Figure 14/GRAPHIC 34-50-96-99B-081-A01.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- 7 Downlink Request (DR) Field
The 5 bit DR field is used to request extraction of downlink messages from the transponder by the interrogator. The codes are defined as follows:

<u>DR</u>	<u>DESCRIPTION</u>
0	No downlink request
1	Request to send Comm B message
2	TCAS information available
3	TCAS information available and request to send Comm B message
4	Comm B broadcast #1 available
5	Comm B broadcast #2 available
6	TCAS information and Comm B broadcast #1 available
7	TCAS information and Comm B broadcast #2 available
8 - 15	(Not assigned)
16 - 31	Comm D, not implemented in TDR-94/94D Class 3A Mode S Transponders

- 8 Flight Status (FS) Field
The 3 bit FS field reports the flight status of the airplane. The codes are defined as follows:

<u>FS</u>	<u>ALERT</u>	<u>SPI</u>	<u>AIRBORNE/ON THE GROUND</u>
0	no	no	airborne
1	no	no	on the ground
2	yes	no	airborne
3	yes	no	on the ground
4	yes	yes	either
5	no	yes	either
6 - 7	(Not assigned)		

- 9 Identification (ID) Field
The 13 bit ID field contains the 4096 identification code as selected by the operator.

- 10 ELM Control (KE) Field
The 1 bit KE field defines the content of the ND and MD fields in Comm D replies, i.e. DF number 24. This function is not implemented in the TDR-94/94D Class 3A Mode S Transponders.

- 11 Message Comm B (MB) Field
The 56 bit MB field contains messages transmitted to the interrogator. In those formats that use the ground initiated Comm B protocol, the MB field contains an 8 bit subfield (BDS) defining the contents of the Comm B message. BDS is expressed in two 4-bit groups identified as BDS1 and BDS2.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- 12 Extended Squitter Message (ME) Field
The 56 bit ME field is used to transmit extended squitter Automatic Dependent Surveillance (ADS) and Aircraft Identification (AI) in DF number 17 messages.
- 13 Message Comm V (MV) Field
The 56 bit MV field contains information used in the air to air exchanges between mode S transponders and is part of the long special surveillance reply using DF number 16. Note that this message field does not follow the Comm B protocol.
- 14 Number of D Segment (ND) Field
The 4 bit ND field provides the number of the segment transmitted in a downlink ELM and is part of the Comm D reply. It is not implemented in the TDR-94/94D Class 3A Mode S Transponders.
- 15 Parity/Interrogator Identity (PI) Field
The 24 bit PI field contains the parity overlaid on the interrogator identity code.
- 16 Reply Information (RI) Field
The 4 bit RI field (used in special surveillance replies DF numbers 0 and 16) reports the airspeed capability and type of reply to an interrogating airplane. Codes are defined as follows:

<u>RI</u>	<u>DESCRIPTION</u>
0	No on-board TCAS
1	(Not assigned)
2	On-board TCAS with resolution capability inhibited
3	On-board TCAS with vertical-only resolution capability (TCAS II)
4	On-board TCAS with vertical and horizontal resolution capability (TCAS III)
5 - 7	(Not assigned)
8 - 15	Indicates that downlink is an acquisition reply, further defined as follows:
8	No maximum airspeed data available
9	Airspeed up to 75 knots
10	Airspeed is greater than 75, up to and including 150 knots
11	Airspeed is greater than 150, up to and including 300 knots
12	Airspeed is greater than 300, up to and including 600 knots
13	Airspeed is greater than 600, up to and including 1200 knots
14	Airspeed is greater than 1200 knots
15	(Not assigned)

Bit 14 of this field is the AQ bit of the interrogation.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

17 Sensitivity Level (SL) Field

This 3-bit UM field reports the sensitivity level at which the TCAS unit is currently operating. This field appears in special surveillance reply formats DF numbers 0 and 16 (for TCAS compatible transponders only). The codes are defined as follows:

- 0 = No TCAS sensitivity level reported
- 1 = TCAS is operating at sensitivity level 1
- 2 = TCAS is operating at sensitivity level 2
- 3 = TCAS is operating at sensitivity level 3
- 4 = TCAS is operating at sensitivity level 4
- 5 = TCAS is operating at sensitivity level 5
- 6 = TCAS is operating at sensitivity level 6
- 7 = TCAS is operating at sensitivity level 7

Note the SL field has no meaning for aircraft that set RI = 0, 1, or 2 (no on board capability to generate resolution advisories).

18 Utility Message (UM) Field

The 6 bit UM field contains transponder status readouts and are used in DF numbers 4, 5, 20, and 21.

19 Vertical Status (VS) Field

The 1 bit VS field indicates the airplane is airborne (VS = 0), or the airplane is on the ground (VS = 1). This field is used in DF numbers 0 and 16.

20 Free and Unassigned Coding Space Fields

Free coding space contains all zeros as transmitted by the interrogators and transponders. Unassigned coding space existing within fields is reserved for possible future use.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FORMAT NUMBER	DOWNLINK BIT FORMAT											
HEX/DEC	DF	SHORT MESSAGE STRUCTURE								MESSAGE TYPE		
0 / 0	0 0000	VS: 1	CC: 1	1	SL: 3	2	RI: 4	2	AC: 13		AP: 24	SHORT SPECIAL SURVEILLANCE
1 / 1	0 0001	Length, content, and structure undefined								P: 24	NOT PRESENTLY DEFINED OR NOT USED	
2 / 2	0 0010									P: 24		
3 / 3	0 0011									P: 24		
4 / 4	0 0100	FS: 3		DR: 5		UM: 6		AC: 13		AP: 24	SURVEILLANCE, ALTITUDE REPLY	
5 / 5	0 0101	FS: 3		DR: 5		UM: 6		ID: 13		AP: 24	SURVEILLANCE, IDENTITY REPLY	
6 / 6	0 0110	Length, content, and structure undefined								P: 24	NOT PRESENTLY DEFINED OR NOT USED	
7 / 7	0 0111									P: 24		
8 / 8	0 1000									P: 24		
9 / 9	0 1001									P: 24		
A / 10	0 1010									P: 24		
B / 11	0 1011	CA: 3		AA: 24						AP: 24		ALL CALL REPLY
C / 12	0 1100	Length, content, and structure undefined								P: 24	NOT PRESENTLY DEFINED OR NOT USED	
D / 13	0 1101									P: 24		
E / 14	0 1110									P: 24		
F / 15	0 1111									P: 24		
LEGEND: XX: M designates a field containing M bits, N denotes free space with N available bits. FIELD DESIGNATORS: AA = Address Announced CC = Crosslink Capability FS = Flight Status SL = Sensitivity Level AC = Altitude Code DF = Downlink Format ID = Interrogator Ident UM = Utility Message AP = Address/Parity DR = Downlink Request RI = Reply Info; Air-to-Air VS = Vertical Status CA = (XPDR) Capability												

TPH6708_01

Mode S, Reply Code Summary
Figure 14 (Sheet 1 of 2)/GRAPHIC 34-50-96-99B-081-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FORMAT NUMBER	DOWNLINK BIT FORMAT										
HEX/DEC	DF	LONG MESSAGE STRUCTURE									MESSAGE TYPE
10 / 16	1 0000	VS: 1	2	SL: 3	2	RI: 4	2	AC: 13	MV: 56	AP: 24	LONG SPECIAL SURVEILLANCE
11 / 17	1 0001	CA: 3			AA: 24				ME: 56	PI: 24	EXTENDED SQUITTER
12 / 18	1 0010	Length, content, and structure undefined								P: 24	NOT PRESENTLY DEFINED OR NOT USED
13 / 19	1 0011									P: 24	
14 / 20	1 0100	FS: 3	DR: 5	UM: 6	AC: 13			MB: 56	AP: 24	COMM-A ALTITUDE REQUEST	
15 / 21	1 0101	FS: 3	DR: 5	UM: 6	ID: 13			MB: 56	AP: 24	COMM-A IDENTITY REQUEST	
16 / 22	1 0110	Length, content, and structure undefined								AP: 24	NOT PRESENTLY DEFINED OR NOT USED
17 / 23	1 0111									AP: 24	
18 / 24 (see note)	11	1	KE: 1	ND: 4	MC: 80				AP: 24	COMM-D, EXTENDED LENGTH MESSAGE	

LEGEND:
XX: M designates a field containing M bits, N denotes free space with N available bits.

NOTE:
Format number 18 / 24 is defined as the format beginning with "11" in the first two bit positions while the following three bits vary with the interrogation content; i.e., two bits are the RC field, and the remaining bit is in the NC field.

FIELD DESIGNATORS:

AA = Address Announced	DR = Downlink Request	ME = Message, Comm-E	SL = Sensitivity Level
AC = Altitude Code	FS = Flight Status	MV = Message, Comm-V	UM = Utility Message
AP = Address/Parity	ID = Interrogator Ident	ND = Number of D Segments	VS = Vertical Status
CA = (XPDR) Capability	KE = (not used)	PI = Parity/Interrogator	
DF = Downlink Format	MB = Message, Comm-B	RI = Reply Info; Air-to-Air	

TPH6708_02

Mode S, Reply Code Summary
Figure 14 (Sheet 2 of 2)/GRAPHIC 34-50-96-99B-081-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352


SUBTASK 34-50-96-870-005-A01

E. Typical TDR 94/94D ATC/Mode S Transponder Installations

(1) Introduction

- (a) This paragraph gives you an overview of the TDR 94/94D operating environment. For installation detail, refer to the TDR 94/94D ATC/Mode S Transponder, Installation Manual which is contained in the Collins Pro Line II Comm/Nav/Pulse System Installation Manual, CPN 523-0772719.
- (b) The TDR 94/94D ATC/Mode S Transponder offers a wide range of installation options. First you should recognize the difference between the TDR 94 and the TDR 94D; the TDR 94 is for single antenna installations, while the TDR 94D can operate with single or dual antenna installations. You are likely to find the TDR 94D in most TCAS installations because dual antennas are required in TCAS.
- (c) Both transponders can accept control data in CSDB or ARINC 429 format; this is set at installation by means of special external straps and is determined by the type of control being used.
- (d) The following paragraphs and accompanying diagrams describe various installation configurations. The first diagram, Figure 15/GRAPHIC 34-50-96-99B-082-A01, shows the various strapping options that must be considered for all installations. These strapping options are applicable to all installations even though they are not shown on the other block diagrams.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352




TDR-94/94D ATC Mode S Transponder Strapping Options
Figure 15/GRAPHIC 34-50-96-99B-082-A01

(2) TDR-94 with CSDB Code Selection

- (a) Figure 16/GRAPHIC 34-50-96-99B-083-A01 shows a TDR 94 installation with a CTL 92/92A CSDB transponder control unit and an altitude encoder. This type of encoder typically supplies altitude data in Gillham code (ARINC 572) format. The encoder data can be supplied to the CTL 92/92A or directly to the TDR 94. However, because the encoder is likely to be located in the radio rack, with or near the transponder, most installations will have the encoder connected directly to the transponder to keep the wire run short.
- (b) Figure 17/GRAPHIC 34-50-96-99B-084-A01 shows an installation using a Central Air Data Computer (CADC) for altitude data which is similar to Figure 16/GRAPHIC 34-50-96-99B-083-A01. In each of these cases, external strapping is required according to the type of altitude data being used.
- (c) An alternate installation configuration is possible using ARINC 429 code selection. In this case, an ARINC 429 source, such as an FMS, would be shown in place of the CTL 92/92A with appropriate strapping as shown of Figure 15/GRAPHIC 34-50-96-99B-082-A01.


ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

- (d) In TCAS installations using Gillham code encoders, two independent encoders are required for monitoring redundancy and integrity. In this case, one encoder is connected to the transponder, while the other supplies data to the CTL-92/92A. In the control the altitude data is converted to CSDB data which is supplied to the CTL-92T. The CSDB data is converted here to ARINC 429 and supplied to the transponder. In the transponder the altitude from the directly-connected encoder is compared to the ARINC 429 data from the other encoder. If the two altitude sources do not agree within 500 feet, a diagnostic code is generated.



TDR-94 ATC/Mode S Transponder, with CTL-92/92A Transponder Control Unit, Typical Installation Diagram
Figure 16/GRAPHIC 34-50-96-99B-083-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352




TDR-94 ATC/Mode S Transponder, With CTL-92/92A Transponder Control and CADC
Altitude Source, Typical Installation Diagram
Figure 17/GRAPHIC 34-50-96-99B-084-A01

(3) TDR-94D with CSDB Code Selection and Dual Antenna Operation

- (a) Figure 18/GRAPHIC 34-50-96-99B-085-A01 shows a TDR 94D in a TCAS installation with a CSDB control and dual antennas. If the transponder is operated with only a single antenna, a special strap is required. The diagram also shows a CADC for altitude data. This can be an encoder as shown in Figure 16/GRAPHIC 34-50-96-99B-083-A01. Either way, appropriate strapping is required. The CTL-92T, a requirement for TCAS control, is connected between the TDR-94D and the CTL-92/92A. In this installation, transponder control data is entered on the CTL-92/92A, and the TCAS control data is added to the data word in the CTL-92T.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352




TDR-94D ATC/Mode S Transponder, Datalink and TCAS Installation, With CSDB Control and CADC Altitude Data Source, Typical Installation Diagram
 Figure 18/GRAPHIC 34-50-96-99B-085-A01

(4) TDR-94D/TCAS with ARINC 429 Code Selection and Dual Antenna

- (a) Figure 19/GRAPHIC 34-50-96-99B-086-A01 shows a TDR 94D in a relatively complex installation. This can be seen as a typical TCAS and data link installation using an ARINC 429 source for code selection.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352



TDR-94D ATC/Mode S Transponder, with ARINC 429 Tuning Source, Typical Installation Diagram
Figure 19/GRAPHIC 34-50-96-99B-086-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TASK 34-50-96-870-807-A01

7. Integrated Circuit Descriptions

- A. The TDR-94/94D uses numerous types of integrated circuits. Always refer to the Illustrated Parts List (IPL) when replacement parts are necessary. Table 8/Table 34-50-96-99A-039-A01 shows the different types of integrated circuits that the TDR-94/94D uses. Refer to the manufacturer's data manuals (or WEB sites) if special data is necessary.

IC TYPE	DESCRIPTION
Refer to Figure 20/GRAPHIC 34-50-96-99B-087-A01	Basic Logic Gate Descriptions
Refer to Figure 21/GRAPHIC 34-50-96-99B-088-A01	Basic Operational Amplifier Descriptions
02	+5V Precision Voltage Reference/Temperature Transducer
117	Adjustable 3-Terminal Positive Voltage Regulator (1.2 to 37V)
1596	Balance Modulator – Demodulator Microcircuit
1825	High Speed Pulse Width Modulator Regulator
10135	2X J-K Master/Slave Flip Flop
12093	Low Power Prescaler
2222A	4X 2222A Transistor Package
22V10C	Programmed PAL
26LS32	4X Differential Line Receiver
28HC256	32k x 8-Bit EEPROM
29F010	128k x 8-Bit Flash Memory
3127	High Frequency Low Current Transmitter Array
317L	Adjustable Positive Voltage Regulator
31015	ARINC 429 Receiver/Transmitter ASIC
580	Voltage Reference
7C109	128k x 8-Bit Static RAM
7C291L	Programmed 2k x 8-Bit UV EPROM
7C291L	Programmed 2k x 8-Bit UV EPROM
7130	1k x 8-Bit Dual Port Static RAM

Integrated Circuit Descriptions Cont.
Table 8/Table 34-50-96-99A-039-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

IC TYPE	DESCRIPTION
74AHC1G04	Inverting Buffer
74HC259	8-Bit Addressable Latch/1 of 8 Decoder
74HC373	Octal 3-State Inverting D-Type Transparent Latch
74HC74	Dual D-Type Flip Flop with Set and Reset
74HCT244	Octal 3- State Buffer
74AC245	Octal Bus Transceiver, 3-State Non-Inverting
74AC374	Octal D-Type Flip Flop with 3-State Outputs
74HCT74	Dual D-Type Flip Flop
7800-10B	Pulse Decoder Gate Array
80C196KC	16-Bit Microcontroller
831-7172-001	Programmed FPGA
835-1681-030	Memory Decode and Mux Logic Microcircuit
9638	Dual Differential Line Driver
9665-052	Message Processor Gate Array
AD580TH	Low Drift Voltage Reference
AS214-92	0.1-3 GHz SPDT Switch
ATtiny 13	Programmed 8-Bit Microcontroller
ERA-2SM	RF/MMIC Surface Mount Amplifier
ERA-5SM	RF/MMIC Surface Mount Amplifier
JMS-5LH	Double Balance RF Mixer (Surface Mount Package)
LM235	Temperature Sensor
LM317M	Adjustable Positive Voltage Regulator
LMX2326TM	Frequency Synthesis Phase-Lock Loop Microcircuit
M27C256B-70C6	Programmed 32k x 8-Bit UV EPROM
MAX2606EUT-T	Voltage-Controlled Oscillator Microcircuit
MAX693A	Microprocessor Supervisory Circuit
MB1501	Serial Input Phase-Lock Loop Frequency Synthesizer
MC149680	Modulator/Demodulator Microcircuit
MC74HC4316AD	Quad Switch Microcircuit
MMPQ2907	Quad General Purpose PNP Transistor Package

Integrated Circuit Descriptions Cont.
Table 8/Table 34-50-96-99A-039-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

IC TYPE	DESCRIPTION
MSA-0686	RF/MMIC Amplifier Microcircuit
MSA-386	RF/MMIC Amplifier Microcircuit
RF MIXER	Double Balance RF Mixer (Surface Mount Package)
RMS-5	Double Balance RF Mixer (Surface Mount Package)
SGA-4586	Cascadeable 50-Ohm Amplifier
SL1451	Wide-Band Phase Lock Loop FM Detector
SN74BNT2244ADB	Octal Buffer and Line/MOS Drivers with 3-State Outputs
UPC1663GV	Ultra Wide-Band Amplifier
UPC2712TB	MMIC Wide-Band Amplifier

Integrated Circuit Descriptions
Table 8/Table 34-50-96-99A-039-A01

ROCKWELL COLLINS COMPONENT MAINTENANCE MANUAL with IPL TDR-94, PART NO 622-9352

DESCRIPTION

BASIC LOGIC GATES ARE DESCRIBED WITH ITS OWN CORRESPONDING FUNCTION TABLE.

TYPICAL FLIP-FLOP DEVICES

TTL 5474 D TYPE

FUNCTIONAL TABLE TTL 5474

CLOCK	INPUTS			OUTPUTS	
	DATA	CLEAR	PRESET	Q	\bar{Q}
⎯	1	1	1	1	0
⎯	0	1	1	0	1
⎯	X	1	1	Q_0	\bar{Q}_0
X	X	1	0	1	0
X	X	0	1	0	1
X	X	0	0	1*	1*

* NONSTABLE WILL NOT STAY WHEN PRESET AND CLEAR INPUTS RETURN TO THEIR INACTIVE (HIGH) LEVEL.

CMOS 4027 J-K TYPE

FUNCTIONAL TABLE CMOS 4027

CLOCK	INPUTS				OUTPUTS	
	J	K	S	R	Q_0	Q
⎯	1	X	0	0	0	1
⎯	X	0	0	0	1	1
⎯	0	X	0	0	0	0
⎯	X	1	0	0	1	0
⎯	X	X	0	0	X	Q_0
X	X	X	1	0	X	\bar{Q}_0
X	X	X	0	1	X	0
X	X	X	1	1	X	1

CMOS 4013 D TYPE

FUNCTIONAL TABLE CMOS 4013

CLOCK	INPUTS			OUTPUTS	
	DATA	RESET	SET	Q	\bar{Q}
⎯	0	0	0	0	1
⎯	1	0	0	1	0
⎯	X	0	0	Q_0	\bar{Q}_0
X	X	1	0	0	1
X	X	0	1	1	0
X	X	1	1	1	1

TTL 5478 J-K TYPE

FUNCTIONAL TABLE TTL 5478

CLOCK	INPUTS				OUTPUTS	
	J	K	P	CLEAR	Q	\bar{Q}
⎯	0	0	1	1	Q_0	\bar{Q}_0
⎯	1	0	1	1	1	0
⎯	0	1	1	1	0	1
⎯	1	1	1	1	TOGGLE	TOGGLE
X	X	X	0	1	1	0
X	X	X	1	0	0	1
X	X	X	0	0	1*	1*

* NONSTABLE WILL NOT STAY WHEN PRESET AND CLEAR INPUTS RETURN TO THEIR INACTIVE (HIGH) LEVEL.

BUFFER GATES

V DC
R

A VERTICAL LINE, WITHIN THE SYMBOL, INDICATES A OPEN COLLECTOR OR OPEN DRAIN OUTPUT. THE PULL-UP RESISTOR IS NOT ALWAYS EVIDENT.

INPUT	OUTPUT
A	B
1	1
0	0

INVERTER

A B
B=A

3-STATE BUFFER

A B
B=A

INPUT	OUTPUT
A	ENABLE
0	0
1	0
X	Z

AND/NAND GATES

INPUT			OUTPUT		
A	B	C	D	D	D
0	0	0	0	1	1
0	0	1	0	1	1
0	1	0	0	1	1
0	1	1	0	1	1
1	0	0	0	1	1
1	0	1	0	1	1
1	1	0	0	1	1
1	1	1	1	0	0

AND GATE

D=ABC

NAND GATE

D= \overline{ABC}

OR/NOR GATES

INPUT			OUTPUT		
A	B	C	C	C	C
0	0	1	0	0	0
1	0	0	1	1	1
0	1	0	1	1	1
1	1	0	1	1	0

NOR GATE

C=A+B

EXCLUSIVE OR GATE

C=AB+AB

OR GATE

C=A+B

NOTES:

- 1 FLIP-FLOP DEVICES SHOWN ARE EDGE TRIGGERED DEVICES.
2. 1=HIGH LEVEL, 0=LOW LEVEL, X=IRRELEVANT, Z=HIGH IMPEDANCE.
3. Q_0 AND \bar{Q}_0 INDICATE NO CHANGE FROM STATE BEFORE CLOCK TRANSITION.
4. POSITIVE LOGIC-LOW INPUT TO PRESET SETS Q TO HIGH LEVEL, LOW INPUT TO CLEAR SETS 1 TO LOW LEVEL.
5. GATES CONTAINING A $\bar{1}$ SYMBOL, WITHIN THE LOGIC SYMBOL, CONTAIN SCHMITT TRIGGER CIRCUITS.

CG0-2287-AC-01


Basis Logic Gate Descriptions
Figure 20/GRAPHIC 34-50-96-99B-087-A01

ROCKWELL COLLINS COMPONENT MAINTENANCE MANUAL with IPL TDR-94, PART NO 622-9352

DESCRIPTION

OPERATIONAL AMPLIFIERS (OP-AMPS) ARE USED TO ADD, SUBTRACT, AVERAGE, INTEGRATE AND COMPARE. THE OP-AMP PRODUCES AN OUTPUT WHEN THERE IS A VOLTAGE DIFFERENCE BETWEEN THE TWO INPUT TERMINALS. A POSITIVE GOING SIGNAL AT THE INVERTING INPUT PRODUCES A NEGATIVE GOING OUTPUT SIGNAL, WHEREAS A POSITIVE GOING SIGNAL AT THE NON-INVERTING INPUT PRODUCES A POSITIVE GOING OUTPUT SIGNAL. SHOWN IN FUNCTIONAL DIAGRAMS A THRU G ARE SEVERAL BASIC OP-AMP CONFIGURATIONS.


FUNCTIONAL DIAGRAM A



V1	V2	V0
0	0	UNDEFINED
0	1	V+
1	0	V-
1	1	UNDEFINED


BASIC COMPARATOR

FUNCTIONAL DIAGRAM B




INVERTING AMPLIFIER

FUNCTIONAL DIAGRAM C




NONINVERTING AMPLIFIER

FUNCTIONAL DIAGRAM D




DIFFERENTIAL AMPLIFIER

FUNCTIONAL DIAGRAM E



SUMMING INVERTER

FUNCTIONAL DIAGRAM F




INTEGRATOR

FUNCTION TABLE

VI	V0
DC ———	RAMP ↗
RAMP ↗	SINE ~
SINE ~	-COS ~
SQUARE □	TRIANGLE ▲

FUNCTIONAL DIAGRAM G



DIFFERENTIATOR


FUNCTION TABLE

VI	V0
RAMP ↗	DC ———
SINE ~	—
TRIANGLE ▲	SQUARE □

COMPENSATION NETWORKS


COMPENSATION NETWORKS ARE ADDED TO OP-AMP CIRCUITS TO OFFSET UNDESIRABLE CHARACTERISTICS. TWO EXAMPLES ARE SHOWN BELOW. OFFSET BALANCING IS REQUIRED IN SMALL SIGNAL APPLICATIONS WHERE VARIATIONS IN THE OP-AMP PARAMETERS MAY CAUSE INPUT DIFFERENCES. PHASE COMPENSATION IS ADDED TO PROVIDE CLOSED LOOP STABILITY TO THE CIRCUIT.

FUNCTIONAL DIAGRAM H




VOLTAGE FOLLOWER

FUNCTIONAL DIAGRAM I



OFFSET BALANCING

FUNCTIONAL DIAGRAM J



PHASE COMPENSATION

CG0-0362-AC-01

Basis Operational Amplifier Descriptions
Figure 21/GRAPHIC 34-50-96-99B-088-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TESTING AND FAULT ISOLATION

TASK 34-50-96-700-801-A01

1. Introduction

- A. Performance (customer acceptance) test procedures, calibration procedures, and schematics for the -004, -005, -006, -007, -008, -108, -308, -309, -408, and -409 statuses of the TDR-94/94D Mode S Transponder are provided in this section.

TASK 34-50-96-700-802-A01

2. Test Equipment

- A. Refer to the Special Tools, Fixtures, and Equipment section for information on the test equipment required.

TASK 34-50-96-700-803-A01

3. Test Procedures

SUBTASK 34-50-96-700-001-A01

A. Use of Test Procedures

NOTE: Testing is restricted to only authorized Rockwell Collins service centers.

- (1) Use Table 1001/Table 34-50-96-99A-009-A01, Final Performance (Customer Acceptance) Test to determine if the TDR-94/94D is operating properly. Use the alignment procedures in Table 1002/Table 34-50-96-99A-010-A01 to calibrate the TDR-94/94D.

SUBTASK 34-50-96-700-002-A01

B. Final Performance (Customer Acceptance) Test

- (1) The Final Performance (Customer Acceptance) Test, Table 1001/Table 34-50-96-99A-009-A01, is performed with the cover on the unit and provides a relatively high degree of assurance that the TDR-94/94D is properly operating. The final performance test is essentially a return-to-service test. The final performance test can also be used as a customer acceptance or receiving inspection test. After any repairs, all final performance test steps must be successfully completed with the cover installed before returning a unit to service. The final performance test can also be used to isolate a fault to a functional area, thus determining which alignment procedures may be applicable. Some of the performance criteria have been adjusted to allow for the tolerances of typical test equipment.

SUBTASK 34-50-96-700-003-A01

C. Detailed Performance Test

- (1) The detailed performance test is combined with the final performance test in Table 1001/Table 34-50-96-99A-009-A01.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SUBTASK 34-50-96-700-004-A01

D. Alignment Procedures

- (1) Refer to Table 1002/Table 34-50-96-99A-010-A01 for the alignment procedures for the TDR-94/94D. If the final performance (customer acceptance) test successfully completes, no alignment procedures are required.

TASK 34-50-96-810-801-A01

4. Fault Isolation

SUBTASK 34-50-96-810-001-A01

A. Fault Isolation Philosophy

CAUTION: REFER TO ADVISORIES PARAGRAPH IN THE INTRODUCTION FOR ESDS HANDLING CAUTION AND COMPONENT WARNING.

- (1) This section provides the primary information that repair personnel should use to isolate faults in the TDR 94/94D. All sections of this manual have important data to aid in the total repair and understanding of the unit. These sections are referenced, as necessary, to facilitate completion of the repair tasks.
- (2) Defective avionics equipment will usually fall into one of two categories: failure with a specific complaint and failures with an unspecified complaints. The function of this section is to guide fault isolation, first to a specific malfunction, then to the applicable circuit area. Voltages and waveforms, in addition to the theory of operation help the technician to isolate the faulty parts.
- (3) Fault isolation and troubleshooting are performed using the test equipment listed in the Special Tools, Fixtures, Equipment and Consumables section of this manual.

SUBTASK 34-50-96-810-002-A01

B. Troubleshooting Approach

- (1) Unspecified Complaint
 - (a) Troubleshooting a unit with an unspecified complaint requires the technician to test the unit according to the performance test to determine if a fault actually exists. In cases where the unit passes all portions of the test and no fault is discovered, the unit can be returned to the aircraft as good and reinstalled. However, an actual fault may still persist and all associated equipment and aircraft wiring should be checked.
 - (b) When a unit does fail the performance test, the next objective is to isolate the actual fault or faults, and begin in-depth troubleshooting procedures. Begin by performing the specific fault isolation procedure(s) in this section.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

(2) Specified Complaint


- (a) Maintenance tags that indicate specific complaints help expedite the troubleshooting process. The technician may, in many cases, choose to omit the performance test and proceed directly to the any applicable fault isolation procedure.

SUBTASK 34-50-96-810-003-A01

C. Troubleshooting Aids

- (1) Maintenance Aid Diagrams - Maintenance aid diagrams are provided in the Schematics and Wiring Diagrams section of this manual, facing the schematic diagrams, to aid in component location and identification/location of test points. Waveforms (if applicable) are shown at troubleshooting test points.
- (2) Maintenance Aid and Schematic Change Pages - Maintenance Aid and Schematic Change Pages are included in the Schematic and Wiring Diagrams section of this manual to provide information on schematic changes necessitated by production changes of service bulletin modifications.
- (3) Schematic Diagrams - Schematic diagrams are provided in the Schematic and Wiring Diagrams section of this manual as an aid to signal tracing and fault isolation.
- (4) Fault Isolation and Diagnostic Procedures - Digital circuit card troubleshooting will be accomplished using standard digital troubleshooting techniques with standard test equipment.

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
 TDR-94, PART NO 622-9352



(68B-01358-001A,3)
 1PF5415_01

TDR-94/94D Test Setup Diagram (Preferred Method)
 Figure 1001/GRAPHIC 34-50-96-99B-020-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

TASK 34-50-96-810-802-A01

5. Procedures

SUBTASK 34-50-96-810-004-A01

A. TDR-94/94D Final Performance (Customer Acceptance) Test Procedure

STEP	PROCEDURE	DESIRED RESULTS
0.0	SETUP INSTRUCTIONS	
0.1	<p>Preferred Setup: Connect TDR-94/94D as shown in Figure 1001/GRAPHIC 34-50-96-99B-020-A01. Test equipment item numbers (XX) that appear in the illustration identify test equipment in Table 9002/Table 34-50-96-99A-032-A01 of the Special Tools, Fixtures, and Equipment section.</p> <p>Alternate Setup: Connect TDR-94/94D as shown in Figure 1002/GRAPHIC 34-50-96-99B-036-A01. Test equipment item numbers (XX) that appear in the illustration identify test equipment in the Special Tools, Fixtures, and Equipment section Table 9003/Table 34-50-96-99A-042-A01.</p> <p><u>NOTE:</u> Interrogation power levels and transmitter output power are referenced to the rear connector(s) of the unit under test (UUT). The insertion loss of coaxial cables between the UUT and the test equipment must be accounted for.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
0.2	<p>AUTOMATIC TEST EQUIPMENT (FINAL) TESTS</p> <p>Preferred Setup: The TDR-94 and TDR-94D are "semi-automatically" tested on a station configured per Figure 1001/GRAPHIC 34-50-96-99B-020-A01 and Table 9002/Table 34-50-96-99A-032-A01. Test software is listed in Table 9002/Table 34-50-96-99A-032-A01. Insert Disk 1 and run SETUP procedure.</p> <p>Alternate Setup: The TDR-94 and TDR-94D are "semi-automatically" tested on a station configured per Figure 1002/GRAPHIC 34-50-96-99B-036-A01 and Table 9003/Table 34-50-96-99A-042-A01. Test software is listed in Table 9003/Table 34-50-96-99A-042-A01. Insert Disk 1 and run SETUP procedure.</p> <p><u>NOTE:</u> Software is written/used by the factory, and may contain specifications which are actually tighter than required per the performance test requirements (ptr). Therefore, refer to this test document for test specifications for those automatic tests which fail.</p>	
0.3	<p>IFR S-1403DL SETUP INFORMATION</p> <p>The IFR S-1403DL test set must have C-Menu setup information stored into memory for proper operation. Ensure that all S-Menus (including S-Menu 00) are turned off. Set the following C-Menu configuration and save it to store locations 1 and 2.</p> <p>C-10 "f01 ATC" ANT B "off" C-50 Counts "10s" C-71 Trig Source "Selfinterr" C-72 All On, Cal C-73 All On C-74 All On C-75 ANT A mod source: "Int", ANT A Enable: "On" C-76 S menu Radix: Octal</p>	
0.4	<p>TEST CONDITIONS</p> <p>Final data is to be taken after a 30 minute warm-up with primary power applied. Perform the setup instructions in Table 1002/Table 34-50-96-99A-010-A01 for standard switch settings prior to running an automatic test.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS									
0.5	<p>BUS NAMING CONVENTIONS</p> <p>When reading this test procedure, the terms CSDB and PLII are used interchangeably to denote the Commercial Standard Digital Bus, commonly known as the Pro-Line II bus at Rockwell Collins, Inc.</p> <p>The ARINC 429 data bus is commonly called the ARINC bus or the 429 bus and either term may appear in documentation.</p> <p>Selection of busses from the test software will refer to port "A" as port 0, port "B" as port 1, and port "C" as port 2.</p>										
1.0	<p>RECEIVER TESTS</p> <p>Perform the following tests on both the top and bottom antenna ports for the TDR-94D. For the TDR-94, perform only those tests specified for the bottom channel.</p>										
1.1	<p>MTL Test</p> <p>Test MTL is defined as the minimum interrogation power level which produces a reply rate of at least 90%. Determine the minimum interrogation level (MTL) required to obtain at least a 90% reply rate for the following interrogations. Verify that these levels are between -75 and -79 dBm.</p> <p style="text-align: center;"><u>Interrogations</u></p> <p>A. MODE-S only All-Call B. ATCRBS MODE-A/MODE-S All-Call C. ATCRBS MODE-C</p> <p><u>NOTE:</u> If the MTL cannot be established within the specification limits, A7R127 and/or A7R137 (CPN 833-6008-020) may be added as required to adjust temperature compensation. Refer to the A7 maintenance aid diagram for component location. This information is provided for reference only, after initial values are determined in production, no further temperature compensation adjustments should be necessary.</p>	<table style="width: 100%; border: none;"> <tr> <td style="text-align: center; width: 50%;">TOP</td> <td style="text-align: center; width: 50%;">BOTTOM</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table> <p><u>NOTE:</u> Refer to step 22.0 in Table 1002/Table 34-50-96-99A-010-A01, Alignment Procedure.</p>	TOP	BOTTOM	_____	_____	_____	_____	_____	_____	
TOP	BOTTOM										
_____	_____										
_____	_____										
_____	_____										
1.2	<p>Sensitivity Variation with Frequency Test</p> <p>Using ATCRBS MODE-C interrogations, ensure that MTL does not vary by more than ± 1 dB for interrogation frequencies between 1029.8 and 1030.2 MHz.</p>	<table style="width: 100%; border: none;"> <tr> <td></td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOT</td> </tr> <tr> <td style="text-align: right;">1029.8 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: right;">1030.2 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		TOP	BOT	1029.8 MHz	_____	_____	1030.2 MHz	_____	_____
	TOP	BOT									
1029.8 MHz	_____	_____									
1030.2 MHz	_____	_____									

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																								
1.3	Receiver Bandwidth Test Vary the interrogation RF frequency to 1007, 1053, 1060, and 1150 MHz. Verify the MODE-A interrogation level, required to produce 90% reply efficiency is greater than -17 dBm.	<table style="width: 100%; border: none;"> <tr> <td></td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOT</td> </tr> <tr> <td>1007 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>1053 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>1060 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>1150 MHz</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		TOP	BOT	1007 MHz	_____	_____	1053 MHz	_____	_____	1060 MHz	_____	_____	1150 MHz	_____	_____									
	TOP	BOT																								
1007 MHz	_____	_____																								
1053 MHz	_____	_____																								
1060 MHz	_____	_____																								
1150 MHz	_____	_____																								
1.4	Dynamic Range Test Verify a minimum reply rate of at least 90% for the following interrogations at input signal levels of -73 dBm and -19 dBm. <u>Interrogations</u> A. MODE-S only All-Call B. ATCRBS MODE-A/MODE-S All-Call C. ATCRBS MODE-C	<table style="width: 100%; border: none;"> <tr> <td colspan="4" style="text-align: center;">Signal level (dBm)</td> </tr> <tr> <td></td> <td style="text-align: center;">-73 dBm</td> <td style="text-align: center;">-19 dBm</td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOT</td> <td style="text-align: center;">TOP BOT</td> </tr> <tr> <td>A</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>B</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>C</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>	Signal level (dBm)					-73 dBm	-19 dBm			TOP	BOT	TOP BOT	A	_____	_____	_____	B	_____	_____	_____	C	_____	_____	_____
Signal level (dBm)																										
	-73 dBm	-19 dBm																								
	TOP	BOT	TOP BOT																							
A	_____	_____	_____																							
B	_____	_____	_____																							
C	_____	_____	_____																							
1.5	Sensitivity Limit Test For the following interrogations at a -81 dBm input signal level, verify that the reply rate does not exceed 10%. <u>Interrogations</u> A. MODE-S only All-Call B. ATCRBS MODE-A/MODE-S All-Call C. ATCRBS MODE-C	<table style="width: 100%; border: none;"> <tr> <td></td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOTTOM</td> </tr> <tr> <td>A</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>B</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>C</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		TOP	BOTTOM	A	_____	_____	B	_____	_____	C	_____	_____												
	TOP	BOTTOM																								
A	_____	_____																								
B	_____	_____																								
C	_____	_____																								
1.6	Undesired Replies For this test, squitter must be disabled by setting Self-Test Inhibit discrete input, P2-38 (-004 thru -007) or P1-19 (-008, -108, -308, -309, -408, -409) to ground. Turn off all interrogations. Verify that the ATCRBS random replies are less than 5 per second and the MODE-S replies are less than 1 per 10 seconds, averaged over a period of at least 30 seconds. After this test, turn interrogations back on and remove the ground from P2-38 or P1-19.	<table style="width: 100%; border: none;"> <tr> <td></td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOT</td> </tr> <tr> <td>ATCRBS</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>MODE-S</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		TOP	BOT	ATCRBS	_____	_____	MODE-S	_____	_____															
	TOP	BOT																								
ATCRBS	_____	_____																								
MODE-S	_____	_____																								
2.0	TRANSMITTER REQUIREMENTS																									
	Unless otherwise specified, perform the following tests on both the top and bottom antenna ports using a MODE-S test set. For the TDR-94, you must do only the tests for the bottom antenna port.																									
2.1	Transmitter Frequency Test Ensure that the output transmitter frequency is 1090 ±0.5 MHz.	_____ MHz																								

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
2.2	<p>Transmitter Power Test</p> <p>a. Interrogate ATCRBS interrogations at a rate of 450 per second, or MODE-S interrogations at a rate of 50 per second. Verify that the output transmitter power is between 315 and 500 watts measured at the strongest reply pulse. Verify that the weakest pulse is within 1 dB of the strongest for ATCRBS replies and within 2 dB for MODE-S replies. Verify the weakest pulse exceeds 250 watts.</p> <p>Strongest ATCRBS pulse Spec: 315 to 500 watts Weakest ATCRBS pulse Spec: = strongest ± 1 dB Weakest MODE-S pulse Spec: = strongest ± 2 dB</p> <p><u>NOTE:</u> Record the peak level of the strongest pulse in dBm to use as a reference for measurements made in step 2.3.</p> <p><u>CAUTION:</u> BEFORE PERFORMING STEP B, SEPARATE THE TRANSMITTER MODULE FROM THE MAIN CHASSIS AND DISCONNECT HIGH VOLTAGE FROM THE TRANSMITTER. FAILURE TO DO THIS WILL RESULT IN SEVERE DAMAGE TO THE SPECTRUM ANALYZER. ALL COVERS MUST REMAIN INTACT FOR DATA TO BE VALID.</p>	<p style="text-align: center;">TOP BOTTOM</p> <p style="text-align: center;">_____ _____</p> <p style="text-align: center;">_____ _____</p> <p style="text-align: center;">_____ _____</p>
	<p>b. Connect the transmitter output directly to the spectrum analyzer. Ensure that the 1090 MHz L.O. leakage from the antenna port is less than -70 dBm when not transmitting. Reconnect high voltage to the transmitter and reassemble the transmitter module to the main chassis after completing the test.</p> <p>1090 MHz L.O. leakage Spec: less than -70 dBm</p>	<p style="text-align: center;">TOP BOTTOM</p> <p style="text-align: center;">_____ _____</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																						
2.2 (Cont)	<p>(This test applies to TDR-94D only.)</p> <p>c. Set the self-test inhibit discrete to active to prevent squittering. Ensure that the transmitter power output of the nonselected antenna is attenuated at least 20 dB relative to the selected antenna during the time the transmitter is transmitting on the other antenna port. Set the self-test inhibit discrete to disable after completing the test.</p> <p>Nonselected antenna power Spec: MIN. 20 dB attenuation</p>	_____																						
2.3	<p>Transmitter Spectrum and Reply Pulse Shape</p> <p>Set up to transmit only MODE-S replies at 50/second. Observe the output spectrum with a spectrum analyzer. Use a 100-kHz resolution bandwidth or less. Use the peak level reference recorded in step 2.2. for the measurements below. Verify the spectrum does not exceed the following limits:</p> <table style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: left;">Frequency Difference (MHz from Carrier)</th> <th style="text-align: left;">Spec:</th> </tr> </thead> <tbody> <tr> <td>>= 1.3 and <7</td> <td>3</td> </tr> <tr> <td>>= 7 and <23</td> <td>20</td> </tr> <tr> <td>>= 23 and <78</td> <td>40</td> </tr> <tr> <td>>= 78</td> <td>60</td> </tr> </tbody> </table>	Frequency Difference (MHz from Carrier)	Spec:	>= 1.3 and <7	3	>= 7 and <23	20	>= 23 and <78	40	>= 78	60	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">Max Relative Response (dB down from peak ref)</th> </tr> <tr> <th style="text-align: center;">TOP</th> <th style="text-align: center;">BOTTOM</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Max Relative Response (dB down from peak ref)		TOP	BOTTOM	_____	_____	_____	_____	_____	_____	_____	_____
Frequency Difference (MHz from Carrier)	Spec:																							
>= 1.3 and <7	3																							
>= 7 and <23	20																							
>= 23 and <78	40																							
>= 78	60																							
Max Relative Response (dB down from peak ref)																								
TOP	BOTTOM																							
_____	_____																							
_____	_____																							
_____	_____																							
_____	_____																							
2.4	<p>Reply Pulse Shape</p> <p>For both ATCRBS and MODE-S replies, verify that the pulse rise time is less than 100 ns and that the pulse decay time is less than 200 ns.</p> <table style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th style="text-align: center;">ATCRBS</th> <th></th> <th style="text-align: center;">MODE-S</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">TOP</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">RISE</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">FALL</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">FALL</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">RISE</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">BOTTOM</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">BOTTOM</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>		ATCRBS		MODE-S	TOP	_____	TOP	_____	RISE	_____	FALL	_____	FALL	_____	RISE	_____	BOTTOM	_____	BOTTOM	_____	<p style="text-align: center;">TOP BOTTOM</p> <p style="text-align: center;">RISE FALL RISE FALL</p> <p style="text-align: center;">_____ _____</p> <p style="text-align: center;">_____ _____</p> <p>If these results are not met, select A3C216 test select value from page 10150 (figure 6) to get results into specs.</p>		
	ATCRBS		MODE-S																					
TOP	_____	TOP	_____																					
RISE	_____	FALL	_____																					
FALL	_____	RISE	_____																					
BOTTOM	_____	BOTTOM	_____																					
2.5	<p>Burst Tests</p> <p>For these tests, verify correct replies and output power for all interrogations.</p>																							
2.5.1	<p>ATCRBS Burst Tests</p> <p>Verify that at least 120 ATCRBS 15-pulse replies can be generated in 100 ms. Repeat the test at a once per second rate.</p>	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">TOP</th> <th style="text-align: center;">BOTTOM</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____ (x)</td> </tr> </tbody> </table>	TOP	BOTTOM	_____	_____ (x)																		
TOP	BOTTOM																							
_____	_____ (x)																							

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS	
2.5.2	<p>MODE-S Burst Tests</p> <p>Verify the following MODE-S reply capabilities:</p> <p>50 MODE-S replies in a 1-second interval including at least 16 long replies.</p> <p>18 MODE-S replies in a 100-ms interval including at least 6 long replies.</p> <p>8 MODE-S replies in a 25-ms interval including at least 4 long replies.</p> <p>4 MODE-S replies in a 1.6-ms interval including at least 2 long replies.</p>	<p>TOP</p> <p>_____</p>	<p>BOTTOM</p> <p>_____ (x)</p> <p>_____ (x)</p> <p>_____ (x)</p> <p>_____ (x)</p>
2.6	<p>MODE-A Reply Format, Ident Interval, and Reply Delay</p> <p>Inject a normal MODE-A interrogation on the bottom channel only. Select 7777 ident code on the test bench control head simulator (computer). Verify IFR displays a 7777 code. Ensure the downlink first framing pulse occurs $3.00 \pm 0.45 \mu\text{s}$ after the P3 leading edge of the interrogation input. Momentarily activate the Ident switch and verify that the SPI pulse is present for 18 ± 2 seconds. Verify that the ATCRBS Downlink modulation has pulse widths of $0.45 \pm 0.05 \mu\text{s}$. Verify the following spacings from the first framing pulse. All spacing and width tolerances are ± 50 ns. Repeat the reply delay test on the top channel (TDR-94D only).</p> <p style="text-align: center;">Downlink first framing pulse. Spec: $3.00 \pm 0.45 \mu\text{s}$ after P3 input</p> <p style="text-align: center;">SPI pulse time Spec: 18 ± 2 seconds</p> <p style="text-align: center;">ATCRBS Downlink pulse width Spec: $0.45 \pm 0.05 \mu\text{s}$</p>	<p>TOP</p> <p>_____ μs</p>	<p>BOTTOM</p> <p>_____ μs</p> <p>BOTTOM</p> <p>_____ s</p> <p>BOTTOM</p> <p>_____ μs</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																														
2.6 (Cont)	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;"><u>Reply Pulse</u></th> <th style="text-align: left; border-bottom: 1px solid black;"><u>Position (μs)</u></th> </tr> </thead> <tbody> <tr><td>C1</td><td>1.45 ±50 ns</td></tr> <tr><td>A1</td><td>2.90 ±50 ns</td></tr> <tr><td>C2</td><td>4.35 ±50 ns</td></tr> <tr><td>A2</td><td>5.80 ±50 ns</td></tr> <tr><td>C4</td><td>7.25 ±50 ns</td></tr> <tr><td>A4</td><td>8.70 ±50 ns</td></tr> <tr><td>B1</td><td>11.60 ±50 ns</td></tr> <tr><td>D1</td><td>13.05 ±50 ns</td></tr> <tr><td>B2</td><td>14.50 ±50 ns</td></tr> <tr><td>D2</td><td>15.95 ±50 ns</td></tr> <tr><td>B4</td><td>17.40 ±50 ns</td></tr> <tr><td>D4</td><td>18.85 ±50 ns</td></tr> <tr><td>2ND framing pulse</td><td>20.30 ±50 ns</td></tr> <tr><td>SPI</td><td>24.65 ±50 ns</td></tr> </tbody> </table>	<u>Reply Pulse</u>	<u>Position (μs)</u>	C1	1.45 ±50 ns	A1	2.90 ±50 ns	C2	4.35 ±50 ns	A2	5.80 ±50 ns	C4	7.25 ±50 ns	A4	8.70 ±50 ns	B1	11.60 ±50 ns	D1	13.05 ±50 ns	B2	14.50 ±50 ns	D2	15.95 ±50 ns	B4	17.40 ±50 ns	D4	18.85 ±50 ns	2ND framing pulse	20.30 ±50 ns	SPI	24.65 ±50 ns	BOTTOM _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x) _____ (x)
<u>Reply Pulse</u>	<u>Position (μs)</u>																															
C1	1.45 ±50 ns																															
A1	2.90 ±50 ns																															
C2	4.35 ±50 ns																															
A2	5.80 ±50 ns																															
C4	7.25 ±50 ns																															
A4	8.70 ±50 ns																															
B1	11.60 ±50 ns																															
D1	13.05 ±50 ns																															
B2	14.50 ±50 ns																															
D2	15.95 ±50 ns																															
B4	17.40 ±50 ns																															
D4	18.85 ±50 ns																															
2ND framing pulse	20.30 ±50 ns																															
SPI	24.65 ±50 ns																															
2.7	<p>MODE-C Reply Format and Reply Delay</p> <p>Interrogate with a normal MODE-C signal on the bottom channel only. Select the Gillham discretes as the altitude source by disconnecting rear connector P2 pins 41 and 42 from ground. Verify that F1 of the ATCRBS reply occurs 3.00 ±0.45 μs after the interrogation P3 leading edge. Observe the transmitted MODE-C reply. Verify that each of the Gillham ALT bits will go low individually with a 39-kΩ pull-down resistor. Use the following table listed to locate the Gillham ALT bits. Repeat the reply delay test on the top channel (TDR-94D only).</p> <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="text-align: center;">ATCRBS F1 spacing from P3</td> <td style="text-align: center;">TOP</td> <td style="text-align: center;">BOTTOM</td> </tr> <tr> <td style="text-align: center;">Spec: 3.00 ±0.45 μs</td> <td style="text-align: center;">_____ μs</td> <td style="text-align: center;">_____ μs</td> </tr> </table>	ATCRBS F1 spacing from P3	TOP	BOTTOM	Spec: 3.00 ±0.45 μs	_____ μs	_____ μs																									
ATCRBS F1 spacing from P3	TOP	BOTTOM																														
Spec: 3.00 ±0.45 μs	_____ μs	_____ μs																														

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																																																				
2.7 (Cont)	<table border="0"> <thead> <tr> <th style="text-align: center;"><u>LOCATION</u></th> <th style="text-align: center;"><u>SIGNAL NAME</u></th> </tr> </thead> <tbody> <tr><td>P1-1</td><td>Gillham ALT B4</td></tr> <tr><td>P1-2</td><td>Gillham ALT B2</td></tr> <tr><td>P1-3</td><td>Gillham ALT B1</td></tr> <tr><td>P1-4</td><td>Gillham ALT A4</td></tr> <tr><td>P1-5</td><td>Gillham ALT A2</td></tr> <tr><td>P1-6</td><td>Gillham ALT A1</td></tr> <tr><td>P1-7</td><td>Gillham ALT D4</td></tr> <tr><td>P1-8</td><td>Gillham ALT D2</td></tr> <tr><td>P1-9</td><td>Gillham ALT C4</td></tr> <tr><td>P1-10</td><td>Gillham ALT C2</td></tr> <tr><td>P1-11</td><td>Gillham ALT C1</td></tr> <tr><td></td><td>F2 (2nd Framing Pulse)</td></tr> </tbody> </table>	<u>LOCATION</u>	<u>SIGNAL NAME</u>	P1-1	Gillham ALT B4	P1-2	Gillham ALT B2	P1-3	Gillham ALT B1	P1-4	Gillham ALT A4	P1-5	Gillham ALT A2	P1-6	Gillham ALT A1	P1-7	Gillham ALT D4	P1-8	Gillham ALT D2	P1-9	Gillham ALT C4	P1-10	Gillham ALT C2	P1-11	Gillham ALT C1		F2 (2nd Framing Pulse)	<table border="0"> <thead> <tr> <th style="text-align: center;">Bit Toggles (BOTTOM)</th> <th style="text-align: center;">Reply Pulse Spacing from F1 (μs)</th> </tr> </thead> <tbody> <tr><td>_____</td><td>17.40</td></tr> <tr><td>_____</td><td>14.50</td></tr> <tr><td>_____</td><td>11.60</td></tr> <tr><td>_____</td><td>8.70</td></tr> <tr><td>_____</td><td>5.80</td></tr> <tr><td>_____</td><td>2.90</td></tr> <tr><td>_____</td><td>18.85</td></tr> <tr><td>_____</td><td>15.95</td></tr> <tr><td>_____</td><td>7.25</td></tr> <tr><td>_____</td><td>4.35</td></tr> <tr><td>_____</td><td>1.45</td></tr> <tr><td>_____</td><td>20.30</td></tr> </tbody> </table>	Bit Toggles (BOTTOM)	Reply Pulse Spacing from F1 (μs)	_____	17.40	_____	14.50	_____	11.60	_____	8.70	_____	5.80	_____	2.90	_____	18.85	_____	15.95	_____	7.25	_____	4.35	_____	1.45	_____	20.30
<u>LOCATION</u>	<u>SIGNAL NAME</u>																																																					
P1-1	Gillham ALT B4																																																					
P1-2	Gillham ALT B2																																																					
P1-3	Gillham ALT B1																																																					
P1-4	Gillham ALT A4																																																					
P1-5	Gillham ALT A2																																																					
P1-6	Gillham ALT A1																																																					
P1-7	Gillham ALT D4																																																					
P1-8	Gillham ALT D2																																																					
P1-9	Gillham ALT C4																																																					
P1-10	Gillham ALT C2																																																					
P1-11	Gillham ALT C1																																																					
	F2 (2nd Framing Pulse)																																																					
Bit Toggles (BOTTOM)	Reply Pulse Spacing from F1 (μs)																																																					
_____	17.40																																																					
_____	14.50																																																					
_____	11.60																																																					
_____	8.70																																																					
_____	5.80																																																					
_____	2.90																																																					
_____	18.85																																																					
_____	15.95																																																					
_____	7.25																																																					
_____	4.35																																																					
_____	1.45																																																					
_____	20.30																																																					
3.0	DECODER TESTS Unless otherwise specified, perform the following tests at -74 dBm and -20 dBm interrogation levels at each antenna port.																																																					
3.1	MODE-A P3 Deviation Negative, Max Interrogate MODE-A with a P3 deviation of -0.9 μs on the appropriate channel. Verify that the reply rate is NOT GREATER than 10%.	<table border="0"> <thead> <tr> <th colspan="2" style="text-align: center;">Signal level (dBm)</th> </tr> <tr> <th style="text-align: center;">-74</th> <th style="text-align: center;">-20</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BOT _____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">TOP _____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Signal level (dBm)		-74	-20	BOT _____	_____	TOP _____	_____																																												
Signal level (dBm)																																																						
-74	-20																																																					
BOT _____	_____																																																					
TOP _____	_____																																																					
3.2	MODE-A P3 Deviation Positive, Max Interrogate MODE-A with a P3 deviation of +0.9 μs on the appropriate channel. Verify that the reply rate is NOT GREATER than 10%.	<table border="0"> <thead> <tr> <th colspan="2" style="text-align: center;">Signal level (dBm)</th> </tr> <tr> <th style="text-align: center;">-74</th> <th style="text-align: center;">-20</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BOT _____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">TOP _____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Signal level (dBm)		-74	-20	BOT _____	_____	TOP _____	_____																																												
Signal level (dBm)																																																						
-74	-20																																																					
BOT _____	_____																																																					
TOP _____	_____																																																					
3.3	MODE-A Pulse Width, Narrow Interrogate MODE-A with 0.30 μs pulse width at a level of -45 dBm on the appropriate channel. Verify that the reply rate is NOT GREATER than 10%.	<table border="0"> <thead> <tr> <th colspan="2" style="text-align: center;">Signal level (dBm)</th> </tr> <tr> <th colspan="2" style="text-align: center;">-45</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BOT _____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">TOP _____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Signal level (dBm)		-45		BOT _____	_____	TOP _____	_____																																												
Signal level (dBm)																																																						
-45																																																						
BOT _____	_____																																																					
TOP _____	_____																																																					
3.4	MODE-A Pulse Width, Normal Interrogate MODE-A with 0.60 μs pulse width on the appropriate channel. Verify AT LEAST 90% MODE-A replies are transmitted.	<table border="0"> <thead> <tr> <th colspan="2" style="text-align: center;">Signal level (dBm)</th> </tr> <tr> <th style="text-align: center;">-74</th> <th style="text-align: center;">-20</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BOT _____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">TOP _____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Signal level (dBm)		-74	-20	BOT _____	_____	TOP _____	_____																																												
Signal level (dBm)																																																						
-74	-20																																																					
BOT _____	_____																																																					
TOP _____	_____																																																					
3.5	MODE-A P3 Deviation Negative, Min Interrogate MODE-A with a P3 deviation of -0.30 μs on the appropriate channel. Verify AT LEAST 90% MODE-A replies are transmitted.	<table border="0"> <thead> <tr> <th colspan="2" style="text-align: center;">Signal level (dBm)</th> </tr> <tr> <th style="text-align: center;">-74</th> <th style="text-align: center;">-20</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BOT _____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: center;">TOP _____</td> <td style="text-align: center;">_____</td> </tr> </tbody> </table>	Signal level (dBm)		-74	-20	BOT _____	_____	TOP _____	_____																																												
Signal level (dBm)																																																						
-74	-20																																																					
BOT _____	_____																																																					
TOP _____	_____																																																					

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
3.6	MODE-A P3 Deviation Positive, Min Interrogate MODE-A with a P3 deviation of +0.30 μ s on the appropriate channel. Verify AT LEAST 90% MODE-A replies are transmitted.	Signal level (dBm) -74 -20 BOT _____ TOP _____
3.7	MODE-C P3 Deviation Negative, Max Interrogate MODE-C with a P3 deviation of -0.90 μ s on the appropriate channel. Verify that the reply rate is NOT GREATER than 10%.	Signal level (dBm) -74 -20 BOT _____ TOP _____
3.8	MODE-C P3 Deviation Positive, Max Interrogate MODE-C with a P3 deviation of +0.90 μ s on the appropriate channel. Verify that the reply rate is NOT GREATER than 10%.	Signal level (dBm) -74 -20 BOT _____ TOP _____
3.9	MODE-C P3 Deviation Negative, Min Interrogate MODE-C with a P3 deviation of -0.30 μ s on the appropriate channel. Verify that the reply rate is AT LEAST 90%.	Signal level (dBm) -74 -20 BOT _____ TOP _____
3.10	MODE-C P3 Deviation Positive, Min Interrogate MODE-C with a P3 deviation of +0.30 μ s on the appropriate channel. Verify that the reply rate is AT LEAST 90%.	Signal level (dBm) -74 -20 BOT _____ TOP _____
4.0	ATCRBS SLS TEST Perform the following tests at MTL +3 dB or -74 dBm. Test also at -60 dBm, -40 dBm, and -22 dBm input signal levels. Conduct the following tests on the bottom antenna port for both TDR-94 and TDR-94D. Repeat the tests on the top antenna port of the TDR-94D only.	
4.1	MODE-C P2 at -1 dB Interrogate with a MODE-C P1, P2, P3 triad with P2 at -1 dB. Deviate the P2 position +0.2 and -0.2 μ s. Verify that the reply rate is NOT GREATER than 10%.	Signal level (dBm) -74 -60 -40 -22 BOT _ _ _ _ TOP _ _ _ _
4.2	MODE-C P2 at -9 dB Interrogate with a MODE-C P1, P2, P3 triad with P2 at -9 dB. Verify that the reply rate is AT LEAST 90%.	Signal level (dBm) -74 -60 -40 -22 BOT _ _ _ _ TOP _ _ _ _
4.3	MODE-C P2 at 0 dB Interrogate with a MODE-C P1, P2, P3 triad with P2 at 0 dB. Set P2 pulse width to 0.60 μ s and verify that the reply rate is NOT GREATER than 1%.	Signal level (dBm) -74 -60 -40 -22 BOT _ _ _ _ TOP _ _ _ _

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
4.4	MODE-A P2 at 0 dB Interrogate with a MODE-A P1, P2, P3 triad with P2 at 0 dB. Deviate the P2 position +0.65 μ s and -0.65 μ s and verify that the reply rate is AT LEAST 90%.	Signal level (dBm) -74 -60 -40 -22 BOT — — — — TOP — — — —
4.5	SLS Suppression Interval Interrogate with a P1, P2, ATCRBS suppression pair with P2 at 0 dB relative to P1. Follow with a normal MODE-A P1, P3 interrogation. Delay the second interrogation 26 μ s from P2 of the first interrogation and verify that the reply rate is NOT GREATER than 10%. Delay the second interrogation 44 μ s from P2 of the first interrogation and verify that replies are generated in response to the second interrogation at a rate of AT LEAST 90%. Second interrogation delayed 26 μ s. NOT GREATER than 10% ATCRBS reply Second interrogation delayed 44 μ s. AT LEAST 90% replies to second interrogation	 _____ _____
5.0	MODE-S SLS TEST	
	Perform the following tests at MTL +3 dB or -73 dBm and also at -22 dBm interrogation input signal levels applied to the bottom antenna port. Repeat the test for the top antenna port of the TDR-94D only.	
5.1	P5 Greater than P6 Ensure that a P5 pulse overlaying the SPR (Sync Phase Reversal) of a MODE-S interrogation results in a reply rate of NOT GREATER than 10% if its amplitude is greater than P6 by 3 dB.	Signal level (dBm) -73 -22 BOT — — TOP — —
5.2	P5 Less Than P6 Ensure that a P5 pulse overlaying the SPR of a MODE-S interrogation results in greater than 99% replies if its amplitude is less than P6 by 12 dB	Signal level (dBm) -73 -22 BOT — — TOP — —
6.0	ALL-CALL DECODER TEST	
	Perform the following tests at MTL +1 dB or -75 dBm and also at -22 dBm interrogation input signal levels. Unless otherwise specified, test the bottom antenna port for the TDR-94, and both antenna ports for the TDR-94D.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
6.1	P4 Pulse Width Variation, ATCRSB/MODE-S All-Call a. Interrogate with a P1, P3, P4 ATCRBS/MODE-S ALL-CALL. Vary the P4 pulse width from 1.45 to 1.75 μ s. Ensure that the downlink MODE-S reply rate exceeds 90%.	Signal level (dBm) -75 -22 BOT _____ TOP _____
	b. Ensure the downlink first preamble pulse occurs 128.00 \pm 0.50 μ s after the P4 pulse leading edge.	Signal level (dBm) -75 -22 BOT _____ TOP _____
	c. Ensure that the downlink modulation has proper spacing and widths for the preamble and information pulses. All spacing and width tolerances are \pm 30 ns.	Signal level (dBm) -75 -22 BOT _____ TOP _____
6.2	MODE-S Address Ensure that the MODE-S address bits will go low individually with a 1.82-k Ω pull-down resistor and remain high individually with a 18.2-k Ω pull-down resistor. Use the following table to locate and address the MODE-S address bits. <u>NOTE:</u> TDR-94/94D transponders -004 status and later, read and accept the MODE-S Address during power-on initialization only. If the MODE-S Address is changed after power-on initialization, the address will not be accepted for use in replies to interrogations. Consequently, if the MODE-S Address provided to the UUT is changed, power to the UUT may have to be cycled before proceeding with this test. <u>NOTE:</u> If the resistor pull-down tests are performed at an assembly level test, the top-level test may substitute a short-to-ground, or open circuit, for 1.82 k Ω and 18.2 k Ω , respectively. Conduct this test for the bottom antenna port only and at a convenient input signal level.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS	
6.2 (Cont)	<u>SIGNAL NAME</u>		
	<u>LOCATION</u>		
	MODE-S ADDR B1	P1-33	_____
	MODE-S ADDR B2	P1-34	_____
	MODE-S ADDR B3	P1-35	_____
	MODE-S ADDR B4	P1-36	_____
	MODE-S ADDR B5	P1-37	_____
	MODE-S ADDR B6	P1-38	_____
	MODE-S ADDR B7	P1-39	_____
	MODE-S ADDR B8	P1-40	_____
	MODE-S ADDR B9	P1-41	_____
	MODE-S ADDR B10	P1-42	_____
	MODE-S ADDR B11	P1-43	_____
	MODE-S ADDR B12	P1-44	_____
	MODE-S ADDR B13	P1-45	_____
	MODE-S ADDR B14	P1-46	_____
	MODE-S ADDR B15	P1-47	_____
	MODE-S ADDR B16	P1-48	_____
	MODE-S ADDR B17	P1-49	_____
	MODE-S ADDR B18	P1-50	_____
	MODE-S ADDR B19	P1-51	_____
	MODE-S ADDR B20	P1-52	_____
	MODE-S ADDR B21	P1-53	_____
	MODE-S ADDR B22	P1-54	_____
MODE-S ADDR B23	P1-55	_____	
MODE-S ADDR B24	P1-56	_____	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
6.3	P4 Pulse Width Variation, ATCRBS-ONLY ALL Interrogate with a P1, P3, P4 ATCRBS-Only All-Call. Vary the P4 pulse width from 0.60 to 1.00 μ s. Verify that the reply rate is NOT GREATER than 10%.	Signal level (dBm) -75 -22 BOT _____ TOP _____
6.4	P4 Pulse Width Variation, ATCRBS/MODE-S ALL CALL Interrogate with a P1, P3, P4 ATCRBS/MODE-S All-Call. Set the P4 pulse width to 1.1 and 2.4 μ s. Verify that the reply rate is NOT GREATER than 10%.	Signal level (dBm) -75 -22 BOT _____ TOP _____
6.5	P4 Minimum Pulse Width, ATCRBS-ONLY ALL CALL Interrogate with a P1, P3, P4 ATCRBS-Only All-Call. Set P4 pulse width to 0.30 μ s. Verify that an ATCRBS reply occurs within 3.00 \pm 0.50 μ s from P3, at a rate of AT LEAST 90%, and the MODE-S reply rate is NOT GREATER than 10%.	Signal level (dBm) -75 -22 BOT _____ TOP _____ 10% or < MODE-S reply 90% or > ATCRBS reply BOT _____ TOP _____
6.6	P4 Position Variation, ATCRBS/MODE-S ALL CALL Interrogate with normal P1, P3, P4 ATCRBS/MODE-S All-Call interrogations. Deviate the P4 position \pm 50 ns. Verify that the All-Call replies are transmitted at a rate of AT LEAST 90%.	Signal level (dBm) -75 -22 BOT _____ TOP _____
6.7	P4 Amplitude 6 dB Below P3 Interrogate with ATCRBS/MODE-S All-Call interrogations. Adjust the P4 amplitude 6 dB below the amplitude of P3. Verify that the MODE-S reply rate is NOT GREATER than 10% and the ATCRBS rate is AT LEAST 90%.	Signal level (dBm) -75 -22 BOT _____ TOP _____ 10% or < MODE-S reply 90% or > ATCRBS reply BOT _____ TOP _____

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
6.8	<p>P4 Deviation, ATCRBS/MODE-S ALL CALL Interrogate with ATCRBS/MODE-S All-Call interrogations. Deviate P4 $\pm 0.30 \mu s$ and verify that the ATCRBS reply rate is AT LEAST 90% and the MODE-S reply rate is NOT GREATER than 10%.</p> <p style="text-align: center;">10% or < MODE-S reply</p> <p style="text-align: center;">90% or > ATCRBS reply</p>	<p>Signal level (dBm)</p> <p style="text-align: center;">-75 -22</p> <p>BOT _____</p> <p>TOP _____</p> <p>BOT _____</p> <p>TOP _____</p>
6.9	<p>P4 Amplitude 1 dB Below P3 Interrogate with ATCRBS-Only All-Call interrogation having a signal level of -73 dBm. Adjust the P4 amplitude 1 dB below amplitude of P3. Verify that the reply rate is NOT GREATER than 10%.</p>	<p>Signal level (dBm)</p> <p style="text-align: center;">-73</p> <p>BOT _____</p> <p>TOP _____</p>
7.0	<p>MODE-S DECODER TEST Perform the following tests at MTL +1 dB or -75 dBm and also -22 dBm interrogation levels. Test the bottom antenna port of the TDR-94, and both antenna ports of the TDR-94D. Set the ADLP select to active. If air/ground discrete is set to airborne, cycle power before beginning tests.</p>	<p>Signal level (dBm)</p> <p style="text-align: center;">-75 -22</p> <p>BOT _____</p> <p>TOP _____</p>
7.1	<p>MODE-S Reply Delay Interrogate with Uplink Format UF=11 interrogations. Verify that the first downlink preamble pulse occurs $128.00 \pm 0.25 \mu s$ after the SPR (Sync Phase Reversal) of the interrogation inputs. Verify that the Downlink Response is DF=11.</p>	
7.2	<p>SPR Deviation -Low Interrogate with Uplink Format UF=11 interrogations. Deviate the SPR position over +50 and -50 ns. Verify that the DF=11 downlink response rate is AT LEAST 90%.</p> <p style="text-align: center;">+50 ns</p> <p style="text-align: center;">-50 ns</p>	<p>Signal level (dBm)</p> <p style="text-align: center;">-75 -22</p> <p>BOT _____</p> <p>TOP _____</p> <p>BOT _____</p> <p>TOP _____</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
7.3	<p>SPR Deviation -High Interrogate with Uplink Format UF=11 interrogations. Deviate the SPR position to +200 ns and -200 ns. Verify that the DF=11 downlink response rate is NOT GREATER than 10%.</p> <p style="text-align: center;">+200 ns</p> <p style="text-align: center;">-200 ns</p>	<p style="text-align: right;">Signal level (dBm)</p> <p style="text-align: center;">-75 -22</p> <p>BOT _____ _____</p> <p>TOP _____ _____</p> <p>BOT _____ _____</p> <p>TOP _____ _____</p>
7.4	<p>UF = 5/DF = 5 Interrogate with Uplink Format UF=5 interrogations. Verify that the downlink response is DF=5. Conduct this test for bottom antenna port only and at a convenient input signal level.</p>	BOTTOM _____
7.5	<p>UF = 5 Different Address Interrogate with Uplink Format UF=5 interrogations that have an address different than that of the unit under test. Verify no reply occurs other than normal DF=11 squitter transmissions. Conduct this test for the bottom antenna port only and at a convenient input signal level.</p>	BOTTOM _____
7.6	<p>UF = 21/DF = 21 Interrogate with Uplink Format UF=21 interrogations. Verify that the downlink response is DF=21. Conduct this test for bottom antenna port only and at a convenient input signal level.</p>	BOTTOM _____
7.7	<p>UF = 0, Max Airspeed Interrogate with Uplink Format UF=0 interrogations. Verify that the MAX AIR SPEED bits independently toggle in the downlink response of DF=0 when discrete pins P2-43, 44, 45 are switched. Conduct this test for bottom antenna port only and at a convenient input signal level.</p>	BOTTOM _____
7.8	<p>UF = 11, Low-Level Interrogate with Uplink Format UF=11 interrogations that have an input signal level at MTL or -76 dBm. Trigger the scope from the generator output of the IFR. Connect the transmitter jack of the IFR to the vertical scope channel. Use the delayed sweep function of the scope to view the first reply pulse with a horizontal rate of 50 ns/div. Verify the jitter of the pulse does not exceed 160 ns total (± 80 ns.).</p>	<p style="text-align: right;">Signal level (dBm)</p> <p style="text-align: center;">-76 -22</p> <p>BOT _____ _____</p> <p>TOP _____ _____</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS									
8.0	<p>INTERFERENCE TEST Perform the following tests for UF=11 MODE-S interrogations at signal levels of -68 and -22 dBm. Inject an interference pulse of 0.80 μs duration, at a carrier frequency of 1030 MHz, but incoherent with the interrogation signal. Test the bottom antenna port for the TDR-94, and both antenna ports for the TDR-94D.</p> <p><u>NOTE:</u> For steps 8.1 and 8.2, the interference pulse can be coincident with a group of 3 or more phase transitions spaced 0.25 μs.</p>										
8.1	<p>Interference Level 3 dB Less Than Signal Level Verify that when the interference pulse overlays the MODE-S interrogation anywhere after the Sync Phase Reversal, the reply rate exceeds 50% if the interference amplitude is 3 dB less than the interrogation signal level.</p>	<p style="text-align: center;">Signal level (dBm)</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td style="text-align: center;">-68</td> <td style="text-align: center;">-22</td> </tr> <tr> <td>BOT</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>TOP</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		-68	-22	BOT	_____	_____	TOP	_____	_____
	-68	-22									
BOT	_____	_____									
TOP	_____	_____									
8.2	<p>Interference Level 9 dB Less Than Signal Level Verify that when the interference pulse overlays the MODE-S interrogation anywhere after the MODE-S P1 pulse leading edge, the reply rate is AT LEAST 90% if the interference amplitude is 9 dB less than the interrogation signal level.</p>	<p style="text-align: center;">Signal level (dBm)</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td style="text-align: center;">-68</td> <td style="text-align: center;">-22</td> </tr> <tr> <td>BOT</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>TOP</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		-68	-22	BOT	_____	_____	TOP	_____	_____
	-68	-22									
BOT	_____	_____									
TOP	_____	_____									
9.0	<p>SQUITTER TEST For this test, turn off the input interrogations.</p>										
9.1	<p>Dual Antenna Squitter Rate Ensure that squitter is generating a DF=11 (Acquisition Squitter) reply at an average rate of 1.0 Hz, alternating between the top and bottom antenna ports for the TDR-94D, and fixed on the bottom antenna port for the TDR-94.</p>	<p style="text-align: center;">_____ (check if okay)</p>									
9.2	<p>Single Antenna Squitter Rate Ensure that grounding the single antenna strap (by selecting single antenna active on the test computer) prevents squitter transmissions on the top antenna port, and that the bottom antenna port alone continues to squitter at a 1.0-Hz rate.</p> <p><u>NOTE:</u> Unit input power must be cycled to recognize the Single Antenna Strap discrete change.</p>	<p style="text-align: center;">_____ (check if okay)</p>									

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.3	Airborne Position Extended Squitter (-004 through -007 and -207 status TDR-94/94D)	
	a. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).	
	b. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1003/GRAPHIC 34-50-96-99B-021-A01. Each data parameter shall be updated at least once per second.	
	c. Verify that the transponder properly transmits an "Even_Second" DF=17 Extended Squitter transmission that has the exact structure for the "ME" field as shown in Figure 1003/GRAPHIC 34-50-96-99B-021-A01.	
	d. Verify that the transponder properly transmits the Airborne Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 second.	
	e. Verify that the transponder properly transmits the Airborne Position alternately from the top and bottom antenna ports for the TDR-94D and from the bottom antenna port only for the TDR-94.	
	f. Verify the transponder continues to transmit DF=11 Acquisition Squitters while continuing to transmit the Airborne Position Squitter Messages as specified in previous steps c, d, and e.	
	g. Maintain the data inputs as provided in step b with the exception that the UTC Time input should be changed to read as indicated in Figure 1003/GRAPHIC 34-50-96-99B-021-A01.	
	h. Verify that the transponder properly transmits an "Odd_Second" DF=17 Extended Squitter transmission that has the exact structure for the "ME" field shown in Figure 1003/GRAPHIC 34-50-96-99B-021-A01.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.3A	GPS Bus/Airborne Position Extended Squitter/Time Tag Verification (-108 status TDR-94/94D only)	
	a. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).	
	b. Ensure that neither Configuration Select discrete 0 or 1 (P1-28 or P1-17) are connected to ground.	
	c. Ensure that ARINC 429 label 203 is not present on the selected Altitude Input Bus.	
	d. Provide the transponder with a GPS Time Tag signal via the GPS Time Tag input (P2-37 high, P2-38 low). The GPS Time Tag signal is a differential (0-5 Vdc) 1 ms pulse that repeats once per second.	
	e. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1004/GRAPHIC 34-50-96-99B-022-A01. Each data parameter must be updated at least one time each second.	
	f. Verify that the transponder properly transmits an Even-Second DF=17 Extended Squitter transmission that has the exact structure for the "ME" field indicated in Figure 1004/GRAPHIC 34-50-96-99B-022-A01.	
	g. Verify that the transponder properly transmits the Airborne Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 seconds.	
	h. Verify that the transponder properly transmits the Airborne Position alternately from the top and bottom antenna ports of the TDR-94D and from the bottom antenna port only of the TDR-94.	
	i. Verify that the transponder continues to transmit DF=11 Acquisition Squitters while continuing to transmit the Airborne Position Squitter messages indicated in steps f, g, and h. above.	
	j. Verify that the transponder properly transmits an Odd-Second DF=17 Extended Squitter transmission that has the exact structure for the "ME" field indicated in Figure 1004/GRAPHIC 34-50-96-99B-022-A01.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.3B	<p>GPS Bus/Airborne Position Extended Squitter/Time Tag Verification (-008 status TDR-94/94D only)</p> <p>a. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).</p> <p>b. Ensure that neither Configuration Select discrete 0 or 1 (P1-28 or P1-17) are connected to ground.</p> <p>c. Ensure that ARINC 429 label 203 is not present on the selected Altitude Input Bus.</p> <p>d. Provide the transponder with a GPS Time Tag signal via the GPS Time Tag input (P2-37 high, P2-38 low). The GPS Time Tag signal is a differential (0-5 Vdc) 1 ms pulse that repeats once per second.</p> <p>e. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1004/GRAPHIC 34-50-96-99B-022-A01 (for step e of test 9.3A). Each data parameter must be updated at least one time each second.</p> <p>f. Interrogate the transponder with the MODE-S interrogations indicated in Figure 1005/GRAPHIC 34-50-96-99B-023-A01 to request BDS register 0.5.</p> <p>g. Verify that the transponder responds properly with two DF=20 replies that have the exact structures for the "MB" field indicated in Figure 1005/GRAPHIC 34-50-96-99B-023-A01.</p> <p>h. Repeat step f. as necessary.</p> <p>i. Verify that the transponder responds properly with two DF=20 replies that have the exact structures for the "MB" field indicated in Figure 1005/GRAPHIC 34-50-96-99B-023-A01.</p> <p><u>NOTE:</u> Steps h. and i. may have to be repeated to get an odd encoding since the transponder alternates the encoding of latitude and longitude data on odd and even intervals at rates of either 100 or 200 ms.</p>	
9.3C	GPS Bus / Airborne Position Extended Squitter / Time Tag Verification (-408/-409)	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	a. Ensure that both Air/Ground Discrete #1 (P2-53) and Air/Ground Discrete #2 (P1-27) are NOT connected to ground (i.e., establish the airborne state).	
	b. Ensure that both Configuration Select "0" (P1-28) and Configuration Select "1" (P1-17) are NOT connected to ground.	
	c. Ensure that there is no Arinc 429 Label 203 present on the selected Altitude Input Bus.	
	d. Provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low). The GPS time tag signal shall be a differential (0 –5 vdc) 1 millisecond pulse, at a repetition rate of 1 per second.	
	e. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1018/GRAPHIC 34-50-96-99B-089-A01. Each data parameter shall be updated at least once per second.	
	f. Verify that the transponder properly transmits an "Even-Second" DF=17 Extended Squitter transmission having the exact structure for the "ME" field indicated in Figure 1018/GRAPHIC 34-50-96-99B-089-A01. <u>NOTE:</u> The single Antenna Bit (RF bit 40) will be set to a "0" for the TDR-94D and a "1" for the TDR-94.	
	g. Verify that the transponder properly transmits the Airborne Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 seconds (i.e., 0.5 +/-0.1 seconds).	
	h. Verify that the transponder properly transmits the Airborne Position alternately from the top and bottom antenna ports for the TDR-94D and from the bottom antenna only for the TDR-94.	
	i. Verify that the transponder continues to transmit DF=11 Acquisition Squitters while continuing to transmit the Airborne Position Squitter Messages as specified steps f, g, and h.	
	j. Verify that the transponder properly transmits an "Odd-Second" DF=17 Extended Squitter transmission having the exact structure for the "ME" field indicated in Figure 1018/GRAPHIC 34-50-96-99B-089-A01.	
9.3D	GPS Bus / Airborne Position Extended Squitter / Time Tag Verification (-308, -309 ONLY)	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	a. Ensure that both Air/Ground Discrete #1 (P2-53) and Air/Ground Discrete #2 (P1-27) are NOT connected to ground (i.e., establish the airborne state).	
	b. Ensure that both Configuration Select "0" (P1-28) and Configuration Select "1" (P1-17) are NOT connected to ground.	
	c. Ensure that there is no Arinc 429 Label 203 present on the selected Altitude Input Bus.	
	d. Provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low). The GPS time tag signal shall be a differential (0 –5 vdc) 1 millisecond pulse, at a repetition rate of 1 per second.	
	e. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1019/GRAPHIC 34-50-96-99B-090-A01. Each data parameter shall be updated at least once per second.	
	f. Interrogate the transponder with the Mode-S interrogation indicated in Figure 1019/GRAPHIC 34-50-96-99B-090-A01 to request BDS Register 0,5.	
	<p>g. Verify that the transponder responds properly with two DF=20 replies containing the exact structures for the "MB" field indicated in Figure 1019/GRAPHIC 34-50-96-99B-090-A01.</p> <p><u>NOTE:</u> The single Antenna Bit (RF bit 40) will be set to a "0" for the TDR94D and a "1" for the TDR-94.</p> <p><u>NOTE:</u> Steps f and g may need to be repeated in order to get an even encoding since the transponder is alternating encoding of latitude and longitude data on odd and even intervals at rates of either 100 or 200 milliseconds.</p>	
	h. Repeat step f as needed.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	<p>i. Verify that the transponder responds properly with two DF=20 replies containing the exact structures for the "MB" field indicated in Figure 1019/GRAPHIC 34-50-96-99B--A01.</p> <p><u>NOTE:</u> The single Antenna Bit (RF bit 40) will be set to a "0" for the TDR94D and a "1" for the TDR-94.</p> <p><u>NOTE:</u> Steps h and i may need to be repeated in order to get an even encoding since the transponder is alternating encoding of latitude and longitude data on odd and even intervals at rates of either 100 or 200 milliseconds.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.4	Acquisition Squitter Inhibit (-004 through -007 and -207 status TDR-94/94D)	
	a. Connect the Acquisition Squitter Inhibit (F) Discrete (P1-26) to ground. Verify that the transponder ceases to transmit DF=11 Acquisition Squitter messages but continues to transmit either airborne or Surface Position Squitter DF=17 messages.	
	b. Set the Acquisition Squitter Inhibit (F) discrete (P1-26) to open before continuing to the next step.	
9.5	Surface Position Extended Squitter (-004 through -007 and -207 status TDR-94/94D)	
	a. Connect either Air/Ground Discrete #1 (P2-53) or Air/Ground Discrete #2 (P1-27) to ground (i.e., establish the surface state).	
	b. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1006/GRAPHIC 34-50-96-99B-024-A01 . Each data parameter is updated at least once per second.	
	c. Verify that the transponder properly transmits an "Even_Second" DF=17 Extended Squitter transmission that has the exact structure for the "ME" fields as shown in Figure 1006/GRAPHIC 34-50-96-99B-024-A01.	
	d. Verify that the transponder properly transmits the Surface Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 second.	
	e. Verify that the transponder properly transmits the Surface Position alternately from the top antenna port for the TDR-94D and from the bottom antenna port only for the TDR-94.	
	f. Verify the transponder continues to transmit DF=11 Acquisition Squitters while continuing to transmit the Surface Position Squitter Messages indicated in steps c, d, and e.	
	g. Maintain the data inputs as provided in step b with the exception that the UTC Time input should be changed to read as shown in Figure 1006/GRAPHIC 34-50-96-99B-024-A01.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	h. Verify that the transponder properly transmits an "Odd_Second" DF=17 Extended Squitter transmission that has the exact structure for the "ME" field as shown in Figure 1006/GRAPHIC 34-50-96-99B-024-A01.	
9.5A	GPS Bus/Surface Position Extended Squitter/Time Tag Verification (-108 status TDR-94/94D only)	
	a. Connect either air/ground discrete #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes the surface state).	
	b. Ensure that neither configuration select discrete 0 or 1 (P1-28 or P1-17) are connected to ground.	
	c. Provide the transponder with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 high, P2-38 low). The GPS Time Tag signal is a differential (0-5 Vdc) 1 ms pulse, that repeats once per second.	
	d. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1007/GRAPHIC 34-50-96-99B-025-A01. Each data parameter must be updated at least one time each second.	
	e. Verify that the transponder properly transmits an Even-Second DF=17 Extended Squitter Transmission that has the exact structure for the "ME" field indicated in Figure 1007/GRAPHIC 34-50-96-99B-025-A01.	
	f. Verify that the transponder properly transmits the Surface Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 seconds.	
	g. Verify that the transponder properly transmits the Surface Position from the top antenna port only of the TDR-94D and from the bottom antenna port only of the TDR-94.	
	h. Verify that the transponder does not transmit DF=11 Acquisition Squitters while transmitting the Surface Position Squitter Messages indicated in steps e, f, and g.	
	i. Do not provide the transponder with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 high, P2-38 low).	
j. Verify that the transponder properly transmits an Odd-Second DF=17 Extended Squitter transmission that has the exact structure for the "ME" field indicated in Figure 1007/GRAPHIC 34-50-96-99B-025-A01.		

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.5B	<p>GPS Bus/Airborne Surface Extended Squitter/Time Tag Verification (-008 status TDR-94/94D only)</p> <p>a. Connect either air/ground discrete #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes the surface state).</p> <p>b. Ensure that neither configuration select discrete 0 or 1 (P1-28 or P1-17) are connected to ground.</p> <p>c. Provide the transponder with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 high, P2-38 low). The GPS Time Tag signal is a differential (0-5 Vdc) 1 ms pulse, that repeats once per second.</p> <p>d. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1007/GRAPHIC 34-50-96-99B-025-A01 (for step d of test 9.5A). Each data parameter must be updated at least one time each second.</p> <p>e. Interrogate the transponder with the MODE-S interrogations indicated in Figure 1008/GRAPHIC 34-50-96-99B-026-A01 to request BDS register 0,6.</p> <p>f. Verify that the transponder responds properly with two DF=20 replies that have the exact structures for the "MB" field indicated in Figure 1008/GRAPHIC 34-50-96-99B-026-A01.</p> <p>g. Do not provide the transponder with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 high, P2-38).</p> <p>h. Repeat step e. as necessary.</p> <p>i. Verify that the transponder responds properly with two DF=20 replies that have the exact structure for the "MB" field in Figure 1008/GRAPHIC 34-50-96-99B-026-A01.</p> <p><u>NOTE:</u> Steps h and i may have to be repeated to get an odd encoding since the transponder alternates the encoding of latitude and longitude data on odd and even intervals at rates of either 100 or 200 ms.</p>	
9.5C	GPS Bus / Surface Position Extended Squitter / Time Tag Verification/ (-408/-409)	
	a. Connect either Air/Ground Discrete #1 (P2-53) or Air/Ground Discrete #2 (P1-27) to ground (i.e., establish the surface state).	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	b. Ensure that both Configuration Select "0" (P1-28) and Configuration Select "1" (P1-17) are NOT connected to ground.	
	c. Provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low). The GPS time tag signal shall be a differential (0 –5 vdc) 1 millisecond pulse, at a repetition rate of 1 per second.	
	d. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1020/GRAPHIC 34-50-96-99B-091-A01. Each data parameter shall be updated at least once per second.	
	e. Verify that the transponder properly transmits an "Even-Second" DF=17 Extended Squitter transmission having the exact structure for the "ME" field indicated in Figure 1020/GRAPHIC 34-50-96-99B-091-A01.	
	f. Verify that the transponder properly transmits the Surface Position Message at random intervals that are uniformly distributed over the range from 0.4 to 0.6 seconds (i.e., 0.5 +/-0.1 seconds).	
	g. Verify that the transponder properly transmits the Surface Position from the top antenna port only for the TDR-94D and from the bottom antenna only for the TDR-94.	
	h. Verify that the transponder does not transmit DF=11 Acquisition Squitters while transmitting the Surface Position Squitter Messages as specified steps e, f, and g.	
	i. Do NOT provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low).	
	j. Verify that the transponder properly transmits an "Odd-Second" DF=17 Extended Squitter transmission having the exact structure for the "ME" field Figure 1020/GRAPHIC 34-50-96-99B-091-A01.	
9.5D	GPS Bus / Surface Position Extended Squitter / Time Tag Verification (-308, -309 ONLY)	
	a. Connect either Air/Ground Discrete #1 (P2-53) or Air/Ground Discrete #2 (P1-27) to ground (i.e., establish the surface state).	
	b. Ensure that both Configuration Select "0" (P1-28) and Configuration Select "1" (P1-17) are NOT connected to ground.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	c. Provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low). The GPS time tag signal shall be a differential (0 –5 vdc) 1 millisecond pulse, at a repetition rate of 1 per second.	
	d. Via the GPS/GNSS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1021/GRAPHIC 34-50-96-99B-092-A01. Each data parameter shall be updated at least once per second.	
	e. Interrogate the transponder with the Mode-S interrogation indicated in Figure 1021/GRAPHIC 34-50-96-99B-092-A01 to request BDS Register 0,6.	
	f. Verify that the transponder responds properly with two DF 20 replies containing the exact structures for the “MB” field indicated in Figure 1021/GRAPHIC 34-50-96-99B-092-A01. <u>NOTE:</u> Steps e and f may need to be repeated in order to get an even encoding since the transponder is alternating encoding of latitude and longitude data on odd and even intervals at rates of either 100 or 200 milliseconds.	
	g. Do NOT provide the transponder unit with a GPS Time Tag signal via the GPS Time Tag inputs (P2-37 High, P2-38 Low).	
	h. Repeat step e as needed.	
	i. Verify that the transponder responds properly with two DF 20 replies containing the exact structures for the “MB” field indicated in Figure 1021/GRAPHIC 34-50-96-99B-092-A01.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.6	<p>FMS/INS Primary Data(-004 through -007 and -207 status TDR-94/94D)</p> <p>a. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).</p> <p>b. Via the FMS/IRS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1009/GRAPHIC 34-50-96-99B-027-A01. Each data parameter is updated at least once per second.</p> <p>c. Via the selected ARINC-429 Altitude Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1009/GRAPHIC 34-50-96-99B-027-A01. Each data parameter is updated at least once per second.</p> <p>d. Connect the IRS ENABLE (F) Discrete (P1-17) to ground to select the FMS/IRS input as the primary navigation data source.</p> <p>e. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission that has the exact structure for the "ME" field shown in Figure 1009/GRAPHIC 34-50-96-99B-027-A01.</p>	
9.6A	<p>FMS/INS Primary Data (-008 and -108 status TDR-94/94D only)</p> <p>a. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).</p> <p>b. Ensure that all GPS labels are removed from the GPS Input Data Bus.</p> <p>c. Via the FMS/IRS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1010/GRAPHIC 34-50-96-99B-028-A01. Each data parameter must be updated at least once per second.</p> <p>d. Via the selected ARINC-429 Altitude Input Data Bus, provide the transponder with the appropriate label and data indicated in Figure 1010/GRAPHIC 34-50-96-99B-028-A01. Each data parameter must be updated at least once per second.</p> <p>e. Interrogate the transponder with the MODE-S interrogation indicated in Figure 1010/GRAPHIC 34-50-96-99B-028-A01 to request BDS register 0,5.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.6A (Cont)	f. Verify that the transponder responds properly with two DF=20 replies that have the exact structure for the "MB" field in Figure 1010/GRAPHIC 34-50-96-99B-028-A01. <u>NOTE:</u> It may be necessary to repeat steps e. and f. to get an even encoding since the transponder alternates the encoding of latitude and longitude data on odd and even intervals at rates of either 100 and 200 ms.	
	g. Repeat step e. as necessary.	
	h. Verify that the transponder responds properly with two DF=20 replies that have the exact structures for the "MB" field in Figure 1010/GRAPHIC 34-50-96-99B-028-A01. <u>NOTE:</u> It may be necessary to repeat steps g and h to get an even encoding since the transponder alternates the encoding of latitude and longitude data on odd and even intervals at rates of either 100 and 200 ms.	
	i. Remove ARINC-429 labels 310, 311, and 313 from the FMS/IRS Input Data Bus.	
9.7	Aircraft Identification Squitter (-004 through -007 and -207 status TDR-94/94D)	
	a. Ensure that Ground Speed Data provided to the transponder via either the GPS/GNSS or FMS/IRS Input Data Buses is set to 0.	
	b. Connect either Air/Ground Discrete #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes the surface state).	
	c. Verify that TYPE_3 (F) (P1-23) discrete input is in the open-circuit state in order to select Aircraft Type Set A.	
	d. Connect TYPE_2 (F) and TYPE_0 (F) discrete inputs (P1-22 and P1-20) to ground to select Aircraft Type 5, (Heavy, >300,000 lbs).	
	e. Via the selected Control Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1011/GRAPHIC 34-50-96-99B-029-A01. Each data parameter must be updated at least once per second.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.7 (Cont)	f. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission that has the exact structure for the "ME" field indicated in Figure 1011/GRAPHIC 34-50-96-99B-029-A01.	
	g. Verify that the transponder properly transmits the Aircraft Identification Message that has same "ME" field given in step f at random intervals that are uniformly distributed over the range from 9.6 to 10.4 seconds.	
	h. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).	
	i. Verify that the transponder properly transmits the Aircraft Identification Message that has same "ME" field given in step f at random intervals that are uniformly distributed over the range from 4.8 to 5.2 seconds.	
9.7A	Aircraft Identification Squitter (-108 status TDR-94/94D only)	
	a. Ensure that Ground Speed Data provided to the transponder via the GPS/GNSS or FMS/IRS Input Data Buses is set to 0 or not available.	
	b. Connect either Air/Ground Discrete #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes the surface state).	
	c. Verify that the TYPE_3 (F) discrete input (P1-23) is in the open-circuit state to select Aircraft Type Set A.	
	d. Connect TYPE_2 (F) and TYPE_0 (F) discrete inputs (P1-22 and P1-20) to ground to select Aircraft Type 5 (greater than 300,000 pounds).	
	e. Via the selected Control Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1012/GRAPHIC 34-50-96-99B-030-A01. Each data parameter must be updated at least once per second.	
	f. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission that has the exact structure for the "ME" field in Figure 1012/GRAPHIC 34-50-96-99B-030-A01.	
	g. Connect TYPE_3 (F) discrete input (P-23) to ground to select Aircraft Type Set B.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.7A (Cont)	h. Connect TYPE_1 (F) discrete input (P1-21) to ground and verify that TYPE_2 (F) and TYPE_0 (F) discrete inputs (P1-22 and P1-20) are in the open-circuit state to select Aircraft Type 2 (lighter-than-air).	
	i. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission that has the exact structure for the "ME" field in Figure 1012/GRAPHIC 34-50-96-99B-030-A01.	
	j. Verify that the transponder properly transmits the Aircraft Identification Message that has the "ME" field from step i at random intervals that are uniformly distributed over the range from 9.6 to 10.4 seconds.	
	k. Ensure that neither Air/Ground Discrete #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).	
	l. Verify that the transponder properly transmits the Aircraft Identification Message that has the "ME" field from step i at random intervals that are uniformly distributed over the range from 4.8 to 5.2 seconds.	
9.7B	Aircraft Identification Message (-008 status TDR-94/94D only)	
	a. Ensure that Ground Speed Data provided to the transponder via the GPS/GNSS or FMS/IRS Input Data Buses is set to 0 or not available.	
	b. Connect either Air/Ground Discrete #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes the surface state).	
	c. Verify that the TYPE_3 (F) discrete input (P1-23) is in the open-circuit state to select Aircraft Type Set A.	
	d. Connect TYPE_2 (F) and TYPE_0 (F) discrete inputs (P1-22 and P1-20) to ground to select Aircraft Type 5 (greater than 300,000 pounds).	
	e. Via the selected Control Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1012/GRAPHIC 34-50-96-99B-030-A01 (for step e of test 9.7A). Each data parameter must be updated at least once per second.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.7B (Cont)	f. Interrogate the transponder with the MODE-S interrogations indicated Figure 1013/GRAPHIC 34-50-96-99B-031-A01 to request BDS register 0, 8.	
	g. Verify that the transponder responds properly with a DF=20 reply that has the exact structure for the "MB" field in Figure 1013/GRAPHIC 34-50-96-99B-031-A01.	
	h. Connect the TYPE_3 discrete input (P1-23) to ground to select Aircraft Type Set B.	
	i. Connect the TYPE_1 (F) discrete input (P1-21) to ground and verify that the TYPE_2 (F) and TYPE_0 (F) discrete inputs (P1-22 and P1-20) are both in the open-circuit state to select Aircraft Type 2 (lighter-than-air).	
	j. Repeat step f.	
	k. Verify that the transponder responds properly with a DF=20 reply that has the exact structure for the "MB" field in Figure 1013/GRAPHIC 34-50-96-99B-031-A01.	
9.7C	Aircraft Identification Squitter (-408/-409)	
	a. Ensure that Ground Speed Data provided to the transponder via either the GPS/GNSS or FMS/IRS Input Data buses is set to ZERO or is NOT Available.	
	b. Connect either Air/Ground Discrete #1 (P2-53) or Air/Ground Discrete #2 (P1-27) to ground (i.e., establish the surface state).	
	c. Verify that TYPE_3 (F) (P1-23) discrete input is in the open-circuit state in order to select Aircraft Type Set A.	
	d. Connect TYPE_2 (F) (P1-22) and TYPE_0 (F) (P1-20) discrete inputs to ground in order to select Aircraft Type 5, i.e., Heavy (>300,000 lbs.).	
	e. Via the selected Control Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1022/GRAPHIC 34-50-96-99B-093-A01. Each data parameter shall be updated at least once per second. <u>NOTE:</u> All characters are set equal to the ICAO ANNEX 10 Character "U".	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	f. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission having the exact structure for the "ME" field indicated in Figure 1022/GRAPHIC 34-50-96-99B-093-A01.	
	g. Connect TYPE_3 (F) (P1-23) discrete input to ground in order to Select Aircraft Type Set B.	
	h. Connect TYPE_1 (F) (P1-21) discrete input to ground and verify that TYPE_2 (F) (P1-22) and TYPE_0 (F) (P1-20) are in the open-circuit state in order to Select	
	i. Verify that the transponder properly transmits a DF=17 Extended Squitter transmission having the exact structure for the "ME" field indicated in Figure 1022/GRAPHIC 34-50-96-99B-093-A01.	
	j. Verify that the transponder properly transmits the Aircraft Identification Message having the "ME" field given in step f. at random intervals that are uniformly distributed over the range from 9.6 to 10.4 seconds (i.e., 10.0+/- 0.4 seconds).	
	k. Ensure that both Air/Ground Discrete #1 (P2-53) and Air/Ground Discrete #2 (P1-27) are NOT connected to ground (i.e., establish the airborne state).	
	l. Verify that the transponder properly transmits the Aircraft Identification Message having the "ME" field given in step f. at random intervals that are uniformly distributed over the range from 4.8 to 5.2 seconds (i.e., 5.0 +/- 0.2 seconds).	
9.7D	Aircraft Identification Message -308, -309 ONLY	
	a. Ensure that Ground Speed Data provided to the transponder via either the GPS/GNSS or FMS/IRS Input Data buses is set to ZERO or is NOT Available.	
	b. Connect either Air/Ground Discrete #1 (P2-53) or Air/Ground Discrete #2 (P1-27) to ground (i.e., establish the surface state).	
	c. Verify that TYPE_3 (F) (P1-23) discrete input is in the open-circuit state in order to select Aircraft Type Set A.	
	d. Connect TYPE_2 (F) (P1-22) and TYPE_0 (F) (P1-20) discrete inputs to ground in order to select Aircraft Type 5, i.e., Heavy (>300,000 lbs.).	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	e. Via the selected Control Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1023/GRAPHIC 34-50-96-99B-094-A01. Each data parameter shall be updated at least once per second.	
	f. Interrogate the transponder with the Mode-S interrogation indicated in Figure 1023/GRAPHIC 34-50-96-99B-094-A01 to request BDS Register 0,8.	
	g. Verify that the transponder responds properly with a DF20 reply containing the exact structure for the "MB" field indicated in Figure 1023/GRAPHIC 34-50-96-99B-094-A01.	
	h. Connect TYPE_3 (F) (P1-23) discrete input to ground in order to Select Aircraft Type Set B.	
	i. Connect TYPE_1 (F) (P1-21) discrete input to ground and verify that TYPE_2 (F) (P1-22) and TYPE_0 (F) (P1-20) are in the open-circuit state in order to Select Aircraft Type 2, i.e., Lighter-than-Air.	
	j. Repeat Step f	
	k. Verify that the transponder responds properly with a DF20 reply containing the exact structure for the "MB" field indicated in Figure 1023/GRAPHIC 34-50-96-99B-094-A01.	
9.8	AIS/ADSS Primary Data (-008 and -108 status TDR-94/94D)	
	a. Ensure that neither Air/Ground discrete inputs #1 or #2 (P2-53 or P1-27) are connected to ground (i.e., establishes the airborne state).	
	b. Ensure that all GPS labels are removed from the GPS Input Data Bus.	
	c. Ensure that all GPS labels are removed from the FMS/IRS Input Data Bus.	
	d. Ensure that Configuration Select S0 discrete input (P1-28) is in the open-circuit state.	
	e. Connect Configuration Select S1 discrete input (P1-17) to ground to select configuration 2.	
	f. Via the AIS/ADS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1014/GRAPHIC 34-50-96-99B-032-A01. Each data parameter must be updated at least once per second.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	g. Interrogate the transponder with the MODE-S interrogations indicated in Figure 1014/GRAPHIC 34-50-96-99B-032-A01 to request BDS register 0,5.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
9.8 (Cont)	h. Verify that the transponder responds properly with DF=20 replies that have the exact structures for the "MB" field in Figure 1014/GRAPHIC 34-50-96-99B-032-A01.	
9.8B	AIS/ADSS Primary Data (-308, -309, -408, -409)	
	a. Ensure that both Air/Ground Discrete #1 (P2-53) and Air/Ground Discrete #2 (P1-27) are NOT connected to ground (i.e., establish the airborne state).	
	b. Ensure that all GPS labels are removed from the GPS Input Data Bus.	
	c. Ensure that all GPS labels are removed from the FMS IRS Input Bus.	
	d. Ensure that Configuration Select 'S0' (P1-28) discrete input is in the open-circuit state.	
	e. Connect Configuration Select 'S1' (P1-17) discrete to ground in order to select Configuration 2.	
	f. Via the AIS/ADS Input Data Bus, provide the transponder with the appropriate labels and data indicated in Figure 1024/GRAPHIC 34-50-96-99B-095-A01. Each data parameter shall be updated at least once per second.	
	g. Interrogate the transponder with the Mode-S interrogation indicated in Figure 1024/GRAPHIC 34-50-96-99B-095-A01 to request BDS Register 0,5.	
	h. Verify that the transponder responds properly with DF=20 replies containing the exact structures for the "MB" field indicated in Figure 1024/GRAPHIC 34-50-96-99B-095-A01.	
9.9	Illegal Configuration Select Check (-008 , -108, -308, -309, -408, and -409 status TDR-94/94D only).	
	a. Do not change the existing settings from Test 9.8.	
	b. Connect Configuration Select S0 discrete input (P1-28) to ground to select configuration 3.	
	c. Verify bit 14 in label 353 on the TDR Output Bus is set to 1.	
	d. Ensure that the Configuration Select S0 and S1 discrete inputs (P1-28 and P1-17) are both set to the open-circuit state to select configuration 0 before you continue to the next test.	
10.0	ATCRBS LIMITING	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
	Test the bottom antenna port for the TDR-94, and both antenna ports for the TDR-94D.	
10.1	500 Hz Rate Interrogate with MODE-C at a 500-Hz rate with an input level of -75 dBm. Verify that the reply rate is AT LEAST 90%.	TOP BOTTOM _____ (x) _____ (x)
10.2	750 Hz Rate Interrogate with MODE-C at a 750-Hz rate and adjust the input level to -45 dBm. Verify that the average reply rate is LESS THAN 90%.	TOP BOTTOM _____ (x) _____ (x)
11.0	STANDBY/ON CROSS-FEED	
	For these tests, the Burst Enable strap, P2-59, must be grounded (set to active). The input (P1-15) "ground" state must be verified at 2.0 V dc; additional tests may be conducted at 0 to 2.0 V dc. The input "open" state must be verified at 15 V dc; additional testing may be conducted using an open circuit input. The output (P1-30) "high impedance" state must be verified to sink less than 100 μ A from a > +20 volt source, and its "low-impedance" state must be verified to sink 1.0 ma at an output level less than 1.0 V dc.	
11.1	High Impedance State Test Set STBY/ON XF IN to the active state (ground P1-15) and verify that STBY/ON XF OUT (P1-30) is in a high-impedance state. Also verify the unit is in Standby Mode and does not respond to interrogations. STBY/ON XF OUT HIGH IMPEDANCE Unit is in standby.	_____ _____ _____ (x) _____ (x)
11.2	Low Impedance State Test Set STBY/ON XF IN to the inactive state (P1-15 open circuit) and verify that STBY/ON XF OUT (P1-30) is in a low-impedance state. Also verify the unit is active and responds to interrogations in normal fashion. STBY/ON XF OUT HIGH IMPEDANCE Unit is in active.	_____ _____ _____ (x) _____ (x)
12.0	FAIL-WARNING REQUIREMENTS	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
12.1	<p>Bad MODE-S Discrete Address Input Remove power from the UUT and ground all MODE-S Discrete Address inputs. Restore power to the UUT. After initialization has been completed, ensure that Fail-Warning output, P1-31, is active low (less than 1.5 V dc).</p>	
12.2	<p>Restored MODE-S Discrete Address Input Remove power from the UUT and set MODE-S Discrete Address Inputs for a valid address, i.e. one where all such inputs are not the same (ground or open). Restore power to the UUT and after initialization has been completed, ensure that Fail-Warning output, P1-31, is set high (greater than 23 V dc when loaded with 140 ohms).</p> <p>Method: Interrogate the unit with MODE-S interrogations set for address 52525252. Set the computer strapping for a MODE-S UUT address of 52525252. Cycle the power and verify that the fail-warn light comes on. Set the computer strapping for a MODE-S UUT address of 00000000. Cycle the power and verify that the Fail warning light goes out. Reset the computer strapping for a MODE-S UUT address of 52525252 and cycle the power.</p> <p style="text-align: center;">Fail warning lamp on Switches off with a bad address</p>	<p style="text-align: center;">_____ (x) _____ (x)</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01



ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
13.0	MUTUAL SUPPRESSION REQUIREMENTS	
	<p>Ensure that a mutual suppression output pulse occurs that brackets any transmissions at an amplitude of 20 volts or more. Verify that a suppression pulse of 15 volts or more prevents ATCRBS decoding during that pulse's time interval. Verify decoder suppression for both top and bottom antenna ports on the TDR-94D, and only for the bottom antenna port on the TDR-94.</p> <p style="text-align: center;">Output pulse 20 or > volts ATCRBS suppression</p>	<p style="text-align: right;">___ (x)</p> <p>TOP ___ (x) BOT ___ (x)</p>
14.0	SELF TEST REQUIREMENTS (-004 through -008 status TDR-94/94D only)	
	<p>Ensure that the UUT initiates Self-Test by grounding the Self-Test Discrete, P2-54. Only one Self-Test cycle should be executed each time the P2-54 discrete input is grounded. Verify that the label 350 output word SSM code changes from 11 to 10 to 01 and back to 11 (normal operation). Transitions from 11 to 10 to 11 are also acceptable.</p> <p>Method: Switch the Air/ground discrete to ground. Use "Select card type" (31) from the computer menu to select CONTROL-ALT CARD TYPE. Use menu option (9), "Control Select Lines", to set the control to ARINC bus 0. Use menu option (36) "TDR Bus A", to change to ARINC label 350. Note the 350 word displayed on the computer screen. Set the Self-Test discrete to active and update the 350 word display by rapidly selecting option 11 three times and pushing the enter key. Verify that the third two-digit number in the 350 word changes from 60 to 40 to 20 then back to 60, or from 60 to 40 back to 60. Reset the Self-Test discrete to inactive.</p> <p><u>NOTE:</u> The 350 word may blank at the first update, if so repeat procedure.</p> <p style="text-align: center;">Unit executes a self test cycle</p>	<p style="text-align: right;">___ (x)</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
14A.0	<p>SIL Designator Requirements (-108, -308, -309, -408, -409 status TDR-94/94D only)</p> <p>a. Verify that the SIL Designator discrete input, P2-54 is in the open-circuit state.</p> <p>b. Interrogate to transponder with MODE-S interrogation as indicated in Figure 1015/GRAPHIC 34-50-96-99B-033-A01 to request BDS register 6,5 (Aircraft Operational Status).</p> <p>c. Verify that the transponder responds properly with a DF=20 reply that has the "MB" field indicated in Figure 1015/GRAPHIC 34-50-96-99B-033-A01.</p> <p>d. Connect the SIL Designator discrete input, P2-54, to ground to initiate a higher Surveillance Integrity Level.</p> <p>e. Interrogate the transponder with the MODE-S interrogations indicated in Figure 1015/GRAPHIC 34-50-96-99B-033-A01 to request BDS register 6,5.</p> <p>f. Verify that the transponder responds properly with a DF=20 reply that has the "MB" field indicated in Figure 1015/GRAPHIC 34-50-96-99B-033-A01.</p> <p>g. Remove the ground from SIL Designator discrete input, P2-54.</p>	
15.0	TDR-94D DIVERSITY TEST	
15.1	<p>Bottom Signal Greater Than Top Signal</p> <p>Interrogate into the top antenna port with a UF=11 MODE-S interrogation that has a signal level of -53 dBm. Interrogate into the bottom antenna port with a UF=11 signal at -50 dBm that is delayed not less than 100 ns from the top signal. Verify that the reply transmits on the bottom antenna port at a rate of AT LEAST 90%, and replies from the top antenna port are at a rate NOT GREATER than 10%.</p> <p style="text-align: center;">90% or > replies on the bottom antenna port, 10% or < on top antenna port</p>	____ (x)

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
15.2	<p>Top Signal Greater Than Bottom Signal Interrogate into the bottom antenna port with an UF=11 MODE-S signal at -53 dBm. Interrogate into the top antenna port with a UF=11 signal at -50 dBm that is delayed not less than 100 ns from the bottom signal. Verify that the reply transmits on the top antenna port at a rate of AT LEAST 90%, and replies from the bottom antenna port are NOT GREATER than 10%.</p> <p style="text-align: center;">90% or > replies on the bottom antenna port, 10% or < on top antenna port</p>	____ (x)
15.3	<p>Top Signal Leads Bottom Signal Interrogate into the top antenna port with a UF=11 MODE-S signal at -73 dBm. Interrogate into the bottom antenna port with a UF=11 signal at -50 dBm that is delayed not more than 350 ns from the top signal. Verify that the reply transmits on the top antenna port at a rate of AT LEAST 90%, and replies from the bottom antenna port are NOT GREATER than 10%.</p> <p style="text-align: center;">90% or > replies on the bottom antenna port, 10% or < on top antenna port</p>	____ (x)
15.4	<p>Bottom Signal Leads Top Signal Interrogate into the bottom antenna port with a UF=11 MODE-S signal at -73 dBm. Interrogate into the top antenna port with a UF=11 signal at -50 dBm that is delayed not more 350 ns from the bottom signal. Verify that the reply transmits on the bottom antenna port at a rate of AT LEAST 90%, and replies from the top antenna port are NOT GREATER than 10%.</p> <p style="text-align: center;">90% or > replies on the bottom antenna port, 10% or < on top antenna port</p>	____ (x)
16.0	I/O REQUIREMENTS	
	Ensure that the following tests meet the appropriate ARINC 429 or CSDB specification.	
16.1	<p>Comm-A/B I/O Set ADLP Present Discrete, P2-60, to its active state (ground). Verify that data can be received on the Comm A/B serial input port, P2-1 and P2-2. Also verify that data is transmitted on the Comm A/B serial output port, P2-3 and P2-4. Data may be transmitted at a low repetition rate.</p> <p style="text-align: center;">Comm-A/B I/O operation O.K.</p>	____ (x)

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.2	<p>ADLP Present Discrete (P2-60)</p> <p>Verify that when this discrete is ground, the Comm-A/B serial/output bus, P2-3 and P2-4, transmits appropriate ARINC 429 words at a 100 kbps rate.</p> <p style="text-align: center;">Present Discrete operation O.K.</p>	<p style="text-align: center;">____ (x)</p>
16.3	<p>TX/XT I/O Ports (Applies to TDR-94D only)</p> <p>Ensure that data can be received on the TX port, P2-9 and P2-10, and transmitted on the XT port, P2-11 and P2-12. Ensure that grounding the TCAS Select [F] Discrete input, P1-13, results in periodic transmissions on the XT bus. When the TCAS Select [F] discrete input is open, there should be no transmissions on the XT bus. Verify that the word transmissions have a bit rate of 100 kbps.</p> <p style="text-align: center;">Data can be received on the TX port. Data can be transmitted on the XT port. TCAS Select operation O.K.</p>	<p style="text-align: center;">____ (x) ____ (x) ____ (x)</p>
16.4	<p>Altitude Inputs</p> <p>a. Set the S-1403 function to 1 (ATCRBS). Set IFR display select to XPDR CODE. Set XPDR CODE switch on IFR to AC2 FEET. Set ARINC altitude on the test computer to output standard ARINC 429 on PORT 0. Set the altitude select on the computer menu for ARINC 429 altitude, PORT 0 Verify that the altitude data displayed on the IFR matches data being sent by the test computer.</p> <p style="text-align: center;">ARINC Altitude operation O.K.</p>	<p style="text-align: center;">____ (x)</p>
	<p>b. Set ARINC altitude on the test computer to output standard ARINC 429 on PORT 1. Verify the IFR does not display valid altitude. Set the altitude select on the computer menu for ARINC 429 altitude, PORT 1. Verify that the altitude data displayed on the IFR matches data being sent by the test computer.</p> <p style="text-align: center;">ARINC Altitude operation O.K.</p>	<p style="text-align: center;">____ (x)</p>

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.4 (Cont)	c. Set the test computer to output PLII altitude on PLII altitude PORT 0. Change the ARINC bus used for altitude data in the previous steps to ADLP. Verify the IFR does not display valid altitude. Set the altitude select on the computer menu for PLII altitude, PORT 0. Verify that the altitude data displayed on the IFR matches data being sent by the test computer. PLII Altitude operation O.K.	____ (x)
	d. Set the test computer to output PLII altitude on PLII altitude PORT 1. Verify the IFR does not display valid altitude. Set the altitude select on the computer menu for PLII altitude, PORT 1. Verify that the altitude data displayed on the IFR matches data being sent by the test computer. PLII Altitude operation O.K.	____ (x)
	e. Set the altitude select lines to GILLHAM. Verify the altitude displayed on the IFR matches what the test computer shows is being sent. GILLHAM Altitude operation O.K.	____ (x)
16.5	ARINC 429 Control Selection a. Select ARINC control. Use the PLII/A429 Control Select to set the control discretes for ARINC 0 input (ARINC 429 PORT 0). Set the ARINC control bus to PORT 0 on the test computer. Monitor label 350 on the TDR bus and verify that valid data is returned. ARINC 0 operation O.K.	____ (x)
	b. Set the control discretes for ARINC 1 input (ARINC 429 PORT 1). Verify that valid data is not returned. Set the ARINC control bus to PORT 1 on the test computer. Monitor label 350 on the TDR bus and verify that valid data is returned. ARINC 1 operation O.K.	____ (x)
	c. Set the control discretes for ARINC 2 input (ARINC 429 PORT 2). Verify that valid data is not returned. Set the ARINC control bus to PORT 2 on the test computer. Verify that valid data is returned. ARINC 2 operation O.K.	____ (x)

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.5 (Cont)	d. Set the Burst Enable to active and verify that burst data can be extracted from all three ports. Reset the burst enable discrete to inactive. Burst Enable discrete operation O.K.	____ (x)
16.6	CSDB/PLII Control Selection Set the CSDB (PLII)/A429 Control Select discrete to PLII (ground P2-56). Set the PLII output on the test computer to output data on the control bus (P2-31, 32). Verify that PLII echo is transmitted on PLII output bus (P2-23, 24), Option 40 on the computer. CSDB/A429 Control Select/CSDB operation O.K.	____ (x)
16.7	Source Ident Straps (P2-46 and P2-47) a. Connect P2-46 to P2-50 (common). Open circuit P2-47. Verify that the TDR output data reflects side two in the SDI bits if ARINC 429 configured, or SI bits if CSDB configured. Method A: Set SDI discretes to 1. Set PLII data to SDI 1 using option 39 on the computer. Verify unit responds with valid data on the PLII bus. Source Ident Straps operation O.K.	____ (x)
	b. Connect P2-47 to P2-50 (common). Open circuit P2-46. Verify that the TDR output data reflects side two in the SDI bits if ARINC 429 is configured, or SI bits if CSDB is configured. Method B: Set SDI discretes to 2. Verify no valid data is echoed on the PLII bus. Source Ident Straps operation O.K.	____ (x)
16.8	Self-Test Inhibit Discrete (P2-38 for -004, -005, -006, -007, -207 status TDR-94/94D or P1-19 for -008/-108, -308/-309/-408/-409 status TDR-94/94D) Verify that when this discrete input (P2-38 or P1-19) is grounded, the unit suspends monitoring and test functions associated with squitter generation. Reduce signal level to a low level that will not cause replies. Ensure that the IFR test set indicates squitter output. Switch the Self-Test inhibit discrete to active (ground). Verify squitter generation is suspended. Reset the Self-Test inhibit to inactive. Self-Test Inhibit Discrete operation O.K.	____ (x)

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.9	Air/Ground Discretes	
16.9.1	<p>Air/Ground Discrete #1 (P2-53)</p> <p>Ensure that grounding the Air/Ground Discrete #1, P2-53, sets bit 6 (vertical status) in DF=1 downlink replies to 1.</p> <p>Verify that transponder continues to reply to ATCRBS and MODE-S interrogations when the Air/Ground Discrete #1, P2-53, is connected to ground.</p> <p>Verify that bit 6 (Vertical Status) in DF= 0 downlink replies is set to 0 when the Air/Ground Discrete #1 is disconnected from ground.</p> <p style="text-align: center;">Air/Ground Discrete #1 operation O.K.</p>	____ (x)
16.9.2	<p>Air/Ground Discrete #2 (P1-27)</p> <p>Ensure that grounding the Air/Ground Discrete #2, P1-27, sets bit 6 (vertical status) in DF=0 downlink replies to 1.</p> <p>Verify that the transponder continues to reply properly to ATCRBS interrogations while the Air/Ground Discrete #2, P1-27, is connected to ground.</p> <p>Verify that transponder DOES NOT reply to ATCRBS interrogations while the Air/Ground Discrete #2, P1-27, is connected to ground.</p> <p>Verify that bit 6 (Vertical Status) in DF=0 downlink replies is set to 0 when the Air/Ground Discrete #2 is disconnected from ground.</p> <p style="text-align: center;">Air/Ground Discrete #2 operation O.K.</p>	____ (x)

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																		
16.10	<p>Auto Altitude Selection Test (-004 through -006 status TDR-94/94D)</p> <p><u>NOTE:</u> The Auto Altitude Selection test applies to -004 through -006 status TDR-94 and TDR-94D units only.</p> <p>a. Establish ARINC-429 Control for the UUT and ensure that the UUT is configured for altitude selections as follows:</p> <table border="0" data-bbox="267 594 893 798"> <thead> <tr> <th><u>PIN NAME</u></th> <th><u>PIN NUMBER</u></th> <th><u>CONDITION</u></th> </tr> </thead> <tbody> <tr> <td>CNTRL/ALT</td> <td>P1-14</td> <td>OPEN</td> </tr> <tr> <td>AS0</td> <td>P2-41</td> <td>GROUND</td> </tr> <tr> <td>AS1</td> <td>P2-42</td> <td>GROUND</td> </tr> <tr> <td>AUTO ALT SEL</td> <td>P1-28</td> <td>OPEN</td> </tr> <tr> <td>ALT PORT SEL</td> <td>P2-48</td> <td>OPEN</td> </tr> </tbody> </table> <p>Ensure that the Alternate Source Select Bit (bit 14) is "0" in the "031" control word provided to the UUT.</p> <p style="text-align: center;">Alternate Source Select bit is "0".</p>	<u>PIN NAME</u>	<u>PIN NUMBER</u>	<u>CONDITION</u>	CNTRL/ALT	P1-14	OPEN	AS0	P2-41	GROUND	AS1	P2-42	GROUND	AUTO ALT SEL	P1-28	OPEN	ALT PORT SEL	P2-48	OPEN	<p style="text-align: center;">_____ (x)</p>
<u>PIN NAME</u>	<u>PIN NUMBER</u>	<u>CONDITION</u>																		
CNTRL/ALT	P1-14	OPEN																		
AS0	P2-41	GROUND																		
AS1	P2-42	GROUND																		
AUTO ALT SEL	P1-28	OPEN																		
ALT PORT SEL	P2-48	OPEN																		
	<p>b. Connect a valid ARINC-429 Altitude source to Altitude Port B of the UUT (P2-29, 30). Select XPONDER MODE, AC2, on the IFR test set and interrogate the UUT with standard MODE-C ATCRBS interrogations. Verify that the altitude displayed by the IFR test set is "EEEE".</p> <p style="text-align: center;">Displayed altitude is "EEEE".</p>	<p style="text-align: center;">_____ (x)</p>																		
	<p>c. Connect Auto Alt Sel (P1-28) to ground and continue to interrogate the UUT with standard MODE-C ATCRBS interrogations. Verify that the altitude displayed by the IFR test set is the same as that provided by the altitude source connected to altitude Port B.</p> <p style="text-align: center;">Displayed altitude matches Port B source altitude.</p>	<p style="text-align: center;">_____ (x)</p>																		
16.10A	Configuration Select Discrettes (-008, -108, -308, -309, -408, -409 TDR-94/94D only)																			

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.10A.1	Configuration Select S0 (P1-28)	
	a. Verify that Configuration Select S0 and S1 discrete inputs P1-28 and P1-17 are in the open-circuit state to select configuration 0.	
	b. Via FMS/IRS Input Data Bus, provide the transponder with the appropriate label and data indicated in Figure 1016/GRAPHIC 34-50-96-99B-034-A01. Each data parameter must be updated at least once per second.	
	c. Interrogate the transponder with the MODE-S interrogations indicated in Figure 1016/GRAPHIC 34-50-96-99B-034-A01 to request BDS register 5,0.	
	d. Verify that the transponder responds properly with a DF=20 reply that has the "MB" field in Figure 1016/GRAPHIC 34-50-96-99B-034-A01.	
	e. Connect Configuration Select S0 discrete input P1-28 to ground to select configuration 1.	
	f. Interrogate the transponder with the MODE-S interrogation indicated in Figure 1016/GRAPHIC 34-50-96-99B-034-A01 to request BDS register 5,0.	
	g. Verify that the transponder responds properly with a DF=20 reply that has the "MB" field indicated in Figure 1016/GRAPHIC 34-50-96-99B-034-A01.	
	h. Remove the ground from Configuration Select S0 discrete input P1-28.	
	i. Remove ARINC label 335 from the FMS/IRS Data Input Bus.	
16.10A.2	Configuration Select S1 (P1-17)	
	a. Connect Configuration Select S1 discrete input P1-17 to ground to select configuration 2.	
	b. Verify that Altitude Select AS0 and AS1 discrete inputs P2-41 and P2-42 are in the open-circuit state.	
	c. Ensure that no GPS data is being applied to the transponder via the GPS Input Data Bus.	
	d. Via the FMS/IRS Input Data Bus, provide the transponder with the labels and data indicated in Figure 1017/GRAPHIC 34-50-96-99B-035-A01. Each data parameter must be updated at least once per second.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.10A.2 (Cont)	e. Interrogate the transponder with the MODE-S interrogations in Figure 1017/GRAPHIC 34-50-96-99B-035-A01 to request BDS register 0,5.	
	f. Verify that the transponder responds properly with a DF=20 reply that has the Type Code indicated in Figure 1017/GRAPHIC 34-50-96-99B-035-A01 for the "MB" field.	
	g. Remove the ground from Configuration Select S1 discrete input P1-17.	
	h. Interrogate the transponder with the MODE-S interrogation indicated in Figure 1017/GRAPHIC 34-50-96-99B-035-A01 to request BDS register 0,5.	
	i. Verify that the transponder responds properly with a DF=20 reply that has the Type Code for the "MB" field indicated in Figure 1017/GRAPHIC 34-50-96-99B-035-A01.	
16.11	Remote Ident Test	
	a. Ensure that the SPI IDENT (F) discrete input, P1-16, is in the open-circuit state. SPI IDENT (F) is in open-circuit state.	____ (x)
	b. Interrogate the UUT with standard ATCRBS MODE-A interrogations. Verify that the reply displayed on the IFR test set DOES NOT indicate "ID". IFR reply does not indicate "ID".	____ (x)
	c. Momentarily connect the SPI IDENT (F) discrete input, P1-16, to ground. Verify that the reply displayed on the IFR test set indicates "ID" for approximately 18 seconds. IFR reply indicates "ID" for approximately 18 sec.	____ (x)
16.12	FMS/IRS Lo/Hi Select Discrete (P1-24) (-008, -108, -308, -309, -408, -409 TDR-94/94D only)	
	a. Connect the FMS/IRS Lo/Hi Select input P1-24 to ground. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	b. Repeat FMS/INS Primary Data test 9.6A and verify high-speed operation of the FMS/INS Input Data Bus (P2-27, P2-28).	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
16.12 (Cont)	c. Remove the ground from FMS/INS Lo/Hi Select Discrete, P1-24. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	d. Repeat FMS/INS Primary Data test 9.6A and verify low-speed operation of the FMS/INS Input Data Bus (P2-27, P2-28)	
16.13	AIS/ADS Lo/Hi Select Discrete (P1-57) (-008, -108, -308, -309, -408, -409 TDR-94/94D only)	
	a. Connect the AIS/ADS Lo/Hi Select Discrete, P1-57 to ground. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	b. Repeat AIS/ADSS Primary Data test 9.8 and verify high-speed operation of AIS/ADS Input Data Bus (P2-39, P2-40).	
	c. Remove the ground from the AIS/ADS Lo/Hi Select Discrete, P1-24. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	d. Repeat AIS/ADSS Primary Data test 9.8 and verify low-speed operation of AIS/ADS Input Data Bus (P2-39, P2-40).	
16.14	GPS Lo/Hi Select Discrete (P1-18) (-008, -108, -308, -309, -408, -409 TDR-94/94D only)	
	a. Connect the GPS Lo/Hi Select Discrete, P1-18, to ground. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	b. Repeat GPS Bus/Airborne Position Extended Squitter test 9.3A (for -108 status TDR-94/94D), test 9.3B (for -008 status TDR-94/94D), test 9.3C (for -408, -409 status) or test 9.3D (for -308, -309 status) and verify high-speed operation of GPS Input Data Bus (P2-49, P2-50).	
	c. Remove the ground from GPS Lo/Hi Select Discrete, P1-18. Cycle UUT power off and then back on so that the transponder accepts the configuration change.	
	d. Repeat GPS Bus/Airborne Position Extended Squitter test 9.3A (for -108 status TDR-94/94D) or test 9.3B (for -008 status TDR-94/94D) and verify low-speed operation of GPS Input Data Bus P2-49, P2-50.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																																			
16.15	Altitude Port A/B Lo/Hi Select Discrete (P1-26) (-008, -108, -308, -309, -408, -409 TDR-94/94D only)																																				
	a. Connect Altitude Port A/B Lo Hi Select Discrete, P1-26, to ground. Cycle UUT power off and then back on so that the transponder accepts the configuration change.																																				
	b. Verify high-speed operation of the Altitude Port A Input Data Bus (P2-25, P2-26).																																				
	c. Remove the ground from Altitude Port A/B Lo/Hi Select Discrete, P1-26. Cycle UUT power off and then back on so that the transponder accepts the configuration change.																																				
	d. Verify low-speed operation of the Altitude Port A Input Data Bus (P2-25, P2-26).																																				
16.16	Maximum Airspeed Select Discretes (P2-43, P2-44, P2-45) (-008, -108, -308, -309, -408, -409 TDR-94/94D only)																																				
	a. Connect either of Air/Ground discrete inputs #1 or #2 (P2-53 or P1-27) to ground (i.e., establishes a surface state).																																				
	b. Verify on the TDR Output Bus (P2-15, P2-16) that bits 22 through 25 of ARINC label 276 are set correctly for the input states of the Maximum Airspeed Select Discretes as indicated below. UUT power must be cycled off and then back on each time the maximum airspeed configuration is changed.																																				
	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">P2-45</th> <th style="text-align: left;">P2-44</th> <th style="text-align: left;">P2-43</th> <th colspan="2" style="text-align: left;">LABEL 276</th> </tr> <tr> <th style="text-align: left;">MAX A/S</th> <th style="text-align: left;">MAX A/S</th> <th style="text-align: left;">MAX A/S</th> <th style="text-align: left;">MSB</th> <th style="text-align: left;">LSB</th> </tr> <tr> <th style="text-align: left;"><u>BIT 17</u></th> <th style="text-align: left;"><u>BIT 16</u></th> <th style="text-align: left;"><u>BIT 15</u></th> <th style="text-align: left;"><u>22</u></th> <th style="text-align: left;"><u>24</u></th> </tr> </thead> <tbody> <tr> <td>OPEN</td> <td>OPEN</td> <td>OPEN</td> <td>000</td> <td></td> </tr> <tr> <td>OPEN</td> <td>OPEN</td> <td>GROUND</td> <td>001</td> <td></td> </tr> <tr> <td>OPEN</td> <td>GROUND</td> <td>OPEN</td> <td>010</td> <td></td> </tr> <tr> <td>GROUND</td> <td>OPEN</td> <td>OPEN</td> <td>100</td> <td></td> </tr> </tbody> </table>	P2-45	P2-44	P2-43	LABEL 276		MAX A/S	MAX A/S	MAX A/S	MSB	LSB	<u>BIT 17</u>	<u>BIT 16</u>	<u>BIT 15</u>	<u>22</u>	<u>24</u>	OPEN	OPEN	OPEN	000		OPEN	OPEN	GROUND	001		OPEN	GROUND	OPEN	010		GROUND	OPEN	OPEN	100		
P2-45	P2-44	P2-43	LABEL 276																																		
MAX A/S	MAX A/S	MAX A/S	MSB	LSB																																	
<u>BIT 17</u>	<u>BIT 16</u>	<u>BIT 15</u>	<u>22</u>	<u>24</u>																																	
OPEN	OPEN	OPEN	000																																		
OPEN	OPEN	GROUND	001																																		
OPEN	GROUND	OPEN	010																																		
GROUND	OPEN	OPEN	100																																		

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
17.0	TRANSPONDER TESTS AND INSPECTIONS	
	<p>COMPLIANCE WITH CODE OF FEDERAL REGULATIONS (CFR), TITLE 14, CHAPTER 1, FEDERAL AVIATION ADMINISTRATION, DEPARTMENT OF TRANSPORTATION, PART 43, APPENDIX F-ATC TRANSPONDER TESTS AND INSPECTIONS.</p> <p>THE FOLLOWING TESTS OR NOTATIONS HAVE BEEN ADDED TO MORE EASILY DEMONSTRATE COMPLIANCE WITH CFR, TITLE 14, CHAPTER 1, PART 43, APPENDIX F, FOR RETURNING THE TDR-94/94D TRANSPONDER TO SERVICE.</p>	
17.1	<p>Radio Reply Frequency (Appendix F, Paragraph (a)(4))</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in step 2.1. of this procedure, and will not be repeated here.</p>	
17.2	<p>Suppression (Appendix F, Paragraph (b)(1))</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in step 4.3. of this procedure and will not be repeated here.</p> <p><u>NOTE:</u> RTCA DO-181 paragraph 2.2.5.1.a. and c. set the limits at 10% versus the 1% limit set by CFR, TITLE 14, CHAPTER 1, PART 43, APPENDIX F, Paragraph (b)(1).</p>	
17.3	<p>Suppression (Appendix F, Paragraph (b)(2))</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in step 4.2. of this procedure, and will not be repeated here.</p>	
17.4	<p>Receiver Sensitivity (Appendix F, Paragraph (c)(1))</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in step 1.1. of this procedure and will not be repeated here.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
17.5	<p>Receiver Sensitivity (Appendix F, Paragraph (c)(2))</p> <p>MTL is defined as the minimum interrogation power level which produces a reply rate of at least 90%.</p> <p>Interrogate the transponder with standard MODE-A interrogations, and verify that the MTL is between -75 and -79 dBm.</p> <p>Interrogate the transponder with standard MODE-C interrogations, and verify that the MTL is between -75 and -79 dBm. Verify that the difference between the MODE-A MTL and the MODE-C MTL does not exceed 1 dB.</p> <p>Difference between MODE-A MTL and MODE-C MTL is 1dB or less.</p>	<p>_____ (x)</p>
17.6	<p>Radio Frequency (RF) Peak Output Power (Appendix F, Paragraphs (d)(iii) and (d)(v))</p> <p>The requirement to demonstrate proper compliance with these paragraphs has been stated in step 2.2.A. of this procedure and will not be repeated here.</p>	
17.7	<p>MODE-S Diversity Transmission Channel Isolation Appendix F, Paragraph (e)</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in step 2.2.C. of this procedure and will not be repeated here.</p>	
17.8	<p>MODE-S Address (Appendix F, Paragraph (f))</p> <p>Ensure that some of the MODE-S Discrete Address inputs to the UUT are set to open circuit and some are shorted to ground. A MODE-S Address of all 0s, or all 1s, is NOT acceptable and will result in a Fail/Warn condition. Likewise, a MODE-S Address of all 0s or all 1s will result in the UUT remaining in the "STANDBY" mode.</p> <p><u>NOTE:</u> The MODE-S Address is binary, however, when using the IFR S-1403 and manual test software the MODE-S Address must be is entered in octal.</p> <p>If the Address is changed at this time, UUT power must be removed and then reapplied to make the TDR Transponder recognize and use the new address.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS																																																																						
17.8 (Cont)	<p>Interrogate the transponder with UF=4 interrogations using the same address as that provided to the UUT, and at a nominal rate of 50 per second. Verify that the transponder properly replies with DF=4 and with AT LEAST a 90% reply ratio.</p> <p>Interrogate the transponder with at least two UF=4 interrogations using addresses that are different than the discrete address provided to the UUT, at a nominal rate of 50 per second. Verify that the transponder does not reply to the interrogations.</p>																																																																							
17.9	<p>MODE-S Formats (Appendix F, Paragraph (g))</p> <p><u>PART A:</u> ALTITUDE/MODE-C/UF=4/UF=20</p> <p>Ensure that Gillham Altitude is selected via the Altitude Selects and set the discrete Gillham Altitude inputs as follows:</p> <table style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2"></th> <th colspan="12" style="text-align: center;">Gillham Altitude Bits</th> </tr> <tr> <th style="text-align: left;">BIT POSITION</th> <th></th> <th>D2</th> <th>D4</th> <th>A1</th> <th>A2</th> <th>A4</th> <th>B1</th> <th>B2</th> <th>B4</th> <th>C1</th> <th>C2</th> <th>C4</th> <th></th> </tr> </thead> <tbody> <tr> <td colspan="14" style="text-align: center;">-----</td> </tr> <tr> <td>Data:</td> <td></td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td></td> </tr> <tr> <td colspan="14">(49,950 to 50,050 feet)</td> </tr> </tbody> </table> <p>"1" indicates connection to ground (selected) "0" indicates open-circuited (not selected) Reference (Gillham code 2524).</p> <p>Interrogate the transponder with standard MODE-C interrogations. Verify that the transponder replies with the altitude value provided via the Gillham inputs.</p> <p>Interrogate the transponder with MODE-S UF=4 interrogations with the PC, RR, DI and SD fields set to 0, and the MODE-S address set the same as that provided to the transponder. Verify that the transponder replies with the altitude value provided via the Gillham inputs.</p> <p>Interrogate the transponder with MODE-S UF=20 interrogations and that have the MODE-S address set the same as that provided to the transponder. Verify that the transponder replies with the altitude value provided via the Gillham inputs.</p>			Gillham Altitude Bits												BIT POSITION		D2	D4	A1	A2	A4	B1	B2	B4	C1	C2	C4		-----														Data:		0	1	0	1	0	1	0	1	0	1	0		(49,950 to 50,050 feet)														
		Gillham Altitude Bits																																																																						
BIT POSITION		D2	D4	A1	A2	A4	B1	B2	B4	C1	C2	C4																																																												

Data:		0	1	0	1	0	1	0	1	0	1	0																																																												
(49,950 to 50,050 feet)																																																																								

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
17.9 (Cont)	<p style="text-align: right;">Gillham Altitude Bits</p> <p>BIT POSITION D2 D4 A1 A2 A4 B1 B2 B4 C1 C2 C4</p> <p>-----</p> <p>Data: 0 0 1 0 1 0 1 0 1 0 0 0</p> <p>(24, 250 to 24,350 feet)</p> <p>"1" indicates connection to ground (selected) "0" indicates open-circuited (not selected) Reference (Gillham code 5210).</p>	
	<p><u>PART B: IDENT/MODE-A/UF=5/UF=21</u></p> <p>Via the selected control bus, supply the transponder with a valid 4096 identification code.</p> <p>Interrogate the transponder with standard MODE-A interrogations. Verify that the transponder replies with the Ident Code provided via the control bus.</p> <p>Interrogate the transponder with MODE-S UF=5 interrogations with the PC, RR, DI and SD fields set to 0, and the MODE-S address set the same as that provided to the transponder. Verify that the transponder replies with the Ident Code provided via the control bus.</p> <p>Interrogate the transponder with MODE-S UF=21 interrogations and that have the MODE-S address set the same as that provided to the transponder. Verify that the transponder replies with the Ident Code provided via the control bus.</p>	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
17.10	<p>MODE-S All-Call Interrogations (Appendix F, Paragraph (h))</p> <p>Interrogate the transponder with MODE-S ONLY ALL-CALL (UF=11) interrogations. Verify that the transponder replies with DF=11 replies that have the same MODE-S Address as the one provided to the transponder via the discrete MODE-S Address inputs.</p> <p>Verify that the Transponder replies with DF=11 replies that have the "CA" field set to one of the following "0, 4, 5, or 7".</p> <p><u>NOTE:</u> RTCA Document No. DO-181, paragraph 2.2.14.4.5, Change 3, pages 4-5, totally redefined the "CA" field.</p> <p>Prior to Change 3, the "CA" field was defined for codes "0" through "3" only, and the code remained fixed for the UUT after the installation was completed.</p> <p>Change 3, now defines codes "0, 4, 5, 6, and 7" with codes "1, 2, and 3" being "Not Defined". In addition, the "CA" field is no longer fixed, but will be dynamic depending on the UUT status at the time of reply.</p>	
17.11	<p>ATCRBS-ONLY All-Call Interrogations (Appendix F, Paragraph (i))</p> <p>Interrogate the transponder with ATCRBS MODE-A ONLY ALL-CALL interrogations that have the nominal pulse spacing and signal level of -50 dBm. Verify that the transponder does not reply to the interrogations. Essentially, a reply ratio NOT GREATER THAN 1% constitutes the NO REPLY condition.</p> <p>Interrogate the transponder with ATCRBS MODE-C ONLY ALL-CALL interrogations having the nominal pulse spacing and signal level of -50 dBm. Verify that the transponder does not reply to the interrogations. Essentially, a reply ratio NOT GREATER THAN 1% constitutes the NO REPLY condition.</p>	
17.12	<p>Squitter Appendix F, Paragraph (j)</p> <p>The requirement to demonstrate proper compliance with this paragraph has been stated in steps 9.1 and 9.2 of this procedure and will not be repeated here.</p>	
18.0	MAINTENANCE FAULT COUNTER RESET	
	The steps of this test may be accomplished using option 17 of the automatic test program if so desired.	

Final Performance (Customer Acceptance) Test. Cont.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS														
18.1	Reset Function After completion of all tests, reset the maintenance fault counter by entering the current date as the Last Maintenance Date via the ARINC control bus word having Label = 277, bits 31, 30 = 10, and data for the current date as follows: <table style="margin-left: 40px;"> <tr> <td><u>BITS</u></td> <td><u>DATA</u></td> </tr> <tr> <td>29</td> <td>Month (BCD Tens)</td> </tr> <tr> <td>25 - 28</td> <td>Month (BCD Units)</td> </tr> <tr> <td>21 - 24</td> <td>Day (BCD Tens)</td> </tr> <tr> <td>17 - 20</td> <td>Day (BCD Units)</td> </tr> <tr> <td>13 - 16</td> <td>Year (BCD Tens)</td> </tr> <tr> <td>9 - 12</td> <td>Year (BCD Units)</td> </tr> </table> <p style="text-align: center;">Fault counter has been reset.</p>	<u>BITS</u>	<u>DATA</u>	29	Month (BCD Tens)	25 - 28	Month (BCD Units)	21 - 24	Day (BCD Tens)	17 - 20	Day (BCD Units)	13 - 16	Year (BCD Tens)	9 - 12	Year (BCD Units)	_____ (x)
<u>BITS</u>	<u>DATA</u>															
29	Month (BCD Tens)															
25 - 28	Month (BCD Units)															
21 - 24	Day (BCD Tens)															
17 - 20	Day (BCD Units)															
13 - 16	Year (BCD Tens)															
9 - 12	Year (BCD Units)															
18.2	Reset Function Close Out Enter ARINC control word having Label = 277, bits 31, 30 = 11, and data as follows: <table style="margin-left: 40px;"> <tr> <td><u>BITS</u></td> <td><u>DATA</u></td> </tr> <tr> <td>17 - 29</td> <td>PAD</td> </tr> <tr> <td>12 - 16</td> <td>0</td> </tr> <tr> <td>9 - 11</td> <td>1</td> </tr> </table> <p>Verify that the UUT responds on the TDR Output Bus with a ARINC word having Label = 351, bits 31, 30 = 11, and maintenance date data in the same format as that given in step 18.1.</p>	<u>BITS</u>	<u>DATA</u>	17 - 29	PAD	12 - 16	0	9 - 11	1							
<u>BITS</u>	<u>DATA</u>															
17 - 29	PAD															
12 - 16	0															
9 - 11	1															
19.0	Service Bulletin Tests															
19.1	Verify SW Version Date															
	Send an ARINC label 277 with bits 31,30 set to 0 to request an ARINC label 351 from the UUT.															
	Verify that the UUT responds by transmitting an ARINC label 351 data word on the TDR Output Bus that has bits 31, 30 set to 0 and the Last Software Version date data given in the same format as shown in the table of test 18.1.															

Final Performance (Customer Acceptance) Test.
Table 1001/Table 34-50-96-99A-009-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 DEG	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	
GPS/GNSS ALTITUDE	33,856 FT	N/A	076	00111110	00	0000 0001 0001 0000 100				11	P	
GPS/GNSS UTC## TIME	0	N/A	150	01101000	10	0000 0000 0000 0000 000				11	P	
LATITUDE-COURSE	-86.0 DEG	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE-FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-CRS	-171.5 DEG	860B60B6	111	01001001	00	1101 1010 0000 1100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	

NOTE: THE SDI FIELD OF VARIOUS WORDS RECEIVED FROM THE GPS/GNSS RECEIVER ACTUALLY REPRESENT DATA AS OPPOSED TO SOURCE-DESTINATION IDENTIFICATION INFORMATION.

INPUT DATA FOR TEST 9.3, STEP b.

BIT SIGNIFICANCE:					MSB	LSB	EVEN		MSB	LSB	MSB	LSB
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	88
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23 (15555)	39	40 (12444) 56
FIELD:	TYPE	SSS	TURN	ALTITUDE			PAD	TIME	ENCODED LATITUDE			ENCODED LONGITUDE
DATA:	0 1101	00	0	1010 1111 0010			0	0	1 0101 0101 0101 0101			1 0010 0100 0100 0100

EVEN-SECOND AIRBORNE POSITION SQUITTER FOR TEST 9.3, STEP c.

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
GPS/GNSS UTC## TIME	1	N/A	150	01101000	10	0100 0000 0000 0000 000				11	P	

INPUT DATA FOR TEST 9.3, STEP g.

BIT SIGNIFICANCE:					MSB	LSB	EVEN		MSB	LSB	MSB	LSB
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	88
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23 (1CFA5)	39	40 (0182D) 56
FIELD:	TYPE	SSS	TURN	ALTITUDE			PAD	TIME	ENCODED LATITUDE			ENCODED LONGITUDE
DATA:	0 1101	00	0	1010 1111 0010			0	1	1 1100 1111 1010 0101			0 0001 1000 0010 1101

ODD-SECOND AIRBORNE POSITION SQUITTER FOR TEST 9.3, STEP h.

TPH6662_01

Airborne Position Extended Squitter Test 9.3, Input Data and Results
 Figure 1003/GRAPHIC 34-50-96-99B-021-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000	0000	0000	0000	0000	11	P
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000	0001	0001	0000	100	11	P
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000	0011	0110	1000	011	11	P
LATITUDE-FINE			120	01010000	10	0000	0001	1000	0011	010	11	P
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101	1010	0000	1100	001	11	P
LONGITUDE-FINE			121	01010001	10	0000	0000	1101	1010	000	11	P

NOTE: The SDI field of various words received from the GPS/GNSS Receiver actually represents data as opposed to Source-Destination Identification information.

INPUT DATA FOR TEST 9.3A, STEP e.

BIT SIGNIFICANCE:					MSB	LSB	EVEN		MSB	LSB	MSB	LSB			
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	88			
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE					
DATA:	1 0110	00	0 or 1	1010 1111 0010		1	0	1 0101 0101 0101 0101		1 0010 0100 0100 0100					

NOTE: The Single Antenna Bit (RF bit 40) is a "0" for the TDR-94D and a "1" for the TDR-94.

EVEN-SECOND, AIRBORNE POSITION SQUITTER TRANSMISSION FOR TEST 9.3A, STEP f.

BIT SIGNIFICANCE:					MSB	LSB	ODD		MSB	LSB	MSB	LSB			
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	88			
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(1CFA5)	39	40	(0182D)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE					
DATA:	1 0110	00	0 or 1	1010 1111 0010		1	1	1 1100 1111 1010 0101		0 0001 1000 0010 1101					

NOTE: The Single Antenna Bit (RF bit 40) is a "0" for the TDR-94D and a "1" for the TDR-94.

ODD-SECOND, AIRBORNE POSITION SQUITTER TRANSMISSION FOR TEST 9.3A, STEP j.

TPH6632_01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #		PC		RR		DI		SD		AP	
DATA:	0 0100		000		1 0000		111		0000 0101 0000 0000		UUT Mode-S Address	
DECODED DATA:	4		0		10 (Hex)		7 (Hex)		0500 (Hex)		Example: AAAAAA (Hex)	

AIRBORNE POSITION INTERROGATION – UF4 For TEST 9.3B, STEP f.

BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB				
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE					
DATA:	1 0110	00	0 or 1	1010 1111 0010		1	0	1 0101 0101 0101 0101		1 0010 0100 0100 0100					
NOTE: The Single Antenna Bit (RF Bit 40) is a "0" for the TDR-94D and a "1" for the TDR-94.															

EVEN-SECOND, AIRBORNE POSITION MESSAGE TRANSMISSION FOR TEST 9.3B, STEP g.

BIT SIGNIFICANCE:				MSB	LSB		ODD	MSB	LSB	MSB	LSB				
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(1CFA5)	39	40	(0182D)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE					
DATA:	1 0110	00	0 or 1	1010 1111 0010		1	1	1 1100 1111 1010 0101		0 0001 1000 0010 1101					
NOTE: The Single Antenna Bit (RF Bit 40) is a "0" for the TDR-94D and a "1" for the TDR-94.															

ODD-SECOND, AIRBORNE POSITION MESSAGE TRANSMISSION FOR TEST 9.3B, STEP i.

TPH6633_01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
GPS/GNSS TRACK	119.9982 DEG	N/A	103	01000011	10	0001 0101 0101 0101 010				11	P	
GPS/GNSS GROUND SPEED	74.0 KNOTS	N/A	112	01001010	10	0000 0001 0100 1000 000				11	P	
GPS/GNSS ALTITUDE	33,856 FT	N/A	076	00111110	00	0000 0001 0001 0000 100				11	P	
GPS/GNSS UTC## TIME	0	N/A	150	01101000	10	0000 0000 0000 0000 000				11	P	
LATITUDE - COURSE	-86.5 DEG	C27D27D2	110	01001000	00	1001 0111 1100 1000 011				11	P	
LATITUDE - FINE			120	01010000	10	0000 0000 1001 0111 110				11	P	
LONGITUDE - CRS	-172.5 DEG	85555555	111	01001001	01	0101 0101 0101 0100 001				11	P	
LONGITUDE - FINE			121	01010001	10	0000 0001 0101 0101 010				11	P	

NOTE : THE SDI FIELD OF VARIOUS WORDS RECEIVED FROM THE GPS/GNSS RECEIVER ACTUALLY REPRESENT DATA AS OPPOSED TO SOURCE-DESTINATION IDENTIFICATION INFORMATION.

INPUT DATA FOR TEST 9.5, STEP b.

BIT SIGNIFICANCE:			MSB	LSB			EVEN	MSB (-86.5)	LSB	MSB (-172.5)	LSB					
"ME" RF BIT:	33	37	38	44	45	51	52	53	54	55	71	72	88			
BDS BUFFER BIT:	1	5	6	12	13	(118)	19	20	21	22	23	(0AAAB)	39	40	(08000)	56
FIELD:	TYPE	MOVEMENT		GROUND TRACK		PAD	TIME	ENCODED LATITUDE			ENCODED LONGITUDE					
DATA:	00101	110 0000		0101010		00	0	0 1010 1010 1010 1011			0 1000 0000 0000 0000					

EVEN-SECOND SURFACE POSITION SQUITTER FOR TEST 9.5, STEP c.

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
GPS/GNSS UTC## TIME	1	N/A	150	01101000	10	0100 0000 0000 0000 000				11	P	

INPUT DATA FOR TEST 9.5, STEP g.

BIT SIGNIFICANCE:			MSB	LSB	MSB	LSB			ODD	MSB	LSB	MSB	LSB			
"ME" RF BIT:	33	37	38	44	45	51	52	53	54	55	71	72	88			
BDS BUFFER BIT:	1	5	6	12	13	(118)	19	20	21	22	23	(096C1)	39	40	(05555)	56
FIELD:	TYPE	MOVEMENT		GROUND TRACK		PAD	TIME	ENCODED LATITUDE			ENCODED LONGITUDE					
DATA:	0 0101	110 0000		0101010		00	1	0 1001 0110 1100 0001			0 0101 0101 0101 0101					

ODD - SECOND SURFACE POSITION SQUITTER FOR TEST 9.5, STEP h. TPH6668_01

Surface Position Extended Squitter Test 9.5, Input Data and Results
 Figure 1006/GRAPHIC 34-50-96-99B-024-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	119.9982 deg.	N/A	103	01000011	10	0001	0101	0101	0101	010	11	P
GPS/GNSS GROUND SPEED	74.0 Kts.	N/A	112	01001010	10	0000	0001	0100	1000	000	11	P
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000	0001	0001	0000	100	11	P
LATITUDE-COURSE	-86.5 deg.	C27D27D2	110	01001000	00	1001	0111	1100	1000	011	11	P
LATITUDE -FINE			120	01010000	10	0000	0000	1001	0111	110	11	P
LONGITUDE-COURSE	-172.5 deg.	85555555	111	01001001	01	0101	0101	0101	0100	001	11	P
LONGITUDE-FINE			121	01010001	10	0000	0001	0101	0101	010	11	P

NOTE: The SDI field of various words received from the GPS/GNSS Receiver actually represents data as opposed to Source-Destination Identification information.

INPUT DATA FOR TEST 9. 5 A, STEP d.

BIT SIGNIFICANCE:		MSB	LSB					EVEN	MSB (-86.5)	LSB	MSB (-172.5)	LSB							
"ME" RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88						
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(0AAAB)	39	40	(08000)	56				
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)			ENCODED LATITUDE		ENCODED LONGITUDE								
DATA:	0	1000	110	0000	1	0101011		1	0	0	1010	1010	1010	1011	0	1000	0000	0000	0000

EVEN-SECOND, SURFACE POSITION SQUITTER TRANSMISSION FOR TEST 9. 5 A, STEP e.

BIT SIGNIFICANCE:		MSB	LSB		MSB	LSB		ODD	MSB (-86.5)	LSB	MSB (-172.5)	LSB							
"ME" RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88						
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(096C1)	39	40	(05555)	56				
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)			ENCODED LATITUDE		ENCODED LONGITUDE								
DATA:	0	1000	110	0000	1	0101011		0	1	0	1001	0110	1100	0001	0	0101	0101	0101	0101

ODD-SECOND, SURFACE POSITION SQUITTER TRANSMISSION FOR TEST 9. 5 A, STEP j.

TPH6630_01

GPS Bus/Airborne Surface Position Extended Squitter/Time Tag Verification
 Test 9.5A, Input Data and Results
 Figure 1007/GRAPHIC 34-50-96-99B-025-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #		PC		RR		DI		SD		AP	
DATA:	0 0100		000		1 0000		111		0000 0110 0000 0000		UUT Mode-S Address	
DECODED DATA:	4		0		10 (Hex)		7 (Hex)		0600 (Hex)		Example: AAAAAA (Hex)	

SURFACE POSITION INTERROGATION - UF4 FOR TEST 9.5B, STEP e.

BIT SIGNIFICANCE:		MSB LSB						EVEN	MSB (-86.5)	LSB	MSB (-172.5)	LSB	
"ME" RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23 (0AAAAB)	39	40 (08000)	56
FIELD:	TYPE		MOVEMENT		ST	GROUND TRACK		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE	
DATA:	0 1000		110 0000		1	0101011		1	0	0 1010 1010 1010 1011		0 1000 0000 0000 0000	

EVEN-SECOND, SURFACE POSITION MESSAGE TRANSMISSION FOR TEST 9.5B, STEP f.

BIT SIGNIFICANCE:		MSB LSB			MSB LSB			ODD	MSB (-86.5)	LSB	MSB (-172.5)	LSB	
"ME" RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23 (096C1)	39	40 (05555)	56
FIELD:	TYPE		MOVEMENT		ST	GROUND TRACK		TIME (T)	Format (F)	ENCODED LATITUDE		ENCODED LONGITUDE	
DATA:	0 1000		110 0000		1	0101011		0	1	0 1001 0110 1100 0001		0 0101 0101 0101 0101	

ODD-SECOND, SURFACE POSITION MESSAGE TRANSMISSION FOR TEST 9.5B, STEP i.

TPH6629_01

GPS Bus/Airborne Surface Position Extended Squitter/Time Tag Verification
 Test 9.5B, Input Data and Results
 Figure 1008/GRAPHIC 34-50-96-99B-026-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
TRACK ANGLE	0 DEG	0000	313	01000011	10	0000 0000 0000 0000 000				11	P	
LATITUDE-COURSE	-86.0 DEG	C2D82800	310	01001000	10	1000 0011 0110 1000 011				11	P	
LONGITUDE-CRS	-171.5 DEG	860B6000	311	01001001	00	1101 1010 0000 1100 001				11	P	

INPUT DATA FOR TEST 9.6, STEP b .

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI (1)	BINARY DATA				SSM	P	
PRESSURE ALTITUDE	33,856 ft	N/A	203	10000011	10	0000 0001 0001 0000 100				11	P	

INPUT DATA FOR TEST 9.6, STEP c.

BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB		
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88
BDS BUFFER BIT:	1	5	6	7	8	9 (33,856 ft)	20	21	22	23 (15552)	39	40 (12444)	56
FIELD:	TYPE	SSS	TURN	ALTITUDE			PAD	TIME	ENCODED LATITUDE			ENCODED LONGITUDE	
DATA:	0 1010	00	0	1010 1111 0010			0	0	1 0101 0101 0101 0010			1 0010 0100 0100 0100	

EXTENDED SQUITTER TRANSMISSIONS FOR TEST 9.6, STEP e .

TPH6675_01

FMS/INS Primary Data Test 9.6, Input Data and Results
 Figure 1009/GRAPHIC 34-50-96-99B-027-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
TRACK ANGLE	0 deg.	0000	313	01000011	10	0000	0000	0000	0000	0000	11	P
LATITUDE-COURSE	-86.0 deg.	C2D82800	310	01001000	10	1000	0011	0110	1000	0111	11	P
LONGITUDE-CRS	-171.5 deg.	860B6000	311	01001001	00	1101	1010	0000	1100	0001	11	P

INPUT DATA FOR TEST 9.6A, STEP c.

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
PRESSURE ALTITUDE	33,856 ft.	N/A	203	10000011	10	0000	0001	0001	0000	100	11	P

INPUT DATA FOR TEST 9.6A, STEP d.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP						
DATA:	0 0100	000	1 0000	111	0000 0101 0000 0000	UUT Mode-S Address						
DECODED DATA:	4	0	10 (Hex)	7 (Hex)	0500 (Hex)	Example: AAAAAA (Hex)						

AIRBORNE POSITION INTERROGATION - UF4 FOR TEST 9.6 A, STEP e.

BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB		
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88
BDS BUFFER BIT:	1	5	6	7	8	9 (33,856 ft.)	20	21	22	23 (15552)	39	40 (12444)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE					
DATA:	1 0010	00	0 or 1	1010 1111 0010	0	0	1 0101 0101 0101 0010	1 0010 0100 0100 0100					

NOTE: The Single Antenna Bit (RF bit 40) is set to "0" for TDR-94D and to "1" for TDR-94.

EVEN - SECOND, AIRBORNE FMS/IRS POSITION MESSAGE TRANSMISSION FOR TEST 9.6A, STEP f.

BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB		
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88
BDS BUFFER BIT:	1	5	6	7	8	9 (33,856 ft.)	20	21	22	23 (1CFA2)	39	40 (0182D)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE					
DATA:	1 0010	00	0 or 1	1010 1111 0010	0	1	1 1100 1111 1010 0010	0 0001 1000 0010 1101					

NOTE: The Single Antenna Bit (RF bit 40) is set to "0" for TDR-94D and to "1" for TDR-94.

ODD - SECOND, AIRBORNE FMS/IRS POSITION MESSAGE TRANSMISSION FOR TEST 9.6A, STEP h.

TPH6638_01

FMS/INS Primary Data Test 9.6A, Input Data and Results
 Figure 1010/GRAPHIC 34-50-96-99B-028-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:		1	8	9	10	11	29	30	31	32
PARAMETER	HEX LABEL	LABEL	SDI	BINARY DATA				SSM	P	
FLIGHT IDENT WORD 1 (CH 1, CH 2)	233	1001 1011	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 2 (CH 3, CH 4)	234	1001 1100	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 3 (CH 5, CH 6)	235	1001 1101	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 4 (CH 7, CH 8)	236	1001 1110	10	1010101 0 1010101 0000				00	P	

NOTE: ALL CHARACTERS ARE SET EQUAL TO THE ICAO ANNEX 10 CHARACTER "U".

INPUT DATA FOR TEST 9.7, STEP e .

"ME" RF BIT:	33	37	38	40	41	46	47	52	53	58	59	64	65	70	71	76	77	82	83	88
BDS BUFFER BIT:	1	5	6	8	9	14	15	20	21	26	27	32	33	38	39	44	45	50	51	56
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8										
DATA:	0 0100	101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION SQUITTER FOR TEST 9.7, STEP f.

TPH6679_01

Aircraft Identification Squitter Test 9.7, Input Data and Results
 Figure 1011/GRAPHIC 34-50-96-99B-029-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:		1	8	9	10	11	29	30	31	32
PARAMETER	HEX LABEL	LABEL	SDI	BINARY DATA				SSM	P	
FLIGHT IDENT WORD 1 (CH 1, CH 2)	233	10011011	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 2 (CH 3, CH 4)	234	10011100	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 3 (CH 5, CH 6)	235	10011101	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 4 (CH 7, CH 8)	236	10011110	10	1010101 0 1010101 0000				00	P	

INPUT DATA FOR TEST 9.7A, STEP e.

"ME" RF BIT:	33	37	38	40	41	46	47	52	53	58	59	64	65	70	71	76	77	82	83	88	
BDS BUFFER BIT:	1	5	6	8	9	14	15	20	21	26	27	32	33	38	39	44	45	50	51	56	
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8											
DATA:	0 0100	101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7A, STEP f.

"ME" RF BIT:	33	37	38	40	41	46	47	52	53	58	59	64	65	70	71	76	77	82	83	88	
BDS BUFFER BIT:	1	5	6	8	9	14	15	20	21	26	27	32	33	38	39	44	45	50	51	56	
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8											
DATA:	0 0011	010	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7A, STEP i.

TPH6639_01

Aircraft Identification Squitter Test 9.7A, Input Data and Results
 Figure 1012/GRAPHIC 34-50-96-99B-030-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RF BIT:	1 5	6 8	9 13	14 16	17 32	33 56
FIELD:	UF #	PC	RR	DI	SD	AP
DATA:	0 0100	000	1 0000	111	0000 1000 0000 0000	UUT MODE-S ADDRESS
DECODED DATA:	4	0	10 (HEX)	7 (HEX)	0800 (HEX)	EXAMPLE: AAAAAA (HEX)

AIRCRAFT IDENTIFICATION INTERROGATION - UF4 FOR TEST 9.7B, STEP f.

"ME" RF BIT:	33 37	38 40	41 46	47 52	53 58	59 64	65 70	71 76	77 82	83 88
BDS BUFFER BIT:	1 5	6 8	9 14	15 20	21 26	27 32	33 38	39 44	45 50	51 56
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8
DATA:	0 0100	101	010101	010101	010101	010101	010101	0101 01	010101	010101

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7B, STEP g.

"ME" RF BIT:	33 37	38 40	41 46	47 52	53 58	59 64	65 70	71 76	77 82	83 88
BDS BUFFER BIT:	1 5	6 8	9 14	15 20	21 26	27 32	33 38	39 44	45 50	51 56
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8
DATA:	0 0011	010	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7B, STEP k.

TPH6644_01

Aircraft Identification Message Test 9.7B, Input Data and Results
Figure 1013/GRAPHIC 34-50-96-99B-031-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000 0001 0001 0000 100				11	P	
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE-FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101 1010 0000 1100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	

INPUT DATA FOR TEST 9.8, STEP f.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #		PC		RR		DI		SD		AP	
DATA:	0 010 0		000		1 0000		111		0000 0101 0000 0000		UUT MODE-S ADDRESS	
DECODED DATA:	4		0		10 (HEX)		7 (HEX)		0500 (HEX)		EXAMPLE: AAAAAA (HEX)	

AIRBORNE POSITION INTERROGATION - UF4 FOR TEST 9.8 STEP g.

BIT SIGNIFICANCE:					MSB	LSB			EVEN	MSB	LSB	MSB	LSB		
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56
FIELD:	TYPE	SSS	SINGLE ANT	ALTITUDE		TIME (T)	FORMAT (F)	ENCODED LATITUDE		ENCODED LONGITUDE					
DATA:	1 0110	00	0 OR 1	1010 1111 0010		0	0	1 0101 0101 0101 0101		1 0010 0100 0100 0100					

NOTE: THE SINGLE ANTENNA BIT (RF BIT 40) IS SET TO "0" FOR THE TDR-94D AND TO "1" FOR THE TDR-94.

EVEN-SECOND AIRBORNE POSITION MESSAGE TRANSMISSION FOR TEST 9.8, STEP h. TPH6645_01

AIS/ADSS Primary Data Test 9.8, Input Data and Results
 Figure 1014/GRAPHIC 34-50-96-99B-032-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

RF BIT:	1 5	6 8	9	13	14 16	17	32	33	56	
FIELD:	UF #	PC	RR	DI	SD	AP				
DATA:	0 0100	000	1 0110	111	0000 0101 0000 0000	UUT MODE - S ADDRESS				
DECODED DATA:	4	0	16 (HEX)	7 (HEX)	0500 (HEX)	EXAMPLE: AAAAAA (HEX)				

AIRCRAFT OPERATIONAL STATUS INTERROGATION - UF4 FOR TEST 14A.0, STEP b.

"ME" RF BIT:	33 37	38 40	41	56	57	72	73 75	76	77 80	81 82	83 84	85	86	87 88
BDS BUFFER BIT:	1 5	6 8	9	24	25	40	41 43	44	45 48	49 50	51 52	53	54	55 56
FIELD:	FORMAT TYPE CODE	SUBTYPE CODE	CC CODES	OM CODES	VN	NIC	NAC _P	BAQ OR RES	SIL	NIC _B OR TRKH _{DG}	HRD	RES		
DATA:	11111	XXX	XXXXXXXXXXXXXXXXXX	XXXXXXXXXXXXXXXXXX	XXX	X	XXXX	XX	00	X	X	XX		

AIRCRAFT OPERATIONAL STATUS - DF20 FOR TEST 14A.0, STEP c .

RF BIT:	1 5	6 8	9	13	14 16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP			
DATA:	0 0100	000	1 0110	111	0000 0101 0000 0000	UUT MODES ADDRESS			
DECODED DATA:	4	0	16 (HEX)	7 (HEX)	0500 (HEX)	EXAMPLE: AAAAAA (HEX)			

AIRCRAFT OPERATIONAL STATUS INTERROGATION - UF4 FOR TEST 14A.0, STEP e.

"ME" RF BIT:	33 37	38 40	41	56	57	72	73 75	76	77 80	81 82	83 84	85	86	87 88
BDS BUFFER BIT:	1 5	6 8	9	24	25	40	41 43	44	45 48	49 50	51 52	53	54	55 56
FIELD:	FORMAT TYPE CODE	SUBTYPE CODE	CC CODES	OM CODES	VN	NIC	NAC _P	BAQ OR RES	SIL	NIC _B OR TRKH _{DG}	HRD	RES		
DATA:	11111	XXX	XXXXXXXXXXXXXXXXXX	XXXXXXXXXXXXXXXXXX	XXX	X	XXXX	XX	10	X	X	XX		

AIRCRAFT OPERATIONAL STATUS - DF20 FOR TEST 14A.0, STEP f .

TPH6659_01

SIL Designator Requirements Test 14A.0, Input Data and Results
 Figure 1015/GRAPHIC 34-50-96-99B-033-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	17	18	28	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	PAD	BINARY DATA		PAD	SSM	P				
TRACK ANGLE RATE	15 DEG/SEC	N/A	335	11011101	10	0000 000	0000 0011 110		0	11	P				

INPUT DATA FOR TEST 16.10A.1, STEP b.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR		DI	SD		AP				
DATA:	0 0100	000	1 0101		111	0000 0000 0000 0000		UUT MODE-S ADDRESS				
DECODED DATA:	4	0	15 (HEX)		7 (HEX)	0000 (HEX)		EXAMPLE: AAAAAA (HEX)				

TRACK AND TURN REPORT INTERROGRATION - UF4 FOR TEST 16.10A.1, STEP c.

"ME" RF BIT:	33	34	35	43	44	45	46	55	56	57	66	67	68	69	77	78	79	88
BDS BUFFER BIT:	1	2	3	11	12	13	14	23	24	25	34	35	36	37	45	46	47	56
FIELD:	ST	SIGN	ROLL ANGLE		ST	SIGN	TRUE TRACK ANGLE		ST	GROUND SPEED		ST	SIGN	TRACK ANGLE RATE		ST	TRUE AIRSPEED	
DATA:	X	X	XXXXXXXXXX		X	X	XXXXXXXXXX		X	XXXXXXXXXX		1	0	111100000		X	XXXXXXXXXX	

TRACK AND TURN REPORT - DF20 FOR TEST 16.10A.1, STEP d.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR		DI	SD		AP				
DATA:	0 0100	000	1 0101		111	0000 0000 0000 0000		UUT MODE-S ADDRESS				
DECODED DATA:	4	0	15 (HEX)		7 (HEX)	0000 (HEX)		EXAMPLE: AAAAAA (HEX)				

TRACK AND TURN REPORT INTERROGRATION - UF4 FOR TEST 16.10A.1, STEP f.

"ME" RF BIT:	33	34	35	43	44	45	46	55	56	57	66	67	68	69	77	78	79	88
BDS BUFFER BIT:	1	2	3	11	12	13	14	23	24	25	34	35	36	37	45	46	47	56
FIELD:	ST	SIGN	ROLL ANGLE		ST	SIGN	TRUE TRACK ANGLE		ST	GROUND SPEED		ST	SIGN	TRACK ANGLE RATE		ST	TRUE AIRSPEED	
DATA:	X	X	XXXXXXXXXX		X	X	XXXXXXXXXX		X	XXXXXXXXXX		0	0	000000000		X	XXXXX XXXXX	

TRACK AND TURN REPORT - DF20 FOR TEST 16.10A.1, STEP g.

TPH6653_01

Configuration Select S0 Discrete Test 16.10A.1, Input Data and Results
 Figure 1016/GRAPHIC 34-50-96-99B-034-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GNSS N/S VELOCITY	0 KNOTS	N/A	166	01110110	10	0000 0000 0000 0000 000				11	P	
GNSS E/W VELOCITY	0 KNOTS	N/A	174	01111100	10	0000 0000 0000 0000 000				11	P	
LATITUDE-COURSE	-86.0 DEG.	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE -FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-CRS	-171.5 DEG.	860B60B6	111	01001001	00	1101 1010 0000 1 100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	
GPS/GNSS TRACK	0 DEG.	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	

NOTE: THE SDI FIELDS OF VARIOUS WORDS RECEIVED FROM THE GPS/GNSS RECEIVER ACTUALLY REPRESENT DATA AS OPPOSED TO SOURCE-DESTINATION IDENTIFICATION INFORMATION.

INPUT DATA FOR TEST 16.10A.2, STEP d.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #		PC		RR		DI		SD		AP	
DATA:	0 0100		000		1 0000		111		0000 0101 0000 0000		UUT MODE - S ADDRESS	
DECODED DATA:	4		0		10 (HEX)		7 (HEX)		0500 (HEX)		EXAMPLE: AAAAAA (HEX)	

AIRBORNE POSITION INTERROGATION - UF4 FOR TEST 16.10 A.2, STEP e.

BIT SIGNIFICANCE:					MSB	LSB			EVEN	MSB	LSB	MSB	LSB	
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88	
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23 (15555)	39	40 (12444)	56	
FIELD:	TYPE		SSS		SNGL ANT		ALTITUDE		UTC		ENCODED LATITUDE		ENCODED LONGITUDE	
DATA:	1 0010		XX		X		XXXXXXXXXXXX		X		XXXXXXXXXXXXXXXXXX		XXXXXXXXXXXXXXXXXXXX	

AIRBORNE POSITION DF20 REPLY FOR TEST 16.10A.2, STEP f.

RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #		PC		RR		DI		SD		AP	
DATA:	0 0100		000		1 0000		111		0000 0101 0000 0000		UUT MODE - S ADDRESS	
DECODED DATA:	4		0		10 (HEX)		7 (HEX)		0500 (HEX)		EXAMPLE: AAAAAA (HEX)	

AIRBORNE POSITION INTERROGATION - UF4 FOR TEST 16.10A.2, STEP h.

BIT SIGNIFICANCE:					MSB	LSB			EVEN	MSB	LSB	MSB	LSB	
"ME" RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88	
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23 (15555)	39	40 (12444)	56	
FIELD:	TYPE		SSS		SNGL ANT		ALTITUDE		UTC		ENCODED LATITUDE		ENCODED LONGITUDE	
DATA:	0 0000		XX		X		XXXXXXXXXXXX		X		XXXXXXXXXXXXXXXXXX		XXXXXXXXXXXXXXXXXXXX	

AIRBORNE POSITION DF20 REPLY FOR TEST 16.10A.2, STEP i.

TPH6654_01

Configuration Select S1 Discrete Test 16.10A.2, Input Data and Results
 Figure 1017/GRAPHIC 34-50-96-99B-035-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000 0001 0001 0000 100				11	P	
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE -FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101 1010 0000 1100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	

INPUT DATA FOR TEST 9.3C STEP e.

AIRBORNE POSITION SQUITTER_EVEN SECOND																				
BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB									
ME RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88							
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56					
FIELD:	TYPE	SSS	Single ANT	ALTITUDE			TIME (T)	Format (F)	ENCODED LATITUDE			ENCODED LONGITUDE								
DATA:	1	0110	00	0	or 1	1010	1111	0010	1	0	1	0101	0101	0101	0101	1	0010	0100	0100	0100

AIRBORNE POSITION SQUITTER EVEN SECOND FOR TEST 9.3C STEP f.

AIRBORNE POSITION SQUITTER_ODD SECOND																				
BIT SIGNIFICANCE:				MSB	LSB		ODD	MSB	LSB	MSB	LSB									
ME RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88							
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(1CFA5)	39	40	(0182D)	56					
FIELD:	TYPE	SSS	Single ANT	ALTITUDE			TIME (T)	Format (F)	ENCODED LATITUDE			ENCODED LONGITUDE								
DATA:	1	0110	00	0	or 1	1010	1111	0010	1	1	1	1100	1111	1010	0101	0	0001	1000	0010	1101

AIRBORNE POSITION SQUITTER ODD SECOND FOR TEST 9.3C STEP j.

TP12530_01

Airborne Position Extended Squitter Test 9.3C, Input Data and Results
Figure 1018/GRAPHIC 34-50-96-99B-089-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000	0000	0000	0000	000	11	P
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000	0001	0001	0000	100	11	P
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000	0011	0110	1000	011	11	P
LATITUDE-FINE			120	01010000	10	0000	0001	1000	0011	010	11	P
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101	1010	0000	1100	001	11	P
LONGITUDE-FINE			121	01010001	10	0000	0000	1101	1010	000	11	P

INPUT DATA FOR TEST 9.3D STEP e.

AIRBORNE POSITION INTERROGATION UF4												
RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP						
DATA:	0 0100	000	1 0000	111	0000 0101 0000 0000	UUT Mode-S Address						
DECODED DATA:	4	0	10 (Hex)	7 (Hex)	0500 (Hex)	Example: AAAAAA (Hex)						

AIRBORNE POSITION INTERROGATION UF4 FOR 9.3D STEP f.

AIRBORNE POSITION MESSAGE_EVEN SECOND															
BIT SIGNIFICANCE:				MSB	LSB		EVEN	MSB	LSB	MSB	LSB				
MB RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE							
DATA:	1 0110	00	0 or 1	1010 1111 0010	1	0	1 0101 0101 0101 0101	1 0010 0100 0100 0100							

EVEN SECOND, AIRBORNE POSITION MESSAGE FOR 9.3D STEP g.

AIRBORNE POSITION MESSAGE_ODD SECOND															
BIT SIGNIFICANCE:				MSB	LSB		ODD	MSB	LSB	MSB	LSB				
MB RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(1CFA5)	39	40	(0182D)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE							
DATA:	1 0110	00	0 or 1	1010 1111 0010	1	1	1 1100 1111 1010 0101	0 0001 1000 0010 1101							

ODD SECOND AIRBORNE POSITION MESSAGE STEP i.

TPI2531_01

GPS Bus / Airborne Position Extended Squitter / Time Tag Test 9.3D, Input Data and Results
Figure 1019/GRAPHIC 34-50-96-99B-090-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	119.9982 deg.	N/A	103	01000011	10	0001	0101	0101	0101	010	11	P
GPS/GNSS GROUND SPEED	74.0 Kts.	N/A	112	01001010	10	0000	0001	0100	1000	000	11	p
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000	0001	0001	0000	100	11	P
LATITUDE-COURSE	-86.5 deg.	C27D27D2	110	01001000	00	1001	0111	1100	1000	011	11	P
LATITUDE -FINE			120	01010000	10	0000	0000	1001	0111	110	11	P
LONGITUDE-COURSE	-172.5 deg.	85555555	111	01001001	01	0101	0101	0101	0100	001	11	P
LONGITUDE-FINE			121	01010001	10	0000	0001	0101	0101	010	11	P

INPUT DATA FOR TEST 9.5C STEP d.

SURFACE POSITION SQUITTER_EVEN SECOND																		
BIT SIGNIFICANCE:		MSB	LSB				EVEN	MSB	(-86.5)	LSB	MSB	(-172.5)	LSB					
ME RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88					
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(0AAA)	39	40	(08000)	56			
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)		ENCODED LATITUDE		ENCODED LONGITUDE								
DATA:	0	1000	110	0000	1	0101011	1	0	0	1010	1010	1010	1011	0	1000	0000	0000	0000

EVEN SECOND POSITION SQUITTER TRANSMISSION FOR TEST 9.5C STEP e.

SURFACE POSITION SQUITTER_ODD SECOND																		
BIT SIGNIFICANCE:		MSB	LSB		MSB	LSB		ODD	MSB	(-86.5)	LSB	MSB	(-172.5)	LSB				
ME RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88					
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(096C1)	39	40	(05555)	56			
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)		ENCODED LATITUDE		ENCODED LONGITUDE								
DATA:	0	1000	110	0000	1	0101011	0	1	0	1001	0110	1100	0001	0	0101	0101	0101	0101

ODD SECOND POSITION SQUITTER TRANSMISSION FOR TEST 9.5C STEP j.

TP12532_01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000 0001 0001 0000 100				11	P	
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE-FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101 1010 0000 1100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	

INPUT DATA FOR TEST 9.5D STEP d.

SURFACE POSITION INTERROGATION UF4												
RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP						
DATA:	0 0100	000	1 0000	111	0000 0110 0000 0000	UUT Mode-S Address						
DECODED DATA:	4	0	10 (Hex)	7 (Hex)	0600 (Hex)	Example: AAAAAA (Hex)						

SURFACE POSITION INTERROGATION UF-4 FOR TEST 9.5D STEP e.

SURFACE POSITION MESSAGE_EVEN SECOND															
BIT SIGNIFICANCE:		MSB	LSB				EVEN	MSB (-86.5)	LSB	MSB (-172.5)	LSB				
MB RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(0AAAB)	39	40	(08000)	56
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE							
DATA:	0 1000	110 0000	1	0101011	1	0	0 1010 1010 1010 1011	0 1000 0000 0000 0000							

EVEN SECOND SURFACE POSITION INTERROGATION FOR TEST 9.5D STEP f.

SURFACE POSITION MESSAGE_ODD SECOND															
BIT SIGNIFICANCE:		MSB	LSB		MSB	LSB	ODD	MSB (-86.5)	LSB	MSB (-172.5)	LSB				
MB RF BIT:	33	37	38	44	45	46	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	12	13	14	20	21	22	23	(096C1)	39	40	(05555)	56
FIELD:	TYPE	MOVEMENT	ST	GROUND TRACK	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE							
DATA:	0 1000	110 0000	1	0101011	0	1	0 1001 0110 1100 0001	0 0101 0101 0101 0101							

ODD SECOND SURFACE POSITION INTERROGATION FOR TEST 9.5D STEP i.

TPI2533_01

GPS Bus / Surface Position Extended Squitter / Time Tag Verification Test 9.5D
Figure 1021/GRAPHIC 34-50-96-99B-092-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:		1 8	9 10	11	29	30 31	32
PARAMETER	HEX LABEL	LABEL	SDI	BINARY DATA		SSM	P
FLIGHT IDENT WORD 1 (CH 1, CH 2)	233	10011011	10	1010101 0 1010101 0000		00	P
FLIGHT IDENT WORD 2 (CH 3, CH 4)	234	10011100	10	1010101 0 1010101 0000		00	p
FLIGHT IDENT WORD 3 (CH 5, CH 6)	235	10011101	10	1010101 0 1010101 0000		00	P
FLIGHT IDENT WORD 4 (CH 7, CH 8)	236	10011110	10	1010101 0 1010101 0000		00	P

INPUT DATA FOR TEST 9.7C STEP e.

AIRCRAFT IDENTIFICATION SQUITTER											
ME RF BIT:	33 37	38 40	41 46	47 52	53 58	59 64	65 70	71 76	77 82	83 88	
BDS BUFFER BIT:	1 5	6 8	9 14	15 20	21 26	27 32	33 38	39 44	45 50	51 56	
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8	
DATA:	0 0100	101	010101	010101	010101	010101	010101	010101	010101	010101	

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7C STEP f.

AIRCRAFT IDENTIFICATION SQUITTER											
ME RF BIT:	33 37	38 40	41 46	47 52	53 58	59 64	65 70	71 76	77 82	83 88	
BDS BUFFER BIT:	1 5	6 8	9 14	15 20	21 26	27 32	33 38	39 44	45 50	51 56	
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8	
DATA:	0 0011	010	010101	010101	010101	010101	010101	010101	010101	010101	

AIRCRAFT IDENTIFICATION SQUITTER TRANSMISSION FOR TEST 9.7C STEP i.

TPI2534_01

Aircraft Identification Message (-408 ONLY) Test 9.7C
Figure 1022/GRAPHIC 34-50-96-99B-093-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:		1	8	9	10	11	29	30	31	32
PARAMETER	HEX LABEL	LABEL	SDI	BINARY DATA				SSM	P	
FLIGHT IDENT WORD 1 (CH 1, CH 2)	233	10011011	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 2 (CH 3, CH 4)	234	10011100	10	1010101 0 1010101 0000				00	p	
FLIGHT IDENT WORD 3 (CH 5, CH 6)	235	10011101	10	1010101 0 1010101 0000				00	P	
FLIGHT IDENT WORD 4 (CH 7, CH 8)	236	10011110	10	1010101 0 1010101 0000				00	P	

INPUT DATA FOR TEST 9.7D STEP e.

AIRCRAFT IDENTIFICATION INTERROGATION UF4												
RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP						
DATA:	0 0100	000	1 0000	111	0000 1000 0000 0000	UUT Mode-S Address						
DECODED DATA:	4	0	10 (Hex)	7 (Hex)	0800 (Hex)	Example: AAAAAA (Hex)						

AIRCRAFT IDENTIFICATION INTERROGATION FOR TEST 9.7D STEP f.

AIRCRAFT IDENTIFICATION SQUITTER																				
MB RF BIT:	33	37	38	40	41	46	47	52	53	58	59	64	65	70	71	76	77	82	83	88
BDS BUFFER BIT:	1	5	6	8	9	14	15	20	21	26	27	32	33	38	39	44	45	50	51	56
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8										
DATA:	0 0011	010	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION INTERROGATION FOR TEST 9.7D STEP g.

AIRCRAFT IDENTIFICATION SQUITTER																				
MB RF BIT:	33	37	38	40	41	46	47	52	53	58	59	64	65	70	71	76	77	82	83	88
BDS BUFFER BIT:	1	5	6	8	9	14	15	20	21	26	27	32	33	38	39	44	45	50	51	56
FIELD:	FORMAT TYPE	AIRCRAFT TYPE	CHAR. 1	CHAR. 2	CHAR. 3	CHAR. 4	CHAR. 5	CHAR. 6	CHAR. 7	CHAR. 8										
DATA:	0 0011	010	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101	010101

AIRCRAFT IDENTIFICATION INTERROGATION FOR TEST 9.7D STEP k.

TPI2535_01

Aircraft Identification Message (-308, -309 ONLY) Test 9.7D
Figure 1023/GRAPHIC 34-50-96-99B-094-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

FIELD BITS:				1	8	9	10	11	29	30	31	32
PARAMETER	VALUE	AWB VALUE	HEX LABEL	LABEL	SDI [1]	BINARY DATA				SSM	P	
GPS/GNSS TRACK	0 deg.	0000	103	01000011	10	0000 0000 0000 0000 000				11	P	
GPS/GNSS ALTITUDE	33,856 ft.	N/A	370	11111000	00	0000 0001 0001 0000 100				11	P	
LATITUDE-COURSE	-86.0 deg.	C2D82D83	110	01001000	10	1000 0011 0110 1000 011				11	P	
LATITUDE -FINE			120	01010000	10	0000 0001 1000 0011 010				11	P	
LONGITUDE-COURSE	-171.5 deg.	860B60B6	111	01001001	00	1101 1010 0000 1100 001				11	P	
LONGITUDE-FINE			121	01010001	10	0000 0000 1101 1010 000				11	P	

INPUT DATA FOR TEST 9.8B STEP f.

AIRBORNE POSITION INTERROGATION UF4												
RF BIT:	1	5	6	8	9	13	14	16	17	32	33	56
FIELD:	UF #	PC	RR	DI	SD	AP						
DATA:	0 0100	000	1 0000	111	0000 0101 0000 0000	UUT Mode-S Address						
DECODED DATA:	4	0	10 (Hex)	7 (Hex)	0500 (Hex)	Example: AAAAAA (Hex)						

AIRBORNE POSITION INTERROGATION UF4 FOR TEST 9.8B STEP g.

AIRBORNE POSITION MESSAGE_EVEN SECOND															
BIT SIGNIFICANCE:					MSB	LSB	EVEN	MSB	LSB	MSB	LSB				
MB RF BIT:	33	37	38	39	40	41	52	53	54	55	71	72	88		
BDS BUFFER BIT:	1	5	6	7	8	9	20	21	22	23	(15555)	39	40	(12444)	56
FIELD:	TYPE	SSS	Single ANT	ALTITUDE	TIME (T)	Format (F)	ENCODED LATITUDE	ENCODED LONGITUDE							
DATA:	1 0110	00	0 or 1	1010 1111 0010	0	0	1 0101 0101 0101 0101	1 0010 0100 0100 0100							

EVEN - SECOND, AIRBORNE POSITION MESSAGE FOR TEST 9.8B STEP h.

TPI2536_01

AIS/ADSS Primary Data (-308, -309, -408, -409) Test 9.8B
Figure 1024/GRAPHIC 34-50-96-99B-095-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

SUBTASK 34-50-96-810-005-A01
B. TDR-94/94D Alignment Procedures

STEP	PROCEDURE	DESIRED RESULTS																																																								
0.0	SETUP INSTRUCTIONS																																																									
0.1	Remove UUT dust cover. Connect TDR-94/94D as shown in Figure 1002/GRAPHIC 34-50-96-99B-036-A01 or Figure 1001/GRAPHIC 34-50-96-99B-020-A01. Test equipment item numbers (XX) that appear in the test setup diagrams are identified in Table 9003/Table 34-50-96-99A-042-A01 or Table 9002/Table 34-50-96-99A-032-A01 of the Special Tools, Fixtures, and Equipment section.																																																									
0.2	Set up IFR 1400C front panel as follows: <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;"><u>SWITCH</u></th> <th style="text-align: left; border-bottom: 1px solid black;"><u>POSITION</u></th> </tr> </thead> <tbody> <tr><td>DISPLAY SELECT</td><td>FREQ MHZ</td></tr> <tr><td>DME REPLY EFFICENXPDR MODE</td><td>C</td></tr> <tr><td>TACAN</td><td>OFF</td></tr> <tr><td>DBL INTERR</td><td>000.0</td></tr> <tr><td>/INTRF PULSE</td><td>OFF</td></tr> <tr><td>PRF</td><td>50</td></tr> <tr><td>SQTR</td><td>ON</td></tr> <tr><td>IDENT</td><td>OFF</td></tr> <tr><td>F2/P2-F1/P1</td><td>F2/P2</td></tr> <tr><td>XPDR P2/P3 DEV</td><td>0.00</td></tr> <tr><td>P2, P3</td><td>CAL, CAL</td></tr> <tr><td>FREQ</td><td>1030</td></tr> <tr><td>FUNCTION SELECT</td><td>XPDR</td></tr> <tr><td>DELTA F</td><td>0.00 OFF</td></tr> <tr><td>DME P2 DEV, P2</td><td>0.0, CAL</td></tr> <tr><td>XPDR PULSE WIDTH</td><td>0.80 CAL</td></tr> <tr><td>SLS/ECHO</td><td>-0, OFF</td></tr> <tr><td>RANGE/VEL/ACCEL</td><td>00000</td></tr> <tr><td>IN/OUT, -1 NMI/NORM</td><td>OUT, NORM</td></tr> <tr><td>RF LEVEL -DBM</td><td>90</td></tr> <tr><td>CW/NORM/OFF</td><td>NORM</td></tr> <tr><td>SUPPRESSOR</td><td>OFF</td></tr> <tr><td>SYNC T0/TAC/TD</td><td>T0</td></tr> <tr><td>SUPPRESSOR VAR</td><td>ADJ to 15V P-P</td></tr> <tr><td>CAL MARKS</td><td>1.45 US</td></tr> <tr><td>AUTO MAN/MAN STEP</td><td>MAN</td></tr> <tr><td>FREQ STEP RATE</td><td>OFF</td></tr> </tbody> </table>	<u>SWITCH</u>	<u>POSITION</u>	DISPLAY SELECT	FREQ MHZ	DME REPLY EFFICENXPDR MODE	C	TACAN	OFF	DBL INTERR	000.0	/INTRF PULSE	OFF	PRF	50	SQTR	ON	IDENT	OFF	F2/P2-F1/P1	F2/P2	XPDR P2/P3 DEV	0.00	P2, P3	CAL, CAL	FREQ	1030	FUNCTION SELECT	XPDR	DELTA F	0.00 OFF	DME P2 DEV, P2	0.0, CAL	XPDR PULSE WIDTH	0.80 CAL	SLS/ECHO	-0, OFF	RANGE/VEL/ACCEL	00000	IN/OUT, -1 NMI/NORM	OUT, NORM	RF LEVEL -DBM	90	CW/NORM/OFF	NORM	SUPPRESSOR	OFF	SYNC T0/TAC/TD	T0	SUPPRESSOR VAR	ADJ to 15V P-P	CAL MARKS	1.45 US	AUTO MAN/MAN STEP	MAN	FREQ STEP RATE	OFF	
<u>SWITCH</u>	<u>POSITION</u>																																																									
DISPLAY SELECT	FREQ MHZ																																																									
DME REPLY EFFICENXPDR MODE	C																																																									
TACAN	OFF																																																									
DBL INTERR	000.0																																																									
/INTRF PULSE	OFF																																																									
PRF	50																																																									
SQTR	ON																																																									
IDENT	OFF																																																									
F2/P2-F1/P1	F2/P2																																																									
XPDR P2/P3 DEV	0.00																																																									
P2, P3	CAL, CAL																																																									
FREQ	1030																																																									
FUNCTION SELECT	XPDR																																																									
DELTA F	0.00 OFF																																																									
DME P2 DEV, P2	0.0, CAL																																																									
XPDR PULSE WIDTH	0.80 CAL																																																									
SLS/ECHO	-0, OFF																																																									
RANGE/VEL/ACCEL	00000																																																									
IN/OUT, -1 NMI/NORM	OUT, NORM																																																									
RF LEVEL -DBM	90																																																									
CW/NORM/OFF	NORM																																																									
SUPPRESSOR	OFF																																																									
SYNC T0/TAC/TD	T0																																																									
SUPPRESSOR VAR	ADJ to 15V P-P																																																									
CAL MARKS	1.45 US																																																									
AUTO MAN/MAN STEP	MAN																																																									
FREQ STEP RATE	OFF																																																									

Alignment Procedure Cont.
Table 1002/Table 34-50-96-99A-010-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS														
0.3	Set up rear of ATC-1400C/S1403C test set as follows: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"><u>SWITCH</u></td> <td style="width: 50%;"><u>POSITION</u></td> </tr> <tr> <td>DECODER</td> <td>NARROW</td> </tr> <tr> <td>EQUALIZER</td> <td>OFF</td> </tr> <tr> <td>SELF-INTERR</td> <td>OFF</td> </tr> <tr> <td>INST DIM</td> <td>LOW</td> </tr> <tr> <td>ADDRESS</td> <td>10101100</td> </tr> </table>	<u>SWITCH</u>	<u>POSITION</u>	DECODER	NARROW	EQUALIZER	OFF	SELF-INTERR	OFF	INST DIM	LOW	ADDRESS	10101100			
<u>SWITCH</u>	<u>POSITION</u>															
DECODER	NARROW															
EQUALIZER	OFF															
SELF-INTERR	OFF															
INST DIM	LOW															
ADDRESS	10101100															
0.4	Set up front panel of 5359A time synthesizer as follows: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"><u>SWITCH</u></td> <td style="width: 50%;"><u>POSITION</u></td> </tr> <tr> <td>SLOPE</td> <td>N</td> </tr> <tr> <td>LEVEL</td> <td>+2V</td> </tr> <tr> <td>SYNC DELAY</td> <td>PRESET</td> </tr> <tr> <td>OUTPUT POLARITY</td> <td>NORM, POS</td> </tr> <tr> <td>AMPLITUDE</td> <td>ADJ to 2.5V</td> </tr> <tr> <td>OFFSET</td> <td>OFF, 0</td> </tr> </table>	<u>SWITCH</u>	<u>POSITION</u>	SLOPE	N	LEVEL	+2V	SYNC DELAY	PRESET	OUTPUT POLARITY	NORM, POS	AMPLITUDE	ADJ to 2.5V	OFFSET	OFF, 0	
<u>SWITCH</u>	<u>POSITION</u>															
SLOPE	N															
LEVEL	+2V															
SYNC DELAY	PRESET															
OUTPUT POLARITY	NORM, POS															
AMPLITUDE	ADJ to 2.5V															
OFFSET	OFF, 0															
0.5	Set up rear of 5359A time synthesizer as follows: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"><u>SWITCH</u></td> <td style="width: 50%;"><u>POSITION</u></td> </tr> <tr> <td>EXT TIMING</td> <td>DISABLE</td> </tr> <tr> <td>EVENTS,SLOPE</td> <td>P</td> </tr> <tr> <td>FREQ-STD</td> <td>INT</td> </tr> <tr> <td>ADDRESS</td> <td>0001000</td> </tr> </table> <p><u>NOTE:</u> Interrogation power levels and transmitter output power levels specified in this document are referenced to the rear connector(s) of the Unit Under Test (UUT). The insertion loss of coaxial cables between the UUT and the test equipment must be accounted for.</p> <p><u>NOTE:</u> Perform alignment steps 1.X for Receiver IF/LVPS Assembly, CPN 687-0727-004. Perform alignment steps 2.X for Receiver IF/LVPS Assembly, CPN 687-0727-005.</p>	<u>SWITCH</u>	<u>POSITION</u>	EXT TIMING	DISABLE	EVENTS,SLOPE	P	FREQ-STD	INT	ADDRESS	0001000					
<u>SWITCH</u>	<u>POSITION</u>															
EXT TIMING	DISABLE															
EVENTS,SLOPE	P															
FREQ-STD	INT															
ADDRESS	0001000															
1.0	Receiver IF/LVPS Assembly, Alignment for CPN 687-0727-004 or prior.															
1.1	Monitor the +5 V dc output at J7-26 with a DVM. Adjust A7R507 if necessary	Verify a reading between 4.99 to 5.01 V dc.														
1.2	Monitor J7-33 on Video Processor A6 with an oscilloscope.															

Alignment Procedure Cont.
Table 1002/Table 34-50-96-99A-010-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
1.3	Set the MODE-S test set to generate ATRBS MODE-C interrogations and apply to the bottom antenna connector. Set the interrogation rate to 450 per second	
1.4	a. Set the MODE-S test set signal strength to -79 dBm. Monitor the Bottom Video signal at A6P22-Pin 33. Adjust A7R131 fully clockwise. <u>NOTE:</u> The oscilloscope must be set to the averaging mode to properly measure the video pulse at the low signal levels required.	Adjust A7R140 for an observed video level of 0.7 volts peak.
	b. Set the MODE-S test set signal strength to -77 dBm.	Adjust A7R131 for an observed video level of 0.7 volts peak.
	c. Verify that the reply rate is between 90% and 100%. If not, readjust A7R140 for desired result.	Reply rate is between 90% and 100%.
1.5	Set the signal strength to -31 dBm. Adjust A7R133 for desired results.	Amplitude of the P1 pulse at J7-33 is 5.00 ±0.05 volts.
1.6	Repeat steps 1.4 and 1.5 as required.	
1.7	Monitor the positive end of A6C67 on top side of the card.	
1.8	Interrogate with a normal MODE-S signal at -27 dBm. Adjust A6R118 until the ditch-slope waveform resulting from P1 has the desired results.	16.2 ±0.2 microseconds wide at its base.
1.9	Do steps 1.10 thru 1.16 for the TDR-94D only. Apply MODE-C interrogations to the UUT top antenna connector.	
1.10	a. Set the MODE-S test set signal strength to -79 dBm. Monitor the Top Video signal at A6P22-Pin 31. Adjust A7R124 fully clockwise. <u>NOTE:</u> The oscilloscope must be set to the averaging mode to properly measure the video pulse at the low signal levels required.	Adjust A7R111 for an observed video level of 0.7 volts peak.
	b. Set the MODE-S test set signal strength to -77 dBm.	Adjust A7R124 for an observed video level of 0.7 volts peak.

Alignment Procedure Cont.
Table 1002/Table 34-50-96-99A-010-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
1.11	<p>Verify that the reply rate is between 90% and 100%. If not, readjust A7R111 for a reply rate between 90% and 100%.</p> <p><u>NOTE:</u> If the Minimum Trigger Level (MTL) cannot be established within the specified limits, or if the MTL does not stay within the specified limits over the operational temperature range, the A7R127 (for the Top channel) and/or A7R137 (for the Bottom channel) (CPN 705-3543-020) may be added as needed.</p>	
1.12	Set the MODE-S test set signal strength for -31 dBm. Adjust A7R123 for desired results.	Amplitude of the P1 pulse at J7-31 is 5.00 ±0.05 volts.
1.13	Repeat steps 1.11 and 1.12 as required.	
1.14	<p>a. Set the MODE-S test set signal strength to -50 dBm. Measure and note the amplitude of the P1 pulse at J7-31.</p> <p>b. Apply the same input signal level to the bottom channel. Measure and note the amplitude of the P1 pulse at J7-33.</p> <p>c. Verify that the two amplitudes are within 0.1 volts of each other. If this is not the case, reduce the stronger of the two measurements by adjusting the appropriate Slope Adjust, A7R123 or A7R133, until the difference is less than 0.1 volts.</p> <p><u>NOTE:</u> If this readjustment is performed, then the MTL must be readjusted in accordance with either step 1.4 or 1.11, whichever is appropriate for the Top or Bottom channel requiring adjustment.</p>	<p>_____ V</p> <p>_____ V</p> <p>Voltage difference should be less than 0.1 volt</p>
1.15	Monitor the positive end of A6C59 on the Video Processor board.	
1.16	<p>Set the MODE-S test set signal strength to -27 dBm. Adjust A6R117 on the Video Processor board such that the ditch-slope waveform resulting from P1 has the desired results.</p> <p><u>NOTE:</u> Extra care must be taken in the adjustments made in the following steps 1.17 through 1.19. DPSK trimmer capacitor A7C301 adjustments should be made in very small increments or steps. These adjustments are critical to the performance of the UUT. Capacitor A7C301 should only be adjusted at the board or card level (if possible).</p>	16.2 ±0.2 μs wide at its base

Alignment Procedure Cont.
Table 1002/Table 34-50-96-99A-010-A01

ROCKWELL COLLINS
COMPONENT MAINTENANCE MANUAL with IPL
TDR-94, PART NO 622-9352

STEP	PROCEDURE	DESIRED RESULTS
1.17	<p>To align the DPSK Demodulator VCO, interrogate the bottom channel with MODE-S ONLY ALL-CALL interrogations having a signal strength of -60 dBm.</p> <p>Vary the interrogation center frequency above 1030 MHz until the reply rate reduces to 90% and note the frequency as the upper frequency limit.</p> <p>Vary the interrogation center frequency below 1030 MHz and note the frequency as the lower frequency limit.</p> <p>Adjust A7C306 such that the two limit frequencies are equidistant from 1030.00 MHz. Verify that both frequencies are removed from 1030 MHz by at least 0.6 MHz. If exact centering of the center frequency is difficult to achieve, the adjustment should be made to slightly favor the higher frequency limit.</p>	<p>_____</p> <p>_____</p>
1.18	<p>The IF bandwidth may be adjusted with A7R305. Adjustment of A7R305 is critical to the performance of the unit and should not be performed at the top-level assembly unless necessary. If adjustment of A7R205 is necessary, then the frequency centering adjustments performed in step 1.17 must be rechecked.</p>	
1.19	<p>To align the DPSK demodulator VCO, interrogate the top channel with a Mode-S Only All-Call interrogations having a signal level of -60 dBm and a center frequency of 1030.0 MHz. Monitor A7TP303 with the oscilloscope and slowly adjust A7C352 for the cleanest and most square observed signal pulses.</p> <p><u>NOTE:</u> DPSK adjustments are interactive. Steps 1.17 through 1.19 should be rechecked prior to continuing with the following procedures.</p>	
1.20	<p>Monitor J7-33. Interrogate the bottom channel with MODE-A or MODE-C interrogations having a signal level of -67 dBm and measure the video amplitude of P1 observed. Turn off all interrogations to the UUT.</p> <p><u>NOTE:</u> Enable the Self-Test function and adjust A7R122 such that the observed self-test signal P1 is equal to the video amplitude previously observed within ± 0.2 volts.</p>	

Alignment Procedure Cont.
Table 1002/Table 34-50-96-99A-010-A01