




Owner's Handbook

Tiger 1200 XR, Tiger XR_x, Tiger XR_x-LRH, Tiger XC_x, Tiger XR_T and Tiger XC_A



This handbook contains information on the Triumph Tiger 1200 XR, Tiger XR_x, Tiger XR_x-LRH, Tiger XC_x, Tiger XR_T and Tiger XC_A motorcycles. Always store this Owner's Handbook with the motorcycle and refer to it for information whenever necessary.

The information contained in this publication is based on the latest information available at the time of printing. Triumph reserves the right to make changes at any time without prior notice, or obligation.

Not to be reproduced wholly or in part without the written permission of Triumph Motorcycles America Limited.

© Copyright 10.2017 Triumph Motorcycles America Limited.

Publication part number 3855518-US issue 1

TABLE OF CONTENTS

This handbook contains a number of different sections. The table of contents below will help you find the beginning of each section where, in the case of the major sections, a further table of contents will help you find the specific subject required.

Foreword.....	3
Safety First.....	7
Warning Labels.....	14
Parts Identification.....	16
Serial Numbers.....	20
Instruments.....	21
General Information.....	89
How to Ride the Motorcycle.....	139
Accessories, Loading and Passengers.....	158
Maintenance.....	163
Cleaning and Storage.....	207
Specifications.....	217
Index.....	222

FOREWORD

Warnings, Cautions and Notes

Throughout this Owner's Handbook particularly important information is presented in the following form:

 **Warning**

This warning symbol identifies special instructions or procedures, which if not correctly followed could result in personal injury, or loss of life.

 **Caution**

This caution symbol identifies special instructions or procedures, which, if not strictly observed, could result in damage to, or destruction of, equipment.

Note:

- **This note symbol indicates points of particular interest for more efficient and convenient operation.**

Warning Labels



At certain areas of the motorcycle, the symbol (above) can be seen. The symbol means CAUTION: REFER TO THE HANDBOOK and will be followed by a pictorial representation of the subject concerned.

Never attempt to ride the motorcycle or make any adjustments without reference to the relevant instructions contained in this handbook.

See page **14** for the location of all labels bearing this symbol. Where necessary, this symbol will also appear on the pages containing the relevant information.

Maintenance

To ensure a long, safe and trouble free life for your motorcycle, maintenance should only be carried out by an authorized Triumph dealer.

Only an authorized Triumph dealer will have the necessary knowledge, equipment and skills to maintain your Triumph motorcycle correctly.

To locate your nearest Triumph dealer, visit the Triumph website at www.triumph.co.uk or telephone Triumph Motorcycles America Limited on (678) 854 2010.

Foreword

Off-Road Use

All models are designed for on-road and light off-road use. Light off-road use includes use on unpaved, dirt or gravel roads, but does not include riding on any motocross course, any off-road competition (such as motocross or enduro riding), or riding off-road with a passenger.

Light off-road use does not include jumping the motorcycle or riding over obstacles. Do not attempt to jump over any bumps or obstacles. Do not attempt to ride over any obstacles.

Noise Control System

Tampering with the noise control system is prohibited.

Owners are warned that the law may prohibit:

1. The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use and,
2. the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Immobilizer and Tire Pressure Monitoring System

This device complies with part 15 of the Federal Communications Commission (FCC) Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to the device could void the user's authority to operate the equipment.

Tires

With reference to the Pneumatic Tires and Tubes for Automotive Vehicles (Quality Control) Order, 2009, Cl. No. 3 (c), it is declared by M/s. Triumph Motorcycles Ltd. that the tires mounted on this motorcycle meet the requirements of IS 15627: 2005 and comply with the requirements under Central Motor Vehicle Rules (CMVR), 1989.

Tiger 1200 XR_x-LRH (Low Ride Height) Models

Unless stated otherwise, information, instructions, and specifications for Tiger 1200 XR_x-LRH models are identical to those detailed in this Owner's Handbook for the Tiger 1200 XR_x standard ride height models.

Note:

- **The Tiger 1200 XR_x-LRH models cannot be equipped with a center stand.**

Owner's Handbook

Warning

This Owner's Handbook, and all other instructions that are supplied with your motorcycle, should be considered a permanent part of your motorcycle and should remain with it even if your motorcycle is subsequently sold.

All riders must read this Owner's Handbook and all other instructions which are supplied with your motorcycle, before riding, in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations. Do not lend your motorcycle to others as riding when not familiar with your motorcycle's controls, features, capabilities and limitations can lead to an accident.

Thank you for choosing a Triumph motorcycle. This motorcycle is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Please read this Owner's Handbook before riding in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations.

This handbook includes safe riding tips, but does not contain all the techniques and skills necessary to ride a motorcycle safely.

Triumph strongly recommends that all riders undertake a safety course approved by the Motorcycle Safety Foundation to ensure safe operation of this motorcycle. Information about the nearest Motorcycle Safety Foundation course to you can be obtained by calling the following nationwide toll free number: 800-447-4700, or by writing to the Motorcycle Safety Foundation at: 2, Jenner Street, Irvine, California 92718. To ensure a long and trouble free life for your motorcycle, maintenance should be carried out as described in this manual by an authorized Triumph dealer.

Foreword

This handbook is available from your local dealer in:

- English
- US English
- French
- German
- Italian
- Dutch
- Spanish
- Portuguese
- Swedish
- Japanese
- Thai.

Talk to Triumph

Our relationship with you does not end with the purchase of your Triumph. Your feedback on the buying and ownership experience is very important in helping us develop our products and services for you.

Please help us by ensuring your authorized Triumph dealership has your email address and registers this with us. You will then receive an online customer satisfaction survey invitation to your email address where you can give us this feedback.

Your Triumph Team.

SAFETY FIRST

The Motorcycle

Warning

All models are designed for on-road use and light off-road use. Light off-road use includes use on unpaved, dirt or gravel roads, but does not include riding on any motocross course, any off-road competition (such as motocross or enduro riding), or riding off-road with a passenger.

Light off-road use does not include jumping the motorcycle or riding over obstacles. Do not attempt to jump over any bumps or obstacles. Do not attempt to ride over any obstacles.

Extreme off-road use could lead to loss of motorcycle control and an accident.

Warning

Tiger 1200 XR_x-LRH (Low Ride Height) Model

The Tiger 1200 XR_x-LRH motorcycles are equipped with lowered suspension and have reduced ground clearance.

As a result, the cornering bank angles that can be achieved by the Tiger 1200 XR_x-LRH are reduced, when compared with the standard ride height Tiger 1200 XR_x.

When riding, keep in mind that your motorcycle's ground clearance is limited. Operate your motorcycle in an area free from traffic to gain familiarity with the motorcycle's ground clearance and bank angle limitations.

Banking to an unsafe angle or unexpected contact with the ground may cause instability, loss of motorcycle control and an accident.

Warning

This motorcycle is not designed to tow a trailer or be mounted with a sidecar.

Installing a sidecar and/or a trailer may result in loss of motorcycle control and an accident.

Safety First

Warning

This motorcycle is designed for use as a two-wheeled vehicle capable of carrying a rider on their own, or a rider and one passenger.

The total weight of the rider, and any passenger, accessories and luggage must not exceed the maximum load limit of:

Tiger 1200 XR - 507 lb (230 kg)

Tiger 1200 XRx - 502 lb (228 kg)

Tiger 1200 XRx-LRH - 507 lb (230 kg)

Tiger 1200 XRT - 502 lb (228 kg)

Tiger 1200 XCx - 491 lb (223 kg)

Tiger 1200 XCA - 493 lb (224 kg).

Warning

This motorcycle is equipped with a catalytic converter below the engine, which along with the exhaust system reaches very high temperature during engine operation.

Flammable materials such as grass, hay/straw, leaves, clothing and luggage etc. could ignite if allowed to come into contact with any part of the exhaust system and catalytic converter.

Always make sure that flammable materials are not allowed to contact the exhaust system or catalytic converter.

Fuel and Exhaust Fumes

Warning

GASOLINE IS HIGHLY FLAMMABLE:

Always turn off the engine when refueling.

Do not refuel or open the fuel filler cap while smoking or in the vicinity of any open (naked) flame.

Take care not to spill any gasoline on the engine, exhaust pipes or mufflers when refueling.

If gasoline is swallowed, inhaled or allowed to get into the eyes, seek immediate medical attention.

Spillage on the skin should be immediately washed off with soap and water and clothing contaminated with gasoline should immediately be removed.

Burns and other serious skin conditions may result from contact with gasoline.

Warning

Never start your engine or let it run for any length of time in a closed area.

The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time.

Always operate your motorcycle in the open-air or in an area with adequate ventilation.

Helmet and Clothing

Warning

When riding the motorcycle, both rider and passenger must always wear a motorcycle helmet, eye protection, gloves, boots, trousers (close fitting around the knee and ankle) and a brightly colored jacket. Brightly colored clothing will considerably increase a rider's (or passenger's) visibility to other operators of road vehicles. Although full protection is not possible, wearing correct protective clothing can reduce the risk of injury when riding.

Warning

A helmet is one of the most important pieces of riding gear as it offers protection against head injuries. You and your passenger's helmet should be carefully chosen and should fit you or your passenger's head comfortably and securely. A brightly colored helmet will increase a rider's (or passenger's) visibility to other operators of road vehicles.

An open face helmet offers some protection in an accident though a full face helmet will offer more.

Always wear a visor or approved goggles to help vision and to protect your eyes.



cbma

When choosing a helmet, always look for a DOT (Department of Transport) sticker indicating that the helmet has DOT approval. Do not buy a helmet without DOT approval.

Riding

Warning

Never ride the motorcycle when fatigued or under the influence of alcohol or other drugs.

Riding when under the influence of alcohol or other drugs is illegal.

Riding when fatigued or under the influence of alcohol or other drugs reduces the rider's ability to maintain control of the motorcycle and may lead to loss of control and an accident.

Warning

All riders must be licensed to operate the motorcycle. Operation of the motorcycle without a license is illegal and could lead to prosecution.

Operation of the motorcycle without formal training in the correct riding techniques that are necessary to become licensed is dangerous and may lead to loss of motorcycle control and an accident.

Safety First

Warning

Always ride defensively and wear the protective equipment mentioned elsewhere in this foreword. Remember, in an accident, a motorcycle does not give the same impact protection as a car.

Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road traveled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in potentially hazardous driving conditions such as bad weather or heavy traffic.

Warning

Continually observe and react to changes in road surface, traffic and wind conditions. All two-wheeled vehicles are subject to external forces which may cause an accident. These forces include but are not limited to:

Wind draft from passing vehicles

Potholes, uneven or damaged road surfaces

Bad weather

Rider error.

Always operate the motorcycle at moderate speed and away from heavy traffic until you have become thoroughly familiar with its handling and operating characteristics. Never exceed the legal speed limit.

Warning

Ensure that you know and respect the rules of the road. Read and observe publications such as 'MOTORCYCLE SAFETY', 'YOU AND YOUR MOTORCYCLE, RIDING TIPS' and also read and become familiar with the contents of the MOTORCYCLE HANDBOOK for your state.

Caution

This Triumph motorcycle is not equipped with spark arresters. Operation in forests, brush or grass areas may violate state and local laws and regulations.

Wobble/Weave

A weave is a relatively slow oscillation of the rear of the motorcycle, while a wobble is a rapid, possibly strong shaking of the handlebar. These are related but distinct stability problems usually caused by excessive weight in the wrong place, or by a mechanical problem such as worn or loose bearings or under-inflated or unevenly worn tires.

Your solution to both situations is the same. Keep a firm hold on the handlebars without locking arms or fighting the steering. Smoothly ease off the throttle to slow gradually. Do not apply the brakes, and do not accelerate to try to stop the wobble or weave. In some cases, it helps to shift your body weight forward by leaning over the tank.

Copyright © 2005 Motorcycle Safety Foundation. All rights reserved. Used with permission.

Handlebars and Footrests

Warning

The rider must maintain control of the vehicle by keeping hands on the handlebars at all times.

The handling and stability of a motorcycle will be adversely affected if the rider removes their hands from the handlebars, resulting in loss of motorcycle control and an accident.

Warning

The rider and passenger must always use the footrests provided, during operation of the vehicle.

By using the footrests, both rider and passenger will reduce the risk of inadvertent contact with any motorcycle components and will also reduce the risk of injury from entrapment of clothing.

Parking

Warning

Always switch off the engine and never leave any keys with the motorcycle before leaving it unattended. By removing any keys, the risk of use of the motorcycle by unauthorized or untrained persons is reduced.

When parking the motorcycle, always remember the following:

Engage first gear to help prevent the motorcycle from rolling off the stand.

The engine and exhaust system will be hot after riding. DO NOT park where pedestrians, animals and/or children are likely to touch the motorcycle.

Do not park on soft ground or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over.

For further details, please refer to the 'How to Ride the Motorcycle' section of this Owner's Handbook.

Parts and Accessories

Warning

Owners should be aware that the only approved parts, accessories and conversions for any Triumph motorcycle are those which carry official Triumph approval and are installed to the motorcycle by an authorized dealer.

In particular, it is extremely hazardous to install or replace parts or accessories whose installation requires the dismantling of, or addition to, either the electrical or fuel systems and any such modification could cause a safety hazard.

The installation of any non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspect of the motorcycle operation that may result in an accident causing injury or death.

Triumph does not accept any liability whatsoever for defects caused by the installation of non-approved parts, accessories or conversions or the installation of any approved parts, accessories or conversions by non-approved personnel.

Maintenance/Equipment

Warning

Consult your authorized Triumph dealer whenever there is doubt as to the correct or safe operation of this Triumph motorcycle.

Remember that continued operation of an incorrectly performing motorcycle may aggravate a fault and may also compromise safety.

Warning

Ensure all equipment that is required by law is installed and functioning correctly. The removal or alteration of the motorcycle's lights, mufflers, emission or noise control systems can violate the law. Incorrect or improper modification may adversely affect the handling, stability or other aspect of the motorcycle operation, which may result in an accident causing injury or death.

Warning

If the motorcycle is involved in an accident, collision or fall, it must be taken to an authorized Triumph dealer for inspection and repair. Any accident can cause damage to the motorcycle that, if not correctly repaired, may cause a second accident that may result in injury or death.


Warning Labels

WARNING LABELS

The labels detailed on this and the following pages indicate important safety information found in this handbook. Before riding, make sure that all riders have understood and complied with all the information to which these labels relate.

For illustration purposes, the Tiger 1200 XR motorcycle is shown.

Warning Label Locations




1. Headlight (page 201)
2. Coolant (page 172)
3. Snow and Mud Tires (page 217)
4. Breaking-In (page 136)

5. Gear Position (page 145)
6. Tires (page 188)
7. Panniers (if equipped) (page 129)

⚠ Caution

All warning labels and decals, with the exception of the Breaking-in label, are mounted on the motorcycle using a strong adhesive. In some cases, labels are installed prior to an application of paint lacquer.

Therefore, any attempt to remove the warning labels will cause damage to the paintwork or body work.




1. Engine Oil (page 169)
2. Unleaded Fuel (page 115)
3. Helmet (page 9)
4. Windshield (page 118)

5. Daily Safety Checks (page 137)
6. Tire Pressure Monitoring System (TPMS) (if equipped) (page 111)


Parts Identification

PARTS IDENTIFICATION



- | | |
|---|--|
| 1. Headlight | 10. Rear turn signal |
| 2. Front turn signal | 11. Rear brake caliper |
| 3. Electrical accessory socket | 12. Rear brake disc |
| 4. Fuel tank and fuel filler cap | 13. Center stand (if equipped) |
| 5. Rider's heated seat switch
(Tiger 1200 XR only) | 14. Rear suspension damping adjuster
(Tiger 1200 XR only) |
| 6. Battery and fuse boxes (under the seat) | 15. Side stand |
| 7. Passenger's heated seat switch
(if equipped) | 16. Gear shift pedal |
| 8. USB socket (under the seat) | 17. Coolant expansion tank |
| 9. Electrical accessory socket
(if equipped) | 18. Radiator cowl |
| | 19. Front brake caliper |
| | 20. Front brake disc |

Parts Identification (Continued)




- | | |
|---|---|
| 1. Brake/tail light | 8. Front fog lights (if equipped) |
| 2. Rear brake fluid reservoir | 9. Front fork |
| 3. Oil filler cap | 10. Engine oil level sight glass |
| 4. Mirror | 11. Rear brake pedal |
| 5. Front suspension damping adjusters
(Tiger 1200 XR only) | 12. Rear suspension spring preload
adjuster (model specific) |
| 6. Windshield | 13. Muffler |
| 7. Headlight adjuster | 14. Seat lock |

Parts Identification

Rider View Parts Identification


Tiger 1200 XR Only



- | | |
|--------------------------------------|---------------------------------------|
| 1. Clutch lever | 12. Engine stop switch |
| 2. Instrument select button | 13. Cruise control adjust button |
| 3. Headlight dimmer switch | 14. Front brake lever |
| 4. Instrument scroll button | 15. Starter button |
| 5. Fog lights switch (if equipped) | 16. Hazard warning lights button |
| 6. Clutch fluid reservoir | 17. Electrical accessory socket |
| 7. Multifunction display screen | 18. Heated grips switch (if equipped) |
| 8. Tachometer | 19. Mode button |
| 9. Ignition switch | 20. Horn button |
| 10. Motorcycle status display screen | 21. Turn signal switch |
| 11. Front brake fluid reservoir | |

Rider View Parts Identification

All Models except Tiger 1200 XR




ckcx

- | | |
|--|---|
| 1. Clutch lever | 12. Front brake lever |
| 2. Headlight dimmer switch | 13. Engine start/stop switch |
| 3. Heated seats switch (if equipped) | 14. HOME button |
| 4. Front fog lights switch (if equipped) | 15. Joystick button |
| 5. Cruise control adjust switch | 16. Electrical accessory socket |
| 6. MODE button | 17. Turn signal switch |
| 7. Clutch fluid reservoir | 18. Horn button |
| 8. Multifunction display screen | 19. Daytime Running Lights (DRL) switch (if equipped) |
| 9. Master ignition switch (if equipped) | 20. Heated grips switch (if equipped) |
| 10. Front brake fluid reservoir | |
| 11. Hazard warning lights switch | |

Serial Numbers

SERIAL NUMBERS

Vehicle Identification Number (VIN)




1. VIN number
2. Label

The Vehicle Identification Number (VIN) is stamped into the steering head area of the frame. In addition, It is displayed on a label which is mounted on the right hand side of the front subframe.

Record the vehicle identification number in the space provided below.

Engine Serial Number



1. Engine serial number

The engine serial number is stamped on the engine crankcase, immediately below the gearbox.

Record the engine serial number in the space provided below.

INSTRUMENTS


Instrument Displays

Overview

There are two types of instrument displays mounted to specific motorcycles models.

All Models except Tiger 1200 XR

All models except for Tiger 1200 XR are equipped with a full color Thin Film Transistor (TFT) digital instrument display.




Thin Film Transistor (TFT) Instrument Display

For more information on the TFT instrument display and its operation, see page 22.

Tiger 1200 XR Models Only

Only Tiger 1200 XR models are equipped with a Liquid Crystal Display (LCD) instrument display.



Liquid Crystal Display (LCD) Instrument Display

For more information on the LCD instrument display and its operation, see page 57.

Instruments


Thin Film Transistor (TFT) Instrument Display

Table of Contents

Instrument Panel Layout.....	23
TFT Display Navigation.....	24
TFT Themes and Styles.....	24
Warning Lights.....	24
Speedometer and Odometer.....	30
Tachometer.....	31
Gear Position Display.....	31
Fuel Gage.....	32
Service Interval Announcement.....	32
Ambient Air Temperature.....	32
Riding Modes.....	33
Riding Mode Selection.....	34
Information Tray.....	36
Main Menu.....	42
Instrument Panel Position Adjustment.....	56

Instrument Panel Layout

The TFT instrument display is mounted to all models except Tiger 1200 XR. Not all instrument features are available on all models.



- | | |
|---|----------------------------------|
| 1. Alarm/immobilizer status indicator light (alarm is an accessory kit) | 8. Gear position symbol |
| 2. Warning lights | 9. Clock |
| 3. Speedometer | 10. Fuel gage |
| 4. Right hand turn signal | 11. Information tray |
| 5. Daytime Running Light (DRL) (if equipped) | 12. Ambient air temperature |
| 6. Oil pressure warning light | 13. Fuel level low warning light |
| 7. Engine management Malfunction Indicator Light (MIL) | 14. ABS warning light |
| | 15. High beam warning light |
| | 16. Left hand turn signal |
| | 17. Current riding mode |

Instruments

TFT Display Navigation

The table below describes the instrument icons and buttons used to navigate through the instrument menus described in this handbook.



Home button (right hand switch housing).



Mode button (left hand switch housing).



Joystick left/right or up/down.



Joystick Centre (press).



Selection arrow (right shown).



Information Tray - left/right scroll via joystick.



Information Tray - up/down scroll via joystick.



Option available within the Information Tray - scroll via joystick up/down.



Short press (press and release) via joystick center.



Long press (press and hold) via joystick center.



Reset current feature, (only available with joystick long press).

TFT Themes and Styles

There is the option to change the style of the instrument display.


Depending on the motorcycle model, there are either one or two themes. Each theme has three different styles to select from.

To select a theme or style, see page **51**.

Styles can also be selected through the Style Options tray, see page **41**.

Theme 1, Style 1 is used for visual recognition throughout this Owner's Handbook.

Theme 1



Theme 1 Style 1

Warning Lights

Note:

- When the ignition is switched on, the instrument warning lights will illuminate for 1.5 seconds and will then go off (except those which remain on until the engine starts, as described in the following pages).

For additional warning and information messages, see page **37**.

Engine Management System Malfunction Indicator Light (MIL)



The Malfunction Indicator Light (MIL) for the engine management system illuminates when the ignition is switched ON (to indicate that it is working) but should not become illuminated when the engine is running.

If the MIL becomes illuminated when the engine is running, this indicates that a fault has occurred in one or more of the systems controlled by the engine management system. In such circumstances, the engine management system will switch to 'limp-home' mode so that the journey may be completed, if the fault is not so severe that the engine will not run.

Warning

Reduce speed and do not continue to ride for longer than is necessary with the MIL illuminated. The fault may adversely affect engine performance, exhaust emissions and fuel consumption.

Reduced engine performance could cause a dangerous riding condition, leading to loss of control and an accident.

Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Note:

- If the MIL flashes when the ignition is switched ON contact an authorized Triumph dealer as soon as possible to have the situation rectified. In these circumstances the engine will not start.

Low Oil Pressure Warning Light



With the engine running, if the engine oil pressure becomes dangerously low, the low oil pressure warning light will illuminate.

Caution

Stop the engine immediately if the low oil pressure warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the low oil pressure warning light is illuminated.

Note:

- The low oil pressure warning light will illuminate if the ignition is switched ON without running the engine.

Immobilizer/Alarm Indicator Light

This Triumph motorcycle is equipped with an engine immobilizer which is activated when the ignition is switched off.

Instruments

Not Equipped With Alarm

When the ignition is switched off, the immobilizer light will flash on and off for 24 hours to show that the engine immobilizer is on. When the ignition is switched on, the immobilizer and the indicator light will be off.

If the indicator light remains on it indicates that the immobilizer has a malfunction that requires investigation. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Equipped With Alarm

The immobilizer/alarm light will only illuminate when the conditions described in the genuine Triumph accessory alarm instructions are met.

ABS (Anti-Lock Brake System) Warning Light



When the ignition is switched on, it is normal that the ABS warning light will flash on and off. The light will continue to flash after engine start-up until the motorcycle first reaches a speed exceeding 6 mph (10 km/h) when it will go off.

Note:

- **Traction control will not function if there is a malfunction with the ABS. The warning lights for the ABS, traction control and the MIL will be illuminated.**

The warning light should not illuminate again until the engine is restarted unless there is a fault, or the ABS is switched off - the warning light will remain illuminated.

If the warning light becomes illuminated at any other time while riding it indicates that the ABS has a malfunction that requires investigation.

Warning

If the ABS is not functioning, the brake system will continue to function as a non-ABS equipped brake system. Do not continue to ride for longer than is necessary with the warning light illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified. In this situation braking too hard will cause the wheels to lock resulting in loss of motorcycle control and an accident.

For details on how to select different ABS settings, see page 33.

Traction Control (TC) Indicator Light



The TC indicator light is used to indicate that the traction control system is active and is working to limit rear wheel slip during periods of hard acceleration or under wet or slippery road conditions.

Warning

If the traction control is not functioning, care must be taken when accelerating and cornering on wet/slippery road surfaces to avoid rear wheel spin. Do not continue to ride for longer than is necessary with the Engine Management System Malfunction Indicator Light (MIL) and traction control warning lights illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked.

Hard acceleration and cornering in this situation may cause the rear wheel to spin resulting in loss of motorcycle control and an accident.

TC Indicator Light Operation:

TC Switched On:

- Under normal riding conditions the indicator light will remain off.
- The indicator light will flash rapidly when the traction control system is working to limit rear wheel slip during periods of hard acceleration or under wet or slippery road conditions.

TC Switched Off:

The indicator light will not illuminate. Instead the TC disabled warning light will be illuminated (see page 27).

Note:

- **Traction control will not function if there is a malfunction with the ABS system. The warning lights for the ABS, traction control and the MIL will be illuminated.**

Traction Control (TC) Disabled Warning Light



The TC disabled warning light should not illuminate unless traction control is switched off or there is a malfunction.

If the warning light becomes illuminated at any other time while riding, it indicates that the traction control system has a malfunction that requires investigation.

Cruise Control Light



The cruise control can only be activated when the motorcycle is traveling at a speed between 19 to 100 mph (30 to 160 km/h) and is in 3rd gear or higher. When activated, the cruise control light will be illuminated (see page 104).

Warning

Cruise control must only be used where you can ride safely at a steady speed.

Cruise control should not be used when riding in heavy traffic, on roads with sharp/blind bends or when they are slippery.

Using cruise control in heavy traffic, on roads with sharp/blind bends or when they are slippery, may result in loss of motorcycle control and an accident.

Instruments

Triumph Semi Active Suspension (TSAS) Warning Light



When the ignition is switched on the warning light will illuminate for 1.5 seconds and then go out.

The warning light has two modes:

Calibration

The TSAS system will recalibrate adjustment motors under the following conditions:

- If the battery has been disconnected for any reason.
- If a fault occurs with the TSAS system during normal operation.

The warning light will flash twice every second during system recalibration, and a message will be shown in the display.

During recalibration the motorcycle must remain stationary. Riding the motorcycle will cause the recalibration to be stopped and the warning light to remain lit.

Fault

If the warning light illuminates continuously or at any other time it indicates one of the following:

- A system recalibration has been interrupted. Allow the system to recalibrate.
- A fault has occurred with the system that requires investigation. Warning messages will be shown in the display. Allow the system to recalibrate. If the fault is still present after recalibration, contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Full details of the Triumph Semi Active Suspension (TSAS) system and the system calibration are described starting on page **108**.

Turn Signals



When the turn signal switch is turned to the left or right, the indicator warning light will flash on and off at the same speed as the turn signals.

Hazard Warning Lights

To turn the hazard warning lights on or off, press and release the hazard warning light switch.

The ignition must be switched ON for the hazard warning lights to function.

The hazard warning lights will remain on if the ignition is switched off, until the hazard warning light switch is pressed again.

High Beam Button



When the high beam button is pressed the high beam will be switched on. Each press of the button will swap between dip and high beam.

Note:

- **If daytime running lights are installed on the motorcycle, the high beam button has additional functionality.**

If the DRL switch is in the daytime running lights position, then press and hold the high beam button to turn the high beam on. It will remain on as long as the button is held in and will turn off as soon as the button is released.

Note:

- **A lighting on/off switch is not installed on this model. The brake/tail light and license plate light all function automatically when the ignition is turned to the ON position.**
- **The headlight will function when the ignition switch is turned to the ON position. The headlight will go off while pressing the starter button until the engine starts.**

Daytime Running Lights (DRL)



When the ignition is switched ON and the daytime running lights switch is set to DAYTIME RUNNING LIGHTS, the daytime running lights warning light will illuminate.

The daytime running lights and low beam headlights are operated manually using a switch on the left hand switch housing, see page 97.

Warning

Do not ride for longer than necessary in poor ambient light conditions with the Daytime Running Lights (DRL) in use.

Riding with the Daytime Running Lights when dark, in tunnels or where poor ambient light is apparent may reduce the riders vision or blind other road users.

Blinding other road users or reduced vision in low ambient light levels may result in loss of motorcycle control and an accident.

Note:

- **During daylight hours the Daytime Running Lights improve the motorcycles visibility to other road users.**
- **Low beam headlights must be used in any other conditions unless the road conditions allow for high beam headlights to be used.**

Low Fuel Warning Light



The low fuel warning light will illuminate when there is approximately 1.0 gallon (3.5 liters) of fuel remaining in the tank.

Instruments

Tire Pressure Monitoring System (TPMS) Warning Light (if equipped)



Warning

Stop the motorcycle if the Tire Pressure Monitoring System (TPMS) warning light illuminates red.

Do not ride the motorcycle until the tires have been checked and the tire pressures are at their recommended pressure when cold.


Note:

- The Tire Pressure Monitoring System (TPMS) is available as an accessory option on all models.



The TPMS warning light will only illuminate red when the front or rear tire pressure is below the recommended pressure, or no signal is received. It will not illuminate if the tire is over inflated. For more information, see page 111.

When the warning light is illuminated, the TPMS symbol indicating which is the deflated tire and its pressure will automatically be visible in the display area.



OPER

1. TPMS light
2. Front tire indicator
3. Rear tire indicator
4. Mode button
5. Joystick control

The tire pressure at which the warning light illuminates is temperature compensated to 68°F (20°C) but the numeric pressure display associated with it is not, see page 189. Even if the numeric display seems at or close to the standard tire pressure when the warning light is on, a low tire pressure is indicated and a puncture is the most likely cause.

Speedometer and Odometer

The speedometer indicates the road speed of the motorcycle.

The odometer shows the total distance that the motorcycle has travelled.

Tachometer



Caution


Never allow engine speed to enter the red zone as severe engine damage may result.

The tachometer shows the engine speed in revolutions per minute - rpm (r/min). At the end of the tachometer range there is the red zone.


Engine speeds in the red zone are above maximum recommended engine speed and are also above the range for best performance.

Gear Position Display

The gear position display indicates which gear (one to six) has been engaged. When the transmission is in neutral (no gear selected), the display will show N.



1. Gear position display (neutral position shown)




1. Gear position display (third gear shown)

Instruments

Fuel Gage

The fuel gage indicates the amount of fuel in the tank.



1. Fuel gage

With the ignition switched on, a filled line indicates the fuel remaining in the fuel tank.

Note:

- **The fuel gage colors may vary depending on the theme or style chosen.**

The gage markings indicate intermediate fuel levels between E (empty) and F (full).

The low fuel warning light will illuminate when approximately 1.0 gallon (3.5 liters) of fuel is remaining in the tank and you should refuel at the earliest opportunity.

The range to empty and instantaneous fuel consumption will be also shown in the information tray. Press the joystick center to acknowledge and hide the low fuel warning.

After refueling, the fuel gage and range to empty information will be updated only while riding the motorcycle. Depending on the riding style, updating could take up to five minutes.

Service Interval Announcement



The service interval announcement shows the total distance or time that the motorcycle has remaining before a service is required. When the remaining distance is 0 miles (0 km), or the remaining time is 0 days, the service symbol will remain on until the service has been carried out and the system has been reset by your authorized Triumph dealer.

If the service is overdue then OVERDUE will be shown and the service symbol will be shown in the information tray.

When the service has been carried out by your authorized Triumph dealer, the system will be reset.

The distance to the next service or OVERDUE message will also be shown on the instrument start up screen when the ignition is turned on.

The service symbol will also be shown if a fault has occurred and the ABS and/or MIL warning lights are illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Ambient Air Temperature

The ambient air temperature is displayed as either °C or °F.

When the motorcycle is stationary the heat of the engine may affect the accuracy of the ambient temperature display.

Once the motorcycle starts moving the display will return to normal after a short time.

To change the temperature from °C or °F see page 53.

Frost Symbol



The frost symbol will illuminate if the ambient air temperature is 39°F (4°C) or lower.

The frost symbol will remain illuminated until the temperature rises to 42°F (6°C).

An alert will also be displayed in the information tray.



CAUTION: LOW AIR TEMPERATURE
RISK OF SURFACE ICE
1/3 warnings



ACKNOWLEDGE

Warning

Black ice (sometimes called clear ice) can form at temperatures several degrees above freezing (32°F (0°C)), especially on bridges and in shaded areas.

Always take extra care when the temperatures are low and reduce speed in potentially hazardous driving conditions such as bad weather.

Excess speed, hard acceleration, heavy braking or hard cornering when roads are slippery may result in loss of motorcycle control and an accident.

Riding Modes

The riding modes allow adjustment of the throttle response (MAP), Anti-lock Brake System (ABS) and Traction Control (TC) settings to suit differing road conditions and rider preferences.

Riding modes can be conveniently selected using the MODE button and joystick located on the left hand switch housing, while the motorcycle is stationary or moving, see page 34.

Up to six riding modes are available depending on your model's specification. If a riding mode is edited (other than the RIDER mode), the icon will change as shown below.

Default Icon	Rider Edited Icon	Description
	-	RIDER
		RAIN
		ROAD
		SPORT
		OFF-ROAD
		OFF-ROAD PRO

Each riding mode is adjustable. For more information, see page 44.

Availability of the ABS, MAP and TC setting options vary between models.

Instruments

Riding Mode Selection

Warning

The selection of riding modes while the motorcycle is in motion requires the rider to allow the motorcycle to coast (motorcycle moving, engine running, throttle closed, clutch lever pulled in and no brakes applied) for a brief period of time.

Riding mode selection while the motorcycle is in motion should only be attempted:

- At low speed
- In traffic-free areas
- On straight and level roads or surfaces
- In good road and weather conditions
- Where it is safe to allow the motorcycle to briefly coast.

Riding mode selection while the motorcycle is in motion **MUST NOT** be attempted:

- At high speeds
- While riding in traffic
- During cornering or on winding roads or surfaces
- On steeply inclined roads or surfaces
- In poor road/weather conditions
- Where it is unsafe to allow the motorcycle to coast.

Failure to observe this important warning may lead to loss of motorcycle control and an accident.

Warning

If ABS and/or traction control (TC) has been disabled in the Main Menu as described on, page **48** for ABS and/or page **48** for TC settings saved for all riding modes will be overridden.

ABS and/or TC will remain off regardless of your riding mode selection until they have been re-enabled or, the ignition has been switched off then on again, or the MODE button is held in to return to the default ROAD mode (which enables ABS and/or TC when the motorcycle is next stationary).

If the ABS is disabled, the brake system will function as a non-ABS equipped braking system. In this situation braking too hard will cause the wheels to lock, and may result in loss of motorcycle control and an accident.

If the traction control is disabled, the motorcycle will handle as normal but without traction control. In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.

Warning

After selecting a riding mode, operate the motorcycle in an area free from traffic to gain familiarity with the new settings.

Do not loan your motorcycle to anyone as they may change the riding mode settings from the one you are familiar with, causing loss of motorcycle control and an accident.

Note:

- The riding mode will default to ROAD when the ignition is switched ON, if the OFF-ROAD or RIDER mode was active the last time the ignition was switched OFF with ABS or TC set to OFF-ROAD or OFF in either of those modes.
- Otherwise, the last selected riding mode will be remembered and activated when the ignition is switched ON.
- If the mode icons are not visible when the ignition switch is in the ON position, make sure that the engine stop switch is in the RUN position.

Note:

- If the battery is disconnected, then the RIDER mode settings will default back to the original factory settings.


The current riding mode is shown in the upper left of the display screen.

To select a riding mode:

- Press and release the MODE button on the left hand switch housing to activate the riding mode selection tray at the bottom of the display screen.
- The currently active riding mode icon is highlighted with a blue background.

To change the selected riding mode:

- Either push the joystick left or right, or repeatedly press the MODE button until the required mode is in the center of the display screen, highlighted with an arrow above it.
- A brief press of the joystick center will select the required riding mode, and the icon in the upper left of the display screen will change.



1. MODE button
2. Current riding mode
3. New riding mode

- Push the joystick left/right or press the MODE button to scroll through the riding mode options in the following order:
 - RIDER
 - RAIN
 - ROAD
 - SPORT
 - OFF-ROAD
 - OFF-ROAD PRO.

Instruments

The selected mode is activated once the following conditions for switching modes have been met:

Motorcycle Stationary - Engine Off

- The ignition is switched ON
- The engine stop switch is in the RUN position.

Motorcycle Stationary - Engine Running

- Neutral gear is selected or the clutch is pulled in.

Motorcycle in Motion

Within 30 seconds of selecting a riding mode the rider must carry out the following simultaneously:

- Close the throttle
- Pull the clutch in
- Make sure that the brakes are not engaged (allow the motorcycle to coast).

Note:

- **It is not possible to switch into or out of OFF_ROAD or RIDER modes while the motorcycle is in motion, if the ABS or TC settings are set to OFF-ROAD or OFF in either of those modes.**
- **In this case, the motorcycle must be brought to a stop before the riding mode change can take place.**

If a riding mode change is not completed, the icon will alternate between the previous riding mode and the newly selected riding mode until the change is complete or it is canceled.

The riding mode selection is now complete and normal riding can be resumed.

Information Tray




Warning

When the motorcycle is in motion, only attempt to switch between the information tray modes or reset the fuel information under the following conditions:

- At low speed
- In traffic free areas
- On straight and level roads or surfaces
- In good road and weather conditions.

Failure to observe this important warning could lead to loss of motorcycle control and an accident.

The information tray appears at the bottom of the display screen and allows easy access to different motorcycle status information.



1. Joystick control
2. Information tray

To view the different information tray items, push the joystick left/right until the required information tray item is shown.

Note:

- To access the information tray, the warning messages must first be acknowledged, see page 37.


The information tray contains the following information tray items:

- Warnings and Information Messages, see page 37
- Fuel Information, see page 38
- Tire Pressure Monitoring System (TPMS) (if equipped), see page 39
- Odometer, see page 39
- Service Interval Announcement, see page 39
- Screen Contrast, see page 41
- Style Options, see page 41
- Coolant Temperature, see page 41
- Screen Adjustment Height, see page 42
- Triumph Semi Active Suspension (TSAS), see page 40
- Trip Meter, see page 38

Different information tray items can be shown or hidden from the information tray. For further information, refer to page 52.

Warnings

Any warnings and information messages are shown in the Warnings tray. An example is shown below.



1. Low battery warning
2. Warning counter
3. Warning description

To view the warnings:

- Push the joystick left/right to scroll through the options until the warning review is shown.
- Push the joystick down/up to review each warning (if more than one). The warning counter will show the number of warnings that are present.
- Push the joystick left/right to return to the information tray.

Instruments

Trip Meter

There are two trip meters that can be accessed and reset in the information tray.



Trip Meter Information Tray

To view a specific trip meter:

- Push the joystick left/right to scroll through the information tray items until Trip 1 meter is shown.
- Select TRIP 1 or TRIP 2 by pushing the joystick down/up.

Note:

- **TRIP 2 meter can be shown or hidden from the information tray. For more information, see page 50.**


To reset a trip meter:

- Select the trip meter to be reset.
- Press and hold the joystick center for more than one second.
- The trip meter will then be reset.

The trip meter can also be reset from the Main menu, see page 49.

Fuel Status Information

The Fuel Status information tray shows fuel consumption information.



1. Fuel information light
2. Average fuel consumption
3. Instantaneous fuel consumption
4. Range to empty
5. Reset

Fuel Information Light

This light illuminates when the fuel level warning light is activated.

Average Fuel Consumption

This is an indication of the average fuel consumption. After being reset the display will show dashes until 0.1 miles/km has been covered.

Instantaneous Fuel Consumption

An indication of the fuel consumption at an instant in time. If the motorcycle is stationary, --.- will be shown in the display area.

Range to Empty

This is an indication of the predicted distance that can be traveled on the remaining fuel in the tank.

Reset


To reset the average fuel consumption, press and hold the joystick center.

Note:

- After refueling, the fuel gage and range to empty information will be updated only while riding the motorcycle. Depending on the riding style, updating could take up to five minutes.

Tire Pressure Monitoring System (TPMS) (if equipped)

The Tire Pressure Monitoring System (TPMS) information tray item shows the front and rear tire pressures and the TPMS warning light. For more information on TPMS, see page 111.



1. TPMS warning light
2. Front tire pressure display
3. Rear tire pressure display

TPMS Warning Light

The warning light will only illuminate when the front or rear tire pressure is below the recommended pressure. It will not illuminate if the tire is over inflated.

Warning

Stop the motorcycle if the Tire Pressure Monitoring System (TPMS) warning light illuminates.

Do not ride the motorcycle until the tires have been checked and the tire pressures are at their recommended pressure when cold.

Front Tire Pressure Display

This shows the current front tire pressure.

Rear Tire Pressure Display

This shows the current rear tire pressure.

Odometer


The odometer shows the total distance that the motorcycle has traveled.



Odometer Information Tray

Service Interval Announcement

The Service Interval Announcement information tray shows the service symbol, the distance/days remaining before the next service and the current odometer reading.



Service Interval Announcement Information Tray

For more information on service interval announcements, see page 32.

Instruments

Triumph Semi Active Suspension (TSAS)

The Triumph Semi Active Suspension (TSAS) information tray item allows adjustment of the TSAS settings.



TSAS Information Tray (Showing SPORT Selected)

To adjust the TSAS settings:

- Push the joystick left/right to scroll through the options until the TSAS settings display is shown.
- Push the joystick center to activate the TSAS adjustment mode.


Note:

- If the riding modes link is disabled, changes made to the TSAS damping settings will remain active until further adjustment takes place, regardless of riding mode selection.
- If the riding modes link is enabled, any adjustments made to the TSAS damping settings will be saved to the currently active riding mode. The new TSAS settings will be automatically recalled whenever the riding mode is reselected. The riding mode's previous TSAS settings will be overwritten.
- If the riding modes link is enabled and a new riding mode is selected, the new riding mode's TSAS settings will automatically become active.
- TSAS has nine damping settings ranging from COMFORT (soft) to SPORT (firm).
- Press and release the joystick center allows individual selection of each of the nine settings.
- Press and hold the joystick control allows direct selection of the preset COMFORT, NORMAL and SPORT settings.
- There is a short time-out period to allow for further scrolling to take place. After the time-out period has elapsed, the selected damping setting will be automatically activated and the display will return to the home screen. Alternatively, press the joystick center to confirm the setting and return to the home screen.

For more information on Triumph Semi Active Suspension (TSAS), see page **108**.

Screen Contrast

The Screen Contrast information tray item allows the display screen contrast to be adjusted.



Screen Contrast Information Tray

There are two options available:

- **HIGH CONTRAST** - This option locks the display screen to the white background version of each display screen style for maximum visibility.
- **AUTO CONTRAST** - This option uses the instrument light sensor to adjust the contrast to the most suitable setting. In bright sunlight, low brightness settings will be overridden to make sure that the instruments can be viewed at all times.

To select an option:

- Push the joystick down/up to select either the **HIGH CONTRAST** or **AUTO CONTRAST** option and press the joystick center to confirm.


If the rider defined brightness setting is suitable this will be used, see page 52.

Note:

- **Do not cover the light sensor on the display screen as this will stop the screen contrast from working correctly.**

Style Options

The Style Options information tray item allows a different style to be applied to the display screen.



Style Options Information Tray (Style 2 Selected)

To change the display screen style:

- Push the joystick down/up to select the required style and then press the joystick center to confirm.

Coolant Temperature

The Coolant Temperature information tray item indicates the temperature of the engine coolant.



Coolant Temperature Information Tray

When the engine is started from cold the display will show grey bars. As the temperature increases more bars in the display will be shown illuminated. When the engine is started from hot the display will show the relevant number of illuminated bars, dependant on engine temperature.

The range is between C (cold) and H (hot) on the display.

Instruments

With the engine running, if the engine coolant temperature becomes dangerously high, the high coolant temperature warning light on the display will be illuminated and the gage will be shown in the information tray.

Caution

Stop the engine immediately if the high coolant temperature warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the high coolant temperature warning light is illuminated.

Windshield Adjustment

The Windshield Adjustment information tray option allows the windshield height to be adjusted to an optimum setting.



SCREEN ADJUST HEIGHT



Windshield Adjustment Mode


To adjust the windshield height:

- Push the joystick left/right until the windshield adjust option is highlighted.
- Push the joystick up/down to adjust the windshield to the required height.
- Push the joystick left/right to access another tray item.

Main Menu

To access the Main menu:

- The motorcycle must be stationary with the ignition switched on.
- Press the HOME button on the right handlebar switch housing.
- Scroll the Main menu by pushing the joystick down/up until the required option is selected and then press the joystick center to confirm.



Main Menu Screen

The Main menu allows access to the following options:

Riding Modes

This menu allows configuration of the riding modes. For more information, see page **44**.

Bike Set Up

This menu allows configuration of the following different features of the motorcycle. For more information, see page **45**.

Trip Set Up

This menu allows configuration of Trip 1 and Trip 2. For more information, see page **49**.

Display Set Up


This menu allows configuration of the display options. For more information, see page 51.

Reset to Defaults

This menu allows all instrument settings to be returned to the default setting. For more information, see page 55.

Riding Modes Menu

The Riding Modes menu allows configuration of the riding modes.



To access the Riding Modes menu:

- Press the HOME button to display the Main menu.
- Push the joystick down and then press the joystick center to select RIDING MODES.


The following model specific options are available:

- Rider
- Rain
- Road
- Sport
- Off-Road
- Off-Road Pro
- Reset To Defaults.


Riding Modes

To change the riding modes settings:


- From the Riding Modes menu, push the joystick down/up to select a specific riding mode and press the joystick center to confirm.



- Push the joystick down/up until the required setting option is selected and press the joystick center to confirm.









- Push the joystick down/up until the required option is selected and press the joystick center to confirm.



Instruments


Riding Mode Configuration

Refer to the following table for the ABS, MAP and TC options available for each riding mode.

Riding Mode						
	RIDER 	RAIN 	ROAD 	SPORT 	OFF-ROAD 	OFF-ROAD PRO 
ABS (Anti-lock Braking System)						
Road	●	●	●	●	⊘	
Off-Road ¹	○	⊘	⊘	⊘	●	○
Off	○	Via Menu	Via Menu	Via Menu	○	●
MAP (Throttle Response)						
Rain	○	●	○	⊘	○	○
Road	●	○	●	○	○	○
Sport ¹	○	⊘	○	●	○	○
Off-Road ¹	○	⊘	⊘	⊘	●	●
TC (Traction Control)						
Rain	○	●	○	⊘	⊘	⊘
Road	●	○	●	○	⊘	⊘
Sport ¹	○	⊘	○	●	○	⊘
Off-Road ¹	○	⊘	⊘	⊘	●	○
Off	○	Via Menu	Via Menu	Via Menu	○	●
¹ Model Specific						
Key						
●		Standard (Factory Default Setting)				
○		Selectable Option				
⊘		Option Not Available				

Bike Set Up Menu

The Bike Set Up menu allows configuration of the different features of the motorcycle.



To access the Bike Set Up menu:


- Press the HOME button to display the Main menu.
- Push the joystick down and then press the joystick center to select BIKE SET UP.

The options available are:

- Triumph Semi Active Suspension (TSAS)
- Triumph Shift Assist
- Hill Hold
- Turn Signals
- Anti-Lock Braking System (ABS)
- Traction Control (TC)
- Service.

Bike Set Up - TSAS

The Triumph Semi-Active Suspension System (TSAS) controls adjustment of the front and rear suspension damping and automatic rear suspension preload settings. For more information on TSAS, see page 108.



Riding Modes Link

The riding modes link allows you to enable or disable the link between TSAS and the riding modes.

If the riding modes link is disabled, changes made to the TSAS damping settings will remain active until further adjustment takes place, regardless of riding mode selection.

If the riding modes link is enabled, any adjustments made to the TSAS damping settings will be saved to the currently active riding mode. The new TSAS settings will be automatically recalled whenever the riding mode is reselected. The riding mode's previous TSAS settings will be overwritten.

If the riding modes link is enabled and a new riding mode is selected, the new riding mode's TSAS settings will automatically become active.

Instruments

To disable or enable the TSAS riding modes link:

- Press the joystick center to select RIDING MODES LINK.
- Push the joystick down/up to scroll between DISABLED and ENABLED.
- Press the joystick center to select the required option.

Mode

This allows the adjustment of the settings from soft to hard by adjusting the rebound and compression damping settings.

Selecting AUTO sets the TSAS system to automatically detect the type of surface being ridden on (road or off-road) and will adjust the rebound and compression damping settings accordingly.

Setting On-Road

This applies the optimal TSAS settings for on-road use and adjusts the rebound and compression damping settings accordingly.

Setting Off-Road

This applies the optimal TSAS settings for off-road use and adjusts the rebound and compression damping settings accordingly.


Bike Set Up - Triumph Shift Assist (if equipped)

Triumph Shift Assist triggers a momentary engine cut to allow gears to engage, without closure of the throttle or operation of the clutch. This feature works for both up-shifts and down-shifts of gear.

The clutch must be used for stopping and pulling away.

Triumph Shift Assist will not operate if the clutch is applied or if an up-shift is attempted by mistake when in 6th gear.

It is necessary to use a positive pedal force to make sure there is a smooth gear shift.




To enable/disable Triumph Shift Assist:

- From the Bike Set Up menu, push the joystick down to select TRIUMPH SHIFT ASSIST and press the joystick to confirm.
- Push the joystick down/up to scroll between ENABLED and DISABLED.
- Press the joystick center to confirm the required selection.
- The display will then return to the BIKE SET UP menu.

Bike Set Up - Hill Hold Control (if equipped)

Hill hold control assists in making hill starts. The system (when activated) will apply the rear brake to hold the motorcycle in position. The system will then automatically deactivate and release the rear brake when it detects that the motorcycle is attempting to move off.




To enable/disable hill hold control:

- From the Bike Set Up menu, push the joystick down to select HILL HOLD and press the joystick center to confirm.
- Push the joystick down to select either ENABLED or DISABLED.
- Press the joystick center to confirm the required selection.
- The display will then return to the Bike Set Up menu.

For more information on hill hold control, see page **152**.

Bike Set Up - Turn Signals

The turn signals can be set to Auto Basic, Auto Advanced or Manual mode.



Selecting a Turn Signals Mode


To select the required turn signals mode:

- From the Bike Set Up menu, push the joystick down to select INDICATORS and press the joystick center to confirm.
- Push the joystick down/up to scroll between AUTO BASIC, AUTO ADVANCED and MANUAL.
 - **Auto Basic** - The self-canceling function is on. The turn signals will activate for eight seconds and an additional 213 ft. (65 meters).
 - **Auto Advanced** - The self-canceling function is on. A quick short press activates the turn signals for three flashes. A longer press activates the turn signals for eight seconds and an additional 213 ft. (65 meters).
 - **Manual** - The self-canceling function is off. The turn signals must be manually canceled using the turn signal switch.
- Press the joystick center to confirm the required selection.
- The display will then return to the Bike Set Up menu.

Instruments

Bike Set Up - ABS

It is possible to temporarily disable the ABS. The ABS cannot be permanently disabled, it will be automatically enabled when the ignition is turned off and then on again, or if the default riding mode is activated by a long press of the MODE button.




To select the required option:

- From the Bike Set Up menu, push the joystick down to select ABS and press the joystick center to confirm.
- Push the joystick down/up to scroll between ENABLED and DISABLED.
- Press the joystick center to confirm the required selection.
- The display will then return to the Bike Set Up menu.

Bike Set Up - Traction Control (TC)

It is possible to temporarily disable the traction control system. The traction control cannot be permanently disabled, it will be automatically enabled when the ignition is turned off and then on again, or if the default riding mode is activated by a long press of the MODE button.




To select the required option:

- From the Bike Set Up menu, push the joystick down to select TC and press the joystick center to confirm.
- Push the joystick down/up to scroll between ENABLED and DISABLED.
- Press the joystick center to select the required option.

The display will then return to the BIKE SET UP display.

Bike Set Up - Service

The service interval is set to a distance and/or time period.



To review the service interval:

- From the Bike Set Up menu, push the joystick down to select SERVICE and press the joystick center to confirm.
- Press the joystick center to display the SERVICE information.
- Selecting RESET allows you to reset the standard time and distance, and also any custom times and distances.
- The display will then return to the Bike Set Up menu.

Trip Setup

The Trip Set Up menu allows configuration of the trip meters. Each trip meter can be configured to be reset either manually or automatically. The setup procedure is the same for both trip meters.

To access the Trip Set Up menu:


- Press the HOME button to display the Main menu.
- Push the joystick down and then press the joystick center to select TRIP SET UP.

The options available are:

- TRIP 1 RESET
- TRIP 2 RESET
- TRIP 2 DISPLAY

Trip Setup - Manual Reset

Manual reset of the trip meters will only reset the selected trip meter when the rider chooses to do so.



To set the trip meter to reset manually:

- Push the HOME button to display the MAIN MENU.
- Push the joystick down and then press the joystick center to select TRIP SETUP.
- Push the joystick down and then press the joystick center to select TRIP 1 RESET or TRIP 2 RESET.
- Push the joystick center to select MANUAL.


There are two options:

- RESET NOW AND CONTINUE - Resets all trip meter data in the relevant trip meter, and the trip meter will only reset when manually done so by the rider.
 - CONTINUE WITHOUT RESET - The trip meter will not be reset. The trip meter will only reset when manually done so by the rider.
- Press the joystick center to confirm the selection and return to the previous menu.

Instruments

Trip Setup - Automatic Reset

Automatic reset will reset each trip meter after the ignition has been switched off for a set time.



To set the trip meters to reset automatically:

- Push the HOME button to display the MAIN MENU.
- Push the joystick down and then press the joystick center to select TRIP SETUP.
- Push the joystick down/up and then press the joystick center to select TRIP 1 RESET or TRIP 2 RESET.
- Push the joystick down/up and select AUTOMATIC and then press the joystick center.
- Push the joystick down/up to select the timer setting and press the joystick center to confirm the required time limit. The required time limit is then stored in the trip memory.


When the ignition is turned off, the trip meter is set to zero when the time period has elapsed.

The following table shows two examples of the automatic trip reset functionality.

Ignition Turned Off	Selected Time Delay	Trip Meter Resets to Zero
10:30 hrs	4 HRS	14:30 hrs
18:00 hrs	16 HRS	10:00 hrs (next day)

Trip 2 Enable/Disable

Trip 2 meter can be enabled or disabled. If Trip 2 is disabled it will no longer be shown in the information tray.




To enable or disable the Trip 2 meter:

- Push the MODE button to display the MAIN MENU.
- Push the joystick down to select TRIP SET UP.
- Push the joystick center to display the TRIP SET UP menu.
- Push the joystick down/up to scroll to the TRIP 2 DISPLAY and press the joystick center.
- Push the joystick down/up to scroll between ENABLED and DISABLED and press the joystick center.

Display Set Up Menu

The Display Set Up menu allows configuration of the different display screen options.



To access the Display Set Up menu:

- Press the HOME button to display the Main menu.
- Push the joystick down and then press the joystick center to select DISPLAY SET UP.


The following options are available:

- Styles and Themes
- Brightness
- Visible Tray
- Shift Indicator
- Language
- Set Units
- Set Clock
- Set Date.


Display Set Up - Styles and Themes

Note:

- **Themes are only available on Tiger 1200 XRT and Tiger 1200 XCA.**



Theme and Style Menu Example



Style Menu Example

To select a style or theme:

- From the Display Set Up menu, push the joystick down to select the STYLES or THEME (if equipped) menu.
 - **Tiger 1200 XRT and Tiger 1200 XCA:** Push the joystick down/up to scroll between the THEMES.
 - Press the joystick center to confirm the selected THEME.
 - **All Models:** Push the joystick down/up to scroll between the STYLES.

Instruments


- Press the joystick center to confirm the selected STYLE.
- The new style or theme will be saved. Press the HOME button to exit.

Note:

- **Selecting AUTO will prevent a style tray from being displayed. The style is changed with riding modes.**



Display Set Up - Brightness

The brightness feature allows the screen's brightness contrast to be changed for day time and night time riding.



BRIGHTNESS (LOW CONTRAST) Shown

There are two brightness options to choose:

- High contrast (day time mode) 
- Low contrast (night time mode) 

To change the brightness level:


- From the Display Set Up menu, push the joystick down to select BRIGHTNESS and press the joystick center to confirm.
- Push the joystick down to select BRIGHTNESS (High Contrast) or BRIGHTNESS (Low Contrast) menu.
- Press the joystick center to select the required menu.
- Push the joystick down/up to adjust the brightness.
- Press the joystick center to confirm the required level of brightness.
- Press the HOME button to return to the main display.

Note:

- **In bright sunlight, low brightness settings will be overridden to make sure that the instruments can be viewed at all times.**

Display Set Up - Visible Tray

The Visible Tray feature allows the selection of required information tray items to be shown in the information tray.



To select the Visible Tray menu:

- From the Display Set Up menu, push the joystick down to select **VISIBLE TRAY** and press the joystick center to confirm.
- Push the joystick down/up until the required information tray item is selected.
- Press the joystick center to select/deselect the information tray item.
An information tray item with a tick next to it will be shown in the tray.
An information tray item without a tick next to it will not be shown in the tray.

Display Set Up - Language

There are several different languages that can be selected to be shown in the display screen.




To select a different language:

- From the Display Set Up menu, push the joystick down to select **LANGUAGE** and press the joystick center to confirm.
- Push the joystick down/up until the required language is selected.
- Press the joystick center to select/deselect the required language.

Display Set Up - Set Units

There are different units of measurement options that can be shown in the display screen.



To select the units of measurement required:

- From the Display Set Up menu, push the joystick down to select **SET UNITS** and press the joystick center to confirm.
- Push the joystick down/up to select the required unit; **DISTANCE & ECONOMY**, **TEMPERATURE** or **PRESSURE**.
- Push the joystick down/up to select the required unit of measurement from the following options:
 - **DISTANCE & ECONOMY:**
 - MILES & MPG (UK)
 - MILES & MPG (US)
 - KM & L/100KM
 - KM & KM/L
 - **TEMPERATURE:**
 - °C
 - °F
 - **PRESSURE:**
 - PSI
 - BAR
 - KPa
- Press the joystick center to confirm.

Instruments

Display Set Up - Set Clock

This function allows the adjustment of the clock.


To set the clock:

- From the Display Set Up menu, push the joystick down to select SET CLOCK and press the joystick center to confirm.
- Push the joystick down/up to select between either 12 HR or 24 HR clock and press the joystick center to confirm selection. The clock will display in either 12 or 24 hour format. Once the clock format is set the display will return to the SET CLOCK menu.

To set the time, push the joystick down/up to select HOUR or MINUTE.


To Adjust the Hour Setting

- Select HOUR on the display and press the joystick center, a tick will appear next to HOUR and the hour display will flash as shown below.
- Push the joystick down/up to set the hour and press the joystick center to confirm.




To Adjust the Minute Setting

- Select MINUTE on the display and press the joystick center, a tick will appear next to MINUTE and the minute display will flash as shown below.
- Push the joystick down/up to set the minute and press the joystick center to confirm.




Display Set Up - Set Date

This function allows the adjustment of the date and date format.



To set the date format:

- From the Display Set Up menu, push the joystick down to select SET DATE and press the joystick center to confirm.
- Press the joystick center to display DATE FORMAT.
- Push the joystick down/up to select either of the DD-MM-YYYY, MM-DD-YYYY or YYYY-MM-DD formats and press the joystick center to confirm selection. Once the date format is set the display will return to the SET DATE menu.




To set the date, push the joystick down/up to select the DAY, MONTH and YEAR.

- Select YEAR and then press the joystick center, a tick will appear next to the YEAR and the YEAR display will flash.
- Push the joystick down/up to set the current year and then press the joystick center to confirm.
- To set the MONTH and DAY repeat the procedure used to set the year. Once the date is set the display will return to the SET DATE menu.

Reset to Defaults

This function allows the main menu display items to be reset to the default setting.



To reset the Main menu display items:

- From the Main menu, push the joystick down and select RESET TO DEFAULTS.
- Press the joystick center to confirm.
- Pushing the joystick down/up, select CONFIRM or CANCEL from the Reset to Defaults menu, and press the joystick center to confirm.
- **Confirm** - The following main menu settings and data will be reset to the factory default values - Riding Modes, Indicator Set Up, Trip Computers, Visible Trays, Language, ABS, Traction Control, Style, and Display Brightness.
- **Cancel** - The main menu settings and data will remain unchanged and the display will return to the previous level.

Instruments

Instrument Panel Position Adjustment

! Warning

Operation of the motorcycle with an incorrectly adjusted instrument panel is dangerous.

An incorrectly adjusted instrument panel will result in loss of instrument vision when riding and may cause a distraction leading to loss of control of the motorcycle and an accident.

Always adjust the instrument panel to provide sufficient vision of the instruments before riding the motorcycle.

! Warning

Never attempt to clean or adjust the instrument panel while riding the motorcycle. Removal of the rider's hands from the handlebars while riding the motorcycle will diminish the ability of the rider to maintain control of the motorcycle.

Attempting to clean or adjust the instrument panel while riding the motorcycle may result in loss of control of the motorcycle and an accident.

Only attempt to clean or adjust the instrument panel while stationary.


! Caution

Do not press directly onto the instrument panel display screen.

Only adjust the position of the instrument panel using the adjustment handle.

Pressing directly on the instrument panel display screen may damage the instrument panel.

The instrument panel can be adjusted to allow for improved visibility of the display screen.



1. Adjustment handle

To adjust the instrument panel:

Note:

- **Moderate force using the thumb and finger is required to adjust the position of the instrument panel.**

Position the instrument panel to allow an unobstructed view of the display screen using the adjustment handle.

Liquid Crystal Display (LCD) Instrument Display


Table of Contents

Instrument Panel Layout.....	58
Warning Lights.....	59
Warning and Information Messages.....	65
Tachometer.....	66
Motorcycle Status Display Screen.....	67
Multifunction Display Screen.....	71
Settings Menu.....	74
Riding Modes.....	81

Instruments

Instrument Panel Layout

The LCD instrument display is only mounted to the Tiger 1200 XR model.



0102

- | | |
|--|---|
| 1. Multifunction display screen | 12. Motorcycle status display screen |
| 2. Engine management Malfunction Indicator Light (MIL) | 13. Traction control indicator light |
| 3. Battery warning light | 14. Low fuel level indicator light |
| 4. Left hand turn signal light | 15. Alarm/immobilizer status indicator light (alarm is an accessory kit) |
| 5. High coolant temperature warning light | 16. Traction control disabled warning light |
| 6. ABS warning light | 17. Tire pressure warning light (if equipped with Tire Pressure Monitoring System (TPMS)) |
| 7. Tachometer red zone | 18. Cruise control light |
| 8. Right hand turn signal light | 19. Low oil pressure warning light |
| 9. Neutral indicator light | 20. Tachometer |
| 10. Fog lights indicator light | |
| 11. High beam indicator light | |

Warning Lights

Note:

- **When the ignition is switched on, the instrument warning lights will illuminate for 1.5 seconds and will then go off (except those which remain on until the engine starts, as described in the following pages).**

Engine Management System Malfunction Indicator Light (MIL)



The Malfunction Indicator Light (MIL) for the engine management system illuminates when the ignition is switched ON (to indicate that it is working) but should not become illuminated when the engine is running.

If the MIL becomes illuminated when the engine is running, this indicates that a fault has occurred in one or more of the systems controlled by the engine management system. In such circumstances, the engine management system will switch to 'limp-home' mode so that the journey may be completed, if the fault is not so severe that the engine will not run.

Warning

Reduce speed and do not continue to ride for longer than is necessary with the MIL illuminated. The fault may adversely affect engine performance, exhaust emissions and fuel consumption.

Reduced engine performance could cause a dangerous riding condition, leading to loss of control and an accident.

Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Note:

- **If the MIL flashes when the ignition is switched ON contact an authorized Triumph dealer as soon as possible to have the situation rectified. In these circumstances the engine will not start.**

Low Oil Pressure Warning Light




With the engine running, if the engine oil pressure becomes dangerously low, the low oil pressure warning light in the tachometer will illuminate and **WARNING - OIL PRESSURE LOW** will be displayed in the multifunction display screen.

Instruments

⚠ Caution

Stop the engine immediately if the low oil pressure warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the low oil pressure warning light is illuminated.



1. Low oil pressure warning light
2. Instrument message

The low oil pressure warning light in the tachometer will illuminate if the ignition is switched on without running the engine.

High Coolant Temperature Warning Light



With the engine running, if the engine coolant temperature becomes dangerously high, the high coolant temperature warning light will illuminate.

⚠ Caution

Stop the engine immediately if the high coolant temperature warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the high coolant temperature warning light is illuminated.

Immobiliser/Alarm Indicator Light



This Triumph motorcycle is equipped with an engine immobilizer which is activated when the ignition switch is turned to the OFF position.

Without Alarm Equipped

When the ignition switch is turned to the OFF position, the immobilizer/alarm light will flash on and off for 24 hours to show that the engine immobilizer is on. When the ignition switch is turned to the ON position the immobilizer and the indicator light will be off.

If the indicator light remains on it indicates that the immobilizer has a malfunction that requires investigation. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

With Alarm Equipped

The immobilizer/alarm light will only illuminate when the conditions described in the genuine Triumph accessory alarm instructions are met.

ABS (Anti-Lock Brake System) Warning Light



When the ignition switch is turned to the ON position, it is normal that the ABS warning light will flash on and off. The light will continue to flash after engine start-up until the motorcycle first reaches a speed exceeding 6 mph (10 km/h) when it will go off.

The warning light should not illuminate again until the engine is restarted unless there is a fault, or:

- ABS is disabled by the rider - the warning light will remain illuminated (see Bike Setup on page **76** or Riding Mode Configuration on page **85**).
- ABS is set to Off-Road - the warning light will flash slowly (see Riding Mode Configuration on page **85**).

Note:


- **Traction control and cruise control may not function if there is a malfunction with the ABS system. In this situation, the warning lights for the ABS, traction control and the MIL may be illuminated.**

If the warning light becomes illuminated at any other time while riding it indicates that the ABS has a malfunction that requires investigation. The following warning message may be displayed:

- **WARNING - ABS SYSTEM DISABLED**

The braking system will be affected as follows:

WARNING - ABS SYSTEM DISABLED



1. **ABS warning light**
2. **Instrument message**

The message **WARNING - ABS SYSTEM DISABLED** indicates that the ABS is not functioning.

Warning

If the ABS is not functioning or has been disabled by the rider (see Bike Setup on page **76** or Riding Mode Configuration on page **85**), the brake system will continue to function as a non-ABS braking system.

Do not continue to ride for longer than is necessary with the warning light illuminated. In the event of a fault, contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

In this situation, braking too hard will cause the wheels to lock resulting in loss of motorcycle control and an accident.

See also Braking on page **146**.

Instruments

Traction Control (TC) Indicator Light



The TC indicator light is used to indicate that the TC system is active and is working to limit rear wheel slip during periods of hard acceleration or under wet or slippery road conditions.

TC Indicator Light Operation:

TC Switched On (Rain, Road or Sport Settings):

- Under normal riding conditions the indicator light will remain off.
- The indicator light will flash rapidly when the TC system is working to limit rear wheel slip during periods of hard acceleration or under wet or slippery road conditions.

TC Switched On (Off-Road Setting):

- Under normal riding conditions, the indicator light will flash slowly to indicate that the TC system is set to Off-Road.
- The TC indicator light will flash rapidly when the TC system is working to limit rear wheel slip during periods of hard acceleration or under wet or slippery conditions.

TC Switched Off:

The indicator light will not illuminate. Instead the TC disabled warning light will be illuminated.

Note:

- **Traction control may not function if there is a malfunction with the ABS system. In this situation, the warning lights for the ABS, TC and the MIL may be illuminated.**

Traction Control (TC) Disabled Warning Light



The TC disabled warning light should not illuminate unless TC is disabled by the rider (see Bike Setup on page **76** or Riding Mode Configuration on page **85**).

If the warning light becomes illuminated at any other time while riding, it indicates that the TC system has a malfunction that requires investigation. The following warning message may be displayed:

- **WARNING - TC SYSTEM DISABLED**

The TC system will be affected as follows:

The message **WARNING - TC SYSTEM DISABLED** indicates that the traction control system is not functioning.

Warning

If the Traction Control (TC) system is not functioning, care must be taken when accelerating and cornering on wet/slippery road surfaces to avoid rear wheel spin.

In the event of a fault, the TC disabled warning light may be accompanied by the engine management system malfunction indicator light and/or the ABS warning light.

Do not continue to ride for longer than is necessary with any of the above warning lights illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Hard acceleration and cornering in this situation may cause the rear wheel to spin resulting in loss of motorcycle control and an accident.

Warning

Cruise control must only be used where you can ride safely at a steady speed.

Cruise control should not be used when riding in heavy traffic, on roads with sharp/blind bends or when they are slippery.

Using cruise control in heavy traffic, on roads with sharp/blind bends or when they are slippery, may result in loss of motorcycle control and an accident.

Turn Signals



When the turn signal switch is turned to the left or right, the indicator warning light will flash on and off at the same speed as the turn signals.

Cruise Control Light



The cruise control can only be activated when the motorcycle is traveling at a speed between 19 to 100 mph (30 to 160 km/h) and is in 3rd gear or higher. When activated, the cruise control light in the tachometer will be illuminated (see page 104).

High Beam Switch



When the ignition is switched ON and the headlight dimmer switch is set to HIGH BEAM, the high beam warning light will illuminate.

Fog Lights (if equipped)



When the ignition is switched on and the fog lights are switched on, the fog lights warning light will illuminate.

Instruments

Low Fuel Warning Light



The low fuel warning light will illuminate when there is approximately 1.0 gallon (3.5 liters) of fuel remaining in the tank.

Neutral

N

The neutral warning light indicates when the transmission is in neutral (no gear selected). The warning light will illuminate when the transmission is in neutral with the ignition switch in the ON position.

Battery Warning Light



When the ignition is switched on, the battery warning light will only illuminate if a fault is recognized with the battery.

With the engine running, if the battery voltage becomes low, the battery warning light in the tachometer will illuminate and the message WARNING - BATTERY LOW will also be shown in the multifunction display screen.

Once the battery is fully charged the warning light will go out and the instrument message will be deactivated. If the battery warning light remains on it indicates that there is a malfunction that requires investigation. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Tire Pressure Warning Light (if equipped with TPMS)




The tire pressure warning light works in conjunction with the Tire Pressure Monitoring System (TPMS) (see page 111).

The warning light will only illuminate when the front or rear tire pressure is below the recommended pressure. It will not illuminate if the tire is over inflated.

When the warning light is illuminated, the message TPMS - FRONT/REAR TIRE LOW PRESSURE will be shown in the multifunction display screen.

Press the SELECT button to acknowledge the message and return to the home screen.

After pressing the SELECT button, the tire pressures display will be automatically shown in the motorcycle information section of the home screen.



1. Tire pressures display

The tire pressure at which the warning light illuminates is temperature compensated to 68°F (20°C) but the numeric pressure display associated with it is not (see page 111). Even if the

numeric display seems at or close to the standard tire pressure when the warning light is on, a low tire pressure is indicated and a puncture is the most likely cause.

Warning

Stop the motorcycle if the tire pressure warning light illuminates and the message TPMS - FRONT/REAR TIRE LOW PRESSURE is displayed.

Do not ride the motorcycle until the tires have been checked and the tire pressures are at their recommended pressure when cold.

Frost Warning Light

Warning

Black ice (sometimes called clear ice) can form at temperatures several degrees above freezing (32°F (0°C)), especially on bridges and in shaded areas.


Always take extra care when the temperatures are low and reduce speed in potentially hazardous driving conditions such as bad weather.

Excess speed, hard acceleration, heavy braking or hard cornering when roads are slippery may result in loss of motorcycle control and an accident.



The frost warning light illuminates if the ambient air temperature is 39°F (4°C) or lower.

The frost warning light will remain illuminated until the temperature rises to 42°F (6°C).



1. Ambient air temperature
2. Frost symbol

Warning and Information Messages



Warning Messages

The following warning messages may be displayed if a fault is detected:

- OIL PRESSURE LOW (see page 60)
- BATTERY LOW (see page 64)
- ABS SYSTEM DISABLED (see page 61)
- TC SYSTEM DISABLED (see page 62)
- FRONT/REAR TIRE PRESSURE LOW (see page 64)
- SENSOR SIGNAL FRONT/REAR TIRE (see page 111).

Instruments



Information Messages


The following information message may be displayed:

- TPMS - BATTERY LOW FRONT/ REAR TIRE (see page 64)

When a warning or information message is activated, the message will be accompanied by the relevant warning or information symbol on the left hand side of the multifunction display.

It is possible for multiple warning and information messages to be displayed when a fault occurs. Where this is the case, warning messages will take priority over information messages and the warning symbol will be displayed on the left hand side of the multifunction display.

The number of currently active warning and information messages is displayed over the warning/information symbol.



1. Symbol (warning symbol shown)
2. Multiple messages indicated

Use the SCROLL button to scroll through the messages being displayed.

Press the SELECT button to acknowledge and hide each message.

Note:

- Some messages are automatically hidden after a short period.
- Hidden warning and information messages remain active and will be redisplayed each time the ignition is switched on, until the condition that triggered the message has been rectified.
- The warning or information symbol will remain visible in the multifunction display while active messages are hidden, along with the number of hidden messages.
- Hidden warning or information messages can be viewed using the Show Warnings function as described in the Settings Menu on page 74.

Tachometer




Never allow engine speed to enter the red zone as severe engine damage may result.

The tachometer shows the engine speed in revolutions per minute - rpm (r/min). At the end of the tachometer range there is the red zone.

Engine speeds in the red zone are above maximum recommended engine speed and are also above the range for best performance.

Motorcycle Status Display Screen




1. Motorcycle status display screen

The motorcycle status display screen is used to display the following:

- Speedometer
- Fuel gage
- Coolant temperature gage
- Gear position display
- Cruise control set speed
- Service indicator
- Clock
- Ambient air temperature and frost symbol.

Speedometer


The digital speedometer indicates the road speed of the motorcycle. The read-out displays the motorcycle road speed in increments of one mile (or kilometer) per hour.



1. Speedometer

Fuel Gage

The fuel gage indicates the amount of fuel in the tank.




1. Fuel gage

With the ignition switched on, the number of bars shown in the display indicates the level of fuel.

Instruments

When the fuel tank is full all eight bars are displayed and when empty, no bars are displayed. Other gage markings indicate intermediate fuel levels between full and empty.

The low fuel warning light will illuminate when there is approximately 1.0 gallon (3.5 liters) of fuel remaining in the fuel tank (see page 64). At this point, two bars will be visible in the fuel gage and the information display in the multifunction display screen will switch to the Range to Empty display.



1. Range to empty display


Refuel at the earliest opportunity when the low fuel warning light is illuminated.

After refueling, the fuel gage and range to empty information will be updated only while riding the motorcycle. Depending on the riding style, updating could take up to five minutes.

Coolant Temperature Gage



Do not continue to run the engine if either of the high temperature warnings are displayed as severe engine damage may result.



1. Coolant temperature gage

The coolant temperature gage indicates the temperature of the engine coolant.


When the ignition is switched on, all eight bars of the display will be shown. When the engine is started from cold the display will show no bars. As the temperature increases more bars in the display will be shown. When the engine is started from hot the display will show the relevant number of bars, dependent on engine temperature.

The normal temperature range is between four and six bars.

If the coolant temperature becomes too high the display will show eight bars and will start to flash. The high coolant temperature light in the tachometer will also flash.


Gear Position Display

The gear position display indicates which gear (one to six) has been engaged. When the transmission is in neutral (no gear selected), the display will show N.



1. Gear position symbol
2. Gear position display (neutral position shown)

Cruise Control Set Speed



1. Cruise control symbol
2. Cruise control set indicator
3. Cruise control set speed

When cruise control is switched on, the cruise control symbol will be visible in the motorcycle status display screen.

The cruise control set speed will be displayed as -- until a speed has been set.


Upon setting a speed, the word SET will be visible below the cruise control symbol. The set speed will be displayed and the cruise control light in the tachometer will be illuminated.

When cruise control is deactivated, the cruise control light in the tachometer will go out but the set speed will remain visible in the motorcycle status display screen.

For more information, see Cruise Control on page 104.

Service Indicator


When the ignition is switched on and the distance to the next service is 500 miles (800 km) or less, the multifunction display will briefly show the distance remaining before the next service in the startup screen.



1. Distance to next service

Instruments

If the service is overdue the distance will be displayed as a negative number and the service indicator will be displayed in the motorcycle status display screen.




1. Service indicator

When the service has been carried out by your authorized Triumph dealer, the system will be reset.

The service indicator will also be displayed if a fault has occurred and the ABS and/or MIL warning lights are illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Clock




1. Clock - 12 hour format displayed

The clock can be displayed in 12 hour or 24 hour format.

To set the clock see Display Setup on page 79.

Ambient Air Temperature



1. Ambient air temperature shown in °C
2. Frost symbol

The ambient air temperature is displayed in °C or °F.


The frost symbol will illuminate if the ambient air temperature is 39°F (4°C) or lower (see page 65).

When the motorcycle is stationary the heat of the engine may affect the accuracy of the ambient temperature display.

Once the motorcycle starts moving the display will return to normal after a short time.

To change the temperature from °C or °F, see Display Setup on page 79.

Multifunction Display Screen



1. Multifunction display screen

The multifunction display screen allows the rider to view, select or configure:


- Riding modes
- Windshield position
- Trip computers
- Motorcycle information
- Motorcycle settings
- Display settings.

The multifunction display screen is also used to display warning and information messages.

For more information on warning and information messages, see page 65.


Home Screen

The multifunction display home screen is used to show the current riding mode, windshield adjustment mode, trip meters and motorcycle information.



1. Current riding mode
2. Windshield adjustment mode
3. Trip 1 display
4. Trip 2 display (if activated)
5. Tire Pressure Monitoring System (TPMS) information (if equipped)

The home screen will show one trip meter as default but can be configured to show two trip meters. For more information on trip set up, see page 75.




1. SCROLL button
2. SELECT button

Instruments

To adjust or edit the home screen items:

- Press and release the SCROLL button until the required item is selected.
- Press and release the SELECT button to access the selected item's sub menu or adjustment screen.
- Press and hold the SELECT button to access the Settings menu. For more information, see page 74.


Riding Mode Display



1. Current riding mode display

Shows the current riding mode. For more information on riding modes, see page 81.

Windshield Adjustment Mode




1. Windshield adjustment mode

To access the windshield adjustment mode:

- Press the SCROLL button until the windshield adjust display is selected.
- Press the SELECT button to activate the windshield adjustment mode.
- Use the SCROLL button to adjust the windshield to the required height.
- There is a short time-out period to allow for further adjustment to take place before the instruments automatically exit the windshield adjustment mode.
- Alternatively, press the SELECT button to exit the windshield adjustment mode.

For more information on windshield adjustment, see page 118.

Trip Meters



1. Trip meter 1 display
2. Trip meter 2 display (if activated)

The home screen will permanently display trip meter one as default, but can be configured to display two trip meters. For information on trip set up, see page 75.

Trip Distance

The total trip distance traveled since the trip meter was last reset to zero.

Trip Meter Reset

To reset either of the trip meters, from the home screen select the trip meter to be zeroed, then press and hold the SCROLL button in either direction for two seconds. After two seconds, all items within the selected trip meter will reset to zero.

Trip 2 can also be set to automatically reset after an adjustable time delay of between one and eight hours. See Trip Setup on page 75.

Motorcycle Information



When the motorcycle is in motion, only attempt to switch between the information and trip meter display modes or reset the trip meter under the following conditions:

- At low speed
- In traffic-free areas
- On straight and level roads or surfaces
- In good road and weather conditions.

Failure to observe this important warning could lead to loss of motorcycle control and an accident.

The motorcycle information display shows the currently selected motorcycle information item.

Note:

- If TPMS is equipped, the tire pressures display will be available for selection.
- The motorcycle information display will automatically switch to the Range to Empty display when the low fuel warning light is illuminated.


To access the motorcycle information menu:

- Press the SCROLL button until the motorcycle information display is selected.
- Press the SELECT button to enter the motorcycle information menu.

Instruments

Motorcycle Information Menu

Any one of the available information items can be selected to be shown in the home screen.



1. Range to empty
2. Instantaneous fuel consumption
3. Odometer
4. Front and rear tire pressures (if equipped with TPMS)

To select an information item to be shown in the home screen:

- Press the SCROLL button until the required information item is selected.
- Press the SELECT button to confirm the selection and return to the home screen.

Each display provides the following information:

Range to Empty

This is an indication of the probable distance that can be traveled on the remaining fuel in the tank.

The distance shown will adapt based on the level of fuel in the tank and changes to the riding style.

Instantaneous Fuel Consumption

An indication of the fuel consumption at an instant in time. If the motorcycle is stationary, --.- will be shown in the display area.

Odometer

Shows the total distance that the motorcycle has traveled.

Front and Rear Tire Pressures (if equipped with TPMS)


The front and rear tire pressures are shown only if the Tire Pressure Monitoring System (TPMS) is installed.

Dashes will be shown in the tire pressure display until the motorcycle reaches a speed of approximately 12 mph (20 km/h).

Settings Menu

To access the SETTINGS menu:

- Press and hold the SELECT button on the left hand switch housing until the SETTINGS menu is shown in the multifunction display screen.



SETTINGS Menu

The following menu items are available for selection:

- EXIT
- SHOW WARNINGS (see page **75**)
- RIDING MODES (see page **75**)
- TRIP SETUP (see page **75**)
- BIKE SETUP (see page **76**)
- DISPLAY SETUP (see page **79**).

A description of each menu item is described in the following pages.

Exit

Select EXIT to return to the home screen.

Show Warnings

Select SHOW WARNINGS to exit the SETTINGS menu and display all active warning or information messages in the multifunction display screen.

For more information on warning and information messages, see page **65**.


Riding Modes

From the SETTINGS menu, select RIDING MODES to configure the ABS, MAP and TC settings for each available riding mode.

For more information on riding mode configuration, see page **85**.

Trip Setup

From the SETTINGS menu, select TRIP SET UP to configure and reset the trip meters.



TRIP SETUP Screen

The following menu items are available for selection:

- EXIT
- TRIP 1 RESET
- TRIP 2 RESET
- TRIP 2 DISPLAY
- AUTO RESET.

Exit

Select EXIT to return to the SETTINGS menu.

Trip 1 and Trip 2 Reset



TRIP 1 RESET (CONFIRM Shown)

Instruments

To reset TRIP 1 or TRIP 2:

- Press the SCROLL button to select the required trip meter to reset, either TRIP 1 RESET or TRIP 2 RESET.
- Press the SCROLL button to select CONFIRM, then press the SELECT button.
- All items within the selected trip meter will be immediately reset to zero and the display will return to the TRIP SETUP menu.

Trip 2 Display



TRIP 2 DISPLAY (ENABLE Shown)

To enable or disable the TRIP 2 DISPLAY:

- Press the SCROLL button to select TRIP 2 DISPLAY, then press the SELECT button.
- Press the SCROLL button to select ENABLE or DISABLE.
- Press the SELECT button to confirm the selection and return to the TRIP SETUP menu.

Auto Reset

The AUTO RESET function applies to TRIP 2 only. TRIP1 must be reset manually using TRIP1 RESET as previously described.




AUTO RESET (4 HRS Shown)

To auto reset the trip meters:

- Press the SCROLL button to select AUTO RESET, then press the SELECT button.
- Press the SCROLL button to select OFF, 1 HR, 2 HRS, 4 HRS or 8 HRS.
- Press the SELECT button to confirm the selection and return to the TRIP SETUP menu.
- After the ignition has been switched OFF and the set time has elapsed, all items within TRIP 2 will be reset to zero.

Bike Setup

From the SETTINGS menu, select BIKE SET UP to configure the Anti-Lock Braking System (ABS) and Traction Control (TC) settings.



BIKE SETUP Menu

The following menu items are available for selection:

- EXIT
- ABS
- TC.

Exit

Select EXIT to return to the SETTINGS menu.

Anti-Lock Braking System (ABS)

It is possible to temporarily disable the ABS system. The ABS system cannot be permanently disabled, it will be automatically enabled when the ignition is turned OFF and then ON again.

Warning

Selecting ABS DISABLE will disable the anti-lock braking system.

The ABS settings stored for each riding mode will be overridden, regardless of whether they are set to Road, Off-Road or OFF.

The ABS and the riding mode ABS settings will not be enabled again until ENABLE is selected from the ABS menu or the ignition is turned OFF then ON again.

If the ABS is disabled, the brake system will function as a non-ABS braking system. In this situation braking too hard will cause the wheels to lock, and may result in loss of motorcycle control and an accident.

Warning

Do not attempt to adjust the ABS settings while the motorcycle is in motion as this may lead to loss of motorcycle control and an accident.

To enable or disable the ABS system:

- Press the SCROLL button to select ABS, then press the SELECT button to confirm.
- Press the SCROLL button to select ENABLE or DISABLE.



ABS (ENABLE Shown)

- Press the SELECT button to confirm the selection and return to the BIKE SETUP menu.
- If DISABLE is selected, the ABS warning light will be illuminated and the message WARNING - ABS SYSTEM DISABLED will be briefly shown in the multifunction display screen.
- The ABS and all riding mode ABS settings will be disabled until the ABS is re-enabled. All ABS settings are automatically enabled when the ignition is turned OFF and then ON again.

Note:

- **If the ABS is disabled by the rider, traction control and cruise control (if equipped) will still function.**

Traction Control (TC)

It is possible to temporarily disable the Traction Control (TC) system. The TC system cannot be permanently disabled, it will be automatically enabled when the ignition is turned OFF and then ON again.

Warning

Selecting TC DISABLE will disable the traction control system.

All traction control settings stored for each riding mode will be overridden regardless of whether they are set to Rain, Road, Sport, Off-Road or Off.

Traction control and the riding mode TC settings will not be enabled again until ENABLE is selected from the TC menu, or the ignition is turned OFF then ON again.

If traction control is disabled, the motorcycle will handle as normal but without traction control. In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.

To enable or disable the traction control:

- Press the SCROLL button to select TC, then press the SELECT button to confirm.
- Press the SCROLL button to select ENABLE or DISABLE.




TC (ENABLE Shown)

- Press the SELECT button to confirm the selection and return to the BIKE SETUP menu.
- If DISABLE is selected, the TC disabled warning light will be illuminated and the message WARNING - TC SYSTEM DISABLED will be briefly shown in the multifunction display screen.
- Traction control and all riding mode traction control settings will be disabled until the traction control is re-enabled. All traction control settings are automatically enabled when the ignition is turned OFF and ON again.

Display Setup

From the SETTINGS menu, select DISPLAY SETUP to configure the display settings.



DISPLAY SETUP Menu

The following menu items are available for selection:

- EXIT
- LANGUAGE
- SET UNITS
- SET CLOCK
- BRIGHTNESS.

Exit

Select EXIT to return to the SETTINGS menu.

Language



LANGUAGE Menu (ENGLISH Shown)

The following languages are available:

- English
- French
- German
- Italian
- Dutch
- Spanish
- Swedish
- Brazilian.

To select a language:

- Press the SCROLL button to select LANGUAGE, then press the SELECT button to confirm.
- Press the SCROLL button to select the required language, then press the SELECT button to confirm and return to the DISPLAY SETUP menu.

Note:

- **All menu items displayed will change to the newly selected language when the SELECT button is pressed.**

Set Units



DISTANCE Menu (MILES shown)

To set the display units:

- Press the SCROLL button to select SET UNITS, then press SELECT to confirm.
- The DISTANCE menu is then shown. Press the SCROLL button to select MILES or KM and then press the SELECT button to confirm.

Instruments

Note:

- If **DISTANCE** has been set to **MILES**, the menu options available will be **MPG (UK)** or **MPG (US)**.
- If **DISTANCE** has been set to **KM**, the menu options available will be **KM/L** or **L/100 KM**.
- Use the **SCROLL** button to select the required unit and press the **SELECT** button to confirm.

Note:

- If **DISTANCE** has been set to **MILES**, then **TEMP (temperature)** is shown. Press the **SCROLL** button to select either **°F** or **°C** and then press the **SELECT** button to confirm.
- If **DISTANCE** has been set to **KM**, then the temperature display will be automatically set to **°C**.
- If equipped with **TPMS**, then the **PRESSURE** menu is shown.
- Press the **SCROLL** button to select either **PSI**, **BAR** or **kPa**.
- Press the **SELECT** button to confirm the settings and return to the **DISPLAY SETUP** menu.

Set Clock



SET CLOCK (24 HR Shown)

To set the clock:

- Press the **SCROLL** button to select **SET CLOCK**, then press the **SELECT** button to confirm.
- Press the **SCROLL** button to select the required clock display either **12 HR** or **24 HR** format and press the **SELECT** button to confirm.
- The **SET HOUR** menu is now shown. Press the **SCROLL** button to select the required hour display and press the **SELECT** button.
- The **SET MINUTE** menu is now shown. Press the **SCROLL** button to select the required minute display and press the **SELECT** button to confirm and return to the **DISPLAY SETUP** menu.

Brightness



BRIGHTNESS Menu


To adjust the brightness of the screen:

- Press the **SCROLL** button to select **BRIGHTNESS**, then press the **SELECT** button to confirm.
- Press the **SCROLL** button to adjust the instrument brightness using the adjustment slider between levels 1 (lowest) to 10 (highest).
- Press the **SELECT** button to save the selection and return to the **DISPLAY SETUP** menu.

Riding Modes

The riding mode system allows adjustment of the Anti-lock Brake System (ABS), throttle response (MAP) and Traction Control (TC) settings to suit different road conditions and rider preferences.

Riding modes can be selected using the MODE and SCROLL buttons on the left hand switch housing, while the motorcycle is stationary or moving.



1. **MODE button**
2. **SCROLL button**

The following riding modes are available:

- RAIN
- ROAD
- OFF-ROAD

Each riding mode is fully adjustable but availability of the ABS, MAP and TC settings options may vary between modes. For more information on riding mode configuration, see page **85**.

Riding Mode Selection

Warning

The selection of riding modes while the motorcycle is in motion requires the rider to allow the motorcycle to coast (motorcycle moving, engine running, throttle closed, clutch lever pulled in and no brakes applied) for a brief period of time.

Riding mode selection while the motorcycle is in motion should only be attempted:

- At low speed
- In traffic-free areas
- On straight and level roads or surfaces
- In good road and weather conditions.
- Where it is safe to allow the motorcycle to briefly coast.

Riding mode selection while the motorcycle is in motion **MUST NOT** be attempted:

- At high speeds
- While riding in traffic
- During cornering or on winding roads or surfaces
- On steeply inclined roads or surfaces
- In poor road/weather conditions
- Where it is unsafe to allow the motorcycle to coast.

Failure to observe this important warning may lead to loss of motorcycle control and an accident.

Warning

If ABS and/or TC has been disabled using the BIKE SETUP menu, the ABS and/or TC settings saved for all riding modes will be overridden.

ABS and/or TC will remain OFF regardless of the riding mode selection, until they have been re-enabled or, the ignition has been switch OFF then ON again.

If the ABS is disabled, the brake system will function as a non-ABS braking system. In this situation braking too hard will cause the wheels to lock, and may result in loss of motorcycle control and an accident.

If the traction control is disabled, the motorcycle will handle as normal but without traction control. In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.


Warning

After selecting a riding mode, operate the motorcycle in an area free from traffic to gain familiarity with the new settings.

Do not loan your motorcycle to anyone as they may change the riding mode settings from those you are familiar with, causing loss of motorcycle control and an accident.

To select a riding mode:

Press and release the MODE button on the left hand switch housing to activate the riding mode selection menu in the multifunction display.



Riding Mode Selection Menu

Further presses of the MODE button will scroll through the riding modes in the following order:

- RAIN
- ROAD
- OFF-ROAD.

Alternatively, the SCROLL button can be used to scroll up or down through the riding modes.


Note:

- **To allow the user to scroll between each of the modes, there is a short time-out to allow for further scrolling to take place before the highlighted riding mode is automatically activated.**

Scroll through the riding modes until the desired mode is highlighted in the selection window.

The name of the highlighted riding mode and its currently stored ABS, MAP and TC settings, are displayed on the left hand side of the multifunction display.

The currently active riding mode is indicated with a border.



1. Selected riding mode
2. Selected riding mode's ABS, MAP and TC settings
3. Currently active riding mode

The riding mode shown in the selection window is automatically activated once the time-out has elapsed, and the following conditions for switching modes have been met.

Motorcycle Stationary - Engine Off

- The ignition is switched ON.
- The engine stop switch is in the RUN position.

Motorcycle Stationary - Engine On

- Neutral gear is selected or the clutch is pulled in.

Motorcycle in Motion


Within 30 seconds of selecting a riding mode the rider must carry out the following simultaneously:

- Close the throttle
- Pull the clutch in
- Make sure that the brakes are not engaged (allow the motorcycle to coast).

Note:

- It is not possible to select OFF-ROAD mode while the motorcycle is in motion, if the ABS or TC settings are set to OFF-ROAD or OFF.
- In this case, the motorcycle must be brought to a stop before the riding mode change can take place.

Once the ABS, MAP and TC settings have changed, the multifunction display will return to the home screen and the selected riding mode will be shown.



1. Selected riding mode
2. Home screen

The riding mode change is now complete and normal riding can be resumed.


Instruments

Note:

- The riding mode will default to ROAD when the ignition is switched ON if the OFF-ROAD mode was active the last time the ignition was switched OFF, with ABS and/or TC set to OFF-ROAD or OFF.
- Otherwise, the last selected riding mode will be remembered and activated when the ignition is switched ON.
- If the mode icons are not visible when the ignition switch is in the ON position, make sure that the engine stop switch is in the RUN position.

Incomplete Riding Mode Changes

In the event of an incomplete riding mode change, both the previous and newly selected riding modes will be highlighted with a dashed border. This indicates that the ABS, MAP or TC settings specified by the newly requested riding mode have not been correctly activated.



1. Incomplete riding mode change

In this case the MIL, ABS or TC warning light(s) may be illuminated depending on the current state of each system.

In the event of an incomplete riding mode change:

- Safely bring the motorcycle to a stop.
- Select neutral gear.
- Turn the ignition OFF and then back ON again.
- Select the required riding mode.
- Restart the engine and continue riding.

Warning

Do not stop the engine using the ignition switch or engine stop switch while the motorcycle is moving.

Always bring the motorcycle to a stop safely and engage neutral gear prior to stopping the engine.

Stopping the engine by turning off the ignition or engine stop switch while the motorcycle is moving can lock the rear wheel causing loss of motorcycle control and an accident.

Caution




Do not stop the engine using the ignition switch or engine stop switch while the motorcycle is moving.

Always bring the motorcycle to a stop safely and engage neutral gear prior to stopping the engine.

The transmission is pressure lubricated only when the engine is running. Inadequate lubrication may cause damage or seizure of the transmission, which can lead to sudden loss of motorcycle control and an accident.

Riding Mode Configuration

Refer to the following table for the ABS, MAP and TC options available for each riding mode.

Riding Mode			
	RAIN 	ROAD 	OFF-ROAD 
ABS (Anti-lock Braking System)			
Road	●	●	⊘
Off-Road	⊘	⊘	●
Off	⊘	⊘	○
MAP (Throttle Response)			
Rain	●	○	○
Road	○	●	○
Off-Road	⊘	⊘	●
TC (Traction Control)			
Rain	●	○	⊘
Road	○	●	⊘
Off-Road	⊘	⊘	●
Off	⊘	⊘	○
Key			
●	Standard (Factory Default Setting)		
○	Selectable Option		
⊘	Option Not Available		

ABS Option Descriptions

Warning

The OFF-ROAD ABS option is NOT intended for use with normal, on-road riding.

Use of the rear brake pedal in this situation can cause the rear wheel to lock under heavy braking.

Riding on-road with the ABS set to OFF-ROAD can lead to instability when braking which may result in loss of motorcycle control and an accident.

Warning

If the ABS is disabled, the brake system will function as a non-ABS braking system. In this situation braking too hard will cause the wheels to lock, and may result in loss of motorcycle control and an accident.

- **Road** - Optimal ABS setting for road use.
- **Off-Road** - Optimal ABS setting for off-road use as follows:
- **Front Brake Lever Operation** - If the front brake lever is operated only, the partially integrated braking system will also apply a small amount of rear brake as described in Braking on page 146. In this situation, the level of ABS intervention is optimized for off-road riding for both front and rear wheels.

Instruments

- **Rear Brake Pedal Operation** - If the rear brake pedal is operated at any point, all rear braking input will be controlled directly by the rear brake pedal. Operating the rear brake pedal will override any rear braking input applied by the partially integrated braking system, through use of the front brake lever. In this situation, the level of ABS intervention is optimized for off-road riding for the front wheel, but the rear wheel will be allowed to lock under heavy braking. Use of the rear brake pedal alone will only apply the rear brake and the rear wheel will be allowed to lock under heavy braking. The ABS warning light will flash slowly.
- **Off** - ABS is turned off. The ABS warning light will be illuminated.

MAP Option Descriptions

- **Rain** - Reduced throttle response when compared to the Road setting, for wet or slippery conditions.
- **Road** - Standard throttle response.
- **Off-Road** - Optimal throttle response setting for off-road use.

TC Option Descriptions

Warning

The OFF-ROAD TC option is not intended for normal, on-road riding.

Riding on-road with TC set to OFF-ROAD can produce instability under acceleration due to the increased amount of rear wheel slip allowed.

Instability caused by rear wheel slip may lead to loss of motorcycle control and an accident.

Warning

If the traction control is disabled, the motorcycle will handle as normal but without traction control. In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.

- **Rain** - Optimal TC setting for wet or slippery conditions. Allows reduced rear wheel slip when compared with the Road setting.
- **Road** - Optimal TC setting for road use, allows a small amount of rear wheel slip.
- **Off-Road** - TC is set up for off-road use, allowing increased rear wheel slip when compared to the Rain, Road and Sport settings. The TC indicator light will flash slowly.
- **Off** - TC is turned OFF. The TC disabled warning light will be illuminated.


Note:

- During riding mode configuration, ABS and TC can be activated or deactivated in the Off-Road and Rider modes.
- If the riding mode being configured is currently selected, adjustments to the ABS, MAP and TC systems will become immediately active.
- If the riding mode being configured is not currently selected, adjustments to the ABS, MAP and TC systems are saved and will become active the next time the riding mode is selected.

To configure a riding mode:

With the motorcycle stationary, press and hold the SELECT button to activate the SETTINGS menu.

Use the SCROLL button to select RIDING MODES then press the SELECT button to confirm the selection.



RIDING MODES Menu

Use the SCROLL button to select the riding mode to be configured, then press the SELECT button to enter the selected riding mode's configuration menu.


Alternatively, press and hold the MODE button to provide direct access to a riding mode's configuration menu as follows:

From the Home Screen

Press and hold the MODE button while in the Home screen to activate the configuration menu for the currently active riding mode.

From the RIDING MODES Menu

Press and hold the MODE button while in the RIDING MODES menu to activate the configuration menu for the required riding mode.



**OFF-ROAD Configuration Menu
(MAP Selected)**

From a riding mode's configuration menu, press the SCROLL button until the required option is selected. Press the SELECT button to confirm and view the option's menu.

Exit

Select EXIT to return to the RIDING MODES menu.

Instruments


ABS



ABS Menu (ROAD Selected)

To change the ABS setting:

- From the ABS menu, press the SCROLL button to select the required option. Press the SELECT button to confirm the selection and return to the configuration menu.

 **Warning**

If the ABS is disabled, the brake system will function as a non-ABS braking system. In this situation braking too hard will cause the wheels to lock, and may result in loss of motorcycle control and an accident.

MAP



MAP Menu (ROAD Selected)

To change the MAP setting:

- From the MAP menu, press the SCROLL button to select the required option. Press the SELECT button to confirm the selection and return to the configuration menu.


TC



TC Menu (ROAD Selected)

To change the TC setting:

- From the TC menu, press the SCROLL button to select the required option. Press the SELECT button to confirm the selection and return to the configuration menu.

 **Warning**

If the traction control is disabled, the motorcycle will handle as normal but without traction control. In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.

Reset



RESET Menu (CONFIRM Selected)

To reset the riding modes:

- From the RESET menu, press the SCROLL button to select CONFIRM to return the selected riding mode's configuration to the factory default settings.
- Refer to the table on page **85** for details of the factory default settings for each riding mode.

GENERAL INFORMATION

Table of Contents

Hand Controls.....	91
Keyless Ignition (if equipped).....	91
Master Ignition Switch (if equipped).....	92
Ignition Key.....	92
Ignition Switch/Steering Lock.....	93
Right Handlebar Switches.....	94
Right Handlebar Switches.....	96
Left Handlebar Switches.....	97
Left Handlebar Switches.....	100
Throttle Control.....	102
Brake and Clutch Lever Adjusters.....	103
Cruise Control.....	104
Activating Cruise Control.....	105
Adjusting the Set Speed While in Cruise Control.....	106
Deactivating Cruise Control.....	106
Resuming the Cruise Control Set Speed.....	107
Triumph Semi Active Suspension (TSAS) (if equipped).....	108
Traction Control (TC).....	109
Optimized Cornering Traction Control (if equipped).....	110
Traction Control Settings.....	111
Tire Pressure Monitoring System (TPMS) (if equipped).....	111
Tire Pressure Sensor Serial Number.....	112
System Display.....	112
Sensor Batteries.....	113
TPMS System Fault.....	113
Tire Pressures.....	114
Low Tire Pressure.....	114
Fuel.....	115
Fuel.....	115
Fuel Tank Cap.....	116
Filling the Fuel Tank.....	117
Windshield.....	118
Handlebar Adjustment.....	119
Stands.....	121
Side Stand.....	121
Center Stand (if equipped).....	121

General Information

Seats	122
Seat Care	122
Passenger Seat	122
Rider's Seat	123
Rider's Seat Height Adjustment	124
Heated Seats (if equipped)	124
Helmet Hook	126
Tool Kit, Handbook and the Triumph Accessory D-Lock	126
Electrical Accessory Sockets	127
Universal Serial Bus (USB) Socket	128
Expedition Aluminum Panniers (if equipped)	129
Breaking-In	136
Daily Safety Checks	137

Hand Controls

Keyless Ignition (if equipped)

The keyless ignition system allows the motorcycle to be started without the use of a mechanical key.

There are three keys supplied with the motorcycle. One smart key and two standard keys.



Smart Key

Note:


- An additional smart key can be purchased from your Triumph dealer. However, only three keys can be programmed to the motorcycle. This can be a combination of smart keys and standard keys.

Smart Key Operation

Press the button on the smart key to turn the key on. The button light shows green briefly to indicate that the smart key is on.

A short press on the smart key button shows the status of the smart key; red is OFF and green is ON. A long press of the button will change the status to OFF or ON after briefly showing the original status color first.

The smart key must be within close proximity (three feet/one meter) of the system sensor, which is located on the left hand side of the motorcycle under the passenger seat. If the smart key is out of range of the sensor then it will be unresponsive and the keyless ignition cannot be activated.



Sensor Location

For more information on starting the engine with keyless ignition, see page 144.

General Information

⚠ Caution

All keys supplied with the motorcycle are specific to the individual motorcycle. They cannot be used on another motorcycle.


If all keys are lost, misplaced or damaged, then the chassis control unit on the motorcycle will need to be replaced.

To avoid unnecessary cost and time, make sure that all spare keys are kept in a secure location.

⚠ Caution

If there is a fault with the smart key or the smart key battery is flat then take the smart key to the nearest Triumph dealer to rectify.

Master Ignition Switch (if equipped)



Master Ignition Switch

The master ignition switch is only mounted to motorcycles in the United States and Canada. The master ignition switch is located on the right hand side of the instrument panel.

To operate the motorcycle with the keyless ignition, the master ignition switch must be in the ON position.

If the master ignition switch is in the OFF position then the keyless ignition cannot be used and the motorcycle cannot be started.

Ignition Key

Tiger 1200 XR Only

⚠ Warning

Additional keys, key rings/chains or items attached to the ignition key may interfere with the steering, leading to loss of motorcycle control and an accident.

Remove all additional keys, key rings/chains and items from the ignition key before riding the motorcycle.


⚠ Caution

Additional keys, key rings/chains or items attached to the ignition key may cause damage to the motorcycle's painted or polished components.

Remove all additional keys, key rings/chains and items from the ignition key before riding the motorcycle.

⚠ Caution

Do not store the spare key with the motorcycle as this will reduce all aspects of security.



cixj

1. Key number tag

In addition to operating the ignition switch/steering lock, the ignition key is required to operate the seat lock and fuel tank cap.


When the motorcycle is delivered from the factory, two ignition keys are supplied together with a small tag bearing the key number. Make a note of the key number and store the spare key and key number tag in a safe place away from the motorcycle.

There is a transponder within the ignition keys to turn off the engine immobilizer. To make sure the immobilizer functions correctly, always have only one of the ignition keys near the ignition switch. Having two ignition keys near the switch may interrupt the signal between the transponder and the engine immobilizer. In this situation the engine immobilizer will remain active until one of the ignition keys is removed.

Always get replacement keys from your authorized Triumph dealer. Replacement keys must be 'paired' with the motorcycle's immobilizer by your authorized Triumph dealer.

Ignition Switch/Steering Lock

Tiger 1200 XR Only



1. Ignition switch/steering lock
2. LOCK position
3. OFF position
4. ON position
5. PARK position

Engine Immobilizer

The ignition barrel housing acts as the antenna for the engine immobilizer.

When the ignition switch is turned to the OFF position and the ignition key is removed, the engine immobilizer is on. The engine immobilizer is turned off when the ignition key is in the ignition switch and it is turned to the ON position.

General Information

Ignition Switch Positions

This is a four-position, key operated switch. The key can be removed from the switch only when it is in the OFF, LOCK or P (PARK) position.

TO LOCK: Turn the handlebar fully to the left, turn the key to the OFF position, push and fully release the key, then rotate it to the LOCK position.

PARKING: Turn the key from the LOCK position to the P position. The steering will remain locked, and the position lights will be switched on.

Note:

- **Do not leave the steering lock in the P position for long periods of time as this will cause the battery to discharge.**

Warning

For reasons of security and safety, always move the ignition switch to the OFF, LOCK or PARK position and remove the key when leaving the motorcycle unattended.

Any unauthorized use of the motorcycle may cause injury to the rider, other road users and pedestrians and may also cause damage to the motorcycle.


Warning

With the key in the LOCK or P position the steering will become locked.

Never turn the key to the LOCK or P positions while the motorcycle is moving as this will cause the steering to lock. Locked steering will cause loss of motorcycle control and an accident.

Right Handlebar Switches

All Models except Tiger 1200 XR



1. HOME button
2. Engine start/stop switch
3. QUICK START position
4. RUN position
5. STOP position
6. Power ON/OFF position
7. Hazard warning lights switch
8. Steering lock button

HOME Button

The HOME button is used to access the main menu on the instrument display.

Press and release the HOME button to select between the main menu and instrument display.

QUICK START Position

The QUICK START position operates the electric starter allowing for a quicker ignition start.

From the ignition off, press and hold the engine start/stop switch in the QUICKSTART position with all the correct conditions met, to start the motorcycle.

For more information, see page 144.

RUN Position

The engine start/stop switch must be in the RUN position for the motorcycle to operate.

STOP Position

The STOP position stops the engine.

Note:

- **Although the engine stop position stops the engine, it does not turn off all the electrical circuits and may cause difficulty in restarting the engine due to a discharged battery.**

Power ON/OFF Position

The Power ON/OFF position switches the electrical circuits and the instrument display between on or off. This allows access to the instrument display without starting the engine when switched ON.

Caution

Do not leave the switch in the Power ON position for a long period of time as this may cause damage to electrical components and will discharge the battery.

Hazard Warning Lights Button

To turn the hazard warning lights on or off, press and release the hazard warning light button.

The ignition must be switched on for the hazard warnings lights to be activated, but the hazard lights will remain active if the ignition is switched off until the hazard warning light button is pressed again.

Steering Lock Button

To lock the motorcycle, turn the handlebar fully to the left and press the steering lock button.

When the ignition is off then the engine immobilizer is on. The engine immobilizer is turned off when the ignition is started.

Warning


For reasons of security and safety, always make sure the steering lock is on when leaving the motorcycle unattended.

Any unauthorized use of the motorcycle may cause injury to the rider, other road users and pedestrians and may also cause damage to the motorcycle.

General Information

Right Handlebar Switches

Tiger 1200 XR Only



1. Engine stop switch - STOP position
2. Engine stop switch - RUN position
3. Cruise control adjust button
4. Starter button
5. Hazard warning lights button

Engine Stop Switch

In addition to the ignition switch being turned to the ON position, the engine stop switch must be in the RUN position for the motorcycle to operate.

The engine stop switch is for emergency use. If an emergency arises which requires the engine to be stopped, move the engine stop switch to the STOP position.

Note:

- Although the engine stop switch stops the engine, it does not turn off all the electrical circuits and may cause difficulty in restarting the engine due to a discharged battery. Ordinarily, only the ignition switch should be used to stop the engine.

Caution

Do not leave the ignition switch in the ON position unless the engine is running as this may cause damage to electrical components and will discharge the battery.

Starter Button

The starter button operates the electric starter. For the starter to operate, the clutch lever must be pulled to the handlebar.

Note:

- Even if the clutch lever is pulled to the handlebar, the starter will not operate if the side stand is down and a gear is engaged.

Cruise Control Adjust Button

The cruise control adjust button is a two way switch with the top marked RES/+ and the bottom marked SET/- (see page 104).


Hazard Warning Lights Button

To turn the hazard warning lights on or off, press and release the hazard warning light button.

The ignition must be switched on for the hazard warnings lights to be activated, but the hazard lights will remain active if the ignition is switched off until the hazard warning light button is pressed again.

Left Handlebar Switches

All Models except Tiger 1200 XR



1. Cruise control adjust switch
2. Daytime Running Lights (DRL) switch (if equipped)
3. MODE button
4. Turn signal switch
5. Joystick button
6. Horn button
7. Heated grips switch
8. Front fog lights switch (if equipped)
9. High beam button
10. Rider's heated seat switch (if equipped)

Cruise Control Adjust Button

The cruise control adjust button is a two way switch with the top marked RES/+ and the bottom marked SET/-.

For more information on cruise control operation, see page 104.

Daytime Running Lights (DRL) Switch (if equipped)



When the ignition is switched ON and the daytime running lights switch is set to DRL mode, the daytime running lights warning light will illuminate.

The daytime running lights and low beam headlights are operated manually using the DRL switch. Press the top of the switch for DRL mode, and the bottom of the switch for low beam headlight mode.

Warning

Do not ride for longer than necessary in poor ambient light conditions with the Daytime Running Lights (DRL) in use.

Riding with the daytime running lights when dark, in tunnels or where poor ambient light is apparent may reduce the riders vision or blind other road users.

Blinding other road users or reduced vision in low ambient light levels may result in loss of motorcycle control and an accident.

Note:

- During daylight hours the daytime running lights improve the motorcycles visibility to other road users.
- Low beam headlights must be used in any other conditions unless the road conditions allow for high beam headlights to be used.

General Information

MODE Button

When the MODE button is pressed and released it will activate the Riding Mode Selection Menu in the display screen. Further presses of the MODE button will scroll through the available riding modes (see Riding Mode Selection on page **81**).

Press and hold the MODE button provides direct access to a riding mode's configuration menu.

For more information on riding mode selection and configuration, see page **85**).

Turn Signal Switch

When the turn signal switch is pushed to the left or right and released, the corresponding turn signals will flash on and off. To turn off the turn signals, push and release the switch in the central position.

Models Equipped with Automatic Self-Canceling Turn Signals

A short press and release of the turn signal switch to the left or right will cause the corresponding turn signals to flash on and off three times, then go off.

A longer press and release of the turn signal switch to the left or right will cause the corresponding turn signals to flash on and off until they are canceled as follows:

The turn signal self-cancel system becomes active eight seconds after operating a turn signal. Eight seconds after turning the turn signal on and after riding a further 213 ft. (65 meters), the turn signal self-cancel system will automatically turn off the turn signals.

To disable the turn signal self-cancel system refer to the Bike Setup section on page **47**.

The turn signals can be canceled manually. To manually turn off the turn signal, press and release the turn signal switch in the central position.

Joystick Button

The Joystick is used to operate the following functions of the instruments:

- Up - scroll the menu from the bottom to the top
- Down - scroll the menu from the top to the bottom
- Left - scroll the menu to the left
- Right - scroll the menu to the right
- Center - press to confirm selection.

Horn Button

When the horn button is pushed, with the ignition switch turned to the ON position, the horn will sound.

Heated Grips Switch

The heated grips will only heat when the engine is running.

When the heated grips are switched on, the heated grips symbol will appear in the display and the selected heat level will be shown.

There are three levels of heat: low, medium and high. This is indicated by the different colors of the symbols shown in the display.



1. Low heat symbol (yellow)
2. Medium heat symbol (orange)
3. High heat symbol (red)

For maximum benefit in cold conditions, from the OFF position press the switch once for the high heat setting initially and then reduce the heat level by pressing the switch again for a low heat setting when the grips have warmed up.

To turn off the heated grips, press and release the switch until the heated grips symbol is no longer shown in the display.

Low Power Voltage Cut Off

If a low voltage is detected, the heated grips switch will power off. The heated grips will not function again until the voltage rises to a safe level.

The switch will not power back on automatically even if the voltage rises to the safe level. The user must manually press the switch again to activate the heated grips.

Fog Lights Switch (if equipped)

To turn the fog lights on or off, with the headlights on, press and release the fog lights switch. When the fog lights are turned on, the fog lights indicator will illuminate in the display.

Note:

- The fog lights switch will only operate when the headlights are on.
- The fog lights switch will reset to off when the ignition is turned off then on again.

High Beam Button

The high beam button has a different function depending on whether Daytime Running Lights (DRL) are installed or not. When the high beam is turned on, the high beam indicator light will illuminate in the display.

Models with Daytime Running Lights (DRL)

If the DRL switch is in the Daytime Running Lights (DRL) position, then press and hold the high beam button to turn the high beam on. It will remain on as long as the button is held in and will turn off as soon as the button is released.

If the DRL switch is in the dip beam position, press the high beam button to switch the high beam on. Each press of the button will swap between dip and high beam.

Note:

- A lighting on/off switch is not installed on this model. The brake/tail light and license plate light all function automatically when the ignition is turned to the ON position.
- The headlight will function when the ignition is turned on and the engine is running.

General Information

Models without Daytime Running Lights (DRL)

Press the high beam button to switch the high beam on. Each press of the button will swap between dip and high beam.

Note:

- A lighting on/off switch is not installed on this model. The position light, brake/tail light and license plate light all function automatically when the ignition is turned to the ON position.
- The headlight will function when the ignition is turned on and the engine is running.



Rider's Heated Seat Switch (if equipped)

The rider's heated seat will only heat when the engine is running. When the rider's heated seat is switched on, then the rider's heated seat symbol will appear in the display. The selected heat level will also be indicated by the color of the symbol.

For more information, see page 124.

Left Handlebar Switches

Tiger 1200 XR Only



1. Headlight dimmer switch
2. Turn signal switch
3. Horn button
4. Instruments SELECT button
5. Instruments SCROLL button
6. MODE button

Headlight Dimmer Switch

High or dip beam can be selected with the headlight dimmer switch. To select high beam, push the switch forward. To select dip beam, push the switch rearwards. When the high beam is turned on, the high beam indicator light will illuminate in the tachometer.

Pass Function

With the headlight dimmer switch set to the dip beam position, pressing the bottom of the switch will activate the pass function.

When pressed, the headlight high beam will be switched on. It will remain on as long as the switch is held in and will turn off as soon as the switch is released.

Note:

- **A lighting on/off switch is not installed on this model. The position light, brake/tail light and license plate light all function automatically when the ignition is turned to the ON position.**
- **The headlight will function when the ignition switch is turned to the ON position and the engine is running.**

There are two alternate ways to turn on the headlight without the engine running:

- Pull in the clutch lever then turn the ignition to the ON position. The headlight will be on and will remain on when the clutch lever is released.
- With the ignition on and the headlight dimmer switch set to the dip beam position, pressing the bottom of the switch will activate the headlight. The headlight will remain on when the switch is released.

The headlight will go off while pressing the starter button until the engine starts.

Turn Signal Switch

When the turn signal switch is pushed to the left or right and released, the corresponding turn signals will flash on and off. To turn off the turn signals, push and release the switch in the central position.

Horn Button

When the horn button is pushed, with the ignition switch turned to the ON position, the horn will sound.

Instrument SELECT Button

When the SELECT button is pressed and released it will select the menu highlighted in the multifunction display screen.

Pressing and holding the SELECT button when the motorcycle is stationary will activate the Settings Menu in the multifunction display (see Settings Menu on page **74**).

Instrument SCROLL Button

When the SCROLL button is pressed and released it will scroll through the menu visible in the instrument's display screen.


MODE Button

When the MODE button is pressed and released it will activate the Riding Mode Selection Menu in the multifunction display screen. Further presses of the mode button will scroll through the available riding modes (see Riding Mode Selection on page **81**).

General Information

Pressing and holding the MODE button will provide direct access to a Riding Mode's Configuration Menu (see Riding Mode Configuration on page 85).

Throttle Control



1. Throttle open position
2. Throttle closed position
3. Cruise control cancel position

This Triumph model has an electronic throttle twist grip to open and close the throttle via the engine control unit. There are no direct-acting cables in the system.

The throttle grip has a resistive feel to it as it is rolled rearwards to open the throttle. When the grip is released it will return to the throttle closed position by its internal return spring and the throttle will close.

From the closed position, the throttle twist grip can be rolled forward 0.12 - 0.16 in (3 - 4 mm) to deactivate the cruise control (see page 106).

There are no user adjustments for the throttle control.

If there is a malfunction with the throttle control the Malfunction Indicator Light (MIL) becomes illuminated and one of the following engine conditions may occur:

- MIL illuminated, restricted engine RPM and throttle movement
- MIL illuminated, limp-home mode with the engine at a fast idle condition only
- MIL illuminated, engine will not start.

For all of the above conditions contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Brake Use

Warning

Reduce speed and do not continue to ride for longer than is necessary with the malfunction indicator light illuminated. The fault may adversely affect engine performance, exhaust emissions and fuel consumption.

Reduced engine performance could cause a dangerous riding condition, leading to loss of motorcycle control and an accident.

Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

At low throttle opening (approximately 68°F (20°C)), the brakes and throttle can be used together.

At high throttle opening (greater than 68°F (20°C)), if the brakes are applied for more than two seconds the throttles will close and the engine speed will reduce. To return to normal throttle operation, release the throttle control, release the brakes and then re-open the throttle.

Brake and Clutch Lever Adjusters

Warning


Do not attempt to adjust the lever with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

After adjusting the lever, operate the motorcycle in an area free from traffic to gain familiarity with the new lever setting. Do not loan your motorcycle to anyone as they may change the lever setting from the one you are familiar with causing loss of motorcycle control and an accident.

An adjuster is mounted to both the front brake and clutch levers. The adjusters allow the distance from the handlebar to the lever to be changed to one of five positions for the front brake lever or four positions for the clutch lever, to suit the span of the operator's hands.

To adjust the lever:

- Push the lever forward and turn the adjuster wheel to align one of the numbered positions with the arrow mark on the lever holder.
- The distance from the handlebar grip to the released lever is shortest when set to number five, and longest when set to number one.



1. Adjuster wheel, brake lever shown
2. Arrow mark

General Information

Cruise Control

Warning

Cruise control must only be used where you can drive safely at a steady speed.

Cruise control should not be used when riding in heavy traffic, on roads with sharp/blind bends or when they are slippery.

Using cruise control in heavy traffic, on roads with sharp/blind bends or when they are slippery, may result in loss of motorcycle control and an accident.

Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road traveled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as speed increases. Always reduce speed in consideration of weather and traffic conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course, on-road competition or on closed-course racetracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's behavior in all conditions.


High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Note:

- **Cruise control may not function if there is a malfunction with the ABS system and the ABS warning light is illuminated.**
- **Cruise control will continue to function if a riding mode is selected with ABS set to Off-Road or Off.**
- **Cruise control will continue to function if ABS has been disabled.**

Tiger 1200 XR Only


The cruise control buttons are located on the right hand switch housing and can be operated with minimum movement by the rider.



1. Cruise control RES/+ button
2. Cruise control SET/- button

All Models except Tiger 1200 XR

The cruise control buttons are located on the left hand switch housing and can be operated with minimum movement by the rider.



1. Cruise control RES/+ button
2. Cruise control SET/- button

Cruise control can be switched on or off at any time but it cannot be activated until all the conditions described on page 105 have been met.

Activating Cruise Control

To turn on the cruise control system, press the SET/- button. The cruise control symbol will be shown in the display screen. The cruise control set speed will be shown as '--' indicating that a speed has not yet been set.


To activate cruise control, the following conditions have to be met:

- The motorcycle must be traveling at a speed between 19 to 100 mph (30 to 160 km/h).
- The motorcycle must be in 3rd gear or higher.
- Once these conditions have been met, press the SET/- button to activate cruise control. The cruise control symbol will be shown in a green light in the TFT display to indicate that cruise control is now active.

The word SET will be shown next to the cruise control symbol. The cruise control set speed will be shown and the cruise control light will illuminate in the tachometer indicating that cruise control is active.


General Information

Tiger 1200 XR Only



1. Cruise control symbol
2. Cruise control set indicator
3. Cruise control set speed
4. Cruise control light

All Models except Tiger 1200 XR



1. Cruise control symbol
2. Cruise control set indicator
3. Cruise control set speed

The cruise control system will maintain the set speed until:

- The set speed is adjusted as described on page **106**.
- Cruise control is deactivated as described on page **106**.

Adjusting the Set Speed While in Cruise Control

To adjust the set speed while in cruise control, press and release the:

- RES/+ button to increase the speed
- SET/- button to decrease the speed.

Each press of the buttons will adjust the speed by 1 mph or 1 km/h. If the buttons are held, the speed continuously increases or decreases in single digit increments.

Stop pressing the adjust button when the desired speed is shown in the display.

Note:

- The cruise control set speed display will flash until the new set speed has been achieved.
- If riding up a steep incline and cruise control is unable to maintain the set speed, the cruise control set speed display will flash until the motorcycle has regained the set speed.

An alternative way to increase the speed in cruise control is to accelerate to the desired speed using the throttle grip and then press the SET/- button.

Deactivating Cruise Control

The cruise control can be deactivated by one of the following methods:

- Roll the throttle twist grip fully forward.
- Pull the clutch lever.
- Operate the front or rear brake.
- Increase speed by using the throttle for more than 60 seconds.

Upon deactivation, the cruise control light will go out in the tachometer but the SET indicator and set speed will still be shown in the display screen, indicating that the cruise control set speed has been stored.

The cruise control set speed can be resumed as described on page 107, provided the cruise control has not been deactivated by turning the ignition switch to the OFF position.

Resuming the Cruise Control Set Speed

**Warning**

When resuming cruise control, always make sure that the traffic conditions are suitable for the set speed.

Using cruise control in heavy traffic, on roads with sharp/blind bends or when they are slippery, may result in loss of motorcycle control and an accident.

Cruise control will be deactivated if one of the following actions has been taken:

- Roll the throttle twist grip fully forward.
- Pull the clutch lever.
- Operate the front or rear brake.
- Increase speed by using the throttle grip for more than 60 seconds.

The cruise control set speed can be resumed by pressing and releasing the RES/+ button provided a set speed has been stored.

The motorcycle must be traveling at a speed between 19 to 100 mph (30 to 160 km/h) and be in 3rd gear or higher.

A stored set speed is indicated by the word SET next to the cruise control symbol in the display screen.

The stored set speed will remain in the cruise control memory until the ignition switch has been turned to the OFF position.

Note:

- **The cruise control set speed display will flash until the resumed set speed has been achieved.**

General Information

Triumph Semi Active Suspension (TSAS) (if equipped)

Note:

- All models except for Tiger 1200 XR are equipped with Triumph Semi Active Suspension (TSAS).



Warning

After adjusting the suspension, operate the motorcycle in an area free from traffic to gain familiarity with the new settings.

Do not loan your motorcycle to anyone as they may change the suspension settings from the one you are familiar with causing loss of motorcycle control and an accident.

The Triumph Semi-Active Suspension System (TSAS) controls adjustment of the front and rear suspension damping and automatic rear suspension preload settings.

TSAS allows a convenient remote adjustment of the TSAS mode and damping settings through the instruments, while the motorcycle is stationary or moving.

TSAS adjustments are made instantaneously once a new mode or damping setting has been selected and the engine is running.

TSAS Modes

The following TSAS modes are available for selection:

- Auto - The TSAS system will automatically detect the type of surface being ridden on (road or off-road) and will adjust rebound and compression damping settings accordingly.
- Off-Road - Optimal TSAS settings for off-road use.

TSAS Damping Settings

There are a total of nine damping settings available for selection ranging from COMFORT (soft) to SPORT (firm) with the three main settings being:

- COMFORT
- NORMAL
- SPORT.

For more information on accessing the TSAS settings, see page 45.

System Calibration

The TSAS system will recalibrate adjustment motors under the following conditions:

- If the battery has been disconnected for any reason.
- If a fault occurs with the TSAS system during normal operation.

The warning light will flash twice every second during system recalibration.

To allow the system to calibrate correctly, the following procedure must be adhered to:

- Turn the ignition on. Do not start the engine.
- Wait for the warning light to stop flashing indicating that adjustment motor calibration is complete.
- Start the engine. If the warning light resumes flashing, the adjustment motors are being recalibrated due to low battery voltage.
- Wait for the warning light to stop flashing before riding the motorcycle.

Failure to follow this procedure will cause the recalibration to be stopped and the warning light to remain lit.

In this case the warning light will extinguish once the recalibration is next allowed to complete.

Traction Control (TC)

Warning

The traction control and optimized cornering traction control systems are not a substitute for riding appropriately for the prevailing surface and weather conditions. The systems cannot prevent loss of traction due to:

- excessive speed when entering turns
- accelerating at a sharp lean angle
- braking.

Traction control or optimized cornering traction control cannot prevent the front wheel from slipping.

Failure to observe any of the above may result in loss of motorcycle control and an accident.

All motorcycles are equipped with Traction Control (TC).

Traction control is a system that helps to maintain traction when accelerating on wet/slippery road surfaces. If sensors detect that the rear wheel is losing traction (slipping), the traction control system will engage and alter the engine power until traction to the rear wheel has been restored.

The traction control indicator light will flash while it is engaged and the rider may notice a change to the sound of the engine.

For information on the traction control indicator light operation, see page **26** and page **62**.

General Information

Optimized Cornering Traction Control (if equipped)

Note:

- **All models except Tiger 1200 XR are equipped with optimized cornering Traction Control (TC).**

Optimized cornering traction control is a system designed to give the rider increased control should the traction control be activated while the motorcycle is leaning in a corner.

The system constantly monitors the lean angle of the motorcycle and adapts the level of traction control intervention to maintain rear wheel traction during cornering.

Warning

If the TC system is not functioning, care must be taken when accelerating and cornering on wet/slippery road surfaces to avoid rear wheel spin.

In the event of a fault, the TC disabled warning light may be accompanied by the engine management system malfunction indicator light and/or the ABS warning light.

Do not continue to ride for longer than is necessary with any of the above warning lights illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Hard acceleration and cornering in this situation may cause the rear wheel to spin resulting in loss of motorcycle control and an accident.

Warning

If a fault occurs with the optimized cornering TC system, the TC disabled warning light will illuminate and a message will be shown in the display.

In this situation, the TC system will continue to operate but without the optimized cornering function, provided that:

- There are no other faults with the TC system.
- TC has NOT been disabled by the rider (see Bike Setup on page 48 or Riding Mode Configuration on page 44).

Care must be taken when accelerating and cornering on wet/slippery road surfaces to avoid rear wheel spin.

In the event of a fault, the TC disabled warning light may be accompanied by the engine management system malfunction indicator light and/or the ABS warning light.

Do not continue to ride for longer than is necessary with any of the above warning lights illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Hard acceleration and cornering in this situation may cause the rear wheel to spin resulting in loss of motorcycle control and an accident.

Note:

- TC and optimized TC control (if equipped) may not function if there is a malfunction with the ABS system. In this situation, the warning lights for the ABS, TC and the MIL may be illuminated.

For full details of the TC disabled warning light operation and its associated instrument warning messages, see page 27.

Traction Control Settings



If the traction control is disabled, the motorcycle will handle as normal but without traction control.

In this situation accelerating too hard on wet/slippery road surfaces may cause the rear wheel to slip, and may result in loss of motorcycle control and an accident.

The TC system can be disabled as described in Bike Setup on page 48, or set to the conditions described in Riding Mode Configuration on page 44.

Tire Pressure Monitoring System (TPMS) (if equipped)



Warning

The daily check of tire pressures must not be excluded because of the installation of the TPMS. Check the tire pressure when the tires are cold and using an accurate tire pressure gage (see page 189).

Use of the TPMS system to set inflation pressures may lead to incorrect tire pressures leading to loss of motorcycle control and an accident.

Function

Tire pressure sensors are mounted to the front and rear wheels. These sensors measure the air pressure inside the tire and transmit pressure data to the instruments. The sensors will not transmit data until the motorcycle reaches a speed of approximately 12 mph (20 km/h). Two dashes will be visible in the system display until the tire pressure signal is received.

After bring the motorcycle to a stop, the sensors continue to transmit data for approximately seven minutes before switching off. The tire pressure values remain visible in the system display until the sensors switch off.

An adhesive label will be mounted to the wheel rim to indicate the position of the tire pressure sensor, which is near the valve.

General Information

Note:

- The Tire Pressure Monitoring System (TPMS) is available as an accessory kit. It must be installed by your authorized Triumph dealer.
- The TPMS display on the instruments will only be activated when the system has been installed.

Tire Pressure Sensor Serial Number

The serial number for the tire pressure sensor is printed on a label attached to the sensor. This number may be required by your authorized Triumph dealer for service or diagnostics.

When the tire pressure monitoring system is being installed to the motorcycle, make sure that your authorized Triumph dealer records the serial numbers of the front and rear tire pressure sensors in the spaces provided below.

Front Tire Pressure Sensor

Rear Tire Pressure Sensor

System Display




The tire pressure warning light works in conjunction with the Tire Pressure Monitoring System (TPMS).

The warning light will only illuminate when the front or rear tire pressure is below the recommended pressure. It will not illuminate if the tire is over inflated.


When the warning light is illuminated, the TPMS symbol indicating which is the deflated tire and its pressure will automatically be shown in the display.

Tiger 1200 XR Only



1. TPMS symbol
2. Front tire pressure indicator
3. Rear tire pressure indicator

All Models except Tiger 1200 XR



1. **Warning lights**
2. **Front tire pressure indicator**
3. **Rear tire pressure indicator**

The tire pressure at which the warning light illuminates is temperature compensated to 68°F (20°C) but the numeric pressure display associated with it is not. Even if the numeric display seems at or close to the standard tire pressure when the warning light is on, a low tire pressure is indicated and a puncture is the most likely cause.

Warning

Stop the motorcycle if the tire pressure warning light illuminates.

Do not ride the motorcycle until the tires have been checked and the tire pressures are at their recommended pressure when cold.

The motorcycle information display will automatically switch to the tire pressure display when a low tire pressure is detected.

Dashes will be displayed in the tire pressure display until the motorcycle reaches a speed of approximately 12 mph (20 km/h).

Sensor Batteries

When the battery voltage in a pressure sensor is low a message will be shown in the display, and the TPMS symbol or message will indicate which wheel sensor has the low battery voltage.

If the batteries are completely flat, only dashes will be shown in the display screen, the red TPMS warning light will be on and the TPMS symbol will flash continuously. A message will also be shown in the display.

Contact your authorized Triumph dealer to have the sensor replaced and the new serial number recorded in the spaces provided on page **112**.

With the ignition switched on, if TPMS symbol flashes continuously or the TPMS warning light remains on there is a fault with the TPMS system. Contact your Triumph dealer to have the fault rectified.

TPMS System Fault

If a fault occurs with the TPMS system, the red TPMS warning light will be illuminated and the message SENSOR SIGNAL FRONT/REAR TIRE will be shown in the display. Contact your authorized Triumph dealer to have the fault rectified.

General Information

Tire Pressures

The tire pressures shown on your instrument panel indicate the actual tire pressure at the time of selecting the display. This may differ from the inflation pressure set when the tires are cold because tires become warmer during riding, causing the air in the tire to expand and the inflation pressure to increase. The cold inflation pressures specified by Triumph take account of this.

Only adjust tire pressures when the tires are cold using an accurate tire pressure gage (see page **189**), and do not use the tire pressure display on the instruments.

Warning

The Tire Pressure Monitoring System (TPMS) is not to be used as a tire pressure gage when adjusting the tire pressures. For correct tire pressures, always check the tire pressures when the tires are cold and using an accurate tire pressure gage (see page **189**).

Use of the TPMS system to set inflation pressures may lead to incorrect tire pressures leading to loss of motorcycle control and an accident.

Caution

Do not use anti puncture fluid or any other item likely to obstruct air flow to the TPMS sensor's orifices. Any blockage to the air pressure orifice of the TPMS sensor during operation will cause the sensor to become blocked, causing irreparable damage to the TPMS sensor assembly.

Damage caused by the use of anti puncture fluid or incorrect maintenance is not considered a manufacturing defect and will not be covered under warranty.

Always have your tires mounted by your authorized Triumph dealer and inform them that tire pressure sensors installed on the wheel.

Low Tire Pressure

Warning

Stop the motorcycle if the tire pressure warning light illuminates.

Do not ride the motorcycle until the tires have been checked and the tire pressures are at their recommended pressure when cold.

If a low tire pressure is detected, the tire pressure warning light will illuminate and a message will be shown in the display (see page **64** or page **30**).

Fuel

Fuel Requirement/Refueling



Fuel Grade

These Triumph motorcycles are designed to run on unleaded gasoline with a CLC or AKI octane rating (R+M)/2 of 87 or higher. Federal regulations require that pumps delivering unleaded gasoline are marked 'UNLEADED' and that the Cost of Living Council (CLC) or Anti-Knock Index (AKI) octane rating is also displayed. These ratings are an average of the Research Octane Number (RON) and the Motor Octane Number (MON).

In certain circumstances engine calibration may be required. Always refer to your authorized Triumph dealer.

Caution

The use of leaded gasoline is illegal in some countries, states or territories. Check local regulations before using leaded gasoline.

Note:

- If 'knocking' or 'pinging' occurs at a steady engine speed under normal load, use a different brand of gasoline or gasoline which has a higher octane rating.

Oxygenated Gasoline

To help in meeting clean air standards, some areas of the U.S. use oxygenated gasoline to help reduce harmful emissions. These gasolines are a blend of conventional gasoline and another compound such as alcohol. This Triumph motorcycle will give its best performance when using unleaded gasoline. However, the following should be used as a guide if you use any oxygenated fuels.

Ethanol

Ethanol fuel is a mixture of 10% Ethanol and 90% gasoline and is often described under the names 'gasohol', 'Ethanol enhanced', or 'contains Ethanol'. This fuel may be used in your Triumph motorcycle.

MTBE (Methyl Tertiary Butyl Ether)

The use of gasolines containing up to 15% MTBE (Methyl Tertiary Butyl Ether) is permitted in this Triumph motorcycle.

Methanol

Caution

Fuels containing methanol should not be used as damage to components in the fuel system can be caused by contact with methanol.

Caution

Because of the generally higher volatility of oxygenated fuels, starting, engine response and fuel consumption may be adversely affected by their use. Should any of these difficulties be experienced, run the motorcycle on normal unleaded gasoline.

General Information

Refueling

Warning

To help reduce hazards associated with refueling, always observe the following fuel safety instructions:

Gasoline (fuel) is highly flammable and can be explosive under certain conditions. When refueling, turn the ignition switch to the OFF position.

Do not smoke.

Do not use a mobile telephone.


Make sure the refueling area is well ventilated and free from any source of flame or sparks. This includes any appliance with a pilot light.

Never fill the tank until the fuel level rises into the filler neck. Heat from sunlight or other sources may cause the fuel to expand and overflow creating a fire hazard.

After refueling always check that the fuel filler cap is correctly closed.

Because gasoline (fuel) is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above will lead to a fire hazard, which could cause damage to property, injury to persons or death.

Fuel Tank Cap



cbmm_2

1. Fuel tank cap
2. Key

To open the fuel tank cap:

- Lift up the flap covering the lock itself.
- Insert the key into the lock and turn the key clockwise.

To close and lock the cap:

- Push the cap down into place with the key inserted, until the lock clicks into place.
- Remove the key and close the key cover.

Caution

Closing the cap without the key inserted will damage the cap, tank and lock mechanism.

Filling the Fuel Tank

Warning

Overfilling the tank can lead to fuel spillage.

If fuel is spilled, thoroughly clean up the spillage immediately and dispose of the materials used safely.

Take care not to spill any fuel on the engine, exhaust pipes, tires or any other part of the motorcycle.

Because fuel is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above may lead to a fire hazard, which could cause damage to property and injury or death to persons.


Fuel spilled near to, or onto the tires will reduce the tires' ability to grip the road. This will result in a dangerous riding condition potentially causing loss of motorcycle control and an accident.

Caution

Avoid filling the tank in rainy or dusty conditions where airborne material can contaminate the fuel.

Contaminated fuel may cause damage to fuel system components.

Fill the fuel tank slowly to help prevent spillage. Do not fill the tank to a level above the bottom of the filler neck. This will make sure there is enough air space to allow for fuel expansion if the fuel inside the tank expands through absorption of heat from the engine or from direct sunlight.



1. **Fuel filler neck**
2. **Maximum fuel level**

After refueling always check that the fuel filler cap is correctly closed.

General Information

Windshield

Warning

Never attempt to clean the windshield while riding the motorcycle.

Removal of the rider's hands from the handlebars while riding the motorcycle will diminish the ability of the rider to maintain the control of the motorcycle.

Attempting to clean the windshield while riding the motorcycle may result in loss of motorcycle control and an accident.

For windshield cleaning information, see page 213.

Windshield Adjustment

Warning

Never place loose items of clothing, fingers, hands or any other part of the body near the windshield during adjustment.


Personal injury may result from trapping parts of the body or loose items of clothing between the windshield and the motorcycle bodywork.

The windshield is adjusted electronically.

Tiger 1200 XR Only

To adjust the windshield:

- The ignition must be on. Adjustment is possible with the motorcycle stationary or in motion.
- To access the windshield adjustment mode, from the home screen, press the SCROLL button until the windshield adjust display is highlighted.



1. Windshield adjustment mode

- Press the SELECT button to activate the windshield adjustment mode.
- Use the SCROLL button to adjust the windshield to the desired height.
- There is a short time-out period to allow for further adjustment to take place before the instruments automatically exit the windshield adjustment mode.
- Alternatively, press the SELECT button to exit the windshield adjustment mode.

All Models except Tiger 1200 XR

To adjust the windshield height:

- The ignition must be on. Adjustment is possible with the motorcycle stationary or in motion.
- The windshield height can only be adjusted from the information tray at the bottom of the display screen.
- Push the joystick left/right until the windshield adjust option is highlighted.



SCREEN ADJUST HEIGHT



Windshield Adjustment Mode

- Push the joystick up/down to adjust the windshield to the required height.
- Push the joystick left/right to access another tray item.

Handlebar Adjustment

Warning

It is recommended to have handlebar adjustments carried out by a trained technician of an authorized Triumph dealer.

Handlebar adjustments carried out by a technician who is not of an authorized Triumph dealer may affect the handling, stability or other aspects of the motorcycle's operation which may result in loss of motorcycle control and an accident.

Warning

Before starting work, make sure that the motorcycle is stabilized and adequately supported. This will help prevent injury to the operator or damage to the motorcycle.

Note:


- **This procedure assumes the handlebars are in the standard position, as delivered from the factory. If the handlebars have already been adjusted as described below, the bolt positions will be reversed.**

The handlebars are adjustable for reach by approximately 0.78 in (20 mm).

General Information


To adjust the handlebars:

- Loosen and remove the handlebar rear (0.31 in (8 mm) threaded) clamp bolts, and then the front (0.39 in (10 mm) threaded) clamp and riser bolts.



1. 0.39 in (10 mm) bolts
2. 0.31 in (8 mm) bolts

- Lift the handlebars out of the handlebar risers and support with the aid of an assistant.
- Rotate both risers through 180° and align the bolt holes.
- Reposition the handlebars to the risers.



1. Upper clamp, left hand
2. Clamp split line, front
3. Handlebar alignment mark

- Reinstall the upper clamps, and secure with the two 0.39 in (10 mm) threaded bolts in the rear bolt positions. Do not fully tighten the bolts at this stage.
- Rotate the handlebar so that the alignment marking on the handlebar aligns with the front left hand split line of the clamp riser.
- Tighten the 0.39 in (10 mm) bolts to **26 lbf ft (35 Nm)**.
- Reinstall the 0.31 in (8 mm) bolts to the front positions and tighten to **19 lbf ft (26 Nm)**.


Stands

Side Stand

Warning

The motorcycle is equipped with an interlock system to prevent it from being ridden with the side stand in the down position.

Never attempt to ride with the side stand down or interfere with the interlock mechanism as this will cause a dangerous riding condition leading to loss of motorcycle control and an accident.



chde 2

1. Side stand

The motorcycle is equipped with a side stand on which the motorcycle can be parked.

Before riding, always make sure that the side stand is fully up after first sitting on the motorcycle.

Note:


- **When using the side stand, always turn the handlebars fully to the left and leave the motorcycle in first gear.**

For instructions on safe parking, refer to the How to Ride the Motorcycle section.

Center Stand (if equipped)

Caution

Do not use body panels or the seat as a hand-hold when placing the motorcycle on the center stand as this will cause damage.



chdf 1

1. Center stand

To set the motorcycle on the center stand, step down firmly on the foot finder part of the stand, then lift the motorcycle up and to the rear using the rear rack as a handhold.

For instructions on safe parking, refer to the How to Ride the Motorcycle section.

General Information

Seats

Seat Care



To prevent damage to the seat or seat cover, care must be taken not to drop the seat.


Do not lean the seat against the motorcycle or any surface which may damage the seat or seat cover. Instead, place the seat, with the seat cover facing upwards, on a clean, flat surface which is covered with a soft cloth.

Do not place any item on the seat which may cause damage or staining to the seat cover.

For seat cleaning information, see page 212.

Passenger Seat

The seat lock is located on the rear fender, below the brake/tail light unit.




1. Seat lock

To remove the seat:

- Insert the ignition key into the seat lock and turn it counterclockwise while pressing down on the rear of the seat. This will release the seat from its lock and allow it to be slid rearwards.
- If equipped with heated seats, disconnect the heated seat's electrical connector for complete removal from the motorcycle.

To re-install the seat:

- Reconnect the heated seat's electrical connector (if equipped), engage the seat's two outer brackets under the loops on the subframe and the two inner brackets to brackets on the rider's seat.
- Gently push the seat forwards and press down at the rear to engage in the seat lock.



1. Passenger seat outer brackets
2. Subframe loops
3. Passenger seat inner brackets
4. Rider seat brackets

Warning

To prevent detachment of the seat during riding, after installation always grasp the seat and pull firmly upwards.

If the seat is not correctly secured, it will detach from the lock.

A loose or detached seat could cause loss of motorcycle control and an accident.


Rider's Seat

Warning

The rider's seat is only correctly retained and supported once the passenger seat is correctly mounted.

Never ride the motorcycle with the passenger seat detached or removed, as the front seat will not be secured and may move.

A loose or detached seat could cause loss of motorcycle control and an accident.



1. Rider's seat

To remove the rider's seat:

- Remove the passenger seat (see page 122).
- Grasp the rider's seat on either side, and slide it rearwards and upwards.
- If equipped with heated seats, disconnect the heated seat's electrical connector for complete removal from the motorcycle.

To re-install the seat:

- Reconnect the heated seat's electrical connector (if equipped).
- Engage the seat's front rail into the bracket at the rear of the fuel tank and lower the rear rail into the rear brackets.
- Push down firmly on the rear of the seat.
- Reinstall the passenger seat (see page 122).

Rider's Seat Height Adjustment

Warning

Always adjust both seat height adjusters.

Adjusting only one height adjuster may prevent correct installation of the seat.


Riding the motorcycle with an incorrectly mounted seat may cause loss of motorcycle control and an accident.

General Information

Warning

After adjusting the seat, operate the motorcycle in an area free from traffic to gain familiarity with the new seat position.

Riding the motorcycle with the seat in an unfamiliar position may cause loss of motorcycle control and an accident.



chd1_2

1. Rider's seat
2. Front height adjuster
3. Rear height adjuster
4. Low seat height position (front shown)
5. High seat height position (front shown)


The rider's seat is adjustable for height by approximately 0.78 in (20 mm).

To adjust the rider's seat:

- Remove the rider's seat (see page 123).
- Reposition both seat height adjusters to the higher or lower position as required. Make sure that both adjuster rails are fully engaged in their brackets on the seat.
- Reinstall the rider's seat (see page 123).

Heated Seats (if equipped)

The heated seats switches (if equipped) are located on the left hand side of the motorcycle.




1. Rider's heated seat switch location
2. Passenger's heated seat switch location

The heated seats will only heat when the engine is running. When the heated seats are switched on, the heated seats symbol will appear in the display. The selected heat level for each seat will also be indicated by the color of the symbol.

There are two levels of heat: low and high.



1. Low heat symbol (amber)
2. High heat symbol (red)



1. Rider's heated seat (low heat selected)
2. Passenger's heated seat (high heat selected)

Rider Heated Seat

- For maximum benefit in cold conditions, from the OFF position press the rider heated seat switch once for the high heat setting initially, and then reduce the heat level by pressing the rider heated seat switch again for the low heat setting when the seat has warmed up.
- To turn the rider heated seat off, press and release the rider heated seat switch until the heated seats symbol is no longer shown in the display.

Passenger Heated Seat

- For maximum benefit in cold conditions, switch the passenger heated seat switch to the high heat setting initially and then reduce the heat level by switching the passenger heated seat switch to the low heat setting when the passenger seat has warmed up.
- To turn the passenger heated seat off, move the switch to its central position. After a short delay, the passenger heated seat symbol will no longer be shown in the display.

Low Power Voltage Cut Off

If a low voltage is detected the heated seats switches will power off. The heated seats will not function again until the voltage rises to a safe level.

The switches will not power back on automatically even if the voltage rises to the safe level. The ignition must be switched off then on again to activate the heated seats.

General Information

Helmet Hook




Warning

Never ride the motorcycle with helmet(s) secured to the helmet hook.

Riding the motorcycle with helmet(s) secured to the helmet hook may cause the motorcycle to become unstable leading to loss of motorcycle control and an accident.

A helmet can be secured to the motorcycle using the helmet hook located on the left hand side of the motorcycle, beneath the rider's seat.



1. Helmet hook

To attach a helmet to the motorcycle:

- Remove the rider's seat (see page 123) and loop the helmet chin strap over the hook.
- To secure the helmet, reinstall the seat and lock into position (see page 123).


Tool Kit, Handbook and the Triumph Accessory D-Lock

The tool kit and handbook are located beneath the passenger seat.

Space is provided under the passenger seat to store a Triumph accessory D-lock (available from your Triumph dealer).

To secure the lock:

- Remove the passenger seat (see page 122).
- Release the straps and remove the handbook and tool kit.
- Position the U-section of the lock to the rear fender tray support features, making sure that the open end faces towards the front of the motorcycle.
- Position the lock body into the rear fender tray as shown below.



1. Lock U-section
2. Lock body
3. Straps



- Mount the tool kit and handbook above the D-lock and secure using the tool kit straps.
- Reinstall the passenger seat (see page 122).

Electrical Accessory Sockets



Caution

Do not leave electrical accessories connected to the front electrical accessory socket when the engine is not running as this will discharge the battery.



1. Front electrical accessory socket
2. Rear electrical accessory socket (if equipped)

All Models

An electrical accessory socket is provided on the motorcycle, located in front of the fuel tank.

The socket will provide a 12 Volt electrical supply and is permanently live. Fuse number seven protects the front electrical accessory socket circuit, refer to the label in the fuse box lid for fuse amperage.

All Models Except Tiger 1200 XR

An additional electrical accessory socket is provided, located on the left side, towards the rear of the motorcycle.

The additional electrical accessory socket is available for Tiger 1200 XR models as an accessory kit from your authorized Triumph dealer.

The socket will provide a 12 Volt electrical supply and is live when the engine is running.

The rear electrical accessory socket is protected by a chassis ECM, which will automatically cut power to the socket in the event of an overload.

Power can be restored to the rear electrical accessory socket by turning the ignition switch off then on again, provided that the socket is not still overloaded.

Note:

- To protect the battery from excessive discharge while using mounted electrical accessories, the combined total current which may be drawn through the electrical accessory sockets is five Amps.
- A plug, suitable for use with the accessory socket, is available from your authorized Triumph dealer.


General Information

Universal Serial Bus (USB) Socket

Warning

The USB socket is not waterproof unless the waterproof cap is installed. Do not connect electronic devices while it is raining.

Water in the USB socket could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.



1. USB socket

A Universal Serial Bus (USB) socket is provided, located under the passenger seat. The connector provides a 5 Volt, 2 Amp power supply which is suitable for charging electronic devices such as mobile phones, cameras and GPS devices.

To access the USB socket:

- Remove the passenger seat.
- Remove the cap from the USB socket.
- Connect your device using a suitable USB cable, then stow the device and USB cable in the space available under the passenger seat.

Caution

Make sure that all electronic devices and cables are safely secured under the seat when riding.

Make sure there is sufficient space surrounding any electronic devices for the seat to close without causing any damage to the electronic device or the motorcycle.

- Install the passenger seat, making sure that the device or USB cable is not trapped.
- Turn the ignition on and start the engine.

Caution


Do not leave the ignition switch in the ON position unless the engine is running as this will discharge the battery.

- When your device has finished charging, remove the passenger seat and disconnect the device.
- Reinstall the USB socket cap and reinstall the passenger seat.

Note:

- The USB socket is protected by a chassis ECM, which will automatically cut power to the socket in the event of an overload.
- Power can be restored to the USB socket by turning the ignition switch off then on again, provided that the socket is not still overloaded.

Expedition Aluminum Panniers (if equipped)



The Expedition Aluminum Panniers and mounting rails are available as an accessory option.

For more details on the Expedition Aluminum Panniers and all other luggage solutions available, contact your authorized Triumph dealer or visit www.triumph.co.uk.

Warning


Do not move or lift the motorcycle by using any part of the panniers, mounting rails or luggage system.

Damage to the motorcycle and/or personal injury may occur.

General Information


Note:

- The same procedure can be followed to remove and mount the left hand or the right hand panniers.
- The pannier lock barrel has two positions as shown.



1. Lock barrel
2. Lock position
3. Unlock position

To Remove Each Pannier:



1. Lock (left hand pannier shown)
2. Locking mechanism release lever

To unlock and remove the pannier from the pannier mountings:


- Turn the key to the UNLOCK position.
- While supporting the pannier, pull the locking mechanism release lever to detach the pannier from the upper mounting points.
- Lift the pannier free from the lower mounting points.

To Install Each Pannier

- Insert the key into the lock.
- Turn the key to the UNLOCK position.

Note:

- The left hand and right hand panniers must be mounted to the correct side of the motorcycle. When mounting the panniers, make sure that the lock barrels are facing towards the rear of the motorcycle.
- Position the pannier onto the lower pannier mounting points as shown below.




1. Lower pannier mounting point

- Position the pannier's locking mechanism onto the upper mounting points.
- Press the pannier inwards to engage the locking mechanism.

Note:

- An audible click can be heard when the pannier's upper mounting locking mechanism is engaged.
- Two status indicators are also provided on the top of the upper mounting point. The status indicators will change color from red to green when the locking mechanism is correctly engaged.
- If the status indicators remain red, the upper mounting locking mechanism is not correctly engaged.



1. Pannier
2. Upper mounting point
3. Locking mechanism
4. Status indicators


- Lock the pannier to the rail by turning the key to the LOCK position.
- Remove the key.

General Information

Warning

An incorrectly mounted pannier may detach while riding, resulting in a dangerous riding condition.

Before riding, always make sure that both panniers are mounted correctly. Make sure that the status indicators located on the top of the pannier's upper mounting points are green and that the lock barrel is turned to the LOCK position and the key removed.



1. Locking mechanism status indicators


2. Lock barrel

A pannier that detaches while riding may cause loss of motorcycle control and an accident.

Pannier Operation

To unlock and open the pannier:


- Insert the key and turn it to the UNLOCK position.
- Release the pannier lid latch. The lid can then be opened.



osb_2

1. Lock barrel - UNLOCK position
2. Pannier lid latch

- The lid can also be removed from the pannier. To remove the lid, detach the retaining straps as shown below.




osd_1

1. Retaining straps

- Press downwards on the quick release mechanism for the pannier lid hinge.
- Slide the lid down and to the rear

to release the pannier lid hinge. The lid can now be removed from the pannier.




1. Pannier lid hinge quick release mechanism

To install the pannier lid:

- Press downwards on the quick release mechanism and relocate the pannier lid hinge.
- Release the quick release mechanism, making sure that the hinge is correctly engaged.
- Attach the retaining straps to the pannier lid.

To close and lock the pannier:

- Close the lid and secure with the pannier lid latch.
- Turn the key to the LOCK position and remove it.



1. Lock barrel - LOCK position
2. Pannier lid latch

Warning

The maximum safe load for each pannier is stated on a label inside the pannier.

Never exceed this loading limit as this may cause the motorcycle to become unstable leading to loss of motorcycle control and an accident.

General Information

Warning

The Expedition Aluminum Panniers are designed to be mounted as a pair.

Never ride the motorcycle with only one pannier installed.

Riding the motorcycle with one pannier installed may cause the motorcycle to become unstable leading to loss of motorcycle control and an accident.

Warning

After mounting or removing the panniers, operate the motorcycle in a safe area free from traffic to gain familiarity with the new handling characteristics.

Operation when not familiar with the new characteristics of the motorcycle may result in loss of motorcycle control and an accident.

Warning

Incorrect loading may result in an unsafe riding condition leading to loss of motorcycle control and an accident.

Always make sure that any loads carried are evenly distributed on both sides of the motorcycle. Make sure that the load is correctly secured such that it will not move around while the motorcycle is in motion.

Evenly distribute the load within each pannier. Pack heavy items at the bottom and on the inboard side of the pannier.

Always check the load security regularly (though not while the motorcycle is in motion) and make sure that the load does not extend beyond the rear of the motorcycle. Never exceed the maximum vehicle loading weight of:

Tiger 1200 XR - 507 lb (230 kg)

Tiger 1200 XRx - 502 lb (228 kg)

Tiger 1200 XRx-LRH - 507 lb (230 kg)

Tiger 1200 XRT - 502 lb (228 kg)

Tiger 1200 XCx - 491 lb (223 kg)

Tiger 1200 XCA - 493 lb (224 kg).

This maximum loading weight is made up from the combined weight of the rider, passenger, any accessories installed and any load carried.

Warning

For models that have manually adjustable suspension, make sure that front and rear spring preload and damping settings are suitable for the loading condition of the motorcycle (see page 185).

Note the maximum permissible payload for the panniers is stated on a label inside the pannier.

Warning

This motorcycle must not be operated above the legal road speed limit except in authorized closed-course conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed-course racetracks. High-speed operation should only be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions.

High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

Never ride an accessory-equipped motorcycle, or a motorcycle carrying a payload of any kind, at speeds above 80 mph (130 km/h). In either/both of these conditions, speeds in excess of 80 mph (130 km/h) should not be attempted even where the legal speed limit permits this.

The presence of accessories and/or payload will cause changes in the stability and handling of the motorcycle.

Failure to allow for changes in motorcycle stability may lead to loss of motorcycle control and an accident.

When riding at high speed, always be aware that various motorcycle configuration and environmental factors can adversely affect the stability of your motorcycle. For example:

- Incorrectly balanced loads on both sides of the motorcycle.
- Incorrectly adjusted front and rear suspension settings.
- Incorrectly adjusted tire pressures.
- Excessively or unevenly worn tires.
- Side winds and turbulence from other vehicles.
- Loose clothing.

Remember that the 80 mph (130 km/h) absolute limit will reduce by the installation of non-approved accessories, incorrect loading, worn tires, overall motorcycle condition and poor road or weather conditions.

General Information

Breaking-In



Breaking-in is the name given to the process that occurs during the first hours of a new vehicle's operation.

In particular, internal friction in the engine will be higher when components are new. Later on, when continued operation of the engine has ensured that the components have 'bedded in', this internal friction will be greatly reduced.

A period of careful breaking-in will ensure lower exhaust emissions, and will optimize performance, fuel economy and longevity of the engine and other motorcycle components.

During the first 500 miles (800 km):

- Do not use full throttle;
- Avoid high engine speeds at all times;
- Avoid riding at one constant engine speed, whether fast or slow, for a long period of time;
- Avoid aggressive starts, stops, and rapid accelerations, except in an emergency;
- Do not ride at speeds greater than 3/4 of maximum speed.

From 500 to 1,000 miles (800 to 1,500 km):

- Engine speed can gradually be increased to the rev limit for short periods.

Both during and after breaking-in has been completed:

- Do not overrev the engine when cold;
- Do not lug the engine. Always downshift before the engine begins to 'struggle';
- Do not ride with engine speeds unnecessarily high. Shifting up a gear helps reduce fuel consumption, reduces noise and helps to protect the environment.

Daily Safety Checks



cboc

Warning

Failure to perform these checks every day before you ride may result in serious motorcycle damage or an accident causing serious injury or death.

Check the following items each day before you ride. The time required is minimal, and these checks will help make sure you have a safe, reliable ride.

If any irregularities are found during these checks, refer to the Maintenance and Adjustment section or see your authorized Triumph dealer for the action required to return the motorcycle to a safe operating condition.

Check:

Fuel: Adequate supply in tank, no fuel leaks (see page 115).

Engine Oil: Correct level visible at sight glass. Add correct specification oil as required. No leaks from the engine or oil cooler (see page 169).

Final Drive: No oil leaks (see page 176).

Tires/Wheels: Correct inflation pressures (when cold). Tread depth/wear, tire/wheel damage, punctures etc. (see page 188).

Nuts, Bolts, Fasteners: Visually check that steering and suspension components, axles, and all controls are properly tightened or fastened. Inspect all areas for loose/damaged fasteners.

Steering Action: Smooth but not loose from lock to lock. No binding of any of the control cables (see page 182).

Brakes: Pull the brake lever and push the brake pedal to check for correct resistance. Investigate any lever/pedal where the travel is excessive before meeting resistance, or if either control feels spongy in operation (see page 177).

ABS: Make sure that the ABS warning light does not remain illuminated at speeds above 6 mph (10 km/h) when moving off (see page 149).

General Information

Brake Pads: There should be more than 0.06 in (1.5 mm) of friction material remaining on all the pads (see page **177**).

Brake Fluid Levels: No brake and clutch fluid leakage. Brake fluid levels must be between the MAX and MIN marks on both reservoirs (see page **180**).

Front Forks: Smooth action. No leaks from fork seals (see page **183**).

Throttle: Throttle grip free play 0.08 - 0.12 in (2 - 3 mm). Make sure that the throttle grip returns to the idle position without sticking (see page **102**).

Clutch Fluid Level: No brake and clutch fluid leakage. The clutch fluid level must be between the MAX and MIN marks on the reservoir (see page **175**).

Coolant: No coolant leakage. Check the coolant level in the expansion tank (when the engine is cold) (see page **172**).

Electrical Equipment: All lights and the horn function correctly (see page **92** and page **91**).

Engine Stop: Stop switch turns the engine off (see page **140**).

Stands: Returns to the fully up position by spring tension. Return springs not weak or damaged (see page **121**).

HOW TO RIDE THE MOTORCYCLE


Table of Contents

Stopping the Engine.....	140
Stopping the Engine.....	141
Starting the Engine.....	142
Starting the Engine.....	144
Moving Off.....	145
Shifting Gears.....	145
Braking.....	146
Anti-Lock Braking System (ABS).....	149
Optimized Cornering ABS.....	150
ABS Warning Light.....	151
Hill Hold Control (if equipped).....	152
Activation.....	153
Deactivation.....	154
Hill Hold Unavailable Message.....	154
Parking.....	154
Considerations for High Speed Operation.....	156

How to Ride the Motorcycle

Stopping the Engine

Tiger 1200 XR Only



1. Neutral indicator light
2. OFF position
3. Ignition switch
4. Engine stop switch - STOP position

To stop the engine:

- Close the throttle completely.
- Select neutral.
- Turn the ignition switch off.
- Select first gear.
- Support the motorcycle on a firm, level surface with the side or center stand.
- Lock the steering.

Caution


The engine should normally be stopped by turning the ignition switch to the OFF position.

The engine stop switch is for emergency use only.

Do not leave the ignition switched on with the engine stopped. This will cause electrical damage.

Stopping the Engine

All Models except Tiger 1200 XR



1. Neutral indicator light
2. Engine stop switch - STOP position
3. Master ignition switch - OFF position (if equipped)

To stop the engine:

- Close the throttle completely.
- Select neutral.
- Place the engine stop switch in the STOP position.
- Turn the master ignition switch to the OFF position (if equipped).
- Select first gear.
- Support the motorcycle on a firm, level surface with the side or center stand.
- Lock the steering.


Caution

Do not leave the ignition switched on with the engine stopped. This will cause electrical damage.

How to Ride the Motorcycle

Starting the Engine

Tiger 1200 XR



1. Engine stop switch - RUN position
2. Starter button
3. Neutral indicator light
4. ON position
5. Ignition switch

To start the engine:

- Check that the engine stop switch is in the RUN position.
- Make sure that the transmission is in neutral.
- Turn the ignition switch on.

Note:

- When the ignition is switched on, the tachometer needle will quickly sweep from zero to maximum and then return to zero. The instrument warning lights will illuminate and will then go off (except those which normally remain on until the engine starts - see **Warning Lights** on page 59). It is not necessary to wait for the needle to return to zero before starting the engine.
- A transponder is installed within the key to turn off the engine immobilizer. Only have one of the ignition keys near the ignition switch. Having two ignition keys near the switch may interrupt the signal between the transponder and the engine immobilizer. In this situation the engine immobilizer will remain active until one of the ignition keys is removed.
- Pull the clutch lever fully into the handlebar.
- Leaving the throttle fully closed, push the starter button until the engine starts.

Warning

Never start the engine or run the engine in a confined area.

Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time.

Always operate your motorcycle in the open air or in an area with adequate ventilation.

Caution

Do not operate the starter continuously for more than five seconds as the starter motor will overheat and the battery will become discharged. Wait 15 seconds between each operation of the starter to allow for cooling and recovery of battery power.

Do not let the engine idle for long periods as this may lead to overheating which will cause damage to the engine.

Caution

If the low oil pressure warning light illuminates after starting the engine, stop the engine immediately and investigate the cause.

Running the engine with low oil pressure will cause severe engine damage.


The motorcycle is equipped with starter lockout switches. The switches prevent the electric starter from operating when the transmission is not in neutral with the side stand down.

If the side stand is extended while the engine is running, and the transmission is not in neutral then the engine will stop regardless of clutch position.

How to Ride the Motorcycle

Starting the Engine

All Models except Tiger 1200 XR



1. Master ignition switch (if equipped)
2. Engine start/stop switch - QUICK START position
3. Neutral indicator light

To start the engine:

- Make sure that the master ignition switch (if equipped) is turned to the ON position, see page 92.
- Pull the clutch lever fully into the handlebar.
- Press and hold the QUICK START position on the engine start/stop switch until the engine starts.
- Make sure that the transmission is in neutral.

The motorcycle is equipped with starter lockout switches. The switches prevent the electric starter from operating when the transmission is not in neutral with the side stand down.

If the side stand is extended while the engine is running, and the transmission is not in neutral then the engine will stop regardless of clutch position.

Warning

Never start the engine or run the engine in a confined area.

Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time.

Always operate your motorcycle in the open air or in an area with adequate ventilation.

Caution

If the low oil pressure warning light illuminates after starting the engine, stop the engine immediately and investigate the cause.

Running the engine with low oil pressure will cause severe engine damage.

Note:

- A transponder is installed within the key to turn off the engine immobilizer. Only have one of the ignition keys near the ignition switch. Having two ignition keys near the switch may interrupt the signal between the transponder and the engine immobilizer. In this situation the engine immobilizer will remain active until one of the ignition keys is removed.

Moving Off

Pull in the clutch lever and select first gear. Open the throttle a little and let out the clutch lever slowly. As the clutch starts to engage, open the throttle a little more, allowing enough engine speed to avoid stalling.

Shifting Gears

! Warning

Do not shift to a lower gear at speeds that will cause excessive engine rpm (r/min). This can lock the rear wheel causing loss of motorcycle control and an accident.


Engine damage may also be caused. Shifting down should be done such that low engine speeds will be ensured.

! Warning

With the traction control enabled, it will limit the amount of front wheel lift and rear wheel slip.

If the traction control is not functioning or disabled, avoid opening the throttle too far or too fast in any of the lower gears as this can lead to the front wheel lifting from the ground (pulling a wheelie) and to the rear tire breaking traction (wheel spin).

Always open the throttle cautiously, particularly if you are unfamiliar with the motorcycle, as a wheelie or loss of traction will cause loss of motorcycle control and an accident.




1. Gear shift pedal

How to Ride the Motorcycle

To shift gears:


- Close the throttle while pulling in the clutch lever.
- Shift into the next higher or lower gear.
- Open the throttle part way, while releasing the clutch lever. Always use the clutch when shifting gear.
- The gear shift mechanism is the positive stop type. This means that, for each movement of the gear shift pedal, you can only select each gear, one after the other, in ascending or descending order.

Braking



dex.1

1. Front brake lever



1. Rear brake pedal

All motorcycle models are equipped with a partially integrated braking system, combined with the Anti-lock Braking System (ABS).

The partially integrated braking system is designed to increase the braking efficiency of the rider.

When the rider applies the front brake, a small amount of rear brake is also applied, allowing for balanced braking.

The amount of rear brake application is related to the level of braking force applied by the rider through the front brake lever.

How to Ride the Motorcycle

Use of the rear brake pedal alone will only apply the rear brake.

For full brake effectiveness, always operate the front brake lever and rear brake pedal together.

Warning

WHEN BRAKING, OBSERVE THE FOLLOWING:

Close the throttle completely, leaving the clutch engaged to allow the engine to help slow down the motorcycle.

Shift down one gear at a time such that the transmission is in first gear when the motorcycle comes to a complete stop.

When stopping, always apply both brakes. Normally the front brake should be applied a little more than the rear.

Shift down or fully disengage the clutch as necessary to keep the engine from stalling.

If the ABS is not functioning or has been disabled, never lock the brakes, as this may cause loss of motorcycle control and an accident.

Warning

For emergency braking, disregard down shifting, and concentrate on applying the front and rear brakes as hard as possible without skidding. Riders should practice emergency braking in a traffic-free area (see ABS warnings below/over).

Warning Continued

Triumph strongly recommends that all riders take a course of instruction, which includes advice on safe brake operation. Incorrect brake technique could result in loss of control and an accident.

Warning

For your safety, always exercise extreme caution when braking (whether equipped with ABS or not), accelerating or turning as any improper action can cause loss of motorcycle control and an accident. Independent use of the front or rear brakes reduces overall braking performance. Extreme braking may cause either wheel to lock, reducing control of the motorcycle and causing an accident (see ABS warnings below).

When possible, reduce speed or brake before entering a turn as closing the throttle or braking in mid-turn may cause wheel slip leading to loss of motorcycle control and an accident.

When riding in wet or rainy conditions, or on loose surfaces, the ability to maneuver and stop will be reduced. All of your actions should be smooth under these conditions. Sudden acceleration, braking or turning may cause loss of motorcycle control and an accident.

For more information on optimized cornering ABS see page 150.

How to Ride the Motorcycle

Warning

When descending a long, steep gradient or mountain pass, make use of the engine's braking effect by down shifting and use both front and rear brakes intermittently.

Continuous brake application or use of the rear brake only can overheat the brakes and reduce their effectiveness leading to loss of motorcycle control and an accident.

Warning

Riding with your foot on the brake pedal or your hands on the brake lever may actuate the brake light, giving a false indication to other road users. It may also overheat the brake, reducing braking effectiveness leading to loss of motorcycle control and an accident.

Warning

Do not coast with the engine switched off, and do not tow the motorcycle. The transmission is pressure-lubricated only when the engine is running. Inadequate lubrication may cause damage or seizure of the transmission, which can lead to sudden loss of motorcycle control and an accident.

Warning

When using the motorcycle on loose, wet, or muddy roads, braking effectiveness will be reduced by dust, mud or moisture collecting on the brakes.

Always brake earlier in these conditions to ensure brake surfaces are cleaned by the braking action.

Riding the motorcycle with brakes contaminated with dust, mud or moisture may cause loss of motorcycle control and an accident.

Caution

Due to the nature of the partially integrated braking system, any attempts to spin the rear wheel while the front brake is applied (Burnout) will cause damage to the braking system and drivetrain.

Anti-Lock Braking System (ABS)

Warning

ABS helps prevent the wheels from locking, therefore maximizing the effectiveness of the braking system in emergencies and when riding on slippery surfaces. The potentially shorter braking distances ABS allows under certain conditions are not a substitute for good riding practice.

Always ride within the legal speed limit.

Never ride without due care and attention and always reduce speed in consideration of weather, road and traffic conditions.

Take care when cornering. If the brakes are applied in a corner, ABS will not be able to counteract the weight and momentum of the motorcycle. This can result in loss of motorcycle control and an accident.

Under some circumstances it is possible that a motorcycle equipped with ABS may require a longer stopping distance than an equivalent motorcycle without ABS.

Warning

If the ABS is not functioning or has been disabled (see Bike Setup on page **76** or Riding Mode Configuration on page **85**), the brake system will continue to function as a non-ABS braking system.

Do not continue to ride for longer than is necessary with the warning light illuminated. In the event of a fault, contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

In this situation, braking too hard will cause the wheels to lock resulting in loss of motorcycle control and an accident.

Note:

- **Normally, the rider will perceive ABS operation as a harder feel or a pulsation of the brake lever and pedal.**
- **The ABS may be activated by sudden upward or downward changes in the road surface.**

How to Ride the Motorcycle

Optimized Cornering ABS

Note:

- **All models except Tiger 1200 XR are equipped with the optimized cornering ABS.**

The optimized cornering ABS is a system designed to give the rider increased control should the ABS be activated while the motorcycle is leaning in a corner.

A sensor constantly monitors the lean angle of the motorcycle. If the motorcycle is leaning in a corner and the ABS is activated, the system will use the lean angle measurement to apply the ABS in a manner most suitable to help the rider maintain motorcycle control.

Warning

The optimized cornering ABS is a system designed to help the rider in emergency braking situations.

The system is designed to give the rider increased control should the ABS be activated while the motorcycle is leaning in a corner.

The potential increased control that the optimized cornering braking system allows under certain conditions is not a substitute for good riding practice.

Warning

Always ride within the legal speed limit.

Never ride without due care and attention and always reduce speed in consideration of weather, surface and traffic conditions.

Take care when cornering.

If the motorcycle is leaning in a corner and the ABS is activated, the optimized cornering ABS will use the lean angle measurement from a sensor to apply the ABS in a manner most suitable to help the rider maintain motorcycle control. The optimized cornering ABS will not however be able to fully counteract the weight and momentum of the motorcycle and braking too hard while cornering may result in loss of motorcycle control and an accident.

Under some circumstances it is possible that a motorcycle equipped with optimized cornering ABS may require a longer stopping distance than an equivalent motorcycle without ABS, or an equivalent motorcycle equipped with ABS but not equipped with optimized cornering ABS.

Warning

If the optimized cornering ABS is not functioning, the ABS warning light will illuminate and the message ABS SYSTEM - CORNERING ABS DISABLED will be displayed in the multifunction display.

In this situation, the ABS will continue to operate but without the optimized cornering function, provided that:

- There are no other ABS faults
- The ABS has not been disabled by the rider (see Bike Setup on page **76** or Riding Mode Configuration on page **85**).

Do not continue to ride for longer than is necessary with the warning light illuminated. In the event of a fault, contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

In this situation, braking too hard during cornering may result in loss of motorcycle control and an accident.

ABS Warning Light



When the ignition switch is turned to the ON position, it is normal for the ABS warning light to flash on and off.

If the ABS warning light is constantly illuminated it indicates that the ABS function is not available because:

- the ABS has been disabled by the rider (see Bike Setup on page **76** or Riding Mode Configuration on page **85**).
- the ABS has a malfunction that requires investigation.

If the ABS warning light becomes illuminated while riding, it indicates that the ABS has a malfunction that requires investigation. One of the following warning messages may be displayed in the multifunction display:

- WARNING - ABS SYSTEM DISABLED
- ABS SYSTEM - CORNERING ABS DISABLED (models equipped with optimized cornering ABS only).

For more information on the ABS warning light, see page **61**.

How to Ride the Motorcycle

Warning

The ABS warning light will illuminate after three minutes, if the rear wheel is driven while the motorcycle is on a stand.

If the motorcycle was ridden prior to being placed on a stand, this time will be reduced to one minute and the ABS warning light will be accompanied by the MIL.

This reaction is normal.

When the ignition is switched off and the motorcycle is restarted, the warning light(s) will remain illuminated until the motorcycle reaches a speed exceeding 6 mph (10 km/h).

Warning

The ABS computer operates by comparing the relative speed of the front and rear wheels.

Use of non-recommended tires can affect wheel speed and cause the ABS function not to operate, potentially leading to loss of motorcycle control and an accident in conditions where the ABS would normally function.

Hill Hold Control (if equipped)

Hill hold control assists the rider in making hill starts. The system (when activated) will apply the rear brake to hold the motorcycle in position. The system will then automatically deactivate and release the rear brake when it detects that the rider is attempting to move off.

Warning

Avoid activating the hill hold control system on slippery surfaces.

The hill hold control system will not be able to prevent the motorcycle from slipping, if it is activated on a surface where there is insufficient levels of tire grip to hold the motorcycle in position.

Activating the hill hold control system on a slippery surface could cause the motorcycle to slip, leading to loss of motorcycle control and an accident.

Warning

The hill hold control system will deactivate if the side stand is moved to the down position, the ignition is switched off, the engine stop switch is moved to the STOP position or if the engine is stopped for any other reason.

The hill hold control system will also deactivate if a fault occurs which causes the MIL to illuminate.

In these circumstances, the front brake must be manually applied to prevent the motorcycle from rolling.

Failure to prevent the motorcycle from rolling may lead to loss of motorcycle control and an accident.

Caution

The hill hold control system is not designed to be used as a parking brake.

Do not continually activate the hill hold system for periods of longer than 10 minutes.

Continuous activation of the hill hold control system for periods of longer than 10 minutes may cause damage to the ABS system.

Activation

Note:

- **The hill hold control system will not operate if there is a fault with the ABS or engine management systems and the ABS and/or MIL warning lights are illuminated.**

To activate the hill hold control system, bring the motorcycle to a stop.

For hill hold control to activate:

- The engine must be running
- The side stand must be in the up position
- The motorcycle must be stationary.

When all of the above conditions are met, squeeze the front brake lever firmly and quickly, then release. Upon releasing the lever, the message HILL HOLD ACTIVATED will appear in the multifunction display.

The hill hold control system is now active and the rear brake will be automatically applied.

The message HILL HOLD ACTIVATED will remain visible in the multifunction display until hill hold control is deactivated.

The rear brake will remain applied until:

- The system detects that the rider is attempting to move off.
- Hill hold control is manually deactivated by the rider.

How to Ride the Motorcycle

Deactivation

The hill hold control system will automatically deactivate when it detects that the rider is attempting to move off. The system will progressively release the rear brake to assist the rider in moving off.

The hill hold control system can also be manually deactivated by a second firm squeeze of the front brake lever.

The message HILL HOLD DEACTIVATED will be displayed briefly in the multifunction display.

Hill Hold Unavailable Message

If when attempting to activate the hill hold control system, the message HILL HOLD UNAVAILABLE - CHECK MANUAL is displayed, this indicates one or more of the following:

- The activation conditions described on page **153** have not been met.
- There is a fault with the ABS or engine management systems and the ABS and/or MIL warning lights are illuminated. See Warning Lights on page **59**.

The hill hold control system can be enabled or disabled (see Bike Setup on page **47**).

Parking

Warning

Gasoline is extremely flammable and can be explosive under certain conditions. If parking inside a garage or other structure, be sure it is well ventilated and the motorcycle is not close to any source of flame or sparks. This includes any appliance with a pilot light.

Failure to follow the above advice may cause a fire resulting in damage to property or personal injury.

Warning


The engine and exhaust system will be hot after riding. DO NOT park where pedestrians and children are likely to touch the motorcycle.

Touching any part of the engine or exhaust system when hot may cause unprotected skin to become burnt.

How to Ride the Motorcycle

Warning

Do not park on a soft or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over causing damage to property and personal injury.



Select neutral and turn the ignition switch to the OFF position.

Lock the steering to help prevent theft.

Always park on a firm, level surface to prevent the motorcycle from falling. This is particularly important when parking off-road.

When parking on a hill, always park facing uphill to prevent the motorcycle from rolling off the stand. Engage first gear to prevent the motorcycle from moving.

On a lateral (sideways) incline, always park such that the incline naturally pushes the motorcycle towards the side stand.

Do not park on a lateral (sideways) incline of greater than 6° and never park facing downhill.

Note:

- When parking near traffic at night, or when parking in a location where parking lights are required by law, leave the tail, license plate and position lights on by turning the ignition switch to P (PARK) on Tiger 1200 XR models.

For Tiger 1200 XR models, do not leave the switch in the P position for long periods of time as this will discharge the battery.

How to Ride the Motorcycle

Considerations for High Speed Operation

Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road traveled.

Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases.

Always reduce speed in consideration of weather and traffic conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed-course racetracks.

High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high-speed riding and are familiar with the motorcycle's characteristics in all conditions.

High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

The handling characteristics of a motorcycle at high speed may vary from those you are familiar with at legal road speeds.

Do not attempt high speed operation unless you have received sufficient training and have the required skills as a serious accident may result from incorrect operation.

Warning

The listed items below are extremely important and must never be neglected. A problem, which may not be noticed at normal operating speeds, may be greatly exaggerated at high speeds.

General

Make sure that the motorcycle has been maintained according to the scheduled maintenance chart.

Steering

Check that the handlebar turns smoothly without excessive free play or tight spots. Make sure that the control cables do not restrict the steering in any way.

Luggage

Make sure that any luggage containers are closed, locked and securely installed on the motorcycle.

How to Ride the Motorcycle

Brakes

Check that the front and rear brakes are functioning properly.

Tires

High speed operation is hard on tires, and tires that are in good condition are crucial to riding safely. Examine their overall condition, inflate to the correct pressure (when the tires are cold), and check the wheel balance. Securely install the valve caps after checking tire pressures. Observe the information given in the Maintenance and Specification sections on tire checking and tire safety.

Fuel

Have sufficient fuel for the increased fuel consumption that will result from high-speed operation.



Caution

The exhaust system is equipped with a catalytic converter to help reduce exhaust emission levels.

The catalytic converter can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low.

Always make sure that you have adequate fuel for your journey.

Engine Oil

Make sure that the engine oil level is correct. Make sure that the correct grade and type of oil is used when topping off.

Final Drive Oil

Make sure that the final drive oil level is correct. Make sure that the correct grade and type of oil is used when topping off.

Coolant

Check that the coolant level is at the upper level line in the expansion tank. (Always check the level with the engine cold.)

Electrical Equipment

Make sure that the headlight, rear/brake light, turn signals, horn, etc. all work properly.

Miscellaneous

Visually check that all fasteners are tight.

ACCESSORIES, LOADING AND PASSENGERS

The addition of accessories and carrying additional weight can affect the motorcycle's handling characteristics causing changes in stability and necessitating a reduction in speed. The following information has been prepared as a guide to the potential hazards of adding accessories to a motorcycle and carrying passengers and additional loads.

Warning

This motorcycle must not be operated above the legal road speed limit except in authorized closed-course conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course, on-road competition or on closed-course racetracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions.

High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

Do not move or lift the motorcycle by using any part of the luggage system or any accessories.

Damage to the motorcycle and/or personal injury may occur.

Accessories

Warning

Do not install accessories or carry luggage that impairs the control of the motorcycle.

Make sure that you have not adversely affected the visibility of any lighting component, road clearance, banking capability (i.e. lean angle), control operation, wheel travel, front fork movement, visibility in any direction, or any other aspect of the motorcycle's operation.

Accessories, Loading and Passengers

Warning

Never ride an accessory-equipped motorcycle, or a motorcycle carrying a payload of any kind, at speeds above 80 mph (130 km/h). In either/both of these conditions, speeds in excess of 80 mph (130 km/h) should not be attempted even where the legal speed limit permits this.

The presence of accessories and/or payload will cause changes in the stability and handling of the motorcycle.

Failure to allow for changes in motorcycle stability may lead to loss of motorcycle control and an accident.

When riding at high speed, always be aware that various motorcycle configuration and environmental factors can adversely affect the stability of your motorcycle. For example:

- Incorrectly balanced loads on both sides of the motorcycle.
- Incorrectly adjusted front and rear suspension settings.
- Incorrectly adjusted tire pressures.
- Excessively or unevenly worn tires.
- Side winds and turbulence from other vehicles.
- Loose clothing.

Remember that the 80 mph (130 km/h) absolute limit will reduce by the installation of non-approved accessories, incorrect loading, worn tires, overall motorcycle condition and poor road or weather conditions.

Warning

Owners should be aware that the only approved parts, accessories and conversions for any Triumph motorcycle are those which carry official Triumph approval and are installed to the motorcycle by an authorized dealer.

In particular, it is extremely hazardous to install or replace parts or accessories whose installation requires the dismantling of, or addition to, either the electrical or fuel systems and any such modification could cause a safety hazard.

The installation of any non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspect of the motorcycle operation that may result in an accident causing injury or death.

Triumph does not accept any liability whatsoever for defects caused by the installation of non-approved parts, accessories or conversions or the installation of any approved parts, accessories or conversions by non-approved personnel.

Loading

Warning

Incorrect loading may result in an unsafe riding condition leading to loss of motorcycle control and an accident.

Accessories, Loading and Passengers

Warning Continued

Always make sure that any loads carried are evenly distributed on both sides of the motorcycle. Make sure that the load is correctly secured such that it will not move around while the motorcycle is in motion.

Evenly distribute the load within each pannier. Pack heavy items at the bottom and on the inboard side of the pannier.

Always check the load security regularly (though not while the motorcycle is in motion) and make sure that the load does not extend beyond the rear of the motorcycle. Never exceed the maximum vehicle loading weight of:

Tiger 1200 XR - 507 lb (230 kg)

Tiger 1200 XRx - 502 lb (228 kg)

Tiger 1200 XRx-LRH - 507 lb (230 kg)

Tiger 1200 XRT - 502 lb (228 kg)

Tiger 1200 XCx - 491 lb (223 kg)

Tiger 1200 XCA - 493 lb (224 kg).

This maximum loading weight is made up from the combined weight of the rider, passenger, any accessories installed and any load carried.

For models that have manually adjustable suspension, make sure that front and rear spring preload and damping settings are suitable for the loading condition of the motorcycle (see page **185**).

Note the maximum permissible payload for the panniers is stated on a label inside the pannier.

Warning

The maximum safe load for each pannier is stated on a label inside the pannier.

Never exceed this loading limit as this may cause the motorcycle to become unstable leading to loss of motorcycle control and an accident.

Warning


The maximum safe load for the top box is stated on a label inside the top box.

Never exceed this loading limit as this may cause the motorcycle to become unstable leading to loss of motorcycle control and an accident.

Warning

Never attempt to store any items between the frame and the fuel tank. This can restrict the steering and will cause loss of motorcycle control leading to an accident.

Weight attached to the handlebar or front fork will increase the mass of the steering assembly and can result in loss of steering control leading to an accident.



Warning

If the passenger seat is used to carry small objects, they must not exceed 5 kg (11 lb) in weight, must not impair control of the motorcycle, must be securely attached and must not extend beyond the rear or sides of the motorcycle.

Carrying objects in excess of 5 kg (11 lb) in weight, that are insecure, impair control or extend beyond the rear or sides of the motorcycle may lead to loss of motorcycle control and an accident.

Even if small objects are correctly loaded onto the passenger seat, the maximum speed of the motorcycle must be reduced to 80 mph (130 km/h).

Note:

- **Adjust the headlight aim to compensate for additional loads (see page 203).**

Passengers

Warning

The handling and braking capabilities of a motorcycle will be affected by the presence of a passenger. The rider must make allowances for these changes when operating the motorcycle with a passenger and should not attempt such operation unless trained to do so and without becoming familiar and comfortable with the changes in motorcycle operating characteristics that this brings about.

Motorcycle operation without making allowances for the presence of a passenger could lead to loss of motorcycle control and an accident.

Warning

Do not carry a passenger unless they are tall enough to reach the footrests provided.

A passenger who is not tall enough to reach the footrests will be unable to sit securely on the motorcycle and may cause instability leading to loss of motorcycle control and an accident.

Accessories, Loading and Passengers

Warning

Your passenger should be instructed that they can cause loss of motorcycle control by making sudden movements or by adopting an incorrect seated position.

The rider should instruct the passenger as follows:

- It is important that the passenger sits still while the motorcycle is in motion and does not interfere with the operation of the motorcycle.
- To keep their feet on the passenger footrests and to firmly hold onto the grab handles or the rider's waist or hips.

Advise the passenger to lean with the rider when traveling around corners and not to lean unless the rider does so.

Warning

Do not carry animals on your motorcycle.

An animal could make sudden and unpredictable movements that could lead to loss of motorcycle control and an accident

Warning

The handling and braking capabilities of a motorcycle will be affected by the presence of a passenger. The rider must make allowances for these changes when operating the motorcycle with a passenger and should not attempt such operation unless trained to do so and without becoming familiar and comfortable with the changes in motorcycle operating characteristics that this brings about.

Motorcycle operation without making allowances for the presence of a passenger could lead to loss of motorcycle control and an accident.

MAINTENANCE

Table of Contents

Scheduled Maintenance	165
Scheduled Maintenance Table	167
Engine Oil	169
Engine Oil Level Inspection	169
Engine Oil and Oil Filter Change	170
Disposal of Used Engine Oil and Oil Filters	171
Oil Specification and Grade	172
Cooling System	172
Coolant Level Inspection	173
Coolant Level Adjustment	173
Coolant Change	174
Throttle Control	175
Clutch	175
Clutch Fluid Level Inspection and Adjustment	175
Final Drive Unit	176
Final Drive Oil Level Adjustment	176
Brakes	177
Brake Wear Inspection	177
Breaking-in New Brake Discs and Pads	178
Brake Pad Wear Compensation	178
Disc Brake Fluid	179
Front Brake Fluid Level Inspection and Adjustment	180
Rear Brake Fluid Inspection and Adjustment	181
Brake Light	181
Steering/Wheel Bearings	182
Steering Inspection	182
Steering (Steering Head) Bearings Inspection	182
Wheel Bearings Inspection	183
Front Suspension	183
Front Fork Inspection	183
Front Suspension Adjustment	184
Compression Damping Adjustment	184
Rebound Damping Adjustment	185
Front Suspension Setting Chart	185
Rear Suspension	186
Rear Suspension Adjustment	186

Maintenance

Spring Preload Adjustment.....	186
Rebound Damping Adjustment.....	187
Rear Suspension Setting Chart.....	187
Tires.....	188
Tire Inflation Pressures.....	189
Tire Wear.....	189
Minimum Recommended Tread Depth.....	190
Tire Replacement.....	190
Battery.....	193
Battery Removal.....	194
Battery Disposal.....	194
Battery Maintenance.....	195
Battery Discharge.....	195
Battery Discharge During Storage and Infrequent Use of the Motorcycle.....	195
Battery Charging.....	196
Battery Installation.....	197
Fuse Boxes.....	197
Main Fuse.....	197
ABS Fuse.....	198
Fuse Box.....	198
Fuse Identification.....	199
Chassis Electronic Control Module (Chassis ECM).....	200
Headlights.....	201
Daytime Running Light (DRL) (if equipped).....	202
Bend Lighting (if equipped).....	202
Headlight Adjustment.....	203
Bulb Replacement.....	205
Headlights.....	205
Front Fog Lights (if equipped).....	206
Brake/Tail Light/License Plate Light.....	206
Turn Signal Lights.....	206

Scheduled Maintenance

Warning

Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment carried out by the owner.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorized Triumph dealer carry out the scheduled maintenance of this motorcycle.

Warning

All maintenance is vitally important and must not be neglected. Incorrect maintenance or adjustment may cause one or more parts of the motorcycle to malfunction. A malfunctioning motorcycle may lead to loss of control and an accident.

Weather, terrain and geographical location affect maintenance. The maintenance schedule should be adjusted to match the particular environment in which the vehicle is used and the demands of the individual owner.

Special tools, knowledge and training are required in order to correctly carry out the maintenance items listed in the scheduled maintenance chart. Only an authorized Triumph dealer will have this knowledge and equipment.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorized Triumph dealer carry out the scheduled maintenance of this motorcycle.

Maintenance

To maintain the motorcycle in a safe and reliable condition, the maintenance and adjustments outlined in this section must be carried out as specified in the schedule of daily checks, and also in line with the scheduled maintenance chart. The information that follows describes the procedures to follow when carrying out the daily checks and some simple maintenance and adjustment items.

Scheduled maintenance may be carried out by your authorized Triumph dealer in three ways; annual maintenance, mileage based maintenance or a combination of both, depending on the mileage the motorcycle travels each year.

1. Motorcycles traveling less than 10,000 miles (16,000 km) per year must be maintained annually. In addition to this, mileage based items require maintenance at their specified intervals, as the motorcycle reaches this mileage.
2. Motorcycles traveling approximately 10,000 miles (16,000 km) per year must have the annual maintenance and the specified mileage based items carried out together.
3. Motorcycles traveling more than 10,000 miles (16,000 km) per year must have the mileage based items maintained as the motorcycle reaches the specified mileage. In addition to this, annual based items will require maintenance at their specified annual intervals.

In all cases maintenance must be carried out at or before the specified maintenance intervals shown. Consult an authorized Triumph dealer for advice on which maintenance schedule is most suitable for your motorcycle.

Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment.

Scheduled Maintenance Table

Operation Description	Odometer Reading in Miles (km) or Time Period, whichever comes first					
		First Service	Annual Service	Mileage Based Service		
	Every	500 (800) 1 Month	Year	10,000 and 30,000 (16,000 and 48,000)	20,000 (32,000)	40,000 (64,000)
Lubrication						
Engine - check for leaks	Day	*	*	*	*	*
Engine oil - replace	-	*	*	*	*	*
Engine oil filter - replace	-	*	*	*	*	*
Fuel System and Engine Management						
Autoscan - carry out a full Autoscan using the Triumph diagnostic tool (print a customer copy)	-	*	*	*	*	*
Fuel system - check for leaks, chafing etc.	Day	*	*	*	*	*
Air cleaner - replace	-			*	*	*
Throttle body plate (butterfly) - check/clean	-			*	*	*
Throttle bodies - balance	-			*	*	*
Secondary air injection system - check	-				*	*
Fuel hoses - replace	Every four years, regardless of mileage					
Evaporative loss hoses - replace	Every four years, regardless of mileage					
Ignition System						
Spark plugs - check	-			*		
Spark plugs - replace	-				*	*
Cooling System						
Cooling system - check for leaks	Day	*	*	*	*	*
Coolant level - check/adjust	Day	*	*	*	*	*
Cooling system - check coolant hoses for chafing, cracks or damage. Replace if necessary	-			*	*	*
Coolant - replace	Every 3 years, regardless of mileage					
Engine						
Clutch - check operation	Day	*	*	*	*	*
Clutch master cylinder - check for leaks	-	*	*	*	*	*
Clutch fluid levels - check	Day	*	*	*	*	*
Clutch fluid - replace	Every 2 years, regardless of mileage					
Valve clearances - check/adjust	-				*	*
Camshaft timing - check/adjust	-				*	*
Wheels and Tires						
Wheels - inspect for damage	Day	*	*	*	*	*
Wheel bearings - check for wear/smooth operation	-	*	*	*	*	*
Wheels - check wheels for broken or damaged spokes and check spoke tightness (models with spoked wheels only)	-	*	*	*	*	*
Tire wear/tire damage - check	Day	*	*	*	*	*
Tire pressures - check/adjust	Day	*	*	*	*	*

Maintenance

Steering and Suspension						
Steering – check for free operation	Day	*	*	*	*	*
Front and rear suspension - check for damage/leaks/smooth operation	Day	*	*	*	*	*
Fork oil – replace	-					*
Steering head bearings – check/adjust	-		*	*	*	*
Steering head bearings – lubricate	-				*	*
Rear suspension linkage – check/lubricate	-				*	*
Brakes						
Brake pads – check wear levels	Day	*	*	*	*	*
Brake master cylinders – check for fluid leaks	Day	*	*	*	*	*
Brake calipers – check for fluid leaks and seized pistons	Day	*	*	*	*	*
Brake fluid levels – check	Day	*	*	*	*	*
Brake fluid – replace	Every 2 years, regardless of mileage					
Final Drive						
Final drive – check for oil leaks	Day	*	*	*	*	*
Final drive oil level – check	-		*	*	*	*
Final drive oil – replace – only first service	-	*				
Electrical						
Lights, instruments and electrical systems – check	Day	*	*	*	*	*
General						
Instruments, chassis ECM and engine ECM - check for latest calibration download using the Triumph diagnostic tool	-	*	*	*	*	*
Bank angle indicators - check for wear	Day	*	*	*	*	*
Fasteners – inspect visually for security	Day	*	*	*	*	*
Accessory rack sliding carriage – check for correct operation†	-		*	*	*	*
Side stand – check for wear/smooth operation	Day	*	*	*	*	*
Side stand pivot pin - clean/grease	-			*	*	*
Center stand – check for wear/smooth operation	Day	*	*	*	*	*
Center stand flanged sleeves – check/clean/grease	-		*	*	*	*
Gear shift pedal - clean bushes	-		*	*	*	*

†Only if equipped.

Engine Oil



cbnz

! Warning

Motorcycle operation with insufficient, deteriorated, or contaminated engine oil will cause accelerated engine wear and may result in engine or transmission seizure.

Seizure of the engine or transmission may lead to sudden loss of motorcycle control and an accident.

In order for the engine, transmission, and clutch to function correctly, maintain the engine oil at the correct level, and change the oil and oil filter in accordance with scheduled maintenance requirements.

Engine Oil Level Inspection

! Warning

Never start the engine or run the engine in a confined area.


Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time.

Always operate your motorcycle in the open-air or in an area with adequate ventilation.

! Caution

Running the engine with insufficient engine oil will cause engine damage.

If the low oil pressure warning light remains on, stop the engine immediately and investigate the cause.



1. **Filler plug**
2. **Sight glass**
3. **Engine oil level (correct level shown)**
4. **Crankcase engine oil level lines**

To inspect the engine oil level:

- With the motorcycle upright and off the side stand, check to see if engine oil is visible in the sight glass at a point halfway between the upper (maximum) and lower (minimum) horizontal lines marked on the crankcase.
- If it is necessary to top off the engine oil level, remove the filler plug and add engine oil, a little at a time, until the level registered in the sight glass is correct. Reinstall and tighten the filler plug.

Note:

- An accurate indication of the level of oil in the engine is only shown when the engine is at normal operating temperature and the motorcycle is upright (not on the side/center stand).
- Start the engine and run at idle for approximately five minutes.
- Stop the engine, then wait for at least three minutes for the engine oil to settle.
- Note the engine oil level visible in the sight glass.
- When correct, engine oil should be visible in the sight glass at a point halfway between the upper (maximum) and lower (minimum) horizontal lines marked on the crankcase.
- If necessary, top off the engine oil level as described earlier.
- Once the correct level is reached, install and tighten the filler plug.

Engine Oil and Oil Filter Change


Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis.

In addition, used engine oil contains harmful contamination that can lead to skin cancer.

Always wear suitable protective clothing and avoid skin contact with used engine oil.

The engine oil and filter must be replaced in accordance with scheduled maintenance requirements.



chgy.1

1. Engine oil drain plug
2. Oil filter

To change the engine oil and oil filter:

- Warm up the engine thoroughly, and then stop the engine and secure the motorcycle in an upright position on level ground.
- Place an oil drain pan beneath the engine.
- Remove the engine oil plug.

Warning

The engine oil may be hot. Contact with hot oil may cause the skin to be scalded or burned.

Always wear suitable protective clothing, gloves and eye protection and avoid skin contact with the engine oil.

- Unscrew and remove the oil filter using Triumph service tool T3880313. Dispose of the old filter in an environmentally friendly way.
- Apply a thin smear of clean engine oil to the sealing ring of the new oil filter.
- Install the oil filter and tighten to **89 lbf in (10 Nm)**.
- After the engine oil has completely drained out, mount a new sealing washer to the engine oil drain plug.
- Install and tighten the engine oil drain plug to **18 lbf ft (25 Nm)**.
- Fill the engine with a 10W/40 or 10W/50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) and JASO MA, such as Castrol Power 1 Racing 4T 10W-40 (fully synthetic) engine oil, sold as Castrol Power RS Racing 4T 10W-40 (fully synthetic) in some countries.
- Start the engine and allow it to idle for a minimum of 30 seconds.

Caution

Raising the engine speed above idle before the engine oil reaches all parts of the engine can cause engine damage or seizure.

Only raise engine speed after running the engine for 30 seconds to allow the engine oil to circulate fully.

Caution

If the engine oil pressure is too low, the low oil pressure warning light will illuminate.

If this light stays on when the engine is running, stop the engine immediately and investigate the cause.

Running the engine with low oil pressure will cause engine damage.

- Make sure that the low oil pressure warning light remains off after starting and the message WARNING - OIL PRESSURE LOW is not visible in the instrument's display screen.
- Stop the engine and recheck the engine oil level. Adjust if necessary.

Disposal of Used Engine Oil and Oil Filters


To protect the environment, do not pour oil on the ground, down sewers or drains, or into groundwater sources. Do not place used oil filters in with general waste. If in doubt, contact your local authority.

Maintenance

Oil Specification and Grade

Triumph's high performance fuel injected engines are designed to use 10W/40 or 10W /50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) and JASO MA, such as Castrol Power 1 Racing 4T 10W-40 (fully synthetic) engine oil, sold as Castrol Power RS Racing 4T 10W-40 (fully synthetic) in some countries.

Refer to the chart below for the correct oil viscosity (10W/40 or 10W/50) to be used in your riding area.



Oil Viscosity Temperature Range

Do not add any chemical additives to the engine oil. The engine oil also lubricates the clutch and any additives could cause the clutch to slip.

Do not use mineral, vegetable, non-detergent oil, castor based oils or any oil not conforming to the required specification. The use of these oils may cause instant, severe engine damage.

Make sure that no foreign matter enters the crankcase during an engine oil change or top off.

Cooling System



To ensure efficient engine cooling, check the coolant level each day before riding the motorcycle, and top off the coolant if the level is low.

Note:

- A year round, Hybrid Organic Acid Technology (known as Hybrid OAT or HOAT) coolant is installed in the cooling system when the motorcycle leaves the factory. It is colored green, contains a 50% solution of ethylene glycol based antifreeze, and has a freezing point of -31°F (-35°C).

Corrosion Inhibitors

Warning

HD4X Hybrid OAT coolant contains corrosion inhibitors and antifreeze suitable for aluminum engines and radiators. Always use the coolant in accordance with the instructions of the manufacturer.

Coolant that contains anti-freeze and corrosion inhibitors contains toxic chemicals that are harmful to the human body. Never swallow antifreeze or any of the motorcycle coolant.

Note:

- **HD4X Hybrid OAT coolant, as supplied by Triumph, is premixed and does not need to be diluted prior to filling or topping off the cooling system.**


To protect the cooling system from corrosion, the use of corrosion inhibitor chemicals in the coolant is essential.

If coolant containing a corrosion inhibitor is not used, the cooling system will accumulate rust and scale in the water jacket and radiator. This will block the coolant passages, and considerably reduce the efficiency of the cooling system.

Coolant Level Inspection

Note:

- **The coolant level should be checked when the engine is cold (at room or ambient temperature).**



1. Expansion tank
2. MAX mark
3. MIN mark

To inspect the coolant level:

- Position the motorcycle on level ground and in an upright position (not on the center stand). The expansion tank can be viewed from the left hand side of the motorcycle.
- Check the coolant level in the expansion tank. The coolant level must be between the MAX and MIN marks. If the coolant is below the minimum level, the coolant level must be adjusted.


Coolant Level Adjustment

Warning

Do not remove the expansion tank cap when the engine is hot.

When the engine is hot, the coolant inside the radiator will be hot and also under pressure.

Contact with this hot, pressurized coolant will cause scalds and skin damage.



1. Expansion tank cap
2. Expansion tank

Maintenance

To adjust the coolant level:

- Allow the engine to cool.
- The expansion tank cap can be removed from the left hand side of the motorcycle.
- Remove the expansion tank cap from the expansion tank and add coolant mixture through the filler opening until the level reaches the MAX mark.
- Reinstall the expansion tank cap.

Note:

- **If the coolant level is being checked because the coolant has overheated, also check the level in the radiator and top off if necessary.**
- **In an emergency, distilled water can be added to the cooling system. However, the coolant must then be drained and replenished with HD4X Hybrid OAT coolant as soon as possible.**

Caution

If hard water is used in the cooling system, it will cause scale accumulation in the engine and radiator and considerably reduce the efficiency of the cooling system.

Reduced cooling system efficiency may cause the engine to overheat and suffer severe damage.

Coolant Change

It is recommended that the coolant is changed by an authorised Triumph dealer in accordance with scheduled maintenance requirements.

Radiator and Hoses

Warning

The fan operates automatically when the engine is running. Always keep hands and clothing away from the fan as contact with the rotating fan can cause injury.

Caution

Using high pressure water sprays, such as from a car wash facility or household pressure washer, can damage the radiator fins, cause leaks and impair the radiator's efficiency.

Do not obstruct or deflect airflow through the radiator by installing unauthorized accessories, either in front of the radiator or behind the cooling fan. Interference with the radiator airflow can cause overheating, potentially resulting in engine damage.

Check the radiator hoses for cracks or deterioration, and hose clips for tightness in accordance with scheduled maintenance requirements. Have your authorized Triumph dealer replace any defective items.

Check the radiator grille and fins for obstructions by insects, leaves or mud. Clean off any obstructions with a stream of low pressure water.

Throttle Control

Warning

Use of the motorcycle with a sticking or damaged throttle control will interfere with the throttle function resulting in loss of motorcycle control and an accident.

To avoid continued use of a sticking or damaged throttle control, always have it checked by your authorized Triumph dealer.

Inspection

Check that the throttle opens smoothly, without undue force and that it closes without sticking. Have your authorized Triumph dealer check the throttle system if a problem is detected or any doubt exists.

Check that there is 0.04 - 0.08 in (1 - 2 mm) of throttle grip free play when lightly turning the throttle grip back and forth.

If there is an incorrect amount of free play, Triumph recommends that you have your authorized Triumph dealer investigate.

Clutch

The motorcycle is equipped with a hydraulically operated clutch that does not require adjustment.

Clutch Fluid Level Inspection and Adjustment

Warning


Use only DOT 4 specification brake and clutch fluid as listed in the specification section of this handbook. The use of brake and clutch fluids other than those DOT 4 fluids listed in the specification section may reduce the efficiency of the clutch system leading to an accident.

Failure to change the brake and clutch fluid at the interval specified in the scheduled maintenance chart may reduce clutch efficiency resulting in an accident.

Inspect the level of brake and clutch fluid in the reservoir and change the fluid in accordance with the scheduled maintenance requirements. Use only DOT 4 fluid as recommended in the

Maintenance

specification section. The brake and clutch fluid must also be changed if it becomes, or is suspected of having become contaminated with moisture or any other contaminants.



1. Reservoir cover screws
2. Reservoir cover
3. Diaphragm seal
4. Upper level line
5. Lower level line

The brake and clutch fluid in the reservoir must be kept between the upper and lower level lines (reservoir held horizontal).

To adjust the brake and clutch fluid level:

- Release the reservoir cover screws, then remove the reservoir cover noting the position of the diaphragm seal.
- Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
- Reinstall the reservoir cover making sure that the diaphragm seal is correctly positioned between the reservoir cover and reservoir body.
- Tighten the reservoir cover screws to **13 lbf in (1.5 Nm)**.

Final Drive Unit

Other than checking the final drive oil level, the unit contains no user serviceable parts. If a fault occurs with the final drive unit, your Triumph dealer must replace the complete assembly.


Check the final drive unit for oil leaks in accordance with the scheduled maintenance chart.

Final Drive Oil Level Adjustment

Warning

Under no circumstances should the final drive unit be disassembled.

Failure to observe this warning could lead to a malfunction of the final drive unit causing lock-up of the rear wheel leading to loss of motorcycle control and an accident.




1. Filler level plug

To check the oil level in the final drive unit:

- Remove the filler level plug.
- Fill with 75W/90 fully synthetic hypoid oil that meets specification API Service Level GL5, such as Castrol SAF-XO fully synthetic hypoid oil, until the level of oil inside the unit is level with the bottom of the filler.
- Reinstall the plug and tighten to **18 lbf ft (25 Nm)**.

Brakes

Brake Wear Inspection



cbmz_2

1. Brake pads
2. Minimum thickness line

Brake pads must be inspected in accordance with scheduled requirements and replaced if worn to, or beyond the minimum service thickness.

If the lining thickness of any pad (front or rear brakes) is less than 0.06 in (1.5 mm), that is, if the pad has worn down to the bottom of the grooves, replace all the pads on the wheel.

Maintenance

Breaking-in New Brake Discs and Pads

Warning

Brake pads must always be replaced as a wheel set. At the front, where two calipers are installed on the same wheel, replace all the brake pads in both calipers.

Replacing individual pads will reduce braking efficiency and may cause an accident.

After replacement brake pads have been mounted, ride with extreme caution until the new pads have broken in.

Warning

Brake pad wear will be increased if the motorcycle is used frequently off-road. Always inspect the brake pads more frequently if the motorcycle is used off-road, and replace the brake pads before they become worn to, or beyond the minimum service thickness.

Riding with worn brake pads may reduce braking efficiency, leading to loss of motorcycle control and an accident.

Triumph recommend a period of careful breaking-in for new brake discs and pads that, if followed correctly, will optimize their performance and longevity.

The recommended distance for breaking-in new brake discs and pads is 200 miles (300 km).

During the breaking-in period, avoid extreme braking, ride with caution and allow for greater braking distances.

Brake Pad Wear Compensation

Warning

If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake lines and hoses or the brakes may be defective.

It is dangerous to operate the motorcycle under such conditions and your authorized Triumph dealer must rectify the fault before riding.

Riding with defective brakes may lead to loss of motorcycle control and an accident.

Disc and brake pad wear is automatically compensated for and has no effect on the brake lever or pedal action. There are no parts that require adjustment on the front and rear brakes.

Disc Brake Fluid

Warning

Brake fluid is hygroscopic which means it will absorb moisture from the air.

Any absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Because of this, always replace brake fluid in accordance with scheduled maintenance requirements.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one which has been previously opened.

Do not mix different brands or grades of brake fluid.

Check for fluid leakage around brake installed, seals and joints and also check the brake hoses for splits, deterioration and damage.

Always rectify any faults before riding.

Failure to observe and act upon any of these items may cause a dangerous riding condition leading to loss of control and an accident.

Warning

If the ABS is not functioning, the brake system will continue to function as a non-ABS equipped brake system. In this situation, braking too hard will cause the wheels to lock resulting in loss of control and an accident.

Reduce speed and do not continue to ride for longer than is necessary with the indicator light illuminated. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Inspect the level of brake fluid in both reservoirs and change the brake fluid in accordance with scheduled maintenance requirements. Use only DOT 4 fluid as recommended in the Specification section. The brake fluid must also be changed if it becomes, or is suspected of having become contaminated with moisture or any other contaminants.

Note:

- **A special tool is required to bleed the ABS braking system. Contact your authorized Triumph dealer when the brake fluid needs replacing or the hydraulic system requires maintenance.**


Maintenance

Front Brake Fluid Level Inspection and Adjustment

Warning

If there has been an appreciable drop in the level of the brake fluid in either brake fluid reservoir, consult your authorized Triumph dealer for advice before riding.

Riding with depleted brake fluid levels, or with a brake fluid leak is dangerous and will cause reduced brake performance potentially leading to loss of motorcycle control and an accident.



1. Upper level line
2. Lower level line

The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).

To inspect the front brake fluid level:

- Check the level of brake fluid visible in the window at the front of the reservoir body.

To adjust the front brake fluid level:


- Release the reservoir cover screws, then remove the reservoir cover noting the position of the diaphragm seal.
- Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
- Reinstall the reservoir cover making sure that the diaphragm seal is correctly positioned between the reservoir cover and reservoir body.
- Tighten the reservoir cover screws to **13 lbf in (1.5 Nm)**.

Rear Brake Fluid Inspection and Adjustment

Warning

If there has been an appreciable drop in the level of the brake fluid in either brake fluid reservoir, consult your authorized Triumph dealer for advice before riding.

Riding with depleted brake fluid levels, or with a brake fluid leak is dangerous and will cause reduced brake performance potentially leading to loss of motorcycle control and an accident.



1. Rear brake fluid reservoir
2. Upper level line
3. Lower level line

To inspect the rear brake fluid level:

- The reservoir is visible from the right hand side of the motorcycle, through a viewing window in the rider's heel guard.

To adjust the rear brake fluid level:

- Loosen the screws and remove the heel guard.
- Release the reservoir cover screws, then remove the reservoir cover and the diaphragm seal.
- Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.
- Reinstall the reservoir cover making sure that the diaphragm seal is correctly positioned between the reservoir cover and reservoir body.
- Tighten the reservoir cover screws to **13 lbf in (1.5 Nm)**.
- Reinstall the heel guard and tighten its screws to **62 lbf in (7 Nm)**.

Brake Light

Warning

Riding the motorcycle with defective brake lights is illegal and dangerous.

An accident causing injury to the rider and other road users may result from use of a motorcycle with defective brake lights.

The brake light is activated independently by either the front or rear brake. If, with the ignition in the ON position, the brake light does not work when the front brake lever is pulled or the rear brake pedal is pressed, have your authorized Triumph dealer investigate and rectify the fault.

Maintenance

Steering/Wheel Bearings

⚠ Caution

To prevent risk of injury from the motorcycle falling during the inspection, make sure that the motorcycle is stabilized and secured on a suitable support.

Do not exert extreme force against each wheel or rock each wheel vigorously as this may cause the motorcycle to become unstable and cause injury by falling from its support.

Make sure that the position of the support block will not cause damage to the sump.

Steering Inspection

Lubricate and inspect the condition of the steering (steering head) bearings in accordance with scheduled maintenance requirements.


Note:

- **Always inspect the wheel bearings at the same time as the steering bearings.**

Steering (Steering Head) Bearings Inspection

⚠ Warning

Riding the motorcycle with incorrectly adjusted or defective steering (steering head) bearings is dangerous and may cause loss of motorcycle control and an accident.



Inspecting the Steering for Free Play

To inspect the steering bearings:

- Position the motorcycle on level ground, in an upright position.
- Raise the front wheel above the ground and support the motorcycle.
- Standing at the front of the motorcycle, hold the lower end of the outer tube of the front forks as illustrated above and 'rock' with a front-to-rear motion.
- If any free play can be detected in the steering (headstock) bearings, ask your authorized Triumph dealer to inspect and rectify any faults before riding.
- Remove the support and place the motorcycle on the side stand.

Wheel Bearings Inspection

Warning

Operation with worn or damaged front or rear wheel bearings is dangerous and may cause impaired handling and instability leading to an accident.

If in doubt, have the motorcycle inspected by an authorized Triumph dealer before riding.

Note:

- **If the wheel bearings in the front or rear wheel allow play in the wheel hub, are noisy, or if the wheel does not turn smoothly, have your authorized Triumph dealer inspect the wheel bearings.**

The wheel bearings must be inspected at the intervals specified in the scheduled maintenance chart.

To inspect the wheel bearings:

- Position the motorcycle on level ground, in an upright position.
- Raise the front wheel above the ground and support the motorcycle.
- Standing at the side of the motorcycle, gently rock the top of the front wheel from side to side.
- If any free play can be detected, ask your authorized Triumph dealer to inspect and rectify any faults before riding.
- Reposition the lifting device and repeat the procedure for the rear wheel.
- Remove the support and place the motorcycle on the side stand.

Front Suspension

Front Fork Inspection

Warning

Riding the motorcycle with defective or damaged suspension is dangerous and may lead to loss of motorcycle control and an accident.

Warning

Never attempt to dismantle any part of the suspension units, as all units contain pressurized oil.

Skin and eye damage can result from contact with the pressurized oil.

Examine each fork for any sign of damage, scratching of the slider surface, or for oil leaks.

If any damage or leakage is found, consult an authorized Triumph dealer.

To check that the forks operate smoothly:

- Position the motorcycle on level ground.
- While holding the handlebars and applying the front brake, pump the forks up and down several times.
- If roughness or excessive stiffness is detected, consult your authorized Triumph dealer.

Maintenance

Front Suspension Adjustment

Warning

Make sure that the correct balance between front and rear suspension is maintained.

Suspension imbalance could significantly change handling characteristics leading to loss of motorcycle control and an accident.

Refer to the front and rear suspension setting charts for further information or consult your dealer.

All models except Tiger 1200 XR are equipped with Triumph Semi Active Suspension (TSAS).

For more information on TSAS settings and adjustment, see page **108**.


Tiger 1200 XR Model

The front forks on the Tiger 1200 XR model are adjustable for compression damping and rebound damping.

Note:

- The Tiger 1200 XR motorcycle is delivered from the factory with the front suspension set at the Solo (Normal) riding settings, as shown in the Front Suspension Setting Chart (see page 185).

Compression Damping Adjustment



1. Compression damping adjuster (white)
2. Fork top cap


The compression damping adjuster is located at the top of the left hand fork.

To change the compression damping force rotate the (white) adjuster clockwise to increase, or counterclockwise to decrease.

Note:

- The setting is measured as the number of adjuster clicks counterclockwise from the fully clockwise (closed) position.

Rebound Damping Adjustment



1. Rebound damping adjuster (red)
2. Fork top cap

The rebound damping adjuster is located at the top of the right hand fork. To change the rebound damping force, rotate the (red) adjuster clockwise to increase, or counterclockwise to decrease.

Note:

- The setting is measured as the number of adjuster clicks counterclockwise from the fully clockwise (closed) position.

Front Suspension Setting Chart

The Solo (Normal) suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The following chart shows suggested settings for the front suspension.

Loading	Compression Damping ¹ (left hand fork)	Rebound Damping ¹ (right hand fork)
Solo (Normal)	17	17
Solo (Comfort)	25	25
Solo (Sport)	4	4
Solo (Off-Road)	25	25
Solo (with Loaded Luggage Items)	13	13
Rider and Passenger	12	12
Rider and Passenger (with Loaded Luggage Items)	11	11

¹ Number of clicks counterclockwise from the fully clockwise (closed) position noting that the first stop (click) is counted as 1.

Note:

- This chart is only a guide. Setting requirements may vary for rider weight and personal preferences. See the following pages for information regarding suspension adjustment.

Maintenance

Rear Suspension

Rear Suspension Adjustment

Warning

Make sure that the correct balance between front and rear suspension is maintained.

Suspension imbalance could significantly change handling characteristics leading to loss of motorcycle control and an accident.

Refer to the front and rear suspension setting charts for further information or consult your dealer.

All models except Tiger 1200 XR are equipped with Triumph Semi Active Suspension (TSAS).

For more information on TSAS settings and adjustment, see page **108**.


Tiger 1200 XR Model

The Rear Suspension Unit (RSU) on the Tiger 1200 XR model is adjustable for spring preload and rebound damping.

Note:

- The Tiger 1200 XR motorcycle is delivered from the factory with the rear suspension set to the Solo (Normal) riding settings, as shown in the Rear Suspension Setting Chart (see page 187).

Spring Preload Adjustment



1. Spring preload adjuster


The spring preload adjuster is situated on the right hand side of the motorcycle, at the top of the rear suspension unit.

To adjust the spring preload setting rotate the 0.2 in (5 mm) hexagon adjuster clockwise to increase, or counterclockwise to decrease.

Note:

- The setting is measured as the number of adjuster turns counter-clockwise from the fully clockwise (closed) position.

Rebound Damping Adjustment



dim

1. Rebound damping adjuster

The rebound damping adjuster is located at the bottom of the rear suspension unit and is accessible from left hand side of the motorcycle.

To adjust the rebound damping setting, rotate the slotted adjuster clockwise to increase, and counterclockwise to decrease.

Note:

- The setting is measured as the number of adjuster clicks counterclockwise from the fully clockwise (closed) position.

Rear Suspension Setting Chart

The standard suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The following chart shows suggested settings for the rear suspension.

An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

The damping must be adjusted to the road conditions and the spring preload.

Loading	Spring Preload ¹	Rebound Damping ²
Solo (Normal)	17	8
Solo (Comfort)	17	12
Solo (Sport)	17	4
Solo (Off-Road)	17	4
Solo (With Loaded Luggage Items)	6	5
Rider and Passenger	0	4
Rider and Passenger (with Loaded Luggage Items)	0	3

¹ Number of turns counterclockwise from the fully clockwise (closed) position.

² Number of clicks counterclockwise from the fully clockwise (closed) position noting that the first stop (click) is counted as 1.

Note:

- This chart is only a guide. Setting requirements may vary for rider weight and personal preferences. See the following pages for information regarding suspension adjustment.

Maintenance

Tires




cboa

This model is equipped with tubeless tires, valves and wheel rims. Use only tires marked TUBELESS and tubeless valves on rims marked SUITABLE FOR TUBELESS TYRES.


Warning

Do not install tube-type tires on tubeless rims. The bead will not seat and the tires could slip on the rims, causing rapid tire deflation that may result in a loss of motorcycle control and an accident. Never install an inner tube inside a tubeless tire. This will cause friction inside the tire and the resulting heat build-up may cause the tube to burst resulting in rapid tire deflation, loss of motorcycle control and an accident.




che.1

Typical Tire Marking - Tubeless Tire



chez_2

Typical Tire Marking - Cast Wheel



Typical Tire Marking - Spoked Wheel

Tire Inflation Pressures

Warning

Incorrect tire inflation will cause abnormal tread wear and instability problems which may lead to loss of motorcycle control and an accident.

Underinflation may result in the tire slipping on, or coming off the rim. Overinflation will cause instability and accelerated tread wear.

Both conditions are dangerous as they may cause loss of motorcycle control and an accident.

Warning

Tire pressures which have been reduced for off-road riding will impair on-road stability. Always make sure that the tire pressures are set as described in the Specification section for on-road use.

Operation of the motorcycle with incorrect tire pressures may cause loss of motorcycle control and an accident.

Correct tire inflation pressures will provide maximum stability, rider comfort and tire life. Always check tire pressures before riding when the tires are cold. Check tire pressures daily and adjust if necessary (see Specification section for correct inflation pressures). Alternatively, ask your authorized Triumph dealer to inspect your wheels and tires.

Tire Pressure Monitoring System (TPMS) (if equipped)

The tire pressures shown on your instruments indicate the actual tire pressure at the time of selecting the display. This may differ from the inflation pressure set when the tires are cold because tires become warmer during riding, causing the air in the tire to expand and increase the inflation pressure. The cold inflation pressures specified by Triumph take account of this.

Owners must only adjust tire pressures when the tires are cold using an accurate pressure gage, and must not use the tire pressure display on the instruments.

Tire Wear

As the tire tread wears down, the tire becomes more susceptible to punctures and failure. It is estimated that 90% of all tire problems occur during the last 10% of tread life (90% worn). It is recommended that tires are changed before they are worn to their minimum tread depth.

Maintenance

Minimum Recommended Tread Depth

In accordance with the periodic maintenance chart, measure the depth of the tread with a depth gage, and replace any tire that has worn to, or beyond, the minimum allowable tread depth specified in the table below:

Under 80 mph (130 km/h)	0.08 in (2 mm)
Over 80 mph (130 km/h)	Rear 0.12 in (3 mm) Front 0.08 in (2 mm)

Warning

This motorcycle must not be operated above the legal road speed limit except in authorized closed-course conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course, on-road competition or on closed-course racetracks.

High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions.

High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

Operation with excessively worn tires is hazardous and will adversely affect traction, stability and handling which may lead to loss of motorcycle control and an accident.

When tires become punctured, leakage is often very slow. Always inspect tires very closely for punctures. Check the tires for cuts, embedded nails or other sharp objects. Operation with punctured or damaged tires will adversely affect stability and handling which may lead to loss of motorcycle control and an accident.

Check the rims for dents or deformation and spokes for looseness and damage. Operation with damaged or defective wheels, spokes or tires is dangerous and loss of motorcycle control and an accident could result.

Always consult your authorized Triumph dealer for tire replacement, or for a safety inspection of the wheels, spokes and tires.

Tire Replacement

All Triumph motorcycles are carefully and extensively tested in a range of riding conditions to ensure that the most effective tire combinations are approved for use on this model. It is essential that approved tires, mounted in approved combinations, are used when purchasing replacement tires. The use of non-approved tires, or approved tires in non-approved combinations,

may lead to motorcycle instability and an accident. On models equipped with ABS, different wheel speeds, caused by non-approved tires can affect the function of the ABS computer.

See the Specification section for details of approved tire combinations. Always have tires mounted and balanced by your authorized Triumph dealer who has the necessary training and skills to ensure safe, effective mounting.

Tire Pressure Monitoring System (TPMS) (if equipped)

Warning

Use of non-recommended tires can affect wheel speed and cause the Triumph traction control function not to operate, potentially leading to loss of motorcycle control and an accident in conditions where the Triumph traction control would normally function.

Warning

The ABS computer operates by comparing the relative speed of the front and rear wheels. Use of non-recommended tires can affect wheel speed and cause the ABS function not to operate, potentially leading to loss of motorcycle control and an accident in conditions where the ABS would normally function.

Warning

If a tire sustains a puncture, the tire must be replaced. Failure to replace a punctured tire, or operation with a repaired tire can lead to instability, loss of motorcycle control and an accident.

Warning

Do not install tube-type tires on tubeless rims. The bead will not seat and the tires could slip on the rims, causing rapid tire deflation that may result in a loss of vehicle control and an accident.

Never install an inner tube inside a tubeless tire.

This will cause friction inside the tire and the resulting heat build-up may cause the tube to burst resulting in rapid tire deflation, loss of motorcycle control and an accident.

Warning

If tire damage is suspected, such as after striking the curb, ask your authorized Triumph dealer to inspect the tire both internally and externally. Remember, tire damage may not always be visible from the outside.

Operation of the motorcycle with damaged tires could lead to loss of motorcycle control and an accident.

Warning

When replacement tires are required, consult your authorized Triumph dealer who will arrange for the tires to be selected, in a correct combination, from the approved list and mounted according to the tire manufacturer's instructions.

When tires are replaced, allow time for the tires to seat to the rim (approximately 24 hours). During this seating period, ride cautiously as an incorrectly seated tire could cause instability, loss of motorcycle control and an accident.

Initially, the new tires will not produce the same handling characteristics as the worn tires and the rider must allow adequate riding distance (approximately 100 miles) to become accustomed to the new handling characteristics.

24 hours after mounting, the tire pressures must be checked and adjusted, and the tires examined for correct seating. Rectification must be carried out as necessary.

The same checks and adjustments must also be carried out when 100 miles have been traveled after installation.

Use of a motorcycle with incorrectly seated tires, incorrectly adjusted tire pressures, or when not accustomed to its handling characteristics may lead to loss of motorcycle control and an accident.

Warning

Tires that have been used on a rolling road dynamometer may become damaged. In some cases, the damage may not be visible on the external surface of the tire.

Tires must be replaced after such use as continued use of a damaged tire may lead to instability, loss of motorcycle control and an accident.

Warning

Use of a motorcycle with incorrectly seated tires, incorrectly adjusted tire pressures, or when not accustomed to its handling characteristics may lead to loss of motorcycle control and an accident.

Warning

Accurate wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. Incorrect wheel balance may cause instability leading to loss of motorcycle control and an accident.

When wheel balancing is required, such as after tire replacement, see your authorized Triumph dealer.

Only use self-adhesive weights. Clip-on weights may damage the wheel and tire resulting in tire deflation, loss of motorcycle control and an accident.

Caution

An adhesive label is installed to the wheel rim to indicate the position of the tire pressure sensor. Care must be taken when replacing the tires to prevent any damage to the tire pressure sensors.

Always have your tires mounted by your authorized Triumph dealer and inform them that tire pressure sensors are installed on the wheels.

Caution

Do not use anti puncture fluid or any other item likely to obstruct air flow to the TPMS sensor's orifices. Any blockage to the air pressure orifice of the TPMS sensor during operation will cause the sensor to become blocked, causing irreparable damage to the TPMS sensor assembly.

Damage caused by the use of anti puncture fluid or incorrect maintenance is not considered a manufacturing defect and will not be covered under warranty.

Always have your tires mounted by your authorized Triumph dealer and inform them that tire pressure sensors are installed on the wheels.

Battery

Warning

Under some circumstances, the battery can give off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulfuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

If battery acid gets on your skin, flush with water immediately.

If battery acid gets in your eyes, flush with water for at least 15 minutes and SEEK MEDICAL ATTENTION IMMEDIATELY.

If battery acid is swallowed, drink large quantities of water and SEEK MEDICAL ATTENTION IMMEDIATELY.

KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN.

Warning

The battery contains harmful materials. Always keep children away from the battery whether or not it is installed in the motorcycle.

Do not attach jump leads to the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gases causing a risk of personal injury.

Maintenance


Battery Removal



Make sure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.


To remove the battery:

- Remove the rider's seat.
- Remove the wing nut and remove the chassis Electronic Control Module (ECM) cover.



1. Chassis ECM cover
2. Wing nut

- Remove the battery strap and the battery cover.
- Disconnect the battery leads, negative (black) lead first.



1. Negative (black) terminal
2. Positive (red) terminal
3. Battery strap
4. Battery
5. Battery cover

- Take the battery out of the case.

Battery Disposal

Should the battery ever require replacement, the original battery must be handed to a recycling agent who will make sure that the dangerous substances from which the battery is manufactured do not pollute the environment.

Battery Maintenance



Battery acid is corrosive and poisonous and will cause damage to unprotected skin. Never swallow battery acid or allow it to come into contact with the skin. To prevent injury, always wear eye and skin protection when handling the battery.

Clean the battery using a clean, dry cloth. Make sure that the cable connections are clean.

The battery is a sealed type and does not require any maintenance other than checking the voltage and routine recharging when required, such as during storage (see the following paragraphs).

It is not possible to adjust the battery acid level in the battery; the sealing strip must not be removed.

Battery Discharge



The charge level in the battery must be maintained to maximize battery life.

Failure to maintain the battery charge level could cause serious internal damage to the battery.

Under normal conditions, the motorcycle charging system will keep the battery fully charged. However, if the motorcycle is unused, the battery will gradually discharge due to a normal process called self discharge; the clock,

Engine Control Module (ECM) memory, high ambient temperatures, or the addition of electrical security systems or other electrical accessories will all increase this rate of battery discharge. Disconnecting the battery from the motorcycle during storage will reduce the rate of discharge.

Battery Discharge During Storage and Infrequent Use of the Motorcycle

During storage or infrequent use of the motorcycle, inspect the battery voltage weekly using a digital multimeter. Follow the manufacturer's instructions supplied with the meter.

Should the battery voltage fall below 12.7 Volts, the battery should be charged.

Allowing a battery to discharge or leaving it discharged for even a short period of time causes sulphation of the lead plates. Sulphation is a normal part of the chemical reaction inside the battery, however over time the sulphate can crystallize on the plates making recovery difficult or impossible. This permanent damage is not covered by the motorcycle warranty, as it is not due to a manufacturing defect.

Keeping the battery fully charged reduces the likelihood of it freezing in cold conditions. Allowing a battery to freeze will cause serious internal damage to the battery.

Maintenance

Battery Charging

Warning

The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space.

The battery contains sulfuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

If battery acid gets on your skin, flush with water immediately.

If battery acid gets in your eyes, flush with water for at least 15 minutes and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

If battery acid is swallowed, drink large quantities of water and **SEEK MEDICAL ATTENTION IMMEDIATELY.**

KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN.

Caution

Do not use an automotive quick charger as it may overcharge and damage the battery.

For help with selecting a battery charger, checking the battery voltage or battery charging, contact your local authorized Triumph dealer.

Should the battery voltage fall below 12.7 Volts, the battery should be charged using a Triumph approved battery charger. Always remove the battery from the motorcycle and follow the instructions supplied with the battery charger.

For extended periods of storage (beyond two weeks) the battery should be removed from the motorcycle and kept charged using a Triumph approved maintenance charger.

Similarly, should the battery charge fall to a level where it will not start the motorcycle, remove the battery from the motorcycle before charging.

Battery Installation

Warning

Make sure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.

To install the battery:

- Place the battery in the battery case.
- Reconnect the battery, positive (red) lead first.
- Apply a light coat of grease to the terminals to prevent corrosion.
- Cover the positive terminal with the protective cap.
- Re-install the battery strap.
- Reinstall the chassis ECM cover and secure with the wing nut. Tighten the wing nut to **11 lbf in (1.25 Nm)**.
- Reinstall the rider's seat.

Note:

- **After reconnecting the battery, it is necessary to allow the TSAS system (if equipped) to recalibrate, see page 108.**

Fuse Boxes

Warning


Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating.

Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

Main Fuse

The 40 Amp main fuse is located beneath the rider's seat and behind the seat bridge.

To access the main fuse, the rider's seat must be removed.




1. Main fuse

Maintenance

ABS Fuse


The 40 Amp ABS fuse is located beneath the rider's seat and behind the main fuse box.

To access the ABS fuse box, the rider's seat and chassis ECM cover must be removed.



1. ABS fuse box

Fuse Box



1. Fuse box

The fuse box that contains all other fuses is located beneath the rider's seat.

To access the fuse box, the rider's seat and chassis ECM cover must be removed.


Fuse Identification

A blown fuse is indicated when all of the systems protected by that fuse become inoperative. When checking for a blown fuse, use the tables to establish which fuse has blown.

The fuse identification numbers listed in the tables correspond with those printed on the fuse box cover, as shown below.

Spare fuses are located on the inside of the fuse box cover and should be replaced if used.

Tiger 1200 XR Only




Fuse Box and Cover

Position	Circuit Protected	Rating (Amps)
1	PS1	20
2	PS2	25
3	PS3	15
4	PS4	25
5	PS5	25
6	Ignition	5
7	Front Accessory Socket	10
8	Engine Management	20
9	Instruments	5

Note:

- Refer to the table on page 200 for details of the systems protected by fuses PS1 to PS5.

All Models except Tiger 1200 XR



Fuse Box and Cover

Position	Circuit Protected	Rating (Amps)
1	PS1	10
2	PS2	10
3	PS3	30
4	PS4	25
5	PS5	25
6	Headlights	10
7	Front Accessory Socket	10
8	Engine Management	20
9	Instruments and Electronic Steering Lock (ESL)	5

Note:

- Refer to the table on page 200 for details of the systems protected by fuses PS1 to PS5.

Maintenance

Chassis Electronic Control Module (Chassis ECM)

Warning

Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating.

Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

Many of the motorcycle's electrical systems (such as lighting, TSAS if equipped, horn, cooling fan, fuel pump, and accessories such as heated grips or seats) are controlled by a Chassis Electronic Control Module (Chassis ECM).

The chassis ECM provides a primary level of protection to the electrical systems it controls. If a fault is detected, the chassis ECM will automatically cut power to the affected system.

The chassis ECM can be reset by turning the Ignition off then on again. Power will be restored to the inoperative system, providing that the condition that caused the fault has been rectified.

The systems controlled by the chassis ECM are also provided with a secondary level of protection, by fuses PS1 to PS5 in the main fuse box (see page **199**). A blown fuse is likely when all of the systems protected by that fuse become inoperative.

Refer to the following table for full details of the chassis ECM controlled systems, and their corresponding fuses.

Electrical System	Fuse
Left headlight main beam (Tiger 1200 XR only)	PS1
Left headlight dipped beam (Tiger 1200 XR only)	
Left front turn signal	
Left rear turn signal	
Rear position light	
RSU position sensor (models with TSAS only)	
Right headlight main beam (Tiger 1200 XR only)	PS2
Right headlight dipped beam (Tiger 1200 XR only)	
Right front turn signal	
Right rear turn signal	
Front position light (Tiger 1200 XR only)	
Brake light	
Ignition (All models except Tiger 1200 XR)	

Electrical System	Fuse
Windshield adjustment motor	PS3
RSU preload adjustment motor (models with TSAS only)	
RSU damping solenoid (models with TSAS only)	
Front suspension compression damping adjustment motor (models with TSAS only)	
Front suspension rebound damping adjustment motor (models with TSAS only)	
Fog lights (if equipped)	
USB connector	
Heated seats (if equipped)	PS4
Heated grips (if equipped)	
Rear electrical accessory socket (if equipped)	
Top box electrical accessory socket (if equipped)	
Cooling fan	PS5
Fuel pump	
Starter solenoid	
Horn	

If after resetting the automatic software protection system or replacing a blown fuse, a fault still persists, contact an authorized Triumph dealer to have the fault checked and rectified.

Headlights



Warning

Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated.

Make sure that the beams are adjusted to illuminate the road surface sufficiently far ahead without blinding oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.

Warning

Never attempt to adjust a headlight beam when the motorcycle is in motion.

Any attempt to adjust a headlight beam when the motorcycle is in motion may result in loss of motorcycle control and an accident.

Caution

Do not cover the headlight or lens with any item likely to obstruct air flow to, or prevent heat escaping from, the headlight lens.

Covering the headlight lens during operation with items of clothing, luggage, adhesive tape, devices intended to alter or adjust the headlight beam or non genuine headlight lens covers will cause the headlight lens to overheat and distort, causing irreparable damage to the headlight assembly.

Damage caused by overheating is not considered a manufacturing defect and will not be covered under warranty.

If the headlight must be covered during use - such as taping of the headlight lens required during closed-course conditions - the headlight must be disconnected.

Daytime Running Light (DRL) (if equipped)

The Daytime Running Light (DRL) is situated within the headlight assembly and is a sealed, maintenance-free LED unit. The headlight unit must be replaced in the event of the failure of the DRL.

Bend Lighting (if equipped)

Bend lighting provides additional LED lighting for left and right turns when riding the motorcycle. It compensates for the bank angle of the motorcycle when cornering in dip beam mode.

The bend lights are switched on and off automatically as the motorcycle leans through corners. The left hand and right hand bend light comprises of four separate lights which switch on and increase in brightness depending on the lean angle of the motorcycle. When the motorcycle is stationary, no bend lights are on.

All Models except Tiger 1200 XR

Caution


If a fault occurs with the headlight unit, then a message will be shown in the instrument display and the headlights will only be available in the dipped beam mode.

Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

Headlight Adjustment

Tiger 1200 XR Only

The headlights can be adjusted by means of vertical and horizontal adjustment screws located on the rear of each headlight. In addition, the headlight unit is equipped with an easily accessible adjuster to allow the vertical adjustment to be corrected when the motorcycle is fully loaded.




1. Horizontal adjustment screw
2. Vertical adjustment screw
3. Headlight adjuster lever for loaded conditions

To adjust the headlight:

- Switch the headlight dipped beam on.
- Turn the vertical adjustment screw on the headlight clockwise to raise the beam or counterclockwise to lower the beam.
- Turn the horizontal adjustment screw clockwise to move the beam to the right or counterclockwise to move the beam to the left.
- Switch the headlights off when the beam settings are satisfactory.

Headlight Adjustment Lever for Loaded Conditions



1. Headlight adjuster lever (unloaded position)
2. Headlight adjuster lever (loaded position)


For normal (unloaded) conditions the headlight adjuster lever should be set in the horizontal position (1).

For loaded conditions rotate the headlight adjuster downwards until it stops (2). This will lower the headlight beams by approximately 2°.

Maintenance

All Models except Tiger 1200 XR

The headlight can be adjusted by means of a vertical adjustment screw located on the rear of the headlight unit. There is no horizontal adjustment. In addition, the headlight is equipped with an easily accessible adjuster to allow the vertical adjustment to be corrected when the motorcycle is fully loaded.



1. Headlight adjuster lever for loaded conditions
2. Vertical adjustment screw

To adjust the headlight:


- Switch the headlight dipped beam on.
- Turn the vertical adjustment screw on the headlight unit clockwise to raise the beam or counterclockwise to lower the beam.

Note:

- There is a small triangle marking on each side of the headlight unit which indicates the height of the light within the headlight unit for adjustment purposes.
- Switch the headlights off when the beam settings are satisfactory.

Headlight Adjustment for Loaded Conditions

The headlight unit is equipped with an adjuster lever to allow the vertical adjustment to be corrected when the motorcycle is fully loaded.



1. Headlight adjuster lever (loaded position)
2. Headlight adjuster lever (unloaded position)

For normal (unloaded) conditions, the headlight adjuster lever should be set in the horizontal position (2).

For loaded conditions, move the headlight adjuster lever until it is in position (1). This will lower the headlight beams by approximately 2°.

Bulb Replacement

⚠ Caution

The use of non-approved bulbs may result in damage to lenses and other lighting unit components.

In addition, the use of bulbs of incorrect wattage may cause the chassis ECM to cut power to affected lighting circuits.

Use genuine Triumph supplied bulbs as specified in the Triumph Parts Catalog.

Always have replacement bulbs installed by an authorized Triumph dealer.

Headlights

All Models except Tiger 1200 XR


The headlight unit is a sealed, maintenance-free LED unit.

Tiger 1200 XR Only

⚠ Warning

The bulbs become hot during use. Always allow sufficient time for the bulb to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before reuse.

The headlight unit does not need to be removed to replace a bulb.



1. Bulb retainer (right hand shown)
2. Bulb retainer hook
3. Bulb

To replace a bulb:

- Remove the rider's seat.
- Disconnect the battery, negative (black) lead first.
- Remove the bulb cover from the bulb to be replaced by rotating it counterclockwise.
- Disconnect the multiplug from the bulb.
- Detach the bulb retainer from the hook on the headlight assembly and rotate it away from the bulb as shown.
- Remove the bulb from the bulb retainer.

Installation is the reverse of the removal procedure.

Maintenance

Front Fog Lights (if equipped)

The fog light units are sealed, maintenance-free LED units.

Brake/Tail Light/License Plate Light

The brake/tail light unit is a sealed, maintenance-free LED unit. The license plate light is integral to the brake/tail light unit.


Turn Signal Lights

The motorcycle is equipped with either LED or bulb turn signal lights.

LED Turn Signal Lights

The turn signal light units are sealed, maintenance-free LED units.

Bulb Turn Signal Lights



celc_2

1. Indicator lens
2. Securing screw

The lens on each indicator light is held in place by a securing screw.

Loosen the screw and remove the lens to gain access to the bulb for replacement.

CLEANING AND STORAGE

Table of Contents

Preparation for Washing.....	208
Where to be Careful.....	208
Washing.....	209
After Washing.....	209
Care of Matt Paintwork.....	210
Care of Gloss Paintwork.....	210
Aluminum Items - not Lacquered or Painted.....	210
Cleaning of Chrome and Stainless Steel Items.....	211
Black Chrome.....	211
Cleaning of the Exhaust System.....	212
Seat Care.....	212
Windshield Cleaning (if equipped).....	213
Care of Leather Products.....	214
Preparation for Storage.....	215
Preparation after Storage.....	216

Cleaning and Storage

Preparation for Washing

Before washing, precautions must be taken to keep water off the following places.

Rear opening of the exhausts: Cover with a plastic bag secured with rubber bands.

Clutch and brake levers, switch housings on the handlebar: Cover with plastic bags.

Ignition switch and steering lock: Cover the keyhole with tape.

Remove any items of jewelry such as rings, watches, zips or belt buckles, which may scratch or otherwise damage painted or polished surfaces.

Use separate cleaning sponges or cleaning cloths for washing painted/polished surfaces and chassis areas. Chassis areas (such as wheels and under fenders) will be exposed to more abrasive road grime and dust, which may then scratch painted or polished surfaces, if the same sponge or cleaning cloths are used.

Where to be Careful

Caution

Do not spray any water at all near the air intake duct. The air intake duct is normally located under the rider's seat, under the fuel tank or near the steering head. Any water sprayed in this area could enter the airbox and engine, causing damage to both items.

Caution

Use of high pressure spray washers is not recommended. When using pressure washers, water may be forced into bearings and other components causing premature wear from corrosion and loss of lubrication.

Avoid spraying water with any great force near the following places:

- Instruments;
- Brake cylinders and brake calipers;
- Under the fuel tank;
- Air intake duct;
- Steering head bearings;
- Wheel bearings.

Note:

- **Use of soaps that are highly alkaline will leave a residue on painted surfaces, and may also cause water spotting. Always use a low alkaline soap to aid the cleaning process.**

Washing

Prepare a mixture of cold water and mild automotive cleaner. Do not use a highly alkaline soap as commonly found at commercial car washes because it leaves a residue.

Wash the motorcycle with a sponge or soft cloth. Do not use abrasive scouring pads or steel wool. They will damage the finish.

Rinse the motorcycle thoroughly with cold water.

After Washing

**Warning**

Never wax or lubricate the brake discs. Loss of braking power and an accident could result. Clean the disc with a proprietary brand of oil-free brake disc cleaner.

Remove the plastic bags and tape, and clear the air intakes.

Lubricate the pivots, bolts and nuts.

Test the brakes before motorcycle operation.

Use a dry cloth or chamois leather to absorb water residue. Do not allow water to stand on the motorcycle as this will lead to corrosion.

Start the engine and run it for 5 minutes. Make sure that there is adequate ventilation for the exhaust fumes.

Cleaning and Storage

Care of Matt Paintwork

Matt paintwork requires no greater care than that already recommended for high gloss paintwork.

- Do not use any polish or wax on matt paintwork.
- Do not try and polish out scratches.

Care of Gloss Paintwork

Gloss paintwork should be washed and dried as described above, then protected using a high quality automotive polish. Always follow the manufacturer's instructions and repeat regularly to maintain your motorcycle's appearance.

Aluminum Items - not Lacquered or Painted

Items such as brake and clutch levers, wheels, engine covers, engine cooling fins, upper and lower yokes and throttle bodies on some models must be correctly cleaned to preserve their appearance. Please contact your dealer if you are unsure which components on your motorcycle are aluminum parts not protected by paint or lacquer, and for guidance on how to clean those items.

Use a proprietary brand of aluminum cleaner which does not contain abrasive or caustic elements.

Clean aluminum items regularly, in particular after use in inclement weather, where the components must be hand washed and dried each time the machine is used.

Warranty claims due to inadequate maintenance will not be allowed.

Cleaning of Chrome and Stainless Steel Items

All chrome and stainless steel parts of your motorcycle must be cleaned regularly to avoid a deterioration of its appearance.

Washing

Wash as previously described.

Drying

Dry the chrome and stainless steel parts as far as possible with a soft cloth or chamois leather.

Protecting



The use of products containing silicone will cause discoloration of the chrome and stainless steel parts and must not be used. Similarly, the use of abrasive cleaners will damage the finish and must not be used.

When the chrome and stainless steel is dry, apply a suitable proprietary chrome cleaner on to the surface, following the manufacturer's instructions.

It is recommended that regular protection be applied to the motorcycle as this will both protect and enhance its appearance.

Black Chrome

Items such as headlight bowls and mirrors on some models must be correctly cleaned to preserve their appearance. Please contact your dealer if you are unsure which components on your motorcycle are black chrome parts. Maintain the appearance of black chrome items by rubbing a small amount of light oil into the surface.

Cleaning and Storage

Cleaning of the Exhaust System

All parts of the exhaust system of your motorcycle must be cleaned regularly to avoid a deterioration of its appearance. These instructions can be applied to chrome, brushed stainless steel and carbon fiber components; matt painted exhaust systems should be cleaned as above, noting the care instructions in the Matt Paintwork section previously.

Note:

- **The exhaust system must be cool before washing to prevent water spotting.**

Washing

Wash as previously described.

Make sure that no soap or water enters the exhausts.

Drying

Dry the exhaust system as far as possible with a soft cloth or chamois leather. Do not run the engine to dry the system or spotting will occur.

Protecting



The use of products containing silicone will cause discoloration of the chrome and must not be used. Similarly, the use of abrasive cleaners will damage the system and must not be used.

When the exhaust system is dry, apply a suitable proprietary motorcycle protection spray onto the surface, following the manufacturer's instructions.

It is recommended that regular protection be applied to the system as this will both protect and enhance the system's appearance.

Seat Care



Use of chemicals or high pressure spray washers is not recommended for cleaning the seat.

Using chemicals or high pressure spray washers may damage the seat cover.

To help maintain its appearance, clean the seat using a sponge or cleaning cloth with soap and water.

Windshield Cleaning (if equipped)



Warning

Never attempt to clean the windshield while the motorcycle is in motion as releasing the handlebars may cause loss of motorcycle control and an accident.

Operation of the motorcycle with a damaged or scratched windshield will reduce the rider's forward vision. Any such reduction in forward vision is dangerous and may lead to loss of motorcycle control and an accident.

Caution

Corrosive chemicals such as battery acid will damage the windshield. Never allow corrosive chemicals to contact the windshield.

Caution

Products such as window cleaning fluids, insect remover, rain repellent, scouring compounds, gasoline or strong solvents such as alcohol, acetone, carbon tetrachloride, etc. will damage the windshield.

Never allow these products to contact the windshield.

Clean the windshield with a solution of mild soap or detergent and cold water.

After cleaning, rinse well and then dry with a soft, lint-free cloth.

If the transparency of the windshield is reduced by scratches or oxidation which cannot be removed, the windshield must be replaced.

Cleaning and Storage

Care of Leather Products

We recommend that you periodically clean your leather products with a damp cloth and allow them to dry naturally at room temperature. This will maintain the appearance of the leather and ensure the long life of your product.

Your Triumph leather product is a natural product and lack of care can result in damage and permanent wear. Follow these simple instructions and give your leather product the respect it deserves:

- Do not use household cleaning products, bleach, detergents containing bleach or any kind of solvent to clean your leather product.
 - Do not immerse your leather product in water.
 - Avoid direct heat from fires and radiators which can dry out and distort the leather.
 - Do not leave your leather product in direct sunlight for prolonged periods of time.
 - Do not dry your leather product by applying direct heat to it at any time.
 - If your leather product does get wet, absorb any excess water with a soft clean cloth then leave the product to dry naturally at room temperature.
 - Avoid exposure of your leather product to high levels of salt, for example sea/salt water or road surfaces that have been treated during the winter for ice and snow.
- If exposure to salt is unavoidable, clean your leather product immediately after each exposure using a damp cloth then leave the product to dry naturally at room temperature.
 - Gently clean any minor marks with a damp cloth then leave the product to dry naturally at room temperature.
 - Place your leather product in a fabric bag or cardboard box to protect it when in storage. Do not use a plastic bag.

Preparation for Storage

Clean and dry the entire vehicle thoroughly.

Fill the fuel tank with the correct grade of unleaded fuel and add a fuel stabilizer (if available), following the fuel stabilizer manufacturer's instructions.



Warning

Gasoline is extremely flammable and can be explosive under certain conditions. Turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Remove the spark plug from each cylinder and put several drops 0.17 fl oz (5 ml) of engine oil into each cylinder. Cover the spark plug holes with a piece of cloth or rag. With the engine stop switch in the RUN position, push the starter button for a few seconds to coat the cylinder walls with oil. Install the spark plugs, tightening to **9 lbf ft (12 Nm)**. Change the engine oil and filter (see page **170**).

Check and if necessary correct the tire pressures.

Set the motorcycle on a stand so that both wheels are raised off the ground. (If this cannot be done, put boards under the front and rear wheels to keep dampness away from the tires.)

Spray rust inhibiting oil (there are a host of products on the market and your dealer will be able to offer you local advice) on all unpainted metal surfaces to prevent rusting. Prevent oil from getting on rubber parts, brake discs or in the brake calipers.

Make sure the cooling system is filled with a 50% mixture of coolant (noting that HD4X Hybrid OAT coolant, as supplied by Triumph, is premixed and requires no dilution) and distilled water solution (see page **172**).

Remove the battery, and store it where it will not be exposed to direct sunlight, moisture, or freezing temperatures. During storage it should be given a slow charge (one ampere or less) approximately once every two weeks (see page **193**).

Store the motorcycle in a cool, dry area, away from sunlight, and with a minimum daily temperature variation.

Put a suitable porous cover over the motorcycle to keep dust and dirt from collecting on it. Avoid using plastic or similar non-breathable, coated materials that restrict air flow and allow heat and moisture to accumulate.

Cleaning and Storage

Preparation after Storage

Install the battery (if removed) (see page **197**).

If the motorcycle has been stored for more than four months, change the engine oil (see page **170**).

Check all the points listed in the Daily Safety Checks section.

Before starting the engine, remove the spark plugs from each cylinder.

Put the side stand down.

Crank the engine on the starter motor several times until the oil pressure light goes out.

Reinstall the spark plugs, tightening to **9 lbf ft (12 Nm)**, and start the engine.

Check and if necessary correct the tire pressures.

Clean the entire vehicle thoroughly.

Check the brakes for correct operation.

Test ride the motorcycle at low speeds.

SPECIFICATIONS

Dimensions, Weights and Performance

A list of model specific dimensions, weights and performance figures is available from your authorized Triumph dealer, or on the Internet at www.triumph.co.uk.

Maximum Payload

Tiger 1200 XR	507 lb (230 kg)
Tiger 1200 XRx	502 lb (228 kg)
Tiger 1200 XRx-LRH	507 lb (230 kg)
Tiger 1200 XRT	502 lb (228 kg)
Tiger 1200 XCx	491 lb (223 kg)
Tiger 1200 XCA	493 lb (224 kg)

Engine

Type	In-line 3 cylinder
Displacement	74.1 cu in (1,215 cc)
Bore x Stroke	3.35 x 2.81 in (85 x 71.4 mm)
Compression Ratio	11:1
Cylinder Numbering	Left to Right
Cylinder Sequence Number	1 at left
Firing Order	1-2-3
Starting System	Electric Starter

Lubrication

Lubrication	Pressure Lubrication (wet sump)
Engine Oil Capacities	
Dry Fill	1.19 gallon (4.5 liters)
Oil/Filter Change	1.07 gallon (4.0 liters)
Oil Change Only	1.02 gallon (3.85 liters)

Cooling

Coolant Type	Triumph HD4X Hybrid OAT coolant
Water/Anti-freeze ratio	50/50 (premixed as supplied by Triumph)
Coolant Capacity	0.74 gallon (2.8 liters)
Thermostat Opens (nominal)	88°C (nominal)

Specifications

Fuel System

Type	Electronic Fuel Injection
Injectors	Solenoid Operated
Fuel Pump	Submerged Electric
Fuel Pressure (nominal)	50.8 lb/in ² (3.5 bar)

Fuel

Type	AKI octane rating (R+M)/2 of 87 unleaded
Tank Capacity	5.28 gallons (20.0 liters)

Ignition

Ignition System	Digital Inductive
Electronic Rev Limiter (r/min)	9,500 r/min
Spark Plug	NGK CR8EK
Spark Plug Gap	0.03 in (0.7 mm)
Gap Tolerance	+0.0015/-0.003 in (+0.05/-0.1 mm)

Transmission

Transmission Type	6 Speed, Constant Mesh
Clutch Type	Wet, Multi-Plate
Final Drive Ratio	2.557:1
Gear Ratios:	
Front Bevel Box	1.042:1 (24/25)
Rear Bevel Box	2.455:1 (11/27)
1 st	2.846:1 (13/37)
2 nd	2.056:1 (18/37)
3 rd	1.583:1 (24/38)
4 th	1.2916:1 (24/31)
5 th	1.138:1 (29/33)
6 th	1.037:1 (27/28)

Approved Tires

A list of approved tires specific to these models is available from your authorized Triumph dealer, or on the Internet at www.triumph.co.uk.

Warning

Use the recommended tires **ONLY** in the combinations given. Do not mix tires from different manufacturers or mix different specification tires from the same manufacturers as this may result in loss of motorcycle control and an accident.

Approved Mud and Snow/Dual Purpose Tires

A list of approved mud and snow/dual purpose tires specific to these models is available from your authorized Triumph dealer, or on the Internet at www.triumph.co.uk.

Warning

The use of mud and snow/dual purpose tires will result in reduced motorcycle stability.

Always operate a motorcycle equipped with mud and snow/dual purpose tires at reduced speeds. The permissible maximum speed is 60 mph (110 km/h). This is also shown on a warning sticker on the motorcycle.

Operation of the motorcycle above the permissible maximum speed may result in loss of motorcycle control and an accident.

Warning

Tire pressures which have been reduced for off-road riding will impair on-road stability. Always make sure that the tire pressures are set as described in the Specifications section for on-road use.

Operation of the motorcycle with incorrect tire pressures may cause loss of motorcycle control leading to an accident.

Specifications

Tires

Tire Pressures (Cold):

Front	32 lb/in ² (2.2 bar)
Rear	39 lb/in ² (2.7 bar)

Tire Sizes:

Front Size	120/70 R19
Rear Size	170/60 R17

Electrical Equipment

Battery Type	YTZ14S
Battery Rating	12 Volt, 11.2 Ah
Alternator	12 Volt, 70 Amp at 4,000 rpm
Headlight	2 x 12 Volt, 55/60 Watt, H4 Halogen (Tiger 1200 XR only)
	LED
Tail/Brake Light	LED
Parking Light	LED
Fog Lights (if equipped)	LED
Turn Signal Lights	RY10W, 12 Volt, 10 Watt, Amber LED (model specific)

Frame

Rake	23.1°
Trail	3.9 in (99.2 mm)

Tightening Torques

Oil Filter	89 lbf in (10 Nm)
Oil Drain Plug	18 lbf ft (25 Nm)
Spark Plug	9 lbf ft (12 Nm)
Rear Wheel Nuts	52 lbf ft (70 Nm)

Fluids and Lubrication

Engine Oil

Semi or fully synthetic 10W/40 or 10W/50 motorcycle engine oil which meets specification API SH (or higher) and JASO MA, such as Castrol Power 1 Racing 4T 10W-40 (fully synthetic)

Brake and Clutch Fluid

DOT 4 Brake and Clutch Fluid

Coolant

Triumph HD4X Hybrid OAT coolant

Bearings and Pivots

Grease to NLGI 2 specification

Final Drive Unit

Castrol SAF-XO (fully synthetic hypoid oil)

Index

INDEX

- A**
- Accessories..... 158
 - Anti-Lock Braking System (ABS)..... 149
 - ABS Warning Light..... 151
 - Optimized Cornering ABS..... 150
- B**
- Battery..... 193
 - Charging..... 196
 - Discharge..... 195
 - Disposal..... 194
 - Installation..... 197
 - Maintenance..... 195
 - Removal..... 194
 - Storage..... 195
 - Brake/Tail Light/License Plate Light..... 206
 - Brakes..... 177
 - Anti-Lock Braking System (ABS)..... 149
 - Brake and Clutch Lever Adjusters..... 103
 - Brake Light..... 181
 - Braking..... 146
 - Breaking-in New Brake Pads and Discs..... 178
 - Disc Brake Fluid..... 179
 - Front Brake Fluid Level Adjustment..... 180
 - Front Brake Fluid Level Inspection..... 180
 - Optimized Cornering ABS..... 150
 - Pad Wear Compensation..... 178
 - Rear Brake Fluid Level Adjustment..... 181
 - Rear Brake Fluid Level Inspection..... 181
 - Wear Inspection..... 177
 - Breaking-In..... 136
 - Bulb Replacement..... 205
- C**
- Chassis Electronic Control Module (Chassis ECM)..... 200
 - Cleaning
 - After Washing..... 209
 - Aluminum Items - not Lacquered or Painted..... 210
 - Black Chrome Items..... 211
 - Care of Leather Products..... 214
 - Chrome and Stainless Steel..... 211
 - Drying..... 212
 - Exhaust System..... 212
 - Gloss Paintwork..... 210
 - Matt Paintwork..... 210
 - Preparation for Washing..... 208
 - Protecting..... 212
 - Seat Care..... 212
 - Washing..... 209
 - Washing the Exhaust..... 212
 - Where to be Careful..... 208
 - Windshield..... 213
 - Clutch..... 175
 - Clutch Fluid Level Adjustment..... 175
 - Clutch Fluid Level Inspection..... 175
 - Considerations for High-Speed Operation..... 156
 - Cooling System..... 172
 - Coolant Change..... 174
 - Coolant Level Adjustment..... 174
 - Coolant Level Inspection..... 173
 - Corrosion Inhibitors..... 172
 - High Coolant Temperature Warning Light..... 60
 - Specifications..... 217
 - Cruise Control..... 105
 - Activating..... 105
 - Adjusting the Set Speed..... 106
 - Buttons..... 105
 - Cruise Control Adjust Button..... 97
 - Deactivating..... 106
 - Resuming the Set Speed..... 107
- E**
- Electrical Accessory Sockets..... 127
 - Electrical Equipment..... 220
 - Specifications..... 220
 - Engine
 - Moving Off..... 145
 - Serial Number..... 20
 - Specifications..... 217
 - Starting the Engine..... 142, 144
 - Stopping the Engine..... 140, 141

Engine Oil.....	169	Replacement.....	205
Disposal of Oil and Filters.....	171	Heated Seats	
Engine Oil Change.....	170	Rider's Heated Seat Switch.....	100
Oil Filter Change.....	170	Helmet Hook.....	126
Oil Level Inspection.....	169	Hill Hold Control.....	152
Specification and Grade.....	172	Activation.....	153
Engine Start/Stop Switch		Deactivation.....	154
QUICK START Position.....	95	Unavailable Message.....	154
RUN Position.....	95		
STOP Position.....	95	I	
F		Ignition	
Final Drive Unit.....	176	Engine Immobilizer.....	93
Oil Level Adjustment.....	177	Ignition Key.....	93
Fluids and Lubricants.....	221	Keyless.....	91
Fog Lights.....	206	Smart Key.....	91
Frame.....	220	Specifications.....	218
Front Suspension.....	183	Switch Positions.....	94
Compression Damping Adjustment.....	184	Switch/Steering Lock.....	93
Fork Inspection.....	183	Immobilizer	
Front Suspension Adjustment.....	184	Indicator Light.....	25, 60
Rebound Damping Adjustment.....	185	Instruments	
Settings Chart.....	185	Description.....	21
Fuel.....	115, 218	Information Messages.....	66
Filling the Fuel Tank.....	117	Motorcycle Status Display Screen.....	67
Fuel Grade.....	115	Multifunction Display Screen.....	71
Fuel Tank Cap.....	116	Speedometer.....	30
Refueling.....	116	Tachometer.....	31, 66
System Specifications.....	218	Warning Messages.....	65
Fuses.....	197	K	
ABS Fuse.....	198	Keyless Ignition.....	91
Main Fuse.....	197	L	
G		Left Handlebar Switches.....	97, 100
Gears		Fog Lights Switch (if equipped).....	99
Shifting Gears.....	146	Headlight Dimmer Switch.....	100
H		Heated Grips Switch.....	98
Hand Controls.....	91	High Beam Button.....	28, 99
Handlebar Adjustment.....	119	Horn Button.....	98, 101
Headlights.....	201	Instrument SCROLL Button.....	101
Adjustment.....	203, 204	Instrument SELECT Button.....	101
Bend Lighting.....	202	Joystick Button.....	98
Daytime Running Lights (DRL).....	202	MODE Button.....	98, 101
		Rider's Heated Seat Switch.....	100

Index

Turn Signal Switch	98, 101	Riding Modes	81
Loading	159	Riding Mode Configuration	85
Lubrication Specifications	217	Riding Mode Selection	82
Luggage Systems		Right Handlebar Switches	94, 96
Expedition Aluminum Panniers (if equipped)	129	Cruise Control Adjust Button	96
M		Daytime Running Light (DRL) Switch	29
Maintenance		Daytime Running Lights (DRL) Switch	97
Scheduled Maintenance	166	Engine Stop Switch	96
Scheduled Maintenance Table	167	Hazard Switch	28
Master Ignition Switch (if equipped)	92	Hazard Warning Lights	95, 96
Maximum Payloads	217	Starter Button	96
Motorcycle Status Display Screen		S	
Ambient Air Temperature	70	Safety	
Clock	70	Daily Checks	137
Coolant Temperature Gage	68	Fuel and Exhaust Fumes	8
Cruise Set Speed	69	Handlebars and Footrests	11
Fuel Gage	67	Helmet and Clothing	9
Gear Position Display	69	Maintenance and Equipment	13
Service Indicator	69	Motorcycle	7
Speedometer	67	Parking	12
Multifunction Display Screen		Parts and Accessories	12
Home Screen	71	Riding	9
Motorcycle Information	73	Seats	122
Riding Mode Display	72	Heated Seats (if equipped)	124
Trip Meter Reset	73	Passenger Seat	122
Trip Meters	73	Rider's Seat	123
Windshield Adjustment Mode	72	Rider's Seat Height Adjustment	124
P		Seat Care	122, 212
Parking	155	Settings Menu	74
Parts Identification		Bike Setup	76
Left Hand Side	16	Display Setup	79
Rider View	18, 19	Riding Modes	75
Right Hand Side	17	Show Warnings	75
Passengers	161	Trip Setup	75
R		Smart Key	91
Rear Suspension	186	Operation	91
Adjustment	186	Stands	121
Rebound Damping Adjustment	187	Center Stand	121
Setting Chart	187	Side Stand	121
Spring Preload Adjustment	186	Steering	
		Bearings Inspection	182
		Inspection	182

Wheel Bearings Inspection.....	183	Main Menu - Trip Setup - Automatic Reset	50
Steering Lock		Main Menu - Trip Setup - Manual Reset.....	49
Steering Lock Button.....	95	Main Menu Overview.....	42
Storage		Riding Mode Selection.....	34
Preparation after Storage.....	216	Riding Modes.....	33
Preparation for Storage.....	215	Service Interval Announcement.....	32
T		TFT Display Navigation.....	24
TFT Digital Display		TFT Themes and Styles.....	24
Ambient Air Temperature.....	32	Warning Lights.....	24
Fuel Gage.....	32	Throttle Control.....	102, 175
Gear Position Display.....	31	Brake Use.....	102
Information Tray - Coolant Temperature.....	41	Tire Pressure Monitoring System.....	111
Information Tray - Fuel Information.....	38	Low Tire Pressure.....	114
Information Tray - Odometer.....	39	Sensor Batteries.....	113
Information Tray - Overview.....	36	System Fault.....	113
Information Tray - Screen Contrast.....	41	Tire Pressure Warning Light.....	112
Information Tray - Service Interval Announcement.....	39	Tire Pressures.....	114
Information Tray - Style Options.....	41	Tires.....	4, 188
Information Tray - Tire Pressure Monitoring.....	39	Inflation Pressures.....	220
Information Tray - Trip Meter.....	38	Low Tire Pressure.....	114
Information Tray - Warning Review.....	37	Minimum Recommended Tread Depth.....	190
Instrument Panel Layout.....	23	Sizes.....	220
Instrument Panel Position Adjustment.....	56	Specifications.....	220
Main Menu - Bike Set Up - ABS.....	48	Tire Inflation Pressures.....	189
Main Menu - Bike Set Up - Service.....	48	Tire Pressures.....	114
Main Menu - Bike Set Up - Traction Control.....	48	Tire Replacement.....	190
Main Menu - Bike Set Up - Turn Signals.....	47	Tire Wear.....	189
Main Menu - Display Set Up - Brightness.....	52	Tool Kit.....	126
Main Menu - Display Set Up - Language.....	53	Torques	
Main Menu - Display Set Up - Set Clock.....	54	Tightening.....	220
Main Menu - Display Set Up - Set Date.....	54	Traction Control (TC).....	109
Main Menu - Display Set Up - Set Units.....	53	Disabled Warning Light.....	27
Main Menu - Display Set Up - Styles and Themes.....	51	Indicator Light.....	26
Main Menu - Display Set Up - Visible Tray.....	52	Optimized Cornering Traction Control.....	110
Main Menu - Reset to Defaults.....	55	Settings.....	111
Main Menu - Riding Mode Configuration.....	44	Transmission	
Main Menu - Riding Modes.....	43	Specifications.....	218
Main Menu - Trip 2 Enable/Disable.....	50	Triumph Semi Active Suspension (TSAS).....	40, 108
Main Menu - Trip Setup.....	49	Damping Settings.....	108
		Modes.....	108
		System Calibration.....	108
		Turn Signal Lights.....	206
		Replacement.....	206

Index

U

Universal Serial Bus (USB) Socket..... 128

V

Vehicle Identification Number..... 20

W

Warning Lights..... 59

Warnings..... 3

 Immobilizer and TPMS..... 4

 Maintenance..... 3

 Noise Control System..... 4

 Off-Road Use..... 4

 Owner's Handbook..... 5

 Warning Label Locations..... 14

 Warning Labels..... 3

 Warning Lights..... 25, 59

Windshield..... 118

 Height Adjustment..... 42, 118, 119