


Aud Mini Plus Manual

Black and white printing with Staple binding



iLuv®

Aud Mini Plus
IPX5 Water Resistant Portable
Stereo Bluetooth Speaker

User Manual



iLuv.com

CONTENTS

Warning and Safety Instructions	1
IPX5 Rated Water Resistance	3
What's included	4
Overview of Aud Mini Plus	5
Battery Charging	7
Power On	9
Bluetooth - Discovery	11
Bluetooth - Connect	
From Your iPhone, iPad, Smartphone, Tablet and Mobile Devices	13
From Your Apple Mac	14
From Window 10 Laptop/Computer	15
From Your Amazon Echo Dot	16
Connect to AUX-In for Non-Bluetooth Device or Window 7 or 8 Computer	19
Answer Calls Hands Free	21
Trouble Shooting	23
Customer Support	25

WARNING AND SAFETY INSTRUCTIONS

WARNING


Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAFETY AND PRECAUTIONS

- Read these instructions - All the safety and operation instruction should be read before this product is operated.
- Keep these instructions - The safety and operation instruction should be retained for future reference.
- Follow all instructions - All operating and use instructions should be followed.
- IPX5 rated Aud Mini Plus can resist water splash but must not merged inside water or left on wet place long time.
- Note, please close the rubber cover for water resistance. When charging or using the 3.5mm audio cable, please keep the speaker away from water as it can be damaged by water.
- Unplug the Micro USB charging cable during lightning storms.


IPX5 RATED WATER RESISTANCE

IPX5 rated water resistance allows you to use Aud Mini Plus for following occasions.




IPX5 rated Aud Mini Plus can resist water splash but must not be merged inside water or left on wet place long time.
Note: Please close the rubber cover for water resistance. When charging or using the 3.5mm audio cable, please keep the speaker away from water as it can be damaged by water.

WHAT'S INCLUDED




OVERVIEW OF AUD MINI PLUS

- | | |
|---|--|
| A Built-in Mic for Handsfree Call | F Charging LED Light (LED is visible when connected to a charging source) |
| B Bluetooth LED Light (LED is visible only when power is on) | G Power Button |
| C Bluetooth Button | H Rubber Cover |
| D Volume Down Button | I Aux-in Port |
| E Play/Pause Button | |



BATTERY CHARGING

ATTENTION VERY IMPORTANT! Charge completely before use



MUSIC PLAY TIME
Music playing time up to 12 hours which varies by volume level and music content.


POWER SAVING FEATURE
Aud Mini Plus automatically turns off the power 15 minutes after BT is disconnected
* When Aud Mini Plus is connected with Amazon Echo Dot, Echo Dot disables the power saving feature to constantly communicate with Aud Mini Plus even when Aud Mini Plus does not play music.

PLAY WHILE CHARGING
You can play music while Aud Mini Plus is in charging. You can continue to plug into a USB charger even when it is fully charged.


CHARGING LED LIGHT
Red charging LED light will flash when the battery charge is less than 15%, alerting you to charge. Red light will be on until fully charged. Once fully charged, the red LED light will be off.

POWER ON

TURN ON
Press and hold [⏻] button for 3 seconds. There will be a music tone, indicating power is on.




TURN OFF
Press and hold [⏻] button for 3 seconds. There will be a music tone, indicating power is off.



- CHARGING LED LIGHT - RED**
- Low Battery
 - Charging
 - Ready
- BLUETOOTH LIGHT - BLUE**
- Fast flashing blue Bluetooth Discovery Mode
 - Slow flashing blue Bluetooth Connected
 - Aux Mode

BLUETOOTH - DISCOVERY

- 1 Power on Aud Mini Plus
- 2 Press and hold [⏻] button for 3 seconds. There will be a music tone. Blue LED light will flash fast, indicating that Aud Mini Plus is discovering your mobile device.



* If blue LED light flashes slowly when you power on, Aud Mini Plus has automatically connected to the last mobile device that was connected before.

* If you want to pair with another device, press and hold [⏻] button for 3 seconds. There will be a music tone and current mobile device will be disconnected. The blue LED light will flash fast and Aud Mini Plus is ready to pair and connect to another device.

BLUETOOTH - CONNECT

FROM YOUR IPHONE, IPAD, SMARTPHONE, TABLET AND MOBILE DEVICES

- 1 Go to settings > Bluetooth
- 2 Turn on Bluetooth
- 3 Search and select "iLuv Aud Mini Plus"
- 4 It will connect in a few seconds
- 5 Blue LED light will flash slowly
- 6 Play music from your phone
- 7 Aud Mini Plus will stream music up to 33 ft from your mobile device

FROM YOUR APPLE MAC

- 1 Click "System Preferences"
- 2 Click "Bluetooth"
- 3 Click "Turn Bluetooth On"
- 4 Search "iLuv Aud Mini Plus" under "Devices"
- 5 Click "Pair" on the listing of "iLuv Aud Mini Plus"
- 6 It will connect in a few seconds
- 7 Blue LED light will flash slowly
- 8 Play music from your Mac

BLUETOOTH - CONNECT

FROM WINDOW 10 LAPTOP/COMPUTER

- 1 Click Action Center icon located on the bottom right
- 2 Click "Bluetooth" tile to turn on Bluetooth. "Bluetooth" tile will become blue. If you do not see "Bluetooth" tile in Action Center, click "Expand".
- 3 Click "Connect" tile.
- 4 Search "iLuv Aud Mini Plus"
- 5 It will connect in a few seconds
- 6 Blue LED light will flash slowly
- 7 Play music from your computer

FROM YOUR AMAZON ECHO DOT

To use the full Alexa service you must download Alexa app by Amazon on your iPhone, iPad, Smartphone, or Tablet.

- 1 Make sure any other Bluetooth device is not connected to Amazon Echo Dot
- 2 Open Alex App
- 3 Click Menu icon with 3 horizontal lines next to "Home" on the top left
- 4 Press "Settings"
- 5 Select your Amazon Echo Dot under "Devices"
- 6 Click "Bluetooth"
- 7 Click "Pair a New Device". Aud Mini Plus will appear in a few seconds.
- 8 Select Aud Mini Plus
- 9 It will connect in a few seconds. Alexa voice from Aud Mini Plus will say "Connected to Aud Mini Plus"
- 10 Music/Sound from the Amazon Echo Dot will be played through Aud Mini Plus

* If Aud Mini Plus becomes disconnected or turned off, turn on Aud Mini Plus and simply say "Alexa, connect my speaker" or "Alexa, pair".

BLUETOOTH - CONNECT

FROM YOUR AMAZON ECHO DOT

WARNING

Amazon Echo Dot disables the power saving feature on the Aud Mini Plus. Therefore, Aud Mini Plus won't automatically turn off power even after 15 minutes without playing music and will stay on. Since Echo Dot will continue to communicate with Aud Mini Plus even when not playing music, it will drain battery charge of Aud Mini Plus at the same rate of music playing with full volume.

SUGGESTION IF IT'S IN BATTERY MODE

OPTION 1 Please keep Aud Mini Plus connected to USB wall charger.
OPTION 2 Turn off Aud Mini Plus when you are not playing music.

- Turn off**
- Press [⏻] button for 3 seconds to turn off
 - Or, say "Alexa, disconnect my speaker". Aud Mini Plus will automatically turn off after 15 minutes without playing music.
- Turn on**
- 1. Press [⏻] button for 3 seconds to turn on Aud Mini Plus
 - 2. Say "Alexa, connect my speaker" or "Alexa, pair". Aud Mini Plus will be connected and play music from Echo Dot.

* For additional support regarding Alexa app, please contact amazon's support team through the app.
1. Open the Alexa app. 2. Select "Help Feedback". 3. Select "Email Customer Service"

CONNECT TO AUX-IN FOR NON-BLUETOOTH DEVICE OR WINDOW 7 OR 8 COMPUTER

- 1 Lift up rubber cover
- 2 Plug one end of 3.5mm Aux-in cable to Aux-in port
- 3 Plug the other end of the Aux-in cable to your non Bluetooth device or laptop/computer. Blue LED light will be on.




4 Play music from the connected device

* Bluetooth will be disabled when Aux-in cable is connected to Aux-in port. Please remove Aux-in cable from the speaker when you want to play music through Bluetooth.

* Aud Mini Plus is water resistant only when the cover is closed. So please keep it closed when not using 3.5mm Aux-in cable.

ANSWER CALLS HANDS FREE



- 1 Once your phone is connected to Bluetooth, speaker will ring when there is incoming call.
- 2 To Answer call, press [⏻] button and begin talking. You should be able to hear call through the speaker.

3 To reject the call, press and hold [⏻] button for 3 seconds.

4 To end call, press [⏻] button again. Music will resume automatically once call ends.

* Hands-free phone call feature works only with an iPhone or a Smartphone through Bluetooth.

* Please place Aud Mini Plus close to you when you talk so that your voice can be clearly heard by the other person since microphone is located on the top of Aud Mini Plus

TROUBLESHOOTING

AUD MINI PLUS DOES NOT TURN ON
Charge Aud Mini Plus at least 15 minutes and turn on the power. Charging LED light will show charging status.
Reset: press and hold Power button for 5 seconds to reset

NO AUDIO SOUND FROM AUD MINI PLUS VIA BLUETOOTH

- Turn off Aud Mini Plus and check Bluetooth device list on your phone. If Aud Mini Plus is listed, forget/unpair the device. Restart the phone. Turn on Aud Mini Plus and pair it again.
- Make sure the volume is up on the Aud Mini Plus and your mobile device
- Check if music from your mobile device is paused
- If your mobile device was out of Bluetooth range, move closer within 33 ft range of Aud Mini Plus
- Turn off Aud Mini Plus and back on
- Check if the music playing app is muted

NO SOUND FROM AUD MINI PLUS WHEN CONNECTED WITH THE 3.5MM AUX-IN CABLE
Please remove case from your mobile device if it prohibits Aux-in cable from being inserted fully

NO CONNECTION TO AMAZON ECHO DOT

- If Blue light flashes slowly which means it is connected to another device via Bluetooth, disconnect the currently paired audio source
- Check if Aud Mini Plus has enough power charge
- Set Aud Mini Plus to pairing mode and say "Alexa, connect my speaker" or "Alexa, pair"

CUSTOMER SUPPORT

If your question is not answered in the troubleshooting, please contact us by visiting: <http://support.iluv.com> or call customer service department at 1-866-807-5946.

LIMITED WARRANTY

WHAT IS COVERED?

Our limited warranty covers the Aud Mini Plus against defects in materials and workmanship under normal use and conditions. The warranty is limited to the original purchaser of the product and is non-transferable. The warranty does not cover damage caused by accident, misuse, abuse, neglect, or unauthorized repairs. The warranty is void if the product has been used for commercial purposes or if the product has been modified or altered in any way. The warranty is void if the product has been used in conjunction with any other product that is not manufactured by iLuv.

EXCLUSIONS

The warranty does not cover: (a) damage caused by accident, misuse, abuse, neglect, or unauthorized repairs; (b) damage caused by fire, flood, or other natural or man-made disasters; (c) damage caused by use of the product for commercial purposes; (d) damage caused by use of the product in conjunction with any other product that is not manufactured by iLuv; (e) damage caused by use of the product in conjunction with any other product that is not manufactured by iLuv.

OUTSTANDING SERVICE

Our customer service team is available to assist you with any questions or concerns you may have. We are committed to providing you with the best possible customer service experience. If you have any questions or concerns, please contact our customer service team at 1-866-807-5946.

RETURNING YOUR PRODUCT

The product may be returned for a full refund if it is found to be defective. The product must be returned within 30 days of purchase. The product must be in its original packaging and must be accompanied by the original receipt. The product must be returned to the retailer from whom it was purchased.

INSTRUCTIONS ON ENVIRONMENT

The product should be disposed of properly. Do not dispose of the product in a landfill. The product should be recycled if possible. The product should be disposed of in accordance with local, state, and federal regulations.

FCC NOTICE (USA)

This device complies with the FCC Rules, Part 15. This device may cause interference with other electronic equipment. If you experience interference, you may need to increase the distance between the device and the equipment. You may also need to reorient the device or the equipment.

iLuv Creative Technology
2 Harbor Park Drive
Port Washington, NY 11050

iLuv®
Designed by iLuv in New York