

1.1.6 Optional Socket




Fig. 10 Optional socket

The optional socket is not connected with the transmitter network and must be supplied by means of a separate power lead.

1.1.7 Grounding Bolt





Fig. 11 Grounding bolt

The grounding bolt connects the rack with the station's main grounding terminal.

Note The rack must be connected to the main grounding terminal in all cases.



1.2 Transmitter Control Unit



Fig. 12 Equipment of the transmitter control unit

- 1) NETCCU
- 2) Rack controller

The transmitter control unit contains the following components:

- NETCCU®
- Rack controller

They monitor and control the transmitter to ensure that it functions properly.

1.2.1 **NETCCU**



Fig. 13 NETCCU

The NETCCU[®] 800 transmitter control unit is responsible for both internal and external communication, including all control functions. The NETCCU[®] 800 shows the current status of the transmitter system on a color display.

Note For detailed information about the NETCCU[®], refer to the NETCCU[®] manual.

2099.9595.72 - 2.10 - E-2



1.2.2 Rack Controller



Fig. 14 Rack controller

The rack controller is used to monitor, control and protect the transmitter rack. It handles the following functions:

- O Keeps the transmitter running if the NETCCU[®] fails
- O Controls data exchange between the NETCCU® and other components via CAN bus
- O Monitors the outlet air temperature
- O Acquires measured data about the intake and outlet air temperatures
- O Transfers messages
- Accepts and outputs rack commands (e.g. transmitter ON -> amplifier ON, cooling system ON)
- O Configures the test points (mode-dependent)
- O Switches off the rack in the event of malfunction (e.g. fan failure)

The following equipment and modules can be connected to the rack controller:

- O NETCCU® via CAN-Bus
- O Exciter (1 or 2)
- External water pump (water-cooled transmitters)
- O Amplifier stages (1 or 2)
- Power distribution
- Temperature sensors
- Power test points

Note The rack controller cannot be operated directly. It is operated via the NETCCU[®].

2099.9595.72 - 2.11 - E-2