Model XT30/XT50 Wiring Diagram

Refer to the XT30/XT50 Installation Guide (LT-0980 1.14) for a complete description of wiring connections. Refer to the XT30/XT50 Programming Guide (LT-0981 1.12) for complete programming instructions.

USE MARKING

Commercial Central Station; Household Fire and Burglar Warning System Control Unit (DACT, PSDN: IP or Cellular)

Bell - 10.2 VDC - 13.9 VDC Total current: 1.5 Amps max.

AUX (RED) — Up to 500mA auxiliary current at 10.2 VDC - 13.9 VDC from Terminal 7.

NFPA 72

This equipment should be installed in accordance with Chapter 2 of the National Fire Alarm Code, ANSI/NFPA 72-2002, (National Fire Protection Association, Batterymarch Park, Ouincy, MA 02269). Printed information describing proper installation, operation, testing, maintenance, evacuation planning, and repair service is to be provided with this equipment. Warning: Owner's instruction notice, not to be removed by anyone except occupant.

POWER LIMITED

All circuits on the Model XT30/XT50 comply with the requirements for inherent power limitation and are Class 2.



LT-0984 1.10 © 2013 Digital Monitoring Products, Inc.