

meadap



OS/T BQ / EQ / IQ



© 2003 Nedap Retail Support -
Netherlands
Parallelweg 2d, 7141 DC Groenlo

The software / hardware described in this book / file is furnished under a license agreement and may be used only in accordance with the terms of the agreement.

Documentation version 1.0

Copyright Notice

All Rights Reserved.

Any technical documentation that is made available by Nedap Retail Support is the copyrighted work of Nedap Retail Support and is owned by Nedap Retail Support.

NO WARRANTY. The technical documentation is being delivered to you AS-IS and Nedap Retail Support makes no warranty as to its accuracy or use. Any use of the technical documentation or the information contained therein is at the risk of the user. Documentation may include technical or other inaccuracies or typographical errors. Nedap Retail Support the right to make changes without prior notice.

No part of this publication may be copied without the express written permission of Nedap Retail Support, Parallelweg 2d, 7141 DC Groenlo, Netherlands

Trademarks

Nedap, the Nedap logo, Nedap EASi/Net and the Nedap EASi/Net are registered trademarks of Nedap N.V. Groenlo. Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Printed in the Netherlands



Technical Support:

- E-mail: support-rs@nedap.nl
- H. Hammer
+31 (0) 544 47 15 19
h.hammer@nedap.nl
- H. Broekhuis
+31 (0) 544 47 15 02
h.broekhuis@nedap.nl
- Fax:
+31 (0) 544 46 58 14

Visitor's address:

Nedap Retail Support
Parallelweg 2d
Groenlo
Netherlands

Postal address:

Nedap Retail Support
Postbus 102
7140 AC Groenlo
Netherlands




Table of contents

Technical Support:	3
BQ PCB	5
EQ PCB	7
EQ3E PCB	9
IQ PCB	11
IQ3E PCB	13
Attenuation	15
IO Connector K23	16
IO Connector K24	16
System configurations	17
BQ System , 1 aisle, Deactivatorunit	18
EQ System , 3 aisles	19
IQ System , 7 aisles, MD CC	21
Checklist modem settings iNCC	20
Connecting a PC to a XQ or EQ/IQ Unit	28
Connecting a XQ or EQ/IQ unit to a modem	29
Connecting to an ISDN line using the DeTeWe TA33 terminal adapter	30



BQ PCB





The following points can be used:


K3	Oscilloscope Tx	K201	Handheld terminal RxTx
K5	Output Tx (connector 3)	K202	Oscilloscope Rx
K9	Jumper Attenuation	K203	Jumper
K11	Power Input	K204	Jumper
K12	Jumper Attenuation	K205	Handheld terminal NCC
K13	Jumper Attenuation	K300	Output Rx (connector 1)
K15	Jumper Attenuation	P1	PA Drive Adjustment
K16	RS232 Interface Connector	P2	Phase Adjustment Tx
K21	Connector FCI	P3	Mixer Bias Adjustment
K23	IO Connector	P4	Slave Data communication Rx
K24	IO Connector	P5	Master Data communication Rx

Indicator leds:

D11	Mux Connector 1 TX	D48	Customer Counting: Led on = active
D12	Mux Connector 2 TX	D202	Communication Error RxTx
D16	Lamp On Connector 3	D220	Label Detection Alarm NCC on = detection
D19	Lamp Overload Connector 3	D221	Communication Error NCC
D25	Sweep Lock	D300	Lamp Overload Connector 1
D26	Center Lock	D301	Lamp On Connector 1
D201	Label Alarm RxTx	D311	Mux Connector 1 RX
D47	Customer Counting: Led on = active	D202	Communication Error RxTx



EQ PCB





The following points can be used:


K3	Oscilloscope Tx	K201	Handheld terminal RxTx
K4	Output Tx (connector 4)	K202	Oscilloscope Rx
K5	Output Tx (connector 3)	K203	Jumper
K6	Synchronization In	K204	Jumper
K9	Jumper Attenuation	K205	Handheld terminal NCC
K10	Master connector	K300	Output Rx (connector 1)
K11	Power Input	K301	Output Rx (connector 2)
K12	Jumper Attenuation	P1	PA Drive Adjustment
K13	Jumper Attenuation	P2	Phase Adjustment Tx
K15	Jumper Attenuation	P3	Mixer Bias Adjustment
K16	RS232 Interface Connector	P4	Slave Data communication Rx
K21	Connector FCI	P5	Master Data communication Rx
K23	IO Connector		

Indicator leds:

D11	Mux Connector 1 TX	D202	Communication Error RxTx
D12	Mux Connector 2 TX	D220	Label Detection Alarm NCC on = detection
D16	Lamp On Connector 3	D221	Communication Error NCC
D17	Lamp On Connector 4	D300	Lamp Overload Connector 1
D18	Lamp Overload Connector 4	D301	Lamp On Connector 1
D19	Lamp Overload Connector 3	D302	Lamp Overload Connector 2
D25	Sweep Lock	D303	Lamp On Connector 2
D26	Center Lock	D311	Mux Connector 1 RX
D201	Label Alarm RxTx	D312	Mux Connector 2 RX



EQ3E PCB





The following points can be used:


K3	Oscilloscope Tx	K24	IO Connector
K4	Output Tx (connector 4)	K201	Handheld terminal RxTx
K5	Output Tx (connector 3)	K202	Oscilloscope Rx
K6	Synchronization In	K203	Jumper
K7	Synchronization In	K204	Jumper
K9	Jumper Attenuation	K300	Output Rx (connector 1)
K11	Power Input	K301	Output Rx (connector 2)
K12	Jumper Attenuation	P1	PA Drive Adjustment
K13	Jumper Attenuation	P2	Phase Adjustment Tx
K15	Jumper Attenuation	P3	Mixer Bias Adjustment
K21	Connector FCI		

Indicator leds:

D11	Mux Connector 1 TX	D202	Communication Error RxTx
D12	Mux Connector 2 TX	D300	Lamp Overload Connector 1
D16	Lamp On Connector 3	D301	Lamp On Connector 1
D17	Lamp On Connector 4	D302	Lamp Overload Connector 2
D18	Lamp Overload Connector 4	D303	Lamp On Connector 2
D19	Lamp Overload Connector 3	D311	Mux Connector 1 RX
D201	Label Alarm RxTx	D312	Mux Connector 2 RX



IQ PCB





The following points can be used:


K3	Oscilloscope Tx	K23	IO Connector
K4	Output Tx (connector 4)	K24	IO Connector
K5	Output Tx (connector 3)	K201	Handheld terminal RxTx
K6	Synchronization In	K202	Oscilloscope Rx
K7	Synchronization In	K203	Jumper
K9	Jumper Attenuation	K204	Jumper
K10	Master connector	K205	Handheld terminal NCC
K11	Power Input	K300	Output Rx (connector 1)
K12	Jumper Attenuation	K301	Output Rx (connector 2)
K13	Jumper Attenuation	P1	PA Drive Adjustment
K15	Jumper Attenuation	P2	Phase Adjustment Tx
K16	RS232 Interface Connector	P3	Mixer Bias Adjustment
K19	Jumper	P4	Slave Data communication Rx
K21	Connector FCI	P5	Master Data communication Rx

Indicator leds:

D11	Mux Connector 1 TX	D51	Customer Counting: Led on = active
D12	Mux Connector 2 TX	D52	Customer Counting: Led on = active
D16	Lamp On Connector 3	D53	Customer Counting: Led on = active
D17	Lamp On Connector 4	D201	Label Alarm RxTx
D18	Lamp Overload Connector 4	D202	Communication Error RxTx
D19	Lamp Overload Connector 3	D220	Label Detection Alarm NCC on = detection
D25	Sweep Lock	D221	Communication Error NCC
D26	Center Lock	D300	Lamp Overload Connector 1
D30	Customer Counting: Led on = active	D301	Lamp On Connector 1
D45	Customer Counting: Led on = active	D302	Lamp Overload Connector 2
D47	Customer Counting: Led on = active	D303	Lamp On Connector 2
D48	Customer Counting: Led on = active	D311	Mux Connector 1 RX
D50	Customer Counting: Led on = active	D312	Mux Connector 2 RX



IQ3E PCB










The following points can be used:

K3	Oscilloscope Tx	K23	IO Connector
K4	Output Tx (connector 4)	K24	IO Connector
K5	Output Tx (connector 3)	K201	Handheld terminal RxTx
K6	Synchronization In	K202	Oscilloscope Rx
K7	Synchronization In	K203	Jumper
K9	Jumper Attenuation	K204	Jumper
K11	Power Input	K300	Output Rx (connector 1)
K12	Jumper Attenuation	K301	Output Rx (connector 2)
K13	Jumper Attenuation	P1	PA Drive Adjustment
K15	Jumper Attenuation	P2	Phase Adjustment Tx
K19	Jumper	P3	Mixer Bias Adjustment
K21	Connector FCI		

Indicator leds:

D11	Mux Connector 1 TX	D51	Customer Counting: Led on = active
D12	Mux Connector 2 TX	D52	Customer Counting: Led on = active
D16	Lamp On Connector 3	D53	Customer Counting: Led on = active
D17	Lamp On Connector 4	D201	Label Alarm RxTx
D18	Lamp Overload Connector 4	D202	Communication Error RxTx
D19	Lamp Overload Connector 3	D300	Lamp Overload Connector 1
D30	Customer Counting: Led on = active	D301	Lamp On Connector 1
D45	Customer Counting: Led on = active	D302	Lamp Overload Connector 2
D47	Customer Counting: Led on = active	D303	Lamp On Connector 2
D48	Customer Counting: Led on = active	D311	Mux Connector 1 RX
D50	Customer Counting: Led on = active	D312	Mux Connector 2 RX


Attenuation

 <p style="text-align: center;">Jumpers</p> <ul style="list-style-type: none">  = 0 dB  = 6 dB  = 12 dB  = 18 dB 	<p>It is possible to attenuate the receiver input sensitivity with 6, 12 or 18dB. In this way the receiver is capable of accepting the high level of the coupled transmitter signal when the panels are too close to each other. When the distance between the antenna's is below 1.5 metre the attenuator should be used to avoid overloading of the receiving input.</p>
--	--




IO Connector K23

1	= DRF2b count in2
2	= DRF2b count in1
3	= DRF2b enable burst
4	= DRF2b sync 150 Hz
5	= Gnd general
6	= +33V
7	= Gnd Customer Counting
8	= sensor in 8
9	= sensor in 7
10	= sensor in 6
11	= sensor in 5
12	= sensor in 4
13	= sensor in 3
14	= sensor in 2
15	= sensor in 1
16	= +15V Customer Counting



IO Connector K24

1	= Ry1 C
2	= Ry1 NO
3	= Ry1 NC
4	= Ry2 C
5	= Ry2 NO
6	= Ry2 NC
7	= opto in 1
8	= opto in 2
9	= common opto inputs
10	= opto out 2
11	= opto out 1
12	= common opto outputs
13	= I2C Sda
14	= I2c Scl
15	= + 6Volt
16	= Gnd






System configurations

1. Shown configurations are examples
2. Settings may differ from the store you are installing - programming
3. Shown firmware is version 1.406 X and 1.407 X, used for these examples, your version may be different!



BQ System , 1 aisle, Deactivatorunit

BQ - Unit



MM

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MM 1.406/A
C Reboot EQ 5E30

7 Edit

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves

1 Network

Address 5E30

C Detect slaves FFFF

C Detect slaves

Address 5E30

C Detect slaves FFFF

←

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves

C Slaves (check)

4B5C<0000 0000 0000
0000<0000 0000 0000
0000<0000 0000 0000
0000<0000 0000 0000

←

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves

9 Flash

7 Save settings
4 Restore

7 Save settings

Done
(Esc to continue)

MS Transmitter

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MS 1.406/A
C Reboot IQ1 4B5C

7 Edit

7 RX 9 Flash
4 TX 6 InOut

4 TX

7 Mux 4 Alarm
1 Power

7 Mux

Mux x 1< On 7 Led 1
Phase A B C D
Conn 1 1 1 1
Group 1 1 1 1

←

7 Mux 4 Alarm
1 Power

4 Alarm

Alarm neighbour

A B C D
5E30<5E30 0000 0000
0000<0000 0000 0000

←

7 Mux 4 Alarm
1 Power

1 Power

Phase A B C D
Power 12< 1 1 1
Actual 1 1 0 0
Agc 1

←

7 Mux 4 Alarm
1 Power

7 RX 9 Flash
4 TX 6 InOut

9 Flash

7 Save settings
4 Restore

7 Save settings

Done
(Esc to continue)

MS Receiver

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MS 1.406/A
C Reboot IQ1 4B5C

7 Edit

7 RX 9 Flash
4 TX 6 InOut

7 RX Edit

7 Mux 8 MutS
4 Alarm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop

7 Mux

Mux x 1< On 7 Led 1
Phase A B C D
Conn 1 1 1 1
Group 1 1 1 1

←

7 Mux 8 MutS
4 Alarm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop

1 Sens

GainA 45< GainB 54
GainC 54< GainD 54
Tresh 8 MaxPW 40
0 Default

←

7 Mux 8 MutS
4 Alarm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop

3 Admo

AdMode 1< Speed 10
AdBuf x 0 0 0
Max 23<20 20 20
Current x 0 0 0

←

7 Mux 8 MutS
4 Alarm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop

7 RX 9 Flash
4 TX 6 InOut

9 Flash

7 Save settings
4 Restore

7 Save settings

Done
(Esc to continue)

MS InOut

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MS 1.406/A
C Reboot IQ1 4B5C

7 Edit

7 RX 9 Flash
4 TX 6 InOut

6 InOut Edit

Usage 1<
7 Free/deact (0/1)
4 CuCo (*)
1 Metal (2/4)

7 Free/deact

Deact Enable 1<
InOut 0 0
Pulse in 1 out 1 s
Lvl 50 Time 30

←

Usage 1<
7 Free/deact (0/1)
4 CuCo (*)
1 Metal (2/4)

←

7 RX 9 Flash
4 TX 6 InOut

9 Flash

7 Save settings
4 Restore


7 Save settings

Done
(Esc to continue)



EQ System, 3 aisles

EQ - Unit



MM

```

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MM 1.406/A
C Reboot EQ 5E30
    
```

7 Edit

```

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves
    
```

1 Network

```

Address 5E30
C Detect slaves FFFF
C Detect slaves
Address 5E30
C Detect slaves FFFF
    
```

←

```

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves
    
```

C Slaves (check)

```

4B5C<0000 0000 0000
0000<0000 0000 0000
0000<0000 0000 0000
0000<0000 0000 0000
    
```

←

```

7 Sweep 9 Flash
4 Alarm 6 Modem
1 Network 3 InOut
C Slaves
    
```

9 Flash

```

7 Save settings
4 Restore
    
```

7 Save settings

```

Done
(Esc to continue)
    
```

MS Transmitter

```

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MS 1.406/A
C Reboot EQ3 4B5C
    
```

7 Edit

```

7 RX 9 Flash
4 TX 6 InOut
    
```

4 TX

```

7 Mux
4 Alarm
1 Power
    
```

7 Mux

```

Mux x 4< On 7 Led 1
Phase A B C D
Conn 3 3 4 4
Group 1 1 1 1
    
```

←

```

7 Mux
4 Alarm
1 Power
    
```

4 Alarm

```

Alarm neighbour
A B C D
4B5C<4B5C 4B5C 0000
0000 0000 0000 0000
    
```

←

```

7 Mux
4 Alarm
1 Power
    
```

1 Power

```

Phase A B C D
Power 12< 12 12 12
Actual 12 12 12 12
Agc 1
    
```

←

```

7 Mux
4 Alarm
1 Power
    
```

←

```

7 RX 9 Flash
4 TX 6 InOut
    
```

9 Flash

```

7 Save settings
4 Restore
    
```

7 Save settings

```

Done
(Esc to continue)
    
```

MS Receiver

```

7 Edit 2003-02-13
4 Test 11:53:54
1 Status MS 1.406/A
C Reboot EQ3 4B5C
    
```

7 Edit

```

7 RX 9 Flash
4 TX 6 InOut
    
```

7 RX Edit

```

7 Mux 8 MutS
4 Alrm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop
    
```

7 Mux

```

Mux 4< On 7 Led 1
Phase A B C D
Conn 1 2 2 2
Group 1 1 1 1
    
```

←

```

7 Mux 8 MutS
4 Alrm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop
    
```

1 Sens

```

GainA 54< GainB 54
GainC 54 GainD 54
Tresh 8 MaxPW 40
0 Default
    
```

←

```

7 Mux 8 MutS
4 Alrm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop
    
```

4 Alarm

```

Ext Rel 0< 0 0 0
AlrmEna 1 1 1 0
Buzzer Ena 1 Mode 0
Lv1 0 Time 0
    
```

←

```

7 Mux 8 MutS
4 Alrm 5 Mcut
1 Sens 2 Sig1 3 Admo
C Freq 0 Scop
    
```

←

```

7 RX 9 Flash
4 TX 6 InOut
    
```

9 Flash

```

7 Save settings
4 Restore
    
```


7 Save settings

```

Done
(Esc to continue)
    
```



IQ System, 7 aisles, Customer Counting, Metal Detection




Buzzer for Metal Detection on relay 1





See last page for an extended view






Checklist modem settings iNCC





















Connecting a PC to a XQ or EQ/IQ Unit



i F = Female, M = Male

Connecting a XQ or EQ/IQ unit to a modem




i F = Female, M = Male




Connecting to an ISDN line using the DeTeWe TA33 terminal adapter

At the moment this manual is written, connecting a ISDN modem to a XQ or an EQ/IQ Unit is NOT supported. The connection shown below can be used in case of an ISDN telephone line.



i F = Female, M = Male




IQ3

MM 7 Edit 2003-02-13 4 Test 10:26:15 1 Status MM 1.407/A C Reboot IQ 52C5 7 Edit 7 Sweep 9 Flash 4 Alarm 6 Modem 1 Network 3 InOut C Slaves 1 Network Address 52C5 C Detect slaves FFFF C Detect slaves Address 52C5 C Detect slaves FFFF 7 Sweep 9 Flash 4 Alarm 6 Modem 1 Network 3 InOut C Slaves C Slaves (check) 6288-72C5 0000 0000 0000 0000 0000 0000 7 Sweep 9 Flash 4 Alarm 6 Modem 1 Network 3 InOut C Slaves 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)	MS Transmitter 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ3 72C5 7 Edit 7 RX 9 Flash 4 TX 6 InOut 4 TX 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 Mux Mux x 4< On 7 Led 1 Phase A B C D Conn 3 3 4 4 Group 1 1 1 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 4 Alarm Alarm neighbour A B C D 72C5<72C5 72C5 6288 0000 0000 0000 0000 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power Phase A B C D Power 12< 12 12 12 Actual 12 12 12 12 Agc 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)	MS Receiver 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ3 72C5 7 Edit 7 RX 9 Flash 4 TX 6 InOut 7 RX 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 7 Mux Mux x 4< On 7 Led 1 Phase A B C D Conn 1 2 2 1 Group 1 1 1 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 1 Sens GainA 54< GainB 54 GainC 54 GainD 20 Tresh 8 MaxPW 40 0 Default 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 4 Alarm Ext Rel 0< 0 0 0 AlrmEna 1 1 1 0 Buzzer Ena 1 Mode 0 Lvl 0 Time 0 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)	CC & MD 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ3 72C5 7 Edit 7 RX 9 Flash 4 TX 6 InOut 6 InOut Usage 4< 7 Free/Deact (0/1) 4 CuCo (*) 1 Metal (2/4) 4 CuCo 7 Counting 4 Direction 7 Counting Single/Double 2< MinPuls 60 TO 15 WA 1:0 2:0 3:0 4:0 Lvl 25 Time 5 7 Counting 4 Direction 1:72C5<A 2:72C5 B 3:72C5 C 4:6288 D Window 2000 ms Lvl 1 Time 5 4 Direction 1:72C5<A 2:72C5 B 3:72C5 C 4:6288 D Window 2000 ms Lvl 1 Time 5 7 Counting 4 Direction Usage 4< 7 Free/Deact (0/1) 4 CuCo (*) 1 Metal (2/4) 1 Metal (2/4) Action 1< 0 0 0 Mode 0 0 0 0 Pulse in 5 s Lvl 25 Time 5 Usage 4< 7 Free/Deact (0/1) 4 CuCo (*) 1 Metal (2/4) 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)
--	---	--	---

IQ4E

MS Transmitter 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ4E 6288 7 Edit 7 RX 9 Flash 4 TX 6 InOut 4 TX 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 Mux Mux x 4< On 7 Led 1 Phase A B C D Conn 3 3 4 4 Group 1 1 1 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 4 Alarm Alarm neighbour A B C D 6288<6288 6288 0000 0000 0000 0000 0000 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power Phase A B C D Power 12< 12 12 6 Actual 12 12 12 0 Agc 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)	MS Receiver 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ4E 6288 7 Edit 7 RX 9 Flash 4 TX 6 InOut 7 RX 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 7 Mux Mux x 4< On 7 Led 1 Phase A B C D Conn 1 2 2 1 Group 1 1 1 1 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 1 Sens GainA 54< GainB 54 GainC 54 GainD 54 Tresh 8 MaxPW 40 0 Default 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Sens 2 Sig1 3 Admo C Freq 0 Scop 4 Alarm Ext Rel 0< 0 0 0 AlrmEna 1 1 1 1 Buzzer Ena 1 Mode 0 Lvl 0 Time 0 7 Mux 8 MutS 4 Alarm 5 Mcut 1 Power 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)	CC & MD 7 Edit 2003-02-13 4 Test 11:33:39 1 Status MS 1.406/B C Reboot IQ4E 6288 7 Edit 7 RX 9 Flash 4 TX 6 InOut 6 InOut Usage -1< 7 Free/Deact (0/1) 4 CuCo (*) 1 Metal (2/4) 4 CuCo 7 Counting 4 Direction 7 Counting Single/Double -1< MinPuls 60 TO 15 WA 1:0 2:0 3:0 4:0 Lvl 1 Time 5 7 Counting 4 Direction 1:6288<A 2:6288 B 3:6288 C 4:0000 D Window 2000 ms Lvl 25 Time 5 4 Direction 1:6288<A 2:6288 B 3:6288 C 4:0000 D Window 2000 ms Lvl 25 Time 5 7 Counting 4 Direction Usage -1< 7 Free/Deact (0/1) 4 CuCo (*) 1 Metal (2/4) 7 RX 9 Flash 4 TX 6 InOut 9 Flash 7 Save settings 4 Restore 7 Save settings Done (Esc to continue)
--	---	--



medap



Metal Detection MD4

NEDAP RETAIL SUPPORT

Metal Detection

Manual MD4 including 62,75 MHz



Caution!

This document is made for Adobe Acrobat Reader 5.0 or higher.
You can download this version of the reader at www.adobe.com



Technical Support:

- support-rs@nedap.nl
- H. Hammer
+31 (0) 544-47 15 19
h.hammer@nedap.nl
- H. Broekhuis
+31 (0) 544-47 15 02
h.broekhuis@nedap.nl

Visitor's address:

Nedap Retail Support
Parallelweg 2d
Groenlo
Netherlands

Postal address:

Nedap Retail Support
Postbus 102
7140 AC Groenlo
Netherlands



Table of content

<i>Technical Support:</i>	2
<i>Modification of the OS/T Metal Detection operating frequency from 66 kHz to 62.75 kHz.</i>	4
<i>1 General</i>	5
<i>2 Block diagram</i>	6
<i>2.1 Explanation of the diagram</i>	7
<i>3 Printed Circuit Board</i>	8
<i>4 Metal Detection PCB in XQ unit</i>	9
<i>5 Metal Detection PCB in EQ/IQ unit</i>	9
<i>6 Handheld terminal settings</i>	10



Modification of the OS/T Metal Detection operating frequency from 66 kHz to 62.75 kHz.

In DSP3 systems the Metal Detection (MD) had an operating frequency of 48 kHz, independent of the 8.2 MHz sweep generation system. It could run as a stand-alone system.

In the OS/T system, it is possible to set up a system including MD with internal electronics in the panels and a single coax connection between the panels.

To realize that, the operating frequency of the OS/T MD had to be derived from the OS/T sweep frequency. The required modification also gave the opportunity to choose a higher operating frequency. That was desired because of an enhanced detectability of metal-lined bags with a very thin aluminum layer, like used in certain types of "Cool Bags".

The new operating frequency was chosen at 66 kHz, 8 kHz above the Acousto-Magnetic (AM) operating frequency of Sensormatic, in stead of 10 kHz below it, but still within a frequency band where the same level of fieldstrength (72 dB μ A/m) is allowed, and not on the frequency's of several positioning systems, time standards and submarine communications.

Unfortunately this carefully chosen frequency appeared to be exactly the listen frequency of Security Tag or Xpondr frequency divider EAS systems. The transmitter frequency of Xpondr is 132 kHz, so the Nedap MD does not suffer from any interference of a Xpondr system.

When installed in neighbor shops, an Xpondr system appeared to be completely deaf.

Therefore we had to modify the operating frequency to a nominal 62.75 kHz in stead of 66 kHz.

This small frequency shift has the least impact in the modification of several filter components.

With the sweep-extend of the OS/T system on position 3, this frequency shifts down to 60.57 kHz.

This range is sufficiently below 66 kHz to prevent interference problems with both digital and older analog Xpondr systems.

The drawback unfortunately is that 62.75 kHz is closer to the AM frequency. A Nedap MD system can function on a distance of about 20 m away from an AM system. This minimum distance now should be at least 25 m.



1 General

The OST combination NCC4 and external RX4/TX4 can be fitted with up to 8 antenna's making it possible to guard up to 4 entrance separately.




This MD4 pcb also makes it possible for the Metal Detection to connect and process up to 4 different entrances separately.

Like the FCI (Flat Cable Interface) pcb this MD4 pcb is also connected to the feature connector on the OST RX4 or TX4. The MD4 pcb does not need tuning and holds no jumpers.

In addition to the 4 Metal Detection in/outputs the pcb is fitted with 4 extra inputs. Floating contacts can be connected to these inputs, for instance to count tag decouplings or shop open/closed.



2 Block diagram





2.1 Explanation of the diagram

On the OST feature connector a 600Hz repeated signal is available from which the flat cable interface produces the 66 kHz which is used on the metal detection PCB's.

The /start pulse from the feature connector are in fact two very narrow pulses about 120uSec apart and repeated in a more or less 600 Hz rhythm.


On every first pulse a 1 shot 74HC123) is triggered to produce a more or less 600 Hz block signal used as a reference signal for a PLL (74HC4046). The VCO of the PLL block oscillates on 132 kHz which by means of a programmable divider divides this signal to around 600 Hz. This signal is then used on the Comp In. of the PLL and the 132 kHz is locked. Another 1 shot triggers a divider by 2 circuit to output the 66 kHz signal which is available on the 4 data cable outputs.

An alarm from the MD RX is shaped and buffered (74hc573) and presented on one of the inputs of a 2 x 4mux (74hc4052). Dependent on the mute_3 signal, ext_clk and ext_i/o are used to address the latch (74hc573) or read the output of the mux.



3 Printed Circuit Board


connection to feature
conn. OST




MD
extra IN

4 Metal Detection PCB in XQ unit

4.1 Circuit board in unit XQ




The **MD4 pcb** is intended to be **placed on top of the TX-PCB*** inside the external unit shown above. A CC4 pcb can be placed inside the unit as well.



***i** Connecting the MD4 PCB to a NR4 on a external NRT4 Unit will decrease EAS performance



5 Metal Detection PCB in EQ/IQ unit





The MD4 PCB will be mounted on the metal plate on top of the IQ unit. It will be connected with a flat-cable to connector K21 (FCI) of the IQ PCB. See the drawing for the right polarity.


6 Handheld terminal settings

For the handheld-terminal settings see the manual of the handheld-terminal (version 1.300 or higher).

7 Wiring examples









The MD4 is designed to be used in combination with the OST external TX unit. Metal detection now can be used in the same entrance configuration as you connect your OST external RX/TX. As on the OST unit, 4 independent Metal Detection connectors are available with independent alarming. (alarming is per entrance not per aisle). As you see there is no change in how to loop the Metal Detection pcb's together. Only be sure to connect only one entrance per connector on the MD4 pcb.

This MD4 is also fitted with 4 additional "alarm-inputs" which can be used for a variety of options. Only a floating contact is needed. One can use the contacts for instance as detection "shop open/closed" – guard on watch – alarm cause – etc etc.

