

1.12.2. Access to logbook

This procedure controls the facilities for sending a list of the various operational events to a terminal connected to the CPU. These data can be sent :

- ◆ continuously in real time or,
- ◆ when requested by the operator.

The operation is controlled from the "LOGBOOK" window and is only possible if maintenance mode has been selected and if the PCL is unlocked, i.e. enabled.

ACTION		RESULT
Having selected the "LOGBOOK" window		<ul style="list-style-type: none"> ◆ The "TRACE ON"/"TRACE OFF" control keys indicates the method of sending data currently selected. ◆ «TRACE ACTIVE» : sends the data in real time. ◆ «TRACE INHIBEE» : sends the data after operator request.
To change the method of sending data:	<ul style="list-style-type: none"> ◆ Press on the "TRACE ON" key or the "TRACE OFF" key. 	<ul style="list-style-type: none"> ◆ The "TRACE ON"/"TRACE OFF" control keys indicates the new method of sending the data.
Sends the data after operator request.	<ul style="list-style-type: none"> ◆ Having selected "TRACE OFF": <ul style="list-style-type: none"> • Press "DISPLAY ALL", • Press on the "PAGE UP" key, • Press on the "PAGE DOWN" key. 	<ul style="list-style-type: none"> ◆ Sends data on all operational events. ◆ Sends data on the 20 operational events previous to the last events listed in the logbook. ◆ Sends data on the 20 operational events which follow on from the last events listed in the logbook.

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2. Use of commands and description of indicators

2.1. Use and description of control panel screens

2.1.1. Outline

The various windows displayed on the Local Control Panel (PCL) provide the operator with the following:

- ◆ Transmitter status data,
- ◆ Commands to change the operational state of the system, and commands to select the various windows.


NOTE : The following windows are not available with an ATSC transmitter:

- ◆ SFN delay
- ◆ Modulation configuration
- ◆ Modulator status
- ◆ MIP data
- ◆ Modulator input setting

There are used in DVB-T transmitters only.


Ergonomics of screens

- ◆ Ergonomics of control keys :
 - Text of **browsing** keys is yellow on blue background
 - Text of **changing and confirming** keys is black on white background
- ◆ Ergonomics of message and information :
 - **Unmodifiable message** is black on cyan blue background
 - **Modifiable message** is cyan blue on black background



- **Modifiable information** is black on green, red, orange, yellow background

- **Normal state** is on green background




- **Abnormal state** but without default is on yellow background



- **Default state due to sub-assemblies** is on red background



- **External default** which concern sub-assemblies is on orange background



- Special case



Information « MAINT MODE / NORMAL MODE » is flashing on yellow background

The reference of the touch screen software is 29 709 093.

2.1.2. Installation windows

2.1.2.1. "INSTALLATION PARAMETERS Level 1" window

This window appears when the changeover switch SW1 on the exciter/CPU interconnection card (MODAP version) or on the management system interconnection card (SIRIUS version), is switched so that the dot is visible and that CPU board is reset.

This window is used to change the transmitter configuration parameters stored in the CPU board.

UHF	SYNTH FREQ 1234567890	MAX PWR 123456	CAL PWR 123456
ENGLISH	AIR COOLING	DUAL EXCITER	DISPLAY IN dB/W
ANALOG. TRANSMIT.	COOLING LOAD NOT FITTED	TS ALARM DISABLE	PASSWORD DISABLE
COOL REDUND NOT FITTED			
REINIT VALUES	VALID	INSTALL NEXT	

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
UHF	Selects the transmitter frequency range. Displays last selection.	VHF I, VHF III, UHF
SYNTH FREQ 1234567890	Displays the RF synthesiser frequency value. Displays last selection.	Pressing this key calls up the "NUMERICAL VALUE" window in which this frequency can be changed.
MAX PWR 123456	Selects the maximum transmitter power (Maximum available RF power). Displays last selection.	Pressing this key calls up the "NUMERICAL VALUE" window in which this typical transmitter power can be changed.
CAL PWR 123456	Selects the actual transmitter power (Calibrated RF power). Displays last selection.	Power level for which probes and power output displays (bargraph) of the transmitter are adjusted. This level is a reference for the software. This actual value is associated with the power levels in % "100", display in window, and with the Auto Gain value "128" (Digital transmitter) of ADAPT exciter. At any time: CAL Power ≤ MAX Power
ENGLISH	Selects the language of the Local Control Panel windows. Displays last selection.	FRANCAIS, ENGLISH, ESPAGNOL

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
AIR COOLING	Selects the cooling type of the cabinet. Displays last selection.	AIR COOLING, LIQUID COOLING
DUAL EXCITER	Selects the exciter configuration. Displays last selection.	SINGLE EXCITER, DUAL EXCITER, PASSIVE RESERVE, N+1
DISPLAY IN dB/W	Selects the type of power unity. Displays last selection.	DISPLAY IN dB/W, DISPLAY IN % If “%” is elected, every RF power display is to be expressed in %, except maximum power which is expressed in Watts. If “dB” is elected, every RF power display is to be expressed in dB, except maximum power which is expressed in Watts.
ANALOG. TRANSMIT.	Selects the modulation type of the transmitter. Displays last selection.	ANALOG. TRANSMIT; DIGITAL TRANSMIT
COOLING LOAD NOT FITTED	Adapts the CPU software to suit the safety interface hardware.	COOLING LOAD NOT FITTED COOLING LOAD FITTED <u>FITTED</u> : The safety of the load network cooling is active. The "COOLING LOAD" key is visible in "INTERLOCK" window.
TS ALARM DISABLE	Adapts the CPU software to suit the low power alarm status.	TS ALARM DISABLE, TS ALARM ENABLE <u>DISABLE</u> : Without input Transport Stream (TS), there is no low power alarm indication. <u>ENABLE</u> : Indication low power alarm is active when the input Transport Stream (TS) is absence
PASSWORD DISABLE	Adapts the CPU software to suit one password use for PCL unlocked.	PASSWORD DISABLE, PASSWORD ENABLE <u>ENABLE</u> : Using of password for PCL unlocked
REINIT VALUES	Sets the CPU board to the default configuration.	Calls up the "WARNING 2" window. This control keys may be used to repeat the installation procedure.
VALID	Validates the configuration displayed on the window.	
INSTALL NEXT	Calls up the "TRANSMITTER INTERFACE PARAMETERS" window.	


Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2.1.2.2. "TRANSMITTER INTERFACE PARAMETERS" window

This window appears when the changeover switch SW1 on the exciter/CPU interconnection card (MODAP) or on the management system interconnection card (SIRIUS) is switched so that the dot is visible and that CPU board is reset.

It is called up by pressing the "INSTALL NEXT" control keys in the "INSTALLATION PARAMETERS Level 1" window.

This window is used to change the transmitter interface parameters stored in the CPU card.



CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>Tx Num</div> <div>12</div>	<p>Selects the transmitter ID number in N+1 or Passive Reserve configurations.</p> <p>Displays last selection.</p>	<p>The transmitter ID number is used for remote control through an RS 232/485 connection.</p> <p>Pressing this key calls up the "NUMERICAL VALUE" window in which this two-digit identification number can be changed.</p>
<div>JBUS</div> <div>RTU</div>	<p>Selects the type of JBUS protocol operation for remote control</p> <p>Displays last selection</p>	<p>JBUS ASCII</p> <p>JBUS RTU</p>
<div>SERIAL</div> <div>RMT CTRL</div>	<p>Selects the type of remote operation.</p> <p>Displays last selection.</p>	<p>SERIAL RMT CTRL, PARALLEL RMT CTRL, USER RMT CTRL</p>
<div>INSTALL</div> <div>NEXT</div>	<p>Calls up the "CABINET CONFIGURATION PARAMETERS" window.</p>	




2.1.2.3. "CABINET CONFIGURATION PARAMETERS" window

This window appears when the changeover switch SW1 on the exciter/CPU interconnection card (MODAP) or on the management system interconnection card (SIRIUS), is switched so that the dot is visible and that CPU board is reset.

It is called up by pressing the "INSTALL NEXT" control keys in the "TRANSMITTER INTERFACE PARAMETERS" window.

This window is used to change the cabinet configuration parameters stored in the CPU board.

CABINET CONFIGURATION				AMPLIS 6 TRANS.
CAB 1	CAB 2	CAB 3	CAB 4	
MP	B4	B6	B10	VALID
AMP 12	AMP 12	AMP 12	AMP 12	CANCEL
DISPLAY	DISPLAY	DISPLAY	DISPLAY	
				INSTALL NEXT

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
	Validates the cabinet selection and detects the amplifier location in each of the cabinet selected.	
	Cancels the entry and calls back the previous values	
	Selects the number of currents measured by amplifier unit (*). Displays last selection	<u>AMPLIS 6 TRANS.</u> : 6 currents measured <u>AMPLIS 8 TRANS.</u> : 8 currents measured

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>C&B 1</div> <div>MP</div>	Selects the type of the cabinet. Displays last selection	NO, MP, B4, B6, B10, B16AG, B16NG, B20, AFF4, AFF8 ♦ <u>NO</u> : No use OPTIMUM / ULTIMATE FAMILY ♦ <u>MP</u> : MPNG Cabinet, ♦ <u>B4</u> : Cabinet consist of 4 RF amplifiers, ♦ <u>B6</u> : Cabinet consist of 6 RF amplifiers, ♦ <u>B16AG</u> : Cabinet consist of 16 RF amplifiers (Old generation cabinet: the main MUX card "MASTER" feed 4 PSUs) ♦ <u>B16NG</u> : Cabinet consist of 16 RF amplifiers (New generation cabinet: The main MUX card "MASTER" feed 5 PSUs) ♦ <u>B20</u> : Cabinet consist of 20 RF amplifiers AFFINITY FAMILY ♦ <u>AFF4</u> : Cabinet consist of 4 RF amplifiers ♦ <u>AFF8</u> : Cabinet consist of 8 RF amplifiers
<div>DISPLAY</div>	Calls up the " AMPLIFIER LOCATION " window	This control keys may be used to selected the amplifier location
<div>INSTALL</div> <div>NEXT</div>	Calls up the "ADAPT INSTALLATION PARAMETERS" window.	

(*) Note

- ♦ In case of using the **2400W VHF amplifier unit** (61388768 or 61388769) ,the window "RF amplifier" include 6 current measurements.
- ♦ In case of using the **1600W VHF amplifier unit** ,the window "RF amplifier" include 8 current measurements.
- ♦ In case of using the **UHF amplifier unit** , the window "RF amplifier" include 6 current measurements.

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
<div>CABINET CONFIGURATION</div>	Gives the window name.	
<div>AMP</div> <div>12</div>	Displays the detected amplifier location number including into this cabinet.	

2.1.2.3.1. "LOCATION AMPLIFIER" window



This window appears when the changeover switch SW1 or S9 is switched so that the dot is visible and that CPU board is reset.

It is called up by pressing the "DISPLAY" control keys in the "CABINET CONFIGURATION PARAMETERS" window.

This window displays the location of RF amplifier in selected cabinet. It is used to change the amplifier location stored in the CPU board.

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
	Decrements the cabinet number (*).	The number resulting from the decrementation is displayed in the message window between the "+ CAB" and "- CAB" control keys. Command is disabled while the PCL is locked (disabled).
	Increments the cabinet number (*).	The number resulting from the incrementation is displayed in the message window between the "+ CAB" and "- CAB" control keys. Command is disabled while the PCL is locked (disabled).
	Detects the amplifier location in cabinet selected.	
	Validates the entry	
	Cancels the entry and calls back the previous windows	
	Calls up the "CABINET CONFIGURATION PARAMETERS" window.	

(*) : Operating only when there is more than one cabinet.

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
CABINET CONFIGURATION	Gives the window name.	
	Toggles between present and absent or vision and sound amplifier location Displays the amplifier location status into this cabinet Displays last selection	PRES. / ABSENT for digital transmitter VISION / SOUND. / ABSENT for analogue transmitter
	Shows the number of the particular cabinet to which the data displayed in this window refer.	

2.1.2.4. "INSTALLATION ADAPT PARAMETERS" window

This window appears when the changeover switch SW1 on the exciter/CPU interconnection card (MODAP) or on the management system interconnection card (SIRIUS) is switched so that the dot is visible and that CPU board is reset.

It is called up by pressing the "INSTALL NEXT" control keys in the "CONFIGURATION CABINET" window.

This window is used to change the configuration adaptation parameters stored in the CPU card.

Note :

♦ MODAP Version only

To set up a new parameter configuration of the modulator, the three corrections (ALE, LUT and OLDC) should be set to the FIXED mode. The control keys can be defined in the "MISCELLANEOUS" windows and "CONTROL MAINT Level 4" windows.

♦ SIRIUS Version only

To set up a new parameter configuration of the modulator, the two corrections (ALE, and LUT) should be set to the FIXED mode. The control keys can be defined in the "MISCELLANEOUS" windows and "CONTROL MAINT Level 4" windows.

COFDM MODAP	LIN. COR ON LINE	DIGIT FILT ON LINE
BAND WIDTH 8 Mhz	N.LIN COR ON LINE	DIGIT FILT 1
DASI FITTED	OLDC FITTED	FOLDBACK NOT FITTED
		INSTALL NEXT

MODAP Version

COFDM SIRIUS	LIN. COR ON LINE	DIGIT FILT ON LINE
BAND WIDTH 8 Mhz	N.LIN COR ON LINE	DIGIT FILT 1
		FOLDBACK NOT FITTED
DVB-H DISABLE		INSTALL NEXT

SIRIUS Version

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>COFDM MODAP</div> <p>OR</p> <div>COFDM SIRIUS</div>	<p>Selects the type of modulator processing the input signal.</p> <p>Displays last selection.</p>	<p>8VSB BOARD / COFDM EXT / IFIQ BOARD / COFDM MODAP / COFDM SIRIUS / FLO SIRIUS</p>
<div>BAND WIDTH 8 Mhz</div> <p>(2)</p>	<p>Selects the band width of the canal for DVBT signal</p> <p>Displays last selection.</p>	<p>BAND WIDTH 6MHz / BAND WIDTH 7MHz / BAND WIDTH 8MHz /</p> <p>This control key is available in COFDM MODAP or COFDM SIRIUS (Internal DVB-T Modulator)</p>
<div>LIN. COR ON LINE</div>	<p>Adapts the CPU software to suit the DAP hardware (Adaptive Linear Equalizer).</p> <p>Displays last selection.</p>	<p>♦ MODAP version</p> <p>LIN. COR NOT FITTED/ LIN. COR ON LINE / LIN. COR BYPASSED</p> <p>♦ SIRIUS version</p> <p>LIN. COR ON LINE / LIN. COR BYPASSED</p>
<div>N.LIN COR ON LINE</div>	<p>Activates or bypasses the DAP non linearity corrector (Look Up Table).</p> <p>Displays last selection.</p>	<p>N. LIN. COR ON LINE / N. LIN. COR BYPASSED</p>
<div>DIGIT FILT ON LINE</div>	<p>Adapts the CPU software to suit the DAP hardware (digital filter).</p> <p>Displays last selection.</p>	<p>♦ MODAP version</p> <p>DIGIT FILT NOT FITTED / DIGIT FILT ON LINE / DIGIT FILT BYPASSED</p> <p>♦ SIRIUS version</p> <p>DIGIT FILT ON LINE / DIGIT FILT BYPASSED</p>
<div>DIGIT FILT 1</div>	<p>Selects the table for the digital filter.</p> <p>Displays last selection.</p>	<p>Values: 1 to 5</p> <p>This value is defined in factory:</p> <p>♦ Value normally used on MODAP Exciter is equal at 5</p> <p>♦ Value normally used on SIRIUS Exciter is equal at 1.</p> <p>Pressing this key calls up the "NUMERICAL VALUE" window in which this value can be changed.</p>
<div>DASI FITTED</div> <p>(1)</p>	<p>Adapts the CPU software to suit the MODAP hardware (Double ASI input).</p> <p>Displays last selection.</p>	<p>DASI NOT FITTED / DASI FITTED</p>
<div>OLDC FITTED</div> <p>(1)</p>	<p>Adapts the CPU software to suit the MODAP hardware (OLDC).</p> <p>Displays last selection.</p>	<p>OLDC FITTED / OLDC NOT FITTED</p>

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>FOLDBACK NOT FITTED</div>	Sets the CPU board to the configuration according to the Americanisation unit hardware type 37418880	FOLDBACK NOT FITTED, FOLDBACK FITTED This option unit must be present so that the power control on antenna VSWR fault will be progressively produce through an algorithm. In the second case that the power control on antenna VSWR fault will be is produce by stairway (-3dB, -6dB and halt 'no power")
<div>DVB-H DISABLE</div> (2)	Adapts the CPU software. Visible on COFDM SIRIUS modulator only Displays last selection.	DISABLE: The DVB-H parameters are not accessible via the DVB-T CONTROL screen. ENABLE: The DVB-H parameters are available via the DVB-T CONTROL screen.
<div>INSTALL NEXT</div>	Calls up the "ETHERNET INSTALLATION PARAMETERS" window.	

(1) : Available on MODAP version only

(2) : Unavailable on MediaFLO modulator

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2.1.2.5. "ETHERNET INSTALLATION PARAMETERS" window

This window appears when the changeover switch SW1 or S9 is switched so that the dot is visible and that CPU board is reset.

- ◆ For Digital Transmitter

It is called up by pressing the "INSTALL NEXT" control keys in "INSTALLATION ADAPTATION PARAMETERS" window.

- ◆ For Analogue Transmitter

It is called up by pressing the "INSTALL NEXT" control keys in "INSTALLATION EXCITER PARAMETERS" window.

This window is used to change the Ethernet configuration parameters used by the communication network. It is only available with TH860 CPU Board.

IP ADDRESS 1234567890123456	BOARD ID 1234567890
SUBNET MASK 1234567890123456	WEB ACTIVATION 1234567890
GATEWAY 1234567890123456	SNMP ACTIVATION 1234567890
NTP ADDRESS 1234567890123456	INSTALL NEXT

MESSAGE & CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>BOARD ID</div> <div>1234567890</div>	Displays the identification number of the CPU board	This reference is single and associated to one CPU board
<div>WEB ACTIVATION</div> <div>1234567890</div>	Used to insert the WEB activation code. Displays the WEB activation code, without option in operation the control keys displays: "0"	THALES produces activation code of the "Agent WEB" option. This code is single and associated to the identification number of the CPU board Pressing this key calls up the "NUMERICAL VALUE" window in which this code value can be inserted.
<div>SNMP ACTIVATION</div> <div>1234567890</div>	Used to insert the SNMP activation code. Displays the SNMP activation code, without option in operation the control keys displays: "0"	THALES produces activation code of the "Agent SNMP" option. This code is single and associated to the identification number of the CPU board Pressing this key calls up the "NUMERICAL VALUE" window in which this code value can be inserted.
<div>IP ADDRESS</div> <div>1234567890123456</div>	Used to Insert the IP address of the transmitter in an Ethernet network. Displays the IP address in operation. When the Ethernet network is not operated the control keys must display: "0.0.0.0"	Your network administrator gives the IP address. NOTA : IP wrong address disturbs the network. Calls up the "NUMERICAL VALUE" window

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

MESSAGE & CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
<div>SUBNET MASK</div> <div>1234567890123456</div>	<p>Used to Insert the sub-net mask number</p> <p>Displays the Sub-net mask number in operation.</p> <p>When the Ethernet network is not operated the control keys must display: "0.0.0.0"</p>	<p>Your network administrator gives the subset mask number.</p> <p>This number, associated with IP address, identifies the network inside your transmitter is.</p> <p>NOTA : Subset mask wrong number disturbs the network.</p> <p>Calls up the "NUMERICAL VALUE" window</p>
<div>GATEWAY</div> <div>1234567890123456</div>	<p>Used to Insert the IP address of gateway</p> <p>Displays the IP address of the gateway in operation.</p> <p>When the Ethernet network is not operated the control keys must display: "0.0.0.0"</p>	<p>Your network administrator gives the gateway IP address.</p> <p>NOTA : Gateway IP wrong address disturbs the network.</p> <p>Calls up the "NUMERICAL VALUE" window</p>
<div>NTP ADDRESS</div> <div>1234567890123456</div>	<p>Used to Insert the IP address of Net work Time Protocol (NTP) SERVER.</p> <p>Displays the IP address in operation.</p> <p>When the Ethernet network is not operated the control keys must display: "0.0.0.0"</p>	<p>Your network administrator gives the IP address of the NTP server.</p> <p>NOTA : IP wrong address of the NTP server disturbs the network.</p> <p>Calls up the "NUMERICAL VALUE" window</p>
<div>INSTALL NEXT</div>	<p>Calls up the "INSTALLATION PARAMETERS Level 1" window.</p>	


Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2.1.3. Warning windows

2.1.3.1. Warning window "WARNING 1"

This window appears when configuration parameters are validated.


It prompts the operator to switch the CPU board off and then on again, by using the changeover switch SW1 or S9; this operation switches the power supply feeding the CPU board off and on in order to reset the transmitter with its new configuration.





2.1.3.2. Warning window "WARNING 2"

It appears when the changeover switch SW1 or S9 is switched so that the dot is visible and that CPU board is reset.

This window appears after pressing "REINIT VALUES" in the "INSTALLATION PARAMETERS Level 1" window.



CONTROL KEYS	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
	Validates the window.	After pressing this control keys, the CPU board is set to the default configuration. The "REINIT VALUES" control keys may be used for a new installation procedure.
	Cancels the window.	


2.1.3.3. Warning window "Software UPDATE"




This window is called up by three following conditions:

- ◆ Inserting PCMCIA card in flash card drive. This card contains the new CPU software.
- ◆ Transmitter must be in installation mode changeover "SW1" or S9 is on position "visible dot".

Press the « RESET » button of CPU board or Power off CPU board, opening the appropriate breakers.

This window displays the download progress of the new CPU software. It is only available with TH860 CPU BOARD.




MESSAGE	FUNCTIONS	SELECTIONS AVAILABLE/COMMENTS
	Give the window name	
	Display the down load operating mode.	PLEASE WAIT. CHECKING SOFTWARE VERSION ERASING FLASH MEMORY PROGRAMMING FLASH MEMORY DONE, PLEASE WAIT.
	Displays the down load progress.	

2.1.3.4. Warning window "WARNING 3"

This window appears when the CPU board start up, the communication between the CPU and tactile screen is not still ready.

It prompts the operator to wait a moment.



2.1.4. "TRANSMITTER STATUS" window

This window appears when the transmitter is switched on and the changeover switch SW1 or S9, behind the CPU board, is switched so that the dot is not visible.

It can also be called up by pressing the "STATUS" control keys on the other windows.

OPTIMUM FAMILY OR ULTIMATE FAMILY




Figure 6 : Dual Drive Transmitter




Figure 7 : Single Drive Transmitter

AFFINTY FAMILY




Figure 8 : Dual Drive Transmitter




Figure 9 : Single Drive Transmitter

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
REQUIR POWER	Calls up the "REQUIRED POWER" window (Reduction power). (3)	<p>♦ ATSC transmitter OR ANALOG transmitter</p> <p>This control keys is available in Maintenance mode only.</p> <p>Control key invisible in Normal mode only.</p> <p>♦ DVB-T transmitters</p> <p>This control keys is available in Maintenance mode and MFN mode operation only.</p> <p>Control key invisible in Normal mode or SFN mode operation.</p>
TRANSMITTER STATUS	Calls up the "GO HOME AND VIEW INSTALLATION PARAMETERS" window. Also displays the window title.	
NEXT STATUS	Calls up the "STATUS" window.	
CONTROL	Calls up the "CONTROL Level 1" window.	
EXCITER	Calls up the "EXCITER Level 1" window.	
AMPLI	Calls up the "AMPLIFIERS" window. (a)	
INTLOCK	Calls up the "INTLOCK" window. (a)	
PSUPPLY	Calls up the "POWER SUPPLY" window. (a)	
AFFIN.	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

(3): Unavailable for MedaFLO modulator

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
TRANSMITTER STATUS	Gives the window name.	
MAINT MODE	Displays the current operating mode of the transmitter (<i>maintenance mode or normal mode</i>).	<p>MAINT MODE / NORMAL MODE</p> <p>Blinking message to indicate that the maintenance mode is operating</p>
SERIAL	Displays the current remote control mode of the transmitter.	<p>SERIAL / PARALLEL</p> <p><u>SERIAL</u> : Remote control through a RS432/485 serial link.</p> <p><u>PARALLEL</u> (Remote controls and indicators): Remote control through hard wired connections.</p>

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
HIGH	Indicates a higher value than the high alarm threshold value.	<u>Flashes</u> if the transmitted power exceeds the maximum power threshold value. <u>Otherwise</u> not visible. The alarm threshold is set using the «RF THRESHOLD» window.
FWC (%) 12345	Displays the transmitted RF power value	This value is expressed in watts or as a percentage of the calibrated power value according with your installation choice
LOW	Indicates a lower value than the low alarm threshold value.	<u>Flashes</u> if the transmitted power is lower than the minimum power threshold value. <u>Otherwise</u> not visible. The alarm threshold is set using the «RF THRESHOLD» window.
HIGH	Indicates a higher value than the threshold value.	<u>Flashes</u> if the reflected power (reverse power) exceeds 3% of calibrated power <u>Otherwise</u> not visible. The threshold value (3%) is unchanging
REFL (%) 1234.5	Displays the reflected power value	This value is expressed in watts or as a percentage of calibrated power value according with your installation choice
FOLDBACK DISABLED INACTIVE	To indicate the reflected (reserve) power control mode.	FOLDBACK ENABLED: When the reflected power value is higher than the threshold value (3%) the power control is progressively produce through an algorithm. FOLDBACK DISABLED: When the reflected power value is higher than the threshold value (3%) the power control is produce by stairway (-3dB, -6dB and halt 'no power')
EXC A	Indicates the exciter selected. (*)	EXC A / EXC B

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
<div>CH-OVER</div> <div>AUTO</div> <div>READY</div>	<p>To indicate the exciter changeover mode (Upper indicator).</p> <p>To indicate the exciter changeover status in automatic mode (Lower indicator).(*)</p>	<p>Upper indicator</p> <p>CH-OVER MAN (Manual) : only when operator gives a command.</p> <p>CH-OVER AUTO : automatic changeover when the selected exciter is faulty.</p> <p>Lower indicator</p> <p>CH OVER DONE / CH OVER NOT DONE / CH OVER IMPOSSIBLE</p> <p>READY : the changeover system is ready for an automatic switch over.</p> <p>DONE : the changeover system is no longer available and it is necessary to change the exciter selected or to carry out a transmitter "RESET" (in this latter case, care must be taken because fault data for all faults which have disappeared will be erased together with their consequences; similarly for all selections carried out on the PCL).</p> <p>IMPOSS : an attempt to carry out an automatic changeover has failed.</p>

(*) : Only in Dual Drive Version

2.1.5. "STATUS" window

This window is called up by pressing the "NEXT STATUS" control keys in the "TRANSMITTER STATUS" window.

It provides access to commands and information which are only available in the "STATUS" window.

OPTIMUM FAMILY OR ULTIMATE FAMILY




Figure 10 : PCL UNLOCKED (ENABLED)




Figure 11 : PCL LOCKED

AFFINTY FAMILY




Figure 12 : PCL UNLOCKED (ENABLED)
















Figure 13 : PCL LOCKED

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
<div>STATUS</div> <div>LOCK CMD / CMD LOCKED</div>	<p>Calls up the "GO HOME AND VIEW INSTALLATION PARAMETERS" window.</p> <p>Locks (disables) the local control panel (P).</p> <p>Displays whether the CMD is locked or unlocked.</p>	<p>LOCK CMD / CMD LOCKED</p> <p>When the CMD is locked, operator commands from the PCL have no effect on the system.</p>

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
 / 	Calls up the "NUMERICAL VALUE" window or the "IDENTIFICATION" window.	PASS / IDENT IDENT: The "IDENTIFICATION" window displays software references for the screen and CPU card ; this function is available when the touch screen is unlocked. UNLOCK: Operation is realized in accordance with your installation choice (<i>PASSWORD DISABLE, or ENABLE</i>) <ul style="list-style-type: none"> Pressing this control Key, the PCL is automatically unlocked or, A password can be entered using the "NUMERICAL VALUE" window while the PCL is unlocked.
	Calls up the "CONTOL Level 1" window.	
	Calls up the "EXCITER Level 1" window.	
	Calls up the "AMPLIFIERS" window. . (a)	
	Calls up the "INTLOCK" window. . (a)	
	Calls up the "POWER SUPPLY" window. (a)	
	Calls up the "AFFINITY" window. (b)	
	Calls up the "TRANSMITTER STATUS" window.	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families


MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
	Gives the window name.	
	Last indicated faults.	This window displays the last three faults which have been indicated.
	Displays the current operating mode of the transmitter (<i>maintenance mode or normal mode</i>).	MAINT MODE / NORMAL MODE Blinking message to indicate that the maintenance mode is operating

2.1.6. "IDENTIFICATION" window


This window is called up by pressing the "IDENT" control keys in the "STATUS" window. This window is only accessible when the touch screen is unlocked with the "LOCK CMD / CMD LOCKED" control keys in the "STATUS" window.

It displays software references for the touch screens, the CPU card and EXCITER units.

OPTIMUM FAMILY OR ULTIMATE FAMILY



AFFINTY FAMILY



CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
IDENT NEXT	Calls up the "MODULATOR IDENTIFICATION" window.	
STATUS	Calls up the "STATUS" window.	
CONTROL	Calls up the "CONTROL Level 1" window.	
EXCITER	Calls up the "EXCITER Level 1" window.	
AMPLI	Calls up the "AMPLIFIERS" window. . (a)	
INTLOCK	Calls up the «INTERLOCK» window . (a)	
PSUPPLY	Calls up the "POWER SUPPLY" window. . (a)	
AFFIN.	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

INDICATOR LAMPS AND MESSAGE DISPLAYS	FUNCTIONS	DISPLAY/COMMENTS
IDENTIFICATION	Gives the window name.	
CPU SOFTWARE 12345678	Displays the reference of the CPU board software.	
PROM 12345678	Displays the reference of the CPU board. PROM software	
SCREEN 12345678	Displays the reference of the touch screen and its software.	
EXC A 12345678	Displays the reference of the Main software for exciter A.	♦ Digital Transmitter, MODAP Version only: With oldest DAP software this message displays could be absent
EXC B 12345678	Displays the reference of the Main software for exciter B. (*)	♦ Analogue Transmitter With the analogue driver, this message displays is not used

(*) : Only in Double Drive Version

2.1.7. "MODULATOR IDENTIFICATION, Type I" window

This window is called up by pressing the "IDENT NEXT" control keys in the "IDENTIFICATION" window. It is only accessible when the touch screen is unlocked with the "LOCK CMD / CMD LOCKED" control keys in the "STATUS" window.

This window displays software references for the MODULATOR unit. It is only available with TANGBERG MODULATOR unit (MODAP version only).

OPTIMUM FAMILY OR ULTIMATE FAMILY

MODULATOR IDENTIFICATION			
MODULE IDENTITY	SCFT VER N°	EXC A	
123	12.34	OTHER EXCITER	
HKE VER N°	FIRM VER N°	IDENT PREV	
123	12.34	STATUS	
CONTROL	EXCITER	AMPLI	INTLOCK
PSUPPLY			

AFFINTY FAMILY

IDENTIFICATION			
CPU SOFTWARE		12345678	
PROM	SCREEN	IDENT NEXT	
12345678	12345678	STATUS	
DAP A	DAP B	AFFIN.	
12345678	12345678		
CONTROL	EXCITER		

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
IDENT PREV	Calls up the "IDENTIFICATION" window.	
STATUS	Calls up the "STATUS" window.	
CONTROL	Calls up the "CONTROL Level 1" window.	
EXCITER	Calls up the "EXCITER Level 1" window.	
AMPLI	Calls up the "AMPLIFIERS" window. (a)	
INTLOCK	Calls up the «INTERLOCK» window (a)	
PSUPPLY	Calls up the "POWER SUPPLY" window. (a)	
AFFIN.	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

INDICATOR LAMPS AND MESSAGE DISPLAYS	FUNCTIONS	DISPLAY/COMMENTS
OTHER EXCITER	Calls up data from the other exciter. (*)	
MODULATOR IDENTIFICATION	Gives the window name.	
MODULE IDENTITY 123	Displays the ID number of the module.	
SCFT VER N° 12.34	Displays the reference of the Internal COFDM MODULATOR software.	
HMC VER N° 123	Displays the reference of the internal COFDM MODULATOR hardware.	
FIRM VER N° 12.34	Displays the reference of the internal COFDM MODULATOR firmware.	
EXC A	Indicates which exciter data are displayed. (*)	EXC A / EXC B

(*) : Only in Double Drive Version


2.1.8. "MODULATOR IDENTIFICATION, type II" window

This window is called up by pressing the "IDENT NEXT" control keys in the "IDENTIFICATION" window. It is only accessible when the touch screen is unlocked with the "LOCK CMD / CMD LOCKED" control keys in the "STATUS" window.


This window displays software references for the type II MODULATOR unit or for the SIRIUS MODULATOR unit.

It is only available with type II MODULATOR unit "ACBB" (MODAP version) or with SIRIUS MODULATOR unit.

OPTIMUM FAMILY OR ULTIMATE FAMILY



AFFINTY FAMILY



CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
IDENT PREV	Calls up the "IDENTIFICATION" window.	
STATUS	Calls up the "STATUS" window.	
CONTROL	Calls up the "CONTROL Level 1" window.	
EXCITER	Calls up the "EXCITER Level 1" window.	
AMPLI	Calls up the "AMPLIFIERS" window. (a)	
INTLOCK	Calls up the «INTERLOCK» window . (a)	
PSUPPLY	Calls up the "POWER SUPPLY" window. (a)	
AFFIN.	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

INDICATOR LAMPS AND MESSAGE DISPLAYS	FUNCTIONS	DISPLAY/COMMENTS
OTHER EXCITER	Calls up data from the other exciter. (*)	
MODULATOR IDENTIFICATION	Gives the window name.	
APPLICATION 12345678	Displays the reference of the internal COFDM ACBB MODULATOR software.	
ECCI 12345678	Displays the reference of the Boot software.	
LINUX 12345678	Displays the reference of the LINUX software.	
FPGA 1 12345678	Displays the reference of the FPGA 1 software.	
FPGA 2 12345678	Displays the reference of the FPGA 2 software.	
EXC A	Indicates which exciter data are displayed. (*)	EXC A / EXC B

(*) : Only in Double Drive Version

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2.1.9. "CONTROL Level 1" window

From other windows it can be called up by pressing the "CONTROL" key.

This window contains the commands available in maintenance mode and normal mode.

OPTIMUM FAMILY or ULTIMATE FAMILY – ANALOG TRANSMITTER




Figure 14: Dual Drive Transmitter




Figure 15: Single Drive Transmitter

OPTIMUM FAMILY or ULTIMATE FAMILY – DIGITAL TRANSMITTER




Figure 16: Dual Drive Transmitter




Figure 17: Single Drive Transmitter

AFFINTY FAMILY – DIGITAL TRANSMITTER




Figure 18: Dual Drive Transmitter

















Figure 19: Single Drive Transmitter

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
	Selects local or remote user interface.	The command is not available if the PCL is locked. Selecting remote user interface locks the following control keyss: CTRL, STDBY, MODE, EXCITER
 Only in Double Drive Version	Initiates shutdown or start-up of the reserve exciter.	Command is disabled while the PCL is locked (disabled).
 Only in Analogue Transmitter	Selects the transmitter on-air/off-air switching mode (manual or automatic)	Command is disabled while the PCL is locked (disabled)
	Selects the transmitter-operating mode (maintenance or normal).	Command is disabled while the PCL is locked (disabled).
	Validates a selection.	
	Cancels a selection.	
	Calls up the "TRANSMITTER STATUS" window.	
	Calls up windows as follows: "CONTROL MAINT Level 2", if the system is in maintenance mode, "CONTROL OPER Level 2", if the system is in normal mode.	
	Calls up the "EXCITER Level 1" window.	
	Calls up the "AMPLIFIERS" window. (a)	
	Calls up the "INTLOCK" window. (a)	
	Calls up the "POWER SUPPLY" window. (a)	
	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
SERIAL	Displays the current remote control mode of the transmitter.	SERIAL / PARALL SERIAL : Remote control through a RS432/485 serial link. PARALL (Remote controls and indicators): Remote control through hard wired connections.
LOCAL	Displays the selected user interface.	REMOTE / LOCAL REMOTE : Indicates a remote user interface. LOCAL : Indicates Local Control Panel. Only commands from the selected user interface will be operative. Flashes until the "CTRL" command is either validated or cleared.
ON Only in Double Drive Version	Displays the status (on or off) of the reserve exciter.	OFF / ON Flashes until the "STDBY" command is either validated or cleared.
AUTO Only in Analogue Transmitter	Displays the on-air/off-air switching mode selected	MANUAL, AUTO Flashes until the «START» command is either validated or cleared
NORMAL / MAINT	Displays the current operating mode of the transmitter (maintenance mode or normal mode).	NORMAL / MAINT Flashes until the "MODE" command is either validated or cleared.

Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

2.1.10. "CONTROL MAINT Level 2" window for Maintenance mode

This window is called up by pressing the "NEXT CONTROL" control keys in the "CONTROL Level 1" window while the transmitter is in maintenance mode.

It provides access to commands and information which are only available in maintenance mode.

OPTIMUM FAMILY OR ULTIMATE FAMILY









MODIFY PASSWD	DATE	MODUL PARAM.	MAINT MODE
RF LEVEL	RF THRES	MISC PARAM.	MANUAL GAIN
HOURL COUNTER	QUALITY THRES	DVB-H PARAM.	LOGBOOK
			STATUS
CONTROL NEXT	EXCITER	AMPLI	INTLOCK PSUPPLY

AFFINTY FAMILY

MODIFY PASSWD	DATE	MODUL PARAM.	MAINT MODE
RF LEVEL	RF THRES	MISC PARAM.	MANUAL GAIN
HOURL COUNTER	QUALITY THRES		LOGBOOK
			STATUS
CONTROL NEXT	EXCITER		AFFIN.

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
MODIFY PASSWD	Calls up the "MODIFY PASSWORD" window (for changing the password).	This control key is available according to your installation choice (PASSWORD DISABLE, ENABLE) Control key visible in selection « PASSWORD ENABLE » only.
RF LEVEL	Calls up the "RF LEVEL" window.	
HOURL COUNTER	Calls up the "HOURL COUNTER" window.	
DATE	Calls up the "DATE & TIME" window.	
RF THRES	Calls up the "RF THRESHOLD" window.	
QUALITY THRES	Calls up the "QUALITY THRESHOLD SETTINGS" window.	
MODUL PARAM.	Calls up the "MODULATOR PARAMETERS" window.	
MISC PARAM.	Calls up the "MISCELLANEOUS" window.	
DVB-H PARAM.	Calls up the "DVB-H MODULATOR PARAMETERS" window.. (1)	The control key is according to your installation mode





Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
	Calls up the "LOGBOOK" window.	
	Calls up the "TRANSMITTER STATUS" window.	
	Calls up the "CONTROL MAINT Level 3" window.	
	Calls up the "EXCITER Level 1" window.	
	Calls up the "AMPLIFIERS" window. (a)	
	Calls up the «INTERLOCK» window (a)	
	Calls up the "POWER SUPPLY" window. (a)	
	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

(1): Visible for DVB-H transmitter only

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
 / 	Displays the current operating mode of the transmitter (<i>maintenance mode or normal mode</i>).	The "MAINT MODE" message window must be displayed.
 / 	Displays, which gain control mode (manual or automatic), is currently picked up by the transmitter.	Blinking message to indicate that the maintenance mode is operating MANUAL GAIN / AUTO GAIN

2.1.11. "CONTROL MAINT Level 3" window for Maintenance mode

This window is called up by pressing the "NEXT CONTROL" control keys in the "CONTROL MAINT Level 2" window while the transmitter is in maintenance mode.

It provides access to commands and information which are only available in maintenance mode.

OPTIMUM FAMILY OR ULTIMATE FAMILY








10 MHz INT	SHOULDER THRES (dB)	GROUP DELAY THRES (ns)
SYNTHE	123	1234
	RIFFLE THRES (dB)	
	12.34	
- FREQUENCY SYNTHE (Hz) +		
1234567890		
VALID CANCEL	MODE MAINT	STATUS
NEXT CONTROL	EXCITER	AMPLI INTLOCK PSUPPLY

AFFINTY FAMILY

10 MHz INT	SHOULDER THRES (dB)
SYNTHE	123
	RIFFLE THRES (dB)
	12.34
- FREQUENCY SYNTHE (Hz) +	
1234567890	
VALID CANCEL	MAINT MODE
NEXT CONTROL	EXCITER
	STATUS AFFIN.

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
SYNTHE	Selects the RF synthesiser alarm mode. Toggles between 10 MHz INT and 10MHz EXT	Flashes until the "SYNTHE" command is either validated or cleared. Commands are disabled while the PCL is locked (disabled).
- / +	Increments or decrements RF synthesiser frequency value.	Control keys are only invisible in SFN mode operation.
VALID	Validates a selection.	
CANCEL	Cancels a selection.	
SHOULDER THRES (dB) 123	Calls up the "NUMERICAL VALUE" window in which the shoulder threshold beyond which the exciter performs a correction can be changed. Displays last selection.	
RIFFLE THRES (dB) 12.34	Calls up the "NUMERICAL VALUE" window in which the ripple threshold beyond which the exciter performs a correction can be changed. Displays last selection.	
GROUP DELAY THRES (ns) 1234	Calls up the "NUMERICAL VALUE" window in which the group delay threshold beyond which the exciter performs a correction can be changed. (3) Displays last selection.	





Information contained in this document is confidential, is THOMSON property and cannot be disclosed in whatever form without prior written authorization of THOMSON.

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
	Calls up the "TRANSMITTER STATUS" window.	
	Calls up the "CONTROL Level 4" window.	
	Calls up the "EXCITER Level 1" window.	
	Calls up the "AMPLIFIERS" window. (a)	
	Calls up the «INTERLOCK» window (a)	
	Calls up the "POWER SUPPLY" window. (a)	
	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

(3): MediaFLO modulator only



MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
 / 	Displays the current operating mode of the transmitter (<i>maintenance mode or normal mode</i>).	The "NORMAL MODE" message window must be displayed. Blinking message to indicate that the maintenance mode is operating
	Displays the RF synthesiser alarm mode.	10 MHz INT, 10 MHz EXT
	Displays the RF synthesiser frequency value.	

2.1.12. "CONTROL MAINT Level 4" window for Maintenance mode (MODAP version ONLY)






This window is called up by pressing the "CONTROL NEXT" control keys in the "CONTROL MAINT Level 3" window while the transmitter is in maintenance mode.

It provides access to commands and information which are only available in maintenance mode.

NOTE: This windows is available in COFDM MODAP version only.






OPTIMUM FAMILY OR ULTIMATE FAMILY**AFFINTY FAMILY**

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
	Selects the type of correction performed by the OLDC card (Fixed or Adaptive).	Command is disabled while the PCL is locked (disabled). In fixed position, the OLDC correction parameters are not continuously adjusted.
	Cancels a selection.	
	Validates a selection.	
	Calls up the "NUMERICAL VALUE" window in which the I/Q amplitude error threshold beyond which the OLDC card performs a correction can be changed. Displays last selection.	Command is disabled while the PCL is locked (disabled).
	Calls up the "NUMERICAL VALUE" window in which the central frequency rejection threshold beyond which the OLDC card performs a correction can be changed. Displays last selection.	Command is disabled while the PCL is locked (disabled).
	Calls up the "TRANSMITTER STATUS" window.	
	Calls up the "CONTROL Level 1" window.	

CONTROL KEYS	FUNCTIONS	DISPLAY/COMMENTS
	Calls up the "EXCITER Level 1" window.	
	Calls up the "AMPLIFIERS" window. (a)	
	Calls up the «INTERLOCK» window (a)	
	Calls up the "POWER SUPPLY" window. (a)	
	Calls up the "AFFINITY" window. (b)	

(a): Not Visible for AFFINITY family

(b): Not Visible for OPTIMUM or ULTIMATE families

MESSAGE	FUNCTIONS	DISPLAY/COMMENTS
	Displays whether a Double ASI input is present or absent in the MODAP unit.	DASI NOT FITTED / DASI FITTED
	Displays whether an OLDC unit is present or absent.	OLDC FITTED / OLDC NOT FITTED
	Displays the type of correction (fixed or adaptive) performed by the OLDC unit. Displays last selection.	ADAPTIVE / FIXED In fixed position, the OLDC correction parameters are not continuously adjusted.
 / 	Displays the current operating mode of the transmitter (<i>maintenance mode or normal mode</i>).	The "MAINT MODE" message window must be displayed. Blinking message to indicate that the maintenance mode is operating