

ESTEEM USERS MANUAL

for

MODELS 192S

Firmware Versions 1.39 and above.

February 1999

Electronic Systems Technology (EST) copyrights this manual and the firmware described in it, with all rights reserved. Under the copyright laws, this manual or the firmware internal to the ESTeem unit may not be copied, in whole or part, without the written consent of EST. Under the law, copying includes translating into another language.

EST cannot guarantee that you will receive notice of a revision to the firmware described in the manual, even if you have returned a registration/warranty card received with the product. You should periodically check with your authorized EST dealer or call factory direct.

EST and the EST logo are registered trademarks of Electronic Systems Technology, Inc. Simultaneously published in the United States and Canada. All rights reserved.

PRODUCT WARRANTY

Electronic Systems Technology, Inc., (hereinafter EST) expressly warrants its products as free of manufacturing defects for a period of one year from the date of sale to first user/customer.

THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED AND THERE IS EXPRESSLY EXCLUDED ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO OTHER WARRANTY GIVEN BY ANY EMPLOYEE, AGENT, DISTRIBUTOR OR OTHER PERSON WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON EST.

LIMITATION OF LIABILITY:

EST's liability shall be limited to refunding of purchase price, repair or replacement of product.

IN NO EVENT SHALL EST HAVE LIABILITY FOR CONSEQUENTIAL, INCIDENTAL, SPECIAL OR EXEMPLARY DAMAGES CAUSED DIRECTLY OR INDIRECTLY BY THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY INTERRUPTION OF SERVICES, LOSS OF BUSINESS OR ANTICIPATORY PROFITS. IN NO EVENT SHALL EST BE LIABLE FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT.

In the event that a unit or part requires replacement or factory servicing, the following conditions apply:

- a) Customer must obtain from EST an authorized RMA (Return Materials Authorization) number (call 509-735-9092 Customer Support) before shipment of product or parts to EST for any reason;
- b) If the whole unit is shipped, it must be in its original carton and shipping components, or a carton and shipping components supplied by EST, or if parts only are shipped, they must be packaged and cushioned so as to prevent damage in transit and shipped freight prepaid;

PRODUCT WILL BE CONSIDERED OUT OF WARRANTY IF:

- a) If the product is damaged due to improper or abnormal use, abuse, mishandling, accident or improper maintenance or failure to follow operating instruction;
- b) If the product is defective as a result of sand, dirt, or water damage;
- c) If any factory-sealed enclosure has been opened or shows evidence of an attempt to be opened;
- d) If defects or damage are caused by the use of unauthorized parts or unauthorized service;
- e) If the product has had its serial numbers altered or removed.

Warranty repair form must be accompanied by proof of user's purchase of unit. Product must be shipped to the manufacturer at the following address:

Electronic Systems Technology
415 North Quay Street
Kennewick, Washington USA 99336

ADDITIONAL SERVICE:

If EST releases an improvement update to firmware internal to the ESTeem unit during the 90 day period after the unit was purchased by the first user/customer, EST will update the applicable unit with the revised version at no charge other than for UPS handling and shipping to and from your location to the EST factory. Return of any such item must be accompanied with proof of purchase.

TABLE OF CONTENTS

CHAPTER 1 - STARTING OUT

Before You Start	1-2
ESTeem Utility.....	1-2
Installing ESTeem Utility Software – Windows 95/98/NT	1-2
Running The Program	1-2
Starting Out	1-2
Basic ESTeem Programming	1-5
Help Functions	1-5
Saving a Program	1-5
Restoring Factory Defaults.....	1-5

CHAPTER 2 - MODES OF OPERATION

Command Mode.....	2-2
Converse Mode	2-2
Transparent Mode	2-3
Semi-Transparent Mode.....	2-3
Hardware Mode Control.....	2-3

CHAPTER 3 - PROGRAMMING ESTEEM FEATURES

Digi-Repeating Feature	3-2
Global Broadcast Feature.....	3-2
Auto Transmit Feature.....	3-3
Auto Connect Feature.....	3-3
Multi-Connect Feature	3-3
Remote Programming Feature.....	3-4

Security Feature	3-4
Hardware Ring Line.....	3-4
Packet Monitor Feature.....	3-5
Using The Infrared Communications Port	3-5
Using The Phone Communications Port	3-6

CHAPTER 4 - ESTEEM APPLICATION PROGRAMS

Transparent Auto-Connect.....	4-2
Transparent Auto-Connect Global	4-2
Interactive Terminal Applications.....	4-3
Programmable Logic Controllers.....	4-3

CHAPTER 5 - RS-232C/422/485 INTERFACING

DTE vs DCE	5-2
Flow Control.....	5-2
Memory Buffers.....	5-3
Data Terminal Ready	5-3
RS-422/485 Configuration.....	5-3
RS-232/422/485 Port Pin-out Table.....	5-4

CHAPTER 6 - ANTENNAS

Antenna and Cable Configurations	6-2
Weather Proofing Coaxial Connectors.....	6-2
Grounding	6-2
Lightning Arrestors	6-2

TABLE OF CONTENTS

CHAPTER 6 – ANTENNAS (continued)

Model 192S Typical Outdoor Antenna Installation Diagram	6-3
Model 192S Typical Indoor Antenna Installation Diagram	6-4
ESTeem SWR Measurements Block Diagram	6-5

CHAPTER 7 - THEORY OF OPERATION

Introduction	7-2
ESTeem How It Works	7-2
Spectrum Utilization	7-3
Packet Protocols	7-3
Flow Control	7-3
Data Privacy	7-3
Effective Baud Rate	7-3

APPENDICES

Appendix A - FCC Licensing

(USA only)	APX A-2
------------------	---------

Appendix B - Specifications

ESTeem Specifications	APX B-1
Model 192S Antenna Specifications	APX B-2

Appendix C - Tables/Diagrams

ESTeem Command Error Message Table	APX C-1
ESTeem System Status Message Table	APX C-2
ESTeem System Error Message Table	APX C-3

Appendix D - ESTeem Software Commands

Factory Default Settings	APX D-1
Definitions	APX D-2