Scan the QR code for support information

VG134

VG134

IMPORTANT SAFETY INSTRUCTIONS

fire, electric shock and injury, including the following:

. Read and understand all instructions

or in a wet basement or show

stand or other unstable surfaces

product

for cleaning.

above 2 meters

and fumes.

provided.

When using your telephone equipment, basic safety

precautions should always be followed to reduce the risk of

. Follow all warnings and instructions marked on the

Unplug this product from the wall outlet before cleaning

4. CAUTION: Do not install the telephone base at a height

. Do not use this product near water such as near a bath tub.

wash bowl, kitchen sink, laundry tub or a swimming pool,

. Do not place this product on an unstable table, shelf,

Avoid placing the telephone system in places with extreme

emperature, direct sunlight, or other electrical devices.

Protect your phone from moisture, dust, corrosive liquids

. Slots and openings in the back or bottom of the telephone

base and handset are provided for ventilation. To protect

nem from overheating, these openings must not be

blocked by placing the product on a soft surface such as

a bed, sofa or rug. This product should never be placed

near or over a radiator or heat register. This product shou

not be placed in any area where proper ventilation is not

. This product should be operated only from the type of

power source indicated on the marking label. If you are

LO. Do not allow anything to rest on the power cord. Do not

install this product where the cord may be walked on.

Never push objects of any kind into this product through

the slots in the telephone base or handset because they

may touch dangerous voltage points or create a short

To reduce the risk of electric shock, do not disassemble

this product, but take it to an authorized service facility.

Opening or removing parts of the telephone base or

handset other than specified access doors may expose

you to dangerous voltages or other risks. Incorrec

L3. Do not overload wall outlets and extension cords

If liquid has been spilled onto the product

base and/or handset has been damaged

If the product has been exposed to rain or water

14. Unplug this product from the wall outlet and refer

is subsequently used.

following conditions

ŻŻ

eassembling can cause electric shock when the product

servicing to an authorized service facility under the

• When the power supply cord or plug is damaged or

• If the product does not operate normally by following

the operating instructions. Adjust only those controls

that are covered by the operation instructions. Improper

adjustment of other controls may result in damage

and often requires extensive work by an authorized

If the product has been dropped and the telephone

If the product exhibits a distinct change in performance.

technician to restore the product to normal operation

circuit. Never spill liquid of any kind on the product

office, consult your dealer or local power company

not sure of the type of power supply in your home or

Do not use liquid or aerosol cleaners. Use a damp cloth

(CA)

(US)







WHAT'S IN THE BOX

VG134

 $\mathbf{\mathbf{x}}$

VG134-1

vtech

Abridged user's manual

Avoid using a telephone (other than cordless) during an

electrical storm. There is a remote risk of electric shock

vicinity of the leak. Under certain circumstances, a spark

may be created when the adapter is plugged into the

cradle. This is a common event associated with the

closing of any electrical circuit. The user should no

plug the phone into a power outlet, and should not

put a charged handset into the cradle, if the phone is

ocated in an environment containing concentration

is adequate ventilation. A spark in such an environment

could create a fire or explosion. Such environments

might include: medical use of oxygen without adequate

ventilation; industrial gases (cleaning solvents; gasoline

Only put the handset of your telephone next to your ear

in a vertical or floor mount position. The prongs are not

For pluggable equipment, the socket-outlet shall

be installed near the equipment and shall be easily

CAUTION: Use only the batteries indicated

wrong type of battery is used for the handset. Use only

Disposed of used batteries according to the instruction.

High or low extreme temperature during use,

Replacement of a battery with an incorrect type

Disposal of a battery into fire or a hot oven, or

Leaving a battery in an extremely high

A battery subjected to extremely low air pressure

Use only the adapter included with this product

22. The applied nameplate is located at the bottom or near

SAVE THESE INSTRUCTIONS

• Use only the battery provided or equivalent. To order a

www.vtechphones.com or call 1 (800) 595-9511. In

Canada, go to <u>phones.vtechcanada.com</u> or call

Do not dispose of the battery in a fire. Check with

local waste management codes for special disposal

Incorrect adapter polarity or voltage can seriously

that can result in an explosion or the leakage of

temperature surrounding environment that can result in an explosion or the leakage of flammable

mechanically crushing or cutting of a battery, that

in this manual. There may be a risk of explosion if a

the supplied rechargeable batteries or replacement

not dispose of batteries in a fire. They may explode.

batteries (BT162342/BT262342) for the handset. Do

• Do not use the battery in following conditions:

torage or transportatior

can result in an explosion.

ammable liquid or gas.

acement, visit our website at

VGI34-X_US-CAN_ACIB_V1.0_230926

© 2023 VTech Technologies Canada Ltd. © 2023 Vrech Technologies Canada Ltd.

Specifications are subject to change without notice.

© 2023 VTech Communications, Inc. |

liquid or gas.

damage the product

of the product

1 (800) 267-737

instructions.

Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective

bdvanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by

Viech product news.

teater and the termination of termination

VTech product news.

product for enhanced warranty support and latest

Co to Www.vtechphones.com (US) to register your

that can defeat a safeguard.

designed to hold the plug in place if it is plugged into a

18. The power adapter is intended to be correctly oriented

vapors; etc.); a leak of natural gas; etc.

ceiling, under-the-table or cabinet outlet.


when it is in normal talk mode

of flammable or flame-supporting gases, unless there

power outlet, or when the handset is replaced in its

16. Do not use the telephone to report a gas leak in the

from lightning.



Do not open or mutilate the battery. Released

a short circuit with conductive material

specified in this manual.

elephones)

Pacemaker patients

the pacemaker.

irned ON

the pacemake

elephones.

battery charger.

ABOUT CORDLESS TELEPHONES

electrolyte is corrosive and may cause burns or injur

Exercise care in handling batteries in order not to create

to the eyes or skin. The electrolyte may be toxic if

Charge the battery provided with this product only

in accordance with the instructions and limitations

Wireless Technology Research, LLC (WTR), an independer

research entity, led a multidisciplinary evaluation of the

nterference between portable wireless telephones and

and Drug Administration, WTR recommends to physicians

Should NOT place wireless telephones directly over

the pacemaker, such as in a breast pocket, when it is

Should use the wireless telephone at the ear opposite

WTR's evaluation did not identify any risk to bystanders with

pacemakers from other persons using wireless telephones

elephone calls are transmitted between the telephone

onversations could be intercepted by radio receiving

his reason, you should not think of cordless telephone

conversations as being as private as those on corded

telephone must be connected to a working electrical

outlet. The electrical outlet should not be controlled by

handset if the telephone base is unplugged, switched

a wall switch. Calls cannot be made from the cordless

Potential TV interference: Some cordless telephones

perate at frequencies that may cause interference

to televisions and VCRs. To minimize or prevent such

interference, do not place the telephone base of the

ordless telephone near or on top of a TV or VCR.

If interference is experienced, moving the cordle

telephone farther away from the TV or VCR often

Rechargeable batteries: Exercise care in handling

batteries in order not to create a short circuit with

onducting material such as rings, bracelets and keys

The battery or conductor may overheat and cause harn

Observe proper polarity between the battery and the

Nickel-metal hydride rechargeable batteries: Dispose

incture the battery. Like other batteries of this type

. Search for or review the phonebook entries

2. When the desired entry displays, press SELECT.

3. Use the dialing keys to edit the number, then

4. Use the dialing keys to edit the name, then

1. Search for or review the phonebook entries

2. When the desired entry appears, press TALK or

If you subscribe to caller ID service, information

second ring. If you answer a call before the caller

The caller ID log stores up to 30 entries. Each entry

has up to 24 digits for the phone number and 15

If the telephone number has more that 15 digits,

shown and saved in the caller ID log.

only the last 15 digits appear. If the name has more

than 15 characters, only the first 15 characters are

information appears on the screen, it will not be

about each caller appears after the first or

(see Review a phonebook entry).

(see Review a phonebook entry).

of these batteries in a safe manner. Do not burn or

f burned or punctured, they could release caustic

material which could cause injury.

Edit a phonebook entry

Dial a phonebook entry

saved in the caller ID log.

characters for the name.

press SELECT.

press SELECT.

■)) to dial.

CALLER ID

duces or eliminates the interference

off or if the electrical power is interrupted.

Electrical power: The telephone base of this cordless

equipment within range of the cordless handset. For

Privacy: The same features that make a cordless

elephone convenient create some limitations

base and the cordless handset by radio waves, so


there is a possibility that the cordless telephone

nplanted cardiac pacemakers. Supported by the U.S. Food

Should keep wireless telephones at least six inches from

Precautions for users of implanted cardiac pacemakers

Cardiac pacemakers (applies only to digital cordless



Telephone base

1 – IN USE light

- VOL+/VOL·

3 – X (DELETE)

- • (SKIP)

- ►/■ (PLAY/STOP)

Play messages

- **(REPEAT**)

4 – Message window

5 – ANS ON

5 – FIND HS

7 – Charging pole

Missed call indicator

headset is in use.

• Flashes when there is an incoming call, or

• Flashes quickly when pairing to a Bluetooth

• On when the telephone is in use, or the

• Adjust the telephone base ringer volume.

Press twice to delete all old messages

Press twice to play the previous message.

• Turn on or off the answering system.

• Page all system handsets.

Review a caller ID log entry

. Press **CID** when the phone is not in use.

2. Scroll to browse through the caller ID log.

When there are calls that have not been reviewed

in the caller ID log, the handset displays XX missed

Each time you review a caller ID log entry marked

NEW, the number of missed calls decreases by

When you have reviewed all the missed calls, the

missed call indicator no longer displays.

entries are then considered old.

Dial a caller ID log entry

■)) to dial.

If you do not want to review the missed calls

one by one, press and hold CANCEL on the idle

handset to erase the missed call indicator. All the

1. Search for or review the caller ID log entries

When the desired entry appears, press TALK or

(see Review a caller ID log entry).

answering system is answering a call.

• Adjust the listening volume.

• Delete the playing message.

• Skip to the next message.

Stop playing messages

Repeat a message

• Flashes slowly when the connected Bluetooth

another telephone sharing the same line is in

(1)2

Handset

- 1 LCD display
- 2 🖾 / VOL 🛦
- in use.

- 3-MENU/SELECT
- · Show the menu • While in a menu, press to select an item, or save an entry or setting.
- 4-OFF/CANCEL
- Hang up a call.
- Return to the previous menu or exit completely without making changes Delete digits while predialing.
- Silence the handset ringer temporarily while the phone is ringing. • <u>Press and hold</u> to erase the missed call indicator

- while the handset is not in use 5 – # Show other dialing options when reviewing a

- 7-MUTE/DELETE
- Mute the microphone during a call • Silence the handset ringer temporarily while the phone is ringing. · Delete the displayed entry while reviewing the phonebook, caller ID log, or redial list.
- Delete digits or characters when entering numbers or name

- press SELECT.

twice.

INSTALL AND CONNECT

Setup Install the battery Connect and charge Mount (optional) THIS SIDE U 2 Connect the telephone base and charger time. If you subscribe to digital subscriber line (DSL) high-speed Internet service Date and time through your telephone line, make sure **'** you connect a DSL filter (not included) to the telephone wall jack. to set the date and time SELECT 503 choose AM or PM 3. Press SELECT to save. <u>}</u> ê

- · Review the phonebook when the phone is not · Scroll up while in a menu, or in the phonebook,
- caller ID log or redial list • Move the cursor to the right when entering numbers or names
- Increase the listening volume during a call.

- caller ID log entry
- 6-REDIAL/PAUSE Review the redial list.
- Insert a dialing pause while dialing or entering numbers into the phonebook

Save a caller ID log entry to the phonebook . Search for or review the caller ID log entries (see Review a caller ID log entry).

- 2. When the desired caller ID log entry displays, 3. Use the dialing keys to edit the number, if
- necessary. Then press SELECT. 4. Use the dialing keys to edit the name, if necessary. Then press SELECT.

Delete the caller ID log entries

- 1. Search for or review the caller ID log entries (see Review a caller ID log entry). 2. When the desired caller ID log entry displays, press DELETE.
- To delete all caller ID log entries:
- 1. Press MENU when the phone is not in use. 2. Scroll to Caller ID log and then press SELECT. 3. Scroll to **Del all calls** and then press **SELECT**

- Review the caller ID log when the telephone is not in use.
- · Scroll down while in a menu, or in the phonebook, caller ID log or redial list
- · Move the cursor to the left when entering numbers or names Decrease the listening volume during a call.
- 9 🛰 TALK/FLASH

8 – CID / VOL

Make or answer a call

- Answer an incoming call when you receive a call waiting alert.
- 10 - Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the phonebo
- 11 TONE 🗙
- Switch to tone dialing temporarily during a call. 12 – 《》 • Make or answer a call using the handset
- speakerphone • During a call, press to switch between the
- phone and the handset earpiece. 13 – OPER 🛈
- Press to add a space when entering names Charger

1 – Charging pole

Display icons

Û	The battery icon flashes when the battery is low and needs charging.
	The battery icon animates when the battery is charging.
	The battery icon becomes solid when the battery is fully charged.
Ø	The handset ringer is turned off.
X	There are new voicemail received from your telephone service provider.
NEW	The entry you are reviewing is new in the caller ID log.
ANS ON	The answering system is turned on.
MSG #	The message number currently playing and the total number of messages.

Sound settings

Key tone

- You can turn the key tone on or off.
- 1. Press **MENU** when the handset is not in use.
- 2. Scroll to **Settings** and then press **SELECT**. 3. Scroll to choose Key tone, then press SELECT.
- 4. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **On** or **Off**, then press SELECT to save.

Ringer tone

- You can choose from different ringer tones for
- each handset. 1. Press **MENU** when the handset is not in use.
- 2. Scroll to **Ringers** and then press **SELECT**.
- 3. Scroll to choose **Ringer tone**, then press
- 4. Press $\mathbf{\nabla}$ or \mathbf{A} to sample each ringer tone, then press **SELECT** to save.
- NOTE: If you turn off the ringer volume, you will not bear ringer to:

TELEPHONE OPERATIONS



Use the handset menu

- 1. Press **MENU** when the phone is not in use.
- 2. Press $\mathbf{\nabla}$ or \mathbf{A} until the screen displays the
- desired feature menu
- 3. Press SELECT
- Press CANCEL to return to the previous menu.
- · Press and hold CANCEL to exit completely.

Make a call

- Press TALK or 🔍, and then dial the telephone number
- Answer a call • Press TALK, ■) or any dialing keys.

End a call

• Press OFF or put the handset back in the telephone base or charger

Speakerphone

During a call, press \P on the handset to switch between speakerphone and handset earpiece.

Volume

• During a call, press VOL▲and VOL▼ to adjust the listening volume.

Mute

- The mute function allows you to hear the other party but the other party cannot hear you
- 1. During a call, press MUTE. The handset displays
- Muted. 2. Press MUTE again to resume the conversation The handset displays Microphone on briefly.

Ringer volume

You can adjust the handset ringer volume level, or turn the ringer off.

- 1. Press **MENU** when the handset is not in use.
- 2. Scroll to **Ringers** and then press **SELECT**.
- Scroll to Ringer volume and then press SELECT. 4. Press \blacksquare or \blacktriangle to choose a volume level or choose Volume:Off. A sample of each ringer
- volume plays as you scroll through the choices. 5. Press SELECT to save.

- If you turn off the volume, the handset will be silenced and display <u>X</u> icon.
- When the ringer volume is set to Off, the handset still rings when you press FIND HS at the telephone base.

Temporary ringer silencing

When the telephone is ringing, you can temporarily silence the ringer without disconnecting the call. The next call rings normally at the preset volume.

- To silence the handset ringer:
- Press CANCEL or MUTE. The handset displays **Ringer muted** and \underline{X} .

Join a call in progress (for two-handset models only)

You can use up to two handsets at a time on an outside call.

- When a handset is already on a call, press TALK or \blacksquare) on another handset to join the call.
- To exit the call, press **OFF** on the handset or place it in the telephone base or charger. The call continues until all handsets hang up.

Call waiting

When you subscribe to call waiting service from your telephone service provider, you hear an alert tone if there is an incoming call while you are already on a call.

• Press FLASH to put the current call on hold and take the new call.

• Press FIND HS on the telephone base when not

in use. All idle handsets ring and display

• Press TALK, **S**, **OFF** or any dialing keys on the

· Place the handset in the telephone base or

NOTE: Do not press and hold FIND HS

for more than 4 seconds. It may lead to

• Press FLASH at any time to switch back and

Use this feature to find the system handset

Press FIND HS at the telephone base.

nandset deregistration.

calls with your Bluetooth headset.

Your telephone system is enhanced with

Bluetooth feature. You can pair a Bluetooth

headset to your telephone system and answer

Before you begin, make sure that your

to any other Bluetooth device.

Bluetooth enabled headset is not connected

Bluetooth wireless technology operates within

a short range (a maximum of approximately

For more details about the Bluetooth feature

L5 feet) from the telephone base. Keep

read the online Complete user's manual.

ABOUT THE BUILT-IN ANSWERING

SYSTEM AND VOICEMAIL SERVICE

For message recording, your telephone has a

built-in answering system, and it also supports

service provider (subscription is required, and fee

Messages are

erver or syst

your telephon

Your message

autómatically

deleted after a

period of time.

Contact your

telephone

provider for

more details

service

provided by

ervice

may be

provider.

stored in a

voicemail service offered by your telephone

The main differences between them are:

Messages are

stored in the

Your messages

will not be

automatically

You have to

delete your

messages

manually.

deleted

elephone base

connected headset within this range.

forth between calls

Find handset

To start paging

* Paging '

To end paging:

handset.

charger

BLUETOOTH[®]

NOTES:

may apply).

Storage

-OR-

-OR-

After the telephone is installed or power returns following a power outage and battery depletion the handset will prompt you to set the date and

When the handset prompts, follow the steps below

Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press

. Use the dialing keys (**0**-**9**) to enter the hour (**HH**) and minute (**MM**). Then press $\mathbf{\nabla}$ or \mathbf{A} to

> **NOTE**: If you have skipped the prompt, you can set up again by pressing MENU. Scroll to Set date/time, and press SELECT Then, follow the steps above

Pair and connect a Bluetooth headset

1. Set your Bluetooth headset to pairing mode. Refer to your Bluetooth headset user's manual

Press TALK or ■) on the handset.

to learn how

for 4 seconds

or charger.

You can

above.

REDIAL LIST

desired entry displays

Display When you

nessages,

the handse

flashes.

To retrieve

messages:

base: or

Access

3. Press TALK to dial.

entry.

new

message

Method

to retrieve

nessages

3. Press and hold FIND HS on the telephone base

• The telephone then enters pairing mode. The IN USE LED turns blue and flashes. • To cancel pairing, press **OFF** on the handset

or place the handset in the telephone base

Bluetooth headset connection status:

Pairing - while pairing to a Bluetooth headset, the IN USE LED flashes in blue quickly. **Connected** - when successfully paired and

connected to a Bluetooth headset, the IN USE LED becomes steady on in blue.

Bluetooth headset in use - when the

connected Bluetooth headset is in use, the **IN USE** LED flashes slowly in blue No connection - the IN USE LED turns off

> You can use your connected Bluetooth headset to answer calls or end the call.

If you fail to connect your Bluetooth headset to the telephone, re-try the pairing steps

While on a call using your Bluetooth headset, keep your headset closer to the telephone base (within 15 feet) and make sure that there are no physical obstacles such as large furniture or thick wall in between.

he Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced Americar elephones and its parent, VTech Holdings Limited, is under cense. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their

Each handset stores the last 5 telephone numbers dialed. When there are already 5 entries, the

oldest entry is deleted to make room for the new

Review and dial a redial list entry

1. Press **REDIAL** when the handset is not in use. 2. Press $\mathbf{\nabla}$, $\mathbf{\Delta}$ or **REDIAL** repeatedly until the

Change LCD language settings

You can select English, French, or Spanish to be used in all screen displays:

- 1. Press MENU when the handset is not in use. 2. Press $\mathbf{\nabla}$ or \mathbf{A} to scroll to **Settings** and then press SELECT
- 3. Press SELECT again to choose LCD language
- 4. Press ▼ or ▲ to choose English, Français or
- **Español**, and then press **SELECT** twice to save.



NOTE: If you accidentally set the LCD language to Spanish or French, press MENU and then enter *364# to change the handset LCD language back to English while the handset is not in use.

Delete a redial list entry

- 1. Search for or review the redial list entries (see Review and dial a redial list entry).
- 2. When the desired redial entry displays, press DELETE.

PHONEBOOK

The phonebook can store up to 30 entries, which are shared by all handsets. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.

Add a phonebook entry

- L. Enter the number when the phone is not in use. Press **MENU**, then go to Step 3.
- Press MENU when the phone is not in use. Scroll to Phonebook and then press SELECT Press SELECT again to choose Add contact. 2. Use the dialing keys to enter the number.
- -OR-Copy a number from the redial list by pressing **REDIAL** and then press $\mathbf{\nabla}$, \mathbf{A} or **REDIAL** repeatedly to select a number. Press SELECT to copy the number.
- 3. Press SELECT to move on to enter the name
- 4. Use the dialing keys to enter the name. Additional key presses show other characters of that particular key

5. Press SELECT to save.

- While entering names and numbers, you can:
- Press DELETE to backspace and erase a digit or characte
- Press and hold **DELETE** to erase the entire entry. Press $\mathbf{\nabla}$ or \mathbf{A} to move the cursor to the left or
- Press and hold PAUSE to insert a dialing pause
- for entering numbers only). Press 0 to add a space (for entering names

Review a phonebook entry

- Entries are sorted alphabetically
- 1. Press \mathfrak{P} when the phone is not in use.
- 2. Scroll to browse through the phonebook, or use the dialing keys to start a name search.

Delete a phonebook entry

- 1. Search for or review the phonebook entries
- (see Review a phonebook entry). 2. When the desired entry displays, press
- DELETE.
- 3. When the handset displays Delete contact?, press SELECT.

New message indication

When there are new messages in the built-in answering system, the handset displays **XX new** messages, and the message window on the telephone base flashes.

Message window display	Description
2	No messages.
ි (flashing)	After a power failutre, the number in the message window flashes to indicate that the date and time need to be set.
1-99	Total number of old messages and memos recorded. The current message number during old message playback.



Message window display	Description
ල - 9 9 (flashing)	 Total number of new messages and memos. The number flashes when there are new messages that have not been reviewed. Current message number during new message playback. After a power failure, the number in the message window flashes. Indicate that the date and time need to be set.
네 - 9 9 & F (alternating)	Memory is full. Messages must be deleted before new messages can be recorded.
1-8	The telephone base speaker volume level while adjusting.
[] = E.	The telephone base ringer level while adjusting.
	 The answering system is being programmed by a system handset. The answering system is answering a call or recording a memo or announcement. The answering system is being accessed remotely. The phonebook or caller ID log is being accessed by a system handset.

NEED HELP?

online FAQs.

online help.

For operations and guides to help you using your

telephone, and for the latest information and

supports, go and check the online help topics and

Use your smartphone or mobile device to access our

府建物

VG134 (US)

/G134 (CA)

Go to https://help.vtechphones.com/vg134 (US);

OR https://phones.vtechcanada.com/en/support/

general/manuals?model=vg134 (Canada)

• Scan the QR code on the right.

Launch the camera app or QR code

scanner app on your smartphone

or tablet. Hold the device's camera

up to the QR code and frame it.

- If the QR code is not clearly

displayed, adjust your camera's

focus by moving your device closer

You can also call our Customer

Support at 1 (800) 595-9511 [in US]

right or visit

<u>www.vtechphones.com/recycle</u>.

(For the US only)

you are done with it

Scan the QR code on the

🔻 Recycle this product when 🔳 🗺

or 1 (800) 267-7377 [in Canada] for

redirection of the online help.

or further away until it is clear.

Tap the notification to trigger the

TURN ON/ OFF THE ANSWERING SYSTEM

The answering system must be turned on to answer and record messages

When the answering system is turned on, the ANS **ON** light on the telephone base turns on and **ANS ON** displays on the handset.

Press **ANS ON** on the base to turn the answering system on or off. - OR -

- 1. Press **MENU** when the handset is not in use. 2. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Answering sys** and
- then press SELECT. 3. Press $\mathbf{\nabla}$ or $\mathbf{\Delta}$ to choose **Answer on/off** and
- then press SELECT. 4. Press ▼ or ▲ to choose On or Off, then press
- SELECT to save.

ANSWERING SYSTEM SETTINGS

Set your built-in answering system The answering system can record and store up to 99 messages. Each message can be up to 3 minutes in length. The total storage capacity for the announcement, messages and memos is approximately 14 minutes. The actual recording time depends on individual message characteristics. Messages remain available for replay until you delete them.

If the answering system has less than 3 minutes of recording time left, "Less than 3 minutes to record" is announced before the message playback and Rec mem low appears on the handset screen.

If the memory is full, the answering system announces, "Memory is full." The number of nessages and F flash, alternatively, in the message window, and **Rec mem full** appears on the handse screen. You must delete some messages before recording new ones.

Your answering system allows you to set your announcement, to save and delete messages activate call screening, to set number of rings before pick up, and to access remotely.

Voice language

NOTE: This feature is available in Canada version only.

The voice prompt language is preset to English You can select English or French to be used for the voice prompts in your answering system.

- 1. Press MENU when the handset is not in use. 2. Press ▼ or ▲ to choose **Answering sys** and
- then press SELECT. 3. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Ans sys setup** and then
- press SELECT. 4. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Voice language** and then press **SELECT**.
- 5. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **English** or **Français** and then press SELECT.

For C-UL compliance only

Mesures de sécurité importantes

- Afin de réduire les risques d'incendie, de blessures es ou d'électrocution, suivez toujours ces mesure préventives de base lorsque vous utilisez votre téléphone : Lisez et comprenez bien toutes les instructions.
- Observez toutes les instructions et mises en garde inscrites sur l'appareil Débranchez ce téléphone de la prise murale avant de le
- nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. V'utilisez qu'un chiffon doux et légèrement humecté. ATTENTION: Ne pas installer le socle téléphonique à une auteur supérieure à 2 mètres.
- N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la
- Ne déposez pas ce téléphone sur un chariot, suppor ou table chancelants. L'appareil pourrait tomber et être érieusement endommagé
- Évitez d'installer le système téléphonique dans les endroits soumis à une température extrême, à la lumière directe du soleil ou à proximité immédiate d'autres appareils électriques ou électroniques. Protégez votre téléphone contre les sources d'humidité, la poussière, les vapeurs e es liquides corrosif
- Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan apis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, ne l'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.
- Ne faites fonctionner cet appareil qu'avec le type 'alimentation indiqué sur les étiquettes de l'appareil Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité
- 10. Ne déposez rien sur le cordon d'alimentation. Installez cet appareil dans un endroit sécuritaire. là où personne ne pourra trébucher sur la ligne d'alimentation ni le cordon téléphonique modulaire.
- 11. N'insérez iamais d'obiets à travers les fentes et ouvertures de cet appareil, car ils pourraient toucher à des points de tension dangereux ou court-circuiter des pièces, ce ui constituerait un risque d'incendie ou d'électrocution 'échappez pas de liquides dans l'appareil.
- 12. Afin de réduire les risques d'électrocution, ne démontez pas l'appareil, mais apportez-le plutôt à un centre de ervice qualifié s'il doit être réparé. En enlevant le couvercle, vous vous exposez à des tensions dangereuse ou autres dangers similaires. Un remontage inadéguat peut être à l'origine d'une électrocution lors d'une itilisation ultérieure de l'appareil. Débranchez l'appareil avant de procéder au nettoyage. Utilisez un chiffon
- 13. Ne surchargez pas les prises de courant et les rallonges. 14. Débranchez cet appareil de la prise de courant et communiquez avec le département de service à la clientèle de VTech dans les cas suivants :
- Lorsque le cordon d'alimentation est endommagé ou
- Si du liquide a été échappé dans l'appareil • Si l'appareil a été exposé à une source d'humidité telle
- que la pluie ou l'eau. Si le produit ne fonctionne pas normalement en respectant les instructions de fonctionnement. Réglez uniquement les commandes indiquées dans le les uctions de fonctionnement. Les réglages incorrects des autres commandes pourraient provoquer un

Announcement

Your outgoing announcement plays when calls are answered by the answering system. The telephone has a default outgoing announcement, "Hello, please leave a message after the tone." You can

use this announcement, or record your own. Record a new outgoing announcement:

- The announcement can be up to 90 seconds in lenath.
- 1. Press **MENU** when the handset is not in use. 2. Press ▼ or ▲ to choose **Answering sys** and then press SELECT.
- Press SELECT to choose Announcement
- 4. The screen displays Play [2] Del [3] Rec [7] and it announces, "To play, press 2. To record, press Z." Press 7 to record.
- 5. The handset announces, "Record after the tone. Press 5 when you are done." and it displays
- Recording... Stop [5]. 6. After the tone, speak towards the handset
- microphone. 7. Press **5** when finished. The handset plays back the recorded announcement. Press 5 or OFF to stop the playback at any time.
- To listen to the recorded announcement again, wait after playback has completed, then press
- **NOTE**: Announcements shorter than two E seconds will not be recorded.

Play your announcement

- . Press MENU when the handset is not in use. 2. Press ▼ or ▲ to choose Answering sys and
- then press SELECT. 3. Press SELECT to choose Announcement
- 4. The screen displays Play [2] Del [3] Rec [7] and it announces, "To play, press 2. To record, press 7." Press 2 to play the current announcement.

Options during playback

- 1. Press VOL ▼ or VOL ▲ to adjust the listening 2. Press **5** or **OFF** to stop at any time.
- Delete your announcement:
- . Press **MENU** when the handset is not in use.
- Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Answering sys** and then press SELECT.
- 3. Press SELECT to choose Announcement
- 4. The screen displays Play [2] Del [3] Rec [7] and it announces, "To play, press 2. To record, press 7." Press 3 to delete your recorded announcement. The handset displays **Annc deleted** and announces "Announcement deleted."

NOTE: After you deleted your own recorded announcement, the answering system answers calls with the default announcement.

- dommage qui pourrait exiger un travail exhaustif de la part d'un technicien autorisé afin de rétablir le
- onctionnement normal de l'appareil.
- Si le produit a été échappé et que le socle et/ou le combiné a été endommagé
- Si le produit affiche une nette diminution de sa
- 15. Évitez d'utiliser un téléphone (autre qu'un sans fil) pendant
- un orage. Les éclairs peuvent être à l'origine d'une
- 16. N'utilisez pas le téléphone pour rapporter une fuite de gaz à proximité de la fuite. En certaines circonstances, une flammèche pourrait être provoquée lorsque l'adaptateu est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement ommun associé à la fermeture d'un circuit électrique. tilisateur ne devrait pas brancher le téléphone à une prise de courant, et ne devrait pas déposer le combiné hargé sur le socle, si le téléphone se trouve à proximi nflammables, à moins que la ventilation soit adéquate Une flammèche dans un tel endroit pourrait provoque un incendie ou une explosion. De tels environnemen peuvent comprendre: des endroits où l'on utilise de oxygène médical sans ventilation adéquate: des ga d'essence, etc.); une fuite de gaz naturel, etc.
- Ne placez que le combiné de votre téléphone près de votre oreille lorsqu'en mode de conversatio
- 18. Ces adaptateurs ont été conçus pour être orientés en position verticale ou montés au sol. Les broches ne sont pas conçues pour maintenir l'adaptateur en place si celui-c est barnché dans une prise au plafond ou sous une table/ armoire
- 19. Pour le MATERIEL RACCORDE PAR PRISE DE COURANT, le socle de prise de courant doit etre installe a proximite du materiel et doit etre aisement accessible.
- 0. MISE EN GARDE: Il peut y avoir un risque utilisez le mauvais type de piles p le téléphone. N'utilisez que les piles rechargeable inclus ou les piles de rechange (BT162342/BT262342). N'incinérez pas les piles. Celles-ci risqueraient d'exploser. Mettre au ebut les batteries usagées conformément aux instructions du fabricant. Débrancher les lignes téléphoniques avant le remplacement des piles.
- Évite d'utiliser la batterie dans les conditions suivantes: des températures extrêmes faibles ou élevées auxquelles une batterie peut être soumise pendant l'utilisation, le stockage ou le transport.
- remplacement d'une batterie par un type incorrect pouvant supprimer une protection
- mise au rebut d'une batterie dans un feu ou dans un four chaud, ou écrasement mécanique ou coupure d'une batterie, susceptible de provoquer une explosion
- maintien d'une batterie dans un environnement à très haute température pouvant provoquer une explosion ou la fuite de liquide ou de gaz inflammables
- batterie soumise à une pression de l'air extrêmement faible pouvant provoquer une explosion ou la fuite de liquide ou de gaz
- 21. N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension erait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril.
- La plaque signalétique appliquée est située au bas ou à proximité du produit.

CONSERVEZ CES INSTRUCTIONS

Set number of rings

You can set the answering system to answer an incoming call after two, three, four, five or six rings; or toll saver.

If you choose toll saver, the answering system answers a call after two rings when you have new messages, or after four rings when you have no new messages. This enables you to check for new messages and avoid paying unnecessary long distance charges if you are calling from outside your local area.

- Press MENU when the handset is not in use. 2. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Answering sys** and
- then press SELECT. 3. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Ans sys setup** and then
- press SELECT. 4. Press ▼ or ▲ to choose # of rings and then
- press SELECT. 5. Press ▼ or ▲ to choose from 6, 5, 4, 3, 2, or Toll saver, then press SELECT to save.

Turn on or off the message alert tone

When the message alert tone is set to **On**, and there is at least one new message, the telephone base beeps every 10 seconds. The tone stops when all new messages have been reviewed.

- 1. Press **MENU** when the handset is not in use. 2. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Answering sys** and then press SELECT.
- 3. Press \triangledown or \blacktriangle to choose **Ans sys setup** and then press SELECT.
- 4. Press ▼ or ▲ to choose Msg alert tone and then press SELECT.

N'utilisez que la pile incluse ou l'équivalent.

echapperait est corrosit et p

éléphones numériques sans fil) :

timulateur cardiaque.

À propos des téléphones sans fil

Confidentialité · Les mé

à cordons.

courant est coupé.

les interférences.

oxique qui peut causer

oxique si avalé.

nducteurs

Ne jetez pas la pile au feu. Vérifiez les instruction

Stimulateurs cardiaques implantés dans l'organisme

Les simulateurs cardiaques (s'applique uniquement aux

écifiques de mise aux rebus auprès des autorité

N'ouvrez pas et ne mutilez pas la pile. L'électrolyte qui s'en

Soyez prudents lorsque vous manipulez les piles afin d'éviter les courts-circuits provoqués par des matériaux

Rechargez la pile incluse avec cet appareil, selon les instructions et limites spécifiées dans ce guide d'utilisation.

L'organisme 'Wireless Technology Research, LLC (WTR)', une

uridisciplinaire des interférences entre les téléphones sans

drogues (FDA) des États-Unis, la firme WTR recommande aux

Ils doivent tenir le téléphone sans fil à une distance d'au

Ils ne doivent PAS placer le téléphone sans fil directemen

sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celui-ci est en marche.

sur l'oreille qui se trouve dans la direction opposée au

Ils doivent utiliser le téléphone sans fil en l'appuyar

L'étude effectuée par l'organisme WRS n'a pas identifié de

des avantages pour les téléphones sans fil affichent

également des restrictions. Les appels téléphonique

ransmis entre le combiné sans fil et le socle par

conversations téléphoniques sans fil soient interceptées pa

des équipements de réception radio se trouvant dans la portée du combiné sans fil. Pour cette raison, vous ne devez

le étant aussi confidentielles que celles des téléphones

pas percevoir les communications téléphoniques sans fil

Alimentation électrique : Le socle de ce téléphone sans fi

doit être branché à une prise électrique fonctionnelle. La prise électrique ne doit pas être contrôlée par un interrupteur

nural. Les appels ne pourront pas être effectués du combiné

nterférences, ne placez pas le socle du téléphone sans fil près

éléviseur ou du magnétoscope afin de réduire possiblement

ou sur un téléviseur ou magnétoscope. S'il y a présence de parasites, il est conseillé d'éloigner le téléphone sans fil du

Piles rechargeables : Manipulez les piles avec soin afin de

ne pas les court-circuiter avec des bagues, bracelets ou clés. Les piles ou le conducteur peut surchauffer et causer des

blessures. Respectez la polarité adéquate entre la pile et le

Les bloc-piles rechargeables à l'hydrure métallique de nickel

Jetez ces blocs-piles de manière écologique et sécuritaire

Ne les incinérez pas et ne les percez pas. Tel que les autres

piles de ce type, elles pourraient dégager une matière

des blessures corporelles si elles sont brûlées ou percées

ans fil si le socle est débranché ou mis hors tension ou si le

Possibilité d'interférences aux téléviseurs : Certains

nagnétoscopes. Pour réduire ou prévenir de telles

téléphones sans fil fonctionnent sur des fréquences pouvant causer des interférences aux téléviseurs et aux

le biais d'ondes radio ; il y a donc la possibilité que vos

risque pour les détenteurs de simulateurs cardiaques causé

par les gens qui utilisent un téléphone sans fil à proximité de

isme. Appuyée par l'Administration des aliments et

rme de recherche indépendante, a mené une évaluation

fil portatifs et les stimulateurs cardiaques implantés dans

Avis aux détenteurs de stimulateurs cardiaque

moins six pouces du stimulateur cardiaque.

des blessures aux yeux ou à la peau. L'électrolyte est

5. Press $\mathbf{\nabla}$ or $\mathbf{\Delta}$ to choose **On** or **Off**, then press SELECT to save.

NOTE: The message alert tone beeps only if all the following conditions are met. - Anwering system is on.

 Messsage alert tone setting is on. - There are new messages.

Delete all messages

822

FCC Part 15

screen.

volume.

Playback messages

You can listen to messages at the telephone base or on a cordless handset. When playback begins, the total number of messages is annouced. Before each message, you hear the day and time of the recording. After the last message, you hear, "End of messages." Make sure you set the date and time correctly. Refer to Set date and time for more

To listen to messages at the base:

• Press ▶/■ when the phone is not in use. When you have no message in the answering system, the telephone base announces, "You have no

Options during playback

message.

Press VOL - or VOL + to adjust the listening

Press >> to skip to the next message. Press ◀ to repeat the playing message. Press ◀ twice to listen to the previous message Press **X** to delete the playing message. The telephone base advances to the next message.

• Press ▶/■ to stop the playback.

To listen to messages with the handset: 1. Press MENU when the handset is not in use. The handset displays Play messages

2. Press SELECT. If you have either new or old messages, the messages play automatically. • The system announces the number of messages, and then begins playback. The message sequence is shown on the handset's

3. Press OFF to stop the playback. **Options during playback**

Press VOL ▼ or VOL ▲ to adjust the listening

Press **6** to skip to the next message. Press 4 to repeat the playing message. Press 4 twice to listen to the previous message Press 3 to delete the playing message. The

telephone base advances to the next message • Press **OFF** to stop the playback.

Using the base 1. Press X when the telephone is not in use. The telephone announces - To delete all old messages, press DELETE again 2. Press X again. All previously reviewed messages are erased and the telephone announces - All old messages deleted.

Using the handset

1. Press MENU when the handset is not in use. 2. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Answering sys** and then press **SELECT**.

provider upon request

user's manual.

ervice provider

Limited warranty.

it is hearing aid compatible

numbers, please:

Industry Canada

is telephone.

before hanging up.

norning or late evening

THE RBRC SEAL

The RBRC seal on the nickel-metal hydride indicates that VTech Comm nc. is voluntarily participating in an industry rogram to collect and recycle these batteries t the end of their useful lives, when taken out of service within the United States and Canada.

The program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area. VTech's participation makes it easy for you to drop off the spent battery at local retailers participating in the RBRC program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involver in this program is part of its commitment to protecting our environment and conserving natural resources.

The RBRC Seal and 1 (800) 8 BATTERY® are registered narks of Call2recycle, Inc.

FCC, ACTA AND IC REGULATIONS

NOTE: This equipment has been tested and found to compl with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with he instructions, may cause harmful interference to radic communications. However, there is no guarantee that nterference will not occur in a particular installation. If this igment does cause harmful interference to radio or vision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct e by one or more of the follo Reorient or relocate the receiving antenna Increase the separation between the equipment and

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipmen his device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be

sured when using this telephone. o ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset may be safely held against the ear of the user. The telephone base shall be

nstalled and used such that parts of the user's body other tha the hands are maintained at a distance of approximately 20 cm (8 inches) or more

This Class B digital apparatus complies with Canadia CAN ICES-3 (B)/NMB-3(B).

FCC Part 68 and ACTA

his equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX.

3. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Delete all old** and then

press SELECT 4. Press **SELECT** to confirm. The handset displays Deleting... and then No old messages. It

NOTES:

returns to the previous menu, and you hear a confirmtion tone.

Answering system remote access

You can reach your answering system remotely by dialing your home telephone number from any touch-tone telephone.

- 1. Dial your telephone number from any touchtone telephone. Once the system plays your announcemen enter the two-digit remote access code (19 is the default code)
- The system automatically announces the number of new or old messages (if any), and then begins to play them.

You can also enter the following remote commands.

Command	Description
1	Play all messages.
2	Play only new messages.
3	Delete the current message (during playback).
33	Delete all old messages.
4	Repeat the current message (during playback).
5	Stop.
*5	Hear a list of remote commands.
6	Skip to the next message (during playback).
*7	Record a new announcement.
8	End the call.
0	Turn the answering system on or off.

3. Hang up or press 8 to end the call.

This identifier must be provided to your telephone service

The plug and jack used to connect this equipment to premise

wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted

provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack

RJ14 jack for two lines. See the installation instructions in the

he Ringer Equivalence Number (REN) is used to determine

how many devices you may connect to your telephone line and still have them ring when you are called. The REN for th

product is encoded as the 6th and 7th characters following

US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0)

or less. For more information, please contact your telephone

specially wired alarm dialing equipment connected to you

elephone line, ensure the connection of this equipmen

about what will disable alarm equipment, consult your

If this equipment is malfunctioning, it must be unplugged

If this equipment is causing harm to the telephone networ

the telephone service provider may temporarily discontinu your telephone service. The telephone service provider is

required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible

ou will be given the opportunity to correct the problem and

functioning of this product. The telephone service provider is

If this product is equipped with a corded or cordless handset,

If this product has memory dialing locations, you may choose

to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency

Remain on the line and briefly explain the reason for the call

his device contains licence-exempt transmitter(s)/receiver(s)

nent Canada's licence-exempt RSS(s). Operation is

Perform such activities in off-peak hours, such as early

that comply with Innovation. Science and Economic

(2) This device must accept any interference, including

nterference that may cause undesired operation of the

Privacy of communications may not be ensured when using

The term "IC:" before the certification/registration number

The Ringer Equivalence Number (REN) for this terminal

only signifies that the Industry Canada technical specifications

equipment is 1.0. The REN indicates the maximum number of

divices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination

of devices subject only to the requirement that the sum of the

subject to the following two conditions:

RENs of all the devices not exceed five.

(1) This device may not cause interference.

ovider may make changes in its facilities, equip

ocedures that could affect the pro

your right to file a complaint with the FCC. Your telephone

required to notify you if such changes are planned.

e service provider is required to inform you of

rom the modular jack until the problem has been corrected

Replacement to this telephone equipment can only be made by the manufacturer or its authorized agents. For replacement procedures, follow the instructions outlined under the

elephone service provider or a qualified installer.

This equipment must not be used with Party Lines. If you have

loes not disable your alarm equipment. If you have questions

Id normally be used for connecting to a single line and an

by ACTA. A compliant telephone cord and modular plug is

- If you do not press any key after you enter the remote access code, all new messages play. If there are no new messages, all old messages play. Once the new messages have played, the telephone announces the help menu options. If you do not press any key within 20 seconds, the remote
- access call automatically disconnects When the answering system is turned off, the telephone answers after 10 rings, and announces, "Please enter vour remote access code."
- When the memory is full, the answering system answers incoming calls after 10 rings and announces, "Memory is full. Enter your remote access code."

Change remote access code

- Press **MENU** when the handset is not in use. 2. Press ▼ or ▲ to choose Answering sys and
- then press SELECT. 3. Press ▼ or ▲ to choose Ans sys setup and then
- press SELECT. 4. Press ▼ or ▲ to choose **Remote code** and then press SELECT.
- 5. Use the dialing keys to enter a two-digit number.
- Press $\mathbf{\nabla}$ or \mathbf{A} to scroll to a desired two-digit number
- 6. Press SELECT to confirm.

Call intercept while using answering system

When a caller is leaving a message on your answering system, you can stop recording and talk to the caller by pressing \sum_{TALK} on the handset.

Recording memo

Memos are your own recorded messages used as reminders for yourself or others using the same answering system. You can record your own memos using a system handset. Playback and delete them in the same way as incoming messages

- 1. Press **MENU** when the handset is not in use. 2. Press ▼ or ▲ to choose Answering sys and
- then press SELECT. 3. Press $\mathbf{\nabla}$ or \mathbf{A} to choose **Record memo** and then press **SELECT**. The handset displays Recording... Stop [5] and announces, "Record after the tone. Press 5 when you are done.
- 4. Speak towards the handset microphone. Press 5 or OFF when you finish recording. The handset announces "Recorded."

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

CALIFORNIA ENERGY COMMISSION BATTERY CHARGING TESTING INSTRUCTIONS

This telephone is set up to comply with the energy-conserving standards right out of the box. These instructions are intended for California Energy Commission (CEC) compliance testing of When the CEC battery charging testing mode is activated, all

telephone functions, except battery charging, will be disabled To activate the CEC battery charging testing mode: . Unplug the telephone base power adapter from the powe

- outlet. Make sure all handsets are plugged with charged batteries before proceedin
- While you press and hold FIND HS, plug the telephone base power adapter back to the power outlet. 3. After about 20 seconds, release **FIND HS** and then press it
- again within 2 seconds. You hear a confirmation tone, the phone successfully enters the CEC battery chargin testing mode, all handsets display To register HS and See manual alternatively.

When the phone fails to enter this mode, repeat Step 1 through Step 3 above

To deactivate the CEC battery charging testing mode: 1. Unplug the telephone base power adapter from the powe

outlet, and then plug it back in. Then the telephone base is owered up as normal. 2. Place the handset in the telephone base to register it back. I

displays Registering... The handset show **Registered** and you hear a beep when the registration process complete. The registration process takes about 60 seconds to complete.

LIMITED WARRANTY

What does this limited warranty cover? The manufacturer of this VTech product, VTech Communications, Inc. ("VTech"), warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided by VTech in sales package ("Product") are free from material defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with operating instructions. This limited warranty extends only to he Consumer for Products purchased and used in the United States of America and Canada.

What will VTech Communications do if the Product is not free from material defects in materials and workmanship during the limited warranty period ("Materially Defective Product")? During the limited warranty period. VTech's authorized service epresentative will replace at VTech's option, without charge, a Materially Defective Product. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. VTech will return replacement products to you in working condition. VTech will retain efective parts, modules, or equipment. Replacement of ne Product, at VTech's option, is your exclusive remedy. You

should expect the replacement to take approximately 30 days. How long is the limited warranty period?

The limited warranty period for the product extends for ONE (1) YEAR from date of purchase (90 days on products purchased as Refurbished"). This limited warranty also applies to replacement Products for a period of either (a) 90 days from the date the replacement Product is shipped to you or (b) (90-day limited warranty on products that are purchased as Refurbished*), whichever is longer.

NOTES:

If you record a memo when the answering system memory is full, the system announces, "Memory is full."

- · Each memo can be up to three minutes in length. Memos shorter than two second are not recorded.
- When the answering system has less than three minutes of recording time left, the handset announces, "Less than three minutes to record," and displays Rec mem low.

Turn on or off the call screening

Use this feature to choose whether incoming messages can be heard over the telephone base when they are being recorded. If you turn call screening on, you hear the incoming message

- 1. Press **MENU** when the handset is not in use. 2. Press ▼ or ▲ to choose **Answering sys** and
- then press SELECT. 3. Press ▼ or ▲ to choose Ans sys setup and then
- press SELECT.
- 4. Press SELECT again to choose Call screening. 5. Press ▼ or ▲ to choose On or Off, then press **SELECT** to save

Screen a call with answering system

Screen calls at the cordless handset If the answering system is on and a call is being answered by the answering system, the handset shows To screen call and press [SELECT] alternately.

Press SELECT to screen the call on your handset The handset shows Screening....

Option while a message is being recorded

• Press VOL ▼ or VOL ▲ on the handset to adjust the call screening volume.

Screen calls at the base

If the answering system and call screening are on. the announcement and the incoming message broadcast at the telephone base when a call is answered by the answering system

Option while a message is being recorded

- Press **VOL** or **VOL** + on the telephone base to adjust the call screening volume.
- Press ▶/■ to temporarily turn on the screening if the call screening is set to off.

Refurbished products purchased from our online store carry a PO-day replacement warranty.

vice representative of VTech; or

with non-VTech electrical accessories; or

Products used for rental purposes); or

removed, altered or rendered illegible; or

What is not covered by this limited warranty? This limited warranty does not cover

or antenna systems; or

How do you get warranty service?

below); or

save you a service call.

unit.

- Product that has been subjected to misuse, accident shipping or other physical damage, improper installation abnormal operation or handling, neglect, inundation,
- ire, water or other liquid intrusion; or Product that has been damaged due to repair, alteration or modification by anyone other than an authorized

Product to the extent that the problem experienced is

caused by signal conditions, network reliability or cable

Product to the extent that the problem is caused by use

Product whose warranty/quality stickers, Product serial

number plates or electronic serial numbers have beer

Product purchased, used, serviced, or shipped for repai

or institutional purposes (including but not limited to

Product returned without valid proof of purchase (see 2

Charges for installation or set up, adjustment of custome

trols, and installation or repair of systems outside the

m outside the United States, or used for co

To obtain warranty service in the United States of America, please visit our website at www.vtechphones.com or call

NOTE: Before calling for service, please review the user's

Except as provided by applicable law, you assume the risk

of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the

return replaced product under this limited warranty to you, transportation, delivery or handling charges prepaid. VTech

Return the entire original package and contents including

the Product to the VTech service location along with a

Include "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and

Provide your name, complete and correct mailing

between you and VTech. It supersedes all other written or oral communications related to this product. VTech provides

no other warranties for this product. The warranty exclusively

describes all of VTech's responsibilities regarding the product

There are no other expressed warranties. No one is authorized

to make modifications to this warranty and you should not rely

State Law Rights: This warranty gives you specific legal rights.

Limitations: Implied warranties, including those of fitness for a

particular purpose and merchantability (an unwritten warranty

rom date of purchase. Some states do not allow limitations on

that the product is fit for ordinary use) are limited to one year

and you may also have other rights which vary from state to

assumes no risk for damage or loss of the Product in transit.

What must you return with the Product to get warranty

description of the malfunction or difficulty;

This warranty is the complete and exclusive agreement

the date of purchase or receipt; and

address, and telephone number.

Other limitations

on any such modification

transport of Product(s) to the service location. VTech will

nanual - a check of the Product's controls and features may

(800) 595-9511 for instructions regarding where to return the Product. In Canada, go to phones.vtechcanada.com or dial 1 (800) 267-7377.



Fees may apply.

indicators.

not apply to you.

LIABILITY

OR 97223, United States

messages

Retrieve voicemail

Voicemail is a feature available from most telephone service providers. It may be included with your telephone service, or may be optional.

When you received a voicemail, the handset displays 🖾 and New voicemail. To retrieve, you typically dial an access number provided by your telephone service provider, and then enter a security code. Contact your telephone service provider for instructions on how to configure the voicemail settings and listen to messages.

NOTE: After you have listened to all new voicemail messages, the indicators on the handset turn off automatically.

Clear the new voicemail indicators

If you have retrieved your voicemail while away rom home, and the handset still displays the new voicemail indicators, use this feature to turn off the

NOTE: This feature turns off the indicators only, it does not delete your voicemail

1. Press MENU when the phone is not in use. 2. Scroll to Settings and then press SELECT. 3. Scroll to Clr voicemail and then press SELECT

ECO MODE

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

GENERAL PRODUCT CARE

Taking care of your telephone Your cordless telephone contains sophisticated electronic parts, so it must be treated with care

Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

Avoid water

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms

Cleaning your telephone

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

how long an implied warranty lasts, so the above limitation may

In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the product, or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Please retain your original sales receipt as proof of

DISCLAIMER AND LIMITATION OF

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product. Company: VTech Communications, Inc.

Address: 9020 SW Washington Square Road - Ste 555 Tigard,

Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in

TECHNICAL SPECIFICATIONS

Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	Handset: 1921.536-1928.448 MHz Telephone Base: 1921.536-1928.448 MHz
Channels	DECT channel: 5
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
Power requirement	Handset: 2.4V Ni-MH battery Telephone base: 6V DC @ 0.4A Charger: 6V DC @ 0.4A
Memory	Phonebook: 30 memory locations; up to 30 digits and 15 characters Caller ID log: 30 memory locations; up to 24 digits and 15 characters



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association Used under license.

The ENERGY STAR[®] program (www. energystar.gov) recognizes and encourages the use of products that save energy and help protect our environment. We are proug to mark this product with the ENERGY STAR® label indicating it meets the latest energy efficiency guidelines.