

Scan the QR code for support information





**vtech** 

# Abridged user's manual

### Your telephone package contains the following items. Save your sales receipt and original packaging in case it is necessary to ship your telephone for warranty service.

WHAT'S IN THE BOX







# 1 set for CS6929-2/ CS6929-26 | 2 sets for CS6929-3 3 sets for CS6929-4

# 4 sets for CS6929-4

**OVERVIEW** 

Telephone base

- Message window

telephone base.

• Press to play messages.

Press to stop playing a message.

Press to repeat the playing message.

Press to skip to the next message.

delete all old messages.

Press to delete the playing message.

the telephone base ringer volume.

Press to page all system handsets.

• Press twice to play the previous message.

• When the phone is not in use, press twice to

Press to adjust the volume during message

• When the phone is not in use, press to adjust

• Press to turn the answering system on or off.

• On when the answering system is turned on.

• Flashes when handsets are being deregistered.

• On when the answering system is answering

· On when the handset is in use or being

- ▶/■ PLAY/STOP

REPEAT

**≫** SKIP

4 – X DELETE

5 - **-**/VOL/**+** 

playback.

6- 也ANS ON/OFF

7-#FIND HANDSET

8 - ANS ON/OFF light

9-IN USE light

registered.

a call.

10 - Speakerphone

11 - Charging pole

• Shows the number of messages, and other

information of the answering system or

Install the battery


INSTALL AND CONNECT | MOUNT (OPTIONAL)


### Connect the telephone base If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, make sure


Connect and charge



Handset









The battery icon flashes when the

battery is low and needs charging.

The battery icon animates when the

The battery icon becomes solid

when the battery is fully charged.

The handset ringer is turned off.

There are new voicemail received

The message number currently

playing and total number of new/

The answering system is turned on.

from your telephone service

old messages recorded.

New caller ID log entry.

The ECO mode activates

battery is charging.

### **IMPORTANT SAFETY INSTRUCTIONS**

1. Read and understand all instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- 2. Follow all warnings and instructions marked on the product.
- 3. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning. 4. CAUTION: Do not install the telephone base at a height
- above 2 meters. 5. Do not use this product near water such as near a bath tub
- wash bowl, kitchen sink, laundry tub or a swimming pool 6. Do not place this product on an unstable table, shelf
- stand or other unstable surfaces. 7. Avoid placing the telephone system in places with extreme
- temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes.
- 8. Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect m from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.
- 9. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
- 10. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
- 11. Never push objects of any kind into this product through the slots in the telephone base or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 12. To reduce the risk of electric shock, do not disassemble his product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect eassembling can cause electric shock when the product is subsequently used.
- 13. Do not overload wall outlets and extension cords.
- 14. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
- · When the power supply cord or plug is damaged or
- If liquid has been spilled onto the product. • If the product has been exposed to rain or water
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized
- If the product has been dropped and the telephone
- base and/or handset has been damaged • If the product exhibits a distinct change in performance.

technician to restore the product to normal operation

### 15. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.

- 16. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline
- 17. Only put the handset of your telephone next to your ear then it is in normal talk mode

vapors; etc.); a leak of natural gas; etc.

- 18. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
- 19. For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily
- CAUTION: Use only the batteries indicated n this manual. There may be a risk of explosion if a wrong type of battery is used for the handset. Use only the supplied rechargeable batteries or replacement batteries (BT262342) for the handset. Do not dispose of batteries in a fire. They may explode
- Disposed of used batteries according to the instruction. · Do not use the battery in following conditions » High or low extreme temperature during use, storage
- or transportation. » Replacement of a battery with an incorrect type that can defeat a safeguard
- » Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion
- » Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- » A battery subjected to extremely low air pressure that can result in an explosion or the leakage of flammable liquid or gas.
- 21. Use only the adapter included with this product. Incorrect adapter polarity or voltage can seriously damage the product.
- 22. The applied nameplate is located at the bottom or near of the product. SAVE THESE INSTRUCTIONS

- · Use only the battery provided or equivalent. To order a replacement, visit our website at www.vtechphone com or call 1 (800) 595-9511. In Canada, go to phones. vtechcanada.com or call 1 (800) 267-7377. Do not dispose of the battery in a fire. Check with
- local waste management codes for special disposal
- Do not open or mutilate the battery. Released

C296\(\)\S5-X\(^2\)2\(\)\CB\(^1\)\O\(^2\)\S0\(\)\S5\(\)

Specifications are subject to change without notice.

© 2022 VTech Technologies Canada Ltd. All rights reserved. 06/22.

2022 VTech Communications, Inc. |

H226VCB-DCX81

### electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.

- Exercise care in handling batteries in order not to create a short circuit with conductive materials.
- Charge the battery provided with this product only in accordance with the instructions and limitatio specified in this manual. Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless

Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians

### Pacemaker patients

- · Should keep wireless telephones at least six inches from
- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker WTR's evaluation did not identify any risk to bystanders with

pacemakers from other persons using wireless telephones.

### **ABOUT CORDLESS TELEPHONES**

- Privacy: The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded
- Electrical power: The telephone base of this cordless lephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged, switched
- off or if the electrical power is interrupted. Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordles telephone farther away from the TV or VCR often

reduces or eliminates the interference.

- Rechargeable batteries: Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm Observe proper polarity between the battery and the battery charger.
- Nickel-metal hydride rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury

### SETUP

After the telephone is installed or power returns following a power outage and battery depletion, the handset will prompt you to set the date and time, and the answering system through voice guide.

### Date and time

Follow the steps below to set the date and time. When the handset prompts you to set the date and

- 1. Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press SELECT
- 2. Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press or to choose AM or
- 3. Press **SELECT** to save.



NOTE: If you have skipped the prompt, you can set up again by pressing MENU. Scroll to choose Set date/time and press SELECT. Then, follow the steps above.

After the setting for the date and time, the handset will display Voice guide to... and set up Ans sys?

### Set answering system through voice guide

This feature assists you to do the basic setup of the answering system. You can follow the voice guide to record your own announcement, set the number of rings and the message alert tone.

- . Press **SELECT** to start the voice guide for the answering system setup. You hear the voice prompt "Hello! This voice guide will assist you with the basic setup of your answering system.
- 2. Setup your answering system by inputting the designated numbers as instructed in the voice

### Change LCD language

You can select English, French, or Spanish to be used in all screen displays.

- 1. Press **MENU** when the handset is not in use.
- 2. Scroll to **Settings**, and then press **SELECT** twice.
- 3. Scroll to choose English, Français or Español, and then press **SELECT** to save.

NOTE: If you accidentally set the LCD language to Spanish or French, press MENU and then enter \*364# to change the handset LCD language back to English while the handset is not in use.

Press **FLASH** to put the current call on hold and

· Press FLASH at any time to switch back and

Use this feature to find the system handset.

• Press FIND HANDSET on the telephone base

when not in use. All idle handsets ring and

Press TALK, ■), OFF or any of the dialing keys on

dialed. When there are already 10 entries, the oldest entry is deleted to make room for the new

### Review and dial a redial list entry

- 2. Press **▼**, **▲** or **REDIAL** repeatedly until the
- desired entry displays. 3. Press TALK or ■)) to dial.
- When the desired redial entry displays, press DELETE.

### INTERCOM

- number if necessary.
- 2. To answer the intercom call, press TALK, ♥), INT or any dialing key on the destination handset.
- 3. To end the intercom call, press **OFF** or place the

· Make or answer a call using the handset speakerphone · During a call, press to switch between the

speakerphone and the handset earpiece. 10 - TONE X

• Switch to tone dialing temporarily during a call.

# 11 - OPER ()

- Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or
- Press and hold to set or dial your voicemail

### • Make or answer a call.

### 2 – LCD display

1 – Handset earpiece

### 3-MENU/SELECT Show the menu

- · While in a menu, press to select an item, or save an entry or setting.
- 4-OFF/CANCEL Hang up a call. • Press to return to the previous menu.
- Press and hold to exit menu display without making changes. · Silence the handset ringer temporarily while
- the phone is ringing. · Press and hold to erase the missed call indicator while the handset is not in use.

### 5 – QUIET#

- Press and hold to turn on or off the quiet mode.
- Show other dialing options when reviewing a caller ID log entry.

### 6 – INT

· Press to start an intercom conversation or transfer a call (for two-handset model only)

### • Flashes when there is an incoming call or 7 - Microphone another telephone sharing the same line is in

### 8-MUTE/DELETE

- · Mute the microphone during a call.
- Silence the handset ringer temporarily while the phone is ringing.

Delete the displayed entry while reviewing

- the phonebook, caller ID log, call block list or • Delete digits or characters when entering
- numbers or names

9 – ◀》

· Press to add a space when entering names.

- 13 TALK/FLASH
- call waiting alert.
- 14-REDIAL/PAUSE • Press repeatedly to review the redial list.
- <u>Press and hold</u> to insert a dialing pause while dialing or entering numbers into the

## 15 - ♥ ▲/VOLUME

- not in use.
- Scroll up while in a menu, or in the phonebook, caller ID log or redial list.
- numbers or names.


### • Increase the listening volume during a call.

- VOLUME/▼CID • Review the caller ID log when the telephone
- is not in use. • Scroll down while in a menu, or in the
- · Move the cursor to the left when entering
- numbers or names • Decrease the listening volume during a call.

· On when the handset is charging.

### 16 - CHARGE light

### Charger



### automatically to reduce power consumption when the handset is within range from the telephone

base.

TELEPHONE OPERATIONS

Display icons

ガ

 $\searrow_{\mathbb{M}}$ 

1/13

ANS ON

NEW

ECO

- Use the handset menu . Press **MENU** when the phone is not in use.
- 2. Press ▼ or ▲ until the screen displays the desired feature menu.
- 3. Press **SELECT** to enter that menu.
- · To exit menu display, press and hold CANCEL.

### Make a call

Press TALK or  $\P$ ), and then dial the telephone number

### Press TALK, ■ or any of the dialing keys.

End a call • Press **OFF** or put the handset back in the telephone base or charger

### **Speakerphone**

During a call, press **◄ )** on the handset to switch between speakerphone and handset

-----

### 2. Use the dialing keys to enter the number -OR-

copy the number. 3. Press **SELECT** to move on to enter the name.

Press SELECT to save.

### While entering names and numbers, you can:

<u>Press and hold</u> **PAUSE** to insert a dialing pause

Press ▼ or ▲ to move the cursor to the left or

Press 0 to add a space (for entering names

(∦ appears) (for entering phone numbers only).

Each handset stores the last 10 telephone numbers

### 1. Press **REDIAL** when the handset is not in use.

- Delete a redial list entry

Use the intercom features for conversations between two handsets

- To answer the outside call, press TALK. The intercom call ends automatically.
- To end the intercom call without answering the outside call, press OFF. The telephone

### Transfer a call

- necessary. 2. To answer the intercom call, press TALK, ◀), or
- you on the outside call in a three-way originating handset

# Answer an incoming call during an intercom

call, there is an alert tone.

While on an outside call, you can use the intercom feature to transfer the call from one handset to

- can now have a private conservation before
- · You can let the destination handset join
  - conversation. Press and hold INT on the

# You can transfer the call. Press **OFF**, or place

original system handset.

- The phonebook can store up to 50 entries, which
- any dialing key on the destination handset. You

### your handset back in the telephone base or charger. Your handset displays Line in use. The destination handset is then connected to the outside call. You can press INT to switch between the

outside call (Outside call displays) and the intercom call (Intercom displays). · The destination handset can end the intercom call by pressing **OFF**, or by placing

the handset back in the telephone base or

charger. The outside call continues with the

# **PHONEBOOK**

are shared by all handsets. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.


Press **MENU** when the phone is not in use, then

scroll to **Phonebook**. Press **SELECT** twice to

choose Add new entry.

1. Enter the number when the phone is not in use Press **MENU**, then go to Step 3.

### **REDIAL** and then press **▼**, **△** or **REDIAL** repeatedly to select a number. Press **SELECT** to



Press and hold DELETE to erase the entire entry.

(for entering numbers only).

teatel and to to complete lateral (Canada) for the latest VTech product news.

Viech product news.

Oo to www.vtechphones.com (US) to register your

The mute function allows you to hear the other party

the listening volume.

During a call, press ▲/VOLUME/▼ to adjust

but the other party cannot hear you. 1. During a call, press MUTE. The handset displays

2. Press **MUTE** again to resume the conversation.

The handset displays **Microphone on** briefly.

- Join a call in progress (for two-handset You can use up to two handsets at a time on an
- To exit the call, press **OFF** on the handset or

When you subscribe to call waiting service from

alert tone if there is an incoming call while you are

your telephone service provider, you hear an

# When a handset is already on a call, press TALK or **◄**)) on another handset to join the call.

### To end paging: Press FIND HANDSET at the telephone base.

the handset.

display \*\* Paging \*\*.

take the new call.

forth between calls.

Find handset

To start paging

-OR-

-OR-

handset back in the telephone base or charger.

# If you receive an incoming call during an intercom

- continues to ring.
- 1. Press INT on your handset during a call. The current call is put on hold. Use the dialing keys to enter a destination handset number if
- 3. From this intercom call, you have the following

# saving it to the phonebook.

# • Answer an incoming call when you receive a

- phonebook
- Review the phonebook when the phone is
- Move the cursor to the right when entering
  - · To return to the previous menu, press CANCEL.

### phonebook, caller ID log or redial list.

# Answer a call

earpiece.

Copy a number from the redial list by pressing

4. Use the dialing keys to enter the name. Additional key presses show other characters of

• Press **DELETE** to backspace and erase a digit or

### Place the handset in the telephone base or place it in the telephone base or charger. The charger. Add a phonebook entry 1. Press INT on your handset when not in use. Use call continues until all handsets hang up. transferring the call. the dialing keys to enter a destination handset NOTE: Do not press and hold FIND HANDSET Call waiting for more than 4 seconds. It may lead to handset product for enhanced warranty support and latest

the dialing keys to start a name search.

### Delete a phonebook entry

1. When the desired entry displays, press **DELETE**. 2. When the handset displays **Delete entry?**, press

### Edit a phonebook entry

- 1. When the desired entry displays, press SELECT. 2. Use the dialing keys to edit the number, then press **SELECT**.
- 3. Use the dialing keys to edit the name, then press **SELECT** to save.

### Dial a phonebook entry

 When the desired entry appears, press TALK or **■**)) to dial.

# CALLER ID

If you subscribe to caller ID service, information about each caller appears after the first or second ring. If you answer a call before the caller information appears on the screen, it will not be saved in the caller ID log.

The caller ID log stores up to 30 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name. If the telephone number has more that 15 digits,

only the last 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the caller ID log.

### Review a caller ID log entry

1. Press CID when the phone is not in use. 2. Scroll to browse through the caller ID log.

### Missed call indicator

When there are calls that have not been reviewed in the caller ID log, the handset displays XX missed

Each time you review a caller ID log entry marked **NEW**, the number of missed calls decreases by

When you have reviewed all the missed calls, the missed call indicator no longer displays. If you do not want to review the missed calls

one by one, press and hold CANCEL on the idle

### handset to erase the missed call indicator. All the entries are then considered old. Dial a caller ID log entry

Mesures de sécurité importante

 When the desired entry appears, press TALK or **■** which the dial of the dia

FOR C-UL COMPLIANCE ONLY

Afin de réduire les risques d'incendie, de blessures

1. Lisez et comprenez bien toutes les instructions.

nauteur supérieure à 2 mètres.

corporelles ou d'électrocution, suivez toujours ces mesures préventives de base lorsque vous utilisez votre téléphone :

Observez toutes les instructions et mises en garde inscrites sur l'appareil.

N'utilisez qu'un chiffon doux et légèrement humecté.

4. ATTENTION: Ne pas installer le socle téléphonique à une

N'utilisez pas ce produit près de l'eau, tel que près d'un

Ne déposez pas ce téléphone sur un chariot, suppor

ou table chancelants. L'appareil pourrait tomber et être

Évitez d'installer le système téléphonique dans les endroits

soumis à une température extrême, à la lumière directe

contre les sources d'humidité, la poussière, les vapeurs e

du soleil ou à proximité immédiate d'autres appareils électriques ou électroniques. Protégez votre téléphone

8. Le boîtier de l'appareil est doté de fentes et d'ouverture

tapis ou autre surface similaires. Ne placez pas cet

d'empêcher la surchauffe, ces ouvertures ne doivent

unité murale ou un cabinet fermé qui ne possède pas

pas être obstruées en plaçant l'appareil sur un lit, divan,

ppareil à proximité d'un élément de chauffage ni d'une Dinthe électrique. De plus, ne l'installez pas dans une

entation indiqué sur les étiquettes de l'apparei

Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité

10. Ne déposez rien sur le cordon d'alimentation. Installez cet

11. N'insérez jamais d'objets à travers les fentes et ouvertures

de tension dangereux ou court-circuiter des pièces, ce

12. Afin de réduire les risques d'électrocution, ne démontez

pas l'appareil, mais apportez-le plutôt à un centre de

ervice qualifié s'il doit être réparé. En enlevant le

l'échappez pas de liquides dans l'appareil.

qui constituerait un risque d'incendie ou d'électrocution

couvercle, vous vous exposez à des tensions dangereuse:

tilisation ultérieure de l'appareil. Débranchez l'appareil

mmuniquez avec le département de service à la clientèle

Lorsque le cordon d'alimentation est endommagé ou

• Si l'appareil a été exposé à une source d'humidité telle

respectant les instructions de fonctionnement. Réglez

instructions de fonctionnement. Les réglages incorrects des autres commandes pourraient provoquer un

uniquement les commandes indiquées dans le les

· Si le produit ne fonctionne pas normalement en

ou autres dangers similaires. Un remontage inadéqua

avant de procéder au nettoyage. Utilisez un chiffon

13. Ne surchargez pas les prises de courant et les rallonges.

14. Débranchez cet appareil de la prise de courant et

· Si du liquide a été échappé dans l'appare

de VTech dans les cas suivants :

que la pluie ou l'eau.

appareil dans un endroit sécuritaire, là où personne ne

pourra trébucher sur la ligne d'alimentation ni le cordon

d'aération situées à l'arrière ou en dessous. Afin

9. Ne faites fonctionner cet appareil qu'avec le type

d'aération adéquate.

éléphonique modulaire

bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage

ou d'une piscine, ou dans un sous-sol humide ou sous la

ettover. N'utilisez pas de nettoveurs liquides ni en aérosol

3. Débranchez ce téléphone de la prise murale avant de le

- Save a caller ID log entry to the phonebook 1. When the desired caller ID log entry displays, press **SELECT**.
  - 2. Press **SELECT** to choose **To Phonebook**.
  - 3. Use the dialing keys to edit the number, if necessary. Then press **SELECT**.
  - 4. Use the dialing keys to edit the name, if necessary. Then press **SELECT** to save.

### Delete the caller ID log entries

• When the desired caller ID log entry displays, press **DELETE**.

To delete all caller ID log entries:

- 2. Scroll to **Caller ID log** and then press **SELECT**. 3. Scroll to **Delete all** and then press **SELECT** twice.
- 1. Press **MENU** when the phone is not in use. An incoming call will ring once and then the system will check if the call should be blocked. You

### CALL BLOCK

If you have subscribed to caller ID service, you can set the telephone to block unknown calls and certain undesired calls. The call block list can store up to 20 entries.

### Block unknown calls

- 1. Press **MENU** when the handset is not in use. 2. Scroll to Call block, and then press SELECT.
- 3. Scroll to choose Calls w/o num, and then press SELECT.
- 4. Scroll to choose **Unblock** or **Block**, and then press **SELECT** to save.

### Add a call block list entry

- 1. Press **MENU** when the handset is not in use. 2. Scroll to Call block, and then press SELECT.
- 3. Press **SELECT** to choose **Block list** 4. Scroll to choose **Add new entry**, and then press
- 5. Use the dialing keys to enter the number (up to 30 digits). 6. Press **SELECT** to move to enter the name.
- 7. Use the dialing keys to enter the name (up to 15
- characters). Additional key presses show other characters of that particular key.
- 8. Press **SELECT** to save.

### Review call block list

- 1. Press **MENU** when the handset is not in use. 2. Scroll to Call block, and then press SELECT.
- 3. Press SELECT to choose Block list 4. Press **SELECT** to choose **Review**.
- Edit a call block list entry
- 1. When the desired entry displays, press **SELECT**.
- 2. Use the dialing keys to edit the number (up to 30 digits), and then press **SELECT**.
- 3. Use the dialing keys to edit the name (up to 15 characters), and then press **SELECT** to save.

fonctionnement normal de l'appareil.

combiné a été endommagé

dommage qui pourrait exiger un travail exhausti

· Si le produit a été échappé et que le socle et/ou le

• Si le produit affiche une nette diminution de sa

15. Évitez d'utiliser un téléphone (autre qu'un sans fil) pendan

un orage. Les éclairs peuvent être à l'origine d'une

16. N'utilisez pas le téléphone pour rapporter une fuite de

gaz à proximité de la fuite. En certaines circonstances, une flammèche pourrait être provoquée lorsque l'adaptateur

est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement

utilisateur ne devrait pas brancher le téléphone à une

prise de courant, et ne devrait pas déposer le combiné

inflammables, à moins que la ventilation soit adéquate

Une flammèche dans un tel endroit pourrait provoque

un incendie ou une explosion. De tels environnemer peuvent comprendre: des endroits où l'on utilise de

l'oxygène médical sans ventilation adéquate: des ga

d'essence, etc.); une fuite de gaz naturel, etc.

18. Ces adaptateurs ont été conçus pour être orientés en

ateriel et doit etre aisement accessible.

chargé sur le socle, si le téléphone se trouve à proximité

commun associé à la fermeture d'un circuit électrique.

de la part d'un technicien autorisé afin de rétablir le

N'utilisez que la pile incluse ou l'équivalent

### Ne jetez pas la pile au feu. Vérifiez les instructions spécifiques de mise aux rebus auprès des autorités

then press **SELECT** to save.

- · N'ouvrez pas et ne mutilez pas la pile. L'électrolyte qui s'en échapperait est corrosif et pourrait causer des brûlures ou des blessures aux yeux ou à la peau. L'électrolyte est toxique si avalé.
- Soyez prudents lorsque vous manipulez les piles afin d'éviter les courts-circuits provoqués par des matériaux conducteurs.
- Rechargez la pile incluse avec cet appareil, selon les instructions et limites spécifiées dans ce guide d'utilisation

Stimulateurs cardiaques implantés dans l'organisme Les simulateurs cardiagues (s'applique uniquement aux téléphones numériques sans fil) :

Ils doivent tenir le téléphone sans fil à une distance d'au

Ils doivent utiliser le téléphone sans fil en l'appuyant

L'étude effectuée par l'organisme WRS n'a pas identifié de

risque pour les détenteurs de simulateurs cardiaques causés

par les gens qui utilisent un téléphone sans fil à proximité de

Confidentialité: Les mêmes caractéristiques qui constituent

conversations téléphoniques sans fil soient interceptées par

portée du combiné sans fil. Pour cette raison, vous ne devez

comme étant aussi confidentielles que celles des téléphone

Alimentation électrique : Le socle de ce téléphone sans fil

doit être branché à une prise électrique fonctionnelle. La prise électrique ne doit pas être contrôlée par un interrupte

mural. Les appels ne pourront pas être effectués du combiné

sans fil si le socle est débranché ou mis hors tension ou si le

interférences, ne placez pas le socle du téléphone sans fil près

téléviseur ou du magnétoscope afin de réduire possiblemen

ou sur un téléviseur ou magnétoscope. S'il y a présence de parasites, il est conseillé d'éloigner le téléphone sans fil du

Piles rechargeables: Manipulez les piles avec soin afin de

es piles ou le conducteur peut surchauffer et causer de

ne pas les court-circuiter avec des baques, bracelets ou clés

blessures. Respectez la polarité adéquate entre la pile et le

Les bloc-piles rechargeables à l'hydrure métallique de nickel

: Jetez ces blocs-piles de manière écologique et sécuritaire

Ne les incinérez pas et ne les percez pas. Tel que les autres

Possibilité d'interférences aux téléviseurs : Certains

téléphones sans fil fonctionnent sur des fréquences pouvant causer des interférences aux téléviseurs et aux magnétoscopes. Pour réduire ou prévenir de telles

des avantages pour les téléphones sans fil affichent

également des restrictions. Les appels téléphoniques

sont transmis entre le combiné sans fil et le socle par

e biais d'ondes radio ; il y a donc la possibilité que vos

des équipements de réception radio se trouvant dans la

pas percevoir les communications téléphoniques sans fil

sur l'oreille qui se trouve dans la direction opposée au

chemise, lorsque celui-ci est en marche

À propos des téléphones sans fil

Ils ne doivent PAS placer le téléphone sans fil directemen

sur le stimulateur cardiaque, tel que dans une poche de

L'organisme 'Wireless Technology Research, LLC (WTR)', une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans il portatifs et les stimulateurs cardiaques implantés dans l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-Unis, la firme WTR recommande aux Avis aux détenteurs de stimulateurs cardiaques

### 17. Ne placez que le combiné de votre téléphone près de votre oreille lorsqu'en mode de conversation

- position verticale ou montés au sol. Les broches ne sont est barnché dans une prise au plafond ou sous une table/ 19. Pour le MATERIEL RACCORDE PAR PRISE DE COURANT, le socle de prise de courant doit etre installe a proximite du
- 20. MISE EN GARDE: Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour le téléphone. N'utilisez que les piles rechargeable inclus ou les piles de rechange (BT262342). N'incinérez pas les
- piles. Celles-ci risqueraient d'exploser. Mettre au rebut les batteries usagées conformément aux instructions du fabricant. Débrancher les lignes téléphoniques avant le remplacement des piles Évite d'utiliser la batterie dans les conditions suivantes
- des températures extrêmes faibles ou élevées
- auxquelles une batterie peut être soumise pendant l'utilisation, le stockage ou le transport remplacement d'une batterie par un type
- incorrect pouvant supprimer une protection. mise au rebut d'une batterie dans un feu ou dans
- coupure d'une batterie, susceptible de provoque une explosion maintien d'une batterie dans un environnement à très haute température pouvant provoquer
- une explosion ou la fuite de liquide ou de gaz batterie soumise à une pression de l'air
- extrêmement faible pouvant provoquer une xplosion ou la fuite de liquide ou de gaz 21. N'utilisez que les adaptateurs inclus avec ce produit.
- L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril. 22. La plaque signalétique appliquée est située au bas ou à
- proximité du produit CONSERVEZ CES INSTRUCTIONS

### Save a caller ID log entry to call block list

- press **SELECT**.
- 3. Use the dialing keys to edit the number, if

necessary. Then press **SELECT**.

Delete a call block list entry

By default, the first ring is set to **On**.

and then press **SELECT** to save.

You can turn the key tone on or off.

2. Press 7464# on the handset.

SOUND SETTINGS

Key tone

Ringer tone

each handset

Ringer volume

turn the ringer off.

press **SELECT** to save.

press **DELETE**.

Mute first rings

4. Use the dialing keys to edit the name, if

necessary. Then press **SELECT** to save.

· When the desired call block list entry displays

can choose to mute the first ring for all incoming

1. Press MENU when the handset is not in use.

1. Press **MENU** when the handset is not in use.

3. Scroll to choose **Key tone**, then press **SELECT** 

You can choose from different ringer tones for

Press MENU when the handset is not in use.

4. Press ▼ or ▲ to sample each ringer tone, then

You can adjust the handset ringer volume level, or

3. Scroll to Ringer volume and then press SELECT.

Off, the handset still rings when you press

FIND HANDSET at the telephone base.

1. Press MENU when the handset is not in use.

Scroll to **Ringers** and then press **SELECT**.

4. Press ▼ or ▲ to sample each volume level,

NOTE: When the ringer volume is set to Off, the handest still also

2. Scroll to **Ringers** and then press **SELECT**.

3. Scroll to choose **Ringer tone**, then press

NOTE: If you turn off the ringer volume, you will not hear ringer to a

4. Scroll to choose On or Off, then press SELECT

2. Scroll to **Settings** and then press **SELECT**.

calls, so that there will be no ring for blocked calls

3. Scroll to choose First ring:On or First ring: Off,

### When the desired caller ID log entry displays, When the telephone is ringing, you can temporarily

- 2. Scroll to To Call block, and then press SELECT.

### Temporary ringer silencing

next call rings normally at the preset volume. To silence the handset ringer:

• Press **OFF** or **MUTE**. The handset displays 💫 and Ringer muted briefly.

silence the ringer without disconnecting the call. The


### Quiet mode

You can turn on the quiet mode for a period of time. During this period, all tones (except paging tone) and call screening are muted. When you turn on the quiet mode, the answering system turns on automatically

- 1. Press and hold QUIET# on the handset when it is not in use.
- 2. Use the dialing keys to enter the duration, and then press **SELECT** to save. To turn off the quiet mode, press and hold
- QUIET# on the handset when it is not in use

### Answering system

For message recording, your telephone has a built-in answering system, and it also supports voicemail service offered by your telephone service provider (subscription is required, and fee may apply).



		BUILT-IN ANSWERING SYSTEM	VOICEMAIL SERVICE
	SUPPORTED BY	Telephone system	Telephone service provider
	SUBSCRIPTION	No	Yes
	FEES	No	May apply
	Answer INCOMING CALLS	<ul> <li>After 3 ringers by default.</li> <li>It can be changed in the handset menu.</li> </ul>	<ul> <li>Usually after 2 rings.</li> <li>It can be changed by contacting your telephone service provider.</li> </ul>
	STORAGE	Telephone base	Server or System
	DISPLAY NEW	Handset - XX     new messages     Telephone base	<ul> <li>Handset -</li></ul>

- 88 flashes

piles de ce type, elles pourraient dégager une matière

des blessures corporelles si elles sont brûlées ou percées

The RBRC program provides a convenient alternative to placing used nickel-metal hydride batteries into

off the spent battery at local retailers participating in the RBRC

recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to

protecting our environment and conserving natural resources

FCC, ACTA AND IC REGULATIONS

NOTE: This equipment has been tested and found to comply

of the Federal Communications Commission (FCC) rules. Thes requirements are intended to provide reasonable protection

against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this

equipment off and on, the user is encouraged to try to correct

Connect the equipment into an outlet on a circuit different

Consult the dealer or an experienced radio/TV technician

WARNING: Changes or modifications to this equipment not

could void the user's authority to operate the equipment

expressly approved by the party responsible for compliance

This device complies with Part 15 of the FCC rules. Operation is

subject to the following two conditions: (1) this device may not

cause harmful interference, and (2) this device must accept any

interference received, including interference that may cause undesired operation. Privacy of communications may not be

To ensure safety of users, the FCC/ISEDC has established criteria for the amount of radio frequency energy that can

be safely absorbed by a user or bystander according to the

intended usage of the product. This product has been tested and found to comply with the FCC/ISEDC criteria. The handset

may be safely held against the ear of the user. The telephone

base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of

This Class B digital apparatus complies with Canadian

the interference by one or more of the following measures:

· Increase the separation between the equipment and

from that to which the receiver is connected.

· Reorient or relocate the receiving antenna

ensured when using this telephone

approximately 20 cm (8 inches) or more.

CAN ICES-3 (B)/NMB-3(B).

ption, which can be determined by turning the

with the requirements for a Class B digital device under Part 15

The RBRC Seal and 1 (800) 8 BATTERY $^{\scriptsize (8)}$  are registered

program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery

VTech's participation in RBRC makes it easy for you to drop

the trash or municipal waste, which may be illegal in your area.

The RBRC seal on the nickel-metal hydride

battery indicates that VTech Communications

Inc. is voluntarily participating in an industry

rogram to collect and recycle these batteries

at the end of their useful lives, when taken out

of service within the United States and Canada.

toxique qui peut cause

THE RBRC SEAL

### **ANSWERING SYSTEM** SERVICE Handset

Press and

<u>hold</u> **™** and

 Press ►/■ on the telephone base; or

code.

- Press MENU, and then select Play messages on the handset Access remotely with an access
  - enter an access numbe from your telephone service provider; OR Press and hold
  - to dial if you have saved the access number.

# Set voice language

RETRIEVE

**MESSAGES** 

The voice prompt language is preset to English. You can select English or French to be used for the voice prompts in your answering system.

- Press MENU when the handset is not in use.
- 2. Scroll to Answering Sys, then press SELECT.
- 3. Scroll to **Ans sys setup**, then press **SELECT**.
- 4. Scroll to Voice language, then press SELECT. 5. Scroll to choose **English** or **Français**, and then
- press **SELECT** to confirm NOTE: This feature is available in Canada

### version only. Announcement

The telephone is preset with a greeting that answers tone. You can use this preset announcement or replace it with your own.

### Record your own announcement You can use the preset announcement to answer

calls, or replace it with your own recorded announcement. It can be up to 90 seconds in length. NOTE: The system does not record any

- announcement shorter than 2 seconds 1. Press MENU when the handset is not in use 2. Scroll to Answering Sys, then press SELECT
- 3. The handset displays Play [2] Del [3] Rec [7], and it announces, "To play, press 2. To record, press
- 4. Press 7 to record. The handset announces, done. " After the tone, speak towards the handset microphone. Then, press 5 when done

### Set number of rings

### FCC Part 68 and ACTA

This identifier must be provided to your telephone service provider upon request. The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted

by ACTA. A compliant telephone cord and modular plug is

RJ14 jack for two lines. See the installation instructions in the user's manual. The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0)

or less. For more information, please contact your telephone

This equipment must not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your elephone line, ensure the connection of this equipmen s not disable your alarm equipment. If you have question about what will disable alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected by the manufacturer or its authorized agents. For replaceme procedures, follow the instructions outlined under the Limited warranty. If this equipment is causing harm to the telephone network,

the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is uired to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible You will be given the opportunity to correct the problem and your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.

it is hearing aid compatible If this product has memory dialing locations, you may choose

before hanging up. Perform such activities in off-peak hours, such as early

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic

(1) This device may not cause interference. (2) This device must accept any interference, including terference that may cause undesired operation of the device.

only signifies that the Industry Canada technical specifications

### 

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX.

provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and ar

service provider.

Replacement to this telephone equipment can only be made

If this product is equipped with a corded or cordless handset,

to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please: Remain on the line and briefly explain the reason for the call

morning or late evening **Industry Canada** 

nent Canada's licence-exempt RSS(s). Operation is subject to the following two conditions

Privacy of communications may not be ensured when using this telephone. The term "IC:" before the certification/registration number

You can set your answering system to answer calls at least two rings earlier than your voicemail service. For example, if your voicemail service answers after six rings, set your answering system to answer after four rings. Thus, if you are on a call, or if the

### 5. Press **▼** or **▲** to choose **2**, **3**, **4**, **5**, **6**, or **Toll** saver, and then press SELECT to save.

When the message alert tone is set to on, and there

is at least one new message, the telephone base

beeps every 10 seconds. The message alert tone is

1. Press **MENU** when the handset is not in use.

2. Scroll to **Answering Sys**, then press **SELECT**.

4. Scroll to Msg alert tone, then press SELECT.

5. Press ▼ or ▲ to choose Tone: On or Tone:Off.

• Turn on the answering system in order to

Turn the built-in answering system on or off

• Press **OANS ON/OFF** turn on; press again to

1. Press **MENU** when the handset is not in use.

2. Press **SELECT** when **Play messages** displays.

Handset

CANCEL

Press 6

Press 4

Press 4

twice

DELETE

Press XDELETE twice when the phone is not in

Delete all messages at the telephone base

The Ringer Equivalence Number (REN) for this terminal

RENs of all the devices not exceed five.

**INSTRUCTIONS** 

batteries before proceeding

displays Registering...

about 60 seconds to complete.

LIMITED WARRANTY

What does this limited warranty cover?

equipment is 0.1. The REN indicates the maximum number of

he termination of an interface may consist of any combination

f devices subject only to the requirement that the sum of the

devices allowed to be connected to a telephone interface.

This product meets the applicable Innovation, Science and

CALIFORNIA ENERGY COMMISSION

This telephone is set up to comply with the energy-conserving

for California Energy Commission (CEC) compliance testing only When the CEC battery charging testing mode is activated, all

telephone functions, except battery charging, will be disabled

Unplug the telephone base power adapter from the powe outlet. Make sure all handsets are plugged with charged

telephone base power adapter back to the power outlet

flashing, release FIND HANDSET and then press it again within 2 seconds. When the phone successfully enters the

CEC battery charging testing mode, all handsets display To

When the phone fails to enter this mode, repeat Step 1 through

Unplug the telephone base power adapter from the power outlet, and then plug it back in. Then the telephone base is

2. Place the handset in the telephone base to register it back. It

The handset show **Registered** and you hear a beep when the

The manufacturer of this VTech product, VTech Communications,

Inc. ("VTech"), warrants to the holder of a valid proof of purchase

("Consumer" or "you") that the Product and all accessories

the following terms and conditions, when installed and used

normally and in accordance with operating instructions. This

limited warranty extends only to the Consumer for Products

purchased and used in the United States of America and Canada

What will VTech Communications do if the Product is not free

from material defects in materials and workmanship during th

imited warranty period ("Materially Defective Product")?

During the limited warranty period, VTech's authorized service

representative will replace at VTech's option, without charge,

Product, we may replace it with a new or refurbished Product

products to you in working condition. VTech will retain defective

ts, modules, or equipment. Replacement of the Product, a

VTech's option, is your exclusive remedy. You should expect the

The limited warranty period for the product extends for ONE (1)

YEAR from date of purchase (90 days on products purchased as

a Materially Defective Product. If we choose to replace the

of the same or similar design. VTech will return replacement

eplacement to take approximately 30 days.

How long is the limited warranty period?

provided by VTech in sales package ("Product") are free from

erial defects in material and workmanship, pursuant to

2. While you press and hold /FIND HANDSET, plug the

3. After about 20 seconds, when the **IN USE** light starts

To deactivate the CEC battery charging testing mode

register HS and See manual alternatively

To activate the CEC battery charging testing mode:

standards right out of the box. These instructions are intended

BATTERY CHARGING TESTING

Telephone base

►/■PLAY/STOP

Press SKIP

Press **≪REPEAT** 

Press REPEAT

twice

Press **XDELETE** 

Options while message playback

ensure the message alert tone is functional

Press any keys on the telephone base (except

FIND HANDSET) to temporarily silence the

Scroll to Ans sys setup, then press SELECT.

and then press **SELECT** to confirm.

message alert tone.

Message playback

Telephone base

Press ►/■PLAY/STOP

Handset

**OPTIONS** 

STOP PLAYBACK

SKIP A MESSAGE

PLAYING THE

REPEAT THE PLAYIN

PREVIOUS MESSAGE

DELETE THE PLAYING

4. Scroll to # of rings, then press SELECT.

answering system is busy recording a message and

you receive another call, the second caller can leave

a voicemail message

Set message alert tone

preset to off

- answering system remotely from any touch-tone . Press **MENU** when the handset is not in use. telephone. The preset code is 19. You can set the Scroll to Answering Sys, then press SELECT. code from 00 to 99
- 3. Scroll to Ans sys setup, then press SELECT.

Remote access

1. Press MENU when the handset is not in use 2. Scroll to Answering Sys, then press SELECT.

A 2-digit security code is required to access the

- 3. Scroll to Ans sys setup, then press SELECT.
- 4. Scroll to Remote code, then press SELECT.
- 5. Use the dialing keys (0-9) to enter a 2-digit
- number, or press ♥ or ▲ to scroll to a desired 2-diait number 6. Press **SELECT** to confirm your selection.

### RETRIEVE VOICEMAIL FROM **TELEPHONE SERVICE**

Voicemail is a feature available from most telephone service providers. It may be included with your telephone service, or may be optional.

### Retrieve voicemail When you received a voicemail, the handset

Fees may apply.

displays and New voicemail. To retrieve, you typically dial an access number provided by your telephone service provider, and then enter a security code. Contact your telephone service provide for instructions on how to configure the voicemail settings and listen to messages.

NOTE: After you have listened to all new voicemail messages the in the second s voicemail messages, the indicators on the handset turn off automatically.

### Set your voicemail number

You can save your access number on each handset for easy access to your voicemail. After you saved the voicemail number, you can press and hold **1** to retrieve voicemail.

- 1. Press **MENU** when the phone is not in use. 2. Scroll to **Settings** and then press **SELECT**.
- 3. Scroll to Voicemail # and then press SELECT.

Turn off the new voicemail indicators

4. Use the dialing keys to enter the voicemail

- number (up to 30 digits). 5. Press **SELECT** to save.
- If you have retrieved your voicemail while away from home, and the handset still displays the new voicemail indicators, use this feature to turn off the
- NOTE: This feature turns off the indicators only, it does not delete vourseless." it does not delete your voicemail messages.

3. Scroll to Clr voicemail and then press SELECT.

Refurbished\*). This limited warranty also applies to replacement

replacement Product is shipped to you or (b) the time remaining

Refurbished products purchased from our online store carry a

Product that has been subjected to misuse, accident.

shipping or other physical damage, improper installation,

abnormal operation or handling, neglect, inundation, fire,

Product that has been damaged due to repair, alteration

Product to the extent that the problem experienced is

Product to the extent that the problem is caused by use

Product whose warranty/quality stickers, Product seria

number plates or electronic serial numbers have been

Product purchased, used, serviced, or shipped for repair

from outside the United States, or used for commercia

Product returned without valid proof of purchase (see 2

Charges for installation or set up, adjustment of custome

controls, and installation or repair of systems outside the

or institutional purposes (including but not limited to

caused by signal conditions, network reliability or cable or

or modification by anyone other than an authorized

Products for a period of either (a) 90 days from the date the

on the original one-year limited warranty (90-day limited

whichever is longer.

90-day replacement warranty

This limited warranty does not cover

antenna systems; or

below); or

What is not covered by this limited warranty

water or other liquid intrusion; or

service representative of VTech; or

with non-VTech electrical accessories; or

removed, altered or rendered illegible; or

Products used for rental purposes); or

warranty on products that are purchased as Refurbished\*),

1. Press MENU when the phone is not in use. 2. Scroll to **Settings** and then press **SELECT**.

### ECO MODE

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the nandset is synchronized with the telephone base.

### GENERAL PRODUCT CARE

electronic parts, so it must be treated with care.

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your appliances during storms.

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use

For operations and guides to help you using your telephone, and for the latest information and supports, go and check the online help topics and

# Go to

https://phones.vtechcanada.com/en/support/ general/manuals?model=CS6929 (Canada) • Scan the QR code on the 回線回

your smartphone or tablet. the QR code and frame it. Tap the notification to trigger the redirection of the online help.

right. Launch the camera app

displayed, adjust your camera's focus by moving your device clear.

Support at 1 (800) 595-9511 [in US] or 1 (800) 267-7377 [in Canada] for help.



### ncidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the product, or other associated equipment, the cost of substitute equipment,

product. Some states do not allow the exclusion or limitation of

DISCLAIMER AND LIMITATION OF LIABILITY VTech Communications, Inc. and its suppliers assume no

assume no responsibility for any loss or claims by third parties that may arise through the use of this product. Company: VTech Communications, Inc

OR 97223, United States **Phone:** 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

### How do you get warranty service? Transmit To obtain warranty service in the United States of America.

In Canada, go to phones.vtechcanada.com or dial 1 (800) 267-NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.

595-9511 for instructions regarding where to return the Product.

mage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of Product(s) to the service location. VTech will return replaced product under this limited warranty to you, transportation, delivery or handling charges prepaid. VTech assumes no risk for

Except as provided by applicable law, you assume the risk of loss

### What must you return with the Product to get warranty service Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty;

Include "valid proof of purchase" (sales receipt) identifying

damage or loss of the Product in transit.

the Product purchased (Product model) and the date of purchase or receipt; and Provide your name, complete and correct mailing address and telephone number

# Other limitations

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this product. VTech provides no other warranties for this product. The warranty exclusively describes all of VTech's responsibilities regarding the product. There are no other expressed warranties. No one is authorized to make modifications to this warranty and you should not rely on any such modification. **State Law Rights:** This warranty gives you specific legal rights, and you may also have other rights which vary from state to

Taking care of your telephone

Your cordless telephone contains sophisticated Avoid rough treatment

own safety, take caution when using electrical Cleaning your telephone

dampened cloth or cleaning solvents of any kind.

online FAQs Use your smartphone or mobile device to access our

https://help.vtechphones.com/CS6929 (US); OR

or QR code scanner app on Hold the device's camera up to - If the QR code is not clearly

closer or further away until it is You can also call our Customer



回光

### from date of purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special,

**Limitations:** Implied warranties, including those of fitness for a

particular purpose and merchantability (an unwritten warranty

that the product is fit for ordinary use) are limited to one year

incidental or consequential damages, so the above limitation or exclusion may not apply to you. Please retain your original sales receipt as proof of

and claims by third parties) resulting from the use of this

Address: 9020 SW Washington Square Road - Ste 555 Tigard

Telephone Base: 1921.536-1928.448 MHz Channels


range

Frequency

control


Handset: 2.4V Ni-MH battery Telephone base: 6V DC @ 0.4A Charger: 6V DC @ 0.4A





Compliant Logo is a trademark of the Used under license. The ENERGY STAR® program (www.

Call block: 20 entries Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083



communications Industry Association. energystar.gov) recognizes and encourages



Crystal controlled PLL synthesizer

Handset: 1921.536-1928.448 MHz

**TECHNICAL SPECIFICATIONS** 

DECT channel: 5 Maximum power allowed by FCC and Nominal IC. Actual operating range may vary effective according to environmental conditions

Power requirement

Phonebook: 50 memory locations; up to 30 digits and 15 characters Caller ID log: 30 memory locations; up to 24 digits and 15 characters

at the time of use.



the use of products that save energy and help protect our environment. We are proud



to mark this product with the ENERGY STAR label indicating it meets the latest energy efficiency guidelines.

# Avoid water

it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

### **Electrical storms**

NEED HELP?

# online help.