

EA_Inspector

Release 3.6



User Guide

TM42-3013I

Contents

	Safety information	8
	New in release 3.6	9
	Changes in release 3.6	9
1	Introduction	10
	About handheld devices	10
	About This manual	10
	Audience	10
	New users	10
	Existing users	10
	What is the EnergyAxis System?	11
	EnergyAxis tools	13
	EA_InstallerPlus	14
	EA_Inspector and EA_Inspector Manager	15
2	About the handheld	16
	About the handheld	16
	Radix specifications	16
	Safe RF exposure using external antenna	18
	EA_Inspector Manager	18
	EA_Inspector	19
	Transmission accuracy	19
	Navigating the software	19
	Database warning	20
3	Operating the handheld	21
	Commonly used keys	21
	<Esc>	21
	<Enter>	21
	Arrow keys	22
	<Tab>	22
	Entering responses (Yes/No)	22
	Using the stylus	22
	Turning the device on and off	22
	Charging the device	22
	Resetting the handheld device	22
	Opening EA_Inspector	23
	Logging in to the handheld	25
	Holding the handheld for meter reading	28

4	About EA_Inspector software	29
	Navigating the software	30
	User privileges	31
	Saving notes and GPS data	31
	Exiting EA_Inspector	33
	Exiting from the login screen	33
5	Performing a ping test	35
	About ping tests	35
	Accessing ping test menu	36
	One shot ping test	37
	One shot ping of electric meter	39
	One shot ping of a EA_Gatekeeper	42
	One shot ping of gas module or AC-250 RMD	44
	One shot ping of a one-way water meter	49
	One shot ping of two-way water meter	52
	Continuous ping test	55
	Continuous ping of electric meter	56
	Continuous ping of a gatekeeper	58
	Continuous ping of gas or two-way water module	60
	Node to node ping test	62
	Editing continuous ping test settings	64
6	Locating a node	66
	About locating nodes	66
	Accessing node location menu	66
	Registered node locator	67
	Find all IDs	67
	Finding an ID	69
	Unregistered node locator	71
7	Reading meter data	74
	Accessing Read Meter Data menu	74
	Reading previous period data	75
	Reading current period data	76
8	Gas/Water Comms	78
	About gas and water communication	78
	Accessing Gas/Water Comms menu	78
	Reading gas/water comm info from an electric device	80
	Reading gas/water comm info from a gas/water device	81
9	Disconnecting and reconnecting meters	82
	About disconnecting and reconnecting electricity meters	82
	REX meter service control switch status	82
	REX2 meter service control switch status	82
	A3 ALPHA meter with internal polyphase service control	83
	About disconnecting and reconnecting gas meters	83
	Accessing Connect/Disconnect menu	84

	Reading status of the service control switch	85
	Checking load side voltage	87
	Connecting an electricity meter	88
	Disconnecting an electricity meter	89
	Reading the state of the secondary relay	91
	Connecting a secondary relay	91
	Disconnecting a secondary relay	92
	Controlling a gas valve	94
	Gas valve privileges	95
	Reading a gas valve's modules	96
	Battery alarm	99
	Hardware failure detected	99
	Opening a gas valve	100
	Closing a gas valve	103
	Controlling a meter's RF transmitter	105
	Reading the current state of an RF transmitter	106
	Disabling an RF transmitter	107
	Enabling an RF transmitter	107
10	Upgrading firmware	109
	About upgrading firmware	109
	REX2 meter with EA_NIC	109
	A3 ALPHA meter with EA_NIC	110
	Upgrading the EA_NIC firmware in the handheld	110
	Upgrading a gas or water module's firmware	112
	Upgrading a gas meter's RMD firmware	116
	Upgrading a meter's EA_NIC radio firmware	119
	Upgrading a REX2 meter's firmware	122
	Upgrading an A3 ALPHA meter's firmware	125
	Upgrading 900 MHz HAN devices	128
	Upgrading a 900 MHz HAN device's radio	128
	Upgrading a 900 MHz HAN device firmware	131
11	Configuring meters	136
	About HAN broadcasts	136
	Accessing HAN Broadcast menu	136
	Configuring HAN Broadcast settings	138
	Checking the status of the meter's HAN broadcast	139
	Turning off the meter's broadcast	141
	Turning on the meter's broadcast	143
	Setting meter associations	144
	Configuring water module leak settings	146
	Performing a demand reset on an electricity meter	148
12	Managing home area network devices	150
	Accessing Home Area Network menu	151
	ZigBee HAN device commands	152
	View devices	152
	Viewing HAN NIC information	154
	900 MHz HAN devices	154

	Commissioning a 900 MHz device	155
	Reading a 900 MHz HAN device	156
	Pinging a 900 MHz HAN device	157
	Method 1 - from the Commission Device screen	157
	Method 2 - from the Ping Device screen	158
	Decommissioning a 900 MHz device	159
	Reading a decommissioned device	161
	Configuring a 900 MHz device	161
	Accessing the Config 900 MHz HAN menu	161
	Configuring general parameters	162
	Configuring pricing parameters	164
	Clearing pricing parameters	166
	Configuring messaging parameters	167
13	Configuring the handheld	170
	About configuring the handheld	170
	Accessing handheld configuration menu	170
	Configuring handheld settings and utility IDs	171
	Configuring EA Defaults	175
	Viewing About EA_Inspector information	176
A	Troubleshooting	177
	General troubleshooting	177
	Trouble connecting to EA_Inspector Manager	177
	Communication mode errors and warning messages	177
	Verifying encrypted communications	178
	Elster contact	179

FCC and Industry Canada compliance

Compliance statement (Part 15.19)

Radix FW950 (equipped with the EnergyAxis network interface card) and Radix FW950 (equipped with the EnergyAxis network interface card and an external antenna) comply with Part 15 (Class B), Part 90 of the FCC rules and with RSS-210 of Industry Canada.

The FCC ID's are G8JHHI03 and G8JHHI04. The Industry Canada is 4557C-HHI03.

General information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Industry Canada statement

This device complies with Industry Canada license-exempt RSS-210 standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Industry Canada antenna statement

Radix FW950 (equipped with the EnergyAxis network interface card and an external antenna) incorporates an external antenna onto the handheld unit. For the handheld units please note the following statements as they relate to the external antenna on the handheld unit.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This radio transmitter IC:4557C-HHI03 has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio IC:4557C-HHI03 a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

- Antenna Part Number: 1B11922

Warning (Part 15.21)

Changes or modifications to the equipment not expressly approved by Elster could void the user's authority to operate this equipment.

User information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

RF exposure

A separation distance of at least 8 inches (20 cm) is to be maintained between the antenna and the human body and must not be co-located or operated in conjunction with any other transmitter or antenna.

Disclaimer of warranties and limitation of liability

There are no understandings, agreements, representations, or warranties either expressed or implied, including warranties of merchantability or fitness for a particular purpose, other than those specifically set out by any existing contract between the parties. Any such contract states the entire obligation of the seller. The contents of this technical manual shall not become part of or modify any prior or existing agreement, commitment, or relationship.

The information, recommendations, descriptions, and safety notices in this technical manual are based on Elster experience and judgment with respect to the operation and maintenance of the described product. This information should not be considered as all-inclusive or covering all contingencies. If further information is required, Elster should be consulted.

No warranties, either expressed or implied, including warranties of fitness for a particular purpose or merchantability, or warranties arising from the course of dealing or usage of trade, are made regarding the information, recommendations, descriptions, warnings, and cautions contained herein.

In no event will Elster be held responsible to the user in contract, in tort (including negligence), strict liability, or otherwise for any special, indirect, incidental, or consequential damage or loss whatsoever, including but not limited to: damage or loss of use of equipment, cost of capital, loss of profits or revenues, or claims against the user by its customers from the use of the information, recommendations, descriptions, and safety notices contained herein.

Safety information

Installation, operation, and maintenance of this product can present potentially hazardous conditions (for example, high voltages) if safety procedures are not followed. To ensure that this product is used safely, it is important that you:

Review, understand, and observe all safety notices and recommendations within this manual.

Do not remove or copy individual pages from this manual, as this manual is intended for use in its entirety. If you were to remove or copy individual pages, cross references and safety notices may be overlooked, possibly resulting in damage to the equipment, personal injury, or even death.

Inform personnel involved in the installation, operation, and maintenance of the product about the safety notices and recommendations contained in this manual.

Within this manual, safety notices appear preceding the text or step to which they apply. Safety notices are divided into the following four classifications:

NOTICE

Notice is used to alert personnel to installation, operation, or maintenance information that is important but not hazard related.

⚠ CAUTION

Caution is used to alert personnel to the presence of a hazard that will or can cause **minor** personal injury, equipment damage, or property damage if the notice is ignored.

⚠ WARNING

Warning is used to alert personnel to the presence of a hazard that **can cause** severe personal injury, death, equipment damage, or property damage if notice is ignored.

⚠ DANGER

Danger is used to alert personnel to the presence of a hazard that **will cause** severe personal injury, death, equipment damage, or property damage if the notice is ignored.

New in release 3.6

EA_Inspector Manager and EA_Inspector introduce the following new features:

- support for 900 MHz HAN devices
- support for enabling/disabling an RF transmitter
- support for controlling the AC-250 RMD (Remote Meter Disconnect) for gas meters

Note: The Radix FW950 handheld (Style No. 1C12455G01) should be equipped with an external antenna to perform actions on the AC-250 RMD. The external antenna allows the Radix handheld to issue commands to gas valves up to 900 feet from the handheld. Contact your Elster representative for more information.

Note: To use the new features in EA_Inspector 3.6, you must use EA_Inspector Manager 3.6. While EA_Inspector will function with prior releases of EA_Inspector Manager, to fully use the software requires EA_Inspector Manager 3.6.

Changes in release 3.6

- To prevent over-writing valid encryption seeds, EA_Inspector Manager checks for new seed data received from EA_MS.

Earlier releases would allow null key sets to overwrite valid keys in the EA_Inspector.

Caution: Elster strongly recommends that encryption seeds only be downloaded after seed changes are made.

1 INTRODUCTION

This document provides comprehensive operating instructions for the use of the EA_Inspector software.

About handheld devices

Handheld devices are lightweight and easy to use handheld computers for troubleshooting EnergyAxis meter communications using touch screen technology.

About This manual

This guide provides instructions for setup, operation and troubleshooting of the handheld device. It is structured for use as an adjunct to Elster system training, as well as a standalone instruction guide and reference. The screen shots shown in various illustrations may vary slightly from your handheld's display.

Audience

This document is designed for utility industry meter readers and supervisory staff.

In order to establish appropriate levels of detail for the material, this document assumes the following:

- The user is experienced in reading meters of the type currently compatible with Elster meters and possesses all the skills necessary to conduct meter reading by conventional means.
- The user has little or no prior expertise with automated metering infrastructure (AMI) technology.
- The user is competent in the basic use of computers and software.

New users

If you are new to Elster AMI products, or are new to AMI products in general, please take some time to go through all the sections of the user guide.

Existing users


If you are already familiar with Elster AMI products, you will still find it helpful to go through the Introduction and detail sections to understand how the features of the handheld device work together and what information is needed to perform each feature.

What is the EnergyAxis System?

The EnergyAxis System (Figure 1-1) is designed for residential and commercial and industrial (C&I) metering automation of electricity, gas and water. It is composed of up to three parts:

1. EnergyAxis Management System (EA_MS) that reads gatekeepers to gather meter data, analyzes RF LAN performance, and exports an XML file of all read data for importing into various enterprise systems such as billing, work order management, outage management, etc.
2. One or more 900 MHz radio frequency (RF) networks composed of an EA_Gatekeeper and up to 1024 or 2048 of the following meters:
 - REX, REX2, and gREX meters equipped with an EA_NIC
 - optional service control switch for remote reconnection/disconnection
 - optional ZigBee communications option board for home automation (REX2 meters only)
 - A3 ALPHA meters with the EA_NIC (EnergyAxis network interface card)
 - water meters equipped with EA_Water Module (900 MHz RF radio)
 - gas meters equipped with EA_Gas Module (900 MHz RF radio)
3. Optional – one or more home automation networks (HAN) composed of a REX2 meter with ZigBee comm option and one or more ZigBee-enabled home area devices (HAD) - for example, programmable thermostat, in home display, or load control device.


Figure 1-1. EnergyAxis System



Each gatekeeper gathers and stores meter data from its registered node meters and associated water and gas modules and manages the EA_LAN. These gatekeepers upload the data to the EnergyAxis Management System (EA_MS) via a public or private WAN either on a scheduled or on-demand basis.

Each REX and REX2 meter, EA_Repeater and A3 ALPHA node can act as **repeaters** that relay meter data from downstream, or **descendent**, meters up to the gatekeeper. When a repeater's RF transmission capability is blocked, the gatekeeper determines that something is wrong and initiates a node scan. The node scan re-builds the 900 MHz network bypassing the faulty node. In this manner, the network is called **proactive** and **self-healing**.

Figure 1-2. EnergyAxis proactive, self-healing mesh network



EnergyAxis tools

Elster provides the following software tools for use with the EnergyAxis System:

- EA_InstallerPlus
- EA_Inspector

Both of these software tools use the Radix FW950 handheld. If you are currently using the Radix FW900, contact your Elster representative for details on upgrading to the FW950 handheld.

The tools require the following additional Elster software installed on a computer:

- EA_InstallerPlus requires Route Manager
- EA_Inspector requires EA_Inspector Manager

The table below details the hardware and software compatibility of EA_Inspector and EA_InstallerPlus.

Hardware Platform	EA_Inspector			PI_900 Rel 1.0	EA_InstallerPlus Rel 2.0
	Rel 1.0	Rel 2.0	Rel 3.0		
Radix FW900 ^a	✓			✓	
Radix FW950		✓	✓		✓
Module Support					
EA_Water v1.0	✓	✓	✓	N/A	N/A
EA_Water v2.x and v3.x	N/A	N/A	✓	N/A	✓

Hardware Platform	EA_Inspector			PI_900 Rel 1.0	EA_InstallerPlus Rel 2.0
	Rel 1.0	Rel 2.0	Rel 3.0		
EA_Gas v1.0	✓	✓	N/A	✓	N/A
EA_Gas v2.x and v3.x	N/A	N/A	✓	N/A	✓

a. The Radix FW 900 hardware is obsolete. Contact Elster for upgrades to Radix FW 950.


EA_InstallerPlus

EA_InstallerPlus software uses the same hardware as EA_Inspector software. Both EA_InstallerPlus and EA_Inspector can run on the same handheld although not at the same time. Refer to the EA_InstallerPlus User Guide for details on operating the software.

Like EA_Inspector, the EA_InstallerPlus requires a manager application, Route Manager to function properly. Refer to the Route Manager User Guide for details on using Route Manager.

Once the handheld is synchronized using Route Manager, routes and accounts are loaded onto the handheld device. The user takes the handheld into the field to install EA_Gas or EA_Water modules.

Figure 1-3. EA_InstallerPlus handheld operation



Once the modules have been successfully installed, the user resynchronizes the handheld using Route Manager. Route Manager is used to create the CIS files for importing into EnergyAxis Management System (EA_MS). It also creates marriage files for the EA_Gas and EA_Water modules that are installed in the field. If EA_InstallerPlus has read any meters, the reading data is exported as AMRDEF files that can be imported into Billing or CIS systems.

EA_Inspector and EA_Inspector Manager


The EA_Inspector is a tool for use with EnergyAxis System. EnergyAxis devices are equipped with RF modules that transmit meter data to gatekeepers through the EA_LAN. The EA_LAN occasionally may need troubleshooting to locate issues and EA_Inspector is the tool designed to locate these issues.

EA_Inspector also performs firmware upgrades for devices in the field. EA_Inspector can also help locate unknown meters or determine the best placement for an EA_Repeater.

Before going into the field, the user synchronizes the handheld with EA_Inspector Manager. This loads and updates the user credentials (logon and permissions) and any other necessary security features.

Note: A new EA_Inspector handheld must be synchronized with EA_Inspector Manager prior to being used in the field to enable user logon capability.

Figure 1-4. EA_Inspector



Once the functions have been performed in the field, resynchronize the handheld using EA_Inspector Manager. EA_Inspector Manager is then used to export GPS coordinates, TOU and demand data and AMRDEF files. Additionally, activity logs (one encrypted and one unencrypted) are downloaded from the handheld.

Note: Encrypted logs are only accessible by the EA_Inspector Manager security administrator.

2 ABOUT THE HANDHELD

About the handheld

The handheld is a Radix FW950 device that functions as the platform handheld installation tool for Elster's EA_Gas and EA_Water modules, as well as supporting EA_Inspector.

The handheld is a rugged Radix handheld computer with the EnergyAxis network interface (EA_NIC) card installed. This handheld allows field personnel to install the EA_Gas and EA_Water modules onto gas meters. The handheld also supports controlling the AC-250 gas meter with Remote Meter Disconnect (RMD). The handheld also performs troubleshooting tasks for EnergyAxis meter RF communications.

Figure 2-1. Radix FW950 handheld (Style No. 7S1501G002)



Radix specifications

- Windows CE 5.0
- .NET Framework 1.1 or 2.0
- Marvell PXA270, 520MHz processor
- 128 MB RAM 512 MB flash drive
- 3.5" (89mm) 240 x 320 TFT 65K Color industrial grade touch screen
- 48-key ergonomic keypad with separate numeric keys
- User replaceable lithium-ion battery pack, 3 hour charge, up to 8 hours use
- EnergyAxis network interface card (EA_NIC)
- Elster software
- RF Transmitter - 451 MHz (wake-up tone); 900 MHz
- RF Receiver - 900 MHz

- FCC compliance: Part 90 and Part 15. The FCC ID is G8JHHI03.
- Operating temperature: -4 °F to +140 °F (-20 °C to + 60 °C)
- USB, Ethernet, serial, IPP, multiple communications ports
- IP-67 rated (1 meter submersion)
 - Elster nose cone is IP-67 rated (1 meter submersion)
- MIL-STD-810F method - 1.5 meter drop onto concrete test
- Optional - the Radix handheld supports using an external antenna for use with the AC 250 Remote Meter Disconnect (RMD) valve control module.

Figure 2-2. Radix FW950 with external antenna (Style No. 1C12455G01)




Safe RF exposure using external antenna

The antenna used for the Radix transmitter must be installed to provide a separation distance of at least 8 inches (20 cm) from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

EA_Inspector Manager

EA_Inspector Manager synchronizes the handheld with a host computer. Synchronizing the handheld copies files between the handheld and the host computer.

Figure 2-3. Handheld-to-meter RF communication



Before EA_Inspector can be run, EA_Inspector Manager must load the following files onto the handheld:

- user credentials (user names and passwords) file¹
- meter ID (marriage) file²
- LAN seed file³
- 900 MHz HAN parameter files⁴

After the first synchronization, the EA_Inspector is ready to be used in the field.

1. Required to operate the handheld.
2. Only required if operating in meter ID mode; LAN ID mode works without marriage files.
3. Not required to operate; only needs to update LAN seeds if changes were made.
4. Only needed if HAN operations are planned.

EA_Inspector

The EA_Inspector is a tool for the EnergyAxis System. EnergyAxis devices (electricity, gas, and water meters and in-home devices) are equipped with RF modules that transmit meter data to EA_Gatekeepers through the EA_LAN. The EA_LAN occasionally may need troubleshooting to locate issues and EA_Inspector is the tool designed to locate these issues. EA_Inspector also performs firmware upgrades for devices in the field. EA_Inspector can also help locate unknown meters or determine the best placement for an EA_Repeater.

The software performs the following actions:

- ping test
- locate node
- read meter data
- gas/water comms
- disconnect and reconnect meters
- update firmware
- configure meters
- manage home area network devices

Note: The handheld may also be loaded with EA_Installer or EA_InstallerPlus software. Both EA_InstallerPlus and EA_Inspector may be installed on the same handheld; however, only one application may be active at a time.

Transmission accuracy

The accuracy of transmitted data is insured in two ways:

- the meter only replies after detection of its unique ID (serial number or LAN ID)
- the EA_NIC and module transmits an error-detection code with the meter data that is used by the handheld to confirm that the data has been received without errors.

Navigating the software

Simple menu commands allow access to the software functions. These commands fall into the following categories:

Main Menu	Sub menu	Sub menu
RF Troubleshooting	Ping	One shot ping test
		Continuous ping test
		Node to node ping test
	Registered node locator	
	Unregistered node locator	
	Gas/Water Comms	Read from Electric Read from Gas/Water
Read Meter Data	Read Current Data Read Previous Data	

Main Menu	Sub menu	Sub menu	
Connect/Disconnect	Load Side Power	Read Current State Load Side Voltage Check Connect Disconnect	
	Secondary Relay	Read Current State Open Relay Close Relay	
	Gas Valve Control	Read Open Close	
	RF Control	Read Current State Disable RF (Transmitter) Enable RF (Transmitter)	
Config Meter	HAN Broadcast	Read Current State Start - turn ON End - turn OFF	
	Meter Association EA_Water Module Demand Reset Firmware Upgrade		
Home Area Network	ZigBee HAN	View Devices HAN NIC Info	
	900 MHz HAN	Commission Ping Decommission	
Configure			General Pricing Messaging Firmware Upgrade
HH Config	HH settings EA Defaults		

Database warning

Do not attempt to modify or edit any of the database tables or files outside of the Elster handheld / EA_Inspector Manager environment without prior authorization by Elster technical support personnel. Unauthorized manipulation of these files may void your software service agreements.


3 OPERATING THE HANDHELD

Commonly used keys

The handheld's keyboard allows the user to access software functions. The handheld responds to keystrokes independent of hardware.

Note: All letters are assumed to be upper case. Function keys <F1> - <F4> are also used.

Figure 3-1. Radix handheld keyboard



<Esc>

- Powers on the device
- Cancels operation
- Exits screen

<Enter>

- In menus/list boxes, selects item
- In editable field, submits entry

Arrow keys

These keys (<Up>, <Down>, <Left>, and <Right>) are used to navigate directionally in the screen.

<Tab>

- Navigates between fields within the current screen (for example, messages and search).

Entering responses (Yes/No)

You respond to questions using either of the following methods:

- Tap the button **Yes** or **No** with the stylus
- Press <Y> or <N> on the keyboard
- Moving to the desired button by using left/right arrow keys and pressing <Enter> when the button is highlighted

Using the stylus

Use the stylus to tap a command button or to move focus to a data entry field. If you do not have a stylus, use the tip of your fingernail (not the soft pad of your finger).

Turning the device on and off

To turn the handheld on, press and hold any key until the handheld turns on.

The handheld turns off automatically after the handheld had been idle for more than one minute off the charging cradle; the idle timeout is configurable.

Charging the device

Place the handheld in its cradle to recharge the battery. The red Battery Status Light on the top right corner of the handheld will flash on and off while the battery is charging. Once that battery is fully charged, the status light will remain on.

Resetting the handheld device

To reset the handheld:

1. Hold down the <R> + <X> + <↑> keys down simultaneously for several seconds.
2. Release the keys when the screen goes blank.
3. Recalibrate the touch screen as directed.


Note: Resetting the handheld in the cradle will remove the EA_Inspector application short-cut from the desktop.

Opening EA_Inspector

To access EA_Inspector:

1. From the handheld's desktop, select the EA_Inspector icon and press <Enter>.

Figure 3-2. Handheld desktop



The EA_Inspector splash screen displays.


Figure 3-3. EA_Inspector splash screen



The EA_NIC loads the EA_Inspector firmware.


Note: You will see the RF Firmware Load screen only if EA_Inspector detects a firmware file with a different version in the handheld than the existing EA_NIC firmware version. If the firmware file version is higher than the current firmware version in EA_NIC, EA_Inspector will upgrade the EA_NIC firmware. Otherwise, EA_Inspector will ask the user "Are you sure you want to update vm.m over vn.n?"

Figure 3-4. Loading firmware



2. Click **OK** to acknowledge the firmware is loaded.

Figure 3-5. Firmware loaded



The login screen displays. See "Logging in to the handheld" on page 25 for instructions on logging in to EA_Inspector.

Logging in to the handheld

Before you can operate the EA_Inspector on the handheld, you must first synchronize the handheld with EA_Inspector Manager. This ensures that users' credentials and other needed files are downloaded to the handheld.

See the **EA_Inspector and EA_Inspector Manager Installation and Administration Guide** for details on synchronizing the handheld with EA_Inspector Manager.

Note: A new EA_Inspector handheld must be synchronized with EA_Inspector Manager prior to being used in the field to ensure user logon capability. Without an initial synchronization, a user cannot log onto the EA_Inspector application on the handheld.

Note: If the expiration date is passed, you cannot log in to EA_Inspector. You must have the Security Administrator synchronize the handheld with EA_Inspector Manager to reset the HH expiration date.


Note: The Login ID and password are not case sensitive. So you do not need to be concerned about typing upper and lower case letters.

To login to EA_Inspector:

1. Enter your **Login ID**.

Note: A Security Admin cannot log in to EA_Inspector. The Security Admin privilege applies to EA_Inspector Manager only.

Figure 3-6. Login screen



2. Enter your **Password**.
3. Click **OK**.


EA_Inspector displays the Main Menu.

— OR —

If the expiration date has passed or a new handheld was not synchronized, a note displays. Your system administrator will need to synchronize the

handheld with EA_Inspector Manager to load user logon information and set the handheld's expiration date.

Figure 3-7. Handheld expiration



— OR —

To properly use EA_Inspector, the handheld must be synchronized with EA_Inspector Manager.

Depending on the user's permissions and privileges (see EA_Inspector Installation and Administration Guide) the handheld may respond in unexpected ways.


If the handheld has not been synchronized with EA_Inspector Manager, the handheld displays a message "No meter SN/LAN ID file exists. Please update with EA_Inspector Manager."

Table 3-1. Permissions and privileges

EA_Inspector Manager	User ID	Handheld	EA_Inspector software
Synchronized Handheld files ^a	Allow LAN ID privilege	UseLANID setting enabled	Behavior
Yes	Yes	Yes	<ul style="list-style-type: none"> • Uses meter LAN ID to identify devices.
Yes	No	No	<ul style="list-style-type: none"> • Displays a message "No meter SN/LAN ID file exists. Please update with EA_Inspector Manager." • Uses meter Serial Number (SN) to identify devices.
Yes	Yes	No	<ul style="list-style-type: none"> • Displays message "No SN/LAN ID file found: Use LAN ID mode enabled." • Automatically enables UseLANID. • Uses meter LAN ID to identify devices.

- a. Refer to the EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details on synchronizing the handheld using EA_Inspector Manager.

Figure 3-8. EA_MS meter and Meter ID file not on handheld




No SN/LAN ID file but without
Allow LAN ID privilege

Logon disabled

No SN/LAN ID file but with
Allow LAN ID privilege

Logon enabled

Figure 3-9. EA_Inspector Main Menu



Holding the handheld for meter reading

When using a handheld device to read a meter, hold the handheld device upright.

Note: The stronger RF signals radiate out of the extended antenna from the front and back of the cover.


Figure 3-10. Handheld-to-meter RF communication



4 ABOUT EA_INSPECTOR SOFTWARE

After successfully logging into the handheld device, you will see the main menu screen.

Figure 4-1. EA_Inspector Main Menu



The main menu screen allows the selection of the following modes:

1. RF Troubleshooting
 - Ping
 - Locate node (registered and unregistered)
 - Gas/Water Comms
2. Read Meter Data
 - Read Current Data
 - Read Previous Data
3. Connect/Disconnect
 - Load Side Power:
 - Read current state
 - Load side voltage check
 - Connect
 - Disconnect
 - Gas Valve Control
 - Read

- Open
- Close
- RF Control
 - Read Current State
 - Disable RF (Transmitter)
 - Enable RF (Transmitter)
- Secondary Relay:
 - Read Current State
 - Open Relay
 - Close Relay
- 4. Configure Meter
 - EA HAN Broadcast
 - Meter Associations
 - EA_Water Module
 - Demand Reset
 - Firmware Upgrade
- 5. Home Area Network
 - ZigBee HAN
 - Ping
 - Devices
 - Channels
 - HAN NIC Info
 - 900 MHz HAN
 - Commission
 - Ping
 - Configure
 - Decommission
- 6. HH Configuration
 - HH Settings
 - EA Defaults

Navigating the software

Instead of using the stylus to navigate the software, you can press the number preceding the command. For example, from the main menu screen you can press the keys to access the commands:

Key	Command
<1>	RF Troubleshooting
<2>	Read Meter Data
<3>	Connect/Disconnect
<4>	Configure Meter
<5>	Home Area Network
<6>	HH Configuration
<0>	Exit

You can also use the arrow keys to navigate up and down the list of commands and then press <Enter> to execute the command.

Additionally, the first letter of each button label is an accelerator key for that function. For example, <S> for **Save**, <P> for **Ping**, <C> for **Cancel**, etc. <ESC> can be used for **Cancel** or for exiting any menu.

User privileges

Depending on the privileges set by the system administrator when adding a user in EA_Inspector Manager, the user may use the LAN ID or the Serial Number to identify a device. Refer to the EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details on user privileges.

If the user has the Allow LAN ID privilege, the user may use the device's LAN ID on data entry screens. If the user does not have the Allow LAN ID privilege, the user must enter the device's Serial Number (S/N) on data entry screens.

Note: To use MAS 6.2 or earlier, you must have Allow LAN ID privileges.

Note: If Allow LAN ID is disabled and the EA_MS 7.0 meter name and LAN ID data have not been downloaded to the handheld, the user will not be able to use EA_Inspector. See "Downloading meter and LAN ID information" on page 33 for details.

In addition to the user having the proper privileges to Allow LAN ID, the handheld itself must be enabled to Use LAN ID. See Table 3-1 on page 26 and "Configuring handheld settings and utility IDs" on page 171 for details on configuring the handheld to use LAN IDs.


Saving notes and GPS data

To enter any action notes or collect GPS data:

1. Click **Save** on any screen.


The Notes screen displays allowing you to enter any notes regarding the activity.

Figure 4-2. Notes screen



2. Additionally, you can click **GPS** to collect the GPS coordinates for the handhelds current location at the time of the communication. The GPS Details screen displays.

Figure 4-3. GPS Details screen



- The GPS Details screen indicates the status of the attempt to get GPS coordinates.
- A successful read displays a status of GPS Info Completed.
3. If the GPS read fails, press **Retry** or <R> to retry the operation.
 4. Click **OK** to exit the screen and save the coordinate values. Click **Cancel** to return to the previous screen without GPS values.

Exiting EA_Inspector

1. While the Main Menu screen is open, press <Esc> or press **Exit** to exit the software.

A dialog displays asking you to confirm you wish to exit.

Figure 4-4. Exiting EA_Inspector



2. Use <Tab>, <Left> or <Right> arrow keys to select the response.

— OR —

Touch **Yes** or press <Y> or press <Enter> when the button is highlighted to accept the selection.

Touch **No** or press <N> or press <Enter> when the button is highlighted to cancel.


Exiting from the login screen

To exit without logging in:

1. From the Login screen, press **Exit**.

A dialog displays asking you to confirm you wish to exit.

Figure 4-5. Exiting EA_Inspector



2. Use <Tab>, <Left> or <Right> arrow keys to select the response.

— OR —

Touch **Yes** or press <Y> or press <Enter> when the button is highlighted to accept the selection.

Touch **No** or press <N> or press <Enter> when the button is highlighted to cancel.

5 PERFORMING A PING TEST

About ping tests

A ping test sends an RF command to an EnergyAxis RF module (EA_NIC) or meter and retrieves the devices ID and serial number. A ping test sends ten packets, receives ten packets in response and reports the average received signal strength indication (RSSI) from the ten attempts. RSSI is displayed in decibel milliWatts (dBm) except for [Node to node ping test](#) which uses the range of 0 to 7 where 0 indicates no signal and 1 indicates the best (or maximum) RSSI and 7 indicates the worst RSSI:

RSSI	Strength (in dBm)
0	no signal
1	> -40 best
2	≤ -40 and > -50
3	≤ -50 and > -60
4	≤ -60 and > -70
5	≤ -70 and > -80
6	≤ -80 and > -90
7	≤ -90 worst


The continuous ping test performs multiple ping tests in sequence.

Accessing ping test menu

To access the Ping Test menu:


1. From the Main Menu, select RF Troubleshooting.

Figure 5-1. EA_Inspector Main Menu



The RF Troubleshooting menu displays.


Figure 5-2. RF Troubleshooting menu



The RF Troubleshooting menu displays.

2. From the RF Troubleshooting menu, select Ping.

Figure 5-3. Ping Test menu



3. The Ping Test menu allows you to select from the following list of ping tests:

- One shot ping test
- Continuous ping test
- Node to node ping test

One shot ping test

To perform a one shot ping:

1. From the **Ping Test** menu, select **One Shot**.

The One Shot Ping Test menu displays.

Note: Depending on the type of utility, you may see the One Shot Ping Test menu for an electric, gas and water utility or the One Shot Ping Test menu for an electric and gas utility. However, if the handheld is set up for electric only, you will not see the One Shot Ping Test menu. Instead you will see the Ping Test input screen.

1: Electric

Figure 5-4. Ping menu for electric, gas and water utility





Figure 5-5. Ping menu for electric and gas utility



2. The One Shot Ping Test menu allows you to select from the following ping tests:
 - 1) One shot ping of electric meter
 - 2) One shot ping of gas module or AC-250 RMD
 - 3) One shot ping of a one-way water meter
 - 4) One shot ping of two-way water meter

One shot ping of electric meter

To perform a one shot ping of an electric meter (REX, REX2, EA_Repeater, EA_Gatekeeper or A3 ALPHA node):

1. From the One Shot Ping Test menu, select **Electric**.
See “One shot ping of a EA_Gatekeeper” on page 42 for details on pinging a gatekeeper.
EA_Inspector displays the ping test input screen.

Figure 5-6. Ping test input screen


The figure shows two versions of the ping test input screen. The left version has an 'ID' text box at the top, followed by an unchecked checkbox labeled 'Is GK'. Below this are labels for 'GK:', 'Parent:', 'Level/Desc:', 'Total KWh:', 'Host/RadioFW:', 'Packets:', 'RSSI:', and 'Meter RSSI:'. At the bottom are three buttons: 'Ping', 'Save', and 'Cancel'. The right version has a 'LAN ID' text box at the top, followed by a checked checkbox labeled 'Is GK'. It has the same labels and bottom buttons as the left version.

Use LAN ID unchecked

Use LAN ID checked

2. Enter the ID of the electric meter to be pinged.
Note: To use the LAN ID to ping devices, you must have Allow LAN ID privilege (see EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details) as well as Use LAN ID enabled on the handheld (see “Configuring handheld settings and utility IDs” on page 171 for details). To use the meter’s serial number to ping devices, your system administrator must download EA_MS meter ID (marriage data) file from EA_MS and synchronize the file to the handheld.
3. Check if the device **Is a GK** (gatekeeper).
4. Click **Ping**.
The ping test occurs and the input screen displays the results as they are received.

Figure 5-7. Successful ping test results - REX2 meter



Serial No. not in database


Note: If the entered ID is not in the downloaded EA_Inspector file, the display lists the ID and a message that the specified ID is unknown.

The ping test results displays the following information:

Item	Description
GK (Gatekeeper)	Indicates the pinged meter's registered gatekeeper.
Parent	Indicates the parent node (or repeater) of the pinged meter.
Level/Desc	Example, 2/1 - The 2 (Level) indicates the node level from the registered gatekeeper of the pinged meter (for example, a node level of 2 indicates that the pinged meter communicates with its registered gatekeeper through one repeater meter); the 1 (Desc) indicates the number of repeater descendants below.
Total kWh	Indicates the Total kWh in the pinged meter's register.
Host/RadioFW	Indicates the firmware version for the host and the radio of the pinged meter.
Packets	Indicates the number the packets received/number of sent . For example, 7/10 indicates that 7 out of 10 packets were received.
RSSI	Indicates the EA_NIC's received signal strength indicator in dBm ^a .
Meter RSSI	For REX2 meters FW 3.0 or higher, indicates the meter's received signal strength indicator (in dBm).


a. Decibel milliwatts (also dBmW).

Figure 5-8. Communication warnings



- If you receive a communication error or warning message [Figure 5-8], see [“Communication mode errors and warning messages”](#) on page 177 for details on troubleshooting communication problems.
5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.
- EA_Inspector opens a Notes screen. See [“Saving notes and GPS data”](#) on page 31 for details on collecting and saving GPS data.

Figure 5-9. Entering notes for saving to log



6. Use the keyboard to enter any notes regarding the test.
7. Press <Enter> to save your notes to the activity log and exit the test.

— OR —

Press <Esc> to exit the test without saving your notes.


One shot ping of a EA_Gatekeeper

Note: If you are pinging a gatekeeper with FW v4.x or 5.x, you must turn off encryption in the handheld. See “Configuring handheld settings and utility IDs” on page 171 for details.

To perform a one shot ping of a EA_Gatekeeper (both enclosure-based and in an A3 ALPHA meter):


1. From the One Shot Ping Test menu, select **Electric**.
EA_Inspector displays the ping test input screen.
2. Check **Is GK (Gatekeeper)**.
3. Enter the **ID** of the gatekeeper to be pinged.
4. Click **Ping**.

Figure 5-10. One shot ping of a gatekeeper



The ping test occurs and the input screen displays the results as they are received.

Figure 5-11. Successful ping of gatekeeper



5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.


EA_Inspector opens a Notes screen. See [“Saving notes and GPS data”](#) on [page 31](#) for details on collecting and saving GPS data.

One shot ping of gas module or AC-250 RMD

To perform a one shot ping of a gas meter's RF module or on an AC-250 RMD (valve control module):

1. From the One Shot Ping Test menu, select **Gas**.
EA_Inspector displays the ping test input screen.

Figure 5-12. Ping test input screen

LAN ID:
Read: 
PreDiv:
PCF:
Time:
Trans Period:
Trans Var:
Firmware:
More **Clear Status**
Pkts,RSSI:
Ping **Save** **Cancel**

2. Click **Ping**.
EA_Inspector prompts you to hold a magnet on the gas module for 3 seconds.

Figure 5-13. Hold magnet prompt

Hold magnet on RTM
unit for 3 seconds.
Cancel
Trans Var:
Firmware:
More **Clear Tmpr**
Pkts,RSSI:
Find Module
Ping **Save** **Cancel**

3. Hold the magnet on the bottom left of the gas module approximately 0.5 inches in from the left edge (see Figure 5-14, Figure 5-15, and Figure 5-16).

Figure 5-14. Holding magnet on gas module v1.0






Figure 5-15. Holding magnet on gas module v2.0




The EA_Gas v3.0 module requires a magnet swipe unless it is operating in Mobile mode or in Hybrid (Fixed and Mobile) mode.

Figure 5-16. Holding magnet on gas module v3.0



The ping test occurs and the input screen displays the results as they are received.

Figure 5-17. Successful ping test results



The ping test results displays the following information:


Item	Description
ID	Indicates the serial number ID of the EA_Gas module.
Read	Indicates the index reading (that is, gas usage).

Item	Description
Status drop list	<ul style="list-style-type: none"> • EncReadErr - a problem has occurred when reading an encoder-type water module; it means a bad digit was read. If Tamper is also set, it means a complete read failure. • RESET_ERROR - the module has been reset since the last clear data. This flag is always set at power up, but will be cleared at final assembly, and at install. • TiltTmpr - Indicates the meter has a tilt tamper condition in effect. • SwitchTmpr - for Water modules this indicates a Leak condition has been detected; indicates the meter has a switch tamper condition in effect as the result of holding a magnet next to the gas module for more than 5 minutes. • LowBattery - indicates that the battery has fallen below the set threshold after a transmit; this is a latched status. • BackFlow - for water modules with encoder-type registers; indicates a back flow condition has been detected • OverLimit - for water modules with encoder-type registers; indicates an over limit condition has been detected • ModuleErr- indicates a configuration error, CRC error, or EEPROM write error has occurred; this is a latched status.
PreDiv	Indicates the Predivider; the number used to convert meter pulses to index usage value. A predivider of 50 means that 50 pulses received from the meter converts to one index read.
PCF	Indicates the pressure compensation factor used to adjust the meter reading for billing.
Time	Indicates the date and time kept in the module.
Trans period	Indicates the number of hours between gas module transmissions of data to its associated gatekeeper. For example, if Trans period is 4 hours, the gas module transmits its data to the gatekeeper every 4 hours.
Trans var	Indicates the window time for the gas module to transmit its data. For example, if the Trans period is 4 hours and the Trans variance is 4 hours, the gas module transmits its data to the gatekeeper at a randomly selected time between 4 AM and 8 AM.
Firmware	Indicates the firmware version used by the EA_Gas module.

4. If the display indicates one or more tamper statuses, click **Clear Status** to clear the statuses from the module.


Note: If a tamper status is not in effect, the Clear Status button will appear disabled.

Figure 5-18. Clearing a status



5. Click **More** to view more information on the gas meter and module.

Figure 5-19. View more information



The More screen displays the following additional information about the gas meter:

Item	Description
SubCount	Indicates the pulse count stored internally in the meter before the predivider is applied to obtain the meter read.
IntDiv/Len	Indicates the Interval Divisor and Length in minutes for determining interval data.

Item	Description
DailySnapshot	Indicates the time of the day at which the meter read is recorded for the daily read.
Style	Indicates the Elster style number for the gas module.
Assembly	Indicates the Elster assembly serial number.
DST	Indicates the time of the daylight saving time change followed by the recurring day and month for the Spring and Fall DST change dates. For example, 2nd Sun/3 indicates the second Sunday in March and 1st Sun/11 indicates the first Sunday in November.
OPMode	Indicates the operating mode of the meter: <ul style="list-style-type: none"> • 0 - EnergyAxis System - the default network mode set after installation using the PI 900 handheld software • 1 - Walk By/Drive By • 2- EAHybrid - Future use • 3- Legacy - Future use • 4 - DeepSleep - factory shipped mode • 5 - Burn-in - mode used during factory configuration

- To return to the previous screen, use a stylus or finger to press **More** on the handheld’s display.
6. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.


One shot ping of a one-way water meter

To ping a one-way or two-way water module, you must perform a **Find** that reports the data transmitted by the water module after a magnet triggers an RF transmission. See [“One shot ping of two-way water meter” on page 52](#) for details on pinging a two-way water module.

To perform a one shot ping of a one-way water meter’s RF module:

1. From the One Shot Ping Test menu, select **Water**.
 EA_Inspector displays the ping test input screen.

Figure 5-20. Ping test input screen




The screenshot shows a dialog box with the following labels: **ID:**, **LAN ID:**, **EncReg:**, **Mt Read:**, and **Status:**. Below these labels is a large empty rectangular text input field. At the bottom of the dialog box are three buttons: **Find** (highlighted with a blue border), **Save**, and **Cancel**.

2. For a one-way water module, click Find.

EA_Inspector prompts you to hold a magnet on the water module for 3 seconds.

Figure 5-21. Hold magnet prompt




The screenshot shows a dialog box with a grey top section containing the text: **Hold magnet on RTM unit for 3 seconds.** Below this text is a **Cancel** button. The bottom section of the dialog box has a yellow background and contains a large empty rectangular text input field. Below the input field is the text **Find Module** and three buttons: **Find**, **Save** (highlighted with a blue border), and **Cancel**.

3. Lift the cover over the water meter.

4. Hold the magnet on the bottom center of the water module (see Figure 5-22).

Figure 5-22. Holding magnet on water meter module 1.0



The ping test occurs, the water module transmits one packet of data that the input screen displays.

Figure 5-23. Successful ping test results

ID:	08765321	
LAN ID:	72321716	
EncReg:	6621657630	
Mt Read:	7	
Status:		
<input type="text"/>		
Module Found		
<input type="button" value="Find"/>	<input type="button" value="Save"/>	<input type="button" value="Cancel"/>

The ping test results displays the following information:

Item	Description
ID	Indicates the serial number ID of the EA_Water module.
LAN ID	Indicates the LAN ID for the EA_Water module.
EncReg	Indicates the encoder register number.
Mt Read	Indicates the meter reading (that is, total water usage).
Status	Indicates the status of the meter or module: <ul style="list-style-type: none"> • Bad Digit - indicates data received from the encoding register was corrupted • Leak - alarm indicating the meter detected a possible leak • No Read - indicates that module did not receive data from the meter • Tamper - alarm indicating the meter detected a possible tamper event

5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

One shot ping of two-way water meter


You can perform a standard ping test a two-way EA_Water 2.0 module. Two-way water modules may be either encoder-based modules or pulse-based modules.

See [“One shot ping of a one-way water meter” on page 49](#) for details on pinging a one-way water meter.

To perform a one shot ping of a two-way water meter’s RF module:

1. From the One Shot Ping Test menu, select **Water**.
EA_Inspector displays the ping test input screen.

Figure 5-24. Ping test input screen



EA_Inspector prompts you to hold a magnet on the water module for 3 seconds to waken the module.

The EA_Water v3.0 module requires a magnet swipe unless it is operating in Mobile mode or in Hybrid (Fixed and Mobile) mode.

Figure 5-25. Holding magnet on water meter module 2.0/3.0






Figure 5-26. Holding magnet on pit mounted meter module



2. For a two-way water module, click **Ping**.


EA_Inspector pings for any two-way water modules within range. The water module responds to the ping.

Figure 5-27. Successful ping two-way water module



3. Click **Clear Status** to clear the statuses in the module.
The handheld displays the results after the statuses are cleared.
4. Click **More** to view additional information.

Figure 5-28. Clear statuses



- To return to the previous screen, use a stylus or finger to press **More** on the handheld's display.
5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Continuous ping test

A continuous ping test performs multiple ping tests lasting for the number of minutes specified by the **Test Time** with a delay time of a specified number of **Seconds Between Pings**. For example, by default, a continuous ping test would perform a ping test lasting 2 minutes with a delay of 5 seconds between ping tests on an electricity meter.

See [“Editing continuous ping test settings” on page 64](#) for details on changing settings.

Note: For a continuous ping on a gas module or a two-way water module, the time between pings is 0.8 seconds and cannot be configured.


Note: You cannot perform a continuous ping test on a one-way water meter. You can perform a Find on a one-way water meter. See [“One shot ping of a one-way water meter” on page 49](#) for details.

The continuous ping test performs multiple ping tests of an EA_Gas module, REX, REX2 and A3 ALPHA meters and EA_Gatekeeper and EA_Repeater.

To perform a continuous ping test:

1. From the Ping Test menu, select **Continuous**.
The Continuous Ping Test menu displays.

Figure 5-29. Continuous ping menu and settings



2. From the Continuous Ping Test menu, you can select to perform one of the following:
 - 1) Continuous ping of electric meter
 - 2) Continuous ping of gas or two-way water module
 - 3) Editing continuous ping test settings

Continuous ping of electric meter

To perform a continuous ping of an electric meter (REX, REX2, EA_Repeater, EA_Gatekeeper or A3 ALPHA node):

1. From the Continuous Ping Test menu, select **Electric**.

See “Continuous ping of a gatekeeper” on page 58 for details on pinging a gatekeeper.

EA_Inspector displays the ping test input screen.

Figure 5-30. Ping test input screen


The screenshot shows a dialog box for configuring a ping test. At the top, there is a label 'ID' followed by a rectangular input field. Below this is a checkbox labeled 'Is GK'. Underneath the checkbox is the text 'Pkts, RSSI, Meter RSSI' in a bold font. This is followed by a large, empty rectangular box intended for displaying test results. At the bottom of the dialog, there are three buttons: 'Ping', 'Save', and 'Cancel', each in its own rectangular button.

2. Enter the **ID** of the electric meter to be pinged.

3. Click **Ping**.


The ping test occurs and the input screen displays the results as they are received.

Figure 5-31. Result of continuous ping of electric meter



Note: Only REX2 meters with FW 3.0 or higher return Meter RSSI.
The continuous ping test continues displaying the results of each test until the testing is complete.

Figure 5-32. Continuous ping test complete



The ping test results display the number the packets received/number of sent, RSSI. For example, 9/10,-23, -19, indicates that nine packets were received out of ten packets sent for an RSSI of -23 dBm and a meter RSSI of -19 dBm.

- Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See "Saving notes and GPS data" on page 31 for details on collecting and saving GPS data.

Continuous ping of a gatekeeper

Note: If you are pinging a gatekeeper with FW v4.x or 5.x, you must turn off encryption in the handheld. See "Configuring handheld settings and utility IDs" on page 171 for details.

To perform a continuous ping of an A3 ALPHA gatekeeper:


- From the Continuous Ping Test menu, select **Electric**.
EA_Inspector displays the ping test input screen.
- Check **Is GK (Gatekeeper)**.

Figure 5-33. Continuous ping test - gatekeeper

The screenshot shows a dialog box for a continuous ping test. At the top, there is a text input field labeled "ID" containing the number "04836519". Below this is a checkbox labeled "Is GK" which is checked. Underneath the checkbox, the text "Pkts, RSSI, Meter RSSI" is displayed. A large empty rectangular box is positioned below this text. Further down, the labels "Avg Packets:" and "Avg RSSI:" are visible. At the bottom of the dialog, there are three buttons: "Ping", "Save", and "Cancel".


- Enter the **ID** for the gatekeeper.

Figure 5-34. Continuous ping test - gatekeeper



4. Click Ping.

Figure 5-35. Continuous ping test - gatekeeper



5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.


EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on page 31 for details on collecting and saving GPS data.

Continuous ping of gas or two-way water module

To perform a continuous ping of a gas or two-way water meter's RF module:

1. From the Continuous Ping Test menu, select **Gas/Water**.
EA_Inspector displays the ping test input screen.

Figure 5-36. Ping test input screen



ID:
Packets, RSSI


Avg Packets:
Avg RSSI:

Ping **Save** **Cancel**

2. Click **Ping**.


EA_Inspector prompts you to hold a magnet on the gas/water module for 3 seconds. See Figure 5-14 for an illustration on how to hold the magnet on a gas module. See Figure 5-22 for an illustration on how to hold the magnet on a water module.

Figure 5-37. Hold magnet prompt



The ping test occurs and the input screen displays the results as they are received.

Figure 5-38. Result of continuous ping of gas RF module



The continuous ping test continues displaying the results of each test until the testing is complete.

The ping test results display the number the packets received/number of sent, RSSI. For example, 9/10, -22 indicates that nine packets were received out of ten packets sent for an RSSI of -22 dBm.

3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See "Saving notes and GPS data" on page 31 for details on collecting and saving GPS data.

Node to node ping test

A node-to-node ping test signals a meter to ping another meter (whether a REX, REX2, EA_Repeater or A3 ALPHA meter). The node-to-node ping test requires the initiator node is a meter registered to a gatekeeper.

Initiator	Responder
REX meter Note: REX meters FW 4.1 cannot initiate node to node ping tests. REX2 meter gREX meter EA_Repeater A3 ALPHA meter/node	any meter Note: REX meters FW 4.1 and higher can respond to node to node ping tests.

Note: An A3 ALPHA gatekeeper cannot initiate or respond to a node-to-node ping test.

To perform a node-to-node ping test:

1. From the Ping Test menu, select **Node to Node Ping**.
EA_Inspector displays the Node to Node Ping dialog.

Figure 5-39. Node to node ping input screen

Node to Node Ping

Initiator

Responder


Attempts:

RSSI:

Ping **Save** **Cancel**

2. Enter the ID of the **Initiator** (the meter initiating the ping).
3. Enter the ID of the **Responder** (the meter to be pinged).
4. Click **Ping**.

Figure 5-40. Ping in process



EA_Inspector displays the results of the node-to-node ping including the number of packets sent and the RSSI as a range of 0 to 7 where 0 indicates no signal and 1 indicates the best (or maximum) RSSI and 7 indicates the worst RSSI. See "About ping tests" on page 35 for details on RSSI and dBm range represented by the node-to-node ping results.

Figure 5-41. Successful node-to-node ping



5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Editing continuous ping test settings

EA_Inspector allows you to configure the following continuous ping test settings:


- Ping packet repeats
- Test time (in minutes)
- Seconds between Pings (applies to electricity meters only)

See [“About ping tests” on page 35](#) for details about RSSI and signal strength.

To change ping test settings:

1. From the Continuous Ping Test menu, select **Edit Ping Settings**.
EA_Inspector displays the Ping Settings dialog.

Figure 5-42. Edit continuous ping test settings



2. Edit the settings as needed:

- Ping Packet Repeats - the number of additional packets transmitted at different frequencies within the 900 MHz unlicensed band
For example, if packet repeats is set to the default of 2, a total of 3 packets (1 packet plus an additional 2 packets) would be send over each of 3 different frequencies in the 900 MHz band.
- Test Time (in minutes) - the duration time (in minutes) of the ping test
- Seconds between Pings - the delay time (in seconds) between ping tests; applies to electricity meters only

Note: For a continuous ping on a gas module, the time between pings is 0.8 seconds and cannot be configured.

3. Click **Save** to save your changes.

You are ready to perform a continuous ping test using the changed settings.

6 LOCATING A NODE

About locating nodes

EA_Inspector is capable of locating registered and unregistered REX, REX2 and A3 ALPHA node electricity meters.

Note: Elster recommends disabling EA_Inspector encryption before locating a registered or unregistered node, especially utilities supporting both unencrypted and encrypted LAN communications. See "Configuring handheld settings and utility IDs" on page 171 for details on disabling LAN encryption.


Note: Gas and water modules are battery operated devices that remain in a sleeping state until they are awakened (by magnet swipe for one-way modules or by receiving a magnet swipe or a wake up signal (v3.x modules) for two-way modules). They cannot be located using the Registered Node or Unregistered Node Locator functions.

Accessing node location menu

To access the Locate Node test menu:


1. From the Main Menu, select RF Troubleshooting.

Figure 6-1. EA_Inspector Main Menu



The RF Troubleshooting menu displays.

Figure 6-2. RF Troubleshooting menu



2. From the RF Troubleshooting menu, select from the following:

- Registered node locator
- Unregistered node locator

Registered node locator

The **Reg Node Locator** command allows you to perform the following node locate functions:

- Find all IDs
- Finding an ID

Note: The accelerator key for Find All is <A> and the key for Find ID is <I>.

Find all IDs

To find all registered nodes:

1. From the RF Troubleshooting menu, select **Reg Node Locator**.
2. Select **Find All**.

EA_Inspector commands all registered nodes to respond.

Figure 6-3. Find All nodes





Figure 6-4. Find all registered nodes results



EA_Inspector displays a listing of registered nodes including the following information:

Item	Description
ID	Indicates the Serial Number or the LAN ID of the registered node (depending on user privileges).

Item	Description
Node Level	Indicates the node level from the registered gatekeeper of the pinged meter. For example, a node level of 2 indicates that the pinged meter communicates with its registered gatekeeper through one repeater meter.
Gatekeeper	Indicates the pinged meter's registered gatekeeper.
RSSI	Indicates the received signal strength indicator (RSSI) of the ping test. For example, -22 indicates an RSSI of -22 dBm.

3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Finding an ID


This function works on REX, REX2, EA_Repeater and A3 ALPHA node meters. See [“User privileges” on page 31](#) for an explanation for using either Serial Number or LAN ID.

To find a specific registered node:

1. From the RF Troubleshooting menu, select **Reg Node Locator**.
2. Enter the ID (Serial Number) or LAN ID of the node to be found.
3. Select **Find ID**.

EA_Inspector commands the registered node to respond.

Figure 6-5. Find an ID



Use LAN ID unchecked

Use LAN ID checked

Note: To use the LAN ID to ping devices, you must have Allow LAN ID privilege (see EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details) as well as Use LAN ID enabled on the handheld (see "Configuring handheld settings and utility IDs" on page 171 for details). To use the meter's serial number to ping devices, your system administrator must download EA_MS meter ID (marriage data) file from EA_MS and synchronize the file to the handheld.

Figure 6-6. Finding an ID





Figure 6-7. Find completed



EA_Inspector displays the information of the registered node:

Item	Description
ID	Indicates the ID (Serial Number) or LAN ID of the registered node.
Node Level	Indicates the node level from the registered gatekeeper of the pinged meter. For example, a node level of 2 indicates that the pinged meter communicates with its registered gatekeeper through one repeater meter.
Gatekeeper	Indicates the pinged meter’s registered gatekeeper.
RSSI	Indicates the received signal strength indicator (RSSI) of the ping test. For example, -22 indicates an RSSI of -22 dBm.


4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Unregistered node locator

EA_Inspector provides the Unregistered Node Locator function to find REX, REX2 and A3 ALPHA meters and EA_Repeaters that are not registered to a gatekeeper.

Figure 6-8. Finding an unregistered node




- 1 - Handheld broadcasts for unregistered nodes
- 2 - Unregistered nodes respond to node scan

To find an unregistered node:

1. From the RF Troubleshooting menu, select **Unreg Node Locator**.
EA_Inspector displays the Unreg Node Locator dialog.


Figure 6-9. Finding unregistered nodes



2. To find unregistered nodes within range of the handheld's RF card, click **Find All**.
EA_Inspector pings to find unregistered nodes.

Any unregistered nodes that hear the command will return their IDs.

Figure 6-10. Unregistered nodes found



3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

7 READING METER DATA

The Read Meter Data command allows you to read TOU and demand data from an electricity meter. The meter data is then transferred into EA_Inspector Manager. Once in EA_Inspector Manager, EA_Inspector Manager posts the collected meter data to a pre-defined location in an AMRDEF format file (the same file type as used by EA_MS to deliver meter data). This method of obtaining meter data provides a mechanism for by-passing any gatekeeper or WAN problems that may impact the delivery of billing data.


Accessing Read Meter Data menu

Note: You must have Read Billing privilege to read previous period data. Billing data is not shown in EA_Inspector. Instead, EA_Inspector displays the success of the read and the data stored for download. To see the current reading on a meter, use the One shot ping test.

To access the Read Meter Data menu:


1. From the Main Menu, select **Read Meter Data**.

Figure 7-1. EA_Inspector Main Menu



The Read Meter Data menu displays.

Figure 7-2. Read Meter Data menu



You can read the following data:

- [Current data collected](#) (since the last demand reset)
- [Previous data collected](#) (prior to the last demand reset)

Note: A demand reset is not automatically performed. If you are reading meter data for the purpose of billing, Elster recommends performing a demand reset prior to reading previous period data.

Reading previous period data


Note: If you are reading meter data for the purpose of billing, Elster recommends performing a demand reset prior to reading previous period data.

To read previous period data from a meter:

1. From the Read Meter Data menu, select **Read Previous Data**.
The Read Previous Data input screen displays.
2. Enter the **LAN ID** for the meter you want to read.
3. Click **Read**.

EA_Inspector reads the previous period data. To view the meter data, synchronize the handheld with EA_Inspector Manager and EA_Inspector Manager will generate an AMRDEF XML file suitable for importing into EA_MS or other management system.

Figure 7-3. Read previous data input screen



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.


EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

Reading current period data

To read current period data from a meter:

1. From the Read Meter Data menu, select **Read Current Data**.
The Read Current Data input screen displays.

Figure 7-4. Read current data input screen



2. Enter the **LAN ID** for the meter you want to read.
3. Click **Read**.
4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

8 GAS/WATER COMMS

About gas and water communication

EA_Inspector allows you to read gas and water communication information from electricity devices (REX2 or A3 ALPHA nodes) or from gas or water devices. These data identify the members of the module's communications table (that is, the specific repeaters that the gas and water modules are using to transmit their data). The communications tables are dynamic and adjust to network conditions and the success of the periodic transmission sessions.


EA_Inspector also allows you to query an electric meter or node about what devices are its "children": the identity of the modules it communicates with is available from the meter itself. These meters keep a corresponding communications table with the identity of the water and/or gas modules it regularly communicates with.

Accessing Gas/Water Comms menu

To access the Gas/Water Comms menu:


1. From the Main Menu, select RF Troubleshooting.

Figure 8-1. EA_Inspector Main Menu




The RF Troubleshooting menu displays.

Figure 8-2. RF Troubleshooting menu



- From the RF Troubleshooting menu, select **Gas/Water Comms**.
The Gas/Water Comms Info menu displays.

Figure 8-3. Gas/Water Comms Info



The Gas/Water Comms Info menu allows you to read gas and water communication information from either of the following devices:

- an electric device
- a gas/water device

Reading gas/water comm info from an electric device


To read gas or water communication information from an electric device:

1. From the Gas/Water Comms Info menu, select **Read from Electric**.
2. Enter the ID for the electric device (REX2 meter or A3 ALPHA node).
3. Click **Read**.

The display lists the gas and water IDs for meters communicating through the specified electric device.

If you receive a communication error or warning message, see [“Communication mode errors and warning messages”](#) on page 177 for details on troubleshooting communication problems.


Figure 8-4. Gas/Water Comms Info - electric device



associated gas and water devices

no associated gas or water devices

Figure 8-5. Gas/Water Comms Info - error message



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on page 31 for details on collecting and saving GPS data.


Reading gas/water comm info from a gas/water device

To read gas or water communication information from a gas or two-way water device:

1. From the Gas/Water Comms Info menu, select **Read from Gas/Water**.
2. Click **Read**.

The display lists the ID for the electric device through which the specified gas or water device communicates.

Figure 8-6. Gas/Water Comms Info



3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on page 31 for details on collecting and saving GPS data.

9

DISCONNECTING AND RECONNECTING METERS

About disconnecting and reconnecting electricity meters

The EA_Inspector handheld allows authorized users to disconnect and reconnect registered and unregistered REX and REX2 meters that have the service control switch installed. Additionally, EA_Inspector also allows users to disconnect and reconnect A3 ALPHA meters equipped with the internal polyphase service control switch .

Refer to PG42-1015, **REX2 meter with service control switch**, and PG42-1007, **REX meter with service control switch**, for details on operating the service control switch.

REX meter service control switch status

A REX meter displays the following service control switch status codes on the meter LCD:


- F10000 - no load side voltage present when switch is supposedly closed
- F00100 - load side voltage present when switch is open
- F00001 - service control switch is open

Note: The LCD can display a combination of codes for example, *F00101*, indicating the service control switch is open and load side voltage is present.

REX2 meter service control switch status

To indicate the status of the service control switch, a REX2 meter displays the following icons on the meter LCD below the display quantity:

Figure 9-1. Service control switch status indicators



A3 ALPHA meter with internal polyphase service control

Form 16S, 100 Ampere-rated A3 ALPHA meters (with EA_NIC) may be equipped with an internal polyphase service control switch. The optional service control switch can remotely disconnect all three electrical phases supplying power to a service. To ensure safety, the A3 ALPHA meter verifies that no load side voltage is present before it closes the switch to reconnect electrical service. If load side voltage is detected, the meter will not reconnect service.

When the polyphase service control switch is open, the potential indicators on the meter LCD will blink to indicate that phase voltages are missing. If the meter displays the service control switch open warning code but the potential indicators are always on (that is, not blinking), then it is possible that the service control switch is open but load side voltage is present.

When the service control switch is open, the A3 ALPHA meter LCD will display two different warning codes:

- F1 001000: Service control switch open
- F1 010000: Potential indicator warning

Because both warning codes are in the F1 group, the codes will be displayed in combination.

Figure 9-2. Service control switch warning codes




About disconnecting and reconnecting gas meters

The EA_Inspector handheld allows authorized users to disconnect and reconnect gas service on the AC-250 RMD (Remote Meter Disconnect).

Figure 9-3. AC-250 RMD on gas meter

AC-250 RMD gas valve control module




Accessing Connect/ Disconnect menu

To access the Connect/Disconnect menu:

1. From the Main Menu, select Connect/Disconnect.

Figure 9-4. EA_Inspector Main Menu



The Connect/Disconnect menu displays.

Figure 9-5. Connect/Disconnect menu



2. From the Connect/Disconnect menu, select from the following:
 - Load Side Power:
 - Read Current State
 - Load Side Voltage Check
 - Connect
 - Disconnect


- Secondary Relay:
 - Read Current State
 - Open Relay
 - Close Relay
- Gas Valve Control
 - Read
 - Open
 - Close
- RF Control
 - Read Current State
 - Disable RF (Transmitter)
 - Enable RF (Transmitter)

Reading status of the service control switch

The handheld allows you to read the status of the REX, REX2 or A3 ALPHA meter's service control switch. To read the status:

1. From the **Connect/Disconnect** menu, select **Load Side Power**.


Figure 9-6. Load Side Power menu



1. Enter the LAN ID of the meter.
2. Select **Read Current State**.

The handheld displays the status of the meter's service control switch.

Figure 9-7. Load Side Power - connected




The table below details the possible values for the service control switch:

Value	Switch Status	Reported as
0	Communication Failure	Communication failure
1	Open	Power is disconnected
2	Open with close pending	Connection is pending
3	Open with load side voltage present	Power is disconnected with load side voltage present.
4	Closed	Power is connected
5	Closed with open pending	Disconnect is pending
6	Unregistered REX Meter	Connect/disconnect cannot be operated for unregistered REX meter Note: REX2 meters allow switch operation even when unregistered.

- Note: In the REX, REX2 and A3 ALPHA meters, a state change is pending because it is awaiting expiration of the control switch capacitor's charge time.
- Note: A service control switch will not connect if voltage is present on the load side of the switch.

Figure 9-8. Communication warnings



If you receive a communication error or warning message [Figure 9-8], see [“Communication mode errors and warning messages”](#) on page 177 for details on troubleshooting communication problems.

Checking load side voltage

Because a service control switch will not connect if load side voltage is present. To check the status of load side voltage:


1. From the **Load Side Power** menu, select **Load Side Voltage Check**.

EA_Inspector queries the meter and displays the status of the meter’s load side voltage.

Read Current State results	Load Side Voltage Check display results
Communication failure ^a	Communication failure
Power is disconnected	No load side voltage
Connection is pending	No load side voltage
Power is disconnected with load side voltage present	Load side voltage is present
Power is connected	Power is present
Disconnect is pending	Power is present
Connect/Disconnect cannot be operated for unregistered REX meter	Connect/Disconnect cannot be operated for unregistered REX meter

a. no response from meter.

Figure 9-9. Load Side Power - voltage present



Connecting an electricity meter

EA_Inspector allows you to connect a REX2 meter regardless of its registration status. However, you can only connect a REX meter that is registered to a gatekeeper.

Note: When connecting a REX2 meter after a disconnect, for safety reasons the meter must observe a minimum period of one minute of no load side voltage before performing the connection. After the one minute of no load side voltage, the actual connect operation may take 20 - 30 seconds. Therefore, when doing a connect immediately after a disconnect, you may need to wait up to 1.5 minutes before the connection occurs.

Note: For REX meters, a connection operation takes about 4 minutes. However, doing a connection immediately after a disconnection may take 8-10 minutes.


To connect a REX or REX2 meter:

1. From the **Main Menu**, select **Connect/Disconnect**.
2. Enter the **LAN ID** of the meter to be connected.
3. From the **Load Side Power** menu, select **Connect - Turn On**.

Note: After sending a connect or disconnect command, EA_Inspector will check service control switch status. If the status is not as expected, then it waits one second and reads status again until 3 attempts occur without a successful change.

EA_Inspector displays the result of the Connect command.

Figure 9-10. Power connected



The data is saved to the activity and result logs automatically.

4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Disconnecting an electricity meter

EA_Inspector allows you to disconnect a REX2 meter regardless of its registration status. However, you can only disconnect a REX meter that is registered to a gatekeeper.


Note: You must wait at least ten minutes to disconnect a REX meter after you connect it. This ensures the handheld receives the correct status of the disconnect switch.

To disconnect a REX or REX2 meter:

1. From the **Main Menu**, select **Connect/Disconnect**.
2. Enter the **LAN ID** of the meter to be disconnected.
3. From the **Load Side Power** menu, select **Disconnect - Turn Off**.

EA_Inspector prompts you to confirm that you want to disconnect the meter.

Figure 9-11. Disconnect input screen



4. Click **Yes** to continue with the Disconnect command.


— OR —

Click **No** to cancel the disconnect.

Note: After sending a connect or disconnect command, EA_Inspector will check service control switch status. If the status is not as expected, then it waits one second and reads status again until 3 attempts occur without a successful change.

EA_Inspector displays the results of the Disconnect command.

Figure 9-12. Data saved



5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

The data is saved to the activity and result logs automatically.

Reading the state of the secondary relay

The handheld allows you to read the status of the gREX meter's secondary relay. To read the status:

1. From the **Connect/Disconnect** menu, select **Secondary Relay**.
2. Enter the **LAN ID** of the meter.
3. Select **Read Current State**.

The handheld displays the status of the meter's secondary relay.

Figure 9-13. Current state of the secondary relay



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

Connecting a secondary relay

The handheld allows you to close, that is, connect, a gREX meter's secondary relay. To connect a secondary relay:

1. From the **Connect/Disconnect** menu, select **Secondary Relay**.
2. Enter the **LAN ID** of the meter with the relay to be connected.
3. From the **Secondary Relay** menu, select **Close Relay**.

EA_Inspector displays the results of the Close Relay command.

Figure 9-14. Connecting power using secondary relay



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.


Disconnecting a secondary relay

The handheld allows you to open, that is, disconnect, a gREX meter's secondary relay. To disconnect a secondary relay:

1. From the **Connect/Disconnect** menu, select **Secondary Relay**.
2. Enter the **LAN ID** of the meter with the relay to be disconnected.
3. From the **Secondary Relay** menu, select **Open Relay**.

EA_Inspector prompts you to confirm that you want to disconnect the meter.

Figure 9-15. Disconnecting power using secondary relay



4. Click **Yes** to continue with the Open Relay command.
— OR —
Click **No** to cancel the disconnect.
EA_Inspector displays the results of the Open Relay command.

Figure 9-16. Disconnecting power using secondary relay



5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.
EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

Controlling a gas valve

EA_Inspector 3.6 adds support for the AC-250 RMD (Remote Meter Disconnect). The RMD includes a valve control module (VCM) for opening and closing the gas valve. The gas valve assembly and EnergyAxis module are mounted on and operate Elster's AC-250 gas meter.

Note: The Radix FW950 handheld (Style No. 1C12455G01) should be equipped with an external antenna to perform actions on the AC-250 RMD. The external antenna allows the Radix handheld to issue commands to gas valves up to 900 feet from the handheld.

Figure 9-17. Radix FW950 with external antenna (Style No. 1C12455G01)



EA_Inspector allows a user to perform the following functions on the gas shut off valve:

- read the RF and VCM modules

- close the valve
- open the valve


Gas valve privileges

To access gas valve functionality, the user must have the **Valve Control** privilege. Refer to the **EA_Inspector and EA_Inspector Manager Installation and Administration Guide** for details.

Additional gas valve functionality is controlled by the following privileges:

- Valve S/N Mode - requires the user to enter the gas valve's serial number prior to reading, opening or closing the gas valve
- PIN Challenge - requires the user to enter the last five digits of the device LAN ID (printed on the label of the RMD) as a PIN prior to opening a gas valve


Figure 9-18. RMD and label on gas meter



Note: If the user has Valve S/N Mode privilege but the handheld does not have a gas SN/LAN ID file, the user cannot access the Gas Valve Control functions.

Figure 9-19 illustrates data entry privilege requirements for performing gas valve functions.

Figure 9-19. Gas valve control access



- EA_Inspector saves an audit log for the results of all Read, Open or Close actions.
- EA_Inspector automatically saves detailed information on the gas valve Open or Close actions to the results log file.
- EA_Inspector saves detailed information on the gas valve Read action to the results log file only when a user clicks Save.

Reading a gas valve’s modules

To read a gas shut off valve’s RF and VCM modules:

1. From the **Connect/Disconnect** menu, select **Gas Valve Control**.
The Gas Valve Control screen displays.

Figure 9-20. Gas valve control privilege





Figure 9-21. Additional gas valve privileges



2. If you have the Valve S/N Mode privilege, enter the gas valve Serial Number.
— OR —
If you do not have the Valve S/N Mode privilege, enter the gas valve LAN ID.
3. Click Read.

Figure 9-22. Read results

LAN ID

VCM Version: 110

Valve Status: Open

Number of OP: 48

Alarm

Error

Read Status Passed

EA_Inspector displays the following information:

Item	Description
VCM Version	Indicates the firmware version of the AC-250 RMD valve control module.
Valve Status	Indicates the state of the gas valve - Open or Closed.
Number of OP	Indicates the number of valve opening and closing operations performed by the VCM.
Alarm	Lists alarms reported by the RF module:
	RF module
	<ul style="list-style-type: none"> • RESET_ERROR • BATTERY_LOW (voltage < 3.0V) • BATTERY_ALARM (voltage < 2.8V) • MODULE_ERROR • OP_MALFN (optical sensor malfunction)
Error	Lists errors reported by the RF module:
	RF module


Item	Description
	<ul style="list-style-type: none"> • EEPROM_ERROR • CRC_ERROR • CONFIG_ERROR • SERIAL_FLASH_ERROR • AP_ERR: Application Mode VCM Error Processing Request • AP_SNS: Application Mode Service Not Supported • AP_ONP: Application Mode Operation Not Possible • AP_IAR: Application Mode Inappropriate Action Requested • BL_ERR: Bootloader Mode VCM Error Processing Request • BL_FWE: Bootloader Flash Write Error • BL_ONP: Bootloader Mode Operation Not Possible • BL_IAR: Bootloader Mode Inappropriate Action Requested • FRAME: Framing Error • TIMEOUT1: No Bits Received • TIMEOUT2: Transmission Died Mid-stream • START_BIT: No Start Bit • STOP_BIT: No Stop Bit • PARITY: Parity Error • BAD_CRC: Bad CRC • MSG_LEN: Invalid Message Length
Status	Indicates the status of the activity: Passed or Failed.

4. Click **Save** to have EA_Inspector save detailed information on the gas valve control to the result log file.

Battery alarm

Note: Battery status will be checked automatically before opening or closing the gas valve. If the battery status is BATTERY_ALARM, the action for opening or closing valve will be cancelled.


Figure 9-23. Battery alarm



Hardware failure detected

If EA_Inspector detects a hardware failure, contact Elster EnergyAxis Support.

Figure 9-24. Hardware failure detected



- Click **OK** to acknowledge the message.

Note: The Valve Status field is for historical reference only. When the Read command is initiated, EA_Inspector reports the last known state of the valve. To determine the true current state of the valve, a valve movement must be performed. If the Valve Status reports Open, the user can send an Open command to confirm that the valve is indeed Open. If the Valve Status reports Closed, the user can send a Close command to confirm that the valve is indeed Closed.

Opening a gas valve

Opening a gas valve turns on gas service.

⚠ WARNING

After opening a gas valve, pilot lights on gas-operated devices and appliances must be checked that they are lit. Be sure you have access to all gas-operated devices before performing the Open command.

To open a gas shut off valve:

1. From the **Connect/Disconnect** menu, select **Gas Valve Control**.
The Gas Valve Control screen displays.

Figure 9-25. Gas valve control privilege

The figure displays two side-by-side screenshots of a gas valve control interface. Both screenshots show a form with the following fields and buttons:


- S/N** (left) or **LAN ID** (right): Text input field.
- VCM Version:** Text label.
- Valve Status:** Text label.
- Number of OP:** Text label.
- Alarm** and **Error**: Dropdown menus.
- Read**, **Open**, **Close**, **Save**, and **Cancel**: Action buttons.

Valve S/N Mode privilege

No Valve S/N Mode privilege


2. If you have the Valve S/N Mode privilege, enter the gas valve **Serial Number**.
— OR —
If you do not have the Valve S/N Mode privilege, enter the gas valve **LAN ID**.
3. Click **Open**.
4. If you have the PIN Challenge privilege:
 - a. Enter the last five digits of the RF module's LAN ID (printed on the RMD label) as a **PIN**.
 - b. Click **OK**.

Figure 9-26. Opening valve - PIN challenge



EA_Inspector prompts you to confirm to open the gas shut off valve.

Figure 9-27. Confirm valve opening



Note: EA_Inspector checks the battery status before opening or closing a gas valve. If a battery alarm occurs, the action for opening or closing the valve is cancelled.

5. To continue with opening the gas valve, click **Yes**.

— OR —

Click **No** to cancel the open command and return to the prior screen.

After opening the gas shut off valve, EA_Inspector displays the result of the action.

Figure 9-28. Open valve results

LAN ID

VCM Version: 110

Valve Status: Open

Number of OP: 49

Alarm

Error

Open Valve Passed

Read Close

Save

6. Click Save only to save a note to the result log or to collect GPS data.

Closing a gas valve

Closing a gas valve turns off gas service. To close a gas shut off valve:

1. From the Connect/Disconnect menu, select Gas Valve Control.
The Gas Valve Control screen displays.

Figure 9-29. Gas valve control privilege

S/N

LAN ID

VCM Version:

Valve Status:

Number of OP:

Alarm

Error

Read Close

Save

Valve S/N Mode privilege

No Valve S/N Mode privilege

2. If you have the Valve S/N Mode privilege, enter the gas valve **Serial Number**.
— OR —
If you do not have the Valve S/N Mode privilege, enter the gas valve **LAN ID**.
3. Click **Close**.
4. If you have the PIN Challenge privilege:
 - a. Enter the last five digits of the RF module's LAN ID (printed on the RMD label) as a **PIN**.
 - b. Click **OK**.

Note: EA_Inspector checks the battery status before opening or closing a gas valve. If a battery alarm occurs, the action for opening or closing the valve is cancelled.

EA_Inspector prompts you to confirm to close the gas shut off valve.

Figure 9-30. Confirm valve closing



5. To continue with closing the gas valve, click **Yes**.
— OR —
Click **No** to cancel the open command and return to the prior screen.
After closing the gas shut off valve, EA_Inspector displays the result of the action.

Figure 9-31. Close valve result

S/N 9876543	LAN ID 5439106
VCM Version: 110	VCM Version: 110
Valve Status: Closed	Valve Status: Closed
Number of OP: 15	Number of OP: 48
Alarm <input type="text"/>	Alarm <input type="text"/>
Error <input type="text"/>	Error <input type="text"/>
Close Valve Passed	Close Valve Passed
<input type="button" value="Read"/> <input type="button" value="Open"/> <input type="button" value="Close"/>	<input type="button" value="Read"/> <input type="button" value="Open"/> <input type="button" value="Close"/>
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	<input type="button" value="Save"/> <input type="button" value="Cancel"/>

6. Click Save only to save a note to the result log or to collect GPS data.

Controlling a meter's RF transmitter

EA_Inspector 3.6 adds support for controlling the radio transmitter of the following devices:

- REX2 meters (FW v2.0 and higher)
- gREX meters (FW v2.0 and higher)

Note: REX2 and gREX meters with FW v2.x will execute the disable or enable command at midnight.

- A3 ALPHA meters equipped with EA_NIC (FW v3.0 and higher)

Note: REX and REX2 meters FW v1.x do NOT support enabling or disabling the RF transmitter.

EA_Inspector allows a user to perform the following functions on the radio transmitter:

- read the current state of the transmitter
- disable the transmitter
- enable the transmitter

EA_Inspector saves an audit log for the results of all RF control operations (Read, Disable, and Enable).

EA_Inspector automatically saves detailed information on the RF control (Read, Disable, and Enable) to the results log file.


Additionally, you can click Save to save notes into the results log or collect GPS data.

Reading the current state of an RF transmitter

To read the current state of the RF transmitter:


1. From the Connect/Disconnect menu, select RF Control.
The RF Control screen displays.

Figure 9-32. RF Control screen



2. Enter the LAN ID for the module.
3. Click Read Current State.

Figure 9-33. Reading the current state




The screen displays the current state of the module's radio.

Disabling an RF transmitter

To disable the RF transmitter in a device:

1. From the Connect/Disconnect menu, select **RF Control**.
The RF Control screen displays.
2. Enter the **LAN ID** for the module.
3. Click **Disable RF**.

Figure 9-34. Disabling RF transmitter




The screen displays the result of the action (that is, successful or failed).

Enabling an RF transmitter

To enable the RF transmitter:

1. From the Connect/Disconnect menu, select **RF Control**.
The RF Control screen displays.
2. Enter the **LAN ID** for the module.
3. Click **Enable RF**.

Figure 9-35. Enabling RF transmitter



The screen displays the result of the action (that is, successful or failed).

10 UPGRADING FIRMWARE

The target of a firmware upgrade must support LAN encryption. Elster security policies do not allow firmware upgrades on meters, modules or nodes that do not support LAN encryption. The device does not need to be operating in encrypted mode; the download process will activate the encrypted mode of operation for the duration of the download and return the device to the original operating mode.

See “Configuring handheld settings and utility IDs” on page 171 for details on enabling LAN encryption on the handheld.

Note: The LAN seed used by the handheld must match the LAN seed used by a device. Without matching LAN seeds, the handheld will not be able to upgrade the firmware. Refer to the *EA_Inspector and EA_Inspector Manager Installation and Administration Guide* for details on downloading LAN seeds.

About upgrading firmware

EA_Inspector allows you to upgrade the firmware for the following hardware:

- EA_NIC (in the handheld)
- meter radio (REX2 and A3 ALPHA meters)
- EA_Gas or two-way EA_Water 2.0 modules
- AC-250 RMD (valve control module)
- REX2 meter
- A3 ALPHA meter with EA_NIC
- 900 MHz HAN device radio
- 900 MHz HAN device

REX2 meter with EA_NIC

EA_Inspector supports over-the-air (OTA) upgrade for the following REX2 meters with EA_NIC:

EA_Inspector	REX2 meter		EA_NIC	LAN Mode 1	LAN Mode 2
	Upgrade Support	HW	FW		
Y	2.0	4.0	3.3	X	X
Y	2.0	3.1	3.3	X	X
Y	2.0	3.1	3.0	X	X
Y	2.0	3.0	3.0	X	X
	2.0	2.3	2.5	X	
	2.0	2.2	2.5	X	
	2.0	2.0	2.3	X	

EA_Inspector	REX2 meter		EA_NIC	LAN Mode 1	LAN Mode 2
	HW	FW			
	2.0	2.0	2.2	X	
	2.0	2.0	2.1	X	
Y	1.0	1.4	3.1	X	X
	1.0	1.3	1.5	X	
	1.0	1.2	1.4	X	
	1.0	1.2	1.3	X	
	1.0	1.2	1.2	X	
	1.0	1.1	1.2	X	
	1.0	1.0	1.1	X	

A3 ALPHA meter with EA_NIC

EA_Inspector supports OTA upgrade for the following A3 ALPHA meters with EA_NIC:

EA_Inspector	A3 ALPHA meter	EA_NIC	LAN Mode 1	LAN Mode 2
Y	5.1	3.3	X	X
Y	5.1	3.2	X	X
Y	5.0	3.0	X	X
Y	4.2	3.0	X	X
Y	4.0	3.3	X	X
Y	4.0	3.0	X	X
	3.1	2.7	X	
	3.1	2.5	X	
	3.0	2.3	X	

Upgrading the EA_NIC firmware in the handheld

Note: Before you can upgrade firmware, files must be downloaded to the handheld using EA_Inspector Manager. See the EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details.

To upgrade the handheld's EA_NIC firmware:


1. Exit from the Main Menu by clicking **Exit**.

Figure 10-1. Exiting EA_Inspector




2. Click **Yes** to exit.
3. At the desktop, click the EA_Inspector icon to restart the software and begin updating the firmware.

Figure 10-2. Confirm update




4. Click **Yes** to begin updating the handheld's EA_NIC firmware. The update begins.

Figure 10-3. Update in progress



When the update is complete, EA_Inspector displays a message.

Figure 10-4. Update complete



5. Click **OK** to finish the update.


Upgrading a gas or water module's firmware

Note: Before you can upgrade firmware, files must be downloaded to the handheld using EA_Inspector Manager. See the EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details.

To upgrade a gas or water module's firmware:


1. From the Main Menu, select **Configure Meter**.

Figure 10-5. EA_Inspector Main Menu screen



EA_Inspector displays the Configure Meter screen.


Figure 10-6. Configure Meter screen



2. Select **Firmware Upgrade**.


EA_Inspector displays the Firmware Upgrade input screen.

Figure 10-7. Firmware upgrade input screen




3. To upgrade firmware in a gas or water meter’s radio/application or valve control module using walk-by or drive-by access, check **WBDB**.
 - If **WBDB** is unchecked, EA_Inspector displays a message prompting you to use a magnet to awaken the RF module.
 - If **WBDB** is checked, you must enter the module’s serial number or LAN ID to allow EA_Inspector to broadcast a wake-up tone to the module.
4. From the drop list, select to **Gas/Water**.
5. Enter the LAN ID of the meter.
6. Click **Go** to upgrading the module’s firmware.
 - a. If firmware files are not located on the handheld, EA_Inspector displays a notice prompting you to get firmware files from EA_Inspector Manager.

Figure 10-8. Firmware files unavailable




- b. Click **OK** to acknowledge the message.
If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the firmware version.
- c. Select the appropriate firmware image from the **Firmware List**.

Figure 10-9. Multiple firmware versions found



- d. Click **OK**.
EA_Inspector begins upgrading the module's firmware.

Figure 10-10. Loading firmware upgrade



- 7. For gas modules, hold the magnet to the module as detailed in Figure 5-14 on page 45.
For water modules, hold the magnet to the module as detailed in Figure 5-25 and Figure 5-22 on page 53.
EA_Inspector displays the result of the upgrade.

Figure 10-11. Successful firmware upgrade



The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.

8. To add notes to the log data file or collect and save GPS data, click **Save**. EA_Inspector opens a Notes screen.
9. Enter notes as needed or see “[Saving notes and GPS data](#)” on page 31 for details on collecting and saving GPS data.

Upgrading a gas meter’s RMD firmware

To upgrade the AC-250 Remote Meter Disconnect (RMD) firmware in the gas meter’s control valve:

1. From the Main Menu, select **Configure Meter**.
EA_Inspector displays the Configure Meter screen.
2. Select **Firmware Upgrade**.
EA_Inspector displays the Firmware Upgrade input screen.
3. From the drop list, select **Gas/Water**.
4. To upgrade firmware in a gas or water meter’s radio/application or valve control module using walk-by or drive-by access, check **WBDB**.
 - If WBDB is unchecked, EA_Inspector displays a message prompting you to use a magnet to awaken the RF module.
 - If WBDB is checked, you must enter the module’s serial number or LAN ID to allow EA_Inspector to broadcast a wake-up tone to the module.


Figure 10-12. Upgrading valve control module



5. Select **Valve Control Module**.
6. Enter the **LAN ID** for the control module.
7. Click **Go**.

If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the firmware version.


Figure 10-13. Firmware List



8. Select the appropriate firmware image from the **Firmware List**.
9. Click **OK**.

EA_Inspector begins upgrading the module's firmware.

Figure 10-14. Loading the firmware image



After the firmware is upgraded, EA_Inspector displays the results of the operation.

Figure 10-15. Upgrade results



10. To add notes to the log data file or collect and save GPS data, click **Save**.

EA_Inspector opens a Notes screen.

11. Enter notes as needed or see “Saving notes and GPS data” on page 31 for details on collecting and saving GPS data.

Note: After a successful Valve Control Module firmware upgrade, let the module initialize by waiting at least three minutes before attempting to perform any gas valve commands such as read, open, or close.


Upgrading a meter's EA_NIC radio firmware

Note: This function applies to REX2 or A3 ALPHA meters equipped with the EA_NIC network interface card.

To upgrade a meter's EA_NIC radio firmware:


1. From the Main Menu, select **Configure Meter**.

Figure 10-16. EA_Inspector Main Menu



EA_Inspector displays the Configure Meter screen.

Figure 10-17. Configure Meter screen



2. Select **Firmware Upgrade**.

EA_Inspector displays the Firmware Upgrade input screen.

Figure 10-18. Upgrading a meter’s radio firmware




3. Select to upgrade **Electricity**.
4. Select to upgrade the meter’s **Radio**.
5. Enter the **LAN ID** of the meter.
6. Click **Go** to begin the upgrade process.

EA_Inspector displays a list of the firmware versions available on the handheld:

- If upgrade files are not available on the handheld, EA_Inspector displays a message.
- Obtain the files by synchronizing the handheld using EA_Inspector Manager.
- If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the appropriate firmware version.

Figure 10-19. Firmware List



- a. Select the proper firmware and click OK.
EA_Inspector begin upgrading the meter’s radio firmware.

Figure 10-20. Loading firmware




Figure 10-21. Upgrade successful



After the upgrade is complete, EA_Inspector displays a message indicating the upgrade was successful.

The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.


- 7. To add notes to the log data file or collect and save GPS data, click **Save**.
EA_Inspector opens a Notes screen.
- 8. Enter notes as needed or see “Saving notes and GPS data” on page 31 for details on collecting and saving GPS data.

Upgrading a REX2 meter's firmware

To upgrade a REX2 meter's firmware:


1. From the Main Menu, select Configure Meter.

Figure 10-22. EA_Inspector Main Menu



EA_Inspector displays the Configure Meter screen.

Figure 10-23. Configure Meter screen



2. Select Firmware Upgrade.

EA_Inspector displays the Firmware Upgrade input screen.

Figure 10-24. Upgrading a meter’s firmware




3. Select to upgrade REX2 Application.
4. Enter the LAN ID of the meter.
5. Click **Go** to begin the upgrade process.

EA_Inspector displays a list of the firmware versions available on the handheld:


- If upgrade files are not available on the handheld, EA_Inspector displays a message.
- Obtain the files by synchronizing the handheld using EA_Inspector Manager.
- If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the appropriate firmware version.

Figure 10-25. Multiple firmware versions found



- a. Click OK.
- EA_Inspector begin upgrading the meter's firmware.

Figure 10-26. Loading firmware



After the upgrade is complete, EA_Inspector displays a message indicating the upgrade was successful.

Figure 10-27. Upgrade successful



The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.


- 6. To add notes to the log data file or collect and save GPS data, click **Save**. EA_Inspector opens a Notes screen.
- 7. Enter notes as needed or see [“Saving notes and GPS data”](#) on page 31 for details on collecting and saving GPS data.

Upgrading an A3 ALPHA meter's firmware

To upgrade an A3 ALPHA meter's firmware:


1. From the Main Menu, select Configure Meter.

Figure 10-28. EA_Inspector Main Menu



EA_Inspector displays the Configure Meter screen.

Figure 10-29. Configure Meter screen



2. Select Firmware Upgrade.

EA_Inspector displays the Firmware Upgrade input screen.

Figure 10-30. Upgrading a meter’s firmware




3. Select to upgrade A3 NIC Application.
4. Enter the LAN ID of the meter.
5. Click **Go** to begin the upgrade process.

EA_Inspector displays a list of the firmware versions available on the handheld:


- If upgrade files are not available on the handheld, EA_Inspector displays a message.
- Obtain the files by synchronizing the handheld using EA_Inspector Manager.
- If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the appropriate firmware version.

Figure 10-31. Multiple firmware versions found



- a. Click **OK**.
EA_Inspector begin upgrading the meter’s firmware.

Figure 10-32. Loading firmware



After the upgrade is complete, EA_Inspector displays a message indicating the upgrade was successful.

Figure 10-33. Upgrade successful



The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.

- 6. To add notes to the log data file or collect and save GPS data, click **Save**.
EA_Inspector opens a Notes screen.
- 7. Enter notes as needed or see “Saving notes and GPS data” on page 31 for details on collecting and saving GPS data.


Upgrading 900 MHz HAN devices

Upgrading a 900 MHz HAN device's radio

To upgrade the radio firmware in a 900 MHz HAN device:


1. From the Main Menu, select **Home Area Network**.
EA_Inspector displays the Home Area Network screen.

Figure 10-34. Home Area Network screen




2. From the Home Area Network, select **900 MHz HAN**.
EA_Inspector displays the 900 MHz HAN screen.

Figure 10-35. 900 MHz HAN screen




3. From the 900 MHz HAN, select **Configure**.
EA_Inspector displays the Config 900 MHz HAN screen.

Figure 10-36. Config 900 MHz HAN screen



4. From the Config 900 MHz HAN, select Firmware Upgrade.
EA_Inspector displays the Firmware Upgrade screen.

Figure 10-37. Firmware Upgrade screen



5. To upgrade the firmware in the device's radio, select Radio.
6. Enter the LAN ID of the meter.
7. Click **Go** to begin the upgrade process.


EA_Inspector displays a list of the firmware versions available on the handheld:

- If upgrade files are not available on the handheld, EA_Inspector displays a message.
- Obtain the files by synchronizing the handheld using EA_Inspector

Manager.

- If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the appropriate firmware version.


Figure 10-38. Firmware List



a. Click OK.


EA_Inspector begin upgrading the firmware.

Figure 10-39. Loading firmware



After the upgrade is complete, EA_Inspector displays a message indicating the upgrade was successful.

Figure 10-40. Upgrade complete



The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.


8. To add notes to the log data file or collect and save GPS data, click **Save**. EA_Inspector opens a Notes screen.
9. Enter notes as needed or see “Saving notes and GPS data” on page 31 for details on collecting and saving GPS data.

Upgrading a 900 MHz HAN device firmware

To upgrade the firmware in a 900 MHz HAN device:


1. From the Main Menu, select **Home Area Network**. EA_Inspector displays the Home Area Network screen.

Figure 10-41. Home Area Network screen




2. From the Home Area Network, select 900 MHz HAN.
EA_Inspector displays the 900 MHz HAN screen.

Figure 10-42. 900 MHz HAN screen




3. From the 900 MHz HAN, select Configure.
EA_Inspector displays the Config 900 MHz HAN screen.

Figure 10-43. Config 900 MHz HAN screen



4. From the Config 900 MHz HAN, select Firmware Upgrade.
EA_Inspector displays the Firmware Upgrade screen.

Figure 10-44. Firmware Upgrade screen



5. To upgrade the firmware in the device, select Application.
6. Enter the LAN ID of the meter.
7. Click **Go** to begin the upgrade process.


EA_Inspector displays a list of the firmware versions available on the handheld:

- If upgrade files are not available on the handheld, EA_Inspector displays a message.
- Obtain the files by synchronizing the handheld using EA_Inspector

Manager.

- If multiple firmware files are found on the handheld, EA_Inspector prompts you to select the appropriate firmware version.


Figure 10-45. Firmware List



a. Click OK.

EA_Inspector begin upgrading the firmware.

Figure 10-46. Loading firmware



After the upgrade is complete, EA_Inspector displays a message indicating the upgrade was successful.

Figure 10-47. Upgrade complete



The firmware upgrade results are saved automatically to a log data file for uploading into EA_Inspector Manager.

8. To add notes to the log data file or collect and save GPS data, click **Save**. EA_Inspector opens a Notes screen.
9. Enter notes as needed or see "Saving notes and GPS data" on page 31 for details on collecting and saving GPS data.

11 CONFIGURING METERS

About HAN broadcasts

Certain REX and REX2 meters may be home area network enabled using an EA_HAN network interface card (NIC). The meter communicates to the NIC relaying information such as consumption. The NIC uses the HAN radio to communicate with a variety of home area devices such as in home displays, programmable thermostats, etc.

EA_Inspector allows you to turn the REX meter communication to the NIC on and off as well as check the status of the communication.


Note: Meters that support HAN are REX meters Firmware version 4.1 and REX2 meters Firmware versions 2.x and higher.

Accessing HAN Broadcast menu

To access the HAN Broadcast menu:


1. From the Main Menu, select **Configure Meter**.

Figure 11-1. EA_Inspector Main Menu



The Configure Meter menu displays.

Figure 11-2. Configure Meter menu



The Configure Meter menu displays the following options:


- EA HAN Broadcast
- Meter Associations
- EA_Water Module
- Demand Reset
- Firmware Upgrade

Configuring HAN Broadcast settings

To configure EnergyAxis HAN broadcast settings:


1. From the Configure Meter menu, select EA HAN Broadcast.

Figure 11-3. Configure Meter menu



The EA HAN Broadcast menu displays.

Figure 11-4. EA HAN Broadcast menu



The EA HAN Broadcast menu includes the following:


- Read Current State
- Start - Turn ON
- End - Turn OFF

Checking the status of the meter's HAN broadcast

To check the status of a meter's HAN broadcast:

1. From the EA HAN Broadcast menu, enter the LAN ID of the selected meter.

Figure 11-5. EA HAN Broadcast menu



The image shows a handheld device screen titled "EA HAN Broadcast". Below the title is a label "LAN ID" followed by a rectangular input field. At the bottom of the screen, there are four stacked buttons: "Read Current State", "Start - Turn ON", "End - Turn OFF", and a split button with "Save" on the left and "Cancel" on the right.

2. Select **Read Current State**.

If the meter selected supports HAN, the handheld displays the status of the HAN Broadcast.

If the selected meter does not support HAN, the handheld displays the message "Broadcast not supported in REX v#."

If you receive a communication error or warning message [Figure 11-8], see ["Communication mode errors and warning messages"](#) on page 177 for details on troubleshooting communication problems.

Figure 11-6. HAN Broadcast status - ON

EA HAN Broadcast

LAN ID

Broadcast ON

Read Current State

Start - Turn ON

End - Turn OFF

Save **Cancel**

Figure 11-7. HAN Broadcast status

EA HAN Broadcast

LAN ID

Broadcast OFF


Read Current State

Start - Turn ON

End - Turn OFF

Save **Cancel**

Figure 11-8. HAN Broadcast error messages



3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Turning off the meter’s broadcast

Note: You must have Program privilege to turn off a meter’s broadcast.

To turn off a meter’s HAN broadcast:

1. From the EA HAN Broadcast menu, enter the ID of the selected meter.
2. Select **End - Turn OFF**.

Figure 11-9. Turn OFF Broadcast




Figure 11-10. HAN Broadcast - OFF



If the selected meter does not support HAN, the handheld displays the message "Broadcast not supported in REX v#."

If you receive a communication error or warning message (Figure 11-8), see "Communication mode errors and warning messages" on page 177 for details on troubleshooting communication problems.

3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See "Saving notes and GPS data" on page 31 for details on collecting and saving GPS data.

Turning on the meter's broadcast

Note: You must have Program privilege to turn on a meter's broadcast.

To turn on a meter's HAN broadcast:

1. From the EA HAN Broadcast menu, enter the ID of the selected meter.
2. Select **Start - Turn ON**.

Figure 11-11. Turn ON Broadcast




Figure 11-12. HAN Broadcast - ON



If the selected meter does not support HAN, the handheld displays the message "Broadcast not supported in REX v#."

If you receive a communication error or warning message (Figure 11-8), see ["Communication mode errors and warning messages"](#) on page 177 for details on troubleshooting communication problems.

3. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on page 31 for details on collecting and saving GPS data.


Setting meter associations

Note: You must have Program privilege to use the Set function.

The Meter Associations menu allows you to write an electric meter association into an EA_Gas or two-way EA_Water 2.0 module.

1. From the Configure Meter menu, select **Meter Associations**.
The Meter Associations dialog displays.


Figure 11-13. Meter Associations



2. Click **Find** to locate the EA_Gas or EA_Water module ID.


The display lists the EA_Gas or EA_Water module and the programmed values including the current electric meter association if one has been programmed into the module.

Figure 11-14. Find Electric Node



3. To set the electric meter association, enter the Electric Node ID.

Figure 11-15. Setting meter associations



4. Click **Set**.

The electric meter ID is written to the module.

5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.


Configuring water module leak settings

Note: EA_Water Module leak settings apply to EA_Water 2.0 modules.

To configure an EA_Water module's leak settings:

1. From the Configure Meter menu, select EA_Water Module.


Figure 11-16. Water Leak Settings input form



The image shows a dialog box titled "Water Leak Settings". It contains the following elements:
- Title: **Water Leak Settings**
- Label: **LAN ID:**
- Checkbox: **High Leak Alarm ON**
- Input field: **OverLimitThres.:** []
- Input field: **Leak Zero Int.:** []
- Input field: **Leak Window Int.:** []
- Buttons: **Read** (highlighted with a dashed border), **Set**, **Save**, and **Cancel**.

2. Click **Read** to locate the water module and retrieve its current leak settings. EA_Inspector displays the module's current leak settings.

Figure 11-17. Water module's leak settings



The image shows the same "Water Leak Settings" dialog box, but now with the following values displayed:
- Title: **Water Leak Settings**
- Label: **LAN ID: 1000**
- Checkbox: **High Leak Alarm ON**
- Input field: **OverLimitThres.:** [1000]
- Input field: **Leak Zero Int.:** [4]
- Input field: **Leak Window Int.:** [24]
- Text: **Get Leak Params Passed**
- Buttons: **Read** (highlighted with a dashed border), **Set**, **Save**, and **Cancel**.

3. Edit the settings as needed:
 - a. Check to turn on **High Leak Alarm**.
Uncheck to turn off High Leak Alarm.

- b. Enter the **Over Limit Threshold** (range from 0 to 65535).
The Over Limit Threshold triggers off the module's interval reading. The value entered here would reflect the maximum (hourly) interval reading allowed before triggering this alarm. Sometimes this is referred to as a **burst alarm** or a **broken pipe alarm**.
 - c. Enter the **Leak Zero Intervals** (must be less than or equal to **Leak Window Intervals**).
Leak Zero Intervals is a low-level leak detection. This leak detection watches for a specified number of zero-consumption intervals over a specified period of time called the **leak window**. Leak Zero Intervals are the minimum number of zero intervals required before setting the leak flag.
 - d. Enter the **Leak Window Intervals** (range from 0 to 96).
The number of intervals in a leak window.
- Note:** The High Leak Alarm will be disabled if the Over Limit Threshold is set to all zeros.
4. Click **Set** to configure the module with the changed settings.

Figure 11-18. Setting leak settings

Water Leak Settings

LAN ID: 1000

High Leak Alarm ON

OverLimitThres.:

Leak Zero Int.:

Leak Window Int.:

Set Leak Params Passed

5. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.
- EA_Inspector opens a Notes screen. See [“Saving notes and GPS data” on page 31](#) for details on collecting and saving GPS data.

Performing a demand reset on an electricity meter


Note: The handheld user must have Billing Read privilege to perform a Demand Reset on an electricity meter. Refer to the EA_Inspector and EA_Inspector Manager Installation and Administration Guide.

To perform a demand reset on an electricity meter:

1. From the Configure Meter menu, select **Demand Reset**.
2. Enter the **LAN ID** of the electricity meter.
3. Click **Reset**.

EA_Inspector commands the meter to perform a demand reset and displays the results of the command.

Figure 11-19. Demand reset results



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on [page 31](#) for details on collecting and saving GPS data.

12

MANAGING HOME AREA NETWORK DEVICES

Certain REX and REX2 meters may be home area network enabled using a ZigBee network interface card (ZigBee NIC) or a 900 MHz HAN NIC.

The meter communicates to the ZigBee NIC relaying information such as consumption. The ZigBee NIC uses the HAN radio to communicate with a variety of home area devices such as in home displays, programmable thermostats, etc.

EA_Inspector allows you to perform the following commands on a ZigBee NIC:

- [View Devices](#)
- [HAN NIC Info](#)

Note: Meters that support ZigBee NIC are REX2 meters with firmware versions 2.x and higher.

Within the HAN menu items, once a user enters a Serial Number or LAN ID, that number or LAN ID will be saved and reshown on each HAN screen. If the user exits the HAN menu below and returns to the main menu, the Serial Number or LAN ID will be reset to blank.

HAN device-related screens show the device numbers as the number returned from the ZigBee NIC (in the range of 0 to 7).

EA_Inspector also allows you to perform the following commands on a 900 MHz HAN device:

- [Commission](#)
- [Ping](#)
- [Configure](#)
- [Decommission](#)


Note: You must have Program 900 MHz HAN privileges to access the [Configure](#) command.

Accessing Home Area Network menu

To access the Home Area Network menu:


1. From the Main Menu, select Home Area Network.

Figure 12-1. EA_Inspector Main Menu



The Home Area Network menu displays.

Figure 12-2. Home Area Network screen




2. Select the device type:
 - a. ZigBee HAN
 - b. 900 MHz HAN

ZigBee HAN device commands

The ZigBee HAN menu allows you to perform the following actions on a ZigBee device:

- View Devices
- HAN NIC Info

Figure 12-3. ZigBee HAN menu




View devices

To view a HAN device:

1. From the ZigBee HAN menu, select View Devices.


Figure 12-4. View HAN Devices screen



2. Enter the LAN ID or SN of the meter with HAN devices.
3. Click View.

A listing of HAN devices associated with the specified LAN ID.

Figure 12-5. HAN Device listing



The device number and name for each HAN device associated with the meter is displayed.

4. Select a device in the list box and click **More** to see more details about the device.

Figure 12-6. HAN device - More details



5. Click **Cancel** to return to the listing.

Viewing HAN NIC information


You can use EA_Inspector to read HAN device number (0 - 255) and to view information about the ZigBee NIC.

Note: ZigBee uses a time called UTC time in a ZigBee time cluster which is the count in seconds from January 1, 2000.

1. To view HAN NIC information, from the ZigBee HAN screen, click **HAN NIC Info**.
2. Enter the **LAN ID** or the **SN** (serial number) for the meter the HAN device is associated.
3. Click **Read**.

The HAN NIC Info displays.

Figure 12-7. HAN NIC Info screen



4. Click **Save** to save the results to a file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See ["Saving notes and GPS data"](#) on page 31 for details on collecting and saving GPS data.


900 MHz HAN devices

The 900 MHz HAN menu allows you to perform the following actions on a 900 MHz HAN device:

- Commission
- Ping
- Configure
- Decommission

Note: You must have Program 900 MHz HAN privileges to access the Configure menu.

Figure 12-8. 900 MHz HAN menu




Commissioning a 900 MHz device

Note: You must have Program 900 MHz HAN privileges to access the Set command.

To commission a 900 MHz HAN device:


1. From the 900 MHz HAN menu, select Commission.
EA_Inspector displays the Commission Device screen.

Figure 12-9. Commission Device screen



2. Enter the LAN ID for the device.
3. Enter the Activation Code you received from Elster.
4. Click Set.

Figure 12-10. Commissioning a device



Incorrect Activation
Code entered

After the commissioning, EA_Inspector displays the status of the command (success or fail).

The device ID, Activation Code and the status are automatically saved to the audit log and the results log.


Note: Once the 900 MHz HAN device is commissioned, EA_Inspector must use the new UID when performing actions on the 900 MHz HAN device.

Reading a 900 MHz HAN device

To read a 900 MHz HAN device:

1. From the 900 MHz HAN menu, select Commission.
EA_Inspector displays the Commission Device screen.
2. Enter the LAN ID for the device.
3. Click Read.

Figure 12-11. Reading a commissioned device



device commissioned
meter not present

- If the device is commissioned, EA_Inspector displays the Activation Code for the device.
- The status line indicates whether the device is commissioned and whether the device is communicating with the meter to which it was commissioned.

The device ID, Activation Code and the status are automatically saved to the audit log and the results log.

Pinging a 900 MHz HAN device


Method 1 - from the Commission Device screen

To ping a 900 MHz HAN device:

1. From the 900 MHz HAN menu, select Commission.
EA_Inspector displays the Commission Device screen.
2. Enter the LAN ID for the device.
3. Click Ping.

EA_Inspector pings the 900 MHz HAN device and displays the communications statistics.

Figure 12-12. Pinging the device - results




Method 2 - from the Ping Device screen

To ping a 900 MHz HAN device:

1. From the 900 MHz HAN menu, select Ping.
EA_Inspector displays the Ping Device screen.


Figure 12-13. Ping Device screen



2. Enter the LAN ID for the device.
3. Click Ping.

EA_Inspector displays the radio firmware version, the device's firmware version, and the communications statistics.

Figure 12-14. Ping results



4. Click **Save** to save data to the results log file for uploading into EA_Inspector Manager.

EA_Inspector opens a Notes screen. See "Saving notes and GPS data" on page 31 for details on collecting and saving GPS data.


Decommissioning a 900 MHz device

Note: You must have Program 900 MHz HAN privileges to access the Set command.

To decommission a 900 MHz HAN device:

1. From the 900 MHz HAN menu, select Decommission.
EA_Inspector displays the Decommission Device screen.

Figure 12-15. Decommissioning a device



2. Enter the LAN ID for the device.
3. Click Set.
EA_Inspector displays the result of the command (success or fail).

Figure 12-16. Decommissioning a device results




The device ID and the status of the decommissioning are automatically saved to the audit log and the results log.

Reading a decommissioned device

To read a decommissioned device:

1. From the 900 MHz HAN menu, select Decommission.
EA_Inspector displays the Decommission Device screen.
2. Enter the LAN ID for the device.
3. Click Read.
EA_Inspector displays the state of the device.

Figure 12-17. Reading a decommissioned device



The device ID and the status of the decommissioning are automatically saved to the audit log and the results log.

Configuring a 900 MHz device


Note: All the general, pricing, and messaging parameters files must be created in EA_Inspector Manager, and then sent to the HH during synchronization. Please refer to the EA_Inspector Installation and Administration Guide for directions on how to create the general, pricing, and messaging parameter files in EA_Inspector Manager.

Accessing the Config 900 MHz HAN menu

To configure a 900 MHz HAN device:

1. From the 900 MHz HAN screen, select Configure.
EA_Inspector displays the Config 900 MHz HAN menu.

Figure 12-18. Config 900 MHz HAN screen



The Config 900 MHz HAN menu allows you to configure the following the parameters:

- General
- Pricing
- Messaging
- Firmware Upgrade


Configuring general parameters

To configure general parameters:

1. From the Config 900 MHz HAN menu, select General.


If parameter files are not located on the handheld, EA_Inspector displays a notice prompting you to get parameter files from EA_Inspector Manager.

Figure 12-19. Handheld parameter file missing



2. Click OK to acknowledge the message.
3. Use EA_Inspector Manager to download the parameter files to the handheld.
4. Retry configuring general parameters.
If multiple parameter files are found on the handheld, EA_Inspector prompts you to select the proper file.

Figure 12-20. Multiple files found




5. Select the appropriate parameter file from the list.
6. Enter the LAN ID for device.
7. Click Set.

EA_Inspector begins configuring general parameters in the 900 MHz HAN device.

EA_Inspector displays the result of the configuration.

Figure 12-21. Configuration passed



EA_Inspector save the results from configuring general parameters and the parameter file name to the audit log and results log automatically.

You can view the audit log and results log through EA_Inspector Manager.

8. To add notes to the log data file or collect and save GPS data, click Save.

EA_Inspector opens a Notes screen.

9. Enter notes as needed.


Configuring pricing parameters

To configure pricing parameters:

1. From the Config 900 MHz HAN menu, select Pricing.


If parameter files are not located on the handheld, EA_Inspector displays a notice prompting you to get parameter files from EA_Inspector Manager.

Figure 12-22. Handheld parameter file missing



2. Click OK to acknowledge the message.
3. Use EA_Inspector Manager to download the parameter files to the handheld.
4. Retry configuring pricing parameters.
If multiple parameter files are found on the handheld, EA_Inspector prompts you to select the proper file.

Figure 12-23. Multiple files found




5. Select the appropriate parameter file from the list.
6. Enter the LAN ID for the device.
7. Click Set.

EA_Inspector begins configuring pricing parameters in the 900 MHz HAN device.

EA_Inspector displays the result of the configuration.

Figure 12-24. Configuration passed



EA_Inspector save the results from configuring pricing parameters and the parameter file name to the audit log and results log automatically.

You can view the audit log and results log through EA_Inspector Manager.

8. To add notes to the log data file or collect and save GPS data, click Save.

EA_Inspector opens a Notes screen.

9. Enter notes as needed.


Clearing pricing parameters

To clear pricing parameters:

1. From the Config 900 MHz HAN menu, select Pricing.
2. Enter the LAN ID for the device.
3. Click Clear.

EA_Inspector displays the results of the command.

Figure 12-25. Clearing pricing



EA_Inspector save the results from configuring pricing parameters and the parameter file name to the audit log and results log automatically.

You can view the audit log and results log through EA_Inspector Manager.

4. To add notes to the log data file or collect and save GPS data, click Save.

EA_Inspector opens a Notes screen.

5. Enter notes as needed.


Configuring messaging parameters

To configure messaging parameters:

1. From the Config 900 MHz HAN menu, select Messaging.


If parameter files are not located on the handheld, EA_Inspector displays a notice prompting you to get parameter files from EA_Inspector Manager.

Figure 12-26. Handheld parameter file missing



2. Click OK to acknowledge the message.
3. Use EA_Inspector Manager to download the parameter files to the handheld.
4. Retry configuring messaging parameters.
If multiple parameter files are found on the handheld, EA_Inspector prompts you to select the proper file.

Figure 12-27. Multiple files found




5. Select the appropriate parameter file from the list.
6. Enter the LAN ID for the device.
7. Click Set.

EA_Inspector begins configuring messaging parameters in the 900 MHz HAN device.

EA_Inspector displays the result of the configuration.

Figure 12-28. Configuration passed



EA_Inspector save the results from configuring messaging parameters and the parameter file name to the audit log and results log automatically.

You can view the audit log and results log through EA_Inspector Manager.

8. To add notes to the log data file or collect and save GPS data, click Save.

EA_Inspector opens a Notes screen.

9. Enter notes as needed.

13 CONFIGURING THE HANDHELD

About configuring the handheld

Users can configure a handheld including the following:

- Configuring handheld settings and utility IDs
- Configuring EA Defaults

Note: Only users with Program privilege can configure a handheld's Utility ID.

Accessing handheld configuration menu

To access the HH Configuration menu:


1. From the Main Menu, select **HH Configuration**.

Figure 13-1. EA_Inspector Main Menu



EA_Inspector displays the HH Configuration menu.

Figure 13-2. HH Configuration menu



2. The HH Configuration menu allows you to perform the following tasks:
- 1) [Configuring handheld settings and utility IDs](#)
 - 2) [Configuring EA Defaults](#)
 - 3) [Viewing About EA_Inspector information](#)

Configuring handheld settings and utility IDs

EA_Inspector allows you to configure the following settings used by the handheld:

- handheld ID
- performing fast reads
- battery warning threshold
- using LAN IDs

Additionally, if supported by your utility and you have the appropriate privileges, you can also change utility IDs.

Note: For security reasons, Elster limits the range of utility IDs that can be selected on a handheld to a pre-defined (and encrypted) list of customer-specific LAN IDs.

To manage handheld settings and utility IDs:

1. From the HH Configuration menu, select **HH Settings**.
EA_Inspector displays the HH Settings screen.

Figure 13-3. HH settings screen - no utility ID file on handheld

HH Settings

HH ID

Battery Warning %

GPS Enabled

FastRead UseLANID

Communication Settings

Utility ID

Encrypted LAN

Figure 13-4. HH settings - Program privilege

HH Settings

HH ID

Battery Warning %

GPS Enabled

FastRead UseLANID

Communication Settings

Utility ID

Encrypted LAN

HH Settings

HH ID

Battery Warning %

GPS Enabled

FastRead UseLANID

Communication Settings


Utility ID

Encrypted LAN

without Program privilege

with Program privilege

Figure 13-5. HH settings screen



with Allow LAN ID privilege

without Allow LAN ID privilege

Note: The settings for the Fast Read and Battery Warning % are only stored in the handheld.


2. Change the **HH ID** for the handheld, if needed.
3. Enter the **Battery Warning %** to receive a low battery warning when the battery reaches the specified level (default is 10%; the min is 10% and the max is 80%).
4. Uncheck **Fast Read** if an extended battery life is necessary.

Note: If checked, the handheld's RF com port is kept open for each RF read. If unchecked, the RF com port is opened and closed for each RF read.

5. Check to allow the handheld to **Use LAN IDs**.

If you have **Allow LAN ID** privilege and the handheld does not have an EA_MS meter ID file and you attempt to disable **Use LAN ID**, EA_Inspector prompts you to synchronize the handheld with EA_Inspector Manager and keeps **Use LAN ID** enabled.

Figure 13-6. HH settings screen - disabling Use LAN ID



6. Check **Encrypted LAN** to enable C12.22 encryption over the EA_LAN.

EA_Inspector communicates with EA_LAN devices using encryption only. EA_LAN encryption seeds are downloaded to the handheld during synchronization with EA_Inspector Manager.

Note: If you are using EA_MS 7.0, you can use the downloaded serial numbers (Use LAN ID is disabled) or if you have Allow LAN ID privilege and you have Use LAN ID enabled on the handheld then you can enter the LAN ID.

If you are using MAS 6.2 or earlier, you will need Allow LAN ID privilege and you will have to enable Use LAN ID on the handheld to enter a LAN ID. You cannot enter serial numbers in EA_Inspector if you are using MAS 6.2 or earlier. See the EA_Inspector and EA_Inspector Manager Installation and Administration Guide for details.

7. By default, Elster configures handhelds to support one utility ID, however, if specified, your utility may support multiple utility IDs, select the appropriate utility ID from the drop list.

Note: You must have Program privilege to change utility ID settings in the handheld.

8. Click **Save** to save your changes.

Note: Changes to the handheld's configuration will NOT be imported into EA_Inspector Manager during the next device synchronization. Changes to handheld settings made in EA_Inspector will be overwritten by settings from EA_Inspector Manager during the next handheld synchronization. You must duplicate handheld setting changes in EA_Inspector Manager for the changes to be permanent.

Configuring EA Defaults


EA_Inspector allows all users to set the default values on the handheld.

- Packet repeats
- Test time (in minutes)
- Seconds between Pings

To manage ping test settings:

1. From the HH Configuration menu, select **EA Defaults**.
EA_Inspector displays the EA Defaults screen.

Figure 13-7. EA Defaults - settings



2. Enter the number of **Ping Packet Repeats** (the number of additional packets transmitted at different frequencies within the 900 MHz unlicensed band; range of 0 to 10 with default of 2).

For example, if packet repeats is set to the default of 2, a total of 3 packets (1 packet plus an additional 2 packets) would be sent over 3 different frequencies in the 900 MHz band.

3. Enter the **Test time** (in minutes) (the duration time (in minutes) for a ping test; range of 1 to 10 with default of 2).
4. Enter the **Seconds between Pings** (the number of seconds delay between pings for the continuous ping test; range of 1 to 60 with default of 5; applies to electricity meters only).

Note: For a continuous ping on a gas module, the time between pings is 0.8 seconds and cannot be configured.

5. Click **Save** to save your changes.

EA_Inspector displays a dialog indicating the settings have been saved.

6. Click **OK** to acknowledge the dialog.


You are ready to perform a continuous ping test using the changed settings.

Viewing About EA_Inspector information

To view About EA_Inspector information:

1. From the HH Configuration menu, select **About**.
EA_Inspector displays the About EA_Inspector dialog.

Figure 13-8. About EA_Inspector screen



The About EA_Inspector screen displays the following information:

Item	Description
Software Name	Indicates you are using EnergyAxis EA_Inspector software.
Software Version	Indicates the version of EA_Inspector you are using.
Firmware Version	Indicates the version of firmware the EA_NIC is using.
Copyright date and holder	Indicates the date and the holder of the copyright for the software.

2. To close the dialog click the **Close** button in the upper right corner of the dialog or press the <Esc> key.

A TROUBLESHOOTING

General troubleshooting

1. Click on the screen with the stylus if the device keys navigation does not produce expected results.
2. Try to reboot the handheld:
 - Hold down the <R> + <X> + <↑> keys down simultaneously for several seconds until the screen goes blank.

— OR —

Refer to the **EA_Inspector** and **EA_Inspector Manager Installation and Administration Guide**.

Trouble connecting to EA_Inspector Manager

1. Make sure the handheld device is correctly seated in the cradle and there is not any contaminated material in between the cradle and handheld's contacts.
2. Verify the connection by starting ActiveSync and waiting for the device to synchronize.
3. Check if the handheld's LED is glowing either green or red. If not then maybe the AC charger is faulty.

Communication mode errors and warning messages

#	HH Message	Reason	HH Comm. Mode	Meter Comm. Mode	Meter Response	User Action Recommended
0	NONE		Unencrypted LAN	Any Meter with Encryption Disabled	AOK or Valid Data	None
1	Meter is out of range or unencrypted. Try again with encryption OFF? (Yes or No)	Meter is out of range or is Legacy mode.	Encrypted LAN	Any Meter	RN (no response)	Retry action with encryption disabled.
2	Action Name + "Failed" (for example, "Find Failed")	Meter is out of range.	Unencrypted LAN	Any Meter	RN (no response)	Move closer to meter and retry action.
3	Meter is encrypted. Retry with encryption ON? (Yes or No)	Meter is encrypted.	Unencrypted LAN	Encrypted Meter NON Ping Request	05 – Inappropriate Action Requested	Retry action with encryption enabled.

#	HH Message	Reason	HH Comm. Mode	Meter Comm. Mode	Meter Response	User Action Recommended
4	LAN Encryption mismatch: please update the handheld seeds with EA_Inspector Manager.	LAN Encryption is mismatched between HH and meter.	Encrypted LAN	Encrypted Meter NON Ping Request	1C – Packet Decryption Failed	Synchronize handheld with EA_Inspector Manager.
5	LAN Encryption mismatch: please update the handheld seeds with EA_Inspector Manager.	LAN Encryption is mismatched between HH and meter.	Encrypted LAN	Meter with Encryption Key but its Encryption Disabled; NON Ping Request	1C – Packet Decryption Failed	Synchronize handheld with EA_Inspector Manager.
6	Warning: Meter is encrypted. Press “E” to retry with encryption.	Reading an encrypted meter.	Unencrypted LAN	Encrypted Meter Single Ping Request	05 – Inappropriate Action Requested The meter provides Host/Radio FW versions, packet number, and RSSI regardless of the encryption states and key values.	Retry action with encryption enabled. If “E” is pressed, the additional data is provided if the encryption key is a match, otherwise an mismatch error is reported.
7	LAN Encryption mismatch: please update the handheld seeds with EA_Inspector Manager.	LAN Encryption is mismatched between HH and meter.	Encrypted LAN	Encrypted Meter Single Ping Request	1C – Packet Decryption Failed	Synchronize handheld with EA_Inspector Manager.
8	LAN Encryption mismatch: please update the handheld seeds with EA_Inspector Manager.	LAN Encryption is mismatched between HH and meter.	Encrypted LAN	Meter with Encryption Key but its Encryption Disabled; Single Ping Request	1C - Packet Decryption Failed	Synchronize handheld with EA_Inspector Manager.

Verifying encrypted communications

To verify encrypted communications, you must have access to the following:

- REX2 meter configured to require encryption
- EA_Inspector with the following:
 - proper LAN seed downloaded
 - same utility ID as the REX2 meter

To verify encryption is working:

1. Using the procedure described in [“Configuring handheld settings and utility IDs” on page 171](#), uncheck to disable Encrypted LAN.
2. Click Save to save the configuration change.
Encryption in the handheld is disabled.
3. Using the procedure described in [“One shot ping of electric meter” on page 39](#), perform a ping test on the REX2 meter.

The handheld displays the radio performance data (packets, RSSI, etc.) but no reading data is displayed.

The handheld displays a message Warning: Meter is encrypted. Press "E" to retry with encryption.

4. Press <E> to retry the ping using encryption.

The handheld retries the ping action with encryption enabled.

Note: After the command, the handheld returns to operating in unencrypted mode.

Elster contact

For EA_NIC error messages or for further information, please contact:

Customer Support
Elster
208 South Rogers Lane
Raleigh, NC 27610

T +1 800 338 5251 (US toll free)

energyaxis.support@us.elster.com

