

Quanta LI170 Test Operation Guide

Version 0.3
Oct. 07, 2012
Winn

Contents

1.	Introduction	3
2.	Test Environment	3
2.1.	Uninstallation	3
2.1.1.	Windows 7 (32 bit)	3
2.2.	Installation of drivers	5
2.2.1.	Windows 7 (32 bit)	5
3.	Operation of Connection Manager	11
3.1.	Windows 7 (32 bit)	11
3.1.1.	Basic Configuration	11
3.1.2.	Extended Information	13
3.1.3.	LTE Manager	15
3.1.4.	Manual PLMN	16
3.1.5.	Change to Commercial Mode	17
3.1.6.	Disable Polling	18
3.1.7.	PIN Management	19
3.1.8.	Automatic Connect Mode	20
3.1.9.	Device Location	21
3.1.10.	Help	22
3.1.11.	Reset	23
4.	Diagnostic Tool	24
4.1.	MsgView	24
4.2.	DbgView	25
5.	Firmware Upgrade	26
5.1.	Image Burn Tool	26
6.	OMA-DM	30
6.1.	Mandatory Configuration	30
6.2.	How to Enable/Disable APN	31
6.3.	How to Modify OMA-DM Server URL	33
6.4.	How to Online Enable/Disable Internet APN	35
6.5.	How to Enable/Disable OMA-DM log	36
6.6.	How to Use VI editor	37

Revision History

Version	Release Date	Description
0.1	Oct. 02, 2012	1 st Test Operation Guide Release
0.2	Oct. 04, 2012	Add chapter 6.
0.3	Oct. 07, 2012	Draft

1. Introduction

This document gives the guidance on how to test Quanta devices.

2. Test Environment


Quanta LI170 device supports Windows XP, Windows Vista (32 bit), and Windows 7 (32 bit) operating system. It's recommended to install Quanta LI170 software in Windows 7 32-bit OS.

2.1. Uninstallation

In order to install latest version of software, uninstallation of previous version is required, including drivers, connection manager, and corresponding software tools.

2.1.1. Windows 7 (32 bit)


1. Please click
Start→Programs→Altair Semiconductor→LTE
ALT3100→Uninstall




2. Please click “Yes (Y)” button.



3. Please click "Uninstall" button.
4. Please wait a few seconds to complete uninstallation.




5. Please click "Close" button.




6. Please click "OK" button.



7. Please click "Start→Programs→Altair Semiconductor→LTE ALT3100→HLVUSB→Uninstall".





8. Please click "YES (Y)" button.
9. Please reboot your computer after you have completed the uninstallation.




2.2. Installation of drivers

2.2.1. Windows 7 (32 bit)


1. Please double clicks on “Altair(Quanta) Tool Package v1.0.0.exe” to start installation.
2. Please click “Next >” button.
3. Please click “Install” button.
4. It will take a few minutes to complete installation.
5. Please click “Next >” button.




6. Please check "I accept the terms in the license agreement".
7. Please click "Next >" button.




8. Please select "Full Installation" type.
9. Please click "Next >" button.




10. Please click "Next >" button.




11. Please click "Install" button.



12. Please click "Next >" button.



13. Please click "Finish" button.




14. Please click "Next >" button.




15. Please check "I accept the terms in the license agreement".


16. Please click "Next >" button.




17. Please click "Install" button.





18. Please click “Continue to install driver anyway (I)”.
19. Please click “Continue to install driver anyway (I)”.
20. Please click “Continue to install driver anyway (I)”.
21. Please click “Continue to install driver anyway (I)”.
22. Please un-check “Launch “Hostless Image Burn””.
23. Please click “Finish” button to complete driver installation.



24. Please click “OK” button.



25. Please click “Finish” button.



26. Please plug in Quanta device and please be patient and wait a few minutes to complete driver installation.
27. Please click “Close (C)” button.
28. Please reset Quanta device (take out and plug in the usb cable), it will take about 50 seconds for Quanta embedded system to be ready.




3. Operation of Connection Manager


3.1. Windows 7 (32 bit)

3.1.1. Basic Configuration

1. In order to get information from our embedded connection manager, it's mandatory to configure as the following instructions.
2. Please click
Start→Programs→Altair Semiconductor→LTE ALT3100→Connection Manager.



3. Please right click on top of connection manager and select
Options→Device Location→Technician PC.




4. Connection manager will pop out window for you to enter IP and port.
5. Please enter IP address "10.0.0.1". (see NOTE)
6. Please click "OK" button.

NOTE: If you have successfully installed Quanta LI170 device, the embedded module will generate DHCP server and its IP address is "10.0.0.1". Meanwhile, our Quanta device will get a DHCP address "10.0.0.133" automatically.





7. Please check if connection manager shows device information correctly and the red Altair logo turns into yellow color.




3.1.2. Extended Information


1. Please right click on top of connection manager and select View→Extended Information.
2. Connection manager will pop out “Extended Information” window.
3. It’s NOT mandatory to set up this “Configuration” tab, connection manager will scan all the supported frequency bands and try to connect to the network.



4. The “Extended Data” tab shows information of Connection Status, APN, Transmission mode, Bandwidth, DL EARFCN, Band, PLMN and Physical Cell ID and so on.





5. The “At Commands” tab will allow you to send AT Commands sets to configure supported functional parameters or to get supported information you want.




3.1.3. LTE Manager

1. Please right click on top of connection manager and select
View→LTE Manager.
2. Connection manager will pop out a “Supervisor Password” window.
3. Please input “123456” and click “OK” button.
4. It will pop out a “LTE Manager” window.
5. LTE Manager shows information about GeneralInfo, LogCreator, Dispatcher, Relay, and GPS Tool.



3.1.4. Manual PLMN

1. Please right click on top of connection manager and select Manual PLMN.
2. Connection manager will pop out a “Plmn Search” window.




3. It's not necessary for you to select PLMN manually if you want to connect to network.




3.1.5. Change to Commercial Mode

1. Please right click on top of connection manager and select “Change to Commercial Mode”.
2. Connection manager will pop out a “User Mode Changed” dialog.




3. Please click “YES (Y)” button.



4. Please wait a few seconds for device to be ready.



3.1.6. Disable Polling

1. Please right click on top of connection manager and select
“Options→Disable Polling”.
2. Connection manager will stop searching for available network.




3.1.7. PIN Management

1. Please right click on top of connection manager and select
“Options→PIN Management→PIN Information”
to get PIN information.
2. Connection manager will pop out “PIN
Information” window.
3. Please click “OK” button.



4. You also can enable PIN usage by right click on
top of connection manager and select
“Options→PIN Management→Enable PIN
Usage”.
5. Please input correct PIN code and click “OK”
button.



3.1.8. Automatic Connect Mode

1. Please right click on top of connection manager and select
“Options→Automatic Connect Mode” to switch connection manager from manual connect mode to automatic connect mode.
2. Connection manager will automatically connect to network.

