



Installation and Management

Lynx.GX

Installation and Management

Models 4T, 4E-BNC, 4E, 8T, 8E, 16T



First Edition, January 2004

Copyright and Service Marks

Copyright © 2004 by Proxim Corp. All rights reserved. No part of this book may be reproduced without prior written permission from Proxim Corp.

The information contained in this book is subject to change without notice. Proxim shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this book or equipment supplied with this book. Proxim makes no warranty of any kind with regard to this book or any equipment supplied with this book, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Tsunami™ and Tsunami.GX are trademarks of Proxim Corporation.

Lynx™ and Lynx.GX™ are trademarks of Proxim Corporation.

OpenView® is a registered trademark of Hewlett Packard Corporation.

Windows® is a registered trademark of Microsoft Corporation.

Other names are trademarks of their respective owners.

Y2K (Year 2000 Issue): All software supplied by and for Proxim products adhere to the 4-digit year nomenclature as required for Year 2000 compliance.

Regulatory Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Shielded cables and I/O cords must be used for this equipment to comply with the relevant FCC regulations.

Changes or modifications not expressly approved in writing by Proxim may void the user's authority to operate this equipment.

This device complies with Part 15 of FCC rules and RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WARNING!

This device must be professionally installed. Instructions for setting the transmitter RF output power are referenced in "Adjust Output Power" on page 27. This device is to be used exclusively for fixed point-to-point operation that employs directional antennas. Be sure to read "Product Safety Instructions" above before installing this product.

Product Safety Instructions

This product must be installed, used, and maintained by experienced telecommunications personnel only.

When installed, this equipment is to be connected to a lightning/surge protection device that meets all applicable national safety requirements.

WARNING!

To avoid injury, risk of fire, and damage, do not connect this product directly to an antenna. Ensure that proper lightning isolation also is provided between this unit and other equipment.

Equipment is to be used and powered by the type of power source indicated on the marking label only.

Lynx.GX radios are intended to be connected to a ± 24 VDC or ± 48 VDC power source, which must be electrically isolated from any AC sources and reliably earthed.

Only a DC power source that complies with the Safety Extra Low Voltage (SELV) requirements in the Standard for the Safety of Information Technology Equipment, including Electrical Business Equipment, CAN/CSA C22.2, No. 950-95 * UL 1950, Third Edition, can be used with this product.

A 5-Amp circuit breaker or fuse is required at the DC power source. If using the Proxim optional power supply (P/N 201-31075-1), use a 15-Amp circuit breaker or fuse on the AC input. In addition, an easily accessible disconnect device should be incorporated into the facility wiring.

Always use copper conductors only for all power connections.

Do not connect or disconnect the power cable to the equipment when the other end of the cable is connected to the DC power supply.

WARNING! This product must be serviced by trained personnel only.

Do not:

- Disassemble this product. Opening or removing any covers voids the warranty for this product. Furthermore, by opening or removing any covers, you could expose yourself to hazardous energy parts. Incorrect reassembly of this product can cause a malfunction or electrical shock when the unit subsequently is used.
- Insert any objects of any shape or size inside this product while powered. Objects could contact hazardous energy parts, resulting in a risk of fire or personal injury.
- Spill any liquids of any kind on or inside this product.
- Cover or block any of the openings (to protect this product from overheating). Side and top cover openings on the IDU are provided for ventilation.

Always ensure the following:

- That sufficient space is provided surrounding this product.
This product can be installed in a standard 19-inch rack. Check the size and clearance requirements for this product and ensure that enough clearance is provided for installation. Consideration should be given to the mechanical loading of the rack and the equipment to avoid potential hazards.
- If this product is to be powered from the same source as other units, ensure that the power supply circuit is not overloaded.
- When installed in a rack, always ensure that proper air flow is provided for this product. Mount as shown in this manual.
- If you are using a standard telephone (for orderwire function) not provided by Proxim with this product, ensure that the telephone has a ringing equivalency specification of 1.0 Baud and is a UL-Listed (ITE) device that has been evaluated to the Standard for the Safety of Information Technology Equipment, including Electrical Business Equipment, CAN/CSA C22.2, No. 950-85 * UL 1950, Third Edition.

The maximum room ambient temperature for the IDU is 50° C. When installed in a closed or multi-unit rack, consideration should be given to installing this equipment in an environment compatible with the maximum room ambient temperature.

Equipment is suitable for mounting on concrete or other noncombustible surfaces only.

Contents

PRODUCT SAFETY INSTRUCTIONS	3
CONTENTS.....	4
Figures.....	5
CHAPTER 1. INTRODUCTION	6
Intended Audience.....	6
Equipment Features	6
Planning for Installation	7
Troubleshooting Hints.....	7
CHAPTER 2. INSTALLING THE IDU AND RFU	8
Step 1. Gather Required Tools.....	8
Step 2. Unpack Shipping Box Contents	9
Step 3. Test Radios Back-to-Back.....	11
Step 4. Install the Radio Units	14
Step 5. Install and Adjust the Antenna	18
Step 6. Establish Connections.....	22
Step 7. Adjust Output Power	27
Step 8. Establish a Link Between the Radios.....	28
Step 9. Establish Near-End to Far-End Communications using Orderwire (optional)	31
CHAPTER 3. MANAGING THE LYNX.GX.....	32
Managing with the Web Interface	33
Managing with SNMP	44
Managing with Telnet.....	44
Maintaining the Radio.....	45
APPENDIX A. INSTALLATION PLANNING	46
Site Selection	46
Availability	47
Fade Margin.....	47
Useful Path Calculations.....	48
Equipment Co-Location	52
Planning for and Selecting IF Cable	53
Planning for Antenna and RF Transmission Line Installation.....	54
APPENDIX B. WEB INTERFACE WINDOWS AND FIELD DESCRIPTIONS	56
Device Tab—Accessing Radio Information	56
Interface Configuration Tab—Modifying T1/E1 Interface Configurations.....	57
System Configuration Tab—Configuring Tx Power, Security Link ID, and Tx Channel Plan	58
Status Tab—Viewing Current Status.....	59
Alarms Tab—Monitoring Link Status	61
Log Tab—Viewing Status and Alarms.....	62
Contact Tab—Viewing Support Information	64
Administration Tab—Changing System Passwords, Date, and Time	64
APPENDIX C. LYNX.GX FRONT PANEL AND CONNECTIONS	69
Models	69
Basic Specifications.....	69
Channel Plans	70
Lynx.GX Front Panel	71
Front Panel Common Connectors, Indicators and Controls.....	72
APPENDIX D. CONNECTORS AND PIN ASSIGNMENTS	75
IDU Main Traffic T1/E1 Connectors.....	75
IDU VF Port	76
IDU Aux Data Port Connector (DCE port)	77
IDU NMS Port Connectors.....	78
IDU Alarm Port Connector	79
IDU Configuration Port Connector (DTE port).....	80
IDU Orderwire Port Connector	81

IDU/RFU Cable Connector and Pin Assignment.....	81
RSL and GND Connectors on IDU	82
RFU/Antenna Connector and Pin Assignment	82
RFU RSL/Tone and Pin Assignment	83
APPENDIX E. SPARES AND ACCESSORIES	84
APPENDIX F. LYNX.GX SPECIFICATIONS	85
Lynx.GX 4T/4E (5.8 GHz) Specifications	85
Lynx.GX 8T (ISM) Specifications.....	86
Lynx.GX 8E (ISM) Specifications	87
Lynx.GX 16T Specifications	88
Detailed Lynx.GX Specifications	89
APPENDIX G. TROUBLESHOOTING	93
Changing Frequency Plans	93
Counteracting and Evaluating Interference	93
Troubleshooting Alarms.....	95
Troubleshooting the Web Interface Management Tool	98
Repair Policy.....	99
TECHNICAL SUPPORT	100
Enhanced Warranty Packages	100
WARRANTY	101
ACRONYMS / GLOSSARY	103

FIGURES

Figure 1. Back-to-Back Test Configuration	12
Figure 2. Link Testing.....	13
Figure 3. Loopback Mode	13
Figure 4. Daisy Chaining NMS Connections at a Hub Location	34
Figure 5. Port Connector Layout for 16 T1 Ports.....	75
Figure 6. VF Plug Pin Assignments	76
Figure 7. Aux Plug Pin Assignments.....	77
Figure 8. NMS Plug Pin Assignment.....	78
Figure 9. Alarm Plug Pin Assignment	79
Figure 10. Configuration Plug Pin Assignments	80
Figure 11. Orderwire RJ-11 Modular Plug (typical termination).....	81
Figure 12. IDU/RFU Cable Connector	81
Figure 13. RSL and GND Connectors on IDU	82
Figure 14. Antenna Type N Female Front Panel Connector	82
Figure 15. Antenna Type N Male Connector	82
Figure 16. RSL/Tone BNC Female Panel Connector	83
Figure 17. RSL/Tone BNC Male Connector to DVM or Headphone.....	83

Chapter 1. Introduction

Proxim Corporation introduces the GX platform of wireless T1 or E1 radio products—Lynx.GX. The split-box design lets you install both units indoors, or one unit indoors (the IDU, or Indoor Unit) and one unit outdoors (the RF Unit, or RFU).

The units can be mounted in a 19-inch or 23-inch rack; each unit is 1.75" high, occupying one rack unit (RU). Two pieces fit in two RU spaces for indoor installation, or you can mount the RFU outdoors on a tower or pole.

The IDU and RFU are connected with a single coaxial cable that carries power, telemetry, TX IF and RX IF signals; the antenna is connected to the RF unit with a coaxial cable. Outdoor placement of the RFU can directly contribute to significant cost savings of cable and antennas, improved system availability, and enhanced path performance.

A standardized and easy-to-use interface is provided, with a full network management system (NMS) for remote equipment management.

INTENDED AUDIENCE

This book is designed for network engineers and field service personnel responsible for installing, maintaining, and troubleshooting the Lynx.GX radios. It is assumed you have an understanding of networks in general and a basic understanding of the following subjects:

- Microwave fundamentals
- Antenna systems
- Transmission line systems
- Electrical grounding
- Microwave test equipment
- T1, E1, DS-3
- Ethernet, Fast Ethernet
- IP networking

EQUIPMENT FEATURES

The following features apply to the Lynx.GX product series:

- Split-box design with IDU and RFU for addressing budget, maintenance, and performance requirements
- User-selectable frequency plans (for those models that support more than one frequency plan)
- Full-featured Fault and Configuration Management through Web browser, SNMP, Telnet, or serial connection
- Advanced diagnostics (such as RSL time-strip charting and alarm logging) for troubleshooting the equipment and the microwave path, including a spectrum analyzer to check remote transmitter function and possible interference
- Auxiliary interfaces include a serial data port and orderwire connection (VF bridge)
- Link ID authentication algorithm to ensure highly secure link transmission.

PLANNING FOR INSTALLATION

There are several planning factors to be considered prior to installing the radio system. In addition to selecting the installation site, you must:

Calculate:

- Required RSL and fade margin to achieve availability objectives
- Required path availability
- Anticipated Multi-Path Reflection Points

Determine:

- System Frequency Plan
- Required Antenna Size and Type
- Required Antenna Mounting Height to obtain proper Path Clearance
- Required Transmission Line Types and Lengths

Plan for:

- The unit's continuous power consumption needs
- Antenna installation
- Lightning protection and system grounding
- Radio hardware mounting
- Cable installation including egress
- Pre-testing Radio Equipment (back-to-back test procedure)

For detailed information regarding these planning items, see "Installation Planning" on page 46.

TROUBLESHOOTING HINTS

- Most common problems are poor transmission line connector terminations.
 - Best way to test is a return loss measurement (VSWR).
 - Basic function can be tested using a continuity and short test with DMM.
 - The transmission line can be evaluated with a network analyzer connected to both ends of cable through the cable and comparing when spectrum analyzer is connected directly to the radio without the cable.
 - Transmission line loss can be evaluated with a back-to-back Receive Signal Level (RSL) test.
 - "Tap and wiggle" testing of all terminations while monitoring RSL and alarms can expose poor terminations.
- Could be a faulty antenna.
 - Very hard to tell without swapping.
 - VSWR test on antenna feed can identify antenna problems.
 - "Tap" test can expose a faulty feed for moisture or connector problems.
- Could be a faulty radio.
 - Back-to-back RSL testing normally exposes a faulty radio.
- Could be a path obstruction or multipath reflection
 - Re-evaluate path clearance including Fresnel zone criteria.
 - Driving or walking the path may be required to identify potential obstructions.
 - Re-check path calculations for multipath reflection points along the paths

Chapter 2. Installing the IDU and RFU

The following sections describe how to install the GX radios.

- Step 1. Gather Required Tools (below)
- Step 2. Unpack the Remaining Contents of Shipping Box (on page 9)
- Step 3. Test the Radios Back-to-Back (on page 11)
- Step 4. Install the Radio Units (on page 14)
- Step 5. Install and Adjust the Antenna (on page 18)
- Step 6. Establish Connections (on page 22)
- Step 7. Adjust Output Power (on page 27)
- Step 8. Establish a Link Between the Radios (on page 28)
- Step 9. Establish near-end to far-end Communications Using Orderwire (optional) (on page 31)

STEP 1. GATHER REQUIRED TOOLS

The following sections list the tools required when installing the radios.

IDU Installation Tools (Indoor)

You must obtain the following tools before installing the IDU:

- Phillips (cross-tip) screwdrivers (for 19-inch rack-mounting and attachment of brackets)
- Small blade (1/8") standard screwdriver (for power supply connector)
- Wire crimpers (if using any 8-pin modular 2-wire or 4-wire connectors that are not pre-made)
- Soldering iron (if using any D-type connector)
- Adjustable 6" wrench to attach the chassis ground wire ($7/16$ " for RFU and $1/4$ " for IDU)

No additional tools are required from the above list if the RFU is mounted indoors.

RF Unit Installation Tools (Outdoor)

You must obtain the following before installing the RF Unit outdoors:

- RFU outdoor mounting kit (NOT INCLUDED WITH SHIPMENT; order separately)
- Adjustable 6-inch wrench (for installing the mounting bolts)
- Large blade standard screwdriver (for pole mounting clamps)
- Additional weatherproofing material for sealing the IDU and antenna connectors. (Butyl tape supplied with RFU mounting kit.)

Test and Configuration Tools

The following tools, which are necessary and useful to have available for testing and configuring the radios:

Digital Multi Meter	To measure RSL, DC power, and for antenna alignment
RF power meter	To measure transmitter output power.
Cellular telephone or 2-way radio	For talking with far-end crew and tower crew.
Bit Error Rate test set	To test link after installation.
Computer*	For NMS access.
Pair of touch-tone telephones 1.4 B or less REN	To test Orderwire circuits and for communication with far-end.

*with 10/100 Ethernet Network Interface Card, CAT5 cross-over cable, and Internet browser

Additional tools may be needed for antenna and transmission line installation and antenna alignment as well as the lightning arrestor mounting and grounding. Consult the antenna manufacturer documentation and review “Installing and Adjusting the Antenna” on page 18.

STEP 2. UNPACK SHIPPING BOX CONTENTS

The boxes should be left intact and sheltered until arrival at the installation site.

If the shipping container shows signs of damage, notify the transportation company immediately. Upon receipt, inspect contents to make sure no parts are missing or damaged.

You should retain all the packaging materials (including all internal boxes). In the unlikely event that you must return the equipment to the factory, use the original packing materials for return shipment. The packaging materials also are recommended for transporting the equipment from location to location.

Shipment Contents

Each Lynx.GX shipment includes one GX Indoor Unit (IDU), one GX RF Unit (RFU), and an installation accessory kit, as shown in the tables below.



Lynx.GX 4xT1

Lynx.GX 4T 5.8 GHz ISM System					
Hi, Model 51850-10H0 (Item 62292)			Low, Model 51850-10L0 (Item 62291)		
Item #	Description		Item #	Description	
62290	Lynx.GX 4T1 Indoor Unit		62290	Lynx.GX 4T1 Indoor Unit	
62138	Lynx.GX 5.8 GHz Hi RF Unit		62137	Lynx.GX 5.8 GHz Low RF Unit	
67262	GX RFU Indoor Installation Kit		67262	GX RFU Indoor Installation Kit	
67263	GX IDU Installation Kit		67263	GX IDU Installation Kit	

Lynx.GX 4xE1 Balanced (RJ48C)

Lynx.GX 4E 5.8 GHz ISM System					
Hi, Model 301-51850-20H0 (Item 62295)			Low, Model 301-51850-20L0 (Item 62294)		
Item #	Description		Item #	Description	
62293	Lynx.GX 4E Indoor Unit, Balanced, RJ48C		62293	Lynx.GX 4E Indoor Unit, Balanced, RJ48C	
62138	Lynx.GX 5.8 GHz Hi RF Unit		62137	Lynx.GX 5.8 GHz Low RF Unit	
67262	GX RFU Indoor Installation Kit		67262	GX RFU Indoor Installation Kit	
67263	GX IDU Installation Kit		67263	GX IDU Installation Kit	

Lynx.GX 4xE1 Unbalanced (BNC)

Lynx.GX 4E 5.8 GHz ISM System			
Hi, Model 301-51850-30H0 (Item #64751)		Low, Model 301-51850-30L0 (Item #64749)	
Item #	Description	Item #	Description
64750	Lynx.GX 4E1 Indoor Unit, Unbal., BNC	64750	Lynx.GX 4E1 Indoor Unit, Unbal., BNC
62138	Lynx.GX 5.8 GHz Hi RF Unit	62137	Lynx.GX 5.8 GHz Low RF Unit
67262	GX RFU Indoor Installation Kit	67262	GX RFU Indoor Installation Kit
67263	GX IDU Installation Kit	67263	GX IDU Installation Kit

Lynx.GX 8xT1

Lynx.GX 8T1 5.8 GHz ISM System			
Hi (Model 301-51145-10H0—Item #62142)		Low (Model 301-51145-10L0—Item #62139)	
Item #	Description	Item #	Description
62135	Lynx.GX 8T Indoor Unit	62135	Lynx.GX 8T Indoor Unit
62138	Lynx.GX 5.8 GHz ISM, Hi RF Unit	62137	Lynx.GX 5.8 GHz Low RF Unit
67262	GX RFU Indoor Installation Kit	67262	GX RFU Indoor Installation Kit
67263	GX IDU Installation Kit	67263	GX IDU Installation Kit

Lynx.GX 8xE1 Balanced (RJ48C)

Lynx.GX 8E1 5.8 GHz ISM System			
Hi (Model 301-51145-20H0—Item #62145)		Low (Model 301-51145-20L0—Item #62144)	
Item #	Description	Item #	Description
62143	Lynx.GX 8E Indoor Unit, Balanced, RJ48C	62143	Lynx.GX 8E Indoor Unit, Balanced, RJ48C
62138	Lynx.GX 5.8 GHz Hi RF Unit	62137	Lynx.GX 5.8 GHz Low RF Unit
67262	GX RFU Indoor Installation Kit	67262	GX RFU Indoor Installation Kit
67263	GX IDU Installation Kit	67263	GX IDU Installation Kit

Lynx.GX 16xT1

Lynx.GX 16T1 5.8 GHz ISM System			
Hi, (Model 301-52290-10H0, Item 62286)		Low, (Model 301-52290-10L0, Item 62284)	
Item #	Description	Item #	Description
62285	Lynx.GX 16T1 Indoor Unit	62285	Lynx.GX 16T1 Indoor Unit
62138	Lynx.GX 5.8 GHz ISM, Hi RF Unit	62137	Lynx.GX 5.8 GHz ISM, Low RF Unit
67262	GX RFU Indoor Installation Kit	67262	GX RFU Indoor Installation Kit
67263	GX IDU Installation Kit	67263	GX IDU Installation Kit

GX Installation Kits

Item	Contents	Qty.
GX RFU Installation Kit	GX RFU Rack Mount Kit (see "Sub-Contents" below)(19" or 23") RFU Grounding Cable	1 1
GX IDU Installation Kit	GX IDU Rack Mount Kit (see "Sub-Contents" below)(19" or 23") IDU Grounding Cable IDU-to-RFU Interface Cable 12" IDU DC Power Cord with CD 3-Pin Terminal Block Custom Cable Kit RJ-45 (see "Sub-Contents" below) Custom Cable Kit DB9 (see "Sub-Contents" below) Rubber Table Mount Feet	1 1 1 1 1 1 4
Documentation and Software CD-ROM	Release Notes, Installation and Maintenance Manual, Quick Install Guide, MIBs	1
GX Quick Install Guide	printed	1
Sub-Contents		
Item	Contents	Qty.
GX IDU Rack Mount Kit (19" or 23")	"L" IDU Rack Mount Brackets 2-inch Extender Brackets GX Rack Mount Screw Pack (see below)	2 2 1
GX RFU Rack Mount Kit (19" or 23")	L" RFU Rack Mount Brackets 2-inch Extender Brackets GX Rack Mount Screw Pack (see below)	2 2 1
GX Rack Mount Screw Pack	Rack Mount Screws Small Extender Bracket Screws	4 8
Custom Cable Kit RJ-45	RJ-45 Connectors	2
Custom Cable Kit DB9	Metal DB9 Connectors DB9 Cable Sheaths	1 1

STEP 3. TEST RADIOS BACK-TO-BACK

Before installing the radios, Proxim recommends a back-to-back test of the radio pair. Back-to-back testing is a simple way to verify that the radios are fully operational before they are installed. The process of installation adds several variables that can lead to system turn-up delays during troubleshooting (such as antenna alignment, cabling, and path dynamics). By pre-testing the radios, you reduce the chance of the radios being the cause of system turn-up problems, and you can focus on other factors, such as the transmission line, antenna alignment, and path clearance.

Note: Back-to-back testing must be performed to verify a radio problem before returning any radio to the factory for repair.

Required Equipment for Test

Back-to-back testing must be performed with both radios at the same location. The following test equipment is required:

- DC power source capable of supplying approximately 200 Watts (total) to the radios (or two radio AC adapters)
- One low-loss coaxial cable, N-to-N male
- One (or more) coaxial in-line fixed attenuators, 50 to 100 dB total attenuation

The following test equipment may also be useful for further testing of the radio:

- Bit Error Rate (BER) tester
- Variable RF attenuator (60 dB range or more, rated for the proper frequency, 5.8 GHz) or several fixed attenuators totaling 100 dB.
- RF power meter

Back-to-Back Test Configuration

When the equipment is connected as shown in the following figure, both radios should have no alarm conditions. (Data Input and AIS OUT are exceptions, if any of the T1/E1 channels are not connected.) If these conditions have been met, it is likely that the radio is operating in accordance to specifications. If errors or alarms occur during this test, verify alarm status. If alarms or errors are still present, one or both of the radio terminals is likely to be faulty.




Figure 1. Back-to-Back Test Configuration

It can be helpful to insert a variable RF attenuator between the radios to fade down the path to determine that the threshold specification is being met. You can run the threshold tests in both directions to isolate the radio problem (if any). See “Link Testing” on page 13 for more information.

You can use an RF power meter to individually test each radio’s output power to test the transmitter functions. You can also use the radio’s output transmitter attenuation to help precisely lower the link to threshold level after inserting attenuation.

If the transmitter output power has been verified (by the mathematics of the back-to-back test or by a power meter) and the threshold is not meeting specification, the side whose threshold is diminished is the likely radio at fault. Swapping IDUs from one end to the other can help determine whether the problem is with the IDU or the RF Unit.

WARNING!

The radios will be damaged if appropriate attenuation is not supplied between radios. You must provide a minimum of 50 dB between the two radios. At 50 dB attenuation, output power can be left at maximum output power.

Link Testing

Link testing is the preferred way to evaluate a radio link's performance. It can be performed from end-to-end or in link test mode (which tests both directions of the radio path). The following figure illustrates a typical test configuration (which may include the radio's path instead of in-line attenuators).




Figure 2. Link Testing

When performing testing, verify all configuration settings.

Note: If link testing indicates an unacceptable level of errors, see the instructions in “RF Link Alarms” on page 95.

Several built-in loopback functions are implemented in the radio. They are:

Local LB

Local radio line interface is in loopback to the line connector (does not test the wireless link). This is useful for external equipment or circuit testing, including an external BER tester.

Remote LB-int

The far end or remote radio is set to loopback data. The radio uses an internally generated signal and external signals are ignored. This is useful for testing the entire radio link without using external test equipment.

Remote LB-ext

Similar to Remote LB-int, but an external T1/E1 signal is required locally. This is useful for testing the entire radio link and includes testing the physical connector to which the external test equipment is connected. Running this test on every interface from both ends of the radio link would completely test every interface connector and the complete radio link.




Figure 3. Loopback Mode

Only one loopback can be enabled per link at a time; that is, only one channel can be tested at a time and configuring a channel in loopback disables the current loopback. The front panel and Web interface loopback LED on the near-end and far-end radios informs the operator that the radio is configured in loopback mode.

STEP 4. INSTALL THE RADIO UNITS

There are two primary ways to install the radio system.

IDU and RFU Indoor Mounting

Both units (the IDU and the RF Unit) are mounted indoors or in a suitable enclosure, stacked on top of one another, in a rack.

IDU Indoor Mounting / RFU Outdoor Mounting

The IDU is mounted indoors and the RF Unit is mounted outdoors, either near the antenna or simply at a location somewhere between the enclosure/structure egress point and the antenna.

Complete the installation of all cables and the antenna system prior to connecting power; refer to “Installing and Adjusting the Antenna” on page 18 for important information.

Installing Both the IDU and RFU Indoors

Although rack-mounting of the IDU is the ideal configuration; the radio can be placed on a tabletop or a cabinet shelf. To prevent movement, apply the rubber table mount feet, found in the GX IDU Installation Kit, under the bottom of the radio at each corner.

For rack mounting, to optimize cabling and to avoid interference with the RFU or antenna cables, mount the IDU high in a standard 19-inch rack. Empty rack-mounting spaces above and below the unit are recommended, especially if the surrounding equipment dissipates a considerable amount of heat (over 40W).

When mounting both the IDU and the RFU indoors, mount the IDU immediately below the RFU with no gap between the units. (The IDU provides required forced-air cooling of a rack-mounted RFU). Leave the equivalent of one rack space above the total 2-unit space for the radio if any equipment is mounted above the radio system.

Set up the radio for mounting (using the rack mounting brackets enclosed with the screws in the shipping container) with the front edge projecting from the front face of a standard 19-inch rack. Alternatively, you can reverse the rack-mounting brackets to install the unit at a flush position. Additional extension brackets are provided for 23-inch rack mounting and are attached to the standard 19-inch rack flanges with screws provided.


The radio has internal fans that intake on the left side and exhaust on the right side of the chassis. When rack mounting, leave a small gap between the outer edges of the radio and the inside edge of the rack.

A short 12” IDU-to-RFU interface cable (TNC to TNC) is included in the GX IDU Installation Kit. Use this cable to connect the IDU to the RFU when both are installed indoors.


To rack-mount the IDU and RFU:

1. Gather all the parts contained in the GX IDU Installation Kit.
2. Set the unit on a flat surface and, using a screwdriver, remove the front screws on each side of the unit that match up to the holes of the rack mounting flange. You must remove these screws to prepare the unit for bracket attachment.
3. Attach the “L” IDU Rack Mount Brackets to each side of the IDU using the long mounting screws that are contained in the GX Rack Mount Screw Pack.


The following figure illustrates mounting bracket attachment for the IDU only (occupying one space in a 19-inch rack).




Attach the “L” RFU Rack Mount Brackets to each side of the RFU using the long mounting screws that are contained in the GX Rack Mount Screw Pack. The following figure illustrates mounting bracket attachment for the combined IDU and RFU (occupying two spaces in a 19-inch rack).



4. Position the radio in the rack and align the holes in the mounting bracket with the holes in the rack. Two screws for each bracket should be used into the rack (these screws are not included).



If you are installing the IDU in a 23-inch rack, you must use the 2-inch extender brackets and attach them to the rack mounting brackets (with the screws provided in the GX Rack Mount Screw Pack), as shown in the following figure:



5. Insert two screws and lock washers, appropriate for your rack, into each of the mounting brackets and tighten.

IMPORTANT!

When the RFU is rack mounted, it must be mounted directly above the IDU and facing with the connectors forward in the same direction as the connector panel of the IDU (as shown). The IDU fan exhaust is used to cool the RFU in a rack mount configuration. Also, if one unit is projection mounted, both units should be projection mounted. In either configuration, an empty rack mount space is required above and below the configuration.

Installing the RFU Outdoors

The outdoor RFU installation consists of these tasks:


- Installing the mounting brackets and mounting plate onto the pole (using two band clamps).
- Mounting and securing the RFU on the mounting plate.

Notes:

- (1) Installing the RFU outdoors requires the use of the optional GX RF UNIT Outdoor Mounting Kit (Proxim part ACC-GX-RF-2, item number 61688), sold separately. The GX RF UNIT Outdoor Mounting Kit contains the items necessary for secure pole mounting of the RFU. See “Lynx.GX Spares and Accessories” for part numbers and ordering information. If the RFU is mounted outdoors on both ends of the link, you must order two outdoor mounting kits.
 - (2) To facilitate assembly, installing the carriage bolts to the top holes of the RFU can be partially completed on the ground before being raised to the pole assembly.
-

Installing the Mounting Plate

1. Obtain the optional GX RF UNIT Outdoor Mounting Kit (Proxim part ACC-GX-RF-2, item number 61688).
2. Hold the mounting plate with the upper and lower V-cut tabs in contact with the pole.
3. Wrap a band clamp around pole/mast and through the vertical slots near the top of the mounting plate. Repeat for lower slots.



4. Tighten both band clamps sufficiently to prevent the mounting plate from rotating on the pole/mast; you can now mount the RFU onto the bracket assembly.

Mounting the RFU

1. Orient the RFU for mounting onto the mounting plate so that the connectors are pointed down and the heatsink fins are facing away from the bracket.
2. Insert carriage bolts into the upper holes of the RFU with the head of the bolt facing the flat side (back) of the RFU.

When facing the unit, place both thumbs over the hex nuts to hold the bolt in place; place the RFU onto the mounting plate by setting the square portion of the carriage bolts into the upper, rectangular slots on the mounting plate. Loosely attach the self-locking hex nuts without tightening.

3. Insert carriage bolts into the lower holes. Loosely attach the self-locking hex nuts.
4. Tighten all hex nuts sufficiently to prevent the RFU from any movement. Ensure the heads of the carriage bolts are properly aligned with the notches in the mounting plate and placed firmly against the mounting plate prior to tightening the self-locking hex nuts.
5. Install an RF lightning arrestor that connects to the antenna cable to the RFU Type-N connector labeled To Antenna and seal the connectors using weatherproofing material (butyl and electrical tape, butyl tape or self-vulcanizing adhesive). A short jumper cable can be used to connect the RF lightning arrestor, if necessary. The lightning arrestor must be properly grounded.
6. Install the IF/DC-passing lightning arrestor that connects to the IDU cable to the RFU TNC connector labeled To IDU and seal the connectors using weatherproofing material. A short jumper cable can be used to connect the IF/DC lightning arrestor, if necessary. The lightning arrestor must be properly grounded.
7. Attach a grounding wire to the ground post of the RUF and route to a proper low impedance ground point. Wire of at least 10 AWG should be used; a braid or strap conductor is the preferred choice.

STEP 5. INSTALL AND ADJUST THE ANTENNA

The installation information discussed in this section is generic. For installation procedures specific to the antenna you are installing, refer to the antenna manufacturer's documentation.

WARNING (FCC requirement for implementation in the USA):

Any antenna used for the transmitter must be fix-mounted on outdoor permanent structures with a separation distance of at least 1.5 meters from all persons during normal operation. Antennas must be professionally installed. Installers must be provided with antenna installation instructions and transmitter operating conditions, including antenna co-location requirements of CFR47 Part 1.1307(b)(3), for satisfying RF exposure compliance.

Helpful Hints—Mounting Antennas

- Proper system and path engineering is required to determine antenna mounting location.
- Antenna height is critical for achieving path clearance, ensuring line of sight, and addressing potential path reflections.
- Ensure that the antennas will not be blocked by people during normal operation.
- Antenna structure must be secure for wind load and whatever climbing may be necessary.
- When mounting the antenna, sufficient clearance must be allocated to swing the antenna at least $\pm 20^\circ$ from the desired bearing.

Mounting the Antenna

This section describes how to permanently mount the antenna to the mast, pole, or tower, and how to attach the antenna to the RFU.

The antenna must be mounted outdoors on a tower, building roof, or other location that provides line-of-sight path clearance to the far-end location. In general, antennas smaller than two feet in diameter, or one-foot panels, are not recommended for use with these radios.

Antennas should be:

- Ordered with the suitable mounting kit specific to the site requirements.
- Very rigidly mounted, with adequate room for azimuth and elevation adjustment from the rear.

The antenna polarization must be the same at both ends of the link, either *vertical* or *horizontal*.

In general, antenna mountings require a support pipe to which upper and lower support brackets are attached with U-bolts. The antenna and optional elevation and azimuth adjustment rods then are mounted onto the support brackets. The entire structure must be adequately grounded for lightning protection (see “Grounding” on page 27). The antenna system must always be installed according to the manufacturer’s instructions.

Unless special test equipment is available, two operating radios are required to align the antennas. Alternatively, you can use a CW generator to transmit a signal toward the end being aligned.

The antenna is coarse-aligned using visual sighting and then fine-aligned using the receive signal level (RSL) voltage provided by the radio.

The RSL voltage reading still can be used to peak antennas even if the wireless units have not synchronized; however, you cannot measure far-end RSL from the near-end terminal until the units are synchronized.

Aligning the Antenna

The larger the antenna, the more critical alignment becomes. For example, with a 2-foot dish at 5.8 GHz, the antenna can be moved ± 3 degrees off the correct heading before the receive signal level drops by 3 dB. This compares with a 6-foot dish, which can be moved only ± 1 degree for the same degradation.

- You must perform antenna alignment on one end of the link at a time, one plane at a time.
- Keep one antenna stationary at all times.
- Fine-align each end several times, until the planned RSL is reached.

In some cases, you may need to perform coarse alignment using a wide arc in both azimuth and elevation while reading the RSL to find the main beam of the opposite end antenna.

Note: The RSL voltage is slightly delayed, so make small incremental adjustments during the fine alignment phase and wait a few seconds for the RSL voltage to settle after each adjustment. When aligned to maximum RSL, ensure that all antenna mechanics are tightened without impacting the alignment.

Coarse Alignment

To coarse-align the antenna, set the antenna mount for flat elevation (no up-tilt or down-tilt) using a spirit level. Point the antenna at a heading marker obtained using a compass/GPS (magnetic corrected) back-bearing from an adjacent location (ideally, 100 feet or more away from the antenna).

If the path has substantial change to elevation from one end to the other, this may not be an advisable method for starting the alignment activities. In such cases, compare antenna elevations at each end of the link and set the initial elevation of the antenna to roughly match the anticipated up-tilt or down-tilt.

If you cannot set a heading marker sufficiently far away (for example when on a city building roof), obtain a rough azimuth setting by sighting along the antenna feed or based upon compass measurements made during the path planning stage.

Note: Use the instructions provided by the antenna manufacturer to verify that both antennas are on the same polarization; otherwise, the RSL will be approximately 25 to 30 dB below the calculated level.

Because maximizing the receive RF signal level at each end of the radio link is critical, most antennas also require fine alignment using an operating link.

Once the coarse alignment is completed at both ends, the link can be powered and some level of reliable communication established. The voltage at the radio test point can be measured with a DVM to determine the relative receive RF signal level.

Note: Be sure to read “Power Connections” on page 27 prior to powering up the radios.

Fine Alignment

When fine-aligning the antenna:

- Adjust the azimuth and then the elevation of the local antenna to maximize the RSL voltage.
- Align the far-end antenna in the same manner, using the RSL voltage of its local RFU.

Helpful Hints—Antenna Alignment

- Rough align antenna azimuth and elevation based upon path planning (using compass bearing or milestone sighting, telescopic sight, binoculars, and so on).
- Apply power to both ends of the radio system
- Use a Digital Volt Meter (DVM) to read the radio’s RSL voltage provided on the RFU to peak antennas. Or, use the RSL reading from the IDU’s front panel test point. (See “RSL / GND” in “Front Panel LED Descriptions” on page 73.)
- When aligning antennas, if the RFU is located indoors or distant from the antenna location, you may want to run wires or a cable from the RSL test point on the RFU to the antenna location so that the voltmeter reading or audio device is directly visible and audible to the technicians aligning the antenna. Alternatively:
 - The RSL value can be provided by a ‘verbal relay’ or by two-way radio (or similar communications device) from the radio location to antenna alignment personnel.
 - The RFU (and IDU, if necessary) can be taken to the antenna location temporarily for the purposes of antenna alignment. An additional short transmission line jumper may be required for this approach, along with TNC-to-N adaptors at each end of the primary transmission line. If this approach is used, the actual RSL when alignment is completed is higher than that planned (due to the shorter transmission line). Verify the desired RSL once the radio system is mounted as originally planned.
 - Coaxial couplers can be placed temporarily at each end of the primary transmission line so the RSL voltage is sent to the antenna location.
- A cellular telephone or two-way radio can be useful for coordinating alignment activities between both ends of the link. You can use an orderwire telephone for end-to-end voice communications once the units are synchronized. Synchronization usually can be accomplished by coarse alignment alone. After synchronization, you can use the orderwire phones to communicate between radio sites for antenna fine alignment.
- Make sure antenna polarization is the same at both ends.
 - Adjust alignment of one antenna at a time, one plane (azimuth vs. elevation) at a time.
 - Adjust each end multiple times until predicted RSL is achieved.

Checking RSL Against Predicted Results

There are two RSL voltages that can be read off the radio.

- The IDU front panel has an RSL Test Point for a voltmeter probe.
- The RFU also has a voltage test point at the BNC connector.

Both the IDU RSL voltage and the RFU RSL voltage readings are identical: They can range from 0.9 volts for -90 dBm to 0.05 volts for -5 dBm. The RSL voltage is $-\text{Volts RSL (mV)}/10$ or -10mV per dBm , so that the readings can range from 0.9 volts for -90 dBm to 0.1 volt for -10 dBm. This unique approach for measurement voltage makes it possible to read the RSL value directly off the DVM; for example: -60 dBm = 0.6V.

Keep in mind that a higher RSL results in a lower absolute voltage. Therefore, when you are 'peaking' an antenna, you actually are attempting to achieve the lowest voltage. For example, a desired RSL of -50 dBm is equivalent to 0.5 Volts RSL and, if you were reading 0.7 Volts of RSL (a higher voltage), this would be a lower (worse) RSL of -70 dBm.

Because the maximum error-free receive signal level is -20 dBm, the receiver can produce errors above this level; however, this level will rarely, if ever, be exceeded in an actual system implementation. See "Calculating Received Signal Level and Link Budget" on page 51 to calculate the anticipated RSL. However, if cabling the system back-to-back with inadequate attenuation, permanent damage can occur. Also, extremely short paths can result in excess RSL.

During anomalous propagation conditions, the RSL can fade up but does not typically increase by more than 10 dB (except in unusual, very long paths, which may increase by 15 dB). This is not something that typically must be planned, but can cause error conditions if the normal (unfaded) RSL is close to the maximum error-free specification.

Antenna alignment should let RSL achieve the level calculated in the link budget. If the RSL is optimized but is approximately 20 dB below the calculated level, it is likely the antennas are aligned on a sidelobe of the antenna's radiated signal. In such case, you must adjust the antennas in a wide arc in both azimuth and elevation (at both sides) until the main lobe is located.

See also "Confirm Receive Signal Level (RSL) " on page 29.

STEP 6. ESTABLISH CONNECTIONS

This section discusses antenna connection, RF coaxial cable connection, IF transmission line connection, grounding, and power connections.

Helpful Hints—Lines and Connections

- Use proper transmission line.
- Proper termination is critical, especially at 5.8 GHz. Follow manufacturer's instructions and use proper tools and connectors.
- Be careful with the bend radius and never kink the transmission line.
- Secure the transmission line to structures; be careful not to crush.
- A direct connection to the antenna feed is ideal (if required, you can use a flexible jumper at the antenna).
- Weatherproof all outdoor connections when completed with installation.
- When the RF Unit is placed indoors, the RF lightning arrestor is best located at the building egress point.
- When the RF Unit is placed outdoors, the IF lightning arrestor is best located at the building egress point. In addition, Proxim recommends that an additional lightning arrestor be placed at the RF input (from the antenna) and one at the junction between IF cable interface to the RFU

NOTE: IF cable lightning arrestors must be specified to pass DC and rated to 1 GHz operation.

- IDU cable lightning arrestors must be specified to pass DC and rated to 1 GHz operation.
- All lightning arrestors and transmission line must be properly grounded.
- Do not use 90-degree adapters unless rated at operating frequency.
- Test power voltages and pinouts at the power connector before connecting power to IDU.

Connecting an Antenna

The radios are equipped with an N-type female connector on the RFU at the antenna port. You can use a short length jumper cable (such as 1/4-inch to 1/2-inch coax or pigtail of approximately 6 feet in length) fitted with two N-type male connectors to connect the RFU antenna port to the antenna (if the RFU is located near the antenna) or to the primary transmission line (if the RFU is mounted remotely from the antenna).

A low-loss 50-ohm cable is recommended for the antenna transmission line between the RFU and the antenna (such as Andrew LDF4-50 or Times LMR-600 1/2-inch coaxial cable, Andrew LDF4.5-50 or Times LMR-900 5/8-inch coaxial cable, or EW-52 wave guide).

The return loss presented by the transmission line at the RFU interface should be as high as possible (20 dB minimum recommended). The length of the antenna transmission line should be kept as short as possible to minimize losses.

To minimize feeder losses, use an elliptical wave guide (typical loss is 1.25 dB/100 ft. at 5.8 GHz) for implementations with longer transmission line lengths (such as >200 feet) or long paths (such as >20 miles). Depending upon path length and transmission line feeder length, 1/2-inch or 5/8-inch coaxial cables are often sufficient. The lower the transmission loss the better, so if your installation can accommodate the larger cable (5/8-inch), this is highly desirable.

Antenna Cabling Guidelines for 5.8 GHz Units

- Coaxial cables of $\frac{7}{8}$ -inch or larger diameter can exhibit moding at 5.8 GHz and are never recommended. Also, some small diameter cable types, such as RG-8 or LMR-400, will have high loss or poor VSWR at these frequencies. If small diameter cables are required, be certain to keep the lengths of these cables as short as possible and always properly terminate these cables.
- For wave guide transmission at 5.8 GHz, EW-52 wave guide is recommended. EW-63 will also work, but may exhibit more loss.
- Do not use right angle N-type connectors with the radios operating at 5.8 GHz.
- Do not use low quality jumper cables with the radios.
- Always precisely follow the antenna manufacturer's recommended procedures and tools for termination.

Connecting RF Coaxial Cables

Prior to installation, determine the specific antenna location and mounting. The transmission line should be kept as short as possible, so when line-of-sight placement of antennas allow flexibility, it is always desirable for the equipment to be located closer to the antenna. See "Planning for Antenna and RF Transmission Line Installation" on page 54 for further planning information.

If the RFU is mounted near the antenna, the RF transmission line can be pre-terminated at both ends and simply attached from the antenna feed to the RFU without any special consideration to securing the transmission line to the antenna structure (as the length is likely to be very short).

In this configuration, Proxim recommends you place an RF lightning suppression device specified for use at 5.8 GHz (such as Polyphaser LSX) between the RF transmission line and the RFU's RF port, as close as possible to the RFU. Always properly ground any lightning suppression device.

When the RFU is mounted near the antenna, generally follow the instructions in this section for the cable used to connect the RFU to the IDU. This cable is likely to be longer and also egresses the structure in which the IDU is located. It may require more care for installation, including grounding, lightning protection, and securing the cable.

Lightning suppression is required at the interconnection cable junction as close as possible to the RFU, as well as at the building egress point. For this cable, the lightning suppressors must be specified to pass DC and support the intermediate frequencies (approximately 800 MHz) and the digital signals carried by this cable. A NexTek PTC series Gas Tube surge protector (<http://www.nexteklightning.com>), rated at 90 Volts or greater, is an appropriate device for this application. These devices are available in various connector and mounting configurations, and provide the flexibility required for different installation configurations.

For example, a PTC-TNM-TNF-09S would be a unit with a TNC-Male connector on one end, and TNC-Female connector on the other end. A PTC-TNF-TNF-09S specifies the same part, but with TNC-Female connectors on both ends.

To prepare the RF transmission line or the RFU-to-IDU cable (**experienced or skilled technician only**):

1. Cut a cable to the proper length (allowing some excess for service loops) that will connect the RFU to the building egress point. Terminate both ends with TNC-Male connectors.
2. Repeat this process for the cable that will connect to the lightning surge protector outside the building egress point and the equipment. Do not install the equipment end connector at this time, to facilitate pulling the cable through ducts, trays, or conduit (as required) between the egress point and the IDU location.
3. Install the building egress lightning surge protector between the two RFU/IDU cable ends outside of the building egress point, and ground the lightning surge protector to a proper broadband earth ground. The proper installation and grounding of this lightning/surge protector is critical, since it is the “firewall” protecting equipment and personnel inside the building from potentially lethal electrical storm power surges.
 - Pay close attention to the transmission line specifications for bend radius when installing.
 - Be careful not to kink, damage, or deform the transmission line in any way.
 - Support the transmission line in a tray on horizontal runs and by hangers on vertical runs. Space hangers according to the manufacturer instructions.
4. Ground the transmission line using the appropriate cable/waveguide grounding kits per the cable/waveguide manufacturer’s instructions. A minimum of three grounding points is recommended—at the antenna end of the cable/waveguide, at the base of the tower, and at the equipment building egress point. In addition, long transmission line runs should be grounded at least every 100 feet.
5. Install lightning protection devices, including proper grounding and termination to cables. There should always be a lightning protection device at the egress point for whatever cables egress the building or enclosure. For an all-indoor implementation, the in-line lightning protection device must be rated for the operating frequency of the radio (5.8 GHz).

Lightning protection for the RFU-to-IDU connection portion of an outdoor implementation of the RFU must be rated to 800 MHz and must be non-blocking to DC. Proxim recommends placing lightning arrestors near the RFU and outside of the equipment building egress point for 2-piece systems. Lightning arrestors must be grounded to a proper broadband earth ground in order to be effective. This means use of a low-inductance ground strap or very short ground cable between the lightning protector and earth (not power company) ground.

6. After installation, terminate the RF transmission line with an N-type (or appropriate) male connector or low-loss adapter attached at the equipment end. For waveguide, this typically requires a CPR-to-N adapter.

Be sure to use manufacturer-specified connectors and termination tools, and follow termination instructions precisely. Improper transmission line terminations can cause excess losses and reflections that can lead to many problems with the system.

7. Prior to operation, check the electrical integrity of the transmission line, including all connectors, with a simple DC check between the center conductor and outer conductor (this is not possible for waveguide, which should be swept to assure transmission performance).

The transmission line ideally should be connected directly to the antenna at one end and to the radio antenna port at the other end; however, short pigtail jumper cables may be required in order to avoid sharp bends in the primary transmission line, or to limit stress on either connection.

Connecting IF Coax Cable

The radio can be installed with the RFU mounted indoors above the IDU in a 19-inch or 23-inch rack, or mounted outdoors onto the pole-mounted bracket (included).

- For indoor mounting, a short IF coaxial cable is included in the accessory kit to connect the IDU to the RFU.
- For indoor/outdoor mounting, a long IF coaxial cable is required to connect the IDU to the RFU outdoors. In such a case, the same cable installation, grounding, surge-protection (except using NexTek PTC series surge protectors and the appropriate cable type) as described above applies. In addition, a low-loss RF transmission line is required to run the RF signal from the RFU to the antenna (located outdoors atop a tower, monopole, rooftop pole, or cell site).

For indoor/outdoor mounting configurations, the connectors on both ends should be TNC (male) to TNC (male). Multiple cables can be used to accomplish IDU-to-egress and egress-to-RFU connections. **Be sure that a proper lightning protection device is installed at the building cable egress point.**

See “Planning For and Selecting IF Cable” on page 53 for cable recommendations.

Connecting Power

The radios do not have a power on/off switch. When you connect the DC power, the unit powers up and is operational in about one minute.

Note: When first powered up, the second LED from the left column lights up red, then the bottom one flashes red. If these conditions continue after one minute, there is a problem powering up the radio and the unit should be returned.

There can be up to 200mW of RF power present at the RFU antenna port.

Before power is applied:

- Terminate the antenna port (either by connecting the RFU to an antenna or to an appropriate 50-ohm load, such as provided by a fixed RF attenuator).
- Connect the cable between the IDU and the RFU.

The IDU can be powered separately (with no cable or RFU present), but do not connect the RFU without removing power first; then connect the IDU-to-RFU cable and re-apply power.

WARNING!


Connect all cables between the IDU and the RFU before applying power to the IDU— Do not apply DC power to the IDU if the RFU antenna connect is not terminated. Likewise, remove power from the IDU before removing any cables between the two units.

DC voltage is conducted on the IF coaxial cable; improper installation of the cable while power is applied could result in damage to the equipment. Be sure to read “Product Safety Instructions” in Chapter 2 before installing this product.

Power is connected using the terminal block connector contained in the accessory kit. The terminal connector is a 3-pin mating connector.

Use the pin information listed in following tables, along with the associated figures, to wire the terminal and connect the DC power supply properly. For DC power return connection, connect to the opposite voltage (either the -DC or the +DC Pin).

Be sure to connect the return to ground at the DC power plug and make sure that all equipment is grounded to proper station earth ground.



<i>Negative DC Power Input Pin Assignment (-20 to -63 VDC)</i>	
Pin Number	Function
1	Power (-DC)
2	Ground
3	Return (+DC)
<i>Positive DC Power Input Pin Assignment (+20 to +63 VDC)</i>	
Pin Number	Function
1	Return (-DC)
2	Ground
3	Power (+DC)

Note: Each radio terminal block must be fused externally with an 5-Amp maximum fuse. The DC power cable must be shorter than 3 meters (9.75 feet).

To wire the DC power, wire the power cable with an adequate current rating into the terminal block connector using the screw connections on the terminal block.

Suggested rating of external fuses and cables is 5 to 8 Amps (-120W to -240W) for 24V and 3 to 5 Amps (-144 W to -240 W) for 48V in order to accommodate inrush current at equipment power-up.

The radios consume less than 1.5 Amp at \pm 48V, less than 3.0 Amp at + 24V under steady-state conditions.

- If using **negative power**, connect the negative voltage to pin **1**. Connect the return connection to pin **3** and use an optional jumper to pin **2** for ground reference.
- If using **positive power**, connect the positive voltage to pin **3**. Connect the return connection to pin **1** and use an optional jumper to pin **2** for ground reference.

The ground connection is available using pin **2**. **Do not ground both sides of the power supply.**

Proxim recommends you leave the ground connection floating if the power supply also is floating. This configuration can help avoid ground loops and provide the best lightning protection; however, if the power source is referenced to ground, this configuration may not provide adequate grounding for lightning protection. This configuration is more susceptible to lightning damage no matter what grounding scheme for the radio power supply is chosen.

A grounding screw and nut is provided on the left front panel of the IDU. Be sure to use the local electrical code to determine wire size and proper connection to the grounding screw, and do not depend on rack mounting screws for a ground connection.


Note: Proper grounding, either through the chassis or the power supply, is important for protecting the unit against lightning. A grounding screw post is provided on the front panel.

Use a digital voltmeter (DVM) to verify the voltage and polarity of the plug after wiring the terminal block for power and before inserting the plug into the IDU.

Grounding

WARNING!

This equipment is intended to be grounded. If you are not using the power supply provided by Proxim Corporation, you must connect the grounding conductor of your power source to the grounding terminal located on the units; or, connect an grounding conductor between the unit's grounding terminals and your grounding point. For safe operation, always ensure that the units are grounded properly per the following figure.



Be sure to:

- Use a common station ground for all equipment
- Ground the radio to the rack
- Ground the tower or mast properly
- Ground the transmission line properly.

STEP 7. ADJUST OUTPUT POWER

In certain cases, you may need to adjust the output power lower from the factory setting; for example, to:

- Meet any required EIRP (Effective Isotropic Radiated Power) limits
- Avoid exceeding the maximum far-end RSL of -20 dBm
- Meet in-bound RSL requirements for a hub site location

Note: In certain countries, Effective Isotropic Radiated Power (EIRP) limits dictate the maximum output power the radio can transmit, given transmission line loss and antenna gain. Consult with appropriate government agencies or Proxim Corporation if there is any question regarding maximum output power allowed.

Using the Web browser interface through the NMS1 or NMS2 port, you can adjust the output power from factory settings. Select the **Sys Cfg** tab and choose from +5 to +25 dBm, in 1 dB steps, in the **Tx Power (dBm)** field.

Note: For precise measurement of transmitter power, a calibrated RF power meter is recommended. This power sensor can be connected directly to the output of the radio without exceeding the power rating. With some power meters, it may be necessary to place a calibrated in-line fixed attenuator between the radio antenna port and the power meter so as to not exceed the power meter's maximum input level. Thru-line power meters do not operate at Proxim radio RF frequencies and are not recommended.

If adjusting the output power to meet an EIRP limit, you must calculate the overall RF system gains and losses, including feeder losses for the type of transmission line installed and the antenna gain.

Note: For the US and Canada, there is no EIRP limit for fixed point-to-point applications of this product.

You can determine the radio transmit power for EIRP-limited installations using the following equation:

$$\text{Tx Power (dBm)} = \text{EIRP Limit (dBm)} + \text{Transmission System Losses (dB)} - \text{Antenna Gain (dB)}$$

STEP 8. ESTABLISH A LINK BETWEEN THE RADIOS

Follow these steps to establish a link between the radios:

1) Connect the transmission line to the antenna and feed it to the RFU location.

Connect the opposite end of the transmission line to the N-type female connector located on the RFU through a lightning arrestor. If the RFU is mounted indoors or in a shelter, the lightning protection should be located at the cable egress point. If the RFU is mounted outdoors, it can be mounted at the RF input port of the RFU. The lightning arrestor must be properly grounded. The transmission line connection must be terminated into an antenna or a load before DC power is applied to the radio.

2) Connect the RFU to the IDU.

Connect the cable that runs from the RFU to the IDU. If the RFU is mounted outdoors, ensure that proper lightning protection is used at the shelter or building egress point as well as at the RFU connector. The lightning arrestor must be properly grounded. If the RFU is mounted indoors, use the supplied TNC jumper cable. No grounding or lightning arrestor is needed.

3) Confirm DC power connection.

With the DC power source active but not plugged into the radio, confirm with a voltmeter that the DC mating connector has the proper power connections as discussed in “Power Connections” on page 27.

- Verify the polarity and the absolute voltage on all pins.
- Verify ground connection for power (if applicable).
- Ensure that the RF Antenna port connection is properly terminated before applying power.
- Ensure that the IDU-to-RFU cable is connected.

4) Connect power to the radio.

When the radio is initially powered-on, some alarm conditions may be present. This is normal and alarms can be ignored at this time.

5) Ensure that the antennas at both ends are aligned.

Perform a general alignment of the antennas on both ends of the path using binoculars, compass, or other related tools. You must have the antennas aligned as accurately as possible before putting radio traffic over the link. This helps in getting the system running more rapidly. Assure that both antennas are set for the same polarization (vertical or horizontal at both ends).

6) Adjust RF power (if necessary).

Using the NMS port, verify the RF output power setting and, if necessary, adjust the output power of the local transmitter in accordance with the path analysis calculations.

In cases of no EIRP limits, the radio transmitter output power should be left at the factory setting, except for very short paths using very high gain antennas, where excessive power may not be advised (in which case power should be reduced), or in cases where lower RSL is desired into a hub site (multi-link) location.

Be sure the RF output port is terminated at all times when power is applied to the radio. Therefore, disconnect power to the unit before connecting a power meter; reapply power once connected.

Often, an RF power meter has a limit to the input power it can measure without damage. Proxim advises you place a calibrated fixed value RF attenuator (typically 20 dB or more) between the radio and the power meter to ensure proper operation and safety for the RF power meter. The value of this fixed attenuation then can be added to the value of the RF power meter reading to obtain the actual transmitter output power.

Other typical causes of inadequate RSL are:

- Path obstructions
- Excess loss in connectors/cables (poor terminations, improper bend radius, kinked, crushed, ...)
- Poor quality or unaccounted for adapters and pigtail jumper cables
- Different antenna polarization at each end of the link
- Improper configuration of the radio's transmit power output adjustment
- Insufficient RF output power (faulty radio transmitter)
- Faulty antenna

7) Confirm Received Signal Level (RSL).

Connect a voltmeter to the RSL measurement port on the RF Unit. This voltage reading corresponds to the Received Signal Level (RSL) of the near-end radio. RSL is the amount of signal the near-end radio is receiving from the far-end radio. Because the antennas have not been finely aligned, the RSL value at this time will not be the desired value. However, you can verify that some communication is taking place between the two units.

Use the RSL voltage reading to align the antennas. Align one antenna at a time as discussed in "Alignment Guidelines" on page 19. Align both ends of the link before proceeding.

The RSL voltage output on the radio's front panel supplies a voltage over the usable range of the radio. (You can also use the RSL port on the RFU, which has both DC and Tone available.)

The RSL of both sides of the link can also be measured using the NMS port. See "Management with the Web Interface" on page 33 for details about connecting to the NMS port and viewing performance parameters.

If the RSL is not at the expected level, re-check the path clearance and transmission line, as these are the typical causes of insufficient RSL.

You can verify radio operations by connecting units back-to-back with attenuators (60-80 dB), as described in "Step 3. Test Radios Back-to-Back" on page 11. If the problem persists, see "6.0 Troubleshooting" on page 93.

The transmitter output power adjustment on the radio affects the RSL. Depending upon EIRP limits (if any), path distance, and antenna gain, you may need to adjust the output transmit power to the proper level before putting the units in service.

Helpful Hints—Checking RSL Against Predicted Results

- Is the RF Link LED red?
 - If so, keep aligning the antennas.
 - If not (or green), the radios are talking!
- Does the measured RSL at both ends closely match the predicted value?
 - If too strong, this is probably OK; the transmitter power may be higher than originally planned.
 - If not strong enough, keep aligning.
 - If still not strong enough, double-check the prediction and compare to the actual installation (verify antenna gains, lengths/type of transmission line, path length, and so on).
 - Are you sure you have line of sight?
 - Did you test the radios in advance?
 - You could have a bad cable, connector termination, or antenna
- Do you need to adjust the output power down?
 - Check path calculations and regulations.
 - Re-verify RSL after power is adjusted.

Several factors can contribute to low RSL:

- Incorrect antenna alignment (aligned on a side lobe and not on the main signal)
- Improper polarization orientation of antennas (horizontal versus vertical)
- Transmission line problems (loose connections, kinked or damaged cables, “loss-y” adapters, improper termination)
- Path obstructions (trees, buildings, hills, and so on)
- Improper path clearance (line-of-sight, earth curvature, Fresnel zone, diffraction, and partial obstruction)
- Weather (inversion layers, ducting, and multipath)
- Antenna feed (coaxial/connector) problem
- Highly reflective surfaces of the path terrain

8) Verify the channel plans.

Verify that the units follow the same channel plan, and that the opposite Tx and Rx frequencies complete a matched pair of radios (for example, A1 and A2 make up a matched pair). The RFU pair is made up of a “Hi” and “Low” pair of the same root model number. Also, if co-locating equipment for multiple paths, make sure that you do not deploy the same transmitter frequency as any of the receive frequencies at the same site.

9) Connect unit to telecommunications equipment to pass the T1/E1 traffic.

Connect to the T1 circuits using properly shielded 8-pin modular (RJ-48C) connectors. Connect to the E1 circuits using properly shielded 8-pin modular (RJ-45) connectors.

All front panel LEDs should either be off or green. (You may need to set Data Input parameters on the HTTP **IntfCfg** page to make the Data Input LED green.) If any LEDs are red, see “Front Panel LED Definition” on page 73 or “Troubleshooting Alarms” on page 95 for more information.

STEP 9. ESTABLISH NEAR-END TO FAR-END COMMUNICATIONS USING ORDERWIRE (OPTIONAL)

To establish near-end to far-end communications using orderwire:

1. Connect telephones to the near-end and far-end radios.

Using a standard RJ-11 telephone cable, connect a standard electronic telephone (a touch tone phone, complete with dialer, or DTMF phones) to the Orderwire connector on the radio front panel. This connector is wired identically to a standard two-wire telephone jack. For connector pin assignment, see “Connectors and Pin Assignments” on page 46.

Note: If you are using a standard telephone (for orderwire function) not provided by Proxim with this product, ensure that the telephone has a ringing equivalency specification of 1.0 B or less and is a UL-Listed (ITE) device that has been evaluated to the Standard for the Safety of Information Technology Equipment, including Electrical Business Equipment, CAN/CSA C22.2, No. 950-85 * UL 1950, Third Edition.

2. Call the far-end radio.

With a telephone connected to each radio on opposite ends of the link, either telephone can be used to dial-up the far-end location. The far-end radio internal ringer and the connected telephone ring, and if answered, two-way full-duplex voice communication is established.

If the radios are connected in a repeater configuration, you can establish orderwire services in the network by connecting the radios (by cabling their front-panel VF connectors). The orderwire operates on radios at each end of the repeater and at the repeater site. You can extend this function through several repeater sites. For hub connections of three or more radios, an external 4-wire VF bridge (600 is required to connect all devices for orderwire operations.

Dialing an * (asterisk/star key) on the orderwire telephone implements an “all call” feature that rings all connected radios. All telephones provide communication to all other telephones in the connected network. Even if a particular telephone does not ring, it can still be used to talk and listen to any ongoing orderwire activity if the orderwire is in use at other terminal locations.

Also, if a phone anywhere in the connected network has accidentally been left off-hook, the # [pound] key can be used to mute all off-hook phones until they are placed on and off hook again.

Chapter 3. Managing the Lynx.GX

You can configure and manage the radios using any of the following methods:

Web Interface

Using a Netscape® or Windows® Internet Explorer browser, you can configure and manage the unit using a Web-based management interface. This management method includes all configuration parameters and monitoring information. The Web browser interface is the most versatile tool to use for the most complete set of information and access to configuration of the radio equipment. Of any of the tools to be used for configuration and troubleshooting, this tool is highly recommended. For more information, see “Management with the Web Interface” on page 33.

SNMP

Using an SNMP management program (such as HP OpenView or Castle Rock SNMPc), you can use MIB information to receive alarm traps, set configuration parameters, and get alarm and status information about the unit. This method provides the majority of configuration and monitoring tools available on the radio, and is a preferred method among those users already familiar with an installed SNMP Manager, or those who have a proprietary network element manager that uses SNMP protocol for communication. The MIB is available from Proxim Technical Services or the Proxim Internet site (<http://www.proxim.com/support>). For more information see “Management with SNMP” on page 44.

Telnet Command Line Interface (CLI) through IP

If a terminal is not available or you are a distance from the radio, you can use Telnet. See “Management with Telnet” on page 44.

Each radio’s IP address is used to identify it for the Web browser interface, SNMP interface, or Telnet session. For any extensive management, use the Web browser interface or the SNMP interface. The CLI is limited to initially configure the IP address, mask, gateway, and password.

Each radio communicates to its far end mate using a low-speed link, thereby creating a proprietary management channel for managing, configuring, and monitoring any link of radios. This communications channel is not accessible for use by end users; it is designated for use by the radios exclusively.

Radios are identified by IP addresses that are assigned by the end user. Default IP addresses are assigned at the factory for the radios.

This link also implements a RIPv2 router to more efficiently manage remote radios that may be connected in a ring or mesh topology. The router is enabled as long as opposite radios in a link are in different IP subnets.

See “Setting Up Static Route for Remote Access to Far End Radio” on page 36 for more details.

MANAGING WITH THE WEB INTERFACE

Minimum Computer Requirements for NMS

The client PC should satisfy the following minimum requirements:

- CPU Processor speed greater than 1 GHz
- Web Browser: Internet Explorer, version later than 5.0; Netscape 7.0 and later
- 10/100 Ethernet Interface
- Windows® Operating System: Windows® 98 or later (including XP Home and Professional)

Accessing the Radio

Use Windows Internet Explorer® or Netscape® to access the radio by entering its IP address in the browser address bar. The radios are configured at the factory with the default IP address of 10.0.0.1. Once you have successfully logged in to the radio, you can change the IP address from the **Admin** tab of the Web interface.

You can configure your computer to this subnet by setting its address to 10.0.0.x (where x is from 2 to 254 and not already used in the network) or use the command line interface through Telnet to change the IP addresses of the radios.

Note: The PC connected to the near-end radio's NMS port must be on the same subnet as the near-end radio to communicate with each other.

Change both the near-end and the far-end radio to the desired IP addresses. You may need to change the subnet of your PC many times to accomplish this as you change from the default IP address to your desired address scheme. Always save the new IP address configurations of the radios.

After changing the IP addresses, you must reconfigure the IP address of your computer to again match the subnet of the radio (following your Operating System guidelines for changing IP addresses).

Providing a Contiguous Management Link

The second NMS port (NMS2) is switched with NMS1 on the front panel of the radio; it is used to daisy-chain a CAT5 cable between co-located radios to provide a contiguous management link between radios at a hub location.

Because the 10/100 Base-T ports are auto-MDI/MDI+X, the link can be established with either a straight CAT5 cable or a cross-over cable.

Factory Default Values:

Default IP Address (set at the factory).....	10.0.0.1
Default Subnet Mask	255.0.0.0
Default Gateway	0.0.0.0




Figure 4. Daisy Chaining NMS Connections at a Hub Location

The next few pages describe how to access the Web Interface and the configuration and management available.

Initial Log-On

To access the Web Interface:

1. At your browser address field enter <http://10.0.0.1> (or your previously set IP address) to open the **Logon** window.



- Enter the following administrative logon username and default password (or your previously set password) in the corresponding fields on the logon page:

Username: **managers**

Password: **managers**

The monitoring logon username and default password are:

Username: **operator**

Password: **operator**


The radios ship from the factory with the default user name and password, as shown above. You should change the password to another value and practice proper security management for limiting access to the

Configuration and **Control** menu tabs through the browser.

Note: If you forget the IP addresses or password, you can reset the radio to factory settings by powering the radio up while depressing the FAR END button for 10 seconds. The default IP address, subnet mask, passwords, and other default settings are installed in the radio.

Web Interface Front Panel LEDs

The radio's front panel LEDs are displayed at the top of each window in the Web interface; they provide the same color and flashing alarm and status information as the actual LEDs on the front panel.



You can choose to view LED information for the near-end radio (the unit to which you are connected) or the far-end radio. The default option when you open a tab or refresh a page is to display the near-end LEDs. If the far-end radio is not available when you choose to view far-end LEDs, these LEDs flash red. See “Front Panel LED Descriptions” on page 73 for more information.

In addition, the large green bar at the very top of the display represents the summary LED (on the back of the IDU) that indicates the health of the radio by summarizing all the eight LEDs on the front panel:

- If all the LEDs are green or off, the bar is green
- If any LED is red, the bar turns red
- If any LED is yellow and none are red, the bar turns yellow

The bar also indicates the state of the Form C relays: Red indicates that the Major or “Out of Service” relay is energized; Yellow indicates that the Minor or “Summary” relay is energized. (A yellow AIS OUT LED will make the summary bar yellow, but will not energize the Minor Relay.) This feature also allows the user to view the summary status of multiple radios concurrently on a single computer display.

The rear panel LED is a single indicator that reflects the summary state of the radio, exactly copying the state of the status bar on the GUI.

Initial Configuration

The default settings of all Lynx.GX radios are:

IP Address: 10.0.0.1
 Subnet Mask: 255.0.0.0
 Gateway Address: 0.0.0.0

The next three steps should be accomplished while both radios are on a test bench. Additional details follow.

Step 1: Change the PCs IP address to the same subnet as 10.0.0.x. This allows you to address the local radio.


Step 2: Using the CLI, change the IP address, subnet mask, and default gateway of the two radios.

Step 3: Using the Web browser, review and configure any additional settings (such as changing T1/E1 parameters) as necessary.

In-Band Management

If it is desired to have in-band management, each side of a radio link must be in a different IP subnet. Using in-band management lets you enable two browsers to be viewed on a PC at the same time.

The following is an example of two browsers enabled for two different radios.



The browser for each radio is opened using the IP address of that radio.


Setting Up Static Route for Remote Access to Far End Radio

To access the far radio from a near-side computer, set that computer's default gateway to 10.0.0.1, or configure a permanent static route on your computer to access the 10.10.0.0 network through 10.0.0.1. This is more useful if you are using the Internet and do not want to change the default gateway of your computer. Having the two ends of a hop on different subnets lets the end user enable two browsers to be presented on a PC screen at the same time. The browser for the near-end radio is opened using the IP address of the near-end radio. A second browser is opened using the IP address of the far-end radio. It finds the far-end radio using the near-end radio as a gateway.

Using the MS-DOS Prompt under Windows, enter the command

```
route add 10.10.0.0 mask 255.255.0.0 10.0.0.1.
```

This example uses the default addresses of 10.0.0.1 for the near end radio, and 10.10.0.x for the far end radio. This is a temporary static route. To make it permanent, add this as a batch file to run at system startup. The GX radios use RIP to learn routes automatically in your network. Remember, this extended NMS network is available only while the wireless link is up.



```

cost for this destination

All symbolic names used for destination are looked up in the network database
file NETWORKS. The symbolic names for gateway are looked up in the host name
database file HOSTS.

If the command is PRINT or DELETE, wildcards may be used for the destination
and gateway, or the gateway argument may be omitted.
Diagnostic Notes:
  Invalid MASK generates an error, that is when (DEST & MASK) != DEST.
  Example> route ADD 157.0.0.0 MASK 155.0.0.0 157.55.80.1
           The route addition failed: 87

Examples:
> route PRINT
> route ADD 157.0.0.0 MASK 255.0.0.0 157.55.80.1 METRIC 3
           ^destination      ^mask          ^gateway      ^metric
> route PRINT
> route DELETE 157.0.0.0
> route PRINT

C:\WINDOWS\Profiles\rma\Desktop>route add 10.0.0.0 mask 255.255.0.0 10.10.0.4
C:\WINDOWS\Profiles\rma\Desktop>

```

Note: If both radios are set to the same IP subnet, no NMS data passes across the wireless link and management of both units at the same time requires another network path. In this setup, the end user has the near-end and the far-end status through the near-end browser, but cannot change configuration of the far-end radio from the near-end radio. This is not a recommended means to manage the radios.

Helpful Configuration Hints

- You must set Tx Power to meet required EIRP limits or RSL requirements.
- You must set IP Address and Subnet Mask to conform to your network. You also must set the Default Gateway Address if your monitoring stations will be on a different IP subnet from the GX radio.
- If you have a T1 radio, you must set the appropriate Line Code and Line Buildout setting.
- To aid in troubleshooting possible problems, Proxim recommends you set System Date and Time to provide correct timestamps for Log Messages.
- For greater security, Proxim recommends changing the Configuration Password. Also, use a unique Link Security Code for each link of radios.
- To avoid alarms on unused channels, Proxim recommends disabling the Input Alarm on all unused channels.

Basic Tasks with the Web Interface

The following sections introduce you to the Web Interface and the tasks that can be accomplished with each window. For more in-depth information about the Web Interface windows, see “Web Interface Windows and Field Descriptions” on page 56.

Task Quick Reference

To view or monitor:	Click this tab:	To view or monitor:	Click this tab:
All or selected status alarms	LOG	Radio sync alarm	ALARMS
Application software version	DEVICE	RF receive frequency	DEVICE
BER (current)	STATUS	RF software version	DEVICE
Bit error alarm	ALARMS	RF transmit frequency	DEVICE
Boot software version	DEVICE	RFU serial number	DEVICE
Data rate	DEVICE	RSL reading of radio over time	STATUS/RSL button
Elapsed time since reset	STATUS	RSL (current)	STATUS
Errored seconds	STATUS	RSL (max)	STATUS
External Input Alarm	ALARMS	RSL (min)	STATUS
Fan summary alarm	ALARMS	RSL (min) timestamp	STATUS
IDU serial number	DEVICE	Severely errored seconds	STATUS
IDU temperature	STATUS	Spectrum Analyzer	ADMIN
Interface type	DEVICE	Status alarms, all or selected	LOG
Major relay alarm	ALARMS	T-1/E-1 AIS	ALARMS
Minor relay alarm	ALARMS	T-1/E-1 Input	ALARMS
Model number	DEVICE		

To configure:	Click this tab:	To configure:	Click this tab:
Alarm external inputs	SYS CFG	IP address	ADMIN
Auxiliary port speed	SYS CFG	Link Security code	SYS CFG
Date and time, system	ADMIN	Orderwire address	SYS CFG
Default gateway address	ADMIN	System passwords	ADMIN
SNMP Community Strings	ADMIN	T1/E1 settings	INTF CFG
Tx Power	SYS CFG		

Viewing Radio Information

<p>Use this tab:</p>	<p>To do this:</p>	<p>Window</p>																																																																																								
<p>Device Tab on page 56</p>	<p>Access radio information, such as model and serial numbers, data rate and frequency, interface type, and software version levels. The fields in this window are not configurable.</p>	<table border="1"> <thead> <tr> <th>Device</th> <th>Intf Cfg</th> <th>Sys Cfg</th> <th>Status</th> <th>Alarms</th> <th>Log</th> <th>Contact</th> <th>Admin</th> </tr> </thead> <tbody> <tr> <td colspan="2">Model Number</td> <td colspan="6">51145-10H0</td> </tr> <tr> <td colspan="2">IDU Serial Number</td> <td colspan="6">ISIS030700007</td> </tr> <tr> <td colspan="2">RF Unit Serial Number</td> <td colspan="6">DQV1234567893</td> </tr> <tr> <td colspan="2">Data Rate</td> <td colspan="6">13.5 Mbps</td> </tr> <tr> <td colspan="2">Interface Type</td> <td colspan="6">8 T1</td> </tr> <tr> <td colspan="2">Boot Software Version</td> <td colspan="6">1.4</td> </tr> <tr> <td colspan="2">Application Software Version</td> <td colspan="6">1.4</td> </tr> <tr> <td colspan="2">RF Software Version</td> <td colspan="6">2.1</td> </tr> <tr> <td colspan="2">RF TX Freq (GHz)</td> <td colspan="6">5.8190 GHz</td> </tr> <tr> <td colspan="2">RF RX Freq (GHz)</td> <td colspan="6">5.7340 GHz</td> </tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	Model Number		51145-10H0						IDU Serial Number		ISIS030700007						RF Unit Serial Number		DQV1234567893						Data Rate		13.5 Mbps						Interface Type		8 T1						Boot Software Version		1.4						Application Software Version		1.4						RF Software Version		2.1						RF TX Freq (GHz)		5.8190 GHz						RF RX Freq (GHz)		5.7340 GHz					
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																																																			
Model Number		51145-10H0																																																																																								
IDU Serial Number		ISIS030700007																																																																																								
RF Unit Serial Number		DQV1234567893																																																																																								
Data Rate		13.5 Mbps																																																																																								
Interface Type		8 T1																																																																																								
Boot Software Version		1.4																																																																																								
Application Software Version		1.4																																																																																								
RF Software Version		2.1																																																																																								
RF TX Freq (GHz)		5.8190 GHz																																																																																								
RF RX Freq (GHz)		5.7340 GHz																																																																																								

Modifying T1 / E1 Channel Interface Configurations

<p>Intf Cfg Tab on page 57</p>	<p>Modify the T1 or E1 channel interface configurations, including line build-out, line code, and loopback configuration.</p>	<table border="1"> <thead> <tr> <th>Device</th> <th>Intf Cfg</th> <th>Sys Cfg</th> <th>Status</th> <th>Alarms</th> <th>Log</th> <th>Contact</th> <th>Admin</th> </tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: center;"> Note: Only users with managers privilege can change the settings. </td> </tr> <tr> <td colspan="8" style="text-align: right;"> HELP </td> </tr> <tr> <th>8 T1 Channel</th> <th>Input Alarm Enable</th> <th>AIS Enable</th> <th>Line Buildout</th> <th>Line Code</th> <th>Loopback Config</th> <th colspan="2">Far-End Loopback Config</th> </tr> <tr> <td>1</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>2</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>3</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>4</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>5</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>6</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>7</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td>8</td> <td><input checked="" type="checkbox"/></td> <td><input checked="" type="checkbox"/></td> <td>0 -133 ft.</td> <td>B8ZS</td> <td>No Loopback</td> <td colspan="2">No Loopback</td> </tr> <tr> <td colspan="7" style="text-align: left;"> Get Default </td> <td style="text-align: right;"> Apply </td> </tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	Note: Only users with managers privilege can change the settings.								HELP								8 T1 Channel	Input Alarm Enable	AIS Enable	Line Buildout	Line Code	Loopback Config	Far-End Loopback Config		1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback		Get Default							Apply
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																																																																			
Note: Only users with managers privilege can change the settings.																																																																																																										
HELP																																																																																																										
8 T1 Channel	Input Alarm Enable	AIS Enable	Line Buildout	Line Code	Loopback Config	Far-End Loopback Config																																																																																																				
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 -133 ft.	B8ZS	No Loopback	No Loopback																																																																																																				
Get Default							Apply																																																																																																			

Viewing the Current Near and Far Status

<p>Status Tab on page 59</p>	<p>View the current Near and Far status for the selected unit, including BER, errored seconds, RSL, elapsed time since reset, and temperature. You also can track the RSL reading of the radio over time by clicking the RSL Log button on the Status window.</p> <p>The fields on this window are not configurable.</p> <p>See “RSL Log” on page 60 for more information.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Device</th> <th style="text-align: left;">Intf Cfg</th> <th style="text-align: left;">Sys Cfg</th> <th style="text-align: left;">Status</th> <th style="text-align: left;">Alarms</th> <th style="text-align: left;">Log</th> <th style="text-align: left;">Contact</th> <th style="text-align: left;">Admin</th> </tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: right;">HELP</td> </tr> <tr> <td colspan="3">Updated: 14:48:50</td> <td style="text-align: center;">Near</td> <td style="text-align: center;">Far</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Current BER</td> <td style="text-align: center;">0.000000e+00</td> <td style="text-align: center;">0.000000e+00</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Current RSL (-dBm)</td> <td style="text-align: center;">-72</td> <td style="text-align: center;">-65</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Errored Seconds</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Severely Errored Seconds</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Min RSL (-dBm)</td> <td style="text-align: center;">-72</td> <td style="text-align: center;">-65</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Min RSL Time Stamp</td> <td style="text-align: center;">08/11/2003 14:32</td> <td style="text-align: center;">08/11/2003 14:32</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Max RSL (-dBm)</td> <td style="text-align: center;">-71</td> <td style="text-align: center;">-64</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">Elapsed Time Since Reset</td> <td style="text-align: center;">00:16:48</td> <td style="text-align: center;">00:16:50</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">IDU Temperature (Celcius)</td> <td style="text-align: center;">26</td> <td style="text-align: center;">31</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">RF Unit Temperature (Celcius)</td> <td style="text-align: center;">43</td> <td style="text-align: center;">46</td> <td colspan="3"></td> </tr> <tr> <td colspan="3" style="text-align: center;">RSL Log</td> <td colspan="2" style="text-align: center;">Reset History</td> <td colspan="3" style="text-align: center;">Reset History</td> </tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	HELP								Updated: 14:48:50			Near	Far				Current BER			0.000000e+00	0.000000e+00				Current RSL (-dBm)			-72	-65				Errored Seconds			0	0				Severely Errored Seconds			0	0				Min RSL (-dBm)			-72	-65				Min RSL Time Stamp			08/11/2003 14:32	08/11/2003 14:32				Max RSL (-dBm)			-71	-64				Elapsed Time Since Reset			00:16:48	00:16:50				IDU Temperature (Celcius)			26	31				RF Unit Temperature (Celcius)			43	46				RSL Log			Reset History		Reset History		
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																																																																											
HELP																																																																																																																		
Updated: 14:48:50			Near	Far																																																																																																														
Current BER			0.000000e+00	0.000000e+00																																																																																																														
Current RSL (-dBm)			-72	-65																																																																																																														
Errored Seconds			0	0																																																																																																														
Severely Errored Seconds			0	0																																																																																																														
Min RSL (-dBm)			-72	-65																																																																																																														
Min RSL Time Stamp			08/11/2003 14:32	08/11/2003 14:32																																																																																																														
Max RSL (-dBm)			-71	-64																																																																																																														
Elapsed Time Since Reset			00:16:48	00:16:50																																																																																																														
IDU Temperature (Celcius)			26	31																																																																																																														
RF Unit Temperature (Celcius)			43	46																																																																																																														
RSL Log			Reset History		Reset History																																																																																																													

Configuring System Parameters

<p>Sys Cfg Tab on page 58</p>	<p>Configure Tx power, orderwire address, security link ID, aux port speed, RF frequency settings, and External Alarms</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Device</th> <th style="text-align: left;">Intf Cfg</th> <th style="text-align: left;">Sys Cfg</th> <th style="text-align: left;">Status</th> <th style="text-align: left;">Alarms</th> <th style="text-align: left;">Log</th> <th style="text-align: left;">Contact</th> <th style="text-align: left;">Admin</th> </tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: center;">Note: Only users with managers privilege can change the settings.</td> </tr> <tr> <td colspan="8" style="text-align: right;">HELP</td> </tr> <tr> <td colspan="3">Tx Power (dBm)</td> <td style="text-align: center;">20</td> <td style="text-align: center;"><input type="text" value="20"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">Orderwire Address</td> <td style="text-align: center;">00</td> <td style="text-align: center;"><input type="text" value="00"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">Link Security Code</td> <td style="text-align: center;">000000000000</td> <td style="text-align: center;"><input type="text" value="000000000000"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">Aux Port Speed (bps)</td> <td style="text-align: center;">19200</td> <td style="text-align: center;"><input type="text" value="19200"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">RF Frequency (TX/RX in GHz)</td> <td style="text-align: center;">5.8190 / 5.7340</td> <td style="text-align: center;"><input type="text" value="5.8190 / 5.7340"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">Alarm when External Input 1</td> <td style="text-align: center;">close</td> <td style="text-align: center;"><input type="text" value="close"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> <tr> <td colspan="3">Alarm when External Input 2</td> <td style="text-align: center;">close</td> <td style="text-align: center;"><input type="text" value="close"/></td> <td colspan="3" style="text-align: right;">Set</td> </tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	Note: Only users with managers privilege can change the settings.								HELP								Tx Power (dBm)			20	<input type="text" value="20"/>	Set			Orderwire Address			00	<input type="text" value="00"/>	Set			Link Security Code			000000000000	<input type="text" value="000000000000"/>	Set			Aux Port Speed (bps)			19200	<input type="text" value="19200"/>	Set			RF Frequency (TX/RX in GHz)			5.8190 / 5.7340	<input type="text" value="5.8190 / 5.7340"/>	Set			Alarm when External Input 1			close	<input type="text" value="close"/>	Set			Alarm when External Input 2			close	<input type="text" value="close"/>	Set		
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																																											
Note: Only users with managers privilege can change the settings.																																																																																		
HELP																																																																																		
Tx Power (dBm)			20	<input type="text" value="20"/>	Set																																																																													
Orderwire Address			00	<input type="text" value="00"/>	Set																																																																													
Link Security Code			000000000000	<input type="text" value="000000000000"/>	Set																																																																													
Aux Port Speed (bps)			19200	<input type="text" value="19200"/>	Set																																																																													
RF Frequency (TX/RX in GHz)			5.8190 / 5.7340	<input type="text" value="5.8190 / 5.7340"/>	Set																																																																													
Alarm when External Input 1			close	<input type="text" value="close"/>	Set																																																																													
Alarm when External Input 2			close	<input type="text" value="close"/>	Set																																																																													

Changing Passwords, System Date and Time, SNMP Community Strings, and IP Address

<p>Admin Tab on page 64</p>	<p>Change the system passwords, system date and time, SNMP community strings, and radio IP address information.</p> <p>You can also enable the built-in Spectrum Analyzer to check for transmission sources that the radio can receive and to determine whether these emitters could be a source of possible interference (click the Spectrum Analyzer button on the Admin window).</p>	
------------------------------------	--	--

Monitoring Link Alarms

<p>Alarms Tab on page 61</p>	<p>Monitor link status — both near-end and far-end link alarm status. The orientation of the alarms matches the position of the connectors on the front panel.</p>	
-------------------------------------	---	--

Viewing All or Selected Status and Alarms

<p>Log Tab on page 62</p>	<p>View all or selected status and alarms for the radio. You can view alarms of all levels or selected levels and greater.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Device</th> <th>Intf Cfg</th> <th>Sys Cfg</th> <th>Status</th> <th>Alarms</th> <th>Log</th> <th>Contact</th> <th>Admin</th> </tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: center;">Choose view level: <input type="radio"/> All <input type="radio"/> Warning <input type="radio"/> Minor <input type="radio"/> Major <input type="radio"/> Critical</td> </tr> <tr> <th>Date/Time</th> <th>Severity</th> <th>Description</th> <th>Status</th> <td colspan="4"></td> </tr> <tr><td>AUG/11/2003 14:24:58</td><td>Major</td><td>BER 10-3 Error</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:58</td><td>Major</td><td>Major relay alarm</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:55</td><td>Minor</td><td>FarEnd Alarm</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:55</td><td>Major</td><td>BER 10-3 Error</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:55</td><td>Major</td><td>Major relay alarm</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:53</td><td>Minor</td><td>Far End Link Down</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:51</td><td>Minor</td><td>Far End Link Down</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:51</td><td>Minor</td><td>FarEnd Alarm</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:24:45</td><td>Normal</td><td>System Reset</td><td></td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:21:58</td><td>Minor</td><td>FarEnd Alarm</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:21:53</td><td>Minor</td><td>Far End Link Down</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:21:53</td><td>Major</td><td>BER 10-3 Error</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:21:53</td><td>Major</td><td>Major relay alarm</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:21:49</td><td>Critical</td><td>Radio Sync</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:48</td><td>Major</td><td>BER 10-3 Error</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:44</td><td>Minor</td><td>RF Unit Comm Error</td><td>Normal</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:43</td><td>Minor</td><td>Far End Link Down</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:43</td><td>Minor</td><td>FarEnd Alarm</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:43</td><td>Minor</td><td>RF Unit Comm Error</td><td>Alarm</td><td colspan="4"></td></tr> <tr><td>AUG/11/2003 14:19:43</td><td>Critical</td><td>Radio Sync</td><td>Alarm</td><td colspan="4"></td></tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	Choose view level: <input type="radio"/> All <input type="radio"/> Warning <input type="radio"/> Minor <input type="radio"/> Major <input type="radio"/> Critical								Date/Time	Severity	Description	Status					AUG/11/2003 14:24:58	Major	BER 10-3 Error	Normal					AUG/11/2003 14:24:58	Major	Major relay alarm	Normal					AUG/11/2003 14:24:55	Minor	FarEnd Alarm	Normal					AUG/11/2003 14:24:55	Major	BER 10-3 Error	Alarm					AUG/11/2003 14:24:55	Major	Major relay alarm	Alarm					AUG/11/2003 14:24:53	Minor	Far End Link Down	Normal					AUG/11/2003 14:24:51	Minor	Far End Link Down	Alarm					AUG/11/2003 14:24:51	Minor	FarEnd Alarm	Alarm					AUG/11/2003 14:24:45	Normal	System Reset						AUG/11/2003 14:21:58	Minor	FarEnd Alarm	Normal					AUG/11/2003 14:21:53	Minor	Far End Link Down	Normal					AUG/11/2003 14:21:53	Major	BER 10-3 Error	Normal					AUG/11/2003 14:21:53	Major	Major relay alarm	Normal					AUG/11/2003 14:21:49	Critical	Radio Sync	Normal					AUG/11/2003 14:19:48	Major	BER 10-3 Error	Alarm					AUG/11/2003 14:19:44	Minor	RF Unit Comm Error	Normal					AUG/11/2003 14:19:43	Minor	Far End Link Down	Alarm					AUG/11/2003 14:19:43	Minor	FarEnd Alarm	Alarm					AUG/11/2003 14:19:43	Minor	RF Unit Comm Error	Alarm					AUG/11/2003 14:19:43	Critical	Radio Sync	Alarm				
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																																																																																																																																																			
Choose view level: <input type="radio"/> All <input type="radio"/> Warning <input type="radio"/> Minor <input type="radio"/> Major <input type="radio"/> Critical																																																																																																																																																																																										
Date/Time	Severity	Description	Status																																																																																																																																																																																							
AUG/11/2003 14:24:58	Major	BER 10-3 Error	Normal																																																																																																																																																																																							
AUG/11/2003 14:24:58	Major	Major relay alarm	Normal																																																																																																																																																																																							
AUG/11/2003 14:24:55	Minor	FarEnd Alarm	Normal																																																																																																																																																																																							
AUG/11/2003 14:24:55	Major	BER 10-3 Error	Alarm																																																																																																																																																																																							
AUG/11/2003 14:24:55	Major	Major relay alarm	Alarm																																																																																																																																																																																							
AUG/11/2003 14:24:53	Minor	Far End Link Down	Normal																																																																																																																																																																																							
AUG/11/2003 14:24:51	Minor	Far End Link Down	Alarm																																																																																																																																																																																							
AUG/11/2003 14:24:51	Minor	FarEnd Alarm	Alarm																																																																																																																																																																																							
AUG/11/2003 14:24:45	Normal	System Reset																																																																																																																																																																																								
AUG/11/2003 14:21:58	Minor	FarEnd Alarm	Normal																																																																																																																																																																																							
AUG/11/2003 14:21:53	Minor	Far End Link Down	Normal																																																																																																																																																																																							
AUG/11/2003 14:21:53	Major	BER 10-3 Error	Normal																																																																																																																																																																																							
AUG/11/2003 14:21:53	Major	Major relay alarm	Normal																																																																																																																																																																																							
AUG/11/2003 14:21:49	Critical	Radio Sync	Normal																																																																																																																																																																																							
AUG/11/2003 14:19:48	Major	BER 10-3 Error	Alarm																																																																																																																																																																																							
AUG/11/2003 14:19:44	Minor	RF Unit Comm Error	Normal																																																																																																																																																																																							
AUG/11/2003 14:19:43	Minor	Far End Link Down	Alarm																																																																																																																																																																																							
AUG/11/2003 14:19:43	Minor	FarEnd Alarm	Alarm																																																																																																																																																																																							
AUG/11/2003 14:19:43	Minor	RF Unit Comm Error	Alarm																																																																																																																																																																																							
AUG/11/2003 14:19:43	Critical	Radio Sync	Alarm																																																																																																																																																																																							

Viewing Proxim Support Information

<p>Contact Tab on page 64</p>	<p>View Proxim Support information (see "Technical Support" on page 100)</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Device</th> <th>Intf Cfg</th> <th>Sys Cfg</th> <th>Status</th> <th>Alarms</th> <th>Log</th> <th>Contact</th> <th>Admin</th> </tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: center;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="background-color: #cccccc;">Address</td> <td colspan="6">Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (U.S., Canada, Central/Latin America)</td> <td colspan="6">1 (866) 674-6626</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (Europe, Middle East, Africa, Asia and Pacific)</td> <td colspan="6">1 (661) 367-2230</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Fax</td> <td colspan="6">1 (408) 731-3676</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Email</td> <td colspan="6">wansupport@proxim.com</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">URL</td> <td colspan="6">www.proxim.com</td> </tr> </table> </td> </tr> </tbody> </table>	Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="background-color: #cccccc;">Address</td> <td colspan="6">Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (U.S., Canada, Central/Latin America)</td> <td colspan="6">1 (866) 674-6626</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (Europe, Middle East, Africa, Asia and Pacific)</td> <td colspan="6">1 (661) 367-2230</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Fax</td> <td colspan="6">1 (408) 731-3676</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Email</td> <td colspan="6">wansupport@proxim.com</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">URL</td> <td colspan="6">www.proxim.com</td> </tr> </table>								Address		Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA						Technical Support (U.S., Canada, Central/Latin America)		1 (866) 674-6626						Technical Support (Europe, Middle East, Africa, Asia and Pacific)		1 (661) 367-2230						Fax		1 (408) 731-3676						Email		wansupport@proxim.com						URL		www.proxim.com					
Device	Intf Cfg	Sys Cfg	Status	Alarms	Log	Contact	Admin																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="background-color: #cccccc;">Address</td> <td colspan="6">Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (U.S., Canada, Central/Latin America)</td> <td colspan="6">1 (866) 674-6626</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Technical Support (Europe, Middle East, Africa, Asia and Pacific)</td> <td colspan="6">1 (661) 367-2230</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Fax</td> <td colspan="6">1 (408) 731-3676</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">Email</td> <td colspan="6">wansupport@proxim.com</td> </tr> <tr> <td colspan="2" style="background-color: #cccccc;">URL</td> <td colspan="6">www.proxim.com</td> </tr> </table>								Address		Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA						Technical Support (U.S., Canada, Central/Latin America)		1 (866) 674-6626						Technical Support (Europe, Middle East, Africa, Asia and Pacific)		1 (661) 367-2230						Fax		1 (408) 731-3676						Email		wansupport@proxim.com						URL		www.proxim.com																
Address		Proxim Corp. 935 Stewart Drive Sunnyvale, CA 94085, USA																																																																
Technical Support (U.S., Canada, Central/Latin America)		1 (866) 674-6626																																																																
Technical Support (Europe, Middle East, Africa, Asia and Pacific)		1 (661) 367-2230																																																																
Fax		1 (408) 731-3676																																																																
Email		wansupport@proxim.com																																																																
URL		www.proxim.com																																																																

Uploading Software

You can upload the most recent version of the application software. To upload a file:

1. Download the most recent software from <http://www.proxim.com/support/>.
2. Connect the PC with the new software to the radio terminal through the NMS.
3. At your browser's address field, enter **http://<IP address>/upload.htm**, or select **File Upload** from the Admin tab. (For factory default, use 10.0.0.1 for the IP address.)
4. If not already logged in, enter the default "managers" **username** and the appropriate **password**; the following Web page is displayed.

The screenshot shows a web interface with the Proxim logo at the top. Below the logo is the title "GX File Upload". There is a text input field labeled "Enter the file name to upload" and a "Browse..." button. Below this, it lists supported upload file types: Application software, FPGA firmware, and Configuration File. A "Start" button is positioned below the list. The interface is divided into two sections. The bottom section is titled "Software Bank Switch" and contains the text: "The system FLASH memory can keep two banks of software. Click the button will reboot the system with the software in the other bank. It will take 1 minute to reboot itself." Below this text is the instruction "Restart browser to connect to the system again." and the status "Bank 0 Status: valid, Current bank is: 1, Bank 1 Status: valid". A "Switch" button is located at the bottom of this section.

5. Enter the name and location of the file you want to upload, or click **Browse** and select the file location.
6. Click **Start**. For software or firmware, the file is uploaded to the unused Bank. Make note of the Current bank number for reference. (The radio has two banks of flash memory available: **Bank 0** and **Bank 1**. Only one bank is in use at a time. After uploading, the radio automatically switches to the bank holding the newly uploaded software.)

Once software upload is complete, the following message is displayed:

```
File upload finished and system will reboot! Restart browser to logon again.
```

You will need to wait one minute for the radio to restart. Close both browser windows and restart your browser. You may complete steps 1 through 3 to ensure the newly uploaded Bank is valid and is the current Bank in use.

To use the previous software version, you can manually switch between banks by clicking the **Switch** button; after switching between Banks, you must close and restart the browser after waiting for the radio to reboot. If a Bank is marked invalid, you cannot switch to that Bank and should upload the latest software to that bank. A Bank may become invalid if a software upload was interrupted.

MANAGING WITH SNMP

The radios support SNMP version 2C and earlier. All SNMP traffic, including traps, SET commands, and GET commands, are sent and received through the NMS whether locally or through the in-band PPP link. See “Planning NMS Configuration” on page 33 to configure the NMS network.

Requirements

- A copy of the Proxim MIB files are required to configure and manage the radios using SNMP. There is a generic MIB for all GX radios (**g4_generic.mib**) and a more interface-specific MIB file per the specific radio and its interfaces (for example, the file **if_t1e1.mib** is used for the Lynx.GX model radios).
- A workstation running an SNMP manager such as HP OpenView, Castle Rock SNMPc, or Ipswitch WhatsUp Gold.

Install the MIB in the SNMP Manager

Follow the instructions provided with the SNMP Management software to load and compile the generic MIB and the specific interface MIB for the radio onto the SNMP Network Manager. The MIBs contain all the traps and configuration variables for the radio SNMP agent. These MIBs are included in the CD that ships with the unit.

Network Connections

Use a ping utility to make sure your SNMP Manager can communicate with the radios. Configure the radio’s SNMP Community strings using the Web interface **Admin** page or through the CLI interface.

These radios support many of the RFC1213 functions, and the enterprise MIBs allow monitoring and configuring of boot, clock, trap, authentication, log, device, status, performance, and configuration information.


MANAGING WITH TELNET

You can use the command line interface (CLI) through Telnet to assign the radio new IP information, change the password, change SNMP community strings, and view some radio status information.

Starting a Session

To start a Telnet session through the NMS port:

1. From Windows, open a Command Prompt, or MS-DOS Prompt (**Start → Run...**).
2. Enter the following at the command line of the command prompt window:
`C:\>Telnet <IP address>`
3. Telnet issues a connection message;




```

C:\>Telnet 10.0.0.1
Connecting To 10.0.0.1...
Microsoft Windows [Version 5.00.2195]
(C) Copyright 1985-2000 Microsoft Corp.

C:\>Telnet 10.0.0.1
Connecting To 10.0.0.1...
  
```

4. When prompted, enter **managers** as the username and **managers** as the password (or your assigned password).

5. Enter **gxHelp** to view available commands, as shown in the following figure:



```

C:\WINNT\System32\telnet.exe
Welcome to Tsunami/Lynx GX Command Line Interface Menu

NMU SW Version  -- 0.8 < Created Nov 11 2002, 11:01:43 >
MAC address     -- 00:d0:92:00:43:40
IP address      -- 10.0.0.1
SubNetMask     -- 255.0.0.0
Default Gateway ---
Set Community String -- private
Get Community String -- public
Current Time/Date -- 11-13-2002 15:02

-----
User Online Command List

gxHelp(), Shows system information and list of commands
getPerf(), Snap Shot of the performance data
setIP(IpAdr), Sets IP address, example - setIP("10.10.5.37")
setMask(Netmask), Sets subnet Mask, example - setMask("255.0.0.0")
setGW(Gateway), Sets default Gateway example - setGW("10.10.5.10")
setSetComStr(ComStr), Sets SNMP set community string
setGetComStr(ComStr), Sets SNMP get community string
setPwd(oldPwd, newPwd), Sets administrator's password

-> value = 6 = 0x6
->
  
```

To end a Telnet session use the **logout** command. A config port session is unavailable until any telnet session has ended.

CLI Commands

These are the CLI commands you can use:

```

gxHelp ..... Shows system information and list of commands.
getPerf ..... Snapshot of the performance data.
setIP ("IpAdr") ..... Sets IP address; example: setIP ("10.10.5.37")
setMask ("Netmask") ..... Sets subnet mask; example: setMask ("255.0.0.0")
setGW ("Gateway") ..... Set to default gateway; example: setGW("10.10.5.10")
setSetComStr ("ComStr") ..... Sets SNMP set community string
setGetComStr ("ComStr") ..... Sets SNMP get community string
SetPwd ("oldPwd", "newPwd") .. Sets administrator's password
  
```

MAINTAINING THE RADIO

The radio does not require any regular maintenance. However, it is prudent to monitor the radio link at regular intervals to ensure that the link conditions are not changing. When visiting a radio site for maintenance, you should check the following items and record the results:

- RSL voltage
- Power setting (NMS)
- Far-end RSL voltage
- Alarm conditions

Be sure to verify that the unit has adequate ventilation.

If any alarm conditions exist, record them. See "Troubleshooting Alarms" on page 95.

Proxim recommends you review the radio's **Log** and **Status** pages to view whatever alarms and changes in performance have occurred since the last maintenance interval. Download the log or perform a 'print screen' with your computer to keep a record of the performance for your maintenance records.

Proxim also recommends that the antenna system be inspected annually. This inspection should include inspection of mounting hardware for tightness and corrosion, condition of the weatherseal on all RF connections, and integrity of ground connections on cable and surge suppressor.