

# PRELIMINARY

## **INSTALLATION AND MAINTENANCE MANUAL**



**WIRELESS  
FAST ETHERNET BRIDGES  
(5.3 AND 5.8 GHz, UNII/LE-LAN)**

---





## Installation and Maintenance Manual

Copyright © 1999 by Glenayre Western Multiplex. All rights reserved. No part of this manual may be reproduced without prior written permission from Glenayre Western Multiplex.

The information contained in this manual is subject to change without notice. Glenayre Western Multiplex shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or equipment supplied with this manual. Glenayre Western Multiplex makes no warranty of any kind with regard to this manual or any equipment supplied with this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Helix<sup>TM</sup> is a registered product of Andrews Corporation.

Printed in the United States of America

**Notice: Y2K (Year 2000 Issue)**

***All software supplied by and for Glenayre Western Multiplex products adheres to the four-(4) digit year nomenclature as required for Year 2000 compliance.***

Glenayre Western Multiplex  
1196 Borregas Avenue  
Sunnyvale, California  
USA  
Tel: +1 408 542-5200  
Fax: +1 408 542-5300

*Our facility has been Registered to the International Organization for Standardization  
ISO 9000 Series Standards for quality.*

Issue: June 1999

This page intentionally left blank



## Regulatory Notice

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio/TV technician for help.

Shielded cables and I/O cords must be used for this equipment to comply with the relevant FCC regulations.

Changes or modifications not expressly approved in writing by Glenayre Western Multiplex may void the user's authority to operate this equipment.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

**This device must be professionally installed.**

This page intentionally left blank

## WARRANTY

### GENERAL TERMS

- 1.1 All Definitions contained in Glenayre Western Multiplex's Conditions of Sale (Glenayre Western Multiplex document number CS96-8), apply to the Warranty.
- 1.2 Subject to the provisions of the Warranty, Glenayre Western Multiplex warrants that the equipment described in Paragraph 1.3 shall conform to their specifications described in Paragraph 1.4 in all material respects and that the equipment shall be free from material defects in materials and workmanship.
- 1.3 This Warranty applies to all original purchases of Glenayre Western Multiplex manufactured equipment and accessories (collectively the "Equipment").
- 1.4 This Warranty applies to the specifications contained in the most recent version of the manual for the model of the Equipment purchased (the "Specifications").
- 1.5 This Warranty does not apply to the following items of Equipment which are covered by the Original Equipment Manufacturer's warranty:
  - (a) antenna systems, including coax cable, waveguide, connectors flex-sections, mounts, other parts of the antenna system and installation materials;
  - (b) non-Glenayre Western Multiplex manufactured rack mounted equipment that is assembled wired and tested at Glenayre Western Multiplex's factory or supplied as part of a system, including orderwire items, channel banks, multiplexers, fuse/alarm panels, remote alarm items; and
  - (c) equipment which is not listed in Glenayre Western Multiplex's price book.
- 1.6 The effective period of this Warranty shall start on the date of shipment of the Equipment and shall end:
  - (a) for all spread spectrum unlicensed radio products and for all licensed digital microwave radio products, two (2) years later;
  - (b) for all analog microwave radio products, three (3) years later; or
  - (c) for all baseband products, five (5) years later (in each case the "Warranty Period").
- 1.7 The Customer acknowledges that Glenayre Western Multiplex does not represent or warrant that the services provided by Glenayre Western Multiplex under this Warranty will ensure uninterrupted or error-free operation of the Equipment.

### RETURN OF EQUIPMENT UNDER WARRANTY

- 2.1 If an item of Equipment malfunctions or fails in normal intended usage and maintenance within the applicable Warranty Period:
  - (a) the Customer shall promptly notify Glenayre Western Multiplex of the problem and the serial number of the defective item;
  - (b) Glenayre Western Multiplex shall, at its sole option, either resolve the problem over the telephone or provide the Customer with a Returned Materials Authorization number (RMA #) and the address of the location to which the Customer may ship the defective item;
  - (c) if the problem is not resolved over the telephone, the Customer shall attach a label to each Returned item describing the fault and the Customer's Return address. The Customer shall, at its cost, properly pack the item to be Returned, prepay the insurance and shipping charges, and ship the item to the specified location;
  - (d) if the Glenayre Western Multiplex product shall prove to be defective in material or workmanship upon examination by Glenayre Western Multiplex, Glenayre Western Multiplex shall either repair or replace the Returned item at its sole option. The replacement item may be new or refurbished; if refurbished, it shall be equivalent in operation to new Equipment. If a Returned item is replaced by Glenayre Western Multiplex, the Customer agrees that the Returned item shall become the property of Glenayre Western Multiplex.

- (e) Glenayre Western Multiplex shall at its cost, ship the repaired item or replacement to any destination within the United States of America by carrier and method of delivery chosen by Glenayre Western Multiplex. If the Customer has requested some other form of conveyance, such as express shipping, or is located beyond the USA borders, then the Customer shall pay to the cost of return shipment.

- 2.2 Equipment which is repaired or replaced by *Glenayre Western Multiplex* under this Warranty shall be covered under all of the provisions of this Warranty for the remainder of the applicable Warranty Period or ninety (90) days from the date of shipment of the repaired item or replacement, whichever period is longer.

### DEFAULT AND TERMINATION

- 3.1 *Glenayre Western Multiplex* may immediately terminate this Warranty and all of its performance under this Warranty, upon notification to the Customer, if the Customer:
  - (a) makes any unauthorized modifications to the Equipment;
  - (b) assigns or transfers the Customer's rights or obligations under this Warranty without the written consent of *Glenayre Western Multiplex*;
  - (c) becomes bankrupt or insolvent, or is put into receivership; or
  - (d) has not paid *Glenayre Western Multiplex* all amounts for the Equipment, services, or other additional charges within thirty (30) days of receipt of written notice from *Glenayre Western Multiplex*.
- 3.2 If this Warranty is terminated by *Glenayre Western Multiplex*, the Customer shall remain liable for all amounts due to *Glenayre Western Multiplex*.

### FORCE MAJEURE

- 4.1 "Force Majeure" has the same meaning as defined in *Glenayre Western Multiplex's* Conditions of Sale (*Glenayre Western Multiplex* document number CS96-8).
- 4.2 *Glenayre Western Multiplex* shall not be responsible for failure to discharge its obligations under this Warranty due to Force Majeure.

### LIMITATIONS AND QUALIFICATIONS OF WARRANTY

- 5.1 This Warranty does not apply to any damage, defect or failure caused by:
  - (a) any part of the Equipment having been modified, adapted, repaired, or improperly installed, operated, maintained, transported or relocated by any person other than *Glenayre Western Multiplex* personnel or a *Glenayre Western Multiplex* authorized service agent, without *Glenayre Western Multiplex's* prior written consent;
  - (b) storage or environmental conditions which do not conform to the applicable sections of the appropriate *Glenayre Western Multiplex* Equipment Manual;
  - (c) failure to conform with the Equipment Installation, Operating and Maintenance Instructions of the appropriate *Glenayre Western Multiplex* Equipment Manual;
  - (d) external causes, including external electrical stress or lightning, or use in conjunction with incompatible equipment, unless such use was with *Glenayre Western Multiplex's* prior written consent;
  - (e) cosmetic damage;
  - (f) accidental damage, negligence, neglect, mishandling, abuse or misuse, other than by *Glenayre Western Multiplex* personnel or a *Glenayre Western Multiplex* authorized service agent; or
  - (g) Force Majeure.

**Please see reverse side for additional limitations on damages.**

**LIMITATIONS ON DAMAGES (North America)**

- 6.1 THE WARRANTY STATED IN THIS DOCUMENT IS THE CUSTOMER'S EXCLUSIVE WARRANTY FOR THE EQUIPMENT; GLENAYRE WESTERN MULTIPLEX SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND OF MERCHANTABILITY.
- 6.2 GLENAYRE WESTERN MULTIPLEX SHALL NOT BE LIABLE IN TORT, INCLUDING LIABILITY IN NEGLIGENCE OR STRICT LIABILITY, AND SHALL HAVE NO LIABILITY AT ALL FOR INJURY TO PERSONS OR PROPERTY. GLENAYRE WESTERN MULTIPLEX'S LIABILITY FOR FAILURE TO FULFIL ITS OBLIGATIONS UNDER THIS WARRANTY OR ANY OTHER LIABILITY UNDER OR IN CONNECTION WITH THE EQUIPMENT SHALL BE LIMITED TO THE AMOUNT OF THE PURCHASE PRICE OF THE EQUIPMENT. THE REMEDIES STATED IN THIS WARRANTY ARE THE CUSTOMER'S EXCLUSIVE REMEDIES AGAINST GLENAYRE WESTERN MULTIPLEX REGARDING THE EQUIPMENT.
- 6.3 EVEN IF GLENAYRE WESTERN MULTIPLEX HAS BEEN ADVISED OF THE POSSIBILITY OF THEM, GLENAYRE WESTERN MULTIPLEX SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING THE COST OF LABOR BY THE CUSTOMER'S OWN EMPLOYEES, AGENTS OR CONTRACTORS IN IDENTIFYING, REMOVING OR REPLACING THE DEFECTIVE ITEM; LOST PROFITS, AND REVENUES; FAILURE TO REALIZE EXPECTED SAVINGS; ANY CLAIM AGAINST A CUSTOMER BY A THIRD PARTY; OR ANY OTHER COMMERCIAL OR ECONOMIC LOSSES OF ANY KIND.
- 6.4 THESE LIMITATIONS AND DISCLAIMERS ARE NOT MADE BY GLENAYRE WESTERN MULTIPLEX WHERE PROHIBITED BY LAW.

**LIMITATIONS ON DAMAGES (International)**

- 6.1 THE WARRANTY STATED IN THIS DOCUMENT IS THE CUSTOMER'S EXCLUSIVE WARRANTY FOR THE EQUIPMENT; ALL OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND OF MERCHANTABILITY ARE EXCLUDED TO THE FULLEST EXTENT PERMITTED BY LAW.
- 6.2 GLENAYRE WESTERN MULTIPLEX'S LIABILITY FOR FAILURE TO FULFIL ITS OBLIGATIONS UNDER THIS WARRANTY OR IN TORT OR AS A RESULT OF STRICT LIABILITY OR ANY OTHER LIABILITY UNDER OR IN CONNECTION WITH THE EQUIPMENT OR ITS SUPPLY SHALL BE LIMITED, EXCEPT IN RESPECT OF DEATH AND PERSONAL INJURY CAUSED BY GLENAYRE WESTERN MULTIPLEX'S NEGLIGENCE, TO THE AMOUNT OF THE PURCHASE PRICE OF THE EQUIPMENT. THE REMEDIES STATED IN THIS WARRANTY ARE THE CUSTOMER'S EXCLUSIVE REMEDIES AGAINST GLENAYRE WESTERN MULTIPLEX REGARDING THE EQUIPMENT.
- 6.3 EVEN IF GLENAYRE WESTERN MULTIPLEX HAS BEEN ADVISED OF THE POSSIBILITY OF THEM, GLENAYRE WESTERN MULTIPLEX SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING THE COST OF LABOR BY THE CUSTOMER'S OWN EMPLOYEES, AGENTS OR CONTRACTORS IN IDENTIFYING, REMOVING OR REPLACING THE DEFECTIVE ITEM; LOST PROFITS, AND REVENUES; FAILURE TO REALIZE EXPECTED SAVINGS; ANY CLAIM AGAINST A CUSTOMER BY A THIRD PARTY; OR ANY OTHER COMMERCIAL OR ECONOMIC LOSSES OF ANY KIND.



## CONDITIONS OF SALE

### DEFINITIONS

- 1.1 In these Conditions, unless there is something in the subject matter or context necessarily inconsistent:
- (a) "Glenayre Western Multiplex" means Glenayre Western Multiplex (d.b.a. Glenayre Western Multiplex), Wilmington, MA;
  - (b) "Equipment" means the equipment itemized on the Quotation/Order Acknowledgment;
  - (c) "International" means any location other than United States of America and Canada, including their territories and possessions;
  - (d) "North America" means any location in the United States of America and Canada, including their territories and possessions;
  - (e) "Order Acknowledgment" means the sales order acknowledgment provided by Glenayre Western Multiplex to the Customer;
  - (f) "Payment Instructions" means Glenayre Western Multiplex's payment instructions, (Glenayre Western Multiplex document P197-1);
  - (g) "Quotation" means the quotation signed by an authorized representative of Glenayre Western Multiplex and provided to the Customer;
  - (h) "Shipping Date" means the actual date on which the Equipment left Glenayre Western Multiplex's factory at Wilmington, MA, U.S.A.;
  - (i) "Warranty" means Glenayre Western Multiplex's warranty, document W97-1;
  - (j) "Invoice" means the bill of goods prepared by Glenayre Western Multiplex for the equipment with the shipping and any insurance costs.
- 1.2 Headings have been inserted in these Conditions for convenience of reference only and will not effect their construction.

### ENTIRE AGREEMENT

- 2.1 The Quotation, these Conditions of Sale, the Order Acknowledgment, the Payment Instructions and the Warranty shall apply to all sales made by Glenayre Western Multiplex and shall constitute the entire agreement by Glenayre Western Multiplex and the Customer (the "Agreement").
- 2.2 Any terms and/or conditions of sale, which may be included on the Customer's purchase order form or any communication from the Customer, that are not identical with the terms and conditions stated in this document shall NOT become a part of the agreement of sale unless expressly agreed to in writing in the Quotation.
- 2.3 Glenayre Western Multiplex's failure to object to any terms and/or conditions of sale contained in any communication from the Customer shall not be considered as acceptance of such terms and/or conditions or as a waiver of the terms and conditions of sale contained herein.
- 2.4 Glenayre Western Multiplex shall sell to the Customer, and the Customer shall purchase from Glenayre Western Multiplex, the Equipment in accordance with the Agreement. Glenayre Western Multiplex accepts the Customer's purchase orders for Equipment and agrees to deliver the Equipment to the Customer only on the terms of the Agreement.
- 2.5 No variation of the Agreement shall be binding unless agreed to in writing by authorized representatives of Glenayre Western Multiplex and the Customer.

### PRICING

- 3.1 All prices in the Quotation are exclusive of all shipping charges and all applicable taxes including but not limited to, federal, state, local, excise, sales and use taxes.
- 3.2 All prices in the Quotation unless otherwise stated:
- (a) for North American customers are FOB Wilmington, MA, USA. (New York Uniform Commercial Code); or
  - (b) for international customers are Ex-Works, Wilmington, MA, U.S.A. (Incoterms 1990).
- 3.3 All prices in the Quotation include standard domestic packing, unless a separate line item is provided detailing export or special packing charges.

### SHIPPING AND INSURANCE

- 4.1 Glenayre Western Multiplex shall arrange shipping and insurance when requested by the Customer, and shall bill the Customer for the Equipment with the shipping and any insurance costs as separate items, on an invoice (the "Invoice").
- 4.2 Delivery dates quoted by Glenayre Western Multiplex are to be considered estimates only. In no event will Glenayre Western Multiplex be liable for any loss or damage resulting from its failure

to deliver products within a specified time.

### TERMS OF PAYMENT

- 5.1 The Customer shall pay for all Equipment, including shipping and insurance in accordance with the terms of the Invoice.
- 5.2 All Invoices for North American Customers are due and payable in thirty (30) days from the date of the Invoice.
- 5.3 International Customers shall make payments in accordance with Glenayre Western Multiplex's Payment Instructions by either:
- (a) providing a wire transfer (telegraphic transfer) for the full amount of the Equipment, shipping and insurance charges contained in the Quotation or the pro-forma Invoice sent to the Customer, prior to the Shipping Date; or
  - (b) establishing an acceptable Letter of Credit (LC) for the full amount of the Equipment, shipping and insurance charges contained in the Quotation prior to the order being booked and accepted by Glenayre Western Multiplex.
- 5.4 If a Customer fails to pay an Invoice when due, Glenayre Western Multiplex may, without prejudice to any other remedy, postpone shipments, alter payment terms, terminate the Agreement and charge interest on all overdue amounts the rate of 1.5% per month compounded monthly (or if less, the maximum allowed by law). Upon demand, the Customer shall pay all such interest charges and all reasonable collection fees, including reasonable legal expenses.

### SECURITY FOR PAYMENT

- 6.1 If the Customer is located in North America, the Customer grants to Glenayre Western Multiplex a purchase money security interest in the Equipment to secure the payment of the purchase price of the Equipment and all other amounts due from the Customer.
- 6.2 If the Customer is not located in North America:
- (a) despite delivery and passing of risk in the Equipment and any other provision of these Conditions, the title in the Equipment shall not pass to the Customer until Glenayre Western Multiplex has received payment in full of the purchase price of the Equipment and all other amounts then due from the Customer, and
  - (b) until the title in the Equipment passes to the Customer: the Customer shall hold the equipment as Glenayre Western Multiplex's fiduciary agent and bailee, and shall properly store, protect and insure the Equipment and shall identify the Equipment as Glenayre Western Multiplex property;
  - (ii) if the Customer fails to pay Glenayre Western Multiplex in accordance with the agreed payment terms, Glenayre Western Multiplex may require the Customer to deliver up the Equipment to Glenayre Western Multiplex, and, if the Customer does not, Glenayre Western Multiplex may enter on the premises where the Equipment is stored and repossess the Equipment; and
  - (iii) the Customer shall not pledge the Equipment by way of security for any, indebtedness of the Customer, but if the Customer does so all moneys owed by the Customer to Glenayre Western Multiplex shall, without prejudice to any other remedy of Glenayre Western Multiplex, immediately become due.

### CHANGES TO PRODUCT SPECIFICATIONS

- 7.1 Glenayre Western Multiplex may, without notice to the Customer, make changes to the specifications of Equipment which do not materially affect the quality or performance of the Equipment.

### EQUIPMENT CONFIGURATION AND EXPEDITING CHARGES

- 8.1 At the Customer's request, Glenayre Western Multiplex may, for a fee agreed in advance:
- (a) reconfigure the Equipment; or
  - (b) expedite the Customer's order.

**SHORTAGES**

- 9.1 The customer shall not make any claim for shortages (which are items that the Invoice does not show are on back-order) after twenty-one (21) days after the date of the Invoice.

**RETURNS AND EXCHANGES**

- 10.1 The return of defective Equipment is covered by the Warranty .
- 10.2 The Customer may only return Equipment that is not defective if:
- the Equipment does not correspond with the Customer's purchase order; or
  - the Equipment has been ordered in error by the Customer and Glenayre Western Multiplex has permitted the Customer to remedy the mistake by ordering the correct equipment and resuming the Equipment and the Customer obtains a Returned Materials Authorization number ("RMA #") from Glenayre Western Multiplex prior to returning any Equipment.
- 10.3 Glenayre Western Multiplex reserves the right to charge a fee for returned equipment under Subparagraph 10.2(b) with the amount of the fee being determined prior to an RMA # being given by Glenayre Western Multiplex.
- 10.4 Authorized returns of equipment under Paragraph 10.2 must be in an undamaged condition, in the original configuration, in the original packing materials and within a time period agreed to when the RMA # was issued.
- 10.5 If the Customer does not comply with the provisions of Paragraphs 10.2, 10.3, and 10.4, the Customer shall pay the full amount of the Invoice.
- 10.6 The party liable for all shipping, insurance and any other expenses incurred by the Customer in returning the Equipment under Paragraph 10.2 and for all loss or damage to the Equipment until received by Glenayre Western Multiplex, shall be: (a) for all items returned under Subparagraph 10.2(a), Glenayre Western Multiplex and (b) for all items resumed under Subparagraph 10.2(b), the Customer.

**CANCELLATION**

- 11.1 If the Customer cancels an order before the Shipping Date, Glenayre Western Multiplex reserves the right to charge the Customer a cancellation charge up to 100% of the amount of the order.
- 11.2 The Customer shall pay all cancellation charges within thirty (30) days from date of the Invoice.

**FORCE MAJEURE**

- 12.1 Glenayre Western Multiplex shall not be liable if its performance of the Agreement becomes commercially impractical due to any contingency beyond Glenayre Western Multiplex's reasonable control, including acts of God, fires, floods, wars, sabotage, civil unrest, accidents, labor disputes or shortages, government laws, rules and regulations, whether valid or invalid, inability to obtain material, equipment or transportation, incorrect, delayed or incomplete specifications, drawings or data supplied by the Customer or others (collectively "Force Majeure"). In no event of Force Majeure shall Glenayre Western Multiplex be required to purchase goods from others to enable it to deliver the Equipment under the Agreement.

**ENGINEERING AND SYSTEM DESIGN**

- 13.1 The Customer is solely responsible for the engineering, design, integration and normal preventative and remedial maintenance of the Customer's system for which Glenayre Western Multiplex supplies Equipment.
- 13.2 Glenayre Western Multiplex is not responsible for the satisfactory operation of the Equipment in conjunction with other manufacturer's equipment, nor for any losses which may occur as a result of a failure of the Equipment to operate in conjunction with other manufacturer's equipment.

**WARRANTY**

- 14.1 All Equipment is covered by the Warranty.
- 14.2 THE WARRANTY CONTAINS LIMITATIONS ON THE CUSTOMER'S RIGHTS AND REMEDIES AGAINST GLENAYRE WESTERN MULTIPLEX UNDER THE AGREEMENT. THE CUSTOMER ACKNOWLEDGES HAVING READ,

UNDERSTOOD AND AGREED TO THOSE LIMITATIONS.

**DAMAGES FOR BREACH OF AGREEMENT**

- 15.1 If either party is successful in any litigation between the parties based on the Agreement, the successful party shall recover from the other, in addition to direct damages, the successful party's reasonable attorney's fees and other costs of litigation.

**INSOLVENCY OF CUSTOMER, ETC.**

- 16.1 Glenayre Western Multiplex may cancel the Agreement and suspend any further deliveries under the Agreement without any liability to the Customer, and, if Equipment has been delivered but not paid for, the price shall become immediately due and payable despite any other agreement to the contrary if:
- any proceedings in bankruptcy, insolvency, receivership or liquidation are taken against the Customer;
  - the Customer makes an assignment for the benefit of creditors or commits an act of bankruptcy or insolvency;
  - the Customer ceases, or threatens to cease, to carry on the ordinary course of its business, or transfers all or substantially all of its property;
  - the Equipment is seized under any legal process or confiscated; or
  - Glenayre Western Multiplex in good faith believes that the ability of the Customer to pay or perform any provision of the Agreement is impaired, or that any of the events mentioned above is about to occur.

**NOTICE**

- 17.1 All requests, instructions and notices from one party to the other must be in writing and may be given via registered post or facsimile transmission to the address of the parties shown on the Quotation or Order Acknowledgment.

**EXPORT PROVISIONS**

- 18.1 The Customer shall not, whether directly or indirectly (including facilitating a third party) export or re-export the Equipment outside the country in which the Customer has stated these items are to be used without obtaining the licenses required under all applicable rules. The Customer shall indemnify Glenayre Western Multiplex against any liability incurred by Glenayre Western Multiplex due to any violation by the Customer of any of the provisions of this Section, but this indemnity shall not apply if the Customer reasonably relies on information supplied to it by Glenayre Western Multiplex with respect to export licenses. Upon receipt of a governmental consent to export the receiving party shall immediately notify the other in writing.

**MISCELLANEOUS**

- 19.1 No waiver by Glenayre Western Multiplex of any breach of this Agreement shall be considered as a waiver of any subsequent breach of the same or any other provision.
- 19.2 Any provision of the Agreement which is, or is deemed to be, unenforceable in any jurisdiction shall be severable from the Agreement in that jurisdiction without in any way invalidating the remaining portions of the Agreement, and that unenforceability shall not make that provision unenforceable in any other jurisdiction.
- 19.3 The rights which accrue to Glenayre Western Multiplex by virtue of the Agreement shall inure for the benefit of and be binding upon the successors and assigns of Glenayre Western Multiplex.
- 19.4 The agreement shall be governed by the laws of the State of California including the California Uniform Commercial Code. However Glenayre Western Multiplex may enforce the provisions of the Agreement in accordance with the laws of the jurisdiction in which the Equipment is situated. The United Nations Convention on the Sale of Goods (The Vienna Convention) shall not apply to the Agreement.
- 19.5 Les parties ont exigés que cette entente soit rédigée en anglais.

# Tsunami™

## Table of Contents

|   |            |
|---|------------|
| <b>1. HOW TO USE THIS MANUAL .....</b>                  | <b>1-1</b> |
| 1.1 MANUAL ORGANIZATION .....                           | 1-1        |
| 1.2 ICONS.....  | 1-2        |
| <b>2. PRODUCT DESCRIPTION .....</b>                     | <b>2-1</b> |
| 2.1 GENERAL DESCRIPTION .....                           | 2-1        |
| 2.2 SPECIFICATIONS .....                                | 2-2        |
| 2.2.1 Transmitter.....                                  | 2-2        |
| 2.2.2 Antenna / Antenna Coupling Unit.....              | 2-3        |
| 2.2.3 Receiver.....                                     | 2-3        |
| 2.2.4 System (Single Hop Performance) .....             | 2-4        |
| 2.2.5 Digital Line Interface.....                       | 2-6        |
| 2.2.6 Auxiliary Connections.....                        | 2-7        |
| 2.2.7 Temperature and Environment .....                 | 2-8        |
| 2.2.8 Power.....  | 2-8        |
| 2.2.9 Regulatory Information.....                       | 2-9        |
| 2.2.10 Mechanical.....                                  | 2-9        |
| 2.3 FRONT PANEL DESCRIPTION .....                       | 2-10       |
| 2.3.1 General .....                                     | 2-10       |
| 2.3.2 Test Points / Power Indicator .....               | 2-11       |
| 2.3.3 Alarm and Status Indicators .....                 | 2-12       |
| 2.3.4 Controls.....                                     | 2-13       |
| 2.3.5 Connections.....                                  | 2-14       |
| 2.4 REAR PANEL DESCRIPTION .....                        | 2-16       |
| 2.5 INSTALLATION ACCESSORIES .....                      | 2-17       |
| <b>3. INSTALLATION &amp; ADJUSTMENTS.....</b>           | <b>3-1</b> |
| 3.1 SHIPPING CONTAINER .....                            | 3-1        |
| 3.2 PACKING ITEMS IDENTIFICATION .....                  | 3-2        |
| 3.3 BEFORE INSTALLATION TASK LIST.....                  | 3-3        |
| 3.3.1 Site Selection Requirements.....                  | 3-3        |
| 3.3.2 Line-of-Sight and Path Clearance Guidelines ..... | 3-4        |
| 3.3.3 RSL Calculation and Link Budget.....              | 3-5        |
| 3.3.4 Fade Margin Calculation.....                      | 3-6        |
| 3.3.5 Availability Calculation .....                    | 3-7        |
| 3.3.6 Frequency Plan Determination.....                 | 3-8        |
| 3.3.7 Power Supply Planning.....                        | 3-9        |
| 3.3.8 Antenna Planning .....                            | 3-10       |
| 3.4 TOOLS REQUIRED .....                                | 3-11       |
| 3.5 FREQUENCY CHANNEL PLANS .....                       | 3-12       |
| 3.6 MOUNTING THE TSUNAMI.....                           | 3-13       |
| 3.7 POWER CONNECTION AND WIRING .....                   | 3-14       |
| 3.7.1 DC Power Wiring.....                              | 3-15       |
| 3.7.2 AC Power Connection.....                          | 3-17       |
| 3.8 ANTENNA CONNECTION.....                             | 3-18       |
| 3.9 TRANSMISSION LINE CONNECTION .....                  | 3-19       |
| 3.10 ANTENNA INSTALLATION & ALIGNMENT.....              | 3-20       |

|           |  |            |
|-----------|--|------------|
| 3.11      | ETHERNET INTERFACE CONNECTION .....  | 3-23       |
| 3.12      | SYSTEM TURN-UP TO SERVICE.....   | 3-24       |
| 3.13      | OUTPUT POWER ADJUSTMENT.....   | 3-30       |
| 3.14      | ADDITIONAL CONNECTIONS .....   | 3-31       |
| 3.14.1    | <i>Orderwire Connection</i> .....  | 3-31       |
| 3.14.2    | <i>Alarm Connections</i> .....   | 3-33       |
| 3.14.3    | <i>Config Port Operation</i> .....   | 3-35       |
| 3.14.4    | <i>AUX DATA (Digital Service Channel) Connection</i> .....                 | 3-37       |
| <b>4.</b> | <b>TROUBLESHOOTING.....</b>  | <b>4-1</b> |
| 4.1       | REGULAR MAINTENANCE .....  | 4-1        |
| 4.2       | CHANGING FREQUENCY PLANS.....  | 4-2        |
| 4.3       | USING A SPARE TERMINAL.....  | 4-3        |
| 4.4       | TECHNICAL SUPPORT .....  | 4-4        |
| 4.5       | REPAIR POLICY .....  | 4-5        |
| 4.6       | FRONT PANEL STATUS LEADS.....  | 4-6        |
| 4.6.1     | <i>RF LINK Alarm</i> .....   | 4-7        |
| 4.6.5     | <i>RADIO FAIL Alarm</i> .....  | 4-9        |
| 4.6.6     | <i>FAR END Alarm</i> .....   | 4-10       |
| 4.7       | ERRORS IN THE DATA STREAM .....  | 4-11       |
| 4.8       | INTERFERENCE COUNTERMEASURES .....   | 4-12       |
| 4.8.1     | <i>Use of a Spectrum Analyzer to Evaluate Potential Interference</i> ..... | 4-14       |
| 4.9       | BACK-TO-BACK TESTING.....  | 4-15       |
| 4.10      | LINK TESTING .....   | 4-17       |
| <b>5.</b> | <b>APPENDICES.....</b>   | <b>5-1</b> |
|           | APPENDIX A - DIGITAL INTERFACE SPECIFICATIONS.....                         | 5-1        |
| 1.        | <i>General Characteristics</i> .....                                       | 5-1        |
| 2.        | <i>Specifications</i> .....  | 5-1        |
|           | APPENDIX B – CONFIGURATION PORT .....                                      | 5-2        |
|           | APPENDIX C - REAR PANEL DATA CONNECTORS .....                              | 5-3        |

## Figures

|   |      |
|---|------|
| FIGURE 2-1: FRONT PANEL, 2.4 GHZ .....                                  | 2-10 |
| FIGURE 3-1: CHANNEL PLANS, DUAL-BAND.....                               | 3-12 |
| FIGURE 3-2: CHANNEL PLAN, SINGLE-BAND .....                             | 3-12 |
| FIGURE 3-3: NEGATIVE VOLTAGE DC CONNECTION .....                        | 3-16 |
| FIGURE 3-4: POSITIVE VOLTAGE DC CONNECTION .....                        | 3-16 |
| FIGURE 3-5: AC CONNECTION.....  | 3-17 |
| FIGURE 3-6: TYPICAL RSL VOLTAGE VERSUS RECEIVED SIGNAL LEVEL (RSL)..... | 3-22 |
| FIGURE 3-7: TYPICAL RF OUTPUT POWER VERSUS PWR VOLTAGE.....             | 3-26 |
| FIGURE 3-8: VF PORT CONNECTION.....                                     | 3-32 |
| FIGURE 3-9: PIN CONNECTIONS, ALARM INTERFACE .....                      | 3-33 |
| FIGURE 3-10: RS-232 CONFIG PORT CONNECTIONS .....                       | 3-36 |
| FIGURE 4-1: BACK-TO-BACK TEST CONFIGURATION .....                       | 4-16 |
| FIGURE 4-2: END-TO-END TEST CONFIGURATION.....                          | 4-17 |
| FIGURE C-1: VF PORT CONNECTION .....                                    | 5-3  |
| FIGURE C-2: ALARM PORT CONNECTIONS.....                                 | 5-3  |
| FIGURE C-3: DIAGNOSTIC PORT 9-PIN D-STYLE CONNECTOR .....               | 5-3  |
| FIGURE C-4: AUX DATA PORT 9-PIN D-STYLE CONNECTOR .....                 | 5-3  |

## Tables

|  |      |
|--|------|
| TABLE 3-A: DC POWER CONNECTION FOR NEGATIVE SUPPLY.....  | 3-14 |
| TABLE 3-B: DC POWER CONNECTION FOR NEGATIVE SUPPLY.....  | 3-14 |
| TABLE 3-C: TRANSMITTER OUTPUT POWER ADJUSTMENT, 0 dBW (5.3 GHZ) AND +23 dBW (5.8 GHZ) EIRP<br>INSTALLATIONS..... | 3-29 |
| TABLE 3-E: ALARM INTERFACE CONNECTIONS .....   | 3-34 |
| TABLE A-1: INTERCONNECTION SPECIFICATION .....   | 5-1  |



---

# 1. How to Use This Manual

## 1.1 Manual Organization

The Installation and Maintenance Manual provides information required to install and maintain *Tsunami* and to use its many features to the fullest advantage. This manual is divided into the following sections:

- Section 1** Provides instructions on how to most effectively utilize the information in this manual.
- Section 2** Provides a brief description and specifications of the *Tsunami*.
- Section 3** Explains the *Tsunami* installation and adjustments in detail.
- Section 4** Provides maintenance, repair and troubleshooting information for the *Tsunami Fast Ethernet* radios.
- Appendices** Charts and diagrams are provided for radio connections and DIP switch settings along with other general information.



*This device must be professionally installed. Instructions on setting the transmitter RF output power are contained in Section 3 of this Manual.*



*This device is to be used exclusively for fixed point-to-point operation that employs directional antennas.*

## 1.2 Icons

Throughout this manual, the following icons are used to highlight areas of special interest and importance.



**Note**



**Practical Tip**



**Caution**



---

## 2. Product Description

### 2.1 General Description

The *Tsunami* unlicensed radios provide a new level of control and convenience in a digital communications network.

These *Tsunami* radios provide 100BaseT intelligent bridging between two locations without the delay and expense of installing cable or traditional microwave.

Because each owner controls the operation of the link, there is no reliance on any outside services. *Tsunami* radio operators are able to operate instant links whenever needed, and to be in control of their own network.

The *Tsunami* offers two primary benefits:

- ❖ **CONVENIENCE**      Easy to install and operate with **no user license requirements** or frequency coordination in the USA. (Other countries may require a user license and/or frequency coordination).
  
- ❖ **CAPABILITY**      Full transparent Fast Ethernet connections with no throughput reduction over any line-of-sight distance (within legal limits of government regulation)

## 2.2 Specifications



*All specifications are subject to change without notice.*

### 2.2.1 Transmitter

|                     |   |                    |
|---------------------|---|--------------------|
| Frequency Selection | Craft port selection with installer-removable 7-cavity RF filter assembly |                    |
| Frequency           | <u>Dual-Band</u>  | <u>Single-Band</u> |
| A1                  | 5281.1 MHz  | 5756.0 MHz         |
| A2                  | 5756.0 MHz  | 5794.1 MHz         |
| B1                  | 5318.9 MHz  | N/A                |
| B2                  | 5794.1 MHz  | N/A                |
| Modulation          | OQPSK   |                    |
| Output Power (typ.) | +23 dBm   |                    |
| Output Power (min.) | +20 dBm   |                    |
| Control Range       | 16 dB min.  |                    |

### 2.2.2 Antenna / Antenna Coupling Unit

|                                    |  |
|------------------------------------|--|
| Mechanics                          | External antenna                                       |
| Antenna Connection                 | N-type female  |
| Impedance                          | 50 ohms  |
| Recommended Antenna (not included) | 1, or 2 foot flat panel or<br>2, 4 or 6 foot parabolic |
| Gain & Beamwidth (3 dB)            |  |
| 1 ft Flat                          | 23.5 dB / 9°   |
| 2 ft Flat                          | 28 dB / 4.6°   |
| 2 ft Parabolic                     | 28.5 dB / 6°   |
| 4 ft Parabolic                     | 35 dB / 3°   |
| 6 ft Parabolic                     | 38 dB / 2.9°   |

### 2.2.3 Receiver

| <u>All Models</u>                            |   |
|--|---|
| Nominal Receive Level                        | -30 to -60 dBm  |
| Maximum Receive Level                        | 0 dBm error free, +10 dBm no damage                                       |
| Frequency Selection                          | Craft port selection with installer-removable 7-cavity RF filter assembly |
| Threshold Rx Level (BER = 10 <sup>-6</sup> ) | -80 dBm   |
| Frequency Range                              |   |
| Dual-band A2/B2 channel                      | 5250-5350 MHz   |
| Dual-band A1/B1 channel                      | 5725-5825 MHz   |
| Single-band A1/B1 channel                    | 5725-5825 MHz   |

### 2.2.4 System (Single Hop Performance)

|                                    |                        |
|------------------------------------|------------------------|
| Error Floor                        | $10^{-11}$             |
| Dispersive Fade Margin             | 58 dB, typical         |
| Transmission delay<br>(radio only) | 250 $\mu$ sec, maximum |
| (10 mile path)                     | 300 $\mu$ sec, maximum |

---

**System** (Single Hop Performance)

| <b>Transmit Frequencies</b> |                  |                    |
|-----------------------------|------------------|--------------------|
|                             | <u>Dual-band</u> | <u>Single-band</u> |
| A1 channel                  | 5281.1 MHz       | 5756.0 MHz         |
| A2 channel                  | 5756.0 MHz       | 5794.1 MHz         |
| B1 channel                  | 5318.9 MHz       | N/A                |
| B2 channel                  | 5794.1 MHz       | N/A                |
| <b>Receive Frequencies</b>  |                  |                    |
|                             | <u>Dual-band</u> | <u>Single-band</u> |
| A1 channel                  | 5756.0 MHz       | 5794.1 MHz         |
| A2 channel                  | 5281.1 MHz       | 5756.0 MHz         |
| B1 channel                  | 5794.1 MHz       | N/A                |
| B2 channel                  | 5318.9 MHz       | N/A                |

## 2.2.5 Digital Line Interface

|                  |   |
|------------------|---|
| Data Interface   | 100BaseT (fully compatible with IEEE 802.3u)            |
| Connectors       | RJ-45/48c (wire)<br>ST (fiber)                          |
| Remote Loopback  | Internal test signal                                    |
| Configuration    | Half duplex or full duplex on the WAN interface         |
| Filtering        | 15,000 frames per second theoretical, before forwarding |
| Buffer           | 256-frame   |
| LAN Table        | 10,000 MAC addresses                                    |
| Self-learning    | Automatic learning and aging                            |
| Digital Capacity | ~45 Mbps full or half duplex (90 Mbps total)            |

## 2.2.6 Auxiliary Connections

|   |  |
|---|--|
| Orderwire Interface   | 2-wire, 4-pin modular jack, female (RJ-11)                       |
| REN (Ringer Equivalency Number)   | 1.0 B  |
| DTMF tones  | within $\pm 1.5\%$ of nominal freq. (+0-6 dB)                    |
| Ringing Voltage   | 48 VDC, typical  |
| <i>(use telephones with solid state ringers, NOT adequate for older style mechanical ringers)</i> |  |
| VF Orderwire Bridge   | 600 ohm balanced, 4-wire, 0 dBm, DB-9, male                      |
| Diagnostic Port   | RS-232, DB-9, male   |
| Aux Data (clear service channel)  | RS-232, $\leq 9600$ baud, DB-9, female                           |
| Alarm   | 2 x Form C, DB-9, female   |
| Test Points   | Output Power<br>Near-end and far-end received signal level (RSL) |

### 2.2.7 Temperature and Environment

|                             |                       |
|-----------------------------|-----------------------|
| Operating Temperature Range | -15 to +65°C          |
| Humidity                    | 95% non-condensing    |
| Altitude                    | 4,500 meters, maximum |

### 2.2.8 Power

|                       |                             |
|-----------------------|-----------------------------|
| DC Input Voltage      | ±20 to ±63 VDC              |
| Power Consumption     | < 45 watts                  |
| AC Adapter (optional) | 100-250 VAC, 50-60 Hz       |
| Connector             | Barrier strip, plug-in type |



## 2.2.9 Regulatory Information

|                    | Dual-band        | Single-band      |
|--------------------|------------------|------------------|
| FCC Identifier     | HZB-U5358/45     | HZB-U58/45       |
| FCC Rule Parts     | 15.407 (UNII)    | 15.407 (UNII)    |
| Industry Canada ID | TBD              | TBD              |
| IC Rule Parts      | RSS 210 (LE-LAN) | RSS-210 (LE-LAN) |


## 2.2.10 Mechanical

|                                       |  |
|---------------------------------------|--|
| Width (for 19-inch EIA rack mounting) | 437 mm (17.2") rack mounting brackets supplied |
| Height                                | 89 mm (3.5") (2RU)                             |
| Depth                                 | 368 mm (14.5")                                 |
| Weight                                | 5 kg. (11 lbs.)                                |

## 2.3 Front Panel Description

### 2.3.1 General

The *Tsunami* radio front panel, as shown in Figure 2-1, has LED indicators, test points, controls and connections that are used for installation, maintenance, operation and troubleshooting. Prior to installation, it is best to be familiar with the front panel of your particular model. Sections 2.3.2 through 2.3.5 briefly describe the front panel access and indicators.



**Figure 2-1: Front Panel, 2.4 GHz**

## 2.3.2 Test Points / Power Indicator

**ON** This is an LED indication. When lit GREEN, *Tsunami* is powered.



*The Tsunami radio products do not have an on/off switch.*

**GND** This is a test point referenced to chassis ground. This is used in conjunction with the next two test points to measure voltages related to radio performance.

**RSL** This is a test point which relates to the Received Signal Level (RSL). A voltage can be measured with a voltmeter (using the GND test point for reference) which corresponds to the actual power level of the incoming received signal. While the DISPLAY FAR END button is pressed, this RSL voltage corresponds to the RSL of the far-end radio. These measurements are used during installation, maintenance and troubleshooting.

**LOCAL TX PWR** This is a test point which corresponds to the output transmit power of the radio. A voltage can be measured with a voltmeter (using the GND test point for reference) which corresponds to the actual power level of the outgoing signal. This measurement is used during installation, maintenance and troubleshooting



*This voltage only applies to the near-end and does not allow measurement of the far-end output transmit power, even when the DISPLAY FAR END button is pressed.*

There is a receptacle on the front panel to the right of the LOCAL TX PWR test point which is an installation adjustment allowing the output transmit power to be increased or decreased within the radio's specified limits. Using a small screwdriver, this adjustment is used to set the output power of the transmitter, in accordance to the path planning.



*The Tsunami system requires professional installation. Transmitted output power limits may apply when using this radio. Consult FCC, IC, Glenayre Western Multiplex or other regulatory authorities for limits which may apply. See Section 3.13.1 for details on setting output power.*

---

### 2.3.3 Alarm and Status Indicators

- TXD** When lit GREEN, indicates transmitted data is active at the data port.
- RXD** When lit GREEN, indicates received data is active at the data port.
- COLL** This is an alarm. When lit RED, indicates that Ethernet collisions are occurring. These collisions may be normal for a heavily used WAN, but should be remedied as soon as possible as the maximum throughput of the radio link is not being realized. It is normal for the COLL indicator to blink occasionally.
- NMS** This is the network management system alarm. When lit RED, this alarm condition indicates that there is a problem with the connection to the NMS of the Tsunami radio.
- RF LINK** When lit RED, this is an alarm condition indicating that the intended received signal is not being received. This alarm may indicate problems related to the path, connections, or the near-end or far-end radio hardware.
- T1 Input** When lit RED, this is an alarm condition indicating a problem with the wayside T1 connection.
- RADIO FAIL** When lit RED, this is an alarm condition indicating a major failure with the near-end radio hardware. It can also indicate improper connections to the CEPT-1 input port.
- FAR END** When lit RED, this is an alarm condition indicating that there are alarm or status conditions present on the far-end radio. Press and hold the "Display Far End" button on the near-end radios to indicate the alarm conditions for the far-end radio terminal. Monitoring the far-end alarms can be helpful for radio installation and routine maintenance.

---

### 2.3.4 Controls

**DISPLAY FAR END** This push-button provides the capability to determine alarms and status of the far-end radio. When pressed and held, the alarm and status LEDs and the RSL test point correspond to the far-end radio's status and RSL value. This can be used for installation, maintenance and troubleshooting. When the LED on this switch is flashing, no far-end information is available. This typically indicates that there is no link between near-end and far-end radios.

## 2.3.5 Connections

### ELECTRONIC ORDERWIRE (EOW)

This connection is used to access the orderwire function. This is a facility for "telephone" style service from one radio to another. A standard electronic telephone [one with a handset and DTMF (push-button tone) dialing] plugs into this connector. The user can dial the orderwire address of the far-end radio (or any radio in the *Tsunami* network) to establish telephone communication between sites. This communication does not interrupt or interfere with the other radio communications. The radio link must be operational to use this facility. The orderwire feature can be very useful for installation, maintenance and troubleshooting.

- Touch-tone Telephone\* (for communication with far-end)

\*Telephone connection specifications:

|  |                                     |
|--|-------------------------------------|
| REN (Ringer Equivalency Number)  | 1.0 B                               |
| DTMF tones   | within $\pm 1.5\%$ of nominal freq. |
| Ringing Voltage  | 48 VDC, typical                     |
| <i>(Ringing voltage is adequate for modern solid state ringers,<br/>NOT for the older mechanical type ringers)</i> |                                     |

### RF CONNECTION

The RF port of the *Tsunami* radio is an N-type female connector that is an integral part of the filter assembly. The filter assembly occupies nearly the entire top half of the front panel. The N-Type connector is used to connect the antenna, typically using coaxial transmission line. In some cases, waveguide may be used as the primary transmission line, in which case a waveguide-to-N adapter is required.



*For the *Tsunami*, 1/2" or 5/8" coaxial cable (LDF4-50 or LDF4.5-50) is recommended. Coaxial cable that is 7/8" or larger can exhibit moding at 5.8 GHz and is not recommended for 5.8 GHz radios. For waveguide transmission line at 5.8 GHz, EW-52 waveguide is recommended. EW-63 will also work, but may exhibit more loss.*

### DATA CONNECTION

The connection for the Fast Ethernet interface that carries the signals in and out of the radio is a RJ45 100BaseT wire connection or ST 100BaseT fiber connection.

---

## AUXILIARY CONNECTIONS

There are 6 auxiliary data connections for *Tsunami* as shown in Figure 2-3.

**VF** This connector is used to link two *Tsunami* radios at a repeater site for Orderwire operation. This would allow orderwire "telephone" calls to and from any point in the *Tsunami* network.



*The Tsunami orderwire circuit can also be connected to other existing orderwire networks. See Section 3.14.1 for details.*

**ALARM** This connector is used for monitoring alarms electrically. The Form C relays can be connected to other transmission equipment for monitoring alarm status locally or remotely.

**CONFIG** This is a serial interface port (RS-232 to the *Tsunami* radio. This port provides configuration and maintenance information about the *Tsunami* radio(s) to a connected computer or terminal.

**AUX DATA** This is a serial interface port (RS-232, ≤9600 baud) which allows the user to connect auxiliary serial data from one point in the radio network to another. It can be used for separate data connection for serial devices.

**10BaseT NMS** This is an Ethernet connection for access to the *Tsunami* NMS (SNMP/HTML).

**T1** This is a wayside data channel for T1 (DS-1) interface of auxiliary traffic.

## 2.4 Rear Panel Description

The *Tsunami* radio rear panel, is blank. All connections and indications are on the front panel for "single panel" access



---

## 2.5 Installation Accessories

The *Tsunami* radio is shipped with several accessories commonly required for the radio as described below:

|                                  |   |
|----------------------------------|---|
| <b>AC Power Supply</b>           | If ordered as an option, this power supply provides AC to DC conversion for use with AC powered locations.  |
| <b>AC Power Cord</b>             | This power cord connects the AC Power Supply, if ordered, to a standard 115V U.S. AC outlet.  |
| <b>Rack Mount Brackets</b>       | Two brackets (along with required mounting screws) are provided which allow 19-inch rack mounting of the <i>Tsunami</i> radio.  |
| <b>Terminal Connector</b>        | This is a 6-pin mating connector used for DC power supply.  |
| <b>D Connector 9-pin</b>         | Four of these mating connectors are provided. One is used for the VF port, one for the CONFIG port, one for the ALARMS port and one for the AUX DATA port.            |
| <b>RF Power Adjustment Cover</b> | A small plastic cap is provided which is placed over the RF output power adjustment receptacle once output power has been set by professional installation personnel. |

Other accessories are available, such as orderwire handsets, connector adapters and special cables. These can be ordered separately upon request.



## 3. Installation & Adjustments

### 3.1 Shipping Container

The equipment is shipped in boxes unless ordered as an integrated system and configured at the factory, in which case the equipment may be racked and shipped in a crate. The equipment is packaged so as to prevent damage in transit.

**The boxes should be left intact and sheltered until arrival at the installation site.**



*If the shipping container shows signs of damage, the transportation company should be notified immediately. Extra care and inspection of the contents is advised immediately upon receipt.*



***It is recommended that all the packaging materials be retained.*** In the unlikely event that the equipment must be returned to the factory, use the original packing materials for return shipment. ***The original packaging materials are also recommended for transporting the equipment from location to location.***

Inside the primary shipping containers, internal boxes may contain other items. These boxes should also be saved for future use.



*Also, save the Tsunami radio test data sheet that is provided. The test data sheet can be placed where the Tsunami terminal will be installed for future quick reference. This sheet could also be placed in the front pocket of this manual, and the manual kept at the radio location for future reference. All Tsunami units are individually tested and the actual measured performance recorded on the Factory Test Data Sheet. You will find this information to be of use during installation, troubleshooting and maintenance.*

A set of quick installation instructions is also provided which can be useful for easy reference during installation.

## 3.2 Packing Items Identification

The primary shipping container houses the radio along with other items including:

- ❖ This manual
- ❖ Installation accessory kit (see Section 2.5)

---

### 3.3 Before Installation Task List

There are several tasks that should be accomplished prior to installing the *Tsunami* radio system. This section briefly describes the following:

- Site selection
- Line-of-Sight and Path Clearance determination
- Anticipated RSL calculation
- Fade margin calculation
- Availability calculation
- Frequency plan determination
- Power supply planning
- Antenna (and accessories) purchase



*Only directional antennas should be used with Tsunami radios. These are typically flat panel or solid parabolic antennas. Glenayre Western Multiplex recommends a maximum beamwidth of 10 degrees for directional systems.*

#### 3.3.1 Site Selection Requirements

The radio site must have:

- access to the appropriate power
- close proximity to the telephone or computer system you wish to interconnect
- line-of-sight to the other radio location with adequate clearance
- location for mounting the antenna

### 3.3.2 Line-of-Sight and Path Clearance Guidelines

The *Tsunami* radios will not operate properly unless they have line-of-sight between their corresponding antennas. The *Tsunami* radio transmission will not pass through trees or other obstacles. Factors to consider include:

- Earth curvature
- Future growth of trees
- Height of buildings

In addition to the line-of-sight requirement, a well-engineered path will also have additional path clearance to allow for signal loss due to partial obstructions, atmospheric ducting and ground reflections. To maximize radio reception, 0.6 times the first Fresnel zone should be calculated and this distance added to the path clearance (in addition to trees or buildings).

### 3.3.3 RSL Calculation and Link Budget

The received signal level (RSL) can be estimated using the following formula:

$$\text{RSL (dBm)} = P_{\text{out}} - FL_1 + G_1 + G_2 - FL_2 - L_p$$

where:  $P_{\text{out}}$  is the transmitter output power (in dBm)

$FL_1$  is the feeder loss of the transmit side (in dB)

$G_1$  is the gain of the transmit antenna (in dB)

$G_2$  is the gain of the receive antenna (in dB)

$FL_2$  is the feeder loss of the receive side (in dB)

$L_p$  is the Path loss, defined by:

$$L_p \text{ (dB)} = 96.6 + 20 \log_{10} F + 20 \log_{10} D$$

where:  $F$  = Frequency in GHz (2.4 or 5.8)

$D$  = Distance of path in miles

This link budget is very important for determining any potential problems during installation. If you have calculated the expected RSL, you can see if it has been achieved during installation, and troubleshoot if necessary.



*In the USA and Canada, Tsunami radios may be installed with any gain directional antennas but with a total system limit of +30 dbm EIRP for the 5.3 GHz transmitter channel frequencies. 5.8 GHz transmitters have an EIRP limit of +53 dBm. For the equation above, replace the  $P_{\text{out}} - FL_1 + G_1$  by the EIRP limit.*

### 3.3.4 Fade Margin Calculation

The fade margin is the difference between the actual received signal and the radio's threshold. Using the formula provided in Section 3.3.3, the anticipated RSL can be calculated. Compare this RSL to the specified threshold of the *Tsunami* radio (shown in Section 2.2) and calculate the fade margin as the difference between the two signal levels.



---

### 3.3.5 Availability Calculation

Availability of the microwave path is a measure of the percent of the time that the link will operate without producing an excessive BER due to multipath fading. In the absence of direct interference, availability is affected by the following:

- Path length
- Fade margin
- Frequency (5.3 or 5.8 GHz in the case of these *Tsunami* radios)
- Terrain (smooth, average, mountainous)
- Climate (dry, temperate, hot/humid)

Depending on the type of traffic carried over the link, the system designer may wish to design for a specific availability. For example, if the data or voice traffic that is carried by the radio is critical then it may be designed for a very high availability (e.g. 99.999% or 5.3 minutes of outage per year). To improve availability, for example, the fade margin can be increased by making the path shorter, or by using higher gain antennas in conjunction with lower loss feeders (by using high quality transmission line or shortening feed length).

### 3.3.6 Frequency Plan Determination

When configuring radios in a hub or repeater configuration, careful engineering of the *Tsunami* radio frequency plans and antenna locations should be performed in order to minimize potential interference between the nearby radios. As a rule of thumb, do not place identical frequency plan radios (e.g. two "A" channel radios) at the same site. In most cases, it is desirable to use a different frequency plan (e.g. A versus B). However, with careful engineering, placing more than one radio of the same frequency channel plan at the same site is easily accomplished. In fact, the *Tsunami* frequency plan is designed to allow complex hub configurations that may require re-using the same frequency plan. When designing these types of configurations, antenna size and antenna location are critical. If identical channel plans must be used at the same site, the same radio channel (e.g. A1 and A1) should be used at a site to minimize interference. Using alternate channels (e.g. A1 and A2) is less likely to be successful (and therefore not recommended) due to the high level of transmitter to receiver isolation required from the antenna system.

Sometimes it is required to locate the *Tsunami* radio nearby a transmitter that is the same as, or close to the *Tsunami* receive or transmit frequencies. In this case, the *Tsunami* terminal that should be placed closest to this interfering transmitter should be the specific terminal with the receive frequency which is furthest from this unwanted transmitted frequency. This approach minimizes the potential of interference. While interference conditions are rare when using the *Tsunami* radios, cases of interference may be overcome by exchanging the radios from end to end or simply reinstalling a different filter unit (if applicable), as described in Section 4.2. In some cases, changing frequency plans (e.g. from A to B) can also help mitigate any interference.



*Section 4.8 of this manual describes interference countermeasures in further detail.*

---

### 3.3.7 Power Supply Planning

The *Tsunami* radio must have access to a supply of appropriate power, either DC or AC (if the AC adapter option has been ordered). The *Tsunami* can be powered from a DC battery system, or from a solar or generator power plant, usually with battery reserves. Typically either a positive or negative ground 24 or 48 volt supply is used. For DC, be sure the cable is of sufficient gauge to carry the necessary current and it is less than three (3) meters (9.75 feet) in length.

Before installing the radio, plan for the continuous power consumption needs in accordance with the specifications given in Section 2.2 of this manual. It is also wise to plan for backup power for critical communication circuits (including the *Tsunami* radio). Backup power allows the radios and associated equipment to continue operation when primary power is interrupted.

### 3.3.8 Antenna Planning

Using path planning mathematics, proper antenna size can be determined which will yield the desired path performance. In general, the larger the antenna that is used with the *Tsunami* radio, the better the link will perform. Larger antennas have narrower beamwidth and higher gain, which will yield better link performance (higher fade margin, better availability) and improve immunity to interference (due to the smaller beamwidths). However, larger antennas are more costly to purchase and install than smaller antennas, in some cases requiring special equipment for installation. All of these factors should be taken into consideration when selecting antennas.



*In areas where transmitted output power restrictions apply, the use of larger antennas will maintain the benefit of narrow beamwidths and receive gain. However, output power may need to be reduced to meet regulations. (See Section 3.13.1)*

Prior to installation, the specific antenna location and mounting should be determined. This advanced planning also yields the transmission line requirements.



*Only directional antennas should be used with *Tsunami* radios. These can be flat panel or solid parabolic antennas.*

### 3.4 Tools Required

The following tools may be required for the installation of the *Tsunami* radios:

- Phillips (cross tip) screwdrivers (for 19-inch rack mounting and attachment of brackets)
- Small blade standard screwdriver (for power supply connector and RF output power adjust)
- Soldering iron (if using any D-type connectors)
- Wire strippers (for removing insulation from power supply and other wiring)
- Wire crimpers (if using any RJ-style connectors that aren't pre-made)
- Digital Voltmeter (to measure RSL, Tx output power, Alarms)

The following tools are recommended for the installation of the *Tsunami* radios:

- RF power meter (to measure transmitter output power)
- Cellular phone or two-way radio (for talking with far-end crew and tower crew)
- Bit Error Rate test set (to test link after installation)
- Computer (for Craft Port or NMS access)
- Touch-tone Telephone\* (to test orderwire circuits and for communication with far-end)


Additional tools will likely be needed for antenna and transmission line installation and antenna alignment. Consult Sections 3.8 through 3.10 of this manual for more details.

\*Telephone connection specifications:


|  |                                     |
|--|-------------------------------------|
| REN (Ringer Equivalency Number)  | 1.0 B                               |
| DTMF tones   | within $\pm 1.5\%$ of nominal freq. |
| Ringing Voltage  | 48 VDC, typical                     |
| <i>(Ringing voltage is adequate for modern solid state ringers,<br/>NOT for the older mechanical type ringers)</i> |                                     |

### 3.5 Frequency Channel Plans

The *Tsunami* system offers non-overlapping channel plans. This channel plan arrangement allows users to implement *Tsunami* systems in the proximity of other *Tsunami* radios (planned or unplanned), hub and repeater applications, and can be used to mitigate interference. The channel plans are illustrated below in Figures 3-1 through 3-2. Section 4.2 and 4.3 describe how to change frequency channel assignments of a *Tsunami* radio.



**Figure 3-1: Channel Plans, Dual-Band**



**Figure 3-2: Channel Plan, Single-Band**

### 3.6 Mounting the *Tsunami*

The *Tsunami* radio can be mounted at any height in a standard 19-inch rack. Blank rack-mounting spaces above and below the *Tsunami* are recommended, especially if the surrounding equipment dissipates a considerable amount of heat (over 40W).

The *Tsunami* radio may be set up for mounting with the front edge projecting from the front face of a standard 19-inch rack using the rack mounting brackets enclosed with the screws in the Accessory Kit (4 per bracket). The rack mounting brackets may be reversed, in order to install for flush or cabinet mounting if preferred. Depending on rack configuration, it may be necessary to remove the four adhesive backed rubber feet on the bottom of the unit.



***The *Tsunami* radio has internal fans which intake and exhaust on the left and right sides of the chassis. When rack mounting, it is important to leave a small gap between the outer edges of the radio and the inside edge of the rack.***



***The *Tsunami* radio may alternatively be placed on a table or shelf attached to a wall. Because of the low weight of the *Tsunami*, any mounting option other than rack mounting will be less secure.***

### 3.7 Power Connection and Wiring



*There is no ON/OFF switch on the Tsunami. As soon as power is applied, the equipment will be operational. This means that there can be up to 1W of RF power present at the antenna port. The antenna port should be terminated before power is applied.*

Power is connected using the DC power plug contained in the Accessory Kit. Use Table 3-A or 3-B along with the associated diagram of Figure 3-3 or 3-4 to connect the DC power cables. For example, for a negative DC power input, use Table 3-A and Figure 3-3.

| NEGATIVE DC POWER INPUT<br>(-20 TO -63 VDC) |                         |
|---|-------------------------|
| PIN   | FUNCTION                |
| 1   | Power (-DC)             |
| 2   | Ground (see figure 3-7) |
| 3   | Return (+DC)            |
| 4   | Return (+DC)            |
| 5   | Ground (see figure 3-7) |
| 6   | Power (-DC)             |

**Table 3-A: DC Power Connection for Negative Supply**

| POSITIVE DC POWER INPUT<br>(+20 TO +63 VDC) |                         |
|---|-------------------------|
| PIN   | FUNCTION                |
| 1   | Return (-DC)            |
| 2   | Ground (see figure 3-8) |
| 3   | Power (+DC)             |
| 4   | Power (+DC)             |
| 5   | Ground (see figure 3-8) |
| 6   | Return (-DC)            |

**Table 3-B: DC Power Connection for Positive Supply**



*Pins 1 and 6 are connected together on the motherboard. Either pin may be used to apply (-DC) DC power input. Similarly, pins 3 and 4 are connected together on the motherboard and may be used to apply (+DC) DC power input.*



*For DC power return connection, connect to the opposite voltage (either the -DC or the +DC Pin) and connect the return to ground at the DC power plug on pins 2 and/or 5.*



### 3.7.1 DC Power Wiring

Connect the power cable with adequate current rating (minimum of 20 AWG) to the terminals shown on the removed (not plugged into the radio) DC power plug using the screw connections. The recommended minimum current rating of external fuses and cables is 3 Amps. The *Tsunami* radios consume less than 1 Amp at  $\pm 48V$  and less than 2 Amps at  $\pm 24V$ . Be sure the DC power cable is less than 3 meters (9.75 feet) in length.



*Each Tsunami terminal should be externally fused separately with a 5 Amp maximum fuse. The DC power cable must be less than three (3) meters in length.*

If using **negative** power, connect the negative voltage to pins 1 or 6. Connect the ground return connection to pins 3 or 4. See Figure 3-3.

If using **positive** power, connect the positive voltage to pins 3 or 4. Connect the ground return connection to pins 1 or 6. See Figure 3-4.

The **ground** connection is available at pins 2 and 5. Either pin may be used to ground the return side of the power supply. Do not ground both sides of the power supply.



*Proper grounding, either through the chassis and/or the power supply, can be very important for protection from lightning. A grounding screw hole is provided on the rear panel.*




*The ground connection may be left floating if the power supply is referenced to ground externally and to avoid ground loops in some configurations. However, this may not provide adequate grounding for lightning protection.*


Use a DVM (digital voltmeter) to verify voltage and polarity on the DC power plug.



*Do not connect the DC power plug to the rear of the Tsunami terminal until a load is connected to the antenna port (either an RF pad, or an RF cable and antenna).*



**Figure 3-3: Negative Voltage DC Connection**



**Figure 3-4: Positive Voltage DC Connection**



*Make sure that when connecting the mating plug that it is properly oriented (terminal screws pointing up) and securely fastened.*

### **3.7.2 AC Power Connection**

The optional AC power supply operates from any AC voltage 100V - 250V and 50 Hz or 60 Hz. The AC supply is equipped with a mating connector that plugs directly into the *Tsunami* radio and an AC cord with a 3-pin AC plug. The AC cord color code is shown in Figure 3-5 in case users wish to replace the AC plug supplied with a different type of plug.

Diagram TBD

**Figure 3-5: AC Connection**

### 3.8 Antenna Connection

The *Tsunami* radio is equipped with an N-type female connector at the antenna port located on the rear panel. A short length (~6 feet) jumper cable such as RG-214 coax (or “pigtail”) fitted with two N-type male connectors can be used to connect the antenna port to the antenna transmission line (see Section 3.9). The recommended cable type for a jumper is RG-214.

A low loss 50-ohm cable (for example LDF4-50 1/2 inch coax) or EW-52 waveguide is recommended for the antenna transmission line between the top of the rack and the antenna. The return loss presented by the transmission line at the top of the rack should be as high as possible (20 dB, minimum recommended). The length of the antenna transmission line should be kept as short as possible (to minimize losses).

To minimize feeder losses, the use of elliptical waveguide is recommended (typical loss is 1.25 dB/100 ft) for feeder lengths in excess of 200 feet. Depending on path length and feeder length, 1/2 inch or 5/8 inch coax cable can be used.



*For the Tsunami radio, 1/2” or 5/8” coaxial cable (LDF4-50 or LDF4.5-50) is recommended. Coaxial cable 7/8” or larger can exhibit moding at 5.8 GHz and is not recommended for 5.8 GHz radios. For waveguide transmission line at 5.8 GHz, EW-52 waveguide is recommended. EW-63 will also work, but may exhibit more loss.*



*Do not use right angle N-type connectors with the 5.8 GHz Tsunami radios: they may present high loss at 5.8 GHz. Do not use a low quality N-type jumper cable with the Tsunami. Some cable types, such as RG-8, may have high loss at 5.8 GHz.*

### 3.9 Transmission Line Connection

The transmission line feeder (such as LDF4-50 1/2 inch coax cable or EW-52 elliptical waveguide) should be prepared first by cutting to the approximate length (allowing some excess) and installing the appropriate connector on the antenna end.

The prepared transmission line is then pulled through the cable ducts, trays or conduit (as required) to the antenna, while being careful not to kink or damage the transmission line in any way.

The transmission line should be supported in a tray on horizontal runs and by hangers on vertical runs. Hangers should be spaced according to the manufacturer's instructions (typically every 5 feet under conditions of no ice and not greater than 85 mph winds).

The transmission line should be grounded using the manufacture's recommended grounding kit. Grounding kits attach to the outer copper conductor. Grounds must be installed at the antenna, at the bottom of the tower (if applicable) and where the transmission line enters the building. Long transmission line runs should be grounded every 100 feet. In areas of high incidence of lightning, dissipaters should be attached to antennas. In addition, coaxial, in-line, spark-gap type, lightning suppressors should be added at the bottom of the coax cable before entering the building/enclosure.



*Any in-line lightning protection device must be rated for the operating frequency of the Tsunami (5.3/5.8 GHz).*

After installation, the transmission line is terminated with an N-type male connector/adaptor attached at the equipment end. For waveguide, this typically requires a CPR-to-N adapter. Prior to operation, the electrical integrity of the transmission line, including all connectors, can be checked with a simple DC check between the center conductor and outer conductor. (This is neither possible, nor required for waveguide).

The transmission line should ideally be connected directly to the antenna at one end and to the Tsunami antenna port at the other end. However, short RG-214 type pigtail jumper cables may be required to avoid sharp bends in the transmission line to limit stress on either connection.



*7/8 inch coax cable or larger is not recommended for use at 5.3 GHz and higher frequencies.*



*Do not use right angle N-type connectors with the 5.3 or 5.8 GHz Tsunami radios: they may present high loss at 5.3 or 5.8 GHz. Do not use a low quality N-type jumper cable with the Tsunami. Some cable types, such as RG-8, may have too high a loss at 5.3 and 5.8 GHz.*

### 3.10 Antenna Installation & Alignment



Due to the possibility of exposure to RF radiation above the recommended levels, do not stand within two (2) feet of the antenna for prolonged periods during system operation. It is the responsibility of the installer to insure that the antenna is mounted in a place that is not accessible to the public.

The antenna installation consists of mounting the antenna on the tower, building roof, or other location that provides line-of-sight path clearance to the far-end location. In general, antennas smaller than 2 feet diameter are not recommended for urban areas due to their wider beamwidths, which results in higher interference susceptibility.

Antennas should be ordered with a suitable mounting kit specific to the site requirements. For example, specifying round or angle tower leg adapters, or a roof tripod as necessary.

If the antenna is to be mounted indoors, "looking" through a window, it is recommended that the antenna be placed approximately 12 inches away from the glass and within 10 degrees of a right angle to the glass. The glass should be lead-free or very low-lead content type and avoid any metallic glass coatings for best results.

The antenna must be very rigidly mounted, with adequate room for azimuth and elevation adjustment.

The antenna polarization must be the same at both ends of the link, either vertical or horizontal.

In general, antenna mountings require a support pipe to which upper and lower support brackets are attached with "U" bolts. The antenna and optional elevation and azimuth adjustment rods are then mounted onto the support brackets. The whole structure must be adequately grounded for lightning protection. The antenna system must always be installed according to the manufacturer's instructions.

Unless special test equipment is available, two operating *Tsunami* terminals are required to align the antennas. Alternatively, a CW generator may be used to transmit a signal toward the end under alignment.

The antenna is coarse aligned using visual sighting and then fine aligned using the receive signal level (RSL) voltage of the *Tsunami*.



*The RSL voltage reading can still be used to peak antennas even if the radios have not synchronized, however far-end RSL cannot be measured from the near-end terminal until radios are synchronized.*

To coarse align the antenna, first set it for flat elevation (no up or down tilt) using a spirit level. Then point it at a heading marker obtained using a compass back-bearing from an adjacent location, (ideally, 100 feet or more away from the antenna).

If a heading marker cannot be set sufficiently far away (for example when on a city building roof or looking through a window) then a rough azimuth setting can be obtained by sighting along the antenna feed.



*It should be verified that both antennas are on the same polarization by using the manufacturer's instructions. Otherwise the RSL will be approximately 25 to 30 dB below the calculated level.*

Most antennas will also need fine alignment obtained using an operating link because it is very important to maximize the receive RF signal level at each end of the radio link.



*Read Section 3.7 before applying DC power to the Tsunami radio.*

Once the coarse alignment has been set-up at both ends, then the link can be powered and some level of reliable communication established. The voltage at the *Tsunami* front panel RSL test point should be measured with a DVM to determine the relative receive RF signal level.

For the fine alignment, adjusting first the azimuth and then the elevation of the local antenna will maximize the RSL voltage. Then, the far antenna is aligned in the same way, using the RSL voltage of its local *Tsunami* radio.

When aligning antennas it may be convenient to run two wires from the RSL and ground test points to the antenna so that the voltmeter reading is directly visible to the technicians aligning the antenna. Also, a cellular telephone or two-way radio may be useful for coordinating alignment activities between both ends of the link. Once the radios are coarse aligned and synchronized, the built-in orderwire phone service can also be used to coordinate alignment between both ends of the link.



*An orderwire telephone will provide end-to-end voice communications once radios are synchronized. Synchronization usually can be accomplished by coarse alignment only. After synchronization, the orderwire phones can be used to communicate between radio sites for antenna fine alignment. The phone interconnect cable can be extended to the antenna when desired.*

The larger the antenna size, the more critical alignment becomes: for example, with a 2 foot dish, the antenna can be moved  $\pm 3$  degrees off the correct heading before the receive signal level drops by 3 dB. This compares with a 6-foot dish which may only be moved  $\pm 1$  degree for the same degradation.

The graph shown in Figure 3-6 shows the typical variation of RSL voltage as the receive signal level is increased from threshold to a higher level. There is some variation between *Tsunami* receivers, but an approximate estimate of the potential RSL value may be made using this figure.




*Use the Factory Test Data Sheet shipped with your Tsunami terminal to obtain the best estimate of your RSL.*

Above 0 dBm RSL, the receiver may produce errors: however this level is rarely likely to be exceeded. A link budget calculation should be made to calculate the anticipated RSL as described in Section 3.3.3. During anomalous propagation conditions, the RSL may fade but will not increase up more than 10 dB (except in unusual very long paths which may fade up by 15 dB).



Antenna alignment should enable the RSL to be peaked to the level calculated in the link budget. If the RSL is peaked but is approximately 20 dB below the calculated level, then it is likely that the antennas are aligned on a sidelobe of the antenna's radiated signal. In this case, the antennas should be rotated in a wide arc until the main lobe is located. (Other possible causes of low RSL are path obstructions, loss in connectors, adapters and pigtail jumper cables or different antenna polarization at each end of the link.)



**Figure 3-6: Typical RSL Voltage versus Received Signal Level (RSL)**



---

### 3.11 Ethernet Interface Connection

The 100BaseT interface connection to the *Tsunami* radio is on the front panel.



*Additional external lightning protection devices are recommended for the connections if the radio is installed in an area prone to lightning.*

The 100BaseT connection to the *Tsunami* is at the data interface on the front of the shelf. Either wire or fiber connections can be used.

### 3.12 System Turn-up to Service

1. Prior to installing the system, it may be desirable to perform a back-to-back test of the *Tsunami* radio pair. Consult Section 4.9 for further details. Back-to-back testing is a simple way to verify that the *Tsunami* radios are fully operational before they are installed. Installation adds several variables (such as antenna alignment) which can lead to system turn-up delays. Also, during back-to-back testing, the DIP switch settings and some connections can be tested. This step can eliminate a majority of troubleshooting once the radios are installed.



*A cellular phone or two-way radio system (walkie talkie, CB, mobile radio) can be very useful during installation. These can be used for temporary near-end and far-end communications between the installation personnel at one site and installation personnel at the other site while installing the system. These can also be helpful for communication between a person at the top of a very tall tower and ground personnel.*



*The *Tsunami* radio incorporates an internal Orderwire feature that provides end-to-end “telephone” style communications. However, the link must be partially operational to use this feature. In lieu of, or in addition to the use of cellular phones or two-way radio, this Orderwire feature can also be very useful for installation, but typically cannot be put into service until step 8 or 9 of this procedure is completed. See Section 3.14.1 for more details.*

2. Perform a general alignment of the antennas on both ends of the path using binoculars, compass or other related tools. It is important to have the antennas aligned as accurately as possible before putting radio traffic over the link. This will help in getting the system running more rapidly. See Section 3.10 for more details.
3. Connect the transmission line to the antenna, and feed it to the *Tsunami* radio location (see Section 3.9). Connect the opposite end of the transmission line to the N-type female connector located on the filter assembly which occupies the top half of the *Tsunami* rear panel. The connection must be terminated into an antenna or a load before DC power is applied to the radio.
4. Verify that the same channel plan (e.g. A, B) as the near-end radio, and the opposite Tx and Rx frequencies (e.g. A1 and A2 make up a matched pair of radios).
5. With the DC power source active, but not plugged into the *Tsunami* radio, using a voltmeter, confirm that the DC mating connector has the proper power connections in accordance with Section 3.7. Verify the polarity and the absolute voltage on all pins. Verify ground connection for power.
6. Connect power to the *Tsunami* radio. Verify that the Front Panel “ON” LED indication is illuminated. This confirms that power has been properly applied.



*Ensure that the RF Antenna port connection is properly terminated before applying power to the Tsunami terminal, as in step 3.*




*When the Tsunami radio is initially powered-on, some alarm conditions may be present. This is normal and alarms can be ignored at this time.*

7. Place a voltmeter across the GND and PWR front panel test points. See Figure 3-7 for voltage setting information and Table 3-C for typical output power levels for given cable lengths where EIRP limits apply. If necessary, use a small screwdriver at the front panel receptacle to adjust the output power of the local transmitter in accordance with the path analysis calculations. The recessed potentiometer is rotated clockwise to increase transmit output power and counter clockwise to decrease transmit output power. After verifying correct setting of the transmit output power, disconnect the voltmeter. Place the cover cap found in the installation accessory kit over the front panel receptacle.



*The Tsunami radio requires professional installation. With some Tsunami models, in certain countries, there may be Effective Isotropic Radiated Power (EIRP) limits which dictate the maximum output power that the Tsunami radio can transmit given the transmission line loss and the gain of the antenna. Consult with appropriate government agencies or Glenayre Western Multiplex if there is any question regarding maximum output power allowed.*



**Figure 3-7: Typical RF Output Power versus PWR Voltage**



*Use the Tsunami Factory Test Data sheet to determine more precisely the voltage corresponding to the RF output power.*



*For precision measurement of transmit output power, it is best to connect an RF power meter to the antenna port. The PWR port voltage may not provide enough precision. This is especially important where EIRP limits apply to the installation.*



*In cases of no EIRP limits, the radio transmitter output power can be adjusted to maximum for installation, except for very short paths using very high gain antennas, where excessive power may not be advised.*



*Don't forget that the RF output port should be terminated at all times when power is applied to the Tsunami radio. Therefore, disconnect power to the radio before connecting a power meter and reapply power once connected. Often, an RF power meter may have a limit to the input power that it can measure without damage. It is advised to place a calibrated fixed value RF attenuator (typically 20 dB or more) between the Tsunami radio and the power meter to assure proper operation and safety for the RF power meter. The value of this fixed attenuation can then be added to the value of the RF power meter reading to obtain the actual Tsunami radio transmitter output power.*

8. Connect a voltmeter across the GND and RSL front panel test points. This voltage reading corresponds to the Received Signal Level (RSL) of the near-end radio. In other words, RSL is the “amount” of signal the near-end radio is receiving from the far-end radio. Since the antennas have not been finely aligned, it is not expected at this time that the RSL will read very high. However, at this point it can be verified that some communication is taking place between the two *Tsunami* terminals. Use the RSL voltage reading to align the antennas. Align one antenna at a time in accordance with Section 3.10. Complete alignment of both ends of the radio link before going further.



*The RSL voltage output on the radio's front panel will output a voltage range over the full receiving capability of the radio (approximately 10 VDC at 0 dBm to 0.0 VDC at threshold).*

The *Tsunami* radio has a unique feature of allowing measurement of the far-end RSL from the near-end radio. This is only possible if the *Tsunami* radios are communicating (the RSL is above threshold). The far-end RSL can be used to verify that adjustments to local antenna alignment are corresponding to the far-end radio reception. Far-end RSL is measured by pressing and holding the DISPLAY FAR END front panel button. While this button is held, the RSL voltage indicates the RSL of the far-end radio. RSL of both ends should be verified to be within approximately 2 dB of predicted value (see Section 3.3.3). There are several factors that can contribute to low RSL:

- Incorrect antenna alignment (aligned on a lobe and not on the main signal)
- Improper polarization alignment of antennas (horizontal vs. vertical)
- Transmission line problems (loose connections, bent or damaged cables, lossy adapters)
- Path obstructions (trees, buildings, hills, etc.)
- Path clearance (line-of-sight, earth curvature, Fresnel zone, diffraction and partial obstruction)
- Weather (inversion layers, ducting and multipath)

- Antenna feed (coaxial/connector) problem



*The Tsunami radio requires professional installation. Don't forget that the transmitter output power adjustment on the Tsunami radio effects the RSL. Depending on EIRP limits (if any), path distance, and antenna gain, you may need to adjust the output transmit power to the proper level before putting the radios in service.*



*If radio synchronization has been established, the radio link may be able to provide some limited communications over the link. It can be helpful to establish voice communications from one end of the radio link to the other using the Orderwire feature of the Tsunami radio. See Section 3.14.1 for details.*

If RSL is lower than anticipated, recheck the path clearance and transmission line as these are the typical causes of low RSL. Radio operations can be verified by connecting radios back-to-back with attenuators (40-60 dB), (see Section 4.9). If the problem remains, consult Section 4 of this manual for troubleshooting techniques which will help determine the source of the problem.

9. Once radio performance is verified and acceptable, the *Tsunami* radios can now be put into service with the intended Fast Ethernet traffic. Connect to the LAN or computer using the RJ45 (wire) or ST (fiber) 100BaseT connector. With Fast Ethernet traffic applied in both directions, all front panel LEDs, except for POWER and the data TXD/RXD lights should be off. If any other LEDs are on, consult the trouble shooting sections of this manual.
10. Now that the link is operational, other services can be connected including Orderwire, Diagnostics, Alarms and Aux Data (Service Channel). Consult Section 3.14 for details on these connections.

|                      |                    | TRANSMITTER POWER (dBm) |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
|----------------------|--------------------|-------------------------|----------|---------|----------------------|----------|---------|----------------------|----------|---------|---------|----------------------|----------|---------|---------|
| Feeder Length Meters | Feeder Length Feet | A/B Chan., 1/2" Coax    |          |         | A/B Chan., 5/8" Coax |          |         | C Channel, 1/2" Coax |          |         |         | C Channel, 5/8" Coax |          |         |         |
|                      |                    | 1' Panel                | 2' Panel | 1' Dish | 1' Panel             | 2' Panel | 1' Dish | 1' Panel             | 2' Panel | 1' Dish | 2' Dish | 1' Panel             | 2' Panel | 1' Dish | 2' Dish |
| 3.0                  | 10                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 6.1                  | 20                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 9.1                  | 30                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 12.2                 | 40                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 15.2                 | 50                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 18.3                 | 60                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 21.3                 | 70                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 24.4                 | 80                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 27.4                 | 90                 |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 30.5                 | 100                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 33.5                 | 110                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 36.6                 | 120                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 39.6                 | 130                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 42.7                 | 140                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 45.7                 | 150                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 48.8                 | 160                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 51.8                 | 170                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 54.9                 | 180                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 57.9                 | 190                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 61.0                 | 200                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 64.0                 | 210                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 67.1                 | 220                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 70.1                 | 230                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 73.2                 | 240                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 76.2                 | 250                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 79.2                 | 260                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 82.3                 | 270                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 85.3                 | 280                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 88.4                 | 290                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 91.4                 | 300                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 94.5                 | 310                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 97.5                 | 320                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 100.6                | 330                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 103.6                | 340                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 106.7                | 350                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 109.7                | 360                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 112.8                | 370                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 115.8                | 380                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 118.9                | 390                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |
| 121.9                | 400                |                         |          |         |                      |          |         |                      |          |         |         |                      |          |         |         |

This chart not yet available;  
 will be completed prior to  
 first product shipment.

**Table 3-C: Transmitter Output Power Adjustment, 0 dBW (5.3 GHz) and +23 dBW (5.8 GHz) EIRP Installations**  
 (As apply to the in US and Canada)

### 3.13 Output Power Adjustment

The *Tsunami* radio requires professional installation. In certain cases, it is necessary to adjust the output power from the factory setting, for example:

- ❖ to meet EIRP (effective isotropic radiated power) limits.
- ❖ to avoid exceeding the maximum far-end RSL of 0 dBm.
- ❖ to coordinate a hub or repeater location.



*To ensure maximum protection of the radio circuits, always ensure the antenna connector is terminated when power is applied.*

For precise measurement of transmitter power, a calibrated RF power meter (such as the HP 435B with Power Sensor HP8481) is recommended. This power sensor can be connected directly to the output of the radio without exceeding the power rating. With some power meters, it may be necessary to place a calibrated in-line fixed attenuator between the radio antenna port and the power meter so as to not exceed the power meter's maximum input level. Thru-line power meters do not operate at *Tsunami* RF frequencies.

If adjusting the output power to meet an EIRP limit, it will be first necessary to calculate the overall system gains and losses, including feeder losses for the type of transmission line installed and the antenna gain. Also refer to Table 3-C for transmitter output power settings where installed with various transmission line lengths and antenna sizes. You may determine the radio transmit power for EIRP limited installations by the following equation:

$$\text{Tx Power (dBm)} = \text{EIRP Limit(dBm)} + \text{Feeder Loss(dB)} - \text{Antenna Gain(dB)}$$



*For the US and Canada, a +30 dBm EIRP limit applies for channels A and B of these *Tsunami* radios. A +53 dBm EIRP limit applies for channel C.*

Output power may be adjusted using a small screwdriver and rotating the potentiometer which is recessed behind the front panel. Clockwise rotation increases output power while counter-clockwise rotation decreases output power.

In lieu of a calibrated RF power meter, the PWR test port voltage can be used to estimate the output power. Figure 3-7 illustrates the voltage reading for various output power levels. The factory test data sheet should be used to establish a more precise setting of this adjustment.



*After setting the correct output power, place the cover cap found in the installation accessory kit over the front panel receptacle.*



## 3.14 Additional Connections

There are additional customer connections which are optional and are **not required** to make the *Tsunami* operational but may prove useful.

### 3.14.1 Orderwire Connection

Orderwire is a “telephone” type wayside service which allows users of the *Tsunami* radio to establish voice communications from one radio to another, either directly to the companion far-end, or through a repeater configuration, or several repeater configurations.

#### Telephone connection specifications:

|  |                                     |
|--|-------------------------------------|
| REN (Ringer Equivalency Number)  | 1.0 B                               |
| DTMF tones   | within $\pm 1.5\%$ of nominal freq. |
| Ringing Voltage  | 48 VDC, typical                     |
| (Ringing voltage is adequate for modern solid state ringers,<br>NOT for the older mechanical type ringers) |                                     |

This Orderwire service does not affect the normal radio transmission of traffic. Refer to Section 2.3.5 for the telephone specifications. For simple near-end to far-end communications, follow the steps below:

1. Using a standard RJ-11 telephone cable, connect a standard electronic telephone (a touch tone phone, complete with dialer; a handset by itself will not work) to the Orderwire connector on the *Tsunami* front panel. This connector is wired identically to a standard two-wire telephone jack, see Figure 3-18 for details.
2. With a telephone connected to each *Tsunami* terminal on opposite ends of the link, either telephone can be used to “dial-up” the far-end location. The far-end terminal’s internal ringer and the connected telephone will ring, and if answered, two-way full-duplex voice communication is established.



*If using the Orderwire or Network management functions, all Tsunami radios connected must have unique address settings (telephone numbers).*

4. If the *Tsunami* radios are connected in a repeater configuration, Orderwire services can be established to all *Tsunami* terminals in the network by implementing a connection of their rear-panel connectors between repeater terminals. At the repeater site, a cable can be connected to the two *Tsunami* terminals between their rear panel VF 9-pin connectors as shown in Figure 3-8. With this cable in place, the Orderwire function will operate at terminals at each end of the repeater and at the repeater site. This function can be continued through several repeater sites if desired. For hub connections of 3 or more *Tsunami* radios at the same site, an external 4-wire bridge is required to connect all radios to the orderwire.



*The orderwire system can be integrated with orderwire equipment supported by many other vendors. If your existing orderwire network uses 2 digit addressing, and 0 dBm VF interface, it can be connected to a Tsunami as shown in Figure 3-8.*



*Dialing a \* (star key) on the orderwire telephone implements an “all call” feature which rings all connected radios. Also, if a phone anywhere in the connected network has accidentally been left off-hook, the # (pound key) key can be used to mute all off-hook handsets until they are placed on and off hook again.*



*The orderwire operates like a “party line”. All telephones provide communication to all other telephones in the connected network. Even if a particular telephone does not ring, it can still be used to talk and listen to any ongoing orderwire activity if the orderwire is in use at other terminal locations.*

Diagrams to be supplied

**VF Connector**

**OrderWire  
Connection**

**Figure 3-8: VF Port Connection**

---

### 3.14.2 Alarm Connections

External alarm outputs are provided at the 9-pin, D-type subminiature ALARM connector. There are two Form C summary alarm relays capable of switching 30 VDC at 1 A. See Table 3-E and Figure 3-9 for Alarm Connections.

The “summary” alarm (Form C relay) is activated by any near-end front panel LED alarm condition, including if the internal test mode is enabled.

The “out-of-service summary” alarm (Form C relay) is activated by any of the following alarm conditions:

- ❖ RF LINK
- ❖ Radio Fail
- ❖ Internal Test

Diagram to be provided

**Figure 3-9: Pin Connections, ALARM Interface**

|              |   |              |   |
|--------------|---|--------------|---|
| <b>PIN 1</b> | <b>NO, SUMMARY ALARM, FORM C</b> - normally open connection on summary alarm relay. Closed when in alarm. | <b>PIN 7</b> | <b>NO, OUT OF SERVICE SUMMARY ALARM, FORM C</b> - normally open connection on out-of-service summary alarm relay. Closed when in alarm. |
| <b>PIN 2</b> | <b>C, SUMMARY ALARM, FORM C</b> - common connection on the summary alarm relay.                           | <b>PIN 8</b> | <b>C, OUT OF SERVICE SUMMARY ALARM, FORM C</b> - common connection for the out-of-service summary alarm relay.                          |
| <b>PIN 3</b> | <b>NC, SUMMARY ALARM, FORM C</b> - normally closed connection on summary alarm relay.                     | <b>PIN 9</b> | <b>NC, OUT OF SERVICE SUMMARY ALARM, FORM C</b> - normally closed connection on out-of-service summary alarm relay. Open when in alarm. |

***Table 3-E: Alarm Interface Connections***

*All alarms are active for a minimum of one second, or as long as the alarm condition persists, which ever is longer.*



---


### 3.14.3 Config Port Operation

The Config Port is used to retrieve diagnostic about the *Tsunami* radios by means of a computer connection.

The config port allows connection of RS-232 devices to poll and receive status of the *Tsunami* radio. The config port provides all front panel alarm and control information and can also provide extended information including some advanced diagnostics and configuration information. Any information that is available on the far-end terminal is also available at the near-end config port (such as far-end RSL, far-end alarms).

### 3.14.3.1 Config Port (RS-232)

For RS-232 diagnostics connection to the *Tsunami* radio, connect the serial device (modem, computer, terminal) to the male 9-pin subminiature connector in accordance with Figure 3-10.



(as viewed from rear panel)

**Figure 3-10: RS-232 Config Port Connections**



*Pins 6 through 9 must not be connected for RS-232 communications to operate properly.*

---

#### **3.14.4 AUX DATA (Digital Service Channel) Connection**

The AUX DATA port is a separate wayside serial port which can be configured to allow the connection of any user serial data (to 9600 baud) through the radio network. Connection to the AUX DATA port is an RS-232 serial interface, identical to the config port (see Section 3.14.3). This port does not affect the Ethernet traffic on the *Tsunami* radio.

## Your Notes on the *Tsunami* Radio



---

## 4. Troubleshooting

### 4.1 Regular Maintenance

The *Tsunami* radios do not require any regular maintenance, however, it is prudent to monitor the radio link at regular intervals to assure that the link conditions are not changing. When visiting a radio site for maintenance, the following items may be checked and their results recorded:

- ❖ RSL Voltage
- ❖ PWR Voltage
- ❖ Far-end RSL Voltage
- ❖ Alarm conditions
- ❖ Verify radio has adequate ventilation

If any alarm conditions exist, they should be recorded, and troubleshooting procedures from this Section of the manual should be followed.

## 4.2 Changing Frequency Plans

The *Tsunami* RF frequency selections are listed in Section 3.5. The near-end radio and the far-end radio must be corresponding (e.g. A1 / A2). The frequency of a given *Tsunami* terminal is set by the specific filter, the physical orientation of this assembly, and a setting within the CONFIG port.

With respect to a given filter, the frequencies are fixed, because tuned RF filters are required for normal operation. Changing of the (pretuned) radio frequencies may be required when installing spares or for special situations, such as interference mitigation. This is accomplished by installing an alternate filter.

For any given model of *Tsunami*, the frequency channel can be changed by swapping the filter.



*It is not necessary to remove the cover assembly of the Tsunami*

1. Remove any cables connected to the antenna connector on the diplexer (filter) and then remove the two screws which mount the filter to the *Tsunami* chassis.
2. Slowly remove the filter from the chassis being careful to not endanger the cables that are connected to the rear side of the filter.
3. Disconnect the two SMA connectors that are attached to the rear of the filter with a 5/16" open end wrench.
4. Select the new filter such that the frequency channel label on the filter corresponds to the desired frequency channel.
5. Connect the two SMA connectors to the new or reoriented filter with the 5/16" open end wrench.
6. Slowly place the wired filter assembly so that it is flush with the rear panel.
7. Install the two screws which mount the filter to the rear panel.
8. Modify the operating frequency as described in the CONFIG menus

---

### 4.3 Using a Spare Terminal

One spare *Tsunami* terminal of a given model type will service any other radio in that same model type, independent of frequency channel plan. For example, a similar model 5.8 GHz channel A2 can be used as a spare for any A or B channel radio at 5.8 GHz. See Section 4.2 for changing frequencies of a spare radio.

Customers with several radios, or radios in critical operations are encouraged to purchase one or more spare radios of each model in their system. This will allow rapid restoration of radio service in the unlikely event of a radio failure.

## 4.4 Technical Support

Glenayre Western Multiplex provides 24-hour telephone technical support for installed *Tsunami* radios. Customers are encouraged to troubleshoot the radio and link in accordance with the latter part of this section in this manual before contacting Glenayre Western Multiplex. Glenayre Western Multiplex also has a limited supply of *Tsunami* radios that can be loaned to out-of-service customers for installation while units are being repaired. Loaner supply is limited, and is only used for critical applications on a first-come, first-served basis.

Customer service #: +1 408 542-5390

## 4.5 Repair Policy

The *Tsunami* terminal includes comprehensive alarm indicators designed to diagnose potential faults. Should a fault occur, it often may be resolved by operator adjustment.

Should a fault occur that cannot be resolved by operator adjustment and has been confirmed by looping terminals together on the bench (See Section 4.9), then the equipment should be returned to the factory for repair.

The *Tsunami* radio is a complex system not designed for user repair. Do not remove the cover or open any part of the *Tsunami* terminal. The complete *Tsunami* terminal should be sent back in its original packing material for factory repair.

Please contact the factory in advance of returning the product. You will be assigned a Return Material Authorization (RMA) number that authorizes your return. Units sent to the factory without an RMA number may be delayed in the processing of the repair. Be sure to include the following information:

- ❖ RMA number
- ❖ description of the problem
- ❖ your name and telephone number
- ❖ return shipping address
- ❖ urgency of repair



*Please refer to the published Warranty policy for repair policy details.*



*Tsunami radios should be packaged in their original packing boxes for shipment whenever possible. Glenayre Western Multiplex can provide an empty box shipment to facilitate proper packaging. Regardless, proper and adequate packaging must be used for shipments to protect the radio(s) from damage. Glenayre Western Multiplex can not be held responsible for any repairs due to inadequately packed materials. Damage caused by improper packing will likely result in higher repair costs and delays (refer to the Warranty section at the beginning of this manual).*

## 4.6 Front Panel Status LEDs

There are several front panel status LEDs on the *Tsunami* radio. These LEDs indicate conditions where either a hardware failure has occurred or the radio link is not optimum. In many cases, a combination of LEDs may be illuminated. The following sections describe the necessary troubleshooting procedures should any LED(s) indicate a problem during or after installation.

#### 4.6.1 RF LINK Alarm

##### Function:

This LED indicates that the demodulator function is not synchronizing with the intended received signal.

##### Possible Causes:

- ❖ Severe path fading due to atmospheric conditions, usually accompanied by low RSL voltage reading
- ❖ Poor transmission line connections usually accompanied by low RSL voltage reading
- ❖ Antenna problems, misalignment, or path clearance usually accompanied by low RSL voltage reading
- ❖ Improper radio settings (e.g. frequency channel)
- ❖ Received signal level (RSL) is too strong
- ❖ Interference
- ❖ Far-End radio transmitter circuitry is faulty
- ❖ Near-End radio receiver circuitry is faulty

##### Recommended Actions:

Check the following at each end of the link:

- ❖ Verify that rear panel filters are opposite channel plans on each end (e.g. one is A1 and other is A2).
- ❖ Verify that rear panel DIP switch settings match each installed filter (see Section 3.12.1).
- ❖ Verify that all connections between radios and antennas are secure and all devices between radios and antennas are rated for the radio frequency band (5.3/5.8 GHz).

Measure RSL by placing a voltmeter across RSL and GND test points. Compare this voltage to the Factory Test Data Sheet and estimate the RSL in dBm. Compare this to the RSL that was expected using path calculations (see Section 3.3.3). Press and hold the DISPLAY FAR END button and measure the far-end RSL (while continuing to hold the button). Compare this RSL to the Factory Test Data Sheet for the far-end radio and estimate the RSL in dBm. Again, compare this RSL to the expected RSL from the link budget calculations.

If RSL from both ends of the radio are approximately the same as each other, but lower than anticipated for this installation, then the likely cause of the BER alarm(s) is excessive losses between the radios. Excessive loss problems could include the transmission line at either end, all adapters, connectors, the antennas, the antenna alignment as well as the path itself (any obstructions or clearance problems). Antenna alignment, line-of-sight and path clearance should be verified; if this does not improve RSL, all devices between the radios and their antennas at both ends should be checked. Make sure all transmission line, connectors and any other devices are properly rated for operation at the radio's frequency (5.3/5.8 GHz).

If only one end has low RSL, this could be caused by low transmit output power from the opposite end radio. Verify that the transmitter output power of the radio opposite to the low RSL receiver has been set in accordance to path calculations, or EIRP restrictions (where applicable). Power adjustment must be performed by professional installation personnel only. The PWR test point can be used and compared with the Factory Test Data Sheet, the front panel recessed potentiometer can be turned clockwise to increase power. If an RF power meter is available, this can be connected to the RF output of the radio for precision measurement. This test will also verify that the radio transmitter is working properly.

If one terminal (or both) has high RSL, this could be caused by a very short path or interference. To verify the possible presence of interference, remove DC power to the radio which is opposite to the one that is reading high RSL. Once power is removed, measure RSL on the remaining radio. If RSL voltage is higher than that which is listed for "Threshold" in the Factory Test Data Sheet, then an interfering signal is present. If interference is suspected, the easiest potential remedy is to swap frequency channels on both sides of the link. See Section 4.2 for details. Swap terminals at both ends of the link so that they are the opposite from their original installation. After both ends are moved, reconnect the radios and determine if the BER alarm is still active. If the BER alarm is still active, other frequency channels can be installed, or other interference countermeasures can be tried, in accordance with Section 4.8.

If all path related and data input problems have been pursued and the BER alarm is still active, the problem could be related to a radio failure. While radio failure is typically indicated by more severe alarm conditions, it is possible that one of the radios may be out of specification, and this could be the cause of the BER alarm. A back-to-back test will verify proper radio operation. See Section 4.9 for details. A threshold test on both radios along with a test to verify proper RF output power would be beneficial.



*Perform a back-to-back test before returning any radio terminal to the factory for repair. A back-to-back test verifies radio operation. (See Section 4.9).*

If the radios successfully pass their back-to-back testing, the problem is likely with the path or the connections between the radio and the antenna or interference. Before reinstalling the radios, be sure to set the output power to the appropriate level for the installation.



---

## 4.6.5 RADIO FAIL Alarm

### Function:

The RADIO FAIL alarm indicates a known problem with the radio hardware.

### Possible Causes:

- ❖ Internal synthesizers are unlocked
- ❖ Internal digital circuits have failed

### Recommended Actions:

1. Remove power from the unit.
2. Check to make sure power supply voltages are within specification.
3. Even if the voltages were within specification, reapply power to the unit.
4. If RADIO FAIL alarm clears, place the radio back into service.
5. If RADIO FAIL alarm does not clear, perform a back-to-back test to verify radio operation, as described in Section 4.9.
6. If RADIO FAIL alarm is still active in a back-to-back test, return the radio to the factory for repair (see Section 4.5).

#### **4.6.6 FAR END Alarm**

**Function:**

This LED indicates that there is an alarm condition present on the far-end radio. When the DISPLAY FAR END button is pressed (and held), the status LEDs indicate the alarm conditions of the far-end radio.

**Possible Cause:**

- ❖ One or more alarm condition(s) exist on the far-end radio

**Recommended Actions:**

1. Press and hold the DISPLAY FAR END button and observe the LED status.
2. Follow instructions for troubleshooting the far-end radio in accordance to the appropriate LEDs which are in alarm, as described in Section 4.6.1 through 4.6.4.

---

## 4.7 Errors in the Data Stream

When the radio is in service, errors in the data stream may occur. This is usually known to the operator by either faulty data indications of downstream equipment or external bit error rate testing.

It is possible that no alarms appear on the front panel during normal operations, but there are errors present in the data stream. Some errors will not result in no alarm (such as bipolar violations, slow "dribbling" errors, improperly terminated connections or incorrect settings), but will be exhibited on downstream data processing equipment or during a BER test. In other cases, there may be data errors due to atmospheric conditions (fading), interference or other reasons, but not at a high enough error level to be indicated with the BER alarm LED. In the case of these types of errors, the following information can be helpful to troubleshoot the radio link.

### Indications:

- ❖ During external BER test, test equipment indicates errors
- ❖ Downstream equipment (mux, channel bank, CODEC, router, etc.) indicates errors

### Possible Causes:

- ❖ Path fading due to atmospheric conditions
- ❖ Poor transmission line connections
- ❖ Antenna problems, misalignment or path clearance
- ❖ Received signal level (RSL) is too strong
- ❖ Far-End radio transmitter circuitry is faulty
- ❖ Near-End radio receiver circuitry is faulty
- ❖ Interference

### Recommended Actions:

1. Verify 100BaseT wiring.
2. Follow the instructions described in Section 4.6.1

## 4.8 Interference Countermeasures

The recommended interference countermeasures available to the *Tsunami* operator are as follows:

### 1. Short Paths

The single most effective countermeasure against interference is to maintain "short path" length. This may be achieved by dividing long paths into multiple small paths by cascading hops. Intermediate repeaters may be formed using back-to-back *Tsunami* terminals and transmit output power reduced, if required.

By definition, "short path" is defined as a path where fades are extremely rare and signal levels vary by no more than  $\pm 3$  dB during fades. This distance will vary with the RF frequency. Typically a "short path" is defined as any path length shorter than 5 miles at 5.8 GHz or 7 miles at 2.4 GHz.

### 2. Narrow Beam Antennas (high gain)

This is the next most effective countermeasure. Narrow beam antennas ensure that the transmitted power is sent in a single direction and this minimizes the possibility of causing interference inadvertently to other users. Narrow beam antennas also reject off-azimuth signals being received from potential sources of interference and have high gain which boosts desired receive levels and improves the carrier to interference ratio. When selecting narrow beam antennas, it is helpful to know that larger antennas generally outperform smaller antennas. Another important antenna specification is the front-to-back ratio which ensures rejection of unwanted signals from azimuth angles behind the antenna.

### 3. Frequency Selection

This is another very effective countermeasure. The *Tsunami* radio offers several distinct non-overlapping frequency channel plans (see Sections 3.5 and 4.2) and the radio's RF filter is able to reject interference more than 10 MHz away from the receive frequency. Offset frequencies combined with other countermeasures may enable several receive channels to operate at a single hub site. Because of the limited spreading ratio used, frequency selection is more efficient than code selection for interference rejection when operating multiple *Tsunami* terminals at a single site. Interference can often be overcome by exchanging frequencies of both-ends of the radio link (e.g. change your A1 terminal to an A2 and change the other end from an A2 to an A1). Also, changing channel plans (e.g. from A to B) can be very effective. (See Section 4.2).

---

#### 4. Antenna Polarization

Cross-polarized antennas can provide approximately 20 to 30 dB discrimination of unwanted signals. The actual discrimination will depend upon the antenna design and any rotation of polarization along the path, for example, due to reflections. Discrimination only exists between two orthogonal polarizations:

- vertical vs. horizontal or
- left-hand circular vs. right-hand circular

There is only 3 dB discrimination between circular and linear (vertical or horizontal) polarization.

Interference can sometimes be overcome by changing antenna polarization at both ends of the link.

#### 5. Transmit Power

The maximum level into the receiver is 0 dBm. Above this level, errors may occur in the receive data stream. Transmit output power should be reduced on very short paths to avoid overload.

#### 6. Equipment/Antenna Location

Occasionally, interference is caused by the radio or the antenna being too close to another similar transmitter. Moving the radio, the antennas, or the interfering equipment can reduce or eliminate interference.



*Interference countermeasures rely to some extent on the measurement of the received interference level and frequency. Prior to turning up a new hop, a spectrum analyzer can be used to monitor the spectrum at each end to check for possible interfering signals. See Section 4.8.1 for more details.*

#### 4.8.1 Use of a Spectrum Analyzer to Evaluate Potential Interference

Connecting to the antenna and using "peak hold" on a spectrum analyzer, the spectrum across the receive frequency range of the radio can be swept and any signals being received at levels above the radio's specified threshold identified. If potential interfering signals are found, then the *Tsunami* frequency plan can be changed to avoid a receive channel which may contain significant interference (see Section 4.2).

For example, interference may be reduced by moving from the A1/A2 plan to the B1/B2 plan or by swapping terminals or RF filters so that A1 becomes A2.



*Signals outside the receiver frequency range may be ignored: they will not cause interference.*

If a spectrum analyzer is not available, the RSL voltage can be used to indicate the background noise and interference level within the receiver RF filter band when the far-end transmitter is turned off. With the far-end radio turned off, if an RSL voltage level above the radio's threshold level is measured, there is potentially interference in this frequency channel.



*When using a spectrum analyzer for determining the presence of interference, very narrow resolution bandwidth settings must be used to detect signals down to the radio's threshold (approximately -87 to -95 dBm, depending on radio type).*

## 4.9 Back-to-Back Testing

Back-to-back testing, as shown in Figure 4-1, is an ideal method of testing the *Tsunami* radios. This testing eliminates link problems caused by auxiliary equipment, installation, or the radio path and isolates potential radio hardware problems. Back-to-back testing must be performed with both radios at the same location. The following test equipment is required:

- ❖ DC power source capable of supplying approximately 90 Watts (total) to the radios (or two AC adapters)
- ❖ One low-loss coaxial cable, N-to-N male
- ❖ One (or more) coaxial in-line calibrated fixed attenuators, 40 to 80 dB total attenuation

The following test equipment may also be useful to perform further testing of the *Tsunami* radio:


- ❖ BER tester
- ❖ Variable (60 dB range or more) RF attenuator (rated for the proper frequency, 2.4 or 5.8 GHz)
- ❖ RF power meter



*Back-to-back testing must be performed to verify a radio problem before returning any radio to the factory for repair.*

When the equipment is connected as shown in Figure 4-1, both *Tsunami* radios should have no alarm conditions. If these conditions have been met, then it is likely that the *Tsunami* radio is operating in accordance to specifications. If errors or alarms occur during this test, verify that all DIP switch settings are properly set. If alarms or errors are still present, the radio is likely to be faulty.

If further troubleshooting is required, a variable RF attenuator can be inserted between the radios to fade down the path to determine that the threshold specification is being met. The threshold tests can be run in both directions to isolate the radio problem (if any). More information testing is provided in Section 4.10. An RF power meter can be used to individually test each radio's output power.



**Figure 4-1: Back-to-Back Test Configuration**



*The Tsunami radios will be damaged if appropriate attenuation is not supplied between radios. You must provide a minimum of 40 dB and no more than 80 dB attenuation between the two radios.*



## 4.10 LINK Testing


Link testing is the preferred way to evaluate a radio link's performance. It can be performed from end-to-end or in link test mode (which tests both directions of the radio path). Figure 4-2 illustrates a typical test configuration (which may include the radio's path instead of in-line attenuators). Figure 4-2 illustrates a typical test configuration for end-to-end testing.

When performing testing, make sure of the following:

- Disconnect all 100BaseT inputs and outputs to both radios.
- Verify all configuration settings.

Link testing may be performed on the bench, with two terminals back to back, or over the radio path. Also, it may be performed from end-to-end (which requires two 100BaseT test sets over a link, the far-end unit slaved to the near-end unit's clock) or in loopback mode, as described in Section 4.9.

If link testing indicates an unacceptable level of errors, follow the instructions in Section 4.6.1. or perform a back-to-back test as described in Section 4.9.



**Figure 4-2: End-to-End Test Configuration**

## Your Notes on the *Tsunami* Radio

## 5. Appendices

### Appendix A - Digital Interface Specifications

#### 1. General Characteristics

100baseT (IEEE 802.3u) Fully compliant to Ethernet V.2

#### 2. Specifications

|                     |   |
|---------------------|---|
| Transmission Medium | UTP   |
| Signaling Technique | Manchester  |
| Topology            | Star  |
| LAN Table           | 10,000 addresses (automatic learning and aging)                 |
| Filtering           | 15,000 pps  |
| Data Rate           | Up to 10 Mbps (limited to throughput of particular radio model) |
| Delay               | 1 frame   |
| Buffer              | 256 frames  |
| Duplex              | Full or half  |

**Table A-1: Interconnection Specification**

## Appendix B – Configuration Port

To be supplied.

---

## Appendix C - Rear Panel Data Connectors

The following figures illustrate the pin structure for all rear panel data connections. All figures are oriented as a customer would view them, facing the rear panel. DC power connection information is found in Section 3.7 of the manual.

To be supplied

### Figure C-1: VF Port Connection

To be supplied

### Figure C-2: Alarm Port Connections

To be supplied

### Figure C-3: Diagnostic Port 9-Pin D-Style Connector

*Do NOT use both the RS-232 and RS-422 connections at the same time!*

To be supplied

### Figure C-4: AUX DATA Port 9-Pin D-Style Connector

*Do NOT use both the RS-232 and RS-422 connections at the same time!*

## Your Notes on the *Tsunami* Radio

# Index

|                                   |   |
|-----------------------------------|---|
| AC.....                           | 3-17  |
| Accessories .....                 | 2-17  |
| Alarm connections .....           | 3-33  |
| Alarms.....                       | 3-28  |
| Alignment, antenna .....          | 3-21  |
| Antenna.....                      | 2-3, 3-3, 3-22, <b>3-28</b> , 4-13                    |
| Antenna connection.....           | 3-18  |
| Antenna installation .....        | 3-20  |
| Antenna planning .....            | 3-10  |
| Availability calculation .....    | 3-7   |
| Bit Error Rate.....               | 3-7   |
| Buffer .....                      | 2-6, 5-1  |
| Calculations .....                | 3-5   |
| Caution.....                      | 1-2   |
| Channel plan .....                | 3-12  |
| Coaxial cable.....                | 3-19  |
| Collisions .....                  | 2-12  |
| Connections .....                 | 2-6, 2-7, 2-14, 2-15, 3-23, 5-1                       |
| Container.....                    | 3-1   |
| DC.....                           | 3-9, 3-15   |
| Delay.....                        | 5-1   |
| Digital Capacity .....            | 2-6   |
| Dispersive fade .....             | 2-4   |
| Duplex.....                       | 5-1   |
| EIRP.....                         | 3-25  |
| <b>Environment</b> .....          | <b>2-8</b>  |
| Errors .....                      | 4-11  |
| Fade margin .....                 | 3-6   |
| Filtering.....                    | 2-6, 5-1  |
| Frequency.....                    | 3-12, <b>4-2</b>                                      |
| Frequency plan.....               | 3-8   |
| Fresnel.....                      | 3-4   |
| Front panel .....                 | 2-10  |
| Grounding .....                   | 3-15  |
| Icons.....                        | 1-2   |
| Installation .....                | 1-1, 2-17, 3-3, 3-24                                  |
| Interference .....                | 4-12  |
| ISO 9000.....                     | i   |
| LAN .....                         | 2-6   |
| Line-of-sight.....                | 3-4   |
| Link budget .....                 | 3-5   |
| Loopback .....                    | 2-6   |
| Mechanical.....                   | 2-9   |
| Mounting.....                     | 3-13  |
| Note .....                        | 1-2   |
| Orderwire .....                   | 2-7, 2-15, 3-24, <b>3-28</b> , <b>3-31</b>            |
| <b>Output power</b> .....         | <b>3-26</b>   |
| <b>Output power, adjust</b> ..... | <b>3-29</b> , <b>3-30</b>                             |
| Path .....                        | 3-4   |
| Path planning .....               | 3-10  |
| Power .....                       | 2-2, <b>2-8</b> , 2-17, 3-3, 3-14, <b>3-30</b> , 4-13 |

|                                 |  |
|---------------------------------|--|
| Power connection.....           | 3-17   |
| Power connection, DC .....      | 3-15   |
| Power supply planning.....      | 3-9  |
| Professional installation ..... | iii, 1-1   |
| Rear panel .....                | 2-16, 5-3  |
| Receive signal level .....      | 2-11, 2-13, 3-3, 3-5, 3-20, 3-21, 3-22, <b>3-27</b> , 4-14 |
| Receiver .....                  | 2-3  |
| Regulatory.....                 | iii, <b>2-9</b>  |
| REN .....                       | 3-31   |
| Repair.....                     | 4-5  |
| RS-232 .....                    | 2-15, 3-35, 3-36, 3-37                                     |
| RSL.....                        | 3-21   |
| Shipping .....                  | 2-17, 3-1  |
| Spares.....                     | 4-3  |
| <b>System</b> .....             | <b>2-4</b> , 2-5   |
| Technical support.....          | 4-4  |
| Telephone .....                 | 3-31   |
| Test .....                      | 2-7, 2-11  |
| Tips .....                      | 1-2  |
| Tools .....                     | 3-11   |
| Transmission line .....         | 3-19   |
| Transmitter.....                | 2-2, 3-29  |
| <b>Troubleshooting</b> .....    | <b>4-1</b>   |
| Turn-up .....                   | 3-24   |
| Warranty.....                   | v  |



For ISO Purposes -  
Last Page of this Manual