

FCC ID: I88PRESTIGE314

# *Prestige 314*

***P314 Broadband Access Gateway With Hub***

## *User's Guide*

Version 3.20

June 2000

**ZyXEL**

TOTAL INTERNET ACCESS SOLUTION

# **Prestige 314**

## **P314 Broadband Access Gateway With Hub**

### **Copyright**

Copyright © 2000 by ZyXEL Communications Corporation.

The contents of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of ZyXEL Communications Corporation.

Published by ZyXEL Communications Corporation. All rights reserved.

### **Disclaimer**

ZyXEL does not assume any liability arising out of the application or use of any products, or software described herein. Neither does it convey any license under its patent rights nor the patent rights of others. ZyXEL further reserves the right to make changes in any products described herein without notice. This publication is subject to change without notice.

### **Trademarks**

Trademarks mentioned in this publication are used for identification purposes only and may be properties of their respective owners.

**Federal Communications Commission (FCC) Interference Statement**

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operations.

This equipment has been tested and found to comply with the limits for a CLASS B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

If this equipment does cause harmful interference to radio/television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**Notice 1**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Notice 2**

Shielded RS-232 cables are required to be used to ensure compliance with FCC Part 15, and it is the responsibility of the user to provide and use shielded RS-232 cables.

**Information for Canadian Users**

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operation, and safety requirements. The Industry Canada does not guarantee that the equipment will operate to a user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly. The customer should be aware that the compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

For their own protection, users should ensure that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**Caution**

Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority or electrician, as appropriate.

**Note**

This digital apparatus does not exceed the class A limits for radio noise emissions from digital apparatus set out in the radio interference regulations of Industry Canada.

# Table of Contents

|  |          |
|--|----------|
| Customer Support .....                                     | viii     |
| Table of Contents .....                                    | ix       |
| List of Figures.....                                       | xvi      |
| List Of Tables .....                                       | xxi      |
| Preface .....  | xxv      |
| <b>Getting Started .....</b>                               | <b>i</b> |
| Chapter 1 Getting to Know Your Prestige.....               | 1-1      |
| 1.1 The Prestige 314 Broadband Access Gateway Hub.....     | 1-1      |
| 1.2 Features of The Prestige 314 .....                     | 1-1      |
| 1.3 Broadband Internet Access via Cable or xDSL Modem..... | 1-3      |
| Chapter 2 Hardware Installation & Initial Setup.....       | 2-1      |
| 2.1 Front Panel LEDs and Back Panel Ports.....             | 2-1      |
| 2.1.1 Front Panel LEDs.....                                | 2-1      |
| 2.2 Prestige 314 Rear Panel and Connections.....           | 2-2      |
| 2.3 Additional Installation Requirements .....             | 2-3      |
| 2.4 Power Up Your Prestige .....                           | 2-4      |
| 2.5 Navigating the SMT Interface .....                     | 2-4      |
| 2.5.1 Main Menu.....                                       | 2-5      |
| 2.5.2 System Management Terminal Interface Summary.....    | 2-6      |
| 2.6 Changing the System Password.....                      | 2-6      |
| 2.6.1 Resetting the Prestige.....                          | 2-7      |
| 2.7 General Setup.....                                     | 2-7      |
| 2.7.1 Dynamic DNS.....                                     | 2-8      |
| 2.7.2 Configuring Dynamic DNS .....                        | 2-9      |
| 2.8 WAN Setup.....   | 2-10     |
| 2.9 LAN Setup.....   | 2-11     |
| 2.9.1 LAN Port Filter Setup.....                           | 2-11     |
| Chapter 3 Internet Access .....                            | 3-2      |

|                                     |   |            |
|-------------------------------------|---|------------|
| 3.1                                 | TCP/IP and DHCP for LAN .....             | 3-2        |
| 3.1.1                               | Factory LAN Defaults .....                | 3-2        |
| 3.1.2                               | IP Address and Subnet Mask.....           | 3-2        |
| 3.1.3                               | Private IP Addresses.....                 | 3-3        |
| 3.1.4                               | RIP Setup.....                            | 3-3        |
| 3.1.5                               | DHCP Configuration .....                  | 3-4        |
| 3.1.6                               | IP Multicast .....                        | 3-4        |
| 3.2                                 | TCP/IP and DHCP Ethernet Setup .....      | 3-5        |
| 3.3                                 | Internet Access Setup .....               | 3-7        |
| 3.3.1                               | Ethernet Encapsulation .....              | 3-7        |
| 3.3.2                               | PPPoE Encapsulation .....                 | 3-9        |
| 3.4                                 | Internet Setup Test.....                  | 3-10       |
| 3.5                                 | Basic Setup Complete.....                 | 3-11       |
| <b>Advanced Applications.....</b>   |   | <b>II</b>  |
| Chapter 4 Remote Node Setup.....    |   | 4-1        |
| 4.1                                 | Remote Node Profile .....                 | 4-1        |
| 4.1.1                               | Ethernet Encapsulation .....              | 4-1        |
| 4.1.2                               | PPPoE Encapsulation .....                 | 4-3        |
| 4.2                                 | Editing TCP/IP Options.....               | 4-4        |
| 4.3                                 | Remote Node Filter .....                  | 4-5        |
| Chapter 5 IP StaticRoute Setup..... |   | 5-1        |
| 5.1                                 | IP Static Route Setup.....                | 5-2        |
| Chapter 6 SUA Server Setup.....     |   | 6-1        |
| 6.1                                 | Single User Account (SUA) .....           | 6-1        |
| 6.1.1                               | Single User Account Configuration.....    | 6-2        |
| 6.1.2                               | SUA Connections and Idle Timeout.....     | 6-3        |
| 6.2                                 | Multiple Servers Behind SUA.....          | 6-3        |
| 6.2.1                               | Configuring a Server behind SUA.....      | 6-4        |
| <b>Advanced Management .....</b>    |   | <b>III</b> |
| Chapter 7 Filter Configuration..... |   | 7-1        |
| 7.1                                 | About Filtering .....                     | 7-1        |
| 7.1.1                               | The Filter Structure of the Prestige..... | 7-2        |
| 7.2                                 | Configuring a Filter Set .....            | 7-4        |

|            |   |      |
|------------|---|------|
| 7.2.1      | Filter Rules Summary Menu .....                 | 7-6  |
| 7.2.2      | Configuring a Filter Rule .....                 | 7-7  |
| 7.2.3      | TCP/IP Filter Rule .....                        | 7-7  |
| 7.2.4      | Generic Filter Rule.....                        | 7-12 |
| 7.3        | Example Filter .....                            | 7-14 |
| 7.4        | Filter Types and SUA .....                      | 7-16 |
| 7.5        | Applying a Filter and Factory Defaults.....     | 7-17 |
| 7.5.1      | LAN traffic .....                               | 7-17 |
| 7.5.2      | Remote Node Filters .....                       | 7-18 |
| Chapter 8  | System Information & Diagnosis.....             | 8-1  |
| 8.1        | System Status.....                              | 8-2  |
| 8.2        | System Information and Console Port Speed ..... | 8-4  |
| 8.2.1      | System Information.....                         | 8-4  |
| 8.2.2      | Console Port Speed.....                         | 8-5  |
| 8.3        | Log and Trace.....                              | 8-5  |
| 8.3.1      | Viewing Error Log.....                          | 8-6  |
| 8.3.2      | UNIX Syslog.....                                | 8-6  |
| 8.3.3      | Call-Triggering Packet.....                     | 8-9  |
| 8.4        | Diagnostic .....                                | 8-10 |
| 8.4.1      | WAN DHCP .....                                  | 8-11 |
| Chapter 9  | Transferring Files .....                        | 9-1  |
| 9.1        | Filename conventions .....                      | 9-1  |
| 9.1.1      | Firmware Development .....                      | 9-2  |
| 9.2        | Backup Configuration.....                       | 9-2  |
| 9.3        | Restore Configuration.....                      | 9-4  |
| 9.4        | Upload Firmware .....                           | 9-5  |
| 9.4.1      | Uploading the Router Firmware .....             | 9-5  |
| 9.4.2      | Uploading Router Configuration File .....       | 9-6  |
| 9.5        | TFTP File Transfer .....                        | 9-7  |
| 9.5.1      | Example TFTP Command .....                      | 9-8  |
| 9.6        | FTP File Transfer.....                          | 9-9  |
| 9.6.1      | Using the FTP command from the DOS Prompt ..... | 9-10 |
| Chapter 10 | System Maintenance & Information .....          | 10-1 |

|  |  |           |
|--|--|-----------|
| 10.1   | Command Interpreter Mode .....             | 10-1      |
| 10.2   | Call Control Support.....                  | 10-2      |
| 10.2.1   | Budget Management.....                     | 10-2      |
| 10.2.2   | Call History .....                         | 10-3      |
| 10.3   | Boot Commands .....                        | 10-4      |
| Chapter 11   | Telnet Configuration and Capabilities..... | 11-1      |
| 11.1   | About Telnet Configuration.....            | 11-1      |
| 11.2   | Telnet Under SUA.....                      | 11-1      |
| 11.3   | Telnet Capabilities.....                   | 11-1      |
| 11.3.1   | Single Administrator.....                  | 11-1      |
| 11.3.2   | System Timeout.....                        | 11-2      |
| 11.3.3   | Telnet Blocking .....                      | 11-2      |
| <b>Troubleshooting, Appendices, Glossary and Index .....</b> |  | <b>IV</b> |
| Chapter 12   | Troubleshooting.....                       | 12-1      |
| 12.1   | Problems Starting Up the Prestige.....     | 12-1      |
| 12.2   | Problems with the LAN Interface.....       | 12-2      |
| 12.3   | Problems with the WAN interface.....       | 12-3      |
| 12.4   | Problems with Internet Access .....        | 12-4      |
| 12.5   | Problems with Telnet.....                  | 12-4      |
| Appendix A   | PPPoE.....                                 | A         |
| Appendix B   | Hardware Specifications .....              | C         |
| Appendix C   | Important Safety Instructions .....        | E         |
| Appendix D   | Power Adapter Specs.....                   | F         |
| Glossary of Terms  | .....                                      | H         |
| Index.....   | .....                                      | O         |



---

# Part I:

---

## Getting Started

---

Chapters 1-3 are structured as a step-by-step guide to help you connect, install and setup your Prestige to operate on your network and access the Internet.

# Chapter 1

## Getting to Know Your Prestige

*This chapter introduces the main features and applications of the Prestige.*

### **1.1 The Prestige 314 Broadband Access Gateway With Hub**

The Prestige 314 is a dual Ethernet Broadband Access Gateway with an integrated 4-port hub and advanced network management features. It is designed for home offices and small businesses to easily and quickly access the Internet via Cable/ADSL modem or broadband router. ZyXEL's Prestige 314 provides not only ease of installation and Internet access, but also a complete solution to efficiently manage data traffic on your network. The embedded web configurator is a breeze to operate and totally independent of the operating system platform you use.

### **1.2 Features of The Prestige 314**

The following are the essential features of the Prestige 314.

#### **Broadband WAN Connection with Integrated Four Port Hub**

The P314 sports a 10Mbps Ethernet port for a cable or xDSL modem connection as well as an integrated hub allowing up to 4 computers on your network to enjoy super-fast Internet access without the need for an additional hub.

#### **Dynamic DNS Support**

With Dynamic DNS support, you can have a static hostname alias for a dynamic IP address, allowing the host to be more easily accessible from various locations on the Internet. You must register for this service with a Dynamic DNS client to use this service.

#### **IP Multicast**

Traditionally, IP packets are transmitted in two ways - unicast or broadcast. Multicast is a third way to deliver IP packets to a group of hosts. IGMP (Internet Group Management Protocol) is the protocol used to support multicast groups. The latest version is version 2 (see RFC2236). Both versions 1 and 2 are supported by the Prestige.

#### **Packet Filtering**

The Packet Filtering mechanism blocks unwanted traffic from entering/leaving your network.

#### **PPPoE**

PPPoE facilitates the interaction of a host with a broadband modem to achieve access to high-speed data networks via a familiar "dial-up networking" user interface.

### **Dynamic DNS Support**

With Dynamic DNS support, you can have a static hostname alias for a dynamic IP address, allowing the host to be more easily accessible from various locations on the Internet.

If you want to utilize this service, you must register for this service with a Dynamic DNS client.

### **PPTP Support**

Point-to-Point Tunneling Protocol (PPTP) is a network protocol that enables secure transfer of data from a remote client to a private server, creating a Virtual Private Network (VPN) using TCP/IP-based networks. PPTP supports on-demand, multi-protocol, and virtual private networking over public networks, such as the Internet.

### **Full Network Management**

Your Prestige offers you a variety of options for network management. It supports password protected local and remote network management via the console port or a telnet connection using SMT (System Management Interface) or the Embedded Web Configurator. It also supports FTP (File Transfer Protocol) server for remote management, TFTP (Trivial FTP), SNMP (Simple Network Management Protocol) and CI (Command Interpreter) mode.

### **Auto-negotiating 10/100Mbps Ethernet**

The LAN interface automatically detects if it's on a 10 or a 100 Mbps Ethernet.

### **Single User Account (SUA)**

SUA is ZyXEL's version of NAT (Network Address Translation) which enables multiple users to share a single ISP account, thereby accessing the Internet for the cost of a single IP address.

### **DHCP (Dynamic Host Configuration Protocol)**

The Prestige supports DHCP Server and Client (RFC 2131 and RFC 2132). The Prestige's DHCP server capability allows you to automatically assign TCP/IP settings to a workstation on your LAN. The Prestige's DHCP client capability allows it to get automatically its IP address from the ISP on the WAN.

### **RoadRunner Support**

In addition to standard cable modem services, the Prestige supports Time Warner's RoadRunner Service.

### **Logging and Tracing**

The Prestige has the following features:

- ◆ Built-in message logging and packet tracing.
- ◆ Unix syslog facility support.

### **Upgrade Prestige Firmware via LAN**

The firmware of the Prestige 314 can be upgraded via the LAN.

### **Embedded FTP and TFTP Servers**

The Prestige's embedded FTP and TFTP servers enable faster firmware upgrade as well as configuration file backup and restoration.

### 1.3 Broadband Internet Access via Cable or xDSL Modem

A cable modem or xDSL modem can be connected to the Prestige 10M WAN Ethernet port and up to four computers can be connected to the four Prestige 10/100M LAN Ethernet ports for super-fast broadband Internet access. The Prestige provides not only the high speed Internet access but also a complete solution to efficiently manage data traffic on your network.




Figure 1-1 Internet Access

# Chapter 2


## Hardware Installation & Initial Setup

*This chapter shows you how to connect the hardware and perform the initial setup.*

### 2.1 Front Panel LEDs and Back Panel Ports

#### 2.1.1 Front Panel LEDs

The LEDs on the front panel indicate the operational status of the Prestige.



**Figure 2-1 Front Panel**

The following table describes the LED functions:

**Table 2-1 LED functions**

| LEDs     | Function | Indicator Status | Active   | Description                                     |
|----------|----------|------------------|----------|---|
| PWR      | Power    | Green            | On       | The power adapter is connected to the Prestige. |
| SYS      | System   |                  | Off      | The system is not ready or failed.              |
|          |          |                  | On       | The system is ready and running.                |
|          |          |                  | Flashing | The system is rebooting.                        |
| 10M LAN  | LAN      | Green            | Off      | The 10M LAN is not connected.                   |
|          |          |                  | On       | The Prestige is connected to a 10M LAN.         |
|          |          |                  | Flashing | The 10M LAN is sending/receiving packets.       |
| 100M LAN |          | Orange           | Off      | The 100M LAN is not connected.                  |
|          |          |                  | On       | The Prestige is connected to a 100Mbps LAN.     |
|          |          |                  | Flashing | The 100M LAN is sending/receiving packets.      |

| LEDs | Function | Indicator Status | Active   | Description                                    |
|------|----------|------------------|----------|--|
| WAN  | WAN      | Green            | Off      | The WAN Link is not ready, or has failed.      |
|      |          |                  | On       | The WAN Link is ok.                            |
|      |          |                  | Flashing | The 10M WAN link is sending/receiving packets. |

## 2.2 Prestige 314 Rear Panel and Connections

The following figure shows the rear panel of your Prestige 314 and the connection diagram.




Figure 2-2 Prestige Rear Panel and Connections


This section outlines how to connect your Prestige 314 to the LAN and the WAN. In the case of connecting a Cable Modem you must connect the coaxial cable from your cable service to the threaded coaxial cable connector on the back of the cable modem. Connect an xDSL Modem to the xDSL Wall Jack. Please also see *Appendix C* for important safety instructions on making connections to the Prestige.

### Step 1. Connecting the Console Port

For the initial configuration of your Prestige, you need to use terminal emulator software on a workstation and connect it to the Prestige through the console port. Connect the 9-pin (smaller) end of the console cable to the console port of the Prestige and the 25-pin (bigger) end to a serial port (COM1, COM2 or other COM

## Appendix B Hardware Specifications

|                                |  |
|--------------------------------|--|
| Power Specification            | I/P AC 120V / 60Hz ; O/P DC 12V 1200 mA  |
| MTBF                           | 100000 hrs   |
| Operation Temperature          | 0° C ~ 40° C   |
| Ethernet Specification for WAN | 10Mbit Half Duplex   |
| Ethernet Specification for LAN | 10/100 Mbit Half / Full Auto-negotiation   |
| Console Port RS – 232          | Pin 1 = NON ; Pin 2 = DTE-RXD; Pin 3 = DTE-TXD; Pin 4 = DTE-DTR; Pin 5 = GND; Pin 6 = DTE-DSR; Pin 7 = DTE-RTS; Pin 8 = DTE-CTS; PIN 9 = NON. See Figure below |



| WAN/LAN Cable Pin Layout: |           |           |          |
|---------------------------|-----------|-----------|----------|
| Straight-Through          |           | Crossover |          |
| (Switch)                  | (Adapter) | (Switch)  | (Switch) |
| 1 IRD +                   | 1 OTD +   | 1 IRD +   | 1 IRD +  |
| 2 IRD -                   | 2 OTD -   | 2 IRD -   | 2 IRD -  |
| 3 OTD +                   | 3 IRD +   | 3 OTD +   | 3 OTD +  |
| 6 OTD -                   | 6 IRD -   | 6 OTD -   | 6 OTD -  |

## Appendix C

# Important Safety Instructions

The following safety instructions apply to the Prestige:

1. Be sure to read and follow all warning notices and instructions.
2. The maximum recommended ambient temperature for the Prestige is 40°C (104°F). Care must be taken to allow sufficient air circulation or space between units when the Prestige is installed inside a closed rack assembly. The operating ambient temperature of the rack environment might be greater than room temperature.
3. Installation in a rack without sufficient airflow can be unsafe.
4. Racks should safely support the combined weight of all equipment.
5. The connections and equipment that supply power to the Prestige should be capable of operating safely with the maximum power requirements of the Prestige. In case of a power overload, the supply circuits and supply wiring should not become hazardous. The input rating of the Prestige is printed on the nameplate.
6. The AC adapter must plug in to the right supply voltage, i.e. 120VAC adapter for North America and 230VAC adapter for Europe. Make sure that the supplied AC voltage is correct and stable. If the input AC voltage is over 10% lower than the standard may cause the Prestige to malfunction.
7. Installation in restricted access areas must comply with Articles 110-16, 110-17, and 110-18 of the National Electrical Code, ANSI/NFPA 70.
8. Do not allow anything to rest on the power cord of the AC adapter, and do not locate the product where anyone can walk on the power cord.
9. Do not service the product by yourself. Opening or removing covers can expose you to dangerous high voltage points or other risks. Refer all servicing to qualified service personnel.
10. Generally, when installed after the final configuration, the product must comply with the applicable safety standards and regulatory requirements of the country in which it is installed. If necessary, consult the appropriate regulatory agencies and inspection authorities to ensure compliance.
11. A rare condition can create a voltage potential between the earth grounds of two or more buildings. If products installed in separate building are interconnected, the voltage potential can cause a hazardous condition. Consult a qualified electrical consultant to determine whether or not this phenomenon exists and, if necessary, implement corrective action before interconnecting the products. If the equipment is to be used with telecommunications circuit, take the following precautions:
  - Never install telephone wiring during a lightning storm.
  - Never install telephone jacks in a wet location unless the jack is specially designed for wet locations.
  - Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
  - Use caution when installing or modifying telephone lines (other than a cordless telephone) during an electrical storm. There is a remote risk of electric shock from lightning.



## Appendix D Power Adapter Specs

---

### AC Power Adapter Specifications

---

#### North America

---

AC Power Adapter model MW48-1201200

Input power: AC120Volts/60Hz

Output power: DC12Volts/1.2A

Power consumption: 9 W

Plug: North American standards

Safety standards: UL, CUL (UL 1310, CSA C22.2 No.233-M91)

---

AC Power Adapter model AD48-1201200DUY

Input power: AC120Volts/60Hz

Output power: DC12Volts/1.2A

Power consumption: 9 W

Plug: North American standards

Safety standards: UL, CUL (UL1950, CSA C22.2 NO. 234-M90)

---

#### European Union

---

AC Power Adapter model AD-1201200DV

Input power: AC230Volts/50Hz,

Output power: DC12Volts/1.2A

Power consumption: 9 W

Plug: European Union standards

Safety standards: TUV, CE (EN 60950)

---

AC Power Adapter model JAD-121200E

Input power: AC230Volts/50Hz,

Output power: DC12Volts/1.2A

Power consumption: 9 W

Plug: European Union standards

Safety standards: TUV, CE (EN 60950)

---

#### UK

---

AC Power Adapter model AD-1201200DK

Input power: AC230Volts/50Hz,

Output power: DC12Volts/1.2A

Power consumption: 9 W

Plug: United Kingdom standards

Safety standards: TUV, CE (EN 60950, BS7002)

---

---

Japan

AC Power Adapter model JOD-48-1124  
Input power: AC100Volts/ 50/60Hz/ 27VA  
Output power: DC12Volts/1.2A  
Power consumption: 9 W  
Plug: Japan standards  
Safety standards: T-Mark

---

Australia and New Zealand

AC Power Adapter model AD-1201200DS  
Input power: AC240Volts/50Hz/0.2A  
Output power: DC12Volts/1.2A  
Power consumption: 9 W  
Plug: Australia and New Zealand standards  
Safety standards: NATA (AS 3260)

---